

JESS Thermodynamic Database v8.9

Calcium

24-Jan-23

Reaction No. 32							
Ca+2 + OH-1 = Ca+2_OH-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:1.37 (3SF)	3	MSL	12002
Note (1): p. 411							
2	5	1	NaCl	lgK:0.08 (1SF)	0	MSL	29203
3	10	0	Inf. Dilution	lgK:1.205 (4SF)	4	MDG	5416
4	15	0	Inf. Dilution	lgK:1.34 (3SF)	3	MHY	5078
5	15	0	Seawater	lgK:1.34 (3SF)	4	MEF	5416
6	25	0	Inf. Dilution	lgK:1.4 (0.05SD)	3	CMN	457
7	25	0	Inf. Dilution	lgK:1.37 (3SF)	5	MHY	5078
8	25	0	Inf. Dilution	lgK:1.1925 (5SF)	3	MDG	5416
9	25	0	Inf. Dilution	lgK:1.2 (0.05SD)	3	CMN	5484
10	25	0	Inf. Dilution	lgK:1.15 (3SF)	3	CRV	6405
11	25	0	Inf. Dilution	lgK:1.3 (0.1SD)	5	CMN	7391
12	25	0	Inf. Dilution	lgK:1.15 (3SF)	3	ENS	7391
13	25	0	Inf. Dilution	lgK:1.38 (3SF)	4	ENS	7391
14	25	0	Inf. Dilution	lgK:1.51 (3SF)	3	MCN	11989
15	25	0	Inf. Dilution	lgK:1.40 (3SF)	5	MSL	12002
Note (15): p. 411							
16	25	0	Inf. Dilution	lgK:1.3 (2SF)	3	EOD	16981
17	25	0	Inf. Dilution	lgK:1.39 (3SF)	3	EOD	31694
Note (17): from Davies & Hoyle, 1951							
18	25	0	SOLMNEQ	lgK:1.23 (3SF)	4	CMN	5416
19	25	0	SOLVEQ	lgK:1.39 (3SF)	4	CMN	5416
20	25	0	Seawater	lgK:1.37 (3SF)	0	MEF	5416
21	25	0	WATCH	lgK:1.22 (3SF)	4	CMN	5416
22	25	0	WATEQF	lgK:1.40 (3SF)	4	CMN	5416
23	25	0.05	Cl-1 salt	lgK:1.0 (0.06SD)	4	CMN	457
24	25	0.05	Cl-1 salt	lgK:1.0 (0.06SD)	5	CMN	457
25	25	0.1	Cl-1 salt	lgK:1. (0.06SD)	3	CMN	457

26	25	0.1	Me4N+ salt	lgK:0.96 (2SF)	6	CRV	552
27	25	0.7	Unknown	lgK:0.74 (0.08SD)	3	EES	7391
28	25	1	NaCl	lgK:0.18 (2SF)	0	MSL	29203
29	25	3	NaClO4	lgK:0.86 (2SF)	5	CRV	2556
30	25	4	NaCl	lgK:0.34 (2SF)	0	MSL	29203
31	35	0	Inf. Dilution	lgK:1.40 (3SF)	4	MHY	5078
32	35	0	Seawater	lgK:1.40 (3SF)	4	MEF	5416
33	37	0	Inf. Dilution	lgK:1.38 (3SF)	2	CRV	28703
34	40	0	Inf. Dilution	lgK:1.4125 (5SF)	4	MDG	5416
35	40	0	Inf. Dilution	lgK:1.48 (3SF)	5	MSL	12002
Note (35): p. 411							
36	50	0	SOLMNEQ	lgK:1.35 (3SF)	4	CMN	5416
37	50	0	SOLVEQ	lgK:1.48 (3SF)	4	CMN	5416
38	50	0	WATCH	lgK:1.33 (3SF)	4	CMN	5416
39	50	0	WATEQF	lgK:1.47 (3SF)	4	CMN	5416
40	50	1	NaCl	lgK:0.43 (2SF)	0	MSL	29203
41	75	0	SOLMNEQ	lgK:1.50 (3SF)	4	CMN	5416
42	75	0	WATCH	lgK:1.45 (3SF)	4	CMN	5416
43	75	0	WATEQF	lgK:1.53 (3SF)	5	CMN	5416
44	75	1	NaCl	lgK:0.48 (2SF)	0	MSL	29203
45	100	0	SOLMNEQ	lgK:1.62 (3SF)	4	CMN	5416
46	100	0	SOLVEQ	lgK:1.77 (3SF)	4	CMN	5416
47	100	0	WATCH	lgK:1.58 (3SF)	4	CMN	5416
48	100	0	WATEQF	lgK:1.58 (3SF)	4	CMN	5416
49	125	0	SOLMNEQ	lgK:1.78 (3SF)	4	CMN	5416
50	125	0	WATCH	lgK:1.72 (3SF)	4	CMN	5416
51	125	0	WATEQF	lgK:1.62 (3SF)	4	CMN	5416
52	150	0	SOLMNEQ	lgK:1.95 (3SF)	4	CMN	5416
53	150	0	SOLVEQ	lgK:2.12 (3SF)	0	CMN	5416
54	150	0	WATCH	lgK:1.86 (3SF)	4	CMN	5416
55	150	0	WATEQF	lgK:1.66 (3SF)	3	CMN	5416
56	175	0	SOLMNEQ	lgK:2.12 (3SF)	3	CMN	5416
57	175	0	WATCH	lgK:2.02 (3SF)	3	CMN	5416
58	175	0	WATEQF	lgK:1.69 (3SF)	0	CMN	5416
59	200	0	SOLMNEQ	lgK:2.30 (3SF)	0	CMN	5416
60	200	0	SOLVEQ	lgK:2.64 (3SF)	0	CMN	5416

61	200	0	WATCH	lgK:2.18 (3SF)	3	CMN	5416
62	200	0	WATEQF	lgK:1.72 (3SF)	0	CMN	5416
63	225	0	SOLMNEQ	lgK:2.49 (3SF)	0	CMN	5416
64	225	0	WATCH	lgK:2.36 (3SF)	0	CMN	5416
65	225	0	WATEQF	lgK:1.75 (3SF)	0	CMN	5416
66	250	0	SOLMNEQ	lgK:2.70 (3SF)	0	CMN	5416
67	250	0	SOLVEQ	lgK:3.44 (3SF)	0	CMN	5416
68	250	0	WATCH	lgK:2.54 (3SF)	0	CMN	5416
69	250	0	WATEQF	lgK:1.78 (3SF)	0	CMN	5416
70	275	0	SOLMNEQ	lgK:2.93 (3SF)	0	CMN	5416
71	275	0	WATCH	lgK:2.73 (3SF)	0	CMN	5416
72	275	0	WATEQF	lgK:1.80 (3SF)	0	CMN	5416
73	300	0	SOLMNEQ	lgK:3.20 (3SF)	0	CMN	5416
74	300	0	SOLVEQ	lgK:4.88 (3SF)	0	CMN	5416
75	300	0	WATCH	lgK:2.93 (3SF)	0	CMN	5416
76	300	0	WATEQF	lgK:1.82 (3SF)	0	CMN	5416
77	325	0	SOLMNEQ	lgK:3.52 (3SF)	0	CMN	5416
78	325	0	WATCH	lgK:3.14 (3SF)	0	CMN	5416
79	325	0	WATEQF	lgK:1.84 (3SF)	0	CMN	5416
80	350	0	SOLMNEQ	lgK:3.90 (3SF)	0	CMN	5416
81	350	0	WATCH	lgK:3.35 (3SF)	0	CMN	5416
82	350	0	WATEQF	lgK:1.85 (3SF)	0	CMN	5416
83	25	0	Inf. Dilution	dH:2. (0.3SD)	4	CMN	457
84	25	0	Inf. Dilution	dH:2. (0.3SD)	5	CMN	457
85	25	0	Seawater	dH:1.25 (3SF)	0	MTD	5416

Reaction No. 33							
Ca+2 + 2<OH-1> = Ca+2_OH-1(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	1	NaCl	lgK:3.886 (4SF)	2	MSL	29203
2	25	0	Inf. Dilution	lgK:5.3 (2SF)	1	ELC	
3	25	0	Inf. Dilution	lgK:5.1 (0.1SD)	2	CMN	19
4	25	0	Inf. Dilution	lgK:5.3 (2SF)	3	CRV	6330
Note (4): p. 8-58							
5	25	0	Inf. Dilution	lgK:5.19 (3SF)	3	CRV	6405
6	25	0	Inf. Dilution	lgK:5.06 (3SF)	3	EOD	16981

7	25	0	Inf. Dilution	lgK:5.102 (4SF)	2	CRV	22551
8	25	0	Inf. Dilution	lgK:5.20 (3SF)	2	CRV	28992
9	25	0	Inf. Dilution	lgK:5.4 (2SF)	2	EOD	29070
10	25	0	Inf. Dilution	lgK:5.1 (2SF)	3	EOD	31694
Note (10): from Greenberg & Copeland, 1960							
11	25	1	NaCl	lgK:4.056 (4SF)	2	MSL	29203
12	25	1	Unknown	lgK:4.29 (3SF)	0	ENS	773
13	25	4	NaCl	lgK:4.523 (4SF)	2	MSL	29203
14	50	0	Inf. Dilution	lgK:5.52 (3SF)	0	CRV	28992
15	50	1	NaCl	lgK:4.387 (4SF)	2	MSL	29203
16	75	1	NaCl	lgK:4.620 (4SF)	2	MSL	29203
17	100	0	Inf. Dilution	lgK:6.30 (3SF)	0	CRV	28992
18	150	0	Inf. Dilution	lgK:7.32 (3SF)	0	CRV	28992
19	200	0	Inf. Dilution	lgK:8.47 (3SF)	0	CRV	28992
20	250	0	Inf. Dilution	lgK:9.77 (3SF)	0	CRV	28992
21	25	0	Inf. Dilution	dG:-7.100 (4SF)	5	CRV	26078
22	25	0	Inf. Dilution	dH:4.3 (2SF)	2	CRV	2556
Note (22): Changed signed							
23	25	0	Inf. Dilution	dH:4.290 (4SF)	5	CRV	26078

Reaction No. 34							
NH3 + Ca+2 = Ca+2_NH3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.06929 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:0.1 (0.05SD)	4	MDS	5084
3	25	0	Inf. Dilution	lgK:-0.10 (2SF)	3	CRV	9402
4	25	0.5	NH4ClO4	lgK:0.05 (0.05SD)	5	MDS	5084
5	25	0.5	Unknown	lgK:0.1 (1SF)	6	CRV	552
6	25	1	Unknown	lgK:0.0 (1SF)	6	CRV	552
7	23	2	NH4NO3	lgR:-0.2 (0.1SD)	5	MGL	53
8	25	1	NH4ClO4	lgR:-0.03 (0.05SD)	5	MDS	5084
9	25	1.5	NH4ClO4	lgR:-0.1 (0.05SD)	5	MDS	5084

Reaction No. 35							
2<NH3> + Ca+2 = Ca+2_NH3 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0	Inf. Dilution	lgK:-0.4857 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:-0.70 (2SF)	3	CRV	9402
3	25	0.5	Unknown	lgK:-0.3 (1SF)	5	CRV	2556
4	25	1	Unknown	lgK:-0.5 (1SF)	5	CRV	2556
5	22	2	NH4NO3	lgR:-0.8 (1SF)	5	CRV	2556
6	25	0.5	NH4ClO4	lgR:-0.28 (2SF)	4	MDS	5084

Reaction No. 36							
SO4-2 + Ca+2 = Ca+2_SO4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	P=100 Inf. Dilution	lgK:2.10 (3SF)	3	ENS	18070
2	15	0	P=250 Inf. Dilution	lgK:2.271 (4SF)	5	MCN	28080
3	25	0	P=250 Inf. Dilution	lgK:2.304 (4SF)	5	MCN	28080
4	35	0	P=250 Inf. Dilution	lgK:2.336 (4SF)	5	MCN	28080
5	15	0	P=500 Inf. Dilution	lgK:2.230 (4SF)	5	MCN	28080
6	25	0	P=500 Inf. Dilution	lgK:2.266 (4SF)	5	MCN	28080
7	35	0	P=500 Inf. Dilution	lgK:2.301 (4SF)	5	MCN	28080
8	15	0	P=750 Inf. Dilution	lgK:2.194 (4SF)	5	MCN	28080
9	25	0	P=750 Inf. Dilution	lgK:2.231 (4SF)	5	MCN	28080
10	35	0	P=750 Inf. Dilution	lgK:2.270 (4SF)	5	MCN	28080
11	15	0	P=1000 Inf. Dilution	lgK:2.162 (4SF)	5	MCN	28080
12	25	0	P=1000 Inf. Dilution	lgK:2.202 (4SF)	5	MCN	28080
13	35	0	P=1000 Inf. Dilution	lgK:2.240 (4SF)	5	MCN	28080
14	100	0	P=1000 Inf. Dilution	lgK:2.4 (2SF)	4	EOD	6495
15	150	0	P=1000 Inf. Dilution	lgK:2.7 (2SF)	4	EOD	6495
16	200	0	P=1000 Inf. Dilution	lgK:3.06 (3SF)	4	EOD	6495

17	250	0	P=1000 Inf. Dilution	lgK:3.49 (3SF)	4	EOD	6495
18	300	0	P=1000 Inf. Dilution	lgK:4. (1SF)	3	EOD	6495
19	15	0	P=1250 Inf. Dilution	lgK:2.136 (4SF)	5	MCN	28080
20	25	0	P=1250 Inf. Dilution	lgK:2.174 (4SF)	5	MCN	28080
21	35	0	P=1250 Inf. Dilution	lgK:2.214 (4SF)	5	MCN	28080
22	15	0	P=1500 Inf. Dilution	lgK:2.109 (4SF)	5	MCN	28080
23	25	0	P=1500 Inf. Dilution	lgK:2.150 (4SF)	5	MCN	28080
24	35	0	P=1500 Inf. Dilution	lgK:2.190 (4SF)	5	MCN	28080
25	100	0	P=2000 Inf. Dilution	lgK:2.4 (2SF)	4	EOD	6495
26	150	0	P=2000 Inf. Dilution	lgK:2.64 (3SF)	4	EOD	6495
27	200	0	P=2000 Inf. Dilution	lgK:2.9 (2SF)	4	EOD	6495
28	250	0	P=2000 Inf. Dilution	lgK:3.2 (2SF)	4	EOD	6495
29	300	0	P=2000 Inf. Dilution	lgK:3.53 (3SF)	3	EOD	6495
30	100	0	P=3000 Inf. Dilution	lgK:2.46 (3SF)	4	EOD	6495
31	150	0	P=3000 Inf. Dilution	lgK:2.65 (3SF)	4	EOD	6495
32	200	0	P=3000 Inf. Dilution	lgK:2.84 (3SF)	4	EOD	6495
33	250	0	P=3000 Inf. Dilution	lgK:3.05 (3SF)	4	EOD	6495
34	300	0	P=3000 Inf. Dilution	lgK:3.28 (3SF)	3	EOD	6495
35	100	0	P=4000 Inf. Dilution	lgK:2.56 (3SF)	4	EOD	6495
36	150	0	P=4000 Inf. Dilution	lgK:2.7 (2SF)	4	EOD	6495
37	200	0	P=4000 Inf. Dilution	lgK:2.84 (3SF)	4	EOD	6495
38	250	0	P=4000 Inf. Dilution	lgK:2.99 (3SF)	4	EOD	6495
39	300	0	P=4000 Inf. Dilution	lgK:3.14 (3SF)	3	EOD	6495

40	100	0	P=5000 Inf. Dilution	lgK:2.69 (3SF)	4	EOD	6495
41	150	0	P=5000 Inf. Dilution	lgK:2.8 (2SF)	4	EOD	6495
42	200	0	P=5000 Inf. Dilution	lgK:2.89 (3SF)	4	EOD	6495
43	250	0	P=5000 Inf. Dilution	lgK:2.98 (3SF)	4	EOD	6495
44	300	0	P=5000 Inf. Dilution	lgK:3.08 (3SF)	3	EOD	6495
45	0	0	Inf. Dilution	lgK:2.10 (3SF)	4	MCN	83
46	0	0	Inf. Dilution	lgK:2.375 (4SF)	3	MFP	140
47	0	0	Inf. Dilution	lgK:2.22 (3SF)	4	MSL	140
48	0	0	Inf. Dilution	lgK:2.44 (3SF)	4	EMU	5398
49	0	0	Inf. Dilution	lgK:1.98 (3SF)	0	MAC	5416
50	0	0	Inf. Dilution	lgK:2.10 (3SF)	0	MCN	5416
51	0	0	Inf. Dilution	lgK:2.07 (3SF)	4	EOD	6495
52	0	0	Inf. Dilution	lgK:2.44 (3SF)	4	MDG	8675
53	0	0	Inf. Dilution	lgK:2.22 (3SF)	5	MSL	12002
Note (53): p. 411							
54	0	0.47	NaClO4/m	lgK:1.13 (3SF)	0	MSL	369
55	0	1.95	NaClO4/m	lgK:0.90 (2SF)	0	MSL	369
56	0	5.88	NaClO4/m	lgK:0.77 (2SF)	4	MSL	369
57	0.5	0.229	NaNO3/m	lgK:0.93 (2SF)	0	MSL	8616
58	0.5	0.503	NaNO3/m	lgK:0.54 (2SF)	0	MSL	8616
59	0.5	1.02	NaNO3/m	lgK:0.26 (2SF)	0	MSL	8616
60	0.5	2.14	NaNO3/m	lgK:0.01 (1SF)	0	MSL	8616
61	0.5	6.02	NaNO3/m	lgK:0.04 (1SF)	0	MSL	8616
62	2			lgK:0.98 (2SF)	0	EES	5398
63	5	0	Inf. Dilution	lgK:2.11 (3SF)	4	MCN	83
64	5	0	Inf. Dilution	lgK:2.27 (3SF)	4	MIS	5574
65	5	0.1	Inert	lgK:1.57 (3SF)	4	MIS	5574
66	5	0.5	Inert	lgK:1.48 (0.05SD)	5	MIS	5574
67	5	1	Inert	lgK:1.52 (3SF)	3	MIS	5574
68	10	0	Inf. Dilution	lgK:2.13 (3SF)	4	MCN	83
69	10	0	Inf. Dilution	lgK:2.13 (3SF)	0	MCN	5416
70	10	0	Inf. Dilution/m	lgK:2.40 (3SF)	4	MCN	7397
71	15	0	Inf. Dilution	lgK:2.14 (3SF)	4	MCN	83

72	15	0	Inf. Dilution	lgK:2.28 (3SF)	4	MIS	5574
73	15	0	Inf. Dilution	lgK:2.15 (3SF)	5	MCN	18421
74	15	0	Inf. Dilution	lgK:2.323 (4SF)	5	MCN	28080
75	15	0	Inf. Dilution/m	lgK:2.35 (3SF)	4	MCN	7397
76	15	0.1	Inert	lgK:1.58 (3SF)	4	MIS	5574
77	15	0.5	Inert	lgK:1.50 (0.05SD)	3	MIS	5574
78	15	1	Inert	lgK:1.59 (3SF)	4	MIS	5574
79	18	0	Inf. Dilution	lgK:2.28 (3SF)	4	MCN	8670
80	18	0	Inf. Dilution	lgK:2.28 (3SF)	3	MCN	11989
81	20	0	Inf. Dilution	lgK:2.16 (3SF)	4	MCN	83
82	20	0	Inf. Dilution	lgK:2.0 (2SF)	3	MSL	931
83	20	0	Inf. Dilution	lgK:2.16 (3SF)	0	MCN	5416
84	20	0	Inf. Dilution/m	lgK:2.34 (3SF)	4	MCN	7397
85	25	0	Inf. Dilution	lgK:2.3 (0.05SD)	5	CMN	68
86	25	0	Inf. Dilution	lgK:2.18 (3SF)	4	MCN	83
87	25	0	Inf. Dilution	lgK:2.23 (3SF)	4	MIS	93
88	25	0	Inf. Dilution	lgK:2.31 (3SF)	4	MDG	931
89	25	0	Inf. Dilution	lgK:2.49 (3SF)	4	EMU	5398
90	25	0	Inf. Dilution	lgK:2.43 (3SF)	4	MCL	5398
91	25	0	Inf. Dilution	lgK:2.37 (3SF)	4	MIS	5398
92	25	0	Inf. Dilution	lgK:2.23 (3SF)	0	MAC	5416
93	25	0	Inf. Dilution	lgK:2.18 (3SF)	0	MCN	5416
94	25	0	Inf. Dilution	lgK:2.30 (0.02SD)	4	ENS	5574
95	25	0	Inf. Dilution	lgK:2.31 (3SF)	4	MIS	5574
96	25	0	Inf. Dilution	lgK:2.11 (3SF)	4	EOD	6495
97	25	0	Inf. Dilution	lgK:2.30 (3SF)	4	ENS	6496
98	25	0	Inf. Dilution	lgK:2.28 (0.02SD)	5	CMN	7391
99	25	0	Inf. Dilution	lgK:2.35 (3SF)	4	MSL	8385
100	25	0	Inf. Dilution	lgK:2.43 (0.03SD)	4	MCL	8402
101	25	0	Inf. Dilution	lgK:2.28 (0.36SD)	4	MIS	8628
102	25	0	Inf. Dilution	lgK:2.57 (3SF)	5	MIS	8646
103	25	0	Inf. Dilution	lgK:2.49 (3SF)	4	MDG	8675
104	25	0	Inf. Dilution	lgK:2.30 (3SF)	5	CRV	9402
105	25	0	Inf. Dilution	lgK:2.276 (4SF)	4	EOD	12002
106	25	0	Inf. Dilution	lgK:2.28 (3SF)	2	EMS	12547
107	25	0	Inf. Dilution	lgK:2.31 (3SF)	4	EOD	12549

Note (107): p. 362 at end							
108	25	0	Inf. Dilution	lgK:2.28(3SF)	3	CRV	18273
Note (108): Table 3, p. 85							
109	25	0	Inf. Dilution	lgK:2.31(3SF)	5	MSL	12002
Note (109): p. 411							
110	25	0	Inf. Dilution	lgK:2.11(3SF)	3	ENS	18070
111	25	0	Inf. Dilution	lgK:2.346(4SF)	5	MCN	28080
112	25	0	CHEMVAL1	lgK:2.32(0.01SD)	0	ENS	5156
113	25	0	CHEMVAL2	lgK:2.32(0.01SD)	0	ENS	5156
114	25	0	CHEMVAL3	lgK:2.43(0.01SD)	0	ENS	5156
115	25	0	CHEMVAL4	lgK:2.43(0.01SD)	5	ENS	5156
116	25	0	Inf. Dilution/m	lgK:2.35(3SF)	4	MCN	7397
117	25	0	Inf. Dilution/m	lgK:2.31(3SF)	4	MEF	8630
118	25	0	SOLMNEQ	lgK:2.30(3SF)	0	CMN	5416
119	25	0	SOLVEQ	lgK:2.31(3SF)	0	CMN	5416
120	25	0	UCT_Sea	lgK:2.30(0.01SD)	4	EDH	5390
121	25	0	Unknown	lgK:2.309(4SF)	3	ENS	7373
122	25	0	WATCH	lgK:2.03(3SF)	0	CMN	5416
123	25	0	WATEQF	lgK:2.31(3SF)	0	CMN	5416
124	25	0.1	Inert	lgK:1.60(3SF)	4	MIS	5574
125	25	0.1	NaCl	lgK:1.39(0.005SD)	2	MIS	3540
126	25	0.1	UCT_Sea	lgK:1.48(0.01SD)	4	EDH	5390
127	25	0.1	Unknown	lgK:1.51(0.02SD)	6	CRV	552
128	25	0.2	NaClO4	lgK:1.54(3SF)	3	MSL	5398
129	25	0.2	UCT_Sea	lgK:1.29(0.01SD)	4	EDH	5390
130	25	0.236	NaNO3/m	lgK:1.03(3SF)	0	MSL	8616
131	25	0.3	UCT_Sea	lgK:1.19(0.01SD)	4	EDH	5390
132	25	0.4	UCT_Sea	lgK:1.13(0.01SD)	4	EDH	5390
133	25	0.47	NaClO4	lgK:1.12(3SF)	0	MSL	11516
Note (133): Kalyanaraman R et al., J. Chem. Thermodyn., 1973, 5, 899							
134	25	0.477	NaClO4/m	lgK:1.19(0.05SD)	2	MSL	369
135	25	0.5	Inert	lgK:1.50(0.05SD)	3	MIS	5574
136	25	0.5	LiCl	lgK:0.79(2SF)	0	MSL	5398
137	25	0.5	NaNO3	lgK:0.76(2SF)	0	MSL	5398
138	25	0.5	UCT_Sea	lgK:1.08(0.01SD)	2	EDH	5390
139	25	0.5	Unknown	lgK:1.12(3SF)	3	CRV	552

140	25	0.504	NaNO3/m	lgK:0.76(2SF)	0	MSL	8616
141	25	0.6	NaCl	lgK:1.03(3SF)	0	MPT	8898
142	25	0.6	UCT_Sea	lgK:1.05(0.01SD)	0	EDH	5390
143	25	0.7	NaCl	lgK:1.0(2SF)	0	EES	5398
144	25	0.7	NaCl	lgK:1.49(3SF)	5	MSL	7229
145	25	0.7	Seawater	lgK:1.5(0.2SD)w	0	MPH	5090
146	25	0.7	UCT_Sea	lgK:1.03(0.01SD)	0	EDH	5390
147	25	0.7	Unknown	lgK:1.03(3SF)	0	EOD	5644
148	25	0.7	Unknown	lgK:1.03(0.02SD)	0	CMN	7391
149	25	0.7	Unknown	lgK:1.24(3SF)	4	ENS	7391
150	25	1	Inert	lgK:1.59(3SF)	4	MIS	5574
151	25	1.01	NaNO3/m	lgK:0.52(2SF)	0	MSL	8616
152	25	2.01	NaClO4/m	lgK:0.94(2SF)	0	MSL	369
153	25	2.1	LiCl	lgK:0.61(2SF)	0	MSL	5398
154	25	2.1	NaNO3	lgK:0.26(2SF)	0	MSL	5398
Note (154): Low wgt for internal consistency							
155	25	2.1	NaNO3/m	lgK:0.26(2SF)	0	MSL	8616
156	25	5.92	NaClO4/m	lgK:0.86(2SF)	4	MSL	369
157	25	6	Acetate buffer	lgK:0.86(2SF)	3	CRV	552
158	25	6	LiCl	lgK:0.43(2SF)	5	MSL	5398
159	25	6	NaNO3	lgK:0.13(2SF)	3	MSL	5398
160	25	6	NaNO3/m	lgK:0.23(2SF)	0	MSL	8616
161	25			lgK:2.57(3SF)	0	MEF	931
162	30	0	Inf. Dilution	lgK:2.20(3SF)	4	MCN	83
163	30	0	Inf. Dilution	lgK:2.20(3SF)	0	MCN	5416
164	30	0	Inf. Dilution/m	lgK:2.34(3SF)	4	MCN	7397
165	35	0	Inf. Dilution	lgK:2.22(3SF)	4	MCN	83
166	35	0	Inf. Dilution	lgK:2.35(3SF)	4	MIS	5574
167	35	0	Inf. Dilution	lgK:2.373(4SF)	5	MCN	28080
168	35	0.1	Inert	lgK:1.64(3SF)	4	MIS	5574
169	35	0.5	Inert	lgK:1.58(0.05SD)	0	MIS	5574
170	35	1	Inert	lgK:1.67(3SF)	4	MIS	5574
171	37	0	Inf. Dilution	lgK:2.23(3SF)	2	CRV	28703
172	37	0.03	Me4NI	lgK:1.90(0.03MD)	5	MGL	29801
173	37	0.05	Me4NI	lgK:1.80(0.04MD)	5	MGL	29801
174	37	0.1	Me4NI	lgK:1.63(0.03MD)	5	MGL	29801


175	37	0.15	Blood Plasma	lgK:1.2 (0.05SD)	0	ENS	94
176	37	0.15	Unknown	lgK:1.63 (3SF)	6	CRV	552
177	37	0.3	Me4NI	lgK:1.48 (0.03MD)	5	MGL	29801
178	37	0.5	Me4NI	lgK:1.48 (0.04MD)	5	MGL	29801
179	38	0	Inf. Dilution	lgK:2.30 (3SF)	3	CRV	8692
180	40	0	Inf. Dilution	lgK:2.25 (3SF)	4	MCN	83
181	40	0	Inf. Dilution	lgK:2.29 (3SF)	4	MSL	140
182	40	0	Inf. Dilution	lgK:2.25 (3SF)	0	MCN	5416
183	40	0	Inf. Dilution	lgK:2.39 (3SF)	5	MSL	12002
Note (183): p. 411							
184	40	0	Inf. Dilution/m	lgK:2.38 (3SF)	4	MEF	8630
185	45	0	Inf. Dilution	lgK:2.27 (3SF)	4	MCN	83
186	45	0	Inf. Dilution	lgK:2.26 (3SF)	0	MCN	5416
187	45	0	Inf. Dilution	lgK:2.41 (3SF)	4	MIS	5574
188	45	0.1	Inert	lgK:1.69 (3SF)	4	MIS	5574
189	45	0.5	Inert	lgK:1.64 (0.05SD)	0	MIS	5574
190	45	1	Inert	lgK:1.89 (3SF)	0	MIS	5574
191	50	0	Inf. Dilution	lgK:2.4 (2SF)	4	EES	5398
192	50	0	Inf. Dilution	lgK:2.46 (3SF)	0	MAC	5416
193	50	0	Inf. Dilution	lgK:2.21 (3SF)	4	EOD	6495
194	50	0	Inf. Dilution/m	lgK:2.44 (3SF)	4	MEF	8630
195	50	0	SOLMNEQ	lgK:2.40 (3SF)	0	CMN	5416
196	50	0	SOLVEQ	lgK:2.41 (3SF)	0	CMN	5416
197	50	0	WATCH	lgK:2.16 (3SF)	0	CMN	5416
198	50	0	WATEQF	lgK:2.39 (3SF)	0	CMN	5416
199	60	0	Inf. Dilution	lgK:2.5 (2SF)	4	EES	5398
200	75	0	Inf. Dilution	lgK:2.35 (3SF)	4	EOD	6495
201	75	0	SOLMNEQ	lgK:2.55 (3SF)	0	CMN	5416
202	75	0	WATCH	lgK:2.32 (3SF)	0	CMN	5416
203	75	0	WATEQF	lgK:2.47 (3SF)	0	CMN	5416
204	100	0	Inf. Dilution	lgK:2.7 (2SF)	3	EES	5398
205	100	0	Inf. Dilution	lgK:2.86 (3SF)	0	MAC	5416
206	100	0	Inf. Dilution	lgK:2.51 (3SF)	4	EOD	6495
207	100	0	Inf. Dilution	lgK:2.44 (3SF)	2	EOD	6495
208	100	0	SOLMNEQ	lgK:2.70 (3SF)	0	CMN	5416
209	100	0	SOLVEQ	lgK:2.67 (3SF)	0	CMN	5416

210	100	0	WATCH	lgK:2.50 (3SF)	0	CMN	5416
211	100	0	WATEQF	lgK:2.53 (3SF)	0	CMN	5416
212	125	0	Inf. Dilution	lgK:2.7 (2SF)	4	EOD	6495
213	125	0	SOLMNEQ	lgK:2.90 (3SF)	0	CMN	5416
214	125	0	WATCH	lgK:2.70 (3SF)	0	CMN	5416
215	125	0	WATEQF	lgK:2.59 (3SF)	0	CMN	5416
216	150	0	Inf. Dilution	lgK:3.1 (2SF)	3	EES	5398
217	150	0	Inf. Dilution	lgK:3.27 (3SF)	0	MAC	5416
218	150	0	Inf. Dilution	lgK:2.78 (3SF)	4	EOD	6495
219	150	0	Inf. Dilution	lgK:2.91 (3SF)	4	EOD	6495
220	150	0	SOLMNEQ	lgK:3.10 (3SF)	0	CMN	5416
221	150	0	SOLVEQ	lgK:3.00 (3SF)	0	CMN	5416
222	150	0	WATCH	lgK:2.91 (3SF)	0	CMN	5416
223	150	0	WATEQF	lgK:2.63 (3SF)	0	CMN	5416
224	150	0.25	NaNO3/m	lgK:1.44 (3SF)	0	MSL	8616
225	150	0.506	NaNO3/m	lgK:1.00 (3SF)	0	MSL	8616
226	150	0.513	NaClO4/m	lgK:1.32 (3SF)	2	MSL	369
227	150	1.07	NaNO3/m	lgK:0.97 (2SF)	0	MSL	8616
228	150	2.01	NaClO4/m	lgK:0.86 (2SF)	0	MSL	369
229	150	2.19	NaNO3/m	lgK:0.66 (2SF)	0	MSL	8616
230	150	5.82	NaNO3/m	lgK:0.54 (2SF)	0	MSL	8616
231	150	5.9	NaClO4/m	lgK:0.73 (2SF)	4	MSL	369
232	175	0	Inf. Dilution	lgK:3.15 (3SF)	4	EOD	6495
233	175	0	SOLMNEQ	lgK:3.34 (3SF)	0	CMN	5416
234	175	0	WATCH	lgK:3.13 (3SF)	0	CMN	5416
235	175	0	WATEQF	lgK:2.68 (3SF)	0	CMN	5416
236	200	0	Inf. Dilution	lgK:3.2 (2SF)	4	EES	5398
237	200	0	Inf. Dilution	lgK:3.71 (3SF)	0	MAC	5416
238	200	0	Inf. Dilution	lgK:3.21 (3SF)	4	EOD	6495
239	200	0	Inf. Dilution	lgK:3.43 (3SF)	4	EOD	6495
240	200	0	SOLMNEQ	lgK:3.60 (3SF)	0	CMN	5416
241	200	0	SOLVEQ	lgK:3.41 (3SF)	0	CMN	5416
242	200	0	WATCH	lgK:3.36 (3SF)	0	CMN	5416
243	200	0	WATEQF	lgK:2.72 (3SF)	0	CMN	5416
244	225	0	Inf. Dilution	lgK:3.76 (3SF)	4	EOD	6495
245	225	0	SOLMNEQ	lgK:3.86 (3SF)	0	CMN	5416

246	225	0	WATCH	lgK:3.60 (3SF)	0	CMN	5416
247	225	0	WATEQF	lgK:2.75 (3SF)	0	CMN	5416
248	250	0	Inf. Dilution	lgK:4.22 (3SF)	0	MAC	5416
249	250	0	Inf. Dilution	lgK:3.75 (3SF)	4	EOD	6495
250	250	0	Inf. Dilution	lgK:4.14 (3SF)	2	EOD	6495
251	250	0	SOLMNEQ	lgK:4.10 (3SF)	0	CMN	5416
252	250	0	SOLVEQ	lgK:3.88 (3SF)	0	CMN	5416
253	250	0	WATCH	lgK:3.84 (3SF)	0	CMN	5416
254	250	0	WATEQF	lgK:2.78 (3SF)	0	CMN	5416
255	250	0.244	NaNO3/m	lgK:1.89 (3SF)	0	MSL	8616
256	250	0.498	NaNO3/m	lgK:1.55 (3SF)	0	MSL	8616
257	250	0.505	NaClO4/m	lgK:1.84 (3SF)	0	MSL	369
258	250	1.06	NaNO3/m	lgK:1.09 (3SF)	0	MSL	8616
259	250	2	NaClO4/m	lgK:1.22 (3SF)	4	MSL	369
260	250	2.21	NaNO3/m	lgK:0.78 (2SF)	0	MSL	8616
261	250	5.82	NaNO3/m	lgK:0.58 (2SF)	0	MSL	8616
262	250	5.93	NaClO4/m	lgK:0.96 (2SF)	4	MSL	369
263	275	0	Inf. Dilution	lgK:4.61 (3SF)	2	EOD	6495
264	275	0	SOLMNEQ	lgK:4.30 (3SF)	0	CMN	5416
265	275	0	WATCH	lgK:4.09 (3SF)	0	CMN	5416
266	275	0	WATEQF	lgK:2.81 (3SF)	0	CMN	5416
267	300	0	Inf. Dilution	lgK:4.78 (3SF)	0	MAC	5416
268	300	0	Inf. Dilution	lgK:4.44 (3SF)	0	EOD	6495
269	300	0	Inf. Dilution	lgK:5.19 (3SF)	0	EOD	6495
270	300	0	SOLMNEQ	lgK:4.50 (3SF)	0	CMN	5416
271	300	0	SOLVEQ	lgK:4.43 (3SF)	0	CMN	5416
272	300	0	WATCH	lgK:4.35 (3SF)	0	CMN	5416
273	300	0	WATEQF	lgK:2.84 (3SF)	0	CMN	5416
274	325	0	SOLMNEQ	lgK:4.73 (3SF)	0	CMN	5416
275	325	0	WATCH	lgK:4.61 (3SF)	0	CMN	5416
276	325	0	WATEQF	lgK:2.86 (3SF)	0	CMN	5416
277	350	0	Inf. Dilution	lgK:19.0 (3SF)	0	MAC	5416
278	350	0	Inf. Dilution	lgK:5.42 (3SF)	0	MAC	5416
279	350	0	SOLMNEQ	lgK:5.00 (3SF)	0	CMN	5416
280	350	0	WATCH	lgK:4.87 (3SF)	0	CMN	5416
281	350	0	WATEQF	lgK:2.88 (3SF)	0	CMN	5416

282	350	1.99	NaClO4/m	lgK:1.78 (3SF)	4	MSL	369
283	350	5.95	NaClO4/m	lgK:1.36 (3SF)	4	MSL	369
284	23	0	Inf. Dilution	dG:-3.15 (0.05SD)	3	MCL	7645
285	25	0	Inf. Dilution	dG:-12.42 (0.05SD) kJ	4	MCN	83
286	0	0	Inf. Dilution	dH:1.11 (3SF)	0	MTD	5416
287	23	0	Inf. Dilution	dH:1.50 (0.20SD)	3	MCL	7645
288	25	0	Inf. Dilution	dH:1.6 (0.1SD)	4	MSL	69
289	25	0	Inf. Dilution	dH:6.11 (0.38SD) kJ	4	MTD	83
290	25	0	Inf. Dilution	dH:1.65 (3SF)	4	MTD	140
291	25	0	Inf. Dilution	dH:1.94 (3SF)	4	MDG	931
292	25	0	Inf. Dilution	dH:1.5 (2SF)	4	MCL	5398
293	25	0	Inf. Dilution	dH:0.81 (2SF)	4	MCL	5398
294	25	0	Inf. Dilution	dH:1.87 (3SF)	4	MDG	5398
295	25	0	Inf. Dilution	dH:1.93 (3SF)	0	MTD	5416
296	25	0	Inf. Dilution	dH:1.65 (3SF)	4	ENS	6496
297	25	0	Inf. Dilution	dH:0.81 (0.01SD)	4	MCL	8402
298	25	0	Inf. Dilution	dH:1.60 (3SF)	5	CRV	9402
299	25	0	Inf. Dilution	dH:6.11 (3SF) kJ	4	MTD	11762
300	25	0	Inf. Dilution/m	dH:6.4 (2SF) kJ	4	MTD	8630
301	25	0	Unknown	dH:1.47 (3SF)	3	ENS	7373
302	25			dH:5.92 (0.09SD) kJ	5	MDG	11763
303	40	0	Inf. Dilution	dH:2.5 (2SF)	4	MCL	5398
304	40	0	Inf. Dilution/m	dH:10.3 (3SF) kJ	4	MTD	8630
305	50	0	Inf. Dilution	dH:3.1 (2SF)	4	MCL	5398
306	50	0	Inf. Dilution	dH:2.81 (3SF)	0	MTD	5416
307	50	0	Inf. Dilution/m	dH:13.0 (3SF) kJ	2	MTD	8630
308	100	0	Inf. Dilution	dH:4.80 (3SF)	0	MTD	5416
309	150	0	Inf. Dilution	dH:7.07 (3SF)	0	MTD	5416
310	200	0	Inf. Dilution	dH:9.63 (3SF)	0	MTD	5416
311	250	0	Inf. Dilution	dH:12.5 (3SF)	0	MTD	5416
312	300	0	Inf. Dilution	dH:15.6 (3SF)	0	MTD	5416

Reaction No. 37



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	P=400 Inf. Dilution	lgK:4.216 (4SF)	3	CRV	11928

Note (1): with lgK0=4.542 & Kp/K=2.12							
2	25	0	P=1000 Inf. Dilution	lgK:3.779(4SF)	3	CRV	11928
Note (2): with lgK0=4.542 & Kp/K=5.80							
3	0	0	Inf. Dilution	lgK:4.5487(5SF)	4	CRV	31793
4	0	0.471	NaClO4/m	lgK:3.378(4SF)	4	MSL	369
5	0	1.95	NaClO4/m	lgK:3.116(4SF)	4	MSL	369
6	0	5.88	NaClO4/m	lgK:3.693(4SF)	4	MSL	369
7	10	0	Inf. Dilution	lgK:4.5366(5SF)	4	CRV	31793
8	20	0	Inf. Dilution	lgK:4.5025(5SF)	4	CRV	31793
9	25	0	Inf. Dilution	lgK:5.04(3SF)	0	CRV	
Note (9): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
10	25	0	Inf. Dilution	lgK:4.59(3SF)	4	MSL	93
11	25	0	Inf. Dilution	lgK:4.6(0.05SD)	4	ENS	5458
12	25	0	Inf. Dilution	lgK:4.8(2SF)	4	ENS	5648
13	25	0	Inf. Dilution	lgK:4.15(3SF)	3	CRV	6330
Note (13): p. 8-58							
14	25	0	Inf. Dilution	lgK:4.36(3SF)	4	ENS	6496
15	25	0	Inf. Dilution	lgK:3.64(3SF)	0	ENS	7694
16	25	0	Inf. Dilution	lgK:4.60(0.16SD)	4	MIS	8628
17	25	0	Inf. Dilution	lgK:4.65(3SF)	4	CRV	9402
18	25	0	Inf. Dilution	lgK:4.21(3SF)	0	CRV	22551
Note (18): p. 66							
19	25	0	Inf. Dilution	lgK:4.32(3SF)	5	CMN	26782
20	25	0	Inf. Dilution	lgK:4.43(3SF)	4	CRV	28992
21	25	0	Inf. Dilution	lgK:4.357(4SF)	5	CRV	31308
22	25	0	Inf. Dilution	lgK:4.4969(5SF)	4	CRV	31793
23	25	0	Inf. Dilution	lgK:4.62(3SF)	4	CRV	32224
24	25	0	CHEMVAL1	lgK:4.19(0.01SD)	0	ENS	5156
25	25	0	CHEMVAL2	lgK:4.19(0.01SD)	0	ENS	5156
26	25	0	CHEMVAL3	lgK:4.19(0.01SD)	0	ENS	5156
27	25	0	CHEMVAL4	lgK:4.12(0.01SD)	0	ENS	5156
28	25	0.477	NaClO4/m	lgK:3.331(4SF)	4	MSL	369
29	25	0.5	NaClO4	lgK:3.0(0.05SD)	0	MIS	5107
30	25	1	Me4NC1	lgK:3.16(0.08SD)	5	MGL	269
31	25	1	NaClO4	lgK:3.0(0.05SD)	0	MIS	5107

32	25	1	Unknown	lgK:2.92 (3SF)	4	ENS	773
33	25	2	NaClO4	lgK:3.0 (0.05SD)	3	MIS	5107
34	25	2.01	NaClO4/m	lgK:3.099 (4SF)	4	MSL	369
35	25	3	NaClO4	lgK:3.16 (3SF)	4	ENS	773
36	25	3	NaClO4	lgK:3.3 (0.05SD)	0	MIS	5107
37	25	3.5	NaClO4	lgK:3.16 (0.05SD)	5	MSL	6213
38	25	4	NaClO4	lgK:3.6 (0.05SD)	0	MIS	5107
39	25	5.92	NaClO4/m	lgK:3.639 (4SF)	4	MSL	369
40	30	0	Inf. Dilution	lgK:3.65 (3SF)	0	MCE	8375
41	30	0	Inf. Dilution	lgK:4.36 (3SF)	5	CMN	26782
42	30	0	Inf. Dilution	lgK:4.5028 (5SF)	4	CRV	31793
43	40	0	Inf. Dilution	lgK:4.45 (3SF)	5	CMN	26782
44	40	0	Inf. Dilution	lgK:4.5510 (5SF)	4	CRV	31793
45	50	0	Inf. Dilution	lgK:4.55 (3SF)	5	CMN	26782
46	50	0	Inf. Dilution	lgK:4.72 (3SF)	4	CRV	28992
47	50	0	Inf. Dilution	lgK:4.6459 (5SF)	4	CRV	31793
48	56	0	Inf. Dilution	lgK:4.63 (3SF)	5	CMN	26782
49	60	0	Inf. Dilution	lgK:4.67 (3SF)	5	CMN	26782
50	60	0	Inf. Dilution	lgK:4.7762 (5SF)	4	CRV	31793
51	70	0	Inf. Dilution	lgK:4.9187 (5SF)	4	CRV	31793
52	75	0	Inf. Dilution	lgK:4.91 (3SF)	5	CMN	26782
53	80	0	Inf. Dilution	lgK:5.0435 (5SF)	4	CRV	31793
54	90	0	Inf. Dilution	lgK:5.1522 (5SF)	4	CRV	31793
55	100	0	Inf. Dilution	lgK:5.30 (3SF)	5	CMN	26782
56	100	0	Inf. Dilution	lgK:5.50 (3SF)	3	CRV	28992
57	100	0	Inf. Dilution	lgK:5.3570 (5SF)	4	CRV	31793
58	100	0	Inf. Dilution/m	lgK:5.46 (3SF)	4	MSL	8671
59	125	0	Inf. Dilution	lgK:5.71 (3SF)	5	CMN	26782
60	125	0	Inf. Dilution/m	lgK:6.03 (3SF)	4	MSL	8671
61	150	0	Inf. Dilution	lgK:6.14 (3SF)	5	CMN	26782
62	150	0	Inf. Dilution	lgK:6.56 (3SF)	3	CRV	28992
63	150	0	Inf. Dilution/m	lgK:6.43 (3SF)	4	MSL	8671
64	150	0.25	NaNO3/m	lgK:4.540 (4SF)	5	MSL	8616
65	150	0.506	NaNO3/m	lgK:4.195 (4SF)	5	MSL	8616
66	150	0.513	NaClO4/m	lgK:4.415 (4SF)	2	MSL	369
67	150	1.07	NaNO3/m	lgK:3.891 (4SF)	5	MSL	8616

68	150	2.01	NaClO ₄ /m	lgK:4.073 (4SF)	0	MSL	369
69	150	2.19	NaNO ₃ /m	lgK:3.537 (4SF)	0	MSL	8616
70	150	5.82	NaNO ₃ /m	lgK:3.196 (4SF)	0	MSL	8616
71	150	5.9	NaClO ₄ /m	lgK:4.321 (4SF)	4	MSL	369
72	175	0	Inf. Dilution/m	lgK:6.95 (3SF)	3	MSL	8671
73	200	0	Inf. Dilution	lgK:7.85 (3SF)	2	CRV	28992
74	200	0	Inf. Dilution/m	lgK:7.43 (3SF)	4	MSL	8671
75	250	0	Inf. Dilution	lgK:9.08 (3SF)	2	CRV	28992
76	250	0.244	NaNO ₃ /m	lgK:5.836 (4SF)	2	MSL	8616
77	250	0.498	NaNO ₃ /m	lgK:5.417 (4SF)	5	MSL	8616
78	250	0.505	NaClO ₄ /m	lgK:5.703 (4SF)	2	MSL	369
79	250	1.06	NaNO ₃ /m	lgK:4.802 (4SF)	5	MSL	8616
80	250	2	NaClO ₄ /m	lgK:4.981 (4SF)	0	MSL	369
81	250	2.21	NaNO ₃ /m	lgK:4.248 (4SF)	5	MSL	8616
82	250	5.82	NaNO ₃ /m	lgK:3.473 (4SF)	5	MSL	8616
83	250	5.93	NaClO ₄ /m	lgK:4.722 (4SF)	4	MSL	369
84	350	1.99	NaClO ₄ /m	lgK:5.813 (4SF)	4	MSL	369
85	350	5.95	NaClO ₄ /m	lgK:5.011 (4SF)	4	MSL	369
86	25	0	Inf. Dilution	dH:0.3 (1SF)	0	CRV	2556
87	25	0	Inf. Dilution	dH:1.71 (3SF)	4	ENS	6496
88	25	0	Inf. Dilution	dH:3.75 (3SF)	0	CRV	9402
89	100	0	Inf. Dilution/m	dH:63.691 (5SF) kJ	0	MTD	8671
90	125	0	Inf. Dilution/m	dH:59.763 (5SF) kJ	0	MTD	8671
91	150	0	Inf. Dilution/m	dH:61.792 (5SF) kJ	4	MTD	8671
92	175	0	Inf. Dilution/m	dH:72.656 (5SF) kJ	4	MTD	8671
93	200	0	Inf. Dilution/m	dH:95.58 (4SF) kJ	4	MTD	8671
94	25	0	Inf. Dilution	Cp:74.40 (4SF)	4	CRV	9402


Reaction No. 38							
Phthalic-2 + Ca+2 = Ca+2_Phthalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.42 (3SF)	2	ENS	773
2	25	0	Inf. Dilution	lgK:2.49 (3SF)	2	MGL	1045
3	25	0	Inf. Dilution	lgK:2. (0.6SD)	0	MGL	1716
Note (3): Prob. truncated							
4	25	0	Inf. Dilution	lgK:2.43 (3SF)	2	MCN	11516

Note (4): Topp N et al., J. Chem. Soc., 1940, 87							
5	25	0	UCT_Sea	lgK:2.42(0.01SD)	2	EDH	5390
6	25	0	Unknown	lgK:2.64(3SF)	2	MPT	2712
7	25	0.1	KCl	lgK:2.41(0.02SD)	3	MSL	999
8	25	0.1	NaCl	lgK:2.45(3SF)	3	MGL	11516
Note (8): Skorik N et al., Zhur. Neorg. Khim., 1989, 34, 2276							
9	25	0.1	NaCl	lgK:2.01(0.05SD)	3	MGL	20992
10	25	0.1	NaCl	lgK:2.08(0.10SD)	3	MIS	20992
11	25	0.1	UCT_Sea	lgK:1.64(0.01SD)	2	EDH	5390
12	25	0.1	Unknown	lgK:1.07(3SF)	2	ENS	773
13	25	0.15	KNO3	lgK:1.35(3SF)	0	MGL	9980
14	25	0.15	Unknown	lgK:1.1(0.05SD)	2	MEF	101
15	25	0.2	UCT_Sea	lgK:1.47(0.01SD)	3	EDH	5390
16	25	0.25	Unknown	lgK:1.7(0.05SD)	3	MGL	1045
17	25	0.3	UCT_Sea	lgK:1.38(0.01SD)	3	EDH	5390
18	25	0.4	UCT_Sea	lgK:1.31(0.01SD)	3	EDH	5390
19	25	0.5	UCT_Sea	lgK:1.27(0.01SD)	3	EDH	5390
20	25	0.6	UCT_Sea	lgK:1.23(0.01SD)	3	EDH	5390
21	25	0.7	UCT_Sea	lgK:1.20(0.01SD)	3	EDH	5390
22	30	0.1	KCl	lgK:2.49(0.01SD)	3	MSL	999
23	35	0.1	KCl	lgK:2.59(0.01SD)	3	MSL	999
24	40	0.1	KCl	lgK:2.66(0.01SD)	3	MSL	999
25	45	0.1	KCl	lgK:2.75(0.01SD)	2	MSL	999
26	25	0	Inf. Dilution	dH:3.14(3SF)	3	MPT	2712

Reaction No. 39							
Salicylic-2 + Ca+2 = Ca+2_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.36(2SF)	0	ENS	6405
2	25	0	Me4NC1	lgK:1.73(3SF)	0	MCL	11516
Note (2): Mironov V et al., Zhur. Neorg. Khim., 1997, 42, 787							
3	25	0	UCT_Sea	lgK:5.03(0.01SD)	4	EDH	5390
4	25	0.1	UCT_Sea	lgK:4.25(0.01SD)	4	EDH	5390
5	25	0.2	UCT_Sea	lgK:4.12(0.01SD)	4	EDH	5390
6	25	0.3	UCT_Sea	lgK:4.03(0.01SD)	4	EDH	5390
7	25	0.4	UCT_Sea	lgK:3.96(0.01SD)	4	EDH	5390


8	25	0.5	UCT_Sea	lgK:3.92(0.01SD)	4	EDH	5390
9	25	0.6	UCT_Sea	lgK:3.88(0.01SD)	4	EDH	5390
10	25	0.7	UCT_Sea	lgK:3.85(0.01SD)	4	EDH	5390
11	37	0.15	NaClO4	lgK:4.3(0.1SD)	6	MGL	107
12	25		Methanol	lgK:4.5(2SF)	5	MPT	2599
13	25		Methanol	dH:-21.2(3SF)kJ	5	MCL	4795

Reaction No. 40



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.25	Unknown	lgK:0.5(0.05SD)	6	MGL	1045
2	25	0	Inf. Dilution	lgK:0.72(2SF)	2	MGL	1045
3	25	0	Inf. Dilution	lgK:1.73(3SF)	2	MGL	4503
4	25	0.03	NaCl	lgK:1.496(4SF)	2	MIS	4503
5	25	0.045	NaCl	lgK:1.42(3SF)	2	MIS	4503
6	25	0.15	NaCl	lgK:0.14(2SF)	0	MEF	140
7	25	0.16	NaCl	lgK:0.15(0.05SD)	0	MIX	108
8	25	0.25	Unknown	lgK:0.6(0.04SD)	6	MGL	1045
9	25	0.5	NaCl	lgK:0.58(2SF)	5	MSP	2260
10	35	0	Inf. Dilution	lgK:1.74(3SF)	2	MGL	4503
11	35	0.03	NaCl	lgK:1.51(3SF)	2	MIS	4503
12	35	0.045	NaCl	lgK:1.42(3SF)	2	MIS	4503
13	37	0.25	Unknown	lgK:0.7(0.04SD)	6	MGL	1045
14	45	0	Inf. Dilution	lgK:1.77(3SF)	2	MGL	4503
15	45	0.03	NaCl	lgK:1.55(3SF)	2	MIS	4503
16	45	0.045	NaCl	lgK:1.44(3SF)	2	MIS	4503
17	45	0.25	Unknown	lgK:0.8(0.05SD)	6	MGL	1045
18	25	0	Inf. Dilution	dH:5.(1SF)kJ	3	MCL	1045
19	25:45	0	Inf. Dilution	dH:-0.376(3SF)	2	MTD	4503

Reaction No. 41



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:3.55(3SF)	5	MGL	154
2	20	0.1	Unknown	lgK:3.50(3SF)	4	ENS	1539
3	22:23	0.16	Unknown	lgK:3.22(3SF)	5	MSC	999

4	23			lgK:3.24 (3SF)	0	MPT	906
5	25	0	Inf. Dilution	lgK:4.85 (3SF)	5	MSL	999
6	25	0	Inf. Dilution	lgK:4.86 (3SF)	5	MGL	2804
7	25	0	Inf. Dilution	lgK:4.7 (2SF)	4	ENS	6405
8	25	0	Inf. Dilution	lgK:4.73 (3SF)	0	CRV	8903
Note (8): Value in MINTEQA2 database now diagnosed as being in error (NIST lgK=4.85!)							
9	25	0	Inf. Dilution	lgK:4.84 (3SF)	5	MGL	11516
Note (9): Heinz E, Z. Biochem., 1951, 321, 314							
10	25	0	Inf. Dilution	lgK:4.90 (3SF)	5	MSL	11516
Note (10): Davies C et al., J. Chem. Soc., 1953, , 4134							
11	25	0	Inf. Dilution	lgK:4.800 (0.02SD)	6	CRV	20830
12	25	0	Unknown	lgK:4.91 (3SF)	4	MGL	9424
13	25	0	Unknown	lgK:4.91 (3SF)	4	MGL	17779
14	25	0	Unknown	lgK:4.84 (3SF)	4	MGL	22560
15	25	0	Unknown	lgK:4.68 (3SF)	1	MIX	22560
16	25	0	Unknown	lgK:4.90 (3SF)	4	MSL	22560
17	25	0.1	Cl-1 salt	lgK:3.64 (3SF)	3	MGL	2804
18	25	0.1	KNO3	lgK:3.5 (0.06SD)	5	MGL	3519
19	25	0.1	NaCl	lgK:3.42 (0.03SD)	3	MIS	3540
20	25	0.1	NaCl	lgK:3.4 (0.04SD)	3	MGL	3925
21	25	0.1	NaClO4	lgK:3.6 (0.06SD)	3	MGL	154
22	25	0.1	NaClO4	lgK:3.5 (2SF)	5	MCT	1867
23	25	0.1	NaClO4	lgK:3.54 (3SF)	4	MGL	3180
24	25	0.15	NaCl	lgK:3.17 (3SF)	0	MCT	22612
25	25	0.15	Unknown	lgK:3.17 (3SF)	4	MEF	999
26	25	0.16	Unknown	lgK:3.15 (3SF)	4	MIX	3478
27	25	0.5	NaClO4	lgK:2.71 (0.01MD)	0	MGL	4896
28	28	0.15	NaCl	lgK:3.20 (3SF)	2	MGL	999
29	30	1	NaClO4	lgK:3.02 (3SF)	3	MGL	22560
30	33	0.25	KClO4	lgK:3.4 (2SF)	0	MGL	999
31	37	0	Inf. Dilution	lgK:4.75 (3SF)	2	CRV	28703
32	37	0	NaCl	lgK:4.845 (4SF)	4	MIS	16470
33	37	0.1	Inert	lgK:3.63 (3SF)	2	CRV	29801
34	37	0.1	KNO3	lgK:3.485 (4SF)	4	MGL	9424
35	37	0.15	Blood Plasma	lgK:3.3 (0.05SD)	5	ENS	94
36	37	0.15	NaCl	lgK:3.274 (4SF)	5	MGL	3520

37	37	0.15	NaCl	lgK:4.850 (4SF)	0	MIS	16470
38	37	0.15	NaCl	lgK:3.28 (3SF)	4	MCT	22612
39	37	0.15	NaCl	lgK:3.14 (3SF)	4	MSL	26689
40	37	0.15	NaCl	lgK:3.33 (0.07SD)	4	MGL	28777
41	37	0.15	NaCl	lgK:3.33 (0.16SD)	4	MIS	28777
42	37	0.15	NaClO4	lgK:3.364 (0.006SD)	5	MGL	2181
43	38	0	Inf. Dilution	lgK:4.78 (3SF)	3	CRV	8692
44	18:45	0.02:0.17	NaCl	dH:-1.71 (3SF) kJ	0	MIS	16470
45	20:70	0.1	Unknown	dH:-2. (1SF)	0	CRV	2556

Reaction No. 42							
Ca+2 + H+1_Citric-3 = Ca+2_H+1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:2.1 (0.06SD)	4	MGL	154
2	25	0	Inf. Dilution	lgK:3.09 (3SF)	3	MIX	999
3	25	0	Inf. Dilution	lgK:2.92 (3SF)	4	MGL	2804
4	25	0	Inf. Dilution	lgK:2.92 (0.04SD)	6	CRV	20830
5	25	0	Inf. Dilution	lgK:3.29 (3SF)	3	MGL	22560
6	25	0	Unknown	lgK:2.81 (3SF)	5	MGL	9424
7	25	0	Unknown	lgK:3.05 (3SF)	3	MSL	22560
8	25	0	Unknown	lgK:2.786 (4SF)	4	MEP	22560
9	25	0.1	Cl-1 salt	lgK:2.03 (3SF)	5	MGL	2804
10	25	0.5	NH4+ salt	lgK:2.52 (3SF)	3	MDS	3154
11	37	0.15	NaCl	lgK:1.83 (3SF)	4	MGL	3520
12	38	0	Inf. Dilution	lgK:2.70 (3SF)	3	CRV	8692
13	20:40	0.1	Unknown	dH:-4. (1SF)	4	CRV	2556


Reaction No. 43							
Ca+2 + H+1(2)_Citric-3 = Ca+2_H+1(2)_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:1.1 (0.06SD)	3	MGL	154
2	25	0	Inf. Dilution	lgK:1.10 (3SF)	0	MIX	999
3	25	0	Inf. Dilution	lgK:1.45 (3SF)	4	MGL	2804
4	25	0	Inf. Dilution	lgK:1.53 (0.08SD)	6	CRV	20830
5	25	0	Unknown	lgK:1.15 (3SF)	4	MSL	22560
6	25	0.1	Cl-1 salt	lgK:1.04 (3SF)	5	MGL	2804

7	25	3	Inert	lgK:3.3 (2SF)	1	EOR	
8	38	0	Inf. Dilution	lgK:1.10 (3SF)	3	CRV	8692

Reaction No. 44							
EDTA-4 + Ca+2 = Ca+2_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:11.0 (3SF)	0	MHY	140
2	20	0	Inf. Dilution	lgK:11.00 (4SF)	0	ENS	773
3	20	0.1	KCl	lgK:10.59 (4SF)	3	MEF	197
4	20	0.1	KCl	lgK:10.70 (4SF)	6	MGL	1957
5	20	0.1	KNO3	lgK:10.7 (0.1SD)	5	EIU	903
6	20	0.1	KNO3	lgK:10.69 (4SF)	5	MEF	903
7	20	0.1	KNO3	lgK:10.51 (4SF)	0	MGL	903
8	20	0.1	KNO3	lgK:11. (2SF)	3	MEP	11516
Note (8): Jokl V et al., Chem. Zvesti, 1965, 19, 249							
9	20	0.1	NaClO4	lgK:10.7 (0.05SD)	4	MGL	197
10	20	0.1	NaClO4	lgK:10.9 (0.05SD)	3	MGL	2038
11	20	0.1	NaClO4	lgK:10.8 (0.05SD)	5	MGL	2038
12	20	0.1	Unknown	lgK:10.42 (4SF)	3	CMN	2174
13	21.7	0.1	NaNO3	lgK:10.85 (4SF)	3	MEF	903
14	23			lgK:11.0 (3SF)	0	MSP	3977
15	25	0	Inf. Dilution	lgK:12.42 (4SF)	3	CRV	552
16	25	0	Inf. Dilution	lgK:12.37 (4SF)	4	ENS	1384
17	25	0	Inf. Dilution	lgK:12.690 (0.03SD)	5	CRV	20830
18	25	0.06:1.5	NaNO3	lgK:12.67 (4SF)	0	EIE	903
19	25	0.1	KCl	lgK:10.6 (0.05SD)	3	MIS	140
20	25	0.1	KNO3	lgK:10.78 (4SF)	4	MIS	149
21	25	0.1	KNO3	lgK:10.7 (0.03SD)	6	MGL	903
22	25	0.1	KNO3	lgK:10.42 (4SF)	0	MGL	11516
Note (22): Bohigian T et al., US Comm. Con. no AT(30-1), 1960, 1823							
23	25	0.1	Me4N+ salt	lgK:10.97 (4SF)	3	CRV	552
24	25	0.1	NaCl	lgK:10.93 (0.01SD)	3	MIS	3540
25	25	0.1	NaClO4	lgK:10.7 (3SF)	5	MEF	903
26	25	0.1	NaClO4	lgK:10.75 (4SF)	6	MCT	1867
27	25	0.1	Unknown	lgK:10.61 (4SF)	6	ENS	2016
28	25	0.5	KNO3	lgK:9.9 (0.05SD)	4	MGL	3832


29	25	0.5	Me4N+ salt	lgK:10.47(4SF)	3	CRV	552
30	25	0.5	Me4NC1	lgK:10.28(4SF)	0	MGL	4556
31	25	1	KNO3	lgK:9.68(3SF)	6	MGL	999
32	30	0.1	KCl	lgK:10.59(4SF)	5	MGL	2019
33	37	0.15	Blood Plasma	lgK:9.9(0.05SD)	0	ENS	94
34	37	0.15	NaCl	lgK:9.36(0.003SD)	0	MGL	1940
Note (34): Low wgt for internal consistency							
35	20	0.1	KNO3	dG:-14.4(3SF)	5	MGL	2039
36	20	0.1	KNO3	dH:-6.55(3SF)	5	MCL	1963
37	20	0.1	KNO3	dH:-6.6(2SF)	5	MCL	2039
38	20	0.1	KNO3	dH:-6.45(3SF)	5	MDG	2603
39	20	0.17	Unknown	dH:-6.45(3SF)	4	MGL	140
40	20:40	0.1	KNO3	dH:-5.8(2SF)	5	MCL	3201
41	25	0.1	KNO3	dH:-6.5(2SF)	5	MCL	139
42	25	0.1	Me4N+ salt	dH:-5.8(2SF)	5	MCL	2558
43	25	0.1	NaNO3	dH:-6.55(3SF)	5	MCL	1379
44	25	0.1	Unknown	dH:-6.1(2SF)	6	CRV	552
45	25	0.1	Unknown	dH:-6.6(2SF)	5	MCL	1384
46	25	0.5	KNO3	dH:-7.051(4SF)	4	MTD	3832
47	25	1	K+1 salt	dH:-7.2(2SF)	6	CRV	552

Reaction No. 45



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.1(2SF)	4	MGL	1957
2	20	0.1	KNO3	lgK:3.2(0.05SD)	4	CSM	139
3	25	0	Inf. Dilution	lgK:3.540(0.05SD)	6	CRV	20830
4	25	0.1	Me4N+ salt	lgK:3.1(2SF)	6	CRV	552
5	25	0.5	Me4NC1	lgK:3.47(3SF)	0	MGL	4556


Reaction No. 47



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:10.9(0.05SD)	3	MGL	190
2	20	0.1	NaClO4	lgK:10.8(0.05SD)	5	MGL	2038
3	20	0.1	NaClO4	lgK:10.8(0.1SD)	5	CRV	13242


4	20	0.1	Unknown	lgK:10.89 (4SF)	6	MEF	999
5	20	0.1	Unknown	lgK:10.63 (4SF)	5	MGL	8226
6	25	0.1	KNO3	lgK:10.6 (3SF)	3	MGL	135
7	25	0.1	KNO3	lgK:10.74 (4SF)	6	MGL	189
8	25	0.1	KNO3	lgK:10.7 (0.06SD)	6	MPS	999
9	25	0.1	KNO3	lgK:10.7 (0.1SD)	5	CRV	13242
10	25	0.1	Unknown	lgK:10.75 (4SF)	6	ENS	773
11	25	0.1	Unknown	lgK:9.98 (3SF)	2	MGL	24382
12	37	0.15	Blood Plasma	lgK:9.8 (0.05SD)	0	ENS	94
13	37	0.15	NaCl	lgK:9.82 (0.008SD)	0	MGL	1940
14	37	0.15	NaCl	lgK:9.8 (0.1SD)	0	CRV	13242
15	20	0.1	KNO3	dH:-5.95 (3SF)	5	MCL	999
16	25	0.1	KNO3	dH:-6.1 (2SF)	5	MCL	139
17	25	0.1	NaNO3	dH:-6.1 (2SF)	5	MCL	1379
18	27	0.1	Unknown	dH:-5.6 (2SF)	5	MCL	999

Reaction No. 48




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:6. (0.4SD)	3	MHG	190
2	25	0.1	KNO3	lgK:6.43 (3SF)	6	MGL	189

Reaction No. 49



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:2.0 (0.1SD)	3	CRV	13242
2	20	0.1	Unknown	lgK:1.98 (3SF)	3	MEF	999
3	25	0.1	KNO3	lgK:1.6 (2SF)	2	MGL	189
4	25	0.1	KNO3	lgK:1.6 (0.2SD)	2	MPS	999
5	37	0.1	NaNO3	lgK:2.1 (0.1SD)	3	CRV	13242

Reaction No. 395



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.58 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.1 (0.05SD)	3	ENS	94

Reaction No. 396							
$2\text{AmButan-1} + \text{Ca}^{+2} + \text{H}^{+1} = \text{Ca}^{+2}_{\text{H}^{+1}}\text{2AmButan-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.94 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.7 (0.05SD)	3	ENS	94

Reaction No. 397							
$2<2\text{AmButan-1}> + \text{Ca}^{+2} = \text{Ca}^{+2}_{\text{2AmButan-1}}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.12 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.4 (0.05SD)	3	ENS	94

Reaction No. 398							
$2<2\text{AmButan-1}> + \text{Ca}^{+2} + 2<\text{H}^{+1}> = \text{Ca}^{+2}_{\text{H}^{+1}}(2)\text{2AmButan-1}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.2 (0.05SD)	4	ENS	94

Reaction No. 426							
$\text{Arg-1} + \text{Ca}^{+2} = \text{Ca}^{+2}_{\text{Arg-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.21 (3SF)	5	MGL	3511
2	25	0.7	KCl	lgK:0.61 (2SF)	0	MGL	6000
3	37	0.15	Blood Plasma	lgK:1.6 (0.05SD)	3	ENS	94
4	37	0.7	KCl	lgK:0.61 (2SF)	0	MGL	6000

Reaction No. 427							
$\text{Arg-1} + \text{Ca}^{+2} + \text{H}^{+1} = \text{Ca}^{+2}_{\text{H}^{+1}}\text{Arg-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.94 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.7 (0.05SD)	3	ENS	94

Reaction No. 428							
$2<\text{Arg-1}> + \text{Ca}^{+2} = \text{Ca}^{+2}_{\text{Arg-1}}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.92 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.2 (0.05SD)	4	ENS	94

Reaction No. 429							
$2\text{<Arg-1>} + \text{Ca}^{+2} + 2\text{<H+1>} = \text{Ca}^{+2}\text{_{H+1}(2)}\text{_{Arg-1}(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.8(0.05SD)	4	ENS	94

Reaction No. 460							
$\text{Ca}^{+2} + \text{Asn-1} = \text{Ca}^{+2}\text{_{Asn-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaCl	lgK:0.87(2SF)	5	MGL	9667
2	37	0.15	Blood Plasma	lgK:1.4(0.05SD)	3	ENS	94

Reaction No. 461							
$\text{Asn-1} + \text{Ca}^{+2} + \text{H+1} = \text{Ca}^{+2}\text{_{H+1}}\text{_{Asn-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.64(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.4(0.05SD)	3	ENS	94

Reaction No. 462							
$2\text{<Asn-1>} + \text{Ca}^{+2} = \text{Ca}^{+2}\text{_{Asn-1}(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.42(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.7(0.05SD)	3	ENS	94

Reaction No. 463							
$2\text{<Asn-1>} + \text{Ca}^{+2} + 2\text{<H+1>} = \text{Ca}^{+2}\text{_{H+1}(2)}\text{_{Asn-1}(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.4(0.05SD)	4	ENS	94

Reaction No. 496							
$\text{Asp-2} + \text{Ca}^{+2} = \text{Ca}^{+2}\text{_{Asp-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.1	HCl	lgK:1.89(3SF)	0	MGL	6912
2	10	0.5	HCl	lgK:1.76(3SF)	0	MGL	6912
3	10	1	HCl	lgK:1.33(3SF)	0	MGL	6912


4	25	0	Inf. Dilution	lgK:2.52 (0.04MD)	4	MGL	6912
5	25	0	NaCl	lgK:2.52 (3SF)	6	MGL	6912
6	25	0	UCT_Sea	lgK:2.38 (0.01SD)	4	EDH	5390
7	25	0.1	HCl	lgK:1.83 (3SF)	2	MGL	6912
8	25	0.1	KCl	lgK:1.60 (3SF)	2	MGL	6710
9	25	0.1	KCl	lgK:1.60 (3SF)	3	MGL	6710
10	25	0.1	KNO3	lgK:2.77 (3SF)	0	MGL	22560
11	25	0.1	NaNO3	lgK:4.13 (3SF)	0	MGL	16058
12	25	0.1	UCT_Sea	lgK:1.60 (0.01SD)	4	EDH	5390
13	25	0.16	Unknown	lgK:0.44 (2SF)	0	ENS	3478
14	25	0.2	UCT_Sea	lgK:1.44 (0.01SD)	4	EDH	5390
15	25	0.3	UCT_Sea	lgK:1.34 (0.01SD)	4	EDH	5390
16	25	0.4	UCT_Sea	lgK:1.28 (0.01SD)	4	EDH	5390
17	25	0.5	HCl	lgK:1.83 (3SF)	2	MGL	6912
18	25	0.5	UCT_Sea	lgK:1.23 (0.01SD)	4	EDH	5390
19	25	0.6	UCT_Sea	lgK:1.19 (0.01SD)	3	EDH	5390
20	25	0.7	UCT_Sea	lgK:1.17 (0.01SD)	2	EDH	5390
21	25	1	HCl	lgK:2.06 (3SF)	2	MGL	6912
22	37	0.1	HCl	lgK:1.79 (3SF)	2	MGL	6912
23	37	0.15	Blood Plasma	lgK:2.0 (0.05SD)	4	ENS	94
24	37	0.15	NaCl	lgK:1.99 (0.005SD)	4	MGL	937
25	37	0.15	NaCl	lgK:1.989 (4SF)	3	MIS	937
26	37	0.15	NaCl	lgK:1.86 (0.21SD)	4	MGL	28777
27	37	0.15	NaCl	lgK:2.07 (0.05SD)	3	MIS	28777
28	37	0.15	NaClO4	lgK:1.1 (0.2SD)	0	MGL	2181
29	37	0.15	Unknown	lgK:1.5 (0.05SD)	6	CRV	552
30	37	0.5	HCl	lgK:1.89 (3SF)	2	MGL	6912
31	37	1	HCl	lgK:2.64 (3SF)	2	MGL	6912
32	45	0.1	HCl	lgK:1.76 (3SF)	0	MGL	6912
33	45	0.5	HCl	lgK:1.93 (3SF)	2	MGL	6912
34	45	1	HCl	lgK:3.03 (3SF)	0	MGL	6912
35	10	0.1	HCl	dH:-1.43 (3SF)	0	MTD	6912
36	10	0.5	HCl	dH:1.67 (3SF)	2	MTD	6912
37	10	1	HCl	dH:17.9 (3SF)	0	MTD	6912
38	25	0	Inf. Dilution	dH:1.4 (2SF) kJ	0	MCL	6131
39	25	0	Inf. Dilution	dH:0.24 (2SF)	0	MCL	6912

40	25	0.1	HCl	dH:-1.43 (3SF)	0	MTD	6912
41	25	0.5	HCl	dH:1.9 (2SF)	5	MTD	6912
42	25	1	HCl	dH:19.8 (3SF)	0	MTD	6912
43	37	0.1	HCl	dH:-1.67 (3SF)	0	MTD	6912
44	37	0.5	HCl	dH:2.15 (3SF)	5	MTD	6912
45	37	1	HCl	dH:21.5 (3SF)	0	MTD	6912
46	45	0.1	HCl	dH:-1.67 (3SF)	0	MTD	6912
47	45	0.5	HCl	dH:2.15 (3SF)	2	MTD	6912
48	45	1	HCl	dH:22.5 (3SF)	0	MTD	6912

Reaction No. 497							
H+1 + Asp-2 + Ca+2 = Ca+2_H+1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.44 (4SF)	0	MGL	6131
2	25	0	Inf. Dilution	lgK:11.4 (0.08MD)	1	MGL	6912
3	25	0	NaCl	lgK:11.44 (4SF)	1	MGL	6912
4	37	0.15	Blood Plasma	lgK:10.2 (0.05SD)	0	ENS	94
5	37	0.15	NaCl	lgK:10.57 (0.01SD)	0	MGL	937
6	37	0.15	NaCl	lgK:10.567 (5SF)	0	MIS	937
7	37	0.15	NaCl	lgK:10.92 (0.29SD)	3	MGL	28777
8	37	0.15	NaCl	lgK:11.13 (0.13SD)	3	MIS	28777
9	37	0.15	NaClO4	lgK:10.6 (0.02SD)	0	MGL	2181
10	37	0.15	NaClO4	lgK:10.590 (5SF)	0	MGL	2181
11	10	0.1	HCl	lgR:11.23 (4SF)	0	MGL	6912
12	10	0.5	HCl	lgR:11.21 (4SF)	0	MGL	6912
13	10	1	HCl	lgR:10.90 (4SF)	0	MGL	6912
14	25	0.1	HCl	lgR:10.76 (4SF)	0	MGL	6912
15	25	0.5	HCl	lgR:10.80 (4SF)	0	MGL	6912
16	25	1	HCl	lgR:11.08 (4SF)	0	MGL	6912
17	37	0.1	HCl	lgR:10.38 (4SF)	0	MGL	6912
18	37	0.5	HCl	lgR:10.48 (4SF)	0	MGL	6912
19	37	1	HCl	lgR:11.23 (4SF)	0	MGL	6912
20	45	0.1	HCl	lgR:10.13 (4SF)	0	MGL	6912
21	45	0.5	HCl	lgR:10.27 (4SF)	0	MGL	6912
22	45	1	HCl	lgR:11.32 (4SF)	0	MGL	6912
23	10	0.1	HCl	dH:-11.5 (3SF)	0	MTD	6912


24	10	0.5	HCl	dH:-9.8 (2SF)	0	MTD	6912
25	10	1	HCl	dH:4.54 (3SF)	0	MTD	6912
26	25	0	Inf. Dilution	dH:-44. (2SF) kJ	0	MCL	6131
27	25	0	Inf. Dilution	dH:-10.5 (3SF)	0	MCL	6912
28	25	0	Inf. Dilution	dH:-44. (2SF) kJ	0	MTD	6912
29	25	0.1	HCl	dH:-12.9 (3SF)	0	MTD	6912
30	25	0.5	HCl	dH:-11.0 (3SF)	0	MTD	6912
31	25	1	HCl	dH:5.02 (3SF)	0	MTD	6912
32	37	0.1	HCl	dH:-13.9 (3SF)	0	MTD	6912
33	37	0.5	HCl	dH:-11.7 (3SF)	0	MTD	6912
34	37	1	HCl	dH:5.26 (3SF)	0	MTD	6912
35	45	0.1	HCl	dH:-14.6 (3SF)	0	MTD	6912
36	45	0.5	HCl	dH:-12.4 (3SF)	0	MTD	6912
37	45	1	HCl	dH:5.74 (3SF)	0	MTD	6912

Reaction No. 498




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.39 (3SF)	5	MGL	999
2	30	0.1	KCl	lgK:4.37 (3SF)	5	MGL	999
3	37	0.15	Blood Plasma	lgK:2.1 (0.05SD)	0	ENS	94
4	37	0.15	NaClO4	lgK:3.855 (4SF)	3	MGL	2181

Reaction No. 499




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.7 (0.05SD)	3	ENS	94

Reaction No. 532



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.65 (3SF)	6	MGL	3511
2	37	0.15	Blood Plasma	lgK:1.2 (0.05SD)	3	ENS	94

Reaction No. 533




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.54 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.3 (0.05SD)	3	ENS	94

Reaction No. 534




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.85 (3SF)	5	MGL	3511
2	25	0.1	Unknown	lgK:1.9 (2SF)	6	CRV	552
3	37	0.15	Blood Plasma	lgK:1.5 (0.05SD)	3	ENS	94

Reaction No. 535




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.3 (0.05SD)	4	ENS	94

Reaction No. 568




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:2.50 (3SF)	3	MGL	905
2	20	0.1	NaClO4	lgK:2.746 (4SF)	4	MGL	3504
3	25	0	NaCl	lgK:2.13 (3SF)	0	MGL	21108
4	25	0.1	NaClO4	lgK:1.92 (3SF)	0	MGL	3180
5	37	0.15	Blood Plasma	lgK:2.3 (0.05SD)	0	ENS	94
6	37	0.15	KNO3	lgK:2.98 (3SF)	5	MGL	3549

Reaction No. 569



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.2 (0.05SD)	4	ENS	94


Reaction No. 570



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.66 (3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:2.7(0.05SD)	4	ENS	94
---	----	------	--------------	-----------------	---	-----	----

Reaction No. 571




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.7(0.05SD)	4	ENS	94

Reaction No. 612




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.96(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.0(0.05SD)	4	ENS	94

Reaction No. 613




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.46(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.5(0.05SD)	4	ENS	94

Reaction No. 614




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2(3SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:10.0(0.05SD)	3	ENS	94

Reaction No. 615



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:17.4(0.05SD)	4	ENS	94

Reaction No. 616



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.5(0.05SD)	3	ENS	94

Reaction No. 617							
$2\text{<Cis-2>} + \text{Ca}+2 + 4\text{<H+1>} = \text{Ca}+2\text{_{H+1(4)_{Cis-2(2)}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:35.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:34.2(0.05SD)	4	ENS	94


Reaction No. 650							
$\text{Glu-2} + \text{Ca}+2 = \text{Ca}+2\text{_{Glu-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.1(2SF)	4	ENS	2152
2	25	0	Inf. Dilution	lgK:2.15(3SF)	4	MGL	6131
3	25	0.1	KCl	lgK:1.43(3SF)	5	MGL	6710
4	25	0.1	KNO3	lgK:2.63(3SF)	0	MGL	22560
5	25	0.16	NaCl	lgK:0.78(2SF)	0	MIX	108
6	25	1	NaCl	lgK:0.60(2SF)	3	MGL	957
7	25	1	NaCl	lgK:0.60(2SF)	5	MGL	957
8	37	0.15	Blood Plasma	lgK:1.5(0.05SD)	4	ENS	94
9	37	0.15	NaCl	lgK:2.17(3SF)	0	MGL	22560
10	37	0.15	NaCl	lgK:1.13(0.09SD)	3	MGL	28777
11	37	0.15	NaCl	lgK:1.43(0.03SD)	3	MIS	28777
12	37	0.15	NaClO4	lgK:1.5(0.04SD)	4	MGL	2181
13	25	0	Inf. Dilution	dH:2.(1SF)kJ	3	MCL	6131

Reaction No. 651							
$\text{H+1} + \text{Glu-2} + \text{Ca}+2 = \text{Ca}+2\text{_{H+1_{Glu-2}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.0(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:11.65(4SF)	0	MGL	6131
3	37	0.15	Blood Plasma	lgK:10.4(0.05SD)	0	ENS	94
4	37	0.15	NaCl	lgK:10.00(0.07SD)	3	MGL	28777
5	37	0.15	NaCl	lgK:10.24(0.12SD)	3	MIS	28777
6	37	0.15	NaClO4	lgK:10.4(0.04SD)	0	MGL	2181
7	25	0	Inf. Dilution	dH:-41.(2SF)kJ	3	MCL	6131

Reaction No. 652							
$2\text{<Glu-2>} + \text{Ca}+2 = \text{Ca}+2\text{_{Glu-2(2)}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:2.86(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.9(0.05SD)	4	ENS	94

Reaction No. 653




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.1(0.05SD)	3	ENS	94

Reaction No. 688




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.65(3SF)	2	EAE	
2	25	0.16	Unknown	lgK:0.18(2SF)	0	MIX	108
3	37	0.15	Blood Plasma	lgK:1.0(0.05SD)	0	ENS	94
4	37	0.15	NaCl	lgK:2.17(3SF)	5	MGL	22560

Reaction No. 689




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.64(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.4(0.05SD)	3	ENS	94

Reaction No. 690




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.12(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.4(0.05SD)	3	ENS	94

Reaction No. 691




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.4(0.05SD)	4	ENS	94

Reaction No. 753



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.1	HCl	lgK:1.25 (3SF)	5	MGL	6912
2	10	0.25	Unknown	lgK:0.9 (0.07SD)	5	MGL	1045
3	10	0.5	HCl	lgK:1.26 (3SF)	5	MGL	6912
4	10	1	HCl	lgK:1.36 (3SF)	5	MGL	6912
5	25	0	Inf. Dilution	lgK:1.43 (3SF)	4	MGL	1045
6	25	0	Inf. Dilution	lgK:1.55 (3SF)	4	MPH	6131
7	25	0	Inf. Dilution	lgK:1.55 (0.06MD)	4	MGL	6912
8	25	0.1	HCl	lgK:1.21 (3SF)	5	MGL	6912
9	25	0.25	Unknown	lgK:1. (0.07SD)	5	MGL	1045
10	25	0.5	HCl	lgK:1.23 (3SF)	5	MGL	6912
11	25	1	HCl	lgK:1.37 (3SF)	5	MGL	6912
12	35	0.1	KNO3	lgK:2.72 (3SF)	0	MGL	22560
13	37	0.1	HCl	lgK:1.18 (3SF)	5	MGL	6912
14	37	0.15	Blood Plasma	lgK:1.4 (0.05SD)	3	ENS	94
15	37	0.25	Unknown	lgK:1.0 (0.1SD)	5	MGL	1045
16	37	0.5	HCl	lgK:1.21 (3SF)	5	MGL	6912
17	37	1	HCl	lgK:1.38 (3SF)	5	MGL	6912
18	45	0.1	HCl	lgK:1.17 (3SF)	5	MGL	6912
19	45	0.5	HCl	lgK:1.20 (3SF)	5	MGL	6912
20	45	1	HCl	lgK:1.38 (3SF)	5	MGL	6912
21	10:37	0.5	HCl	dH:-0.71 (2SF)	5	MTD	6912
22	10:45	0.1	HCl	dH:-0.96 (2SF)	5	MTD	6912
23	10:45	1	HCl	dH:0.24 (2SF)	5	MTD	6912
24	25	0	Inf. Dilution	dH:-5. (1SF) kJ	4	MCL	1045
25	25	0	Inf. Dilution	dH:-5. (1SF) kJ	4	MCL	6131
26	25	0	Inf. Dilution	dH:-0.72 (2SF)	4	MCL	6912
27	25	0.1	Unknown	dH:1.0 (2SF)	4	CRV	552
28	45	0.5	HCl	dH:-0.96 (2SF)	5	MTD	6912


Reaction No. 754



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.25	Unknown	lgK:9.8 (0.08SD)	5	MGL	1045
2	10:45	0.1	HCl	lgK:10.15 (4SF)	5	MGL	6912
3	25	0	Inf. Dilution	lgK:9.52 (3SF)	4	MGL	1045

4	25	0	Inf. Dilution	lgK:9.93 (3SF)	4	MPH	6131
5	25	0	Inf. Dilution	lgK:9.9 (0.1MD)	4	MGL	6912
6	25	0.25	Unknown	lgK:9.4 (0.08SD)	5	MGL	1045
7	25:45	0.1	HCl	lgK:9.79 (3SF)	5	MGL	6912
8	37	0.15	Blood Plasma	lgK:9.7 (0.05SD)	3	ENS	94
9	37	0.25	Unknown	lgK:9.2 (0.1SD)	5	MGL	1045
10	37:45	0.1	HCl	lgK:9.51 (3SF)	5	MGL	6912
11	10	0.5	HCl	lgR:10.26 (4SF)	5	MGL	6912
12	10	1	HCl	lgR:10.44 (4SF)	5	MGL	6912
13	25	0.5	HCl	lgR:9.87 (3SF)	5	MGL	6912
14	25	1	HCl	lgR:10.01 (4SF)	5	MGL	6912
15	37	0.5	HCl	lgR:9.55 (3SF)	5	MGL	6912
16	37	1	HCl	lgR:9.67 (3SF)	5	MGL	6912
17	45	0.1	HCl	lgR:9.32 (3SF)	5	MGL	6912
18	45	0.5	HCl	lgR:9.34 (3SF)	5	MGL	6912
19	45	1	HCl	lgR:9.44 (3SF)	5	MGL	6912
20	10	0.1	HCl	dH:-8.84 (3SF)	5	MTD	6912
21	10	0.5	HCl	dH:-9.56 (3SF)	5	MTD	6912
22	10	1	HCl	dH:-10.5 (3SF)	5	MTD	6912
23	25	0	Inf. Dilution	dH:-36. (2SF) kJ	4	MCL	1045
24	25	0	Inf. Dilution	dH:-40. (2SF) kJ	4	MCL	6131
25	25	0	Inf. Dilution	dH:-9.32 (3SF)	4	MCL	6912
26	25	0.1	HCl	dH:-9.8 (2SF)	5	MTD	6912
27	25	0.5	HCl	dH:-10.76 (4SF)	5	MTD	6912
28	25	1	HCl	dH:-11.7 (3SF)	5	MTD	6912
29	37	0.1	HCl	dH:-10.5 (3SF)	5	MTD	6912
30	37	0.5	HCl	dH:-11.7 (3SF)	5	MTD	6912
31	37	1	HCl	dH:-12.67 (4SF)	5	MTD	6912
32	45	0.1	HCl	dH:-11.0 (3SF)	5	MTD	6912
33	45	0.5	HCl	dH:-12.2 (3SF)	5	MTD	6912
34	45	1	HCl	dH:-13.15 (4SF)	5	MTD	6912


Reaction No. 755



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.52 (3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:1.8(0.05SD)	4	ENS	94
---	----	------	--------------	-----------------	---	-----	----

Reaction No. 756




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.9(0.05SD)	4	ENS	94

Reaction No. 820




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	KCl	lgK:9.58(3SF)	0	MGL	2117
2	25	0.16	Unknown	lgK:0.48(2SF)	6	MIX	108
3	37	0.15	Blood Plasma	lgK:1.0(0.05SD)	6	ENS	94

Reaction No. 821




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.8(0.05SD)	3	ENS	94

Reaction No. 822




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.02(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.3(0.05SD)	3	ENS	94

Reaction No. 823



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.4(0.05SD)	3	ENS	94


Reaction No. 851



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.58(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:1.1(0.05SD)	3	ENS	94
---	----	------	--------------	-----------------	---	-----	----

Reaction No. 852




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.9(0.05SD)	3	ENS	94

Reaction No. 853




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.12(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.4(0.05SD)	3	ENS	94

Reaction No. 854




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.6(0.05SD)	3	ENS	94

Reaction No. 887




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.2(2SF)	2	EES	
2	25	0.1	KNO3	lgK:3.96(3SF)	0	MGL	1089
3	37	0.15	Blood Plasma	lgK:1.1(0.05SD)	3	ENS	94

Reaction No. 888



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.9(0.05SD)	3	ENS	94


Reaction No. 889



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.12(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:1.4(0.05SD)	3	ENS	94
---	----	------	--------------	-----------------	---	-----	----

Reaction No. 890




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.6(0.05SD)	3	ENS	94

Reaction No. 926




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.40(3SF)	4	MPH	6131
2	37	0.15	Blood Plasma	lgK:1.0(0.05SD)	4	ENS	94
3	25	0	Inf. Dilution	dH:-6.(1SF)kJ	4	MCL	6131

Reaction No. 927




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.02(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.3(0.05SD)	3	ENS	94

Reaction No. 928




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.67(4SF)	4	MPH	6131
2	37	0.15	Blood Plasma	lgK:11.6(0.05SD)	0	ENS	94
3	25	0	Inf. Dilution	dH:-50.(2SF)kJ	4	MCL	6131

Reaction No. 929




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.05(4SF)	4	MPH	6131
2	37	0.15	Blood Plasma	lgK:20.8(0.05SD)	3	ENS	94
3	25	0	Inf. Dilution	dH:-95.(2SF)kJ	4	MCL	6131

Reaction No. 930




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.8(0.05SD)	4	ENS	94

Reaction No. 931




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:39.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:39.7(0.05SD)	3	ENS	94

Reaction No. 975




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	Unknown	lgK:-0.66(2SF)	4	MIX	108
2	37	0.15	Blood Plasma	lgK:1.2(0.05SD)	3	ENS	94

Reaction No. 976




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.74(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.5(0.05SD)	3	ENS	94

Reaction No. 977




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.32(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.6(0.05SD)	3	ENS	94

Reaction No. 978



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.7(0.05SD)	4	ENS	94


Reaction No. 1007



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:1.48(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.0(0.05SD)	6	ENS	94

Reaction No. 1008




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.02(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.3(0.05SD)	3	ENS	94

Reaction No. 1009




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.4(0.05SD)	3	ENS	94

Reaction No. 1010




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.29(4SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:11.4(0.05SD)	0	ENS	94

Reaction No. 1011




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.3(0.05SD)	4	ENS	94

Reaction No. 1012



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:37.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:38.5(0.05SD)	4	ENS	94


Reaction No. 1052



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.48(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:1.0(0.05SD)	6	ENS	94
---	----	------	--------------	-----------------	---	-----	----

Reaction No. 1053




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.64(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.4(0.05SD)	3	ENS	94

Reaction No. 1054




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.32(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.6(0.05SD)	3	ENS	94

Reaction No. 1055




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.6(0.05SD)	4	ENS	94

Reaction No. 1084




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.78(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.3(0.05SD)	3	MGL	94

Reaction No. 1085



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.5(0.05SD)	4	ENS	94

Reaction No. 1086



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.42(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.7(0.05SD)	3	ENS	94

Reaction No. 1087							
$2\text{<Pro-1>} + \text{Ca}^{+2} + 2\text{<H+1>} = \text{Ca}^{+2}\text{_{H+1(2)_{Pro-1(2)}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.8(0.05SD)	4	ENS	94

Reaction No. 1122							
$\text{Ser-1} + \text{Ca}^{+2} = \text{Ca}^{+2}\text{_{Ser-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.43(3SF)	4	MGL	999
2	25	0	Inf. Dilution	lgK:1.50(3SF)	4	MPH	6131
3	25	0	UCT_Sea	lgK:1.43(0.01SD)	4	EDH	5390
4	25	0.1	KNO3	lgK:3.59(3SF)	0	MGL	1089
5	25	0.1	UCT_Sea	lgK:1.05(0.01SD)	4	EDH	5390
6	25	0.16	Unknown	lgK:0.5(1SF)	0	MIX	108
7	25	0.2	UCT_Sea	lgK:0.97(0.01SD)	4	EDH	5390
8	25	0.3	UCT_Sea	lgK:0.93(0.01SD)	4	EDH	5390
9	25	0.4	UCT_Sea	lgK:0.91(0.01SD)	4	EDH	5390
10	25	0.5	UCT_Sea	lgK:0.89(0.01SD)	4	EDH	5390
11	25	0.6	UCT_Sea	lgK:0.88(0.01SD)	4	EDH	5390
12	25	0.7	UCT_Sea	lgK:0.87(0.01SD)	4	EDH	5390
13	25	3	NaCl	lgK:1.0(0.04SD)	6	MGL	1276
14	37	0.15	Blood Plasma	lgK:1.3(0.05SD)	3	ENS	94
15	25	0	Inf. Dilution	dH:10.(2SF)kJ	4	MCL	6131

Reaction No. 1123							
$\text{H+1} + \text{Ser-1} + \text{Ca}^{+2} = \text{Ca}^{+2}\text{_{H+1_{Ser-1}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.6(2SF)	4	MPH	6131
2	37	0.15	Blood Plasma	lgK:9.5(0.05SD)	3	ENS	94
3	25	0	Inf. Dilution	dH:-35.(2SF)kJ	4	MCL	6131

Reaction No. 1124							
$2\text{<Ser-1>} + \text{Ca}^{+2} = \text{Ca}^{+2}\text{_{Ser-1(2)}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.42(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.7(0.05SD)	3	ENS	94

Reaction No. 1125							
$2\text{<Ser-1>} + \text{Ca}^{+2} + 2\text{<H+1>} = \text{Ca}^{+2}\text{_{H+1(2)}_Ser-1(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.6(0.05SD)	4	ENS	94

Reaction No. 1159							
$\text{Thr-1} + \text{Ca}^{+2} = \text{Ca}^{+2}\text{_{Thr-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.58(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.1(0.05SD)	3	ENS	94

Reaction No. 1160							
$\text{Thr-1} + \text{Ca}^{+2} + \text{H}^{+1} = \text{Ca}^{+2}\text{_{H+1_Thr-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.74(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.5(0.05SD)	3	ENS	94

Reaction No. 1161							
$2\text{<Thr-1>} + \text{Ca}^{+2} = \text{Ca}^{+2}\text{_{Thr-1(2)}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.12(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.4(0.05SD)	3	ENS	94

Reaction No. 1162							
$2\text{<Thr-1>} + \text{Ca}^{+2} + 2\text{<H+1>} = \text{Ca}^{+2}\text{_{H+1(2)}_Thr-1(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.5(0.05SD)	4	ENS	94

Reaction No. 1195							
$\text{Trp-1} + \text{Ca}^{+2} = \text{Ca}^{+2}\text{_{Trp-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.23(3SF)	4	MGL	2261
2	37	0.15	Blood Plasma	lgK:1.2(0.05SD)	3	ENS	94

Reaction No. 1196							
-------------------	--	--	--	--	--	--	--

Trp-1 + Ca+2 + H+1 = Ca+2_H+1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.94(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.7(0.05SD)	3	ENS	94

Reaction No. 1197							
2<Trp-1> + Ca+2 = Ca+2_Trp-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.32(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.6(0.05SD)	3	ENS	94

Reaction No. 1198							
2<Trp-1> + Ca+2 + 2<H+1> = Ca+2_H+1(2)_Trp-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.1(0.05SD)	4	ENS	94

Reaction No. 1233							
Tyr-2 + Ca+2 = Ca+2_Tyr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.96(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.0(0.05SD)	4	ENS	94


Reaction No. 1234							
2<Tyr-2> + Ca+2 = Ca+2_Tyr-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.16(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.2(0.05SD)	3	ENS	94

Reaction No. 1235							
Tyr-2 + Ca+2 + H+1 = Ca+2_H+1_Tyr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.2(0.05SD)	4	ENS	94

Reaction No. 1236							
Tyr-2 + Ca+2 + 2<H+1> = Ca+2_H+1(2)_Tyr-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.5(0.05SD)	3	ENS	94

Reaction No. 1237




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.6(0.05SD)	3	ENS	94

Reaction No. 1238




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:40.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:38.8(0.05SD)	4	ENS	94

Reaction No. 1283




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.4(0.05SD)	3	ENS	94

Reaction No. 1284




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.12(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.4(0.05SD)	3	ENS	94

Reaction No. 1285



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.8(0.05SD)	3	ENS	94

Reaction No. 1286



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0	Inf. Dilution	lgK:1.58 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.1 (0.05SD)	3	ENS	94

Reaction No. 1322							
CO3-2 + Ca+2 = Ca+2_CO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5.5	0	Inf. Dilution	lgK:3.13 (3SF)	4	EMU	5416
2	5.5	0	Inf. Dilution	lgK:3.13 (3SF)	4	MSL	6346
3	22	0	Inf. Dilution	lgK:4.39 (3SF) w	0	MPH	5398
Note (3): Low wgt for internal consistency							
4	25	0	Inf. Dilution	lgK:3.1 (0.03SD)	5	CMN	332
5	25	0	Inf. Dilution	lgK:3.2 (2SF)	4	EES	5398
6	25	0	Inf. Dilution	lgK:3.15 (3SF)	4	MGL	5398
7	25	0	Inf. Dilution	lgK:3.1 (2SF)	4	MSL	5398
8	25	0	Inf. Dilution	lgK:4.48 (3SF)	0	MSC	5398
9	25	0	Inf. Dilution	lgK:3.20 (3SF)	4	EMU	5416
10	25	0	Inf. Dilution	lgK:3.22 (3SF)	3	CRV	6232
11	25	0	Inf. Dilution	lgK:3.22 (3SF)	6	MSL	6346
12	25	0	Inf. Dilution	lgK:3.22 (3SF)	7	MSL	6346
13	25	0	Inf. Dilution	lgK:3.15 (3SF)	6	MGL	6350
14	25	0	Inf. Dilution	lgK:3.224 (4SF)	4	ENS	6496
15	25	0	Inf. Dilution	lgK:3.2 (0.05SD)	5	CMN	7391
16	25	0	Inf. Dilution	lgK:3.92 (3SF)	0	ENS	7391
Note (16): Low wgt for internal consistency							
17	25	0	Inf. Dilution	lgK:4.44 (3SF)	0	MSL	8385
18	25	0	Inf. Dilution	lgK:3.15 (3SF)	4	CRV	8749
19	25	0	Inf. Dilution	lgK:3.15 (3SF)	5	MSC	9065
20	25	0	Inf. Dilution	lgK:3.15 (3SF)	5	CRV	9402
21	25	0	Inf. Dilution	lgK:3.20 (3SF)	3	EOD	31694
Note (21): from Garrels & Thompson, 1962							
22	25	0	Inf. Dilution	lgK:3.15 (3SF)	4	CRV	32224
23	25	0	CHEMVAL1	lgK:3.15 (0.01SD)	0	ENS	5156
24	25	0	CHEMVAL2	lgK:3.15 (0.01SD)	0	ENS	5156
25	25	0	CHEMVAL3	lgK:3.15 (0.01SD)	0	ENS	5156
26	25	0	CHEMVAL4	lgK:3.15 (0.01SD)	5	ENS	5156
27	25	0	SOLMNEQ	lgK:3.20 (3SF)	4	CMN	5416

28	25	0	SOLVEQ	lgK:3.22 (3SF)	0	CMN	5416
29	25	0	UCT_Sea	lgK:3.15 (0.01SD)	4	EDH	5390
30	25	0	Unknown	lgK:3.225 (4SF)	3	ENS	7373
31	25	0	WATCH	lgK:3.14 (3SF)	4	CMN	5416
32	25	0	WATEQF	lgK:3.16 (3SF)	4	CMN	5416
33	25	0.1	UCT_Sea	lgK:2.38 (0.01SD)	4	EDH	5390
34	25	0.2	UCT_Sea	lgK:2.25 (0.01SD)	4	EDH	5390
35	25	0.3	UCT_Sea	lgK:2.20 (0.01SD)	4	EDH	5390
36	25	0.4	UCT_Sea	lgK:2.18 (0.01SD)	4	EDH	5390
37	25	0.5	UCT_Sea	lgK:2.18 (0.01SD)	4	EDH	5390
38	25	0.6	NaCl	lgK:2.45 (3SF)	3	MPT	8898
39	25	0.6	UCT_Sea	lgK:2.19 (0.01SD)	4	EDH	5390
40	25	0.7	NaCl	lgK:1.5 (2SF)	0	EES	5398
41	25	0.7	UCT_Sea	lgK:2.21 (0.01SD)	4	EDH	5390
42	25	0.7	Unknown	lgK:2.2 (0.05SD)	5	MEF	4996
43	25	0.7	Unknown	lgK:2.21 (3SF)	5	MEF	5398
44	25	0.7	Unknown	lgK:2.21 (3SF)	4	EOD	5644
45	25	0.7	Unknown	lgK:2.1 (0.1SD)	3	CMN	7391
46	25	1	NaCl	lgK:1.22 (3SF)	0	MDS	5398
47	35	0	Inf. Dilution	lgK:3.22 (3SF)	4	CRV	8749
48	37	0	Inf. Dilution	lgK:3.2 (2SF)	2	CRV	28703
49	37	0.15	Blood Plasma	lgK:2.9 (0.05SD)	0	ENS	94
50	40	0	Inf. Dilution	lgK:3.42 (3SF)	4	EMU	5416
51	40	0	Inf. Dilution	lgK:3.38 (3SF)	7	MSL	6346
52	50	0	Inf. Dilution	lgK:3.4 (2SF)	4	EES	5398
53	50	0	Inf. Dilution	lgK:3.32 (3SF)	4	CRV	8749
54	50	0	SOLMNEQ	lgK:3.40 (3SF)	4	CMN	5416
55	50	0	SOLVEQ	lgK:3.55 (3SF)	0	CMN	5416
56	50	0	WATCH	lgK:3.40 (3SF)	4	CMN	5416
57	50	0	WATEQF	lgK:3.50 (3SF)	4	CMN	5416
58	60	0	Inf. Dilution	lgK:3.5 (2SF)	4	EES	5398
59	60	0	Inf. Dilution	lgK:5.34 (3SF) w	0	MPH	5398
60	60	0	Inf. Dilution	lgK:3.63 (3SF)	4	EMU	5416
61	60	0	Inf. Dilution	lgK:3.65 (3SF)	4	MSL	6346
62	70	0	Inf. Dilution	lgK:5.55 (3SF) w	0	MPH	5398
63	75	0	SOLMNEQ	lgK:3.65 (3SF)	4	CMN	5416

64	75	0	WATCH	lgK:3.68 (3SF)	4	CMN	5416
65	75	0	WATEQF	lgK:3.99 (3SF)	0	CMN	5416
66	80	0	Inf. Dilution	lgK:5.74 (3SF)w	0	MPH	5398
67	80	0	Inf. Dilution	lgK:3.92 (3SF)	0	EMU	5416
68	80	0	Inf. Dilution	lgK:3.92 (3SF)	4	MSL	6346
69	90	0	Inf. Dilution	lgK:5.82 (3SF)w	0	MPH	5398
Note (69): Low wgt for internal consistency							
70	98	0	Inf. Dilution	lgK:6.00 (3SF)w	0	MPH	5398
71	100	0	Inf. Dilution	lgK:3.9 (2SF)	4	EES	5398
72	100	0	SOLMNEQ	lgK:3.90 (3SF)	4	CMN	5416
73	100	0	SOLVEQ	lgK:3.76 (3SF)	0	CMN	5416
74	100	0	WATCH	lgK:3.99 (3SF)	4	CMN	5416
75	100	0	WATEQF	lgK:4.60 (3SF)	0	CMN	5416
76	125	0	SOLMNEQ	lgK:4.15 (3SF)	3	CMN	5416
77	125	0	WATCH	lgK:4.32 (3SF)	3	CMN	5416
78	125	0	WATEQF	lgK:5.32 (3SF)	0	CMN	5416
79	150	0	Inf. Dilution	lgK:4.5 (2SF)	4	EES	5398
80	150	0	SOLMNEQ	lgK:4.50 (3SF)	3	CMN	5416
81	150	0	SOLVEQ	lgK:4.27 (3SF)	0	CMN	5416
82	150	0	WATCH	lgK:4.67 (3SF)	3	CMN	5416
83	150	0	WATEQF	lgK:6.11 (3SF)	0	CMN	5416
84	175	0	SOLMNEQ	lgK:4.85 (3SF)	3	CMN	5416
85	175	0	WATCH	lgK:5.04 (3SF)	3	CMN	5416
86	175	0	WATEQF	lgK:6.97 (3SF)	0	CMN	5416
87	200	0	Inf. Dilution	lgK:5.2 (2SF)	4	EES	5398
88	200	0	SOLMNEQ	lgK:5.20 (3SF)	3	CMN	5416
89	200	0	SOLVEQ	lgK:5.06 (3SF)	0	CMN	5416
90	200	0	WATCH	lgK:5.44 (3SF)	3	CMN	5416
91	200	0	WATEQF	lgK:7.89 (3SF)	0	CMN	5416
92	225	0	SOLMNEQ	lgK:5.56 (3SF)	3	CMN	5416
93	225	0	WATCH	lgK:5.86 (3SF)	3	CMN	5416
94	225	0	WATEQF	lgK:8.86 (3SF)	0	CMN	5416
95	250	0	SOLMNEQ	lgK:5.90 (3SF)	3	CMN	5416
96	250	0	SOLVEQ	lgK:6.13 (3SF)	0	CMN	5416
97	250	0	WATCH	lgK:6.30 (3SF)	3	CMN	5416
98	250	0	WATEQF	lgK:9.87 (3SF)	0	CMN	5416

99	275	0	SOLMNEQ	lgK:6.18 (3SF)	0	CMN	5416
100	275	0	WATCH	lgK:6.76 (3SF)	0	CMN	5416
101	275	0	WATEQF	lgK:10.92 (4SF)	0	CMN	5416
102	300	0	SOLMNEQ	lgK:6.45 (3SF)	0	CMN	5416
103	300	0	SOLVEQ	lgK:7.93 (3SF)	0	CMN	5416
104	300	0	WATCH	lgK:7.25 (3SF)	0	CMN	5416
105	300	0	WATEQF	lgK:12.00 (4SF)	0	CMN	5416
106	325	0	SOLMNEQ	lgK:6.72 (3SF)	0	CMN	5416
107	325	0	WATCH	lgK:7.75 (3SF)	0	CMN	5416
108	325	0	WATEQF	lgK:13.10 (4SF)	0	CMN	5416
109	350	0	SOLMNEQ	lgK:7.00 (3SF)	0	CMN	5416
110	350	0	WATCH	lgK:8.28 (3SF)	0	CMN	5416
111	350	0	WATEQF	lgK:14.23 (4SF)	0	CMN	5416
112	10:50	0	Inf. Dilution	dH:4. (0.3SD)	5	CSM	233
113	25	0	Inf. Dilution	dH:4.025 (4SF)	4	MTD	5416
114	25	0	Inf. Dilution	dH:3.545 (4SF)	4	ENS	6496
115	25	0	Inf. Dilution	dH:4.00 (3SF)	5	CRV	9402
116	25	0	Unknown	dH:3.547 (4SF)	3	ENS	7373


Reaction No. 1323							
H+1 + CO3-2 + Ca+2 = Ca+2_H+1_CO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.4 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:11.59 (4SF)	0	ENS	6405
3	25	0	Inf. Dilution	lgK:11.35 (4SF)	0	CRV	9402
4	25	0	Inf. Dilution	lgK:11.599 (5SF)	3	EOD	21825
5	25	0	Inf. Dilution	lgK:11.33 (4SF)	4	CRV	32224
6	25	0	CHEMVAL1	lgK:11.43 (0.01SD)	0	ENS	5156
7	25	0	CHEMVAL2	lgK:11.43 (0.01SD)	0	ENS	5156
8	25	0	CHEMVAL3	lgK:11.43 (0.01SD)	0	ENS	5156
9	25	0	CHEMVAL4	lgK:11.60 (0.01SD)	0	ENS	5156
10	25	0	UCT_Sea	lgK:11.58 (0.01SD)	0	EDH	5390
11	25	0	Unknown	lgK:11.453 (5SF)	0	ENS	7373
12	25	0.1	UCT_Sea	lgK:10.75 (0.01SD)	0	EDH	5390
13	25	0.2	UCT_Sea	lgK:10.51 (0.01SD)	0	EDH	5390
14	25	0.3	UCT_Sea	lgK:10.32 (0.01SD)	0	EDH	5390

15	25	0.4	UCT_Sea	lgK:10.18(0.01SD)	0	EDH	5390
16	25	0.5	UCT_Sea	lgK:10.05(0.01SD)	0	EDH	5390
17	25	0.6	UCT_Sea	lgK:9.94(0.01SD)	0	EDH	5390
18	25	0.7	UCT_Sea	lgK:9.83(0.01SD)	0	EDH	5390
19	25	0.7	Unknown	lgK:9.90(3SF)	0	EOD	5644
20	37	0	Inf. Dilution	lgK:11.6(3SF)	2	CRV	28703
21	37	0.15	Blood Plasma	lgK:10.9(0.05SD)	0	ENS	94
22	100	0	Inf. Dilution	lgK:12.2(3SF)	0	ELC	
23	25	0	Unknown	dH:-0.869(3SF)	0	ENS	7373

Reaction No. 1386							
PO4-3 + Ca+2 = Ca+2_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.46(0.05SD)	4	MGL	245
2	25	0	Inf. Dilution	lgK:6.46(3SF)	4	MGL	931
3	25	0	Inf. Dilution	lgK:6.46(0.02SD)	4	CMN	7391
4	25	0	Inf. Dilution	lgK:6.46(3SF)	4	EFE	8710
5	25	0	Inf. Dilution	lgK:7.10(3SF)	0	CRV	8749
6	25	0	Inf. Dilution	lgK:6.46(3SF)	5	CRV	9402
7	25	0	Inf. Dilution	lgK:6.46(3SF)	3	EOD	31694
Note (7): from Chughtai, Marshall & Nancollas, 1968							
8	25	0	Inf. Dilution	lgK:6.46(3SF)	4	CRV	32224
9	25	0	CHEMVAL2	lgK:6.46(0.01SD)	0	ENS	5156
10	25	0	CHEMVAL3	lgK:6.46(0.01SD)	0	ENS	5156
11	25	0	CHEMVAL4	lgK:6.46(0.01SD)	4	ENS	5156
12	25	0	UCT_Sea	lgK:6.46(0.01SD)	4	EDH	5390
13	25	0.1	Inert	lgK:5.44(3SF)	2	EFE	8710
14	25	0.1	UCT_Sea	lgK:5.20(0.01SD)	4	EDH	5390
15	25	0.15	NaCl	lgK:1.3(2SF)	0	MCT	22612
16	25	0.2	UCT_Sea	lgK:4.92(0.01SD)	4	EDH	5390
17	25	0.3	UCT_Sea	lgK:4.76(0.01SD)	4	EDH	5390
18	25	0.4	UCT_Sea	lgK:4.65(0.01SD)	4	EDH	5390
19	25	0.5	UCT_Sea	lgK:4.58(0.01SD)	4	EDH	5390
20	25	0.6	UCT_Sea	lgK:4.53(0.01SD)	4	EDH	5390
21	25	0.68	Unknown	lgK:4.98(3SF)	3	MGL	7177
22	25	0.7	UCT_Sea	lgK:4.50(0.01SD)	4	EDH	5390

23	25	0.7	Unknown	lgK:4.98 (3SF)	3	ENS	7177
24	25	0.7	Unknown	lgK:4.5 (0.1SD)	6	CMN	7391
25	25	0.7	Unknown	lgK:4.80 (3SF)	3	ENS	7391
26	37	0	Inf. Dilution	lgK:6.54 (3SF)	4	MGL	245
27	37	0	Inf. Dilution	lgK:6.3 (2SF)	3	ENS	931
28	37	0	Inf. Dilution	lgK:6.13 (3SF)	3	MGL	5068
29	37	0	Inf. Dilution	lgK:6.52 (3SF)	2	CRV	28703
30	37	0.01	KCl	lgK:6.13 (0.05SD)	5	MGL	5068
31	37	0.1	KCl	lgK:6.15 (0.02SD)	0	MGL	32047
32	37	0.15	Blood Plasma	lgK:6.1 (0.05SD)	0	ENS	94
33	37	0.15	NaCl	lgK:1.4 (2SF)	0	MCT	22612
34	37	0.4	Unknown	lgK:5.15 (3SF)	3	EOD	29777
35	38	0	Inf. Dilution	lgK:6.54 (3SF)	3	CRV	8692
36	25	0	Inf. Dilution	dG:-8.81 (0.03SD)	5	MPT	245
37	25	0	Inf. Dilution	dH:3.1 (2.0SD)	5	MTD	245
38	25	0	Inf. Dilution	dH:3.00 (3SF)	5	CRV	9402
39	25:37	0	Inf. Dilution	dH:3.1 (2.0SD)	4	MCL	245


Reaction No. 1387



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.10 (4SF)	3	CRV	9402
2	25	0	Inf. Dilution	lgK:15.035 (5SF)	3	EOD	21825
3	25	0	Inf. Dilution	lgK:15.05 (4SF)	4	CRV	32224
4	25	0	CHEMVAL2	lgK:15.09 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:15.09 (0.01SD)	3	ENS	5156
6	25	0	CHEMVAL4	lgK:14.90 (0.01SD)	0	ENS	5156
7	25	0	UCT_Sea	lgK:15.01 (0.01SD)	0	EDH	5390
8	25	0.1	UCT_Sea	lgK:13.54 (0.01SD)	0	EDH	5390
9	25	0.2	UCT_Sea	lgK:13.18 (0.01SD)	0	EDH	5390
10	25	0.3	UCT_Sea	lgK:12.97 (0.01SD)	0	EDH	5390
11	25	0.4	UCT_Sea	lgK:12.81 (0.01SD)	0	EDH	5390
12	25	0.5	UCT_Sea	lgK:12.61 (0.01SD)	0	EDH	5390
13	25	0.6	UCT_Sea	lgK:12.61 (0.01SD)	0	EDH	5390
14	25	0.7	UCT_Sea	lgK:12.56 (0.01SD)	0	EDH	5390
15	37	0	Inf. Dilution	lgK:14.99 (4SF)	2	CRV	28703


16	37	0.15	Blood Plasma	lgK:12.7(0.05SD)	0	ENS	94
17	37	0.15	NaCl	lgK:13.285(5SF)	3	CRV	22388
18	25	0	Inf. Dilution	dH:-0.50(2SF)	5	CRV	9402

Reaction No. 1388




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.95(4SF)	3	CRV	9402
2	25	0	Inf. Dilution	lgK:20.923(5SF)	3	EOD	21825
3	25	0	Inf. Dilution	lgK:20.93(4SF)	3	CRV	32224
4	25	0	CHEMVAL2	lgK:20.95(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:20.95(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:20.60(0.01SD)	0	ENS	5156
7	25	0	UCT_Sea	lgK:20.55(0.01SD)	0	EDH	5390
8	25	0.1	UCT_Sea	lgK:19.07(0.01SD)	0	EDH	5390
9	25	0.2	UCT_Sea	lgK:18.68(0.01SD)	0	EDH	5390
10	25	0.3	UCT_Sea	lgK:18.43(0.01SD)	0	EDH	5390
11	25	0.4	UCT_Sea	lgK:18.25(0.01SD)	0	EDH	5390
12	25	0.5	UCT_Sea	lgK:18.09(0.01SD)	0	EDH	5390
13	25	0.6	UCT_Sea	lgK:17.98(0.01SD)	0	EDH	5390
14	25	0.7	UCT_Sea	lgK:17.88(0.01SD)	0	EDH	5390
15	37	0	Inf. Dilution	lgK:20.71(4SF)	2	CRV	28703
16	37	0.15	Blood Plasma	lgK:18.6(0.05SD)	0	ENS	94
17	37	0.15	NaCl	lgK:19.023(5SF)	4	CRV	22388
18	25	0	Inf. Dilution	dH:-1.30(3SF)	5	CRV	9402

Reaction No. 1390



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:35.7(3SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:32.3(0.05SD)	0	ENS	94

Reaction No. 1391



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:27.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:25.3(0.05SD)	4	ENS	94

Reaction No. 1425							
SiH2O4-2 + Ca+2 = Ca+2_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:4.36(0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:3.58(0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:3.41(0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:3.32(0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:3.25(0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:3.21(0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:3.17(0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:3.14(0.01SD)	4	EDH	5390
9	25	1	NaClO4	lgK:3.1(0.05SD)	5	MIS	455
10	37	0.15	Blood Plasma	lgK:3.0(0.05SD)	4	ENS	94

Reaction No. 1426							
SiH2O4-2 + Ca+2 + H+1 = Ca+2_H+1_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.3(3SF)	1	ELC	
2	25	0	UCT_Sea	lgK:14.08(0.01SD)	0	EDH	5390
3	25	0.1	UCT_Sea	lgK:13.31(0.01SD)	0	EDH	5390
4	25	0.2	UCT_Sea	lgK:13.13(0.01SD)	0	EDH	5390
5	25	0.3	UCT_Sea	lgK:13.08(0.01SD)	0	EDH	5390
6	25	0.4	UCT_Sea	lgK:13.02(0.01SD)	0	EDH	5390
7	25	0.5	UCT_Sea	lgK:12.98(0.01SD)	0	EDH	5390
8	25	0.6	UCT_Sea	lgK:12.96(0.01SD)	0	EDH	5390
9	25	0.7	UCT_Sea	lgK:12.94(0.01SD)	0	EDH	5390
10	37	0.15	Blood Plasma	lgK:11.8(0.05SD)	0	ENS	94

Reaction No. 1427							
2<SiH2O4-2> + Ca+2 + 2<H+1> = Ca+2_H+1(2)_SiH2O4-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:30.02(0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:28.65(0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:28.39(0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:28.24(0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:28.13(0.01SD)	4	EDH	5390

6	25	0.5	UCT_Sea	lgK:28.06(0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:28.02(0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:27.99(0.01SD)	4	EDH	5390
9	37	0.15	Blood Plasma	lgK:25.7(0.05SD)	4	ENS	94

Reaction No. 1487							
Ascorbic-2 + Ca+2 + H+1 = Ca+2_H+1_Ascorbic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.5(0.05SD)	3	ENS	94

Reaction No. 1504							
2<Citric-3> + Ca+2 = Ca+2_Citric-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.8(2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:8.02(3SF)	0	MGL	22560
3	37	0.15	Blood Plasma	lgK:4.0(0.05SD)	0	ENS	94
4	37	0.15	NaCl	lgK:4.61(0.12SD)	3	MGL	28777
5	37	0.15	NaCl	lgK:4.73(0.08SD)	3	MIS	28777
6	37	0.15	NaClO4	lgK:4.965(0.044SD)	4	MGL	2181

Reaction No. 1505							
H+1 + Citric-3 + Ca+2 = Ca+2_H+1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.5(2SF)	3	ENS	2152
2	25	0	Inf. Dilution	lgK:3.02(3SF)	0	CRV	8903
Note (2): Value in MINTEQA2 database now diagnosed as being in error							
3	25	0	Unknown	lgK:9.23(3SF)	2	MGL	17779
4	25	0.1	KNO3	lgK:8.0(0.2SD)	5	MGL	3519
5	25	0.1	NaCl	lgK:8.3(0.2SD)	0	MGL	3925
6	25	0.5	NaClO4	lgK:6.7(0.09MD)	0	MGL	4896
7	37	0.03:0.3	KNO3	lgK:7.81(3SF)	0	MGL	9424
8	37	0	Inf. Dilution	lgK:9.28(3SF)	2	CRV	28703
9	37	0.1	Inert	lgK:7.97(3SF)	3	CRV	29801
10	37	0.15	Blood Plasma	lgK:7.5(0.05SD)	2	ENS	94
11	37	0.15	NaCl	lgK:7.614(4SF)	4	CRV	22388
12	37	0.15	NaCl	lgK:7.48(0.15SD)	3	MGL	28777

13	37	0.15	NaCl	lgK:7.73(0.35SD)	3	MIS	28777
14	37	0.15	NaClO4	lgK:7.614(0.015SD)	6	MGL	2181
15	100	0	Inf. Dilution	lgK:9.0(2SF)	1	ELC	


Reaction No. 1506							
2<H+1> + Citric-3 + Ca+2 = Ca+2_H+1(2)_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.3(3SF)	3	ENS	2152
2	25	0	Inf. Dilution	lgK:1.29(3SF)	0	CRV	8903
Note (2): Value in MINTEQA2 database now diagnosed as being in error							
3	25	0	Unknown	lgK:12.3(3SF)	2	MGL	17779
4	37	0	Inf. Dilution	lgK:12.26(4SF)	2	CRV	28703
5	37	0.15	Blood Plasma	lgK:11.0(0.05SD)	3	ENS	94
6	37	0.15	NaCl	lgK:10.92(0.19SD)	3	MGL	28777
7	37	0.15	NaCl	lgK:11.55(0.24SD)	2	MIS	28777
8	37	0.15	NaClO4	lgK:11.005(0.03SD)	3	MGL	2181

Reaction No. 1507							
2<Citric-3> + Ca+2 + 2<H+1> = Ca+2_H+1(2)_Citric-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5(3SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:16.0(0.05SD)	0	ENS	94
3	37	0.15	NaCl	lgK:15.0(3SF)	0	CRV	22388

Reaction No. 1562							
Lactic-1 + Ca+2 = Ca+2_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.07(3SF)	2	MHY	4920
2	25	0	Inf. Dilution	lgK:1.47(3SF)	2	MSL	999
3	25	0	Unknown	lgK:1.42(3SF)	2	MHY	22560
4	25	0.1	KCl	lgK:1.55(3SF)	3	MSL	5230
5	25	0.1	KCl	lgK:1.6(0.06SD)	3	MSL	6836
6	25	0.15	NaCl	lgK:0.48(2SF)	0	MCT	22612
7	25	0.15	Unknown	lgK:0.82(2SF)	2	MEF	999
8	25	0.16	Unknown	lgK:0.8(1SF)	2	MIX	3478
9	25	0.5	NaCl	lgK:0.92(2SF)	2	MIS	22560
10	25	0.5	NaClO4	lgK:1.0(0.08MD)	2	MGL	4896


11	25	1	NaClO4	lgK:0.91(2SF)	2	MIX	7703
12	25	1	Unknown	lgK:0.90(2SF)	3	MQH	999
13	25	4	NaCl	lgK:0.99(2SF)	4	MMX	31270
14	30	0.1	KCl	lgK:1.7(0.03SD)	3	MSL	6836
15	35	0.1	KCl	lgK:1.8(0.05SD)	3	MSL	6836
16	37	0.15	Blood Plasma	lgK:0.90(2SF)	0	ENS	94
17	37	0.15	NaCl	lgK:0.61(2SF)	0	MCT	22612
18	37	0.15	NaCl	lgK:1.10(0.10SD)	2	MGL	28777
19	37	0.15	NaCl	lgK:0.94(0.04SD)	0	MIS	28777
20	40	0.1	KCl	lgK:1.9(0.05SD)	4	MSL	6836
21	45	0.1	KCl	lgK:2.05(0.02SD)	2	MSL	6836
22	25:45	0.1	KCl	dH:10.91(0.01SD)	3	MTD	6836

Reaction No. 1563



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:1.62(3SF)	5	MIS	22560
2	25	1	NaClO4	lgK:1.45(3SF)	5	MIX	7703
3	25	1	Unknown	lgK:1.24(3SF)	6	MQH	999
4	25	4	NaCl	lgK:1.42(3SF)	4	MMX	31270
5	37	0.15	Blood Plasma	lgK:1.2(2SF)	4	ENS	94

Reaction No. 1600



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.25	Unknown	lgK:2.0(0.04SD)	5	MGL	1045
2	20	0.1	NaClO4	lgK:1.96(3SF)	5	MGL	154
3	25	0	Inf. Dilution	lgK:2.77(3SF)	4	MGL	1045
4	25	0	Inf. Dilution	lgK:3.01(0.02SD)	4	MSL	3621
5	25	0	Inf. Dilution	lgK:2.66(3SF)	5	MCN	11516

Note (5): Topp N et al., J. Chem. Soc., 1940, , 87


6	25	0	Inf. Dilution	lgK:2.24(3SF)	3	MKN	11516
---	----	---	---------------	---------------	---	-----	-------

Note (6): Bell R et al., J. Chem. Soc., 1951, , 2357

7	25	0	UCT_Sea	lgK:2.66(0.01SD)	4	EDH	5390
8	25	0.1	KCl	lgK:3.01(3SF)	0	MSL	22560
9	25	0.1	NaCl	lgK:2.00(0.08SD)	5	MIS	3540


10	25	0.1	NaClO4	lgK:2.08(3SF)	5	MIS	22560
11	25	0.1	UCT_Sea	lgK:1.96(0.01SD)	4	EDH	5390
12	25	0.1	Unknown	lgK:1.96(3SF)	6	MGL	1217
13	25	0.16	NaCl	lgK:2.06(3SF)	4	MIX	3478
14	25	0.16	NaCl	lgK:2.06(3SF)	3	MIX	6806
15	25	0.2	KCl	lgK:1.80(3SF)	5	MHY	999
16	25	0.2	UCT_Sea	lgK:1.81(0.01SD)	4	EDH	5390
17	25	0.25	Unknown	lgK:1.9(0.03SD)	5	MGL	1045
18	25	0.3	UCT_Sea	lgK:1.74(0.01SD)	4	EDH	5390
19	25	0.4	UCT_Sea	lgK:1.70(0.01SD)	4	EDH	5390
20	25	0.5	UCT_Sea	lgK:1.67(0.01SD)	4	EDH	5390
21	25	0.6	UCT_Sea	lgK:1.66(0.01SD)	4	EDH	5390
22	25	0.7	UCT_Sea	lgK:1.66(0.01SD)	4	EDH	5390
23	25	1	NaNO3	lgK:1.67(3SF)	6	MGL	1506
24	30	0	Inf. Dilution	lgK:3.2(0.04SD)	4	MSL	3621
25	35	0	Inf. Dilution	lgK:3.2(0.04SD)	4	MSL	3621
26	37	0.15	Blood Plasma	lgK:1.8(0.05SD)	4	ENS	94
27	37	0.15	NaCl	lgK:1.77(3SF)	5	MSL	26689
28	37	0.25	Unknown	lgK:1.9(0.04SD)	5	MGL	1045
29	40	0	Inf. Dilution	lgK:3.3(0.06SD)	4	MSL	3621
30	25	0	Inf. Dilution	dH:-7.(1SF)kJ	4	MCL	1045
31	25	1	NaNO3	dH:-0.44(0.02SD)	5	MCL	1506

Reaction No. 1601



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.36(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.4(0.05SD)	4	ENS	94


Reaction No. 1602



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.25	Unknown	lgK:5.8(0.06SD)	5	MGL	1045
2	25	0	Inf. Dilution	lgK:6.49(3SF)	5	MGL	1045
3	25	0	UCT_Sea	lgK:6.52(0.01SD)	4	EDH	5390
4	25	0.1	UCT_Sea	lgK:5.71(0.01SD)	4	EDH	5390

5	25	0.1	Unknown	lgK:5.77 (3SF)	5	MGL	1217
6	25	0.2	UCT_Sea	lgK:5.63 (0.01SD)	4	EDH	5390
7	25	0.25	Unknown	lgK:5.7 (0.05SD)	5	MGL	1045
8	25	0.3	UCT_Sea	lgK:5.56 (0.01SD)	4	EDH	5390
9	25	0.4	UCT_Sea	lgK:5.53 (0.01SD)	4	EDH	5390
10	25	0.5	UCT_Sea	lgK:5.51 (0.01SD)	4	EDH	5390
11	25	0.6	UCT_Sea	lgK:5.50 (0.01SD)	4	EDH	5390
12	25	0.7	UCT_Sea	lgK:5.50 (0.01SD)	4	EDH	5390
13	37	0.15	Blood Plasma	lgK:5.5 (0.05SD)	4	ENS	94
14	37	0.25	Unknown	lgK:5.7 (0.06SD)	5	MGL	1045
15	25	0	Inf. Dilution	dH:-9. (1SF) kJ	5	MCL	1045


Reaction No. 1643



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	9	0	Inf. Dilution	lgK:3.072 (4SF)	7	EEX	6467
2	9	0	Inf. Dilution	lgK:3.072 (4SF)	3	EOD	6467
3	15	0	Inf. Dilution	lgK:3.110 (4SF)	7	EEX	6463
4	18	0	Inf. Dilution	lgK:3.00 (3SF)	3	MCN	8670
5	25	0	Inf. Dilution	lgK:3.187 (4SF)	7	MCN	6464
6	25	0	Inf. Dilution	lgK:3.187 (4SF)	3	EOD	6467
7	25	0	Inf. Dilution	lgK:3.000 (4SF)	3	EOD	12002
8	25	0	Inf. Dilution	lgK:3.0 (2SF)	3	CRV	18273
Note (8): Table 3, p. 85							
9	25	0	Inf. Dilution	lgK:3.19 (0.03SD)	6	CRV	20830
10	25	0.02	NaClO4	lgK:2.08 (3SF)	0	MIX	906
11	25	0.05	NaCl	lgK:2.70 (0.03SD)	0	MIS	3540
12	25	0.06	NaClO4	lgK:2.11 (3SF)	0	MIX	906
13	25	0.1	KNO3	lgK:2.30 (0.06SD)	2	MIX	906
14	25	0.1	NaCl	lgK:2.54 (0.09SD)	0	MIS	3540
15	25	0.1	NaCl	lgK:2.38 (0.06SD)	3	MGL	20992
16	25	0.1	NaCl	lgK:2.46 (0.014SD)	3	MIS	20992
17	25	0.1	NaClO4	lgK:2.10 (3SF)	0	MIX	906
18	25	0.1	Unknown	lgK:3.0 (2SF)	0	MGL	140
19	25	0.15	NaCl	lgK:1.99 (0.04SD)	0	MIS	3540
20	25	0.15	NaCl	lgK:1.46 (3SF)	0	MCT	22612

21	25	0.2	NaClO4	lgK:2.06 (3SF)	0	MIX	906
22	25	0.5	Me4NC1	lgK:2.70 (0.1SD)	0	MSL	26686
23	25	0.5	Unknown	lgK:1.95 (3SF)	2	MDS	3154
24	25	1	NaCl	lgK:1.93 (0.05SD)	3	MSL	26686
25	25	1	NaClO4	lgK:1.66 (3SF)	0	MDS	931
26	25	1	NaClO4	lgK:2.43 (0.1SD)	2	MSL	26686
27	25	1	NaNO3	lgK:2.69 (3SF)	0	MVM	1720
28	25	1	Unknown	lgK:1.66 (3SF)	0	ENS	773
29	30	0	Inf. Dilution	lgK:3.220 (4SF)	7	EEX	6467
30	30	0	Inf. Dilution	lgK:3.220 (4SF)	3	EOD	6467
31	35	0.1	KNO3	lgK:4.85 (3SF)	0	MGL	1187
32	37	0.03:0.5	Et4N+ salt	lgK:2.46 (3SF)	3	MIS	2261
33	37	0	Inf. Dilution	lgK:3.272 (4SF)	7	EEX	6463
34	37	0	Inf. Dilution	lgK:3.272 (4SF)	3	EOD	6467
35	37	0	Inf. Dilution	lgK:3.44 (3SF)	2	CRV	28703
36	37	0.03	Me4NI	lgK:2.72 (0.04MD)	5	MGL	29801
37	37	0.05	Me4NI	lgK:2.61 (0.04MD)	5	MGL	29801
38	37	0.1	Me4NI	lgK:2.46 (0.05MD)	5	MGL	29801
39	37	0.15	Blood Plasma	lgK:1.8 (0.05SD)	0	ENS	94
40	37	0.15	KCl	lgK:2.36 (3SF)	5	MGL	6468
41	37	0.15	NaCl	lgK:1.47 (3SF)	0	MCT	22612
42	37	0.15	NaCl	lgK:2.290 (4SF)	4	EOD	26689
43	37	0.3	Me4NI	lgK:2.23 (0.05MD)	3	MGL	29801
44	37	0.35	Unknown	lgK:2.01 (3SF)	3	EOD	29777
45	37	0.5	Me4NI	lgK:2.22 (0.06MD)	2	MGL	29801
46	38	0	Inf. Dilution	lgK:3.44 (3SF)	4	MSL	6475
47	38	0	Inf. Dilution	lgK:3.44 (3SF)	3	CRV	8692
48	38	0	Inf. Dilution	lgK:3.44 (3SF)	5	MSL	26858
49	38	0	Unknown	lgK:3.37 (3SF)	2	MSP	16641
50	45	0	Inf. Dilution	lgK:3.326 (4SF)	7	EEX	6467
51	45	0	Inf. Dilution	lgK:3.326 (4SF)	3	EOD	6467
52	50	0	Inf. Dilution	lgK:3.358 (4SF)	7	EEX	6463

Reaction No. 1644



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	20	0.1:1.5	HNO3	lgK:3.49 (3SF)	0	MSL	906
2	25	1	NaClO4	lgK:2.69 (3SF)	2	MDS	999
3	37	0	Inf. Dilution	lgK:4.68 (3SF)	0	CRV	28703
4	37	0.15	Blood Plasma	lgK:2.4 (0.05SD)	2	ENS	94

Reaction No. 1645							
H+1 + Oxalic-2 + Ca+2 = Ca+2_H+1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.1 (2SF)	1	ELC	
2	37	0	Inf. Dilution	lgK:6.17 (3SF)	2	CRV	28703
3	37	0.15	Blood Plasma	lgK:4.7 (0.05SD)	0	ENS	94

Reaction No. 1684							
Pyruvic-1 + Ca+2 = Ca+2_Pyruvic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:1.85 (3SF)	0	MGL	931
2	25	0	Inf. Dilution	lgK:1.08 (3SF)	6	MSL	999
3	25	0.16	Unknown	lgK:0.8 (1SF)	4	MIX	3478
4	25	0.3	NaClO4	lgK:0.56 (0.02MD)	4	MGL	1458
5	25	3	NaClO4	lgK:0.59 (0.02MD)	6	MGL	1458
6	37	0.15	Blood Plasma	lgK:0.8 (0.05SD)	2	ENS	94

Reaction No. 1705							
2<Salicylic-2> + Ca+2 = Ca+2_Salicylic-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.46 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:7.5 (0.05SD)	4	ENS	94
3	25		Methanol	lgK:7.0 (2SF)	5	MPT	2599
4	25		Methanol	dH:-28. (2SF) kJ	5	MCL	4795

Reaction No. 1706							
Salicylic-2 + Ca+2 + H+1 = Ca+2_H+1_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.07 (4SF)	1	ELC	
2	25	0	UCT_Sea	lgK:14.84 (0.01SD)	0	EDH	5390
3	25	0.1	UCT_Sea	lgK:13.38 (0.01SD)	0	EDH	5390
4	25	0.2	UCT_Sea	lgK:13.21 (0.01SD)	0	EDH	5390

5	25	0.3	UCT_Sea	lgK:13.13(0.01SD)	0	EDH	5390
6	25	0.4	UCT_Sea	lgK:13.81(0.01SD)	0	EDH	5390
7	25	0.5	UCT_Sea	lgK:13.03(0.01SD)	0	EDH	5390
8	25	0.6	UCT_Sea	lgK:13.74(0.01SD)	0	EDH	5390
9	25	0.7	UCT_Sea	lgK:13.72(0.01SD)	0	EDH	5390
10	37	0.15	Blood Plasma	lgK:14.3(0.05SD)	0	ENS	94

Reaction No. 1729							
Succinic-2 + Ca+2 = Ca+2_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.25	Unknown	lgK:1.4(0.04SD)	4	MGL	1045
2	20	0.1	NaClO4	lgK:1.20(3SF)	5	MGL	154
3	25	0	Inf. Dilution	lgK:2.24(3SF)	4	MGL	1045
4	25	0	Inf. Dilution	lgK:2.00(3SF)	5	MCN	11516
Note (4): Topp N et al., J. Chem. Soc., 1940, 87							
5	25	0	Inf. Dilution	lgK:2.0(2SF)	4	CRV	18273
Note (5): Table 3, p. 85							
6	25	0	UCT_Sea	lgK:2.00(0.01SD)	4	EDH	5390
7	25	0.1	NaClO4	lgK:1.33(3SF)	5	MCT	1867
8	25	0.1	UCT_Sea	lgK:1.20(0.01SD)	4	EDH	5390
9	25	0.15	KNO3	lgK:0.95(2SF)	2	MGL	9980
10	25	0.15	Unknown	lgK:1.16(3SF)	5	MEF	999
11	25	0.16	NaCl	lgK:1.0(2SF)	4	MIX	3478
12	25	0.2	KCl	lgK:1.20(3SF)	5	MHY	999
13	25	0.2	UCT_Sea	lgK:1.01(0.01SD)	4	EDH	5390
14	25	0.25	Unknown	lgK:1.5(0.03SD)	3	MGL	1045
15	25	0.3	UCT_Sea	lgK:0.91(0.01SD)	4	EDH	5390
16	25	0.4	UCT_Sea	lgK:0.83(0.01SD)	4	EDH	5390
17	25	0.5	UCT_Sea	lgK:0.78(0.01SD)	4	EDH	5390
18	25	0.6	UCT_Sea	lgK:0.74(0.01SD)	4	EDH	5390
19	25	0.7	UCT_Sea	lgK:0.71(0.01SD)	4	EDH	5390
20	37	0.15	Blood Plasma	lgK:1.3(0.05SD)	3	ENS	94
21	37	0.25	Unknown	lgK:1.5(0.03SD)	3	MGL	1045
22	45	0.25	Unknown	lgK:1.6(0.04SD)	3	MGL	1045
23	25	0	Inf. Dilution	dH:10.(2SF)kJ	4	MCL	1045


Reaction No. 1730							
2<Succinic-2> + Ca+2 = Ca+2_Succinic-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.26(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.3(0.05SD)	4	ENS	94

Reaction No. 1731							
Succinic-2 + Ca+2 + H+1 = Ca+2_H+1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.25	Unknown	lgK:5.9(0.05SD)	5	MGL	1045
2	25	0	Inf. Dilution	lgK:6.68(3SF)	6	MGL	1045
3	25	0	UCT_Sea	lgK:6.57(0.01SD)	4	EDH	5390
4	25	0.1	UCT_Sea	lgK:5.78(0.01SD)	4	EDH	5390
5	25	0.2	UCT_Sea	lgK:5.63(0.01SD)	4	EDH	5390
6	25	0.25	Unknown	lgK:6.0(0.04SD)	5	MGL	1045
7	25	0.3	UCT_Sea	lgK:5.55(0.01SD)	4	EDH	5390
8	25	0.4	UCT_Sea	lgK:5.49(0.01SD)	4	EDH	5390
9	25	0.5	UCT_Sea	lgK:5.46(0.01SD)	4	EDH	5390
10	25	0.6	UCT_Sea	lgK:5.45(0.01SD)	4	EDH	5390
11	25	0.7	UCT_Sea	lgK:5.44(0.01SD)	4	EDH	5390
12	37	0.15	Blood Plasma	lgK:6.0(0.05SD)	4	ENS	94
13	37	0.25	Unknown	lgK:6.0(0.05SD)	5	MGL	1045
14	45	0.25	Unknown	lgK:6.0(0.05SD)	5	MGL	1045
15	25	0	Inf. Dilution	dH:11.(2SF)kJ	5	MCL	1045

Reaction No. 1764							
Tartaric-2 + Ca+2 = Ca+2_Tartaric-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.25	Unknown	lgK:2.1(0.04SD)	5	MGL	1045
2	20	0.1	KClO4	lgK:2.00(3SF)	6	MDS	999
3	25	0	Inf. Dilution	lgK:2.98(3SF)	6	MGL	1045
4	25	0	Inf. Dilution	lgK:2.80(3SF)	5	MCN	11516
Note (4): Topp N et al., J. Chem. Soc., 1940, 87							
5	25	0.1	NaCl	lgK:2.26(0.02SD)	2	MGL	20992
6	25	0.1	NaCl	lgK:2.13(0.01SD)	3	MIS	20992
7	25	0.1	NaClO4	lgK:1.83(3SF)	2	MCT	1867

8	25	0.1	NaClO ₄	lgK:2.83(3SF)	0	MGL	3181
9	25	0.1	Unknown	lgK:1.94(3SF)	6	MGL	1217
10	25	0.16	Unknown	lgK:1.78(3SF)	4	MIX	3478
11	25	0.2	KCl	lgK:1.80(3SF)	6	MHY	999
12	25	0.25	Unknown	lgK:2.1(0.04SD)	3	MGL	1045
13	25	0.5	NaClO ₄	lgK:1.66(0.05MD)	6	MGL	4896
14	25	1.5	KNO ₃	lgK:1.6(2SF)	5	MMR	4484
15	37	0.09	NaClO ₄	lgK:2.17(3SF)	3	MGL	999
16	37	0.15	Blood Plasma	lgK:1.8(0.05SD)	4	ENS	94
17	37	0.25	Unknown	lgK:1.9(0.04SD)	5	MGL	1045
18	25	0	Inf. Dilution	dH:-9.(1SF)kJ	5	MCL	1045


Reaction No. 1765



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.3(2SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:2.0(0.05SD)	3	ENS	94


Note (2): Was 2.4

Reaction No. 1766



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.25	Unknown	lgK:5.3(0.07SD)	5	MGL	1045
2	25	0	Inf. Dilution	lgK:5.84(3SF)	6	MGL	1045
3	25	0.1	Unknown	lgK:5.06(3SF)	6	MGL	1217
4	25	0.25	Unknown	lgK:5.0(0.05SD)	5	MGL	1045
5	37	0.15	Blood Plasma	lgK:5.0(0.05SD)	4	ENS	94
6	37	0.25	Unknown	lgK:5.1(0.06SD)	5	MGL	1045
7	25	0	Inf. Dilution	dH:-12.(2SF)kJ	5	MCL	1045


Reaction No. 1800



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO ₄	lgK:2.662(4SF)	3	MGL	3504
2	20	0.15	KNO ₃	lgK:3.15(3SF)	0	MGL	3549
3	25	0	Inf. Dilution	lgK:3.6(2SF)	1	EES	
4	37	0.15	Blood Plasma	lgK:2.5(0.05SD)	2	ENS	94


5	37	0.15	KNO3	lgK:3.01(3SF)	3	MGL	3549
---	----	------	------	---------------	---	-----	------

Reaction No. 1801




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:2.8(0.05SD)	4	ENS	94

Reaction No. 1827




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:9.7(0.05SD)	3	ENS	94

Reaction No. 1828




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:19.1(0.05SD)	4	ENS	94

Reaction No. 1858




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	Unknown	lgK:0.0(1SF)	0	MIX	108
2	37	0.15	Blood Plasma	lgK:3.8(0.05SD)	4	ENS	94

Reaction No. 1859



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.0(2SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:4.0(0.05SD)	2	ENS	94
3	37	0.15	NaClO4	lgK:3.8(0.1SD)	4	MGL	1621

Reaction No. 1860



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.2(3SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:12.9(0.05SD)	4	ENS	94
3	37	0.15	NaClO4	lgK:12.9(0.1SD)	4	MGL	1621

Reaction No. 1861

2<H+1> + GSH-3 + Ca+2 = Ca+2_H+1(2)_GSH-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:20.7(0.05SD)	3	ENS	94
3	37	0.15	NaClO4	lgK:20.7(0.1SD)	3	MGL	1621

Reaction No. 2004							
Desfer-2 + Ca+2 = Ca+2_Desfer-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:2.64(3SF)	6	MGL	3572
2	25	0	Inf. Dilution	lgK:3.5(2SF)	4	ENS	6405
3	37	0.15	Blood Plasma	lgK:2.6(0.05SD)	4	ENS	94

Reaction No. 2030							
DTPA-5 + Ca+2 + H+1 = Ca+2_H+1_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.8(0.05SD)	4	ENS	94
3	37	0.15	NaCl	lgK:15.80(0.008SD)	5	MGL	1940

Reaction No. 2031							
DTPA-5 + Ca+2 + 2<H+1> = Ca+2_H+1(2)_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.2(0.05SD)	3	ENS	94
3	37	0.15	NaCl	lgK:20.23(0.02SD)	5	MGL	1940

Reaction No. 2032							
DTPA-5 + Ca+2 + 3<H+1> = Ca+2_H+1(3)_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:27.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.9(0.05SD)	4	ENS	94
3	37	0.15	NaCl	lgK:23.9(0.02SD)	5	MGL	1940

Reaction No. 2033							
DTPA-5 + 2<Ca+2> = Ca+2(2)_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0	Inf. Dilution	lgK:15.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.9(0.05SD)	4	ENS	94

Reaction No. 2072							
CDTA-4 + Ca+2 = Ca+2_CDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:12.50(4SF)	6	MHY	1947
2	20	0.1	KNO3	lgK:12.50(4SF)	6	MPT	197
3	20	0.1	KNO3	lgK:13.15(4SF)	0	MGL	1963
Note (3): Low wgt for internal consistency							
4	20	0.1	NaClO4	lgK:13.1(0.05SD)	2	MGL	197
5	20	0.1	NaClO4	lgK:13.2(0.05SD)	0	MGL	2038
6	20	0.1	Unknown	lgK:12.08(4SF)	3	MPL	999
7	25	0	Inf. Dilution	lgK:15.0(3SF)	0	ENS	6405
Note (7): Low wgt for internal consistency							
8	25	0.1	KNO3	lgK:12.3(3SF)	4	MEF	999
9	25	0.1	KNO3	lgK:11.34(4SF)	0	MGL	11516
Note (9): Bohigian T et al., Prog. Rep. US Atom. En. Comm., 1960							
10	25	0.1	Unknown	lgK:13.15(4SF)	0	ENS	2016
11	25	0.5	Me4NCl	lgK:13.68(4SF)	0	MGL	4556
Note (11): Low wgt for internal consistency							
12	37	0.15	Blood Plasma	lgK:11.6(0.05SD)	0	ENS	94
13	20	0.1	KNO3	dH:-3.70(3SF)	3	MCL	1963
14	20	1	KCl	dH:-5.55(3SF)	5	MCL	2018
15	25	0.1	KNO3	dH:-6.2(2SF)	3	MCL	139
16	25	0.1	Methanol:Water 99:1Wgt NaClO4	lgK:9.5(2SF)	4	MGL	906

Reaction No. 2086							
EDDA-2 + Ca+2 = Ca+2_EDDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.63(3SF)	0	MGL	1941
2	25	0.1	NaClO4	lgK:2.9(2SF)	4	MCL	1685
3	37	0.15	Blood Plasma	lgK:2.8(0.05SD)	4	ENS	94
4	37	0.15	NaCl	lgK:4.0(2SF)	0	MDG	1779
Note (4): Low wgt for internal consistency							

5	25	0.1	NaClO4	dH:0.3(1SF)kJ	5	MCL	1685
---	----	-----	--------	---------------	---	-----	------

Reaction No. 2111							
EGTA-4 + Ca+2 = Ca+2_EGTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:10.97(4SF)	6	MHY	1957
2	20	0.1	KCl	lgK:11.070(5SF)	5	MGL	3584
3	20	0.1	KNO3	lgK:10.97(4SF)	6	MGL	1956
4	25	0.1	KNO3	lgK:11.0(3SF)	4	MGL	999
5	25	0.1	Unknown	lgK:10.7(3SF)	4	MGL	999
6	37	0.15	Blood Plasma	lgK:10.3(0.05SD)	3	ENS	94
7	20	0.1	KNO3	dH:-8.38(3SF)	5	MCL	1956
8	25	0.1	KCl	dH:-7.94(3SF)	5	MCL	999
9	25	0.1	KNO3	dH:-8.0(2SF)	5	MCL	139
10	25	0.1	Methanol:Water 99:1Wgt NaClO4	lgK:11.1(3SF)	5	MGL	906

Reaction No. 2135							
EHPG-4 + Ca+2 = Ca+2_EHPG-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:7.20(3SF)	6	MGL	1941
2	37	0.15	Blood Plasma	lgK:7.0(0.05SD)	4	ENS	94
3	25	0.1	KNO3	dH:2.09(3SF)	5	MCL	1941

Reaction No. 2136							
EHPG-4 + Ca+2 + H+1 = Ca+2_H+1_EHPG-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:16.0(0.05SD)	4	ENS	94

Reaction No. 2137							
EHPG-4 + Ca+2 + 2<H+1> = Ca+2_H+1(2)_EHPG-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:23.0(0.05SD)	4	ENS	94

Reaction No. 2158							
EEDTA-4 + Ca+2 = Ca+2_EEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	20	0.1	KCl	lgK:10.05 (4SF)	6	MGL	1957
2	20	0.1	KNO3	lgK:10.0 (3SF)	4	MGL	1956
3	37	0.15	Blood Plasma	lgK:9.8 (0.05SD)	3	ENS	94
4	20	0.1	KNO3	dH:-6.85 (3SF)	5	MCL	1956
5	25	0.1	KNO3	dH:-6.4 (2SF)	5	MCL	139

Reaction No. 2159							
EEDTA-4 + Ca+2 + H+1 = Ca+2_H+1_EEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:14.0 (0.05SD)	4	ENS	94

Reaction No. 2182							
NTA-3 + Ca+2 = Ca+2_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:7.704 (4SF)	4	MHY	140
2	0.5	0.1	KNO3	lgK:6.61 (3SF)	5	MGL	1118
3	10	0	Inf. Dilution	lgK:7.652 (4SF)	4	MHY	140
4	15	0.1	KNO3	lgK:6.59 (3SF)	5	MGL	1118
5	20	0	Inf. Dilution	lgK:7.608 (4SF)	4	MHY	140
6	20	0	Inf. Dilution	lgK:8.17 (3SF)	4	MHY	1118
7	20	0.1	KCl	lgK:6.45 (3SF)	6	CMN	1118
8	20	0.1	KCl	lgK:6.46 (0.01SD)	6	MGL	2595
9	20	0.1	KCl	lgK:6.41 (3SF)	6	MGL	3486
10	20	0.1	KNO3	lgK:6.50 (3SF)	4	MGL	1118
11	20	0.1	KNO3	lgK:6.56 (3SF)	6	MGL	1979
12	23	0.1	NH4Cl	lgK:6.6 (2SF)	4	MCG	1118
13	25	0	Inf. Dilution	lgK:7.608 (4SF)	4	CRV	552
14	25	0	Inf. Dilution	lgK:7.71 (3SF)	7	ENS	1384
15	25	0	KNO3	lgK:7.699 (0.003SD)	4	MPT	5829
16	25	0	Me4NNO3	lgK:7.62 (0.05SD)	3	MPT	5829
17	25	0.05	KNO3	lgK:6.72 (0.01SD)	6	MGL	5829
18	25	0.05	Me4NNO3	lgK:6.74 (0.005SD)	6	MGL	5829
19	25	0.1	KNO3	lgK:6.57 (3SF)	5	MGL	1118
20	25	0.1	KNO3	lgK:6.33 (3SF)	5	MGL	11516
Note (20): Bohigian T et al., Prog. Rep. US Atom. En. Comm. Con. 1960							
21	25	0.1	NaCl	lgK:6.31 (0.01SD)	5	MIS	3540

22	25	0.1	NaClO4	lgK:6.3 (2SF)	6	MCT	1867
23	25	0.1	NaClO4	lgK:6.44 (3SF)	5	MGL	3180
24	25	0.1	Unknown	lgK:6.4 (0.05SD)	6	CRV	552
25	25	0.301	Me4NNO3	lgK:6.24 (0.006SD)	6	MGL	5829
26	25	0.304	KNO3	lgK:6.007 (0.001SD)	6	MGL	5829
27	25	1	KNO3	lgK:5.55 (0.004SD)	6	MGL	5829
28	25	1	Me4NNO3	lgK:5.9 (0.03SD)	6	MGL	5829
29	25	2.5	KNO3	lgK:5.32 (0.01SD)	6	MGL	5829
30	25	2.5	Me4NNO3	lgK:6.01 (0.01SD)	6	MGL	5829
31	25.3	0.1	KNO3	lgK:6.33 (3SF)	4	MGL	1118
32	30	0	Inf. Dilution	lgK:7.595 (4SF)	4	MHY	140
33	30	0.1	KNO3	lgK:6.57 (3SF)	5	MGL	1118
34	35	0.1	KNO3	lgK:6.53 (3SF)	5	MGL	1118
35	37	0.15	Blood Plasma	lgK:6.2 (0.05SD)	4	ENS	94
36	40	0.1	KNO3	lgK:6.53 (3SF)	5	MGL	1118
37	42.4	0.1	KNO3	lgK:6.35 (3SF)	4	MGL	1118
38	20	0.1	KNO3	dH:-1.4 (2SF)	6	CMN	1118
39	20	0.1	KNO3	dH:-1.36 (3SF)	5	MCL	1118
40	20	0.1	KNO3	dH:-1.36 (3SF)	5	MCL	3683
41	20:40	0.1	KNO3	dH:-2.0 (2SF)	5	MCL	3201
42	25	0	Inf. Dilution	dH:-1. (1SF)	4	MEF	140
43	25	0.1	KNO3	dH:-1.39 (3SF)	5	MTD	6627
44	25	0.1	Unknown	dH:-1.36 (3SF)	6	CRV	552

Reaction No. 2183



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:11.60 (4SF)	0	MEF	11516
Note (1): Schwarzenbach G et al., Helv. Chim. Acta, 1945, 28, 828							
2	25	0	Inf. Dilution	lgK:8.81 (3SF)	2	CRV	552
3	25	0	KNO3	lgK:9.66 (0.04SD)	4	MPT	5829
4	25	0	Me4NNO3	lgK:9.86 (0.009SD)	3	MPT	5829
5	25	0.05	KNO3	lgK:9.3 (0.04SD)	6	MGL	5829
6	25	0.05	Me4NNO3	lgK:9.35 (0.02SD)	6	MGL	5829
7	25	0.301	Me4NNO3	lgK:8.97 (0.02SD)	6	MGL	5829
8	25	0.304	KNO3	lgK:8.87 (0.004SD)	6	MGL	5829


9	25	1	KNO3	lgK:8.67(0.004SD)	6	MGL	5829
10	25	1	Me4NNO3	lgK:8.8(0.06SD)	3	MGL	5829
11	25	2.5	KNO3	lgK:8.5(0.04SD)	6	MGL	5829
12	25	2.5	Me4NNO3	lgK:9.4(0.03SD)	0	MGL	5829
13	37	0.15	Blood Plasma	lgK:8.3(0.05SD)	0	ENS	94
14	25	0.1	Unknown	dH:-7.8(2SF)	6	CRV	552

Reaction No. 2184							
Ca+2 + NTA-3 + H2O = Ca+2_OH-1_NTA-3 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-6.0(2SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:-6.0(0.05SD)	4	ENS	94

Reaction No. 2214							
Acetic-1 + Ca+2 = Ca+2_Acetic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	200	0	P=500 Inf. Dilution	lgK:2.53(3SF)	4	MSL	6426
2	300	0	P=500 Inf. Dilution	lgK:3.72(3SF)	4	MSL	6426
3	350	0	P=500 Inf. Dilution	lgK:4.59(3SF)	4	MSL	6426
4	0	0	Inf. Dilution	lgK:0.99(2SF)	4	CRV	8888
5	10	0.25	Unknown	lgK:0.6(0.04SD)	5	MGL	1045
6	18	0	Inf. Dilution	lgK:0.0(1SF)	0	MCN	686
7	20	0.2	KCl	lgK:0.53(2SF)	3	MHY	4920
8	25	0	Inf. Dilution	lgK:1.24(0.02SD)	3	MGL	380
9	25	0	Inf. Dilution	lgK:1.12(3SF)	4	MGL	381
10	25	0	Inf. Dilution	lgK:1.14(3SF)	4	ENS	1541
11	25	0	Inf. Dilution	lgK:1.71(3SF)	3	MSC	4482
12	25	0	Inf. Dilution	lgK:0.77(2SF)	3	MSL	7730
13	25	0	Inf. Dilution	lgK:0.93(2SF)	4	CRV	8888
14	25	0	Inf. Dilution	lgK:0.0(1SF)	0	MCN	11989
15	25	0	Inf. Dilution	lgK:0.931(3SF)	4	EOD	29559
16	25	0.03	NaCl	lgK:0.87(2SF)	4	MIS	11516
Note (16): Emara M et al., Electrochim. Acta, 1981, 26, 1705							
17	25	0.15	KNO3	lgK:0.59(2SF)	5	MGL	9980
18	25	0.15	NaCl	lgK:0.48(2SF)	4	MCT	22612


19	25	0.15	Unknown	lgK:0.5(0.05SD)	4	MEF	101
20	25	0.16	Unknown	lgK:0.62(2SF)	3	MIX	3478
21	25	0.25	Unknown	lgK:0.57(0.01SD)	5	MGL	1045
22	25	0.5	Unknown	lgK:0.74(2SF)	4	MDS	3154
23	30	0.4	NaNO3	lgK:0.50(0.04SD)	4	MGL	906
24	35	0	Inf. Dilution	lgK:1.26(0.01SD)	3	MGL	931
25	35	0.25	Unknown	lgK:0.61(0.01SD)	5	MGL	1045
26	37	0	Inf. Dilution	lgK:1.60(3SF)	0	EOD	23288
27	37	0.15	Blood Plasma	lgK:0.5(1SF)	3	ENS	94
28	37	0.15	NaCl	lgK:0.57(2SF)	3	MCT	22612
29	37	0.15	NaCl	lgK:1.10(0.03SD)	0	MGL	23288
Note (29): Model selection appears suspect c.f. Zbar curves							
30	45	0.25	Unknown	lgK:0.70(0.02SD)	5	MGL	1045
31	50	0	Inf. Dilution	lgK:1.00(3SF)	4	CRV	8888
32	75	0	Inf. Dilution	lgK:1.15(3SF)	4	CRV	8888
33	80	0	Inf. Dilution	lgK:1.2(2SF)	4	MSL	6426
34	90	0	Inf. Dilution	lgK:1.259(4SF)	4	EOD	29559
35	100	0	Inf. Dilution	lgK:1.35(3SF)	4	CRV	8888
36	125	0	Inf. Dilution	lgK:1.58(3SF)	4	CRV	8888
37	150	0	Inf. Dilution	lgK:1.84(3SF)	4	CRV	8888
38	150	0	Inf. Dilution	lgK:1.822(4SF)	4	EOD	29559
39	175	0	Inf. Dilution	lgK:2.12(3SF)	4	CRV	8888
40	200	0	Inf. Dilution	lgK:2.43(3SF)	4	CRV	8888
41	210	0	Inf. Dilution	lgK:2.532(4SF)	4	EOD	29559
42	225	0	Inf. Dilution	lgK:2.76(3SF)	4	CRV	8888
43	250	0	Inf. Dilution	lgK:3.12(3SF)	4	CRV	8888
44	275	0	Inf. Dilution	lgK:3.53(3SF)	4	CRV	8888
45	300	0	Inf. Dilution	lgK:3.98(3SF)	4	CRV	8888
46	325	0	Inf. Dilution	lgK:4.51(3SF)	4	CRV	8888
47	350	0	Inf. Dilution	lgK:5.07(3SF)	4	CRV	8888
48	25	0	Inf. Dilution	dH:3.5(2SF) kJ	4	MCL	1045
49	25:35	0	Inf. Dilution	dH:0.9(0.1SD)	4	MGL	380
50	25		Methanol	lgK:4.7(2SF)	5	MGL	4795

Reaction No. 2218




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.62(3SF)	2	EAE	
2	25	0	Inf. Dilution	lgK:1.40(3SF)	4	EOD	29559
3	37	0.15	Blood Plasma	lgK:1.9(0.05SD)	0	ENS	94
4	37	0.15	NaCl	lgK:2.88(0.06SD)	0	MGL	23288
Note (4): Model selection appears suspect c.f. Zbar curves							
5	90	0	Inf. Dilution	lgK:1.937(4SF)	4	EOD	29559
6	150	0	Inf. Dilution	lgK:3.013(4SF)	4	EOD	29559
7	210	0	Inf. Dilution	lgK:4.398(4SF)	4	EOD	29559
8	25		Methanol	lgK:7.2(2SF)	5	MGL	4795

Reaction No. 2227




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.67(2SF)	6	MGL	999
2	37	0.15	Blood Plasma	lgK:0.7(0.05SD)	4	ENS	94

Reaction No. 2234




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:2.9(0.05SD)	4	ENS	94
2	37	0.15	NaClO4	lgK:2.9(0.03SD)	6	MGL	107

Reaction No. 2235



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:4.7(0.05SD)	4	ENS	94

Reaction No. 2440




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.2	Pr4NC1	lgK:1.361(4SF)	2	MGL	257
2	5	0	Inf. Dilution	lgK:2.38(3SF)	4	MSL	5398
3	5	0	Inf. Dilution	lgK:2.67(3SF)	4	MSL	5398
4	15	0	Inf. Dilution	lgK:2.28(3SF)	0	MSL	5398
5	15	0	Inf. Dilution	lgK:2.44(3SF)	4	MSL	5398
6	18			lgK:2.6(2SF)	0	MQH	931

7	22	0.006	Unknown	lgK:2.20 (3SF)	4	MGL	140
8	25	0	Inf. Dilution	lgK:2.74 (3SF)	5	MGL	245
9	25	0	Inf. Dilution	lgK:2.7 (0.08SD)	4	CRV	552
10	25	0	Inf. Dilution	lgK:2.41 (3SF)	3	MSL	5398
11	25	0	Inf. Dilution	lgK:2.58 (3SF)	4	MSL	5398
12	25	0	Inf. Dilution	lgK:2.66 (0.1SD)	5	CMN	7391
13	25	0	Inf. Dilution	lgK:2.42 (3SF)	3	ENS	7391
14	25	0	Inf. Dilution	lgK:2.74 (3SF)	4	CRV	8749
15	25	0	Inf. Dilution	lgK:2.42 (3SF)	3	EOD	31694
Note (15): from Gregory, et al., 1970							
16	25	0	Inf. Dilution/m	lgK:2.54 (0.05MD)	4	EDH	6142
17	25	0.05	NaCl	lgK:2.14 (0.08SD)	2	MIS	3540
18	25	0.1	Me4N+ salt	lgK:1.87 (3SF)	4	MIS	3540
19	25	0.1	NaCl	lgK:1.87 (0.06SD)	5	MIS	3540
20	25	0.1	NaNO3	lgK:1.64 (3SF)	0	MGL	6412
21	25	0.1	NaNO3	lgK:1.64 (0.02MD)	0	MGL	6412
22	25	0.1	Unknown	lgK:6.27 (3SF)	0	MGL	3180
23	25	0.15	NaCl	lgK:1.57 (0.07SD)	0	MIS	3540
24	25	0.2	KCl	lgK:1.5 (0.05SD)	0	MIS	250
25	25	0.2	Pr4NCl	lgK:1.70 (3SF)	4	MGL	257
26	25	0.68	Unknown	lgK:1.25 (3SF)	4	MGL	7177
27	25	0.7	NaClO4	lgK:1.39 (3SF)	6	CRV	552
28	25	0.7	Unknown	lgK:1.39 (3SF)	4	MGL	5322
29	25	0.7	Unknown	lgK:1.25 (3SF)	4	ENS	7177
30	25	0.7	Unknown	lgK:1.28 (0.03SD)	6	CMN	7391
31	37	0.004:0.02	Cl-1 salt	lgK:2.77 (0.05SD)	0	MIS	5068
32	37	0	Inf. Dilution	lgK:2.77 (3SF)	4	MGL	245
33	37	0	Inf. Dilution	lgK:2.83 (3SF)	4	MGL	931
34	37	0	Inf. Dilution	lgK:2.77 (3SF)	5	MGL	5068
35	37	0	Inf. Dilution	lgK:2.59 (3SF)	4	MSL	5398
36	37	0.1	Me4N+ salt	lgK:2.02 (3SF)	4	MGL	9983
37	37	0.15	Inert	lgK:1.94 (3SF)	2	CRV	29801
38	37	0.15	KCl	lgK:1.94 (3SF)	2	MGL	6468
39	37	0.15	KNO3	lgK:1.3 (2SF)	0	MGL	255
40	37	0.15	KNO3	lgK:1.3 (2SF)	0	MPS	255
41	37	0.15	NaCl	lgK:1.86 (3SF)	3	MCE	140

42	37	0.4	Unknown	lgK:1.55 (3SF)	3	EOD	29777
43	37.5	0	Inf. Dilution	lgK:2.77 (3SF)	4	MGL	931
44	37.5	0	Inf. Dilution	lgK:2.61 (3SF)	4	MSL	5398
45	38	0	Inf. Dilution	lgK:1.50 (3SF)	0	CRV	8692
46	5	0	Inf. Dilution	dG:-3.3 (2SF)	4	MSL	247
47	15	0	Inf. Dilution	dG:-3.2 (2SF)	4	MSL	247
48	25	0	Inf. Dilution	dG:-3.7 (0.01SD)	5	MPT	245
49	25	0	Inf. Dilution	dG:-3.3 (2SF)	3	MSL	247
50	37.5	0	Inf. Dilution	dG:-3.7 (2SF)	4	MSL	247
51	5	0	Inf. Dilution	dH:-10. (2SF)	0	MSL	247
52	15	0	Inf. Dilution	dH:-5. (1SF)	0	MSL	247
53	20:40	0	Inf. Dilution	dH:3. (1SF)	4	CRV	552
54	25	0	Inf. Dilution	dH:3.3 (0.6SD)	5	MTD	245
55	25	0	Inf. Dilution	dH:2. (1SF)	2	MSL	247
56	25:37	0	Inf. Dilution	dH:3.3 (2SF)	4	MCL	931
57	37.5	0	Inf. Dilution	dH:10. (5.SD)	0	MSL	247


Reaction No. 2441



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0	Inf. Dilution	lgK:0.7 (1SF)	4	MSL	5398
2	15:37	0	Inf. Dilution	lgK:1.0 (2SF)	4	MSL	5398
3	25	0	Inf. Dilution	lgK:1.41 (0.05SD)	3	MGL	245
4	25	0	Inf. Dilution	lgK:0.96 (0.1MD)	5	MGL	6170
5	25	0	Inf. Dilution	lgK:1.0 (0.2SD)	5	CMN	7391
6	25	0	Inf. Dilution	lgK:0.57 (2SF)	0	ENS	7391
7	25	0	Inf. Dilution	lgK:1.07 (3SF)	4	ENS	7391
8	25	0	Inf. Dilution	lgK:1.00 (3SF)	4	CRV	8749
9	25	0	Inf. Dilution	lgK:0.55 (2SF)	3	EOD	31694
Note (9): from Gregory, Moreno & Brown, 1970							
10	25	0.68	Unknown	lgK:0.24 (2SF)	3	MGL	7177
11	25	0.7	Unknown	lgK:0.24 (0.02SD)	3	CMN	7391
12	25	0.7	Unknown	lgK:0.24 (2SF)	3	EOD	7391
13	25	3	NaClO4	lgK:0.49 (2SF)	3	MSL	6170
14	37	0.05:0.14	Cl-1 salt	lgK:1.44 (0.05SD)	0	MIS	5068
15	37	0	Inf. Dilution	lgK:1.50 (3SF)	3	MGL	245

16	37	0	Inf. Dilution	lgK:0.89(2SF)	4	ENS	931
17	37	0.1	Me4N+ salt	lgK:1.11(3SF)	2	MGL	9983
18	37	0.15	KNO3	lgK:0.6(1SF)	5	MGL	255
19	37	0.15	KNO3	lgK:0.5(0.4SD)	3	MPS	255
20	37	0.4	Unknown	lgK:0.86(2SF)	3	EOD	29777
21	37:40	0.15	Unknown	lgK:1.06(3SF)	0	CRV	552
22	37.5	0	Inf. Dilution	lgK:0.87(2SF)	4	MGL	931
23	38	0	Inf. Dilution	lgK:1.50(3SF)	3	CRV	8692
24	5	0	Inf. Dilution	dG:-1.3(2SF)	4	MSL	247
25	15	0	Inf. Dilution	dG:-1.1(2SF)	5	MSL	247
26	25	0	Inf. Dilution	dG:-1.92(0.04SD)	3	MPT	245
27	25	0	Inf. Dilution	dG:-1.0(2SF)	5	MSL	247
28	37.5	0	Inf. Dilution	dG:-0.8(1SF)	2	MSL	247
29	5	0	Inf. Dilution	dH:8.(1SF)	0	MSL	247
30	5:37	0	Inf. Dilution	dH:3.6(2SF)	4	MTD	5398
31	15	0	Inf. Dilution	dH:6.(1SF)	0	MSL	247
32	20:40	0	Inf. Dilution	dH:3.(1SF)	4	CRV	552
33	25	0	Inf. Dilution	dH:3.4(1.7SD)	5	MTD	245
34	25	0	Inf. Dilution	dH:4.(1SF)	4	MSL	247
35	37	0	Inf. Dilution	dH:3.4(1.7SD)	4	MCL	245
36	37.5	0	Inf. Dilution	dH:0.0(1SF)	0	MSL	247

Reaction No. 2443



Note: $\text{Ca}_3(\text{PO}_4)_2(\text{beta}, \text{s})$ is less soluble than alpha form

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0	Inf. Dilution	lgK:29.01(4SF)	0	MSL	404
2	15	0	Inf. Dilution	lgK:28.77(4SF)	0	MSL	404
3	25	0	Inf. Dilution	lgK:28.92(4SF)	3	MSL	404
4	25	0	Inf. Dilution	lgK:28.92(4SF)	3	CRV	2556
5	25	0	Inf. Dilution	lgK:25.0(3SF)	0	CRV	22551
6	25	0	Inf. Dilution	lgK:28.9(3SF)	3	EOD	31694
Note (6): from Gregory et al., 1974							
7	25	0	Inf. Dilution	lgK:25.23(4SF)	0	MSL	31718
Note (7): See $\text{Ca}_3(\text{PO}_4)_2(\text{alpha}, \text{s})$							
8	25	0	Inf. Dilution	lgK:28.9(3SF)	4	CRV	31723

9	25	0	Inf. Dilution	lgK:28.9(3SF)	5	CRV	31748
10	25	0	Inf. Dilution	lgK:28.9(3SF)	4	EOD	31761
11	25	0	Inf. Dilution	lgK:32.63(4SF)	0	CRV	32224
Note (11): specifies beta form							
12	25	0	Inf. Dilution	lgK:34.53(4SF)	0	CRV	32224
Note (12): specifies whitlockite							
13	25	0	CHEMVAL2	lgK:32.63(0.01SD)	0	ENS	5156
14	25	0	CHEMVAL3	lgK:32.63(0.01SD)	0	ENS	5156
15	25	0	CHEMVAL4	lgK:32.70(0.01SD)	0	ENS	5156
16	25	0	CHEMVAL4	lgK:32.70(0.01SD)	0	ENS	5156
17	37	0	Inf. Dilution	lgK:29.55(4SF)	3	MSL	404
18	37	0	Inf. Dilution	lgK:29.55(4SF)	3	CRV	2556
19	37	0	Inf. Dilution	lgK:29.55(4SF)	4	CRV	26737
20	37	0	Inf. Dilution	lgK:29.6(3SF)	4	CRV	31723
21	5	0	Inf. Dilution	dG:-36.9(3SF)	0	MSL	404
22	15	0	Inf. Dilution	dG:-37.9(3SF)	0	MSL	404
23	25	0	Inf. Dilution	dG:-39.4(3SF)	0	MSL	404
24	37	0	Inf. Dilution	dG:-41.9(3SF)	0	MSL	404
25	5	0	Inf. Dilution	dH:-16.(2SF)	0	MSL	404
26	10:40	0	Inf. Dilution	dH:-13.00(4SF)	0	CRV	2556
27	15	0	Inf. Dilution	dH:-1.5(2SF)	0	MSL	404
28	25	0	Inf. Dilution	dH:13.(2SF)	0	MSL	404
29	37	0	Inf. Dilution	dH:31.(2SF)	0	MSL	404

Reaction No. 2444							
4<Ca+2> + 3<PO4-3> + H+1 + 3<H2O> = Ca+2(4)_H+1_PO4-3(3)_H2O(3)_(s)							
Note: See also Ca+2(8)_H+1(2)_PO4-3(6)_H2O(5)_(s) which is deprecated							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:46.9(0.1SD)	3	MSL	253
2	25	0	Inf. Dilution	lgK:47.08(4SF)	3	CRV	2556
3	25	0	Inf. Dilution	lgK:43.8(3SF)	0	MSL	31718
4	25	0	Inf. Dilution	lgK:48.3(3SF)	2	CRV	31723
Note (4): 96.6 / 2 - see also Ca+2(8)_H+1(2)_PO4-3(6)_H2O(5)							
5	25	0	CHEMVAL2	lgK:46.90(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL3	lgK:46.99(0.01SD)	0	ENS	5156
7	25	0	CHEMVAL4	lgK:47.00(0.01SD)	2	ENS	5156

8	25	0.1	Unknown	lgK:44.08(4SF)	2	CRV	31724
9	37	0	Inf. Dilution	lgK:48.46(4SF)	2	CRV	2556
Note (9): May refer to unhydrated Ca+2(4)_H+1_PO4-3(3)_(s)							
10	37	0	Inf. Dilution	lgK:49.30(4SF)	3	CRV	26737
11	37	0	Inf. Dilution	lgK:49.3(0.2SD)	4	MSL	31716
12	37	0	Inf. Dilution	lgK:49.3(3SF)	3	CRV	31723
Note (12): 98.6 / 2 - see also Ca+2(8)_H+1(2)_PO4-3(6)_H2O(5)							
13	37	0.01	KNO3	lgK:47.4(3SF)	3	MSL	31716
Note (13): Read from Fig 1 (with some selection for internal consistency)							
14	37	0.1	KNO3	lgK:44.2(3SF)	3	MSL	31716
Note (14): Read from Fig 1							


Reaction No. 2445							
Ca+2 + H+1_PO4-3 + 2<H2O> = Ca+2_H+1_PO4-3_H2O(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0	Inf. Dilution	lgK:6.63(3SF)	6	MSL	247
2	15	0	Inf. Dilution	lgK:6.60(3SF)	6	MSL	247
3	18	0	Inf. Dilution	lgK:6.57(3SF)	4	CRV	552
4	25	0	Inf. Dilution	lgK:6.58(3SF)	5	CRV	8
5	25	0	Inf. Dilution	lgK:6.6(0.05SD)	5	CMN	246
6	25	0	Inf. Dilution	lgK:6.59(3SF)	6	MSL	247
7	25	0	Inf. Dilution	lgK:6.6(0.1SD)	5	ENS	5199
8	25	0	Inf. Dilution	lgK:6.6(2SF)	5	CRV	6405
9	25	0	Inf. Dilution	lgK:6.60(3SF)	3	EOD	31694
Note (9): from Gregory et al., 1970							
10	25	0	Inf. Dilution	lgK:6.20(3SF)	2	MSL	31718
11	25	0	Inf. Dilution	lgK:6.59(3SF)	4	CRV	31723
12	25	0	Inf. Dilution	lgK:6.59(3SF)	5	CRV	31748
13	25	0	Inf. Dilution	lgK:6.59(3SF)	4	EOD	31761
14	25	0.1	Unknown	lgK:5.8(2SF)	1	EES	
Note (14): Based on behaviour at 37C							
15	25	0.3	Unknown	lgK:5.6(2SF)	1	EES	
Note (15): Based on behaviour at 37C							
16	37	0	Inf. Dilution	lgK:6.5(0.05SD)	5	MGL	251
17	37	0	Inf. Dilution	lgK:6.67(3SF)	4	CRV	552
18	37	0	Inf. Dilution	lgK:6.65(3SF)	5	MSL	6468

19	37	0	Inf. Dilution	lgK:6.635 (4SF)	4	CRV	26737
20	37	0	Inf. Dilution	lgK:6.73 (3SF)	4	CRV	31723
21	37	0.03	KCl	lgK:6.12 (3SF)	5	MSL	6468
22	37	0.05	KCl	lgK:6.03 (3SF)	5	MSL	6468
23	37	0.1	KCl	lgK:5.88 (3SF)	5	MSL	6468
24	37	0.1	Unknown	lgK:5.88 (3SF)	5	CRV	2556
25	37	0.2	KCl	lgK:5.77 (3SF)	3	MSL	6468
26	37	0.3	KCl	lgK:5.71 (3SF)	3	MSL	6468
27	37	0.4	Unknown	lgK:5.37 (3SF)	3	EOD	29777
28	37	0.5	KCl	lgK:5.73 (3SF)	2	MSL	6468
29	37	0.5	Unknown	lgK:5.73 (3SF)	4	CRV	2556
30	37.5	0	Inf. Dilution	lgK:6.62 (3SF)	6	MSL	247
31	5	0	Inf. Dilution	dG:-8.4 (2SF)	5	MSL	247
32	15	0	Inf. Dilution	dG:-8.7 (2SF)	5	MSL	247
33	25	0	Inf. Dilution	dG:-9.0 (2SF)	5	MSL	247
34	37.5	0	Inf. Dilution	dG:-9.4 (2SF)	5	MSL	247
35	5	0	Inf. Dilution	dH:-1.8 (2SF)	0	MSL	247
36	15	0	Inf. Dilution	dH:-0.8 (1SF)	0	MSL	247
37	20:40	0	Inf. Dilution	dH:2. (1SF)	4	CRV	552
38	25	0	Inf. Dilution	dH:0.4 (1SF)	2	MSL	247
39	37.5	0	Inf. Dilution	dH:2.0 (2SF)	4	MSL	247

Reaction No. 2462							
P207-4 + Ca+2 = Ca+2_P207-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	19			lgK:5.00 (3SF)	0	MCO	140
2	25	0	Inf. Dilution	lgK:6.8 (0.05SD)	4	MGL	267
3	25	0	Inf. Dilution	lgK:5.60 (3SF)	3	MTN	268
4	25	0.1	Me4NBr	lgK:5.39 (3SF)	3	MTN	268
5	25	0.1	Me4NBr	lgK:5.4 (0.05SD)	3	MTN	268
6	25	0.1	NaCl	lgK:4.33 (0.01SD)	0	MDG	3540
7	25	1	Me4NBr	lgK:4.89 (3SF)	3	MTN	268
8	25	1	Me4NCl	lgK:5.55 (3SF)	0	MGL	140
9	25	1	Me4NCl	lgK:4.95 (0.25SD)	0	MGL	269
10	25	2	Me4NCl	lgK:4.79 (0.3SD)	5	MGL	269
11	30	0.1	NH4+ salt	lgK:5.23 (0.05SD)	4	MIS	5262


12	37	0	Inf. Dilution	lgK:5.75 (3SF)	3	MTN	268
13	37	0.1	Me4NBr	lgK:5.44 (3SF)	3	MTN	268
14	37	0.15	NaCl	lgK:3.47 (3SF)	0	MCE	140
15	37	1	Me4NBr	lgK:4.63 (3SF)	3	MTN	268
16	40	0	Inf. Dilution	lgK:6.5 (2SF)	4	MGL	140
17	50	0	Inf. Dilution	lgK:5.86 (3SF)	3	MTN	268
18	50	0.1	Me4NBr	lgK:5.39 (3SF)	3	MTN	268
19	50	1	Me4NBr	lgK:4.3 (2SF)	3	MTN	268

Reaction No. 2463




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.6 (2SF)	4	MTN	268
2	25	0.1	Me4NBr	lgK:3.3 (0.05SD)	5	MTN	268
3	25	1	Me4NBr	lgK:2.22 (3SF)	4	MTN	268
4	25	1	Me4NCl	lgK:2.30 (0.15SD)	5	MGL	5428
5	25	0	Inf. Dilution	dH:4.6 (2SF)	4	MTD	268

Reaction No. 2464




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.6 (2SF)	1	EES	
2	25	0	Inf. Dilution	lgK:8.9 (0.05SD)	3	MGL	267

Reaction No. 2465



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.3 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:7.9 (0.05SD)	0	MGL	267
3	25	3	Inert	lgK:7.5 (2SF)	1	EES	

Reaction No. 2480



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	2	0.1	KNO3	lgK:5.80 (3SF)	0	MGL	281
Note (1): Low wgt for internal consistency							
2	20	0.1	KCl	lgK:5.0 (0.05SD)	5	MGL	280

3	20	0.1	Me4NNO3	lgK:6.31(0.01SD)	0	MGL	284
4	23	0.1	(K,NH4)Cl	lgK:4.6(2SF)	0	MGL	140
5	23			lgK:4.0(2SF)	0	MSL	140
6	25	0	Inf. Dilution	lgK:8.1(2SF)	0	MGL	140
7	25	0	Inf. Dilution	lgK:6.90(3SF)	3	MTN	268
8	25	0	Inf. Dilution	lgK:6.90(3SF)	3	EOD	29070
9	25	0.016	Unknown	lgK:6.41(3SF)	0	MSL	140
10	25	0.1	K+1 salt	lgK:4.99(3SF)	6	CRV	552
11	25	0.1	KCl	lgK:5.20(0.04SD)	3	MGL	277
12	25	0.1	KNO3	lgK:4.80(3SF)	4	MGL	281
13	25	0.1	Me4NBr	lgK:6.4(2SF)	0	MTN	268
14	25	0.1	NaCl	lgK:5.05(0.02SD)	4	MDG	3540
15	25	0.1	NaCl	lgK:4.9(0.1SD)	5	MGL	3925
16	25	1	Me4NBr	lgK:5.36(3SF)	5	MGL	268
17	25	1	Me4NCl	lgK:5.44(3SF)	5	MGL	140
18	25	1	Me4NCl	lgK:5.44(3SF)	5	MSL	140
19	25	1	Me4NCl	lgK:5.44(0.25SD)	5	CMN	5428
20	25	2	Me4NCl	lgK:5.29(0.3SD)	0	MGL	269
21	25			lgK:3.56(3SF)	0	MTP	140
22	30	0.1	NH4+ salt	lgK:5.69(0.05SD)	0	MIS	5262
23	30			lgK:6.51(3SF)	0	MSL	140
24	35	0.1	KNO3	lgK:5.74(3SF)	0	MGL	5398
Note (24): Low wgt for internal consistency							
25	37	0	Inf. Dilution	lgK:6.80(3SF)	3	MTN	268
26	37	0.1	Me4NBr	lgK:6.33(3SF)	0	MTN	268
27	37	1	Me4NBr	lgK:5.25(3SF)	5	MGL	268
28	40	0	Inf. Dilution	lgK:7.8(2SF)	3	MGL	140
29	45	0.1	KNO3	lgK:4.73(3SF)	5	MGL	281
30	50	0	Inf. Dilution	lgK:6.72(3SF)	3	MTN	268
31	50	0.1	Me4NBr	lgK:6.27(3SF)	0	MTN	268
32	50	1	Me4NBr	lgK:5.18(3SF)	5	MTN	268
33	60			lgK:6.68(3SF)	0	MSL	140
34	20	0.1	Me4NNO3	dH:3.3(2SF)	0	MCL	284
35	25	0	Inf. Dilution	dH:-3.2(2SF)	4	MTD	268
36	25	0.1	KNO3	dH:-6.6(3.SD)	0	MTD	281

Reaction No. 2481							
Ca+2 + H+1_P3O10-5 = Ca+2_H+1_P3O10-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	2	0.1	KNO3	lgK:3.00 (3SF)	5	MGL	281
2	20	0.1	KCl	lgK:3.1 (2SF)	5	MGL	140
3	20	0.1	Me4NNO3	lgK:4.02 (0.01SD)	0	MGL	284
4	23	0.1	NH4Cl	lgK:3.3 (2SF)	4	MGL	140
5	25	0	Inf. Dilution	lgK:3.9 (0.05SD)	2	MTN	268
6	25	0	Inf. Dilution	lgK:3.90 (3SF)	3	EOD	29070
7	25	0.1	KCl	lgK:3.04 (0.02SD)	3	MGL	277
8	25	0.1	KNO3	lgK:3.2 (0.1SD)	3	CMN	281
Note (8): Suspect other species							
9	25	0.1	KNO3	lgK:3.28 (3SF)	5	MGL	5398
10	25	0.1	Me4N+ salt	lgK:3.9 (0.1SD)	3	CRV	552
11	25	0.1	Me4NBr	lgK:3.78 (3SF)	0	MTN	268
12	25	0.1	Na+1 salt	lgK:3.2 (2SF)	6	CRV	552
13	25	1	Me4NBr	lgK:3.3 (0.05SD)	3	MTN	268
14	25	1	Me4NCl	lgK:3.04 (3SF)	5	MGL	140
15	25	1	Me4NCl	lgK:3.01 (0.15SD)	5	MSL	269
16	25	2	Me4NCl	lgK:3.27 (0.3SD)	0	MGL	269
17	35	0.1	KNO3	lgK:3.34 (3SF)	5	MGL	281
18	45	0.1	KNO3	lgK:3.07 (3SF)	0	MGL	281
19	0:50	1	Unknown	dH:2. (1SF)	6	CRV	552
20	25	0.1	KNO3	dH:-0.82 (0.01SD)	0	MTD	281

Reaction No. 2482							
OH-1 + Ca+2_P3O10-5 = Ca+2_OH-1_P3O10-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.5 (2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:2.1 (2SF)	0	ERG	

Reaction No. 2483							
OH-1 + P3O10-5 + Ca+2 = Ca+2_OH-1_P3O10-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.4 (0.05SD)	5	MGL	267
2	40	0	Inf. Dilution	lgK:9.8 (2SF)	4	MGL	140

Reaction No. 2484							
Ca+2 + H+1(2)_P3010-5 = Ca+2_H+1(2)_P3010-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.9(0.05SD)	5	MTN	268
2	25	0	Inf. Dilution	lgK:3.90(3SF)	3	EOD	29070
3	25	1	Me4NBr	lgK:2.77(3SF)	5	MTN	268


Reaction No. 2502							
F-1 + Ca+2 = Ca+2_F-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	100	0	P=500 Inf. Dilution	lgK:1.11(3SF)	5	EOD	6495
2	150	0	P=500 Inf. Dilution	lgK:1.57(3SF)	5	EOD	6495
3	200	0	P=500 Inf. Dilution	lgK:2.08(3SF)	5	EOD	6495
4	250	0	P=500 Inf. Dilution	lgK:2.67(3SF)	4	EOD	6495
5	300	0	P=500 Inf. Dilution	lgK:3.33(3SF)	3	EOD	6495
6	100	0	P=1000 Inf. Dilution	lgK:1.07(3SF)	5	EOD	6495
7	150	0	P=1000 Inf. Dilution	lgK:1.5(2SF)	5	EOD	6495
8	200	0	P=1000 Inf. Dilution	lgK:1.98(3SF)	5	EOD	6495
9	250	0	P=1000 Inf. Dilution	lgK:2.51(3SF)	4	EOD	6495
10	300	0	P=1000 Inf. Dilution	lgK:3.07(3SF)	3	EOD	6495
11	100	0	P=2000 Inf. Dilution	lgK:1.01(3SF)	5	EOD	6495
12	150	0	P=2000 Inf. Dilution	lgK:1.41(3SF)	5	EOD	6495
13	200	0	P=2000 Inf. Dilution	lgK:1.84(3SF)	5	EOD	6495
14	250	0	P=2000 Inf. Dilution	lgK:2.3(2SF)	4	EOD	6495
15	300	0	P=2000 Inf. Dilution	lgK:2.78(3SF)	3	EOD	6495
16	100	0	P=3000 Inf. Dilution	lgK:0.96(2SF)	5	EOD	6495

17	150	0	P=3000 Inf. Dilution	lgK:1.34 (3SF)	5	EOD	6495
18	200	0	P=3000 Inf. Dilution	lgK:1.75 (3SF)	5	EOD	6495
19	250	0	P=3000 Inf. Dilution	lgK:2.16 (3SF)	4	EOD	6495
20	300	0	P=3000 Inf. Dilution	lgK:2.59 (3SF)	3	EOD	6495
21	100	0	P=4000 Inf. Dilution	lgK:0.93 (2SF)	5	EOD	6495
22	150	0	P=4000 Inf. Dilution	lgK:1.29 (3SF)	5	EOD	6495
23	200	0	P=4000 Inf. Dilution	lgK:1.67 (3SF)	5	EOD	6495
24	250	0	P=4000 Inf. Dilution	lgK:2.06 (3SF)	4	EOD	6495
25	300	0	P=4000 Inf. Dilution	lgK:2.46 (3SF)	3	EOD	6495
26	100	0	P=5000 Inf. Dilution	lgK:0.92 (2SF)	5	EOD	6495
27	150	0	P=5000 Inf. Dilution	lgK:1.26 (3SF)	5	EOD	6495
28	200	0	P=5000 Inf. Dilution	lgK:1.62 (3SF)	5	EOD	6495
29	250	0	P=5000 Inf. Dilution	lgK:1.99 (3SF)	4	EOD	6495
30	300	0	P=5000 Inf. Dilution	lgK:2.35 (3SF)	3	EOD	6495
31	0	0	Inf. Dilution	lgK:0.66 (2SF)	4	EOD	6495
32	2	1	NaClO4	lgK:0.41 (2SF)	5	MIS	310
33	2	1	NaClO4	lgK:0.43 (2SF)	5	MIS	312
34	15	1	NaNO3	lgK:0.52 (2SF)	3	MIS	5398
35	25	0	Inf. Dilution	lgK:1.04 (3SF)	3	MRX	140
36	25	0	Inf. Dilution	lgK:1.0 (0.1SD)	5	MRX	5433
37	25	0	Inf. Dilution	lgK:0.68 (2SF)	3	EOD	6495
38	25	0	Inf. Dilution	lgK:0.94 (2SF)	4	ENS	6496
39	25	0	Inf. Dilution	lgK:1.31 (0.06SD)	3	EES	7391
40	25	0	Inf. Dilution	lgK:1.33 (3SF)	4	CRV	8749
41	25	0	Inf. Dilution	lgK:1.10 (3SF)	5	CRV	9402
42	25	0	Inf. Dilution	lgK:1.1 (2SF)	3	EOD	29891
43	25	0	Inf. Dilution	lgK:0.94 (2SF)	4	CRV	32224
44	25	0	CHEMVAL1	lgK:1.10 (0.01SD)	0	ENS	5156

45	25	0	CHEMVAL2	lgK:1.10 (0.01SD)	0	ENS	5156
46	25	0	CHEMVAL3	lgK:1.10 (0.01SD)	0	ENS	5156
47	25	0	CHEMVAL4	lgK:1.24 (0.01SD)	5	ENS	5156
48	25	0	UCT_Sea	lgK:1.10 (0.01SD)	4	EDH	5390
49	25	0.1	NaCl	lgK:0.82 (2SF)	5	MIS	5398
50	25	0.1	UCT_Sea	lgK:0.72 (0.01SD)	4	EDH	5390
51	25	0.2	NaCl	lgK:0.77 (2SF)	5	MIS	5398
52	25	0.2	UCT_Sea	lgK:0.65 (0.01SD)	4	EDH	5390
53	25	0.3	UCT_Sea	lgK:0.62 (0.01SD)	4	EDH	5390
54	25	0.4	NaCl	lgK:0.70 (2SF)	5	MIS	5398
55	25	0.4	UCT_Sea	lgK:0.61 (0.01SD)	4	EDH	5390
56	25	0.5	NaClO4	lgK:0.51 (2SF)	3	MRX	140
57	25	0.5	NaClO4	lgK:0.70 (2SF)	5	MIS	309
58	25	0.5	NaClO4	lgK:0.7 (0.05SD)	5	MIS	309
59	25	0.5	UCT_Sea	lgK:0.60 (0.01SD)	4	EDH	5390
60	25	0.6	NaCl	lgK:0.64 (2SF)	5	MIS	5398
61	25	0.6	UCT_Sea	lgK:0.60 (0.01SD)	4	EDH	5390
62	25	0.7	NaCl	lgK:0.63 (2SF)	5	MIS	5398
63	25	0.7	UCT_Sea	lgK:0.60 (0.01SD)	4	EDH	5390
64	25	0.7	Unknown	lgK:0.60 (2SF)	4	EOD	5644
65	25	0.7	Unknown	lgK:0.65 (0.06SD)	5	CMN	7391
66	25	0.7	Unknown	lgK:0.51 (2SF)	4	ENS	7391
67	25	0.7	Unknown	lgK:0.65 (2SF)	4	ENS	7391
68	25	0.8	NaCl	lgK:0.61 (2SF)	5	MIS	5398
69	25	1	NaCl	lgK:0.56 (2SF)	3	MIS	437
70	25	1	NaCl	lgK:0.59 (2SF)	5	MIS	5398
71	25	1	NaClO4	lgK:0.63 (2SF)	5	MIS	310
72	25	1	NaClO4	lgK:0.53 (2SF)	5	MIS	312
73	25	1	NaNO3	lgK:0.57 (2SF)	3	MIS	5398
74	25	1	Unknown	lgK:0.6 (0.05SD)	6	CRV	552
75	35	0	Inf. Dilution	lgK:1.39 (3SF)	4	CRV	8749
76	35	1	NaClO4	lgK:0.74 (2SF)	5	MIS	312
77	35	1	NaNO3	lgK:0.62 (2SF)	3	MIS	5398
78	39	1	NaClO4	lgK:0.79 (2SF)	5	MIS	310
79	50	0	Inf. Dilution	lgK:0.8 (1SF)	2	EOD	6495
80	50	0	Inf. Dilution	lgK:1.46 (3SF)	4	CRV	8749

81	75	0	Inf. Dilution	lgK:0.97 (2SF)	2	EOD	6495
82	100	0	Inf. Dilution	lgK:1.17 (3SF)	2	EOD	6495
83	125	0	Inf. Dilution	lgK:1.4 (2SF)	2	EOD	6495
84	150	0	Inf. Dilution	lgK:1.65 (3SF)	3	EOD	6495
85	175	0	Inf. Dilution	lgK:1.92 (3SF)	3	EOD	6495
86	200	0	Inf. Dilution	lgK:2.22 (3SF)	5	EOD	6495
87	225	0	Inf. Dilution	lgK:2.54 (3SF)	4	EOD	6495
88	250	0	Inf. Dilution	lgK:2.89 (3SF)	4	EOD	6495
89	275	0	Inf. Dilution	lgK:3.28 (3SF)	3	EOD	6495
90	300	0	Inf. Dilution	lgK:3.73 (3SF)	0	EOD	6495
91	25	0	Inf. Dilution	dH:4.12 (3SF)	4	ENS	6496
92	25	0	Inf. Dilution	dH:3.50 (3SF)	5	CRV	9402
93	25	1	NaClO4	dH:3.489 (4SF)	3	MCL	310
94	25	1	NaClO4	dH:3.800 (4SF)	3	MEF	310
95	25	1	NaClO4	dH:4. (1.SD)	3	CMN	437
96	25	1	NaNO3	dH:2. (1.SD)	3	EVK	437
97	25	1	NaNO3	dH:2.294 (4SF)	3	MTD	437
98	25	1	Unknown	dH:3.5 (2SF)	6	CRV	552

Reaction No. 2509



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	200	0	P=300 Inf. Dilution	lgK:1.146 (4SF)	2	EOD	29559
2	5	0.5	Inert	lgK:-0.06 (0.2SD)	0	MIS	8681
3	10	0.1	Inert	lgK:-0.03 (1SF)	0	EOD	5574
4	10	0.5	Inert	lgK:-0.05 (1SF)	0	EOD	5574
5	10	1	Inert	lgK:-0.12 (2SF)	0	EOD	5574
6	15	0.5	Inert	lgK:-0.04 (0.2SD)	0	MIS	8681
7	15	1	NaNO3	lgK:-0.3 (0.05SD)	0	MIS	5019
8	15	1	NaNO3/m	lgK:0.66 (2SF)	0	MIS	12227
9	15	1	NaNO3/m	lgK:0.64 (2SF)	0	MAG	12227
10	23	1	LiClO4	lgK:-0.22 (2SF)	0	MCE	5398
11	25	0	Inf. Dilution	lgK:0.466 (3SF)	0	EMU	5416
12	25	0	Inf. Dilution	lgK:0.2 (1SF)	3	EOD	21825
13	25	0	Inf. Dilution	lgK:-0.292 (3SF)	0	EOD	29559
14	25	0	CHEMVAL1	lgK:0.08 (0.01SD)	0	ENS	5156

15	25	0	CHEMVAL2	lgK:0.08(0.01SD)	0	ENS	5156
16	25	0	CHEMVAL3	lgK:0.08(0.01SD)	0	ENS	5156
17	25	0	CHEMVAL4	lgK:-0.32(0.01SD)	0	ENS	5156
18	25	0.1	Inert	lgK:0.03(1SF)	0	EOD	5574
19	25	0.1	Unknown	lgK:0.2(0.2SD)	0	CRV	552
20	25	0.5	Inert	lgK:-0.02(1SF)	0	EOD	5574
21	25	0.5	Inert	lgK:-0.02(0.2SD)	0	MIS	8681
22	25	0.5	Unknown	lgK:-0.1(0.03SD)	0	CRV	552
23	25	1	Inert	lgK:0.13(2SF)	0	EOD	5574
24	25	1	NaClO4	lgK:-0.2(0.1SD)	2	ERS	315
25	25	1	NaNO3	lgK:-0.2(0.05SD)	2	MIS	5019
26	25	1	NaNO3/m	lgK:0.76(2SF)	0	MIS	12227
27	25	1	NaNO3/m	lgK:0.77(2SF)	0	MAG	12227
28	35	0.5	Inert	lgK:0.01(0.2SD)	0	MIS	8681
29	35	1	NaNO3/m	lgK:0.81(2SF)	0	MIS	12227
30	35	1	NaNO3/m	lgK:0.75(2SF)	0	MAG	12227
31	45	0.1	Inert	lgK:0.10(2SF)	0	EOD	5574
32	45	0.5	Inert	lgK:0.02(1SF)	0	EOD	5574
33	45	0.5	Inert	lgK:0.02(0.2SD)	0	MIS	8681
34	45	1	Inert	lgK:0.14(2SF)	0	EOD	5574
35	45	1	NaNO3	lgK:-0.2(0.05SD)	0	MIS	5019
36	45	1	NaNO3/m	lgK:0.89(2SF)	0	MIS	12227
37	45	1	NaNO3/m	lgK:0.86(2SF)	0	MAG	12227
38	60	1	NaNO3/m	lgK:0.92(2SF)	0	MIS	12227
39	60	1	NaNO3/m	lgK:0.95(2SF)	0	MAG	12227
40	65	1	NaNO3	lgK:-0.09(0.05SD)	0	MIS	5019
41	85	1	NaNO3	lgK:-0.01(0.05SD)	0	MIS	5019
42	150	0	HCl/m	lgK:-0.07(0.01SD)	0	MSL	12189
43	150	0	Inf. Dilution/m	lgK:-0.07(0.01SD)	0	EOD	12628
44	250	0	Inf. Dilution/m	lgK:1.13(3SF)	0	EOD	12628
45	250	0	Inf. Dilution/m	lgK:1.85(3SF)	2	EOD	12628
46	275	0	Inf. Dilution/m	lgK:2.24(3SF)	0	EOD	12628
47	300	0	Inf. Dilution/m	lgK:2.02(3SF)	0	MCL	12628
48	25	0.6	NaCl	lgR:0.35(2SF)	3	MPT	8898
49	25	0.7	NaCl	lgR:-0.8(1SF)	3	MSL	7229
50	10:50	1	Unknown	dH:2.(1SF)	0	CRV	2556

51	25	1	NaNO3/m	dH:-1.719(4SF)	0	MTD	12227
52	250	0	Inf. Dilution/m	dH:82.(2SF)kJ	0	EOD	12628
53	275	0	Inf. Dilution/m	dH:94.(2SF)kJ	0	EOD	12628
54	300	0	Inf. Dilution/m	dH:102.(3SF)kJ	0	MCL	12628
55	25	1	NaNO3/m	dS:-6.3(3.5SD)	0	EFE	12227
56	25		Ethanol:Acetone 50:50Wgt	lgK:2.695(4SF)	4	MDG	5398

Reaction No. 2519							
Ca+2 + H+1_CO3-2 = Ca+2_H+1_CO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:0.7(1SF)	3	MCN	5398
2	4.4	0	Inf. Dilution	lgK:0.91(2SF)	4	EMU	5416
3	4.4	0	Inf. Dilution	lgK:0.91(2SF)	7	MSL	6346
4	15	0	Inf. Dilution	lgK:0.88(2SF)	4	EMU	5416
5	15.1	0	Inf. Dilution	lgK:0.97(2SF)	4	EMU	5416
6	15.1	0	Inf. Dilution	lgK:0.97(2SF)	7	MSL	6346
7	20:24	0.152	NaCl	lgK:0.8(0.05SD)	0	MGL	334
Note (7): Recalculated by Plummer & Busenberg, 1982, 46, 1011 [6346]							
8	22	0	Inf. Dilution	lgK:1.27(3SF)w	4	MPH	5398
9	25	0	Inf. Dilution	lgK:1.26(3SF)	4	MGL	140
10	25	0	Inf. Dilution	lgK:1.2(0.04SD)	5	CMN	5366
11	25	0	Inf. Dilution	lgK:1.0(2SF)	4	MCN	5398
12	25	0	Inf. Dilution	lgK:1.25(3SF)	4	MSC	5398
13	25	0	Inf. Dilution	lgK:0.99(2SF)	4	EMU	5416
14	25	0	Inf. Dilution	lgK:1.14(3SF)	4	EMU	5416
15	25	0	Inf. Dilution	lgK:1.28(0.06SD)	5	MGL	6346
16	25	0	Inf. Dilution	lgK:1.11(0.07SD)	7	MGL	6346
17	25	0	Inf. Dilution	lgK:1.32(3SF)	4	MSL	6346
18	25	0	Inf. Dilution	lgK:1.25(3SF)	5	MSL	6346
19	25	0	Inf. Dilution	lgK:1.14(3SF)	7	MSL	6346
20	25	0	Inf. Dilution	lgK:1.3(2SF)	4	EOD	6346
Note (20): Data of Martynova, Desalination, 1974, 15, 259							
21	25	0	Inf. Dilution	lgK:1.106(4SF)	4	ENS	6496
22	25	0	Inf. Dilution	lgK:1.0(0.1SD)	5	CMN	7391
23	25	0	Inf. Dilution	lgK:1.23(3SF)	4	ENS	7391
24	25	0	Inf. Dilution	lgK:1.225(4SF)	4	ENS	7391

25	25	0	Inf. Dilution	lgK:1.14 (3SF)	4	MSL	8385
26	25	0	Inf. Dilution	lgK:1.26 (3SF)	3	EOD	31694
Note (26): from Garrels & Thompson, 1962							
27	25	0	Inf. Dilution/m	lgK:2.63 (3SF)	0	CRV	24953
28	25	0	SOLMNEQ	lgK:1.26 (3SF)	4	CMN	5416
29	25	0	SOLVEQ	lgK:1.23 (3SF)	0	CMN	5416
30	25	0	WATCH	lgK:1.02 (3SF)	0	CMN	5416
31	25	0	WATEQF	lgK:1.02 (3SF)	0	CMN	5416
32	25	0.6	NaCl	lgK:0.29 (2SF)	5	MPT	8898
33	25	0.7	NaCl	lgK:0.02 (1SF)	1	EES	
34	25	0.7	Seawater	lgK:0.29 (2SF)	5	MGL	4996
35	25	0.7	Unknown	lgK:0.29 (2SF)	3	MEF	5398
36	25	0.7	Unknown	lgK:0.33 (0.05SD)	4	CMN	7391
37	35	0	Inf. Dilution	lgK:1.16 (3SF)	4	EMU	5416
38	35	0	Inf. Dilution	lgK:1.17 (3SF)	4	EMU	5416
39	35	0	Inf. Dilution	lgK:1.17 (3SF)	7	MSL	6346
40	45	0	Inf. Dilution	lgK:1.21 (3SF)	4	EMU	5416
41	45	0	Inf. Dilution	lgK:1.29 (3SF)	4	EMU	5416
42	45	0	Inf. Dilution	lgK:1.21 (3SF)	6	MSL	6346
43	50	0	Inf. Dilution	lgK:3.4 (2SF)	0	MSC	5
44	50	0	Inf. Dilution	lgK:1.35 (3SF)	4	MCN	5398
45	50	0	Inf. Dilution/m	lgK:2.58 (3SF)	0	CRV	24953
46	50	0	SOLMNEQ	lgK:1.64 (3SF)	4	CMN	5416
47	50	0	SOLVEQ	lgK:1.32 (3SF)	0	CMN	5416
48	50	0	WATCH	lgK:1.34 (3SF)	0	CMN	5416
49	50	0	WATEQF	lgK:1.35 (3SF)	0	CMN	5416
50	60	0	Inf. Dilution	lgK:1.65 (3SF) w	4	MPH	5398
51	65	0	Inf. Dilution	lgK:1.21 (3SF)	0	EMU	5416
52	65	0	Inf. Dilution	lgK:1.21 (3SF)	2	MSL	6346
53	70	0	Inf. Dilution	lgK:1.77 (3SF) w	4	MPH	5398
54	75	0	Inf. Dilution/m	lgK:2.61 (3SF)	0	CRV	24953
55	75	0	SOLMNEQ	lgK:2.03 (3SF)	0	CMN	5416
56	75	0	WATCH	lgK:1.63 (3SF)	0	CMN	5416
57	75	0	WATEQF	lgK:1.68 (3SF)	0	CMN	5416
58	80	0	Inf. Dilution	lgK:1.82 (3SF) w	4	MPH	5398
59	80	0	Inf. Dilution	lgK:1.27 (3SF)	0	EMU	5416

Note (59): Low wgt for internal consistency							
60	80	0	Inf. Dilution	lgK:1.27 (3SF)	0	MSL	6346
61	90	0	Inf. Dilution	lgK:1.94 (3SF)w	4	MPH	5398
62	90	0	Inf. Dilution	lgK:1.35 (3SF)	0	MSL	6346
63	98	0	Inf. Dilution	lgK:2.01 (3SF)w	3	MPH	5398
64	100	0	Inf. Dilution	lgK:3.9 (2SF)	0	MSC	5
65	100	0	Inf. Dilution/m	lgK:2.68 (3SF)	0	CRV	24953
66	100	0	SOLMNEQ	lgK:2.43 (3SF)	0	CMN	5416
67	100	0	SOLVEQ	lgK:1.57 (3SF)	0	CMN	5416
68	100	0	WATCH	lgK:1.91 (3SF)	0	CMN	5416
69	100	0	WATEQF	lgK:2.01 (3SF)	0	CMN	5416
70	125	0	SOLMNEQ	lgK:2.84 (3SF)	0	CMN	5416
71	125	0	WATCH	lgK:2.17 (3SF)	0	CMN	5416
72	125	0	WATEQF	lgK:2.35 (3SF)	0	CMN	5416
73	150	0	Inf. Dilution	lgK:4.5 (2SF)	0	MSC	5
74	150	0	Inf. Dilution/m	lgK:2.95 (3SF)	0	CRV	24953
75	150	0	SOLMNEQ	lgK:3.27 (3SF)	0	CMN	5416
76	150	0	SOLVEQ	lgK:1.91 (3SF)	0	CMN	5416
77	150	0	Unknown	lgK:1.15 (3SF)	0	MSL	22077
78	150	0	WATCH	lgK:2.42 (3SF)	0	CMN	5416
79	150	0	WATEQF	lgK:2.68 (3SF)	0	CMN	5416
80	150			lgK:1.15 (3SF)	0	MSL	5398
81	175	0	SOLMNEQ	lgK:3.73 (3SF)	0	CMN	5416
82	175	0	WATCH	lgK:2.65 (3SF)	0	CMN	5416
83	175	0	WATEQF	lgK:3.01 (3SF)	0	CMN	5416
84	200	0	Inf. Dilution	lgK:5.2 (2SF)	6	MSC	5
85	200	0	SOLMNEQ	lgK:4.24 (3SF)	0	CMN	5416
86	200	0	SOLVEQ	lgK:2.36 (3SF)	0	CMN	5416
87	200	0	WATCH	lgK:2.87 (3SF)	0	CMN	5416
88	200	0	WATEQF	lgK:3.34 (3SF)	0	CMN	5416
89	225	0	SOLMNEQ	lgK:4.84 (3SF)	0	CMN	5416
90	225	0	Unknown	lgK:1.76 (3SF)	0	MSL	22077
91	225	0	WATCH	lgK:3.08 (3SF)	0	CMN	5416
92	225	0	WATEQF	lgK:3.68 (3SF)	0	CMN	5416
93	225			lgK:1.76 (3SF)	0	MSL	5398
94	250	0	SOLMNEQ	lgK:5.50 (3SF)	0	CMN	5416

95	250	0	SOLVEQ	lgK:3.02 (3SF)	0	CMN	5416
96	250	0	WATCH	lgK:3.28 (3SF)	0	CMN	5416
97	250	0	WATEQF	lgK:4.01 (3SF)	0	CMN	5416
98	275	0	SOLMNEQ	lgK:6.22 (3SF)	0	CMN	5416
99	275	0	WATCH	lgK:3.47 (3SF)	0	CMN	5416
100	275	0	WATEQF	lgK:4.34 (3SF)	0	CMN	5416
101	300	0	SOLMNEQ	lgK:7.00 (3SF)	0	CMN	5416
102	300	0	SOLVEQ	lgK:4.12 (3SF)	0	CMN	5416
103	300	0	WATCH	lgK:3.65 (3SF)	0	CMN	5416
104	300	0	WATEQF	lgK:4.67 (3SF)	0	CMN	5416
105	325	0	SOLMNEQ	lgK:7.86 (3SF)	0	CMN	5416
106	325	0	WATCH	lgK:3.83 (3SF)	0	CMN	5416
107	325	0	WATEQF	lgK:5.01 (3SF)	0	CMN	5416
108	350	0	SOLMNEQ	lgK:8.80 (3SF)	0	CMN	5416
109	350	0	WATCH	lgK:4.00 (3SF)	0	CMN	5416
110	350	0	WATEQF	lgK:5.34 (3SF)	0	CMN	5416
111	0:50	0	Inf. Dilution	dH:5. (1SF)	3	CRV	552
112	25	0	Inf. Dilution	dH:2.69 (3SF)	3	ENS	6496

Reaction No. 2520							
Ca+2 + CO3-2 = Ca+2_CO3-2_(Arag.,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	P=400 Inf. Dilution	lgK:7.980 (4SF)	3	CRV	11928
Note (1): with lgK0=8.345 & Kp/K=2.32							
2	25	0	P=1000 Inf. Dilution	lgK:7.489 (4SF)	3	CRV	11928
Note (2): with lgK0=8.345 & Kp/K=7.18							
3	0.7	0	Inf. Dilution	lgK:8.226 (4SF)	5	MSL	6346
4	3.9	0	Inf. Dilution	lgK:8.226 (4SF)	7	MSL	6346
5	4.9	0	Inf. Dilution	lgK:8.234 (4SF)	7	MSL	6346
6	15.1	0	Inf. Dilution	lgK:8.274 (4SF)	7	MSL	6346
7	25	0	Inf. Dilution	lgK:8.22 (3SF)	3	ENS	773
8	25	0	Inf. Dilution	lgK:8.3 (0.05SD)	4	ENS	5484
9	25	0	Inf. Dilution	lgK:8.34 (3SF)	3	CRV	6232
10	25	0	Inf. Dilution	lgK:8.336 (4SF)	4	MGL	6346
11	25	0	Inf. Dilution	lgK:8.332 (4SF)	7	MSL	6346

12	25	0	Inf. Dilution	lgK:8.22 (3SF)	2	CRV	6405
13	25	0	Inf. Dilution	lgK:8.26 (3SF)	4	CRV	8749
14	25	0	Inf. Dilution	lgK:8.30 (3SF)	7	MSL	8910
15	25	0	Inf. Dilution	lgK:8.22 (3SF)	4	CRV	32224
16	25	0	CHEMVAL1	lgK:8.22 (0.01SD)	0	ENS	5156
17	25	0	CHEMVAL2	lgK:8.22 (0.01SD)	0	ENS	5156
18	25	0	CHEMVAL3	lgK:8.22 (0.01SD)	0	ENS	5156
19	25	0	CHEMVAL4	lgK:8.12 (0.01SD)	0	ENS	5156
20	25	0	Inf. Dilution/m	lgK:8.333 (4SF)	5	MSL	21799
21	25	1	Unknown	lgK:7.0 (2SF)	1	EOR	
22	35	0	Inf. Dilution	lgK:8.395 (4SF)	7	MSL	6346
23	35	0	Inf. Dilution	lgK:8.32 (3SF)	4	CRV	8749
24	44.9	0	Inf. Dilution	lgK:8.474 (4SF)	7	MSL	6346
25	50	0	Inf. Dilution	lgK:8.46 (3SF)	4	CRV	8749
26	55	0	Inf. Dilution	lgK:8.590 (4SF)	7	MSL	6346
27	65	0	Inf. Dilution	lgK:8.698 (4SF)	4	MSL	6346
28	80	0	Inf. Dilution	lgK:8.876 (4SF)	2	MSL	6346
29	90	0	Inf. Dilution	lgK:9.021 (4SF)	0	MSL	6346
30	0:90	0	Inf. Dilution	dH:3. (1SF)	4	CRV	552
31	25	0	Inf. Dilution	dH:2.6 (0.1SD)	5	ENS	5484
32	25	0	Inf. Dilution	dH:2.589 (4SF)	4	ENS	6496

Reaction No. 2526							
Ca+2 + Mg+2 + 2<CO3-2> = Ca+2_Mg+2_CO3-2 (2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.1 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:17.00 (4SF)	0	CRV	9402
3	25	0	Inf. Dilution	lgK:15.44 (4SF)	0	CRV	28992
4	25	0	Inf. Dilution	lgK:18.06 (4SF)	0	CRV	32224
5	50	0	Inf. Dilution	lgK:16.19 (4SF)	0	CRV	28992
6	100	0	Inf. Dilution	lgK:17.88 (4SF)	0	CRV	28992
7	150	0	Inf. Dilution	lgK:19.91 (4SF)	0	CRV	28992
8	200	0	Inf. Dilution	lgK:22.10 (4SF)	0	CRV	28992
9	25	0	Inf. Dilution	dH:8.36 (3SF)	2	CRV	9402
10	25	0	Inf. Dilution	Cp:200.00 (5SF)	3	CRV	9402

Reaction No. 2527							
$\text{Ca}+2_ \text{CO}_3-2_ (\text{Calc.}, \text{s}) + \text{Mg}+2_ \text{CO}_3-2_ (\text{s}) = \text{Ca}+2_ \text{Mg}+2_ \text{CO}_3-2(2)_ (\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.3(1SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:1.7(2SF)	0	CRV	6405

Reaction No. 2528							
$\text{Mg}+2 + \text{Ca}+2 + 2<\text{CO}_2(\text{g})> + 2<\text{H}_2\text{O}> = \text{Ca}+2_ \text{Mg}+2_ \text{CO}_3-2(2)_ (\text{s}) + 4<\text{H}+1>$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-19.0(3SF)	1	ELC	

Reaction No. 2529							
$\text{Mg}+2 + \text{Ca}+2 + 4<\text{H}+1_ \text{CO}_3-2> = \text{Ca}+2_ \text{Mg}+2_ \text{CO}_3-2(2)_ (\text{s}) + 2<\text{CO}_2(\text{g})> + 2<\text{H}_2\text{O}>$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2(3SF)	1	ELC	

Reaction No. 2530							
$2<\text{Ca}+2_ \text{CO}_3-2_ (\text{Calc.}, \text{s})> + \text{Mg}+2 = \text{Ca}+2_ \text{Mg}+2_ \text{CO}_3-2(2)_ (\text{s}) + \text{Ca}+2$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.2(1SF)	1	ELC	

Reaction No. 2531							
$\text{Ca}+2_ \text{Mg}+2_ \text{CO}_3-2(2)_ (\text{s}) + \text{Mg}+2 = 2<\text{Mg}+2_ \text{CO}_3-2_ (\text{s})> + \text{Ca}+2$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.5(1SF)	1	ELC	

Reaction No. 2535							
$\text{NO}_3-1 + \text{Ca}+2 = \text{Ca}+2_ \text{NO}_3-1$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18	0	Inf. Dilution	lgK:0.28(2SF)	4	MCN	140
2	18	0	Inf. Dilution	lgK:0.41(2SF)	4	MCN	931
3	18	0	Inf. Dilution	lgK:0.283(3SF)	3	MCN	11989
4	23	1	LiClO ₄	lgK:-0.22(2SF)	5	MCE	5398
5	23	1	NaClO ₄	lgK:-0.22(2SF)	5	MCE	5398
6	25	0	Inf. Dilution	lgK:0.5(0.2SD)	5	CMN	353
7	25	0	Inf. Dilution	lgK:0.6(1SF)	3	MAC	931
8	25	0	Inf. Dilution	lgK:0.31(2SF)	4	MCN	931

9	25	0	Inf. Dilution	lgK:0.7(0.05SD)	5	MSL	5055
10	25	0	Inf. Dilution	lgK:0.28(0.03SD)	5	CMN	7391
11	25	0	Inf. Dilution	lgK:0.041(0.04SD)	3	MMR	31218
12	25	0	Inf. Dilution	lgK:0.7(1SF)	4	CRV	32224
13	25	0	CHEMVAL4	lgK:0.60(0.01SD)	5	ENS	5156
14	25	0	UCT_Sea	lgK:0.70(0.01SD)	2	EDH	5390
15	25	0.1	UCT_Sea	lgK:0.29(0.01SD)	2	EDH	5390
16	25	0.2	UCT_Sea	lgK:0.20(0.01SD)	2	EDH	5390
17	25	0.3	UCT_Sea	lgK:0.14(0.01SD)	2	EDH	5390
18	25	0.4	UCT_Sea	lgK:0.10(0.01SD)	2	EDH	5390
19	25	0.5	LiClO ₄	lgK:0.06(0.05SD)	3	MSL	5055
20	25	0.5	UCT_Sea	lgK:0.06(0.01SD)	2	EDH	5390
21	25	0.5	Unknown	lgK:-0.1(0.1SD)	6	CRV	552
22	25	0.6	UCT_Sea	lgK:0.03(0.01SD)	2	EDH	5390
23	25	0.7	UCT_Sea	lgK:0.01(0.01SD)	2	EDH	5390
24	25	0.7	Unknown	lgK:-0.51(0.02SD)	3	EES	7391
25	25	1	LiClO ₄	lgK:-0.06(0.05SD)	5	MSL	5055
26	25	1	NaClO ₄	lgK:-0.2(0.05SD)	5	MCE	315
27	25	2	LiClO ₄	lgK:-0.018(0.05SD)	5	MSL	5055
28	25	3	LiClO ₄	lgK:0.037(0.05SD)	5	MSL	5055
29	25	3	Unknown	lgK:-0.1(0.1SD)	6	CRV	552
30	25	4	LiClO ₄	lgK:0.079(0.05SD)	5	MSL	5055
31	25	6	Unknown	lgK:-3.13(3SF)	3	EES	5398
32	26	10:40	NH ₄ ClO ₄	lgK:-0.78(2SF)	4	MRM	931
33	48	10:40	NH ₄ ClO ₄	lgK:-0.82(2SF)	4	MRM	931
34	70	10:40	NH ₄ ClO ₄	lgK:-0.82(2SF)	4	MRM	931
35	94	10:40	NH ₄ ClO ₄	lgK:-0.85(2SF)	4	MRM	931
36	18:25	0	Inf. Dilution	dH:-5.7(2SF)	0	MTD	931
37	25	0	Inf. Dilution	dH:-1.3(2SF)	4	CRV	552
38	25	1	Unknown	dH:-1.5(2SF)	3	CRV	552
39	25		Ethanol:Acetone 50:50Wgt	lgK:2.765(4SF)	4	MDG	5398
40	23	0.5	Propan-2-ol:Water 90:10Wgt Unknown	lgK:0.57(2SF)	5	MCE	931

Reaction No. 2536

2<NO3-1> + Ca+2 = Ca+2_NO3-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.65(0.09SD)	5	MSL	5055
2	25	0	Inf. Dilution	lgK:0.6(1SF)	4	CRV	32224
3	25	0	CHEMVAL4	lgK:0.50(0.01SD)	6	ENS	5156
4	25	0	UCT_Sea	lgK:0.60(0.01SD)	4	EDH	5390
5	25	0.1	UCT_Sea	lgK:-0.03(0.01SD)	2	EDH	5390
6	25	0.2	UCT_Sea	lgK:-0.15(0.01SD)	2	EDH	5390
7	25	0.3	UCT_Sea	lgK:-0.25(0.01SD)	2	EDH	5390
8	25	0.4	UCT_Sea	lgK:-0.31(0.01SD)	2	EDH	5390
9	25	0.5	LiClO4	lgK:-0.30(0.05SD)	5	MSL	5055
10	25	0.5	UCT_Sea	lgK:-0.35(0.01SD)	2	EDH	5390
11	25	0.6	UCT_Sea	lgK:-0.37(0.01SD)	2	EDH	5390
12	25	0.7	UCT_Sea	lgK:-0.38(0.01SD)	2	EDH	5390
13	25	1	LiClO4	lgK:-0.52(0.05SD)	5	MSL	5055
14	25	2	LiClO4	lgK:-0.38(0.05SD)	5	MSL	5055
15	25	3	LiClO4	lgK:-0.4(0.05SD)	5	MSL	5055
16	25	4	LiClO4	lgK:-0.35(0.05SD)	5	MSL	5055
17	23	0.5	Propan-2-ol:Water 90:10Wgt Unknown	lgK:0.85(2SF)	5	MCE	931

Reaction No. 2546							
P4O12-4 + Ca+2 = Ca+2_P4O12-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.05	NaCl	lgK:3.75(3SF)	5	MCE	2343
2	20	0.1	NaCl	lgK:3.28(3SF)	5	MCE	2343
3	20	0.15	NaCl	lgK:2.98(3SF)	5	MCE	2343
4	20	0.2	NaCl	lgK:2.90(3SF)	5	MCE	2343
5	25	0	Inf. Dilution	lgK:5.42(0.3SD)	4	MCN	386
6	25	0	Inf. Dilution	lgK:4.89(3SF)	4	MSL	389
7	25	0	Inf. Dilution	lgK:5.4(0.03SD)	4	CRV	552
8	25	0.1	Na+1 salt	lgK:3.39(3SF)	6	CRV	552
9	25	1	Me4NCl	lgK:3.1(0.05SD)	5	CMN	385

Reaction No. 2555							
P4O13-6 + Ca+2 = Ca+2_P4O13-6							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NC1	lgK:5.45(3SF)	5	MIS	385
2	25	1	Me4NC1	lgK:5.5(0.05SD)	5	MGL	388
3	30	0.1	NH4+ salt	lgK:7.11(0.05SD)	6	MIS	5262

Reaction No. 2556							
Ca+2 + H+1_P4O13-6 = Ca+2_H+1_P4O13-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NC1	lgK:3.31(3SF)	5	MIS	385
2	25	1	Me4NC1	lgK:3.5(0.2SD)	3	MGL	388

Reaction No. 2557							
Ca+2_P4O13-6 + Ca+2 = Ca+2(2)_P4O13-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NC1	lgK:3.35(3SF)	5	MIS	385
2	25	1	Me4NC1	lgK:3.(0.3SD)	3	MGL	388

Reaction No. 2560							
Ca+2_Mg+2_CO3-2(2)_(s) + Mg+2 + 6<H2O> = 2<Mg+2_CO3-2_H2O(3)_(s)> + Ca+2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-7.6(2SF)	1	ELC	

Reaction No. 2561							
Ca+2 + CO3-2 = Ca+2_CO3-2_(Calc.,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	P=25 Inf. Dilution	lgK:8.39(3SF)	5	MSL	26782
2	8	0	P=35 Inf. Dilution	lgK:8.26(3SF)	5	MSL	26782
3	23	0	P=45 Inf. Dilution	lgK:8.31(3SF)	5	MSL	26782
4	23	0	P=55 Inf. Dilution	lgK:8.32(3SF)	5	MSL	26782
5	1	0	P=95 Inf. Dilution	lgK:8.19(3SF)	5	MSL	26782
6	8	0	P=185 Inf. Dilution	lgK:8.08(3SF)	5	MSL	26782
7	23	0	P=200 Inf. Dilution	lgK:8.16(3SF)	5	MSL	26782


8	23	0	P=225 Inf. Dilution	lgK:8.17(3SF)	5	MSL	26782
9	25	0	P=250 Inf. Dilution	lgK:8.17(3SF)	5	MSL	26782
10	300		P=250	lgK:5.69(3SF)	0	MSL	5416
11	1	0	P=260 Inf. Dilution	lgK:7.98(3SF)	5	MSL	26782
12	23	0	P=300 Inf. Dilution	lgK:8.10(3SF)	5	MSL	26782
13	23	0	P=330 Inf. Dilution	lgK:8.03(3SF)	5	MSL	26782
14	8	0	P=350 Inf. Dilution	lgK:7.88(3SF)	5	MSL	26782
15	1	0	P=390 Inf. Dilution	lgK:7.86(3SF)	5	MSL	26782
16	25	0	P=400 Inf. Dilution	lgK:8.039(4SF)	3	CRV	11928
Note (16): with lgK0=8.426 & Kp/K=2.44							
17	23	0	P=405 Inf. Dilution	lgK:7.97(3SF)	5	MSL	26782
18	25	0	P=410 Inf. Dilution	lgK:8.00(3SF)	5	MSL	26782
19	23	0	P=495 Inf. Dilution	lgK:7.89(3SF)	5	MSL	26782
20	200		P=500	lgK:5.62(3SF)	0	MSL	5416
21	250		P=500	lgK:5.30(3SF)	0	MSL	5416
22	300		P=500	lgK:5.26(3SF)	0	MSL	5416
23	300		P=500	lgK:5.45(3SF)	0	MSL	5416
24	8	0	P=505 Inf. Dilution	lgK:7.76(3SF)	5	MSL	26782
25	23	0	P=510 Inf. Dilution	lgK:7.87(3SF)	5	MSL	26782
26	25	0	P=518 Inf. Dilution	lgK:7.87(3SF)	5	MSL	26782
27	1	0	P=590 Inf. Dilution	lgK:7.64(3SF)	5	MSL	26782
28	23	0	P=605 Inf. Dilution	lgK:7.76(3SF)	5	MSL	26782
29	8	0	P=640 Inf. Dilution	lgK:7.59(3SF)	5	MSL	26782
30	23	0	P=640 Inf. Dilution	lgK:7.72(3SF)	5	MSL	26782
31	1	0	P=685 Inf. Dilution	lgK:7.52(3SF)	5	MSL	26782

32	25	0	P=690 Inf. Dilution	lgK:7.68 (3SF)	5	MSL	26782
33	23	0	P=790 Inf. Dilution	lgK:7.59 (3SF)	5	MSL	26782
34	1	0	P=795 Inf. Dilution	lgK:7.41 (3SF)	5	MSL	26782
35	8	0	P=815 Inf. Dilution	lgK:7.40 (3SF)	5	MSL	26782
36	23	0	P=845 Inf. Dilution	lgK:7.55 (3SF)	5	MSL	26782
37	1	0	P=875 Inf. Dilution	lgK:7.31 (3SF)	5	MSL	26782
38	25	0	P=950 Inf. Dilution	lgK:7.45 (3SF)	5	MSL	26782
39	25	0	P=1000 Inf. Dilution	lgK:7.518 (4SF)	3	CRV	11928
Note (39): with lgK0=8.426 & Kp/K=8.10							
40	300		P=1000	lgK:5.33 (3SF)	0	MSL	5416
41	0.2	0	Inf. Dilution	lgK:8.379 (4SF)	7	MSL	6346
42	3.8	0	Inf. Dilution	lgK:8.397 (4SF)	7	MSL	6346
43	4.6	0	Inf. Dilution	lgK:8.376 (4SF)	7	MSL	6346
44	5	0	Inf. Dilution	lgK:8.378 (4SF)	7	MSL	6346
45	5	0	Inf. Dilution	lgK:8.35 (3SF)	5	CRV	6496
46	5	0	Inf. Dilution	lgK:8.37 (3SF)	3	MSL	9027
Note (46): Criticized by Sass et al, 1983 (coz ion pairing excl from analysis)							
47	10	0	Inf. Dilution	lgK:8.410 (4SF)	7	MSL	6346
48	10	0	Inf. Dilution	lgK:8.36 (3SF)	5	CRV	6496
49	14.7	0	Inf. Dilution	lgK:8.425 (4SF)	5	MSL	6346
50	15	0	Inf. Dilution	lgK:8.37 (3SF)	5	CRV	6496
51	15.1	0	Inf. Dilution	lgK:8.404 (4SF)	7	MSL	6346
52	20	0	Inf. Dilution	lgK:8.39 (3SF)	5	CRV	6496
53	22	0.15	Unknown	lgK:8.01 (3SF)	0	CSM	8
54	24.6	0	Inf. Dilution	lgK:8.489 (4SF)	4	MSL	6346
55	25	0	Inf. Dilution	lgK:8.50 (0.02SD)	3	CSM	233
56	25	0	Inf. Dilution	lgK:8.475 (4SF)	5	MSL	332
57	25	0	Inf. Dilution	lgK:8.4 (0.05SD)	0	MSL	335
58	25	0	Inf. Dilution	lgK:8.48 (3SF)	3	CRV	6232
59	25	0	Inf. Dilution	lgK:8.480 (4SF)	4	MGL	6346
60	25	0	Inf. Dilution	lgK:8.485 (4SF)	5	MSL	6346

61	25	0	Inf. Dilution	lgK:8.35 (3SF)	3	CRV	6405
62	25	0	Inf. Dilution	lgK:8.42 (3SF)	4	CRV	6496
63	25	0	Inf. Dilution	lgK:8.43 (3SF)	4	CRV	8749
64	25	0	Inf. Dilution	lgK:8.48 (3SF)	5	MSL	8910
65	25	0	Inf. Dilution	lgK:8.45 (3SF)	3	MSL	9027
Note (65): Criticized by Sass et al, 1983 (coz ion pairing excl from analysis)							
66	25	0	Inf. Dilution	lgK:8.36 (3SF)	3	CRV	9402
67	25	0	Inf. Dilution	lgK:8.31 (3SF)	3	EOD	12584
68	25	0	Inf. Dilution	lgK:8.420 (4SF)	5	CRV	22551
69	25	0	Inf. Dilution	lgK:8.48 (3SF)	4	EOD	23102
70	25	0	Inf. Dilution	lgK:8.36 (3SF)	3	CRV	28992
71	25	0	Inf. Dilution	lgK:8.475 (4SF)	3	EOD	29419
72	25	0	Inf. Dilution	lgK:8.46 (0.005SD)	4	EOD	31301
73	25	0	Inf. Dilution	lgK:8.35 (3SF)	4	CRV	32224
74	25	0	CHEMVAL1	lgK:8.35 (0.01SD)	0	ENS	5156
75	25	0	CHEMVAL2	lgK:8.35 (0.01SD)	0	ENS	5156
76	25	0	CHEMVAL3	lgK:8.35 (0.01SD)	0	ENS	5156
77	25	0	CHEMVAL4	lgK:8.31 (0.01SD)	3	ENS	5156
78	25	0	Inf. Dilution/m	lgK:8.444 (4SF)	5	MSL	21799
79	25	0	Unknown	lgK:8.4789 (5SF)	3	ENS	7373
80	25	0.7	Unknown	lgK:6.3 (0.03SD)	0	CSM	233
81	25			lgK:7.12 (3SF)	0	MSL	5416
82	25.5	0	Inf. Dilution	lgK:8.489 (4SF)	4	MSL	6346
83	30	0	Inf. Dilution	lgK:7.77 (3SF)	0	MCE	8375
84	35	0	Inf. Dilution	lgK:8.553 (4SF)	5	MSL	6346
85	35	0	Inf. Dilution	lgK:8.50 (3SF)	4	CRV	8749
86	37.8	0	Inf. Dilution	lgK:8.558 (4SF)	7	MSL	6346
87	38	0	Inf. Dilution	lgK:8.559 (4SF)	7	MSL	6346
88	40	0	Inf. Dilution	lgK:8.53 (3SF)	5	CRV	6496
89	45	0	Inf. Dilution	lgK:8.628 (4SF)	7	MSL	6346
90	50	0	Inf. Dilution	lgK:8.63 (3SF)	4	CRV	8749
91	50	0	Inf. Dilution	lgK:8.65 (3SF)	3	CRV	28992
92	51.1	0	Inf. Dilution	lgK:8.663 (4SF)	7	MSL	6346
93	51.6	0	Inf. Dilution	lgK:8.664 (4SF)	7	MSL	6346
94	54.5	0	Inf. Dilution	lgK:8.706 (4SF)	7	MSL	6346
95	54.8	0	Inf. Dilution	lgK:8.699 (4SF)	7	MSL	6346


96	55	0	Inf. Dilution	lgK:8.704 (4SF)	7	MSL	6346
97	55.2	0	Inf. Dilution	lgK:8.688 (4SF)	7	MSL	6346
98	57.6	0	Inf. Dilution	lgK:8.731 (4SF)	7	MSL	6346
99	64.6	0	Inf. Dilution	lgK:8.779 (4SF)	7	MSL	6346
100	65	0	Inf. Dilution	lgK:8.803 (4SF)	7	MSL	6346
101	72.4	0	Inf. Dilution	lgK:8.876 (4SF)	7	MSL	6346
102	73	0	Inf. Dilution	lgK:8.931 (4SF)	7	MSL	6346
103	74.9	0	Inf. Dilution	lgK:8.914 (4SF)	7	MSL	6346
104	75.2	0	Inf. Dilution	lgK:8.906 (4SF)	7	MSL	6346
105	75.4	0	Inf. Dilution	lgK:8.922 (4SF)	7	MSL	6346
106	80.1	0	Inf. Dilution	lgK:8.995 (4SF)	7	MSL	6346
107	81	0	Inf. Dilution	lgK:9.000 (4SF)	7	MSL	6346
108	81.7	0	Inf. Dilution	lgK:9.002 (4SF)	7	MSL	6346
109	82	0	Inf. Dilution	lgK:9.018 (4SF)	7	MSL	6346
110	88.5	0	Inf. Dilution	lgK:9.104 (4SF)	7	MSL	6346
111	89.7	0	Inf. Dilution	lgK:9.138 (4SF)	7	MSL	6346
112	100	0	Inf. Dilution	lgK:9.33 (3SF)	3	CRV	28992
113	150	0	Inf. Dilution	lgK:10.28 (4SF)	2	CRV	28992
114	150	1	NaCl	lgK:7.79 (3SF)	3	EOD	5072
115	200	0	Inf. Dilution	lgK:11.37 (4SF)	2	CRV	28992
116	200	1	NaCl	lgK:8.12 (3SF)	5	EOD	5072
117	250	0	Inf. Dilution	lgK:12.60 (4SF)	2	CRV	28992
118	0:90	0	Inf. Dilution	dH:2.0 (2SF)	0	CRV	552
119	25	0	Inf. Dilution	dH:2.3 (0.1SD)	4	ENS	5484
120	25	0	Inf. Dilution	dH:2.297 (4SF)	4	ENS	6496
121	25	0	Inf. Dilution	dH:3.15 (3SF)	1	CRV	9402
122	25	0	Inf. Dilution	Cp:107.70 (5SF)	4	CRV	9402

Reaction No. 2835



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.54 (3SF)	4	CRV	2556

Reaction No. 3106



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	20	0.1	KNO3	lgK:8.56(0.02SD)	6	MGL	2037
2	20	0.1	KNO3	lgK:8.4(2SF)	3	CRV	13242
3	25	0.1	KNO3	lgK:8.53(3SF)	6	MGL	999
4	30	0.1	Unknown	lgK:8.34(3SF)	4	ENS	773

Reaction No. 3107							
TTHA-6 + Ca+2 = Ca+2_TTHA-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:10.5(0.05SD)	3	MGL	2037
2	20	0.1	KNO3	lgK:10.5(0.1SD)	3	CRV	13242
3	25	0.1	KNO3	lgK:9.89(3SF)	0	MGL	999
4	30	0.1	KCl	lgK:10.06(4SF)	2	MGL	999

Reaction No. 3109							
Ca+2 + HOEDTA-3 + H+1 = Ca+2_H+1_HOEDTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.2(3SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:11.(2SF)	3	ENS	94

Reaction No. 3110							
HOEDTA-3 + Ca+2 = Ca+2_HOEDTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:8.56(3SF)	6	MGL	2121
2	20	0.1	KCl	lgK:8.14(3SF)	6	MGL	999
3	20	0.1	KNO3	lgK:8.51(3SF)	6	MGL	2121
4	20	0.1	NaClO4	lgK:8.55(3SF)	5	MMC	2038
5	25	0.1	KNO3	lgK:8.43(3SF)	6	MGL	2121
6	25	0.1	Unknown	lgK:8.2(0.1SD)	6	CRV	552
7	29.6	0.1	KCl	lgK:8.0(2SF)	4	MGL	999
8	30	0.1	KNO3	lgK:8.35(3SF)	6	MGL	2121
9	30	0.1	NaClO4	lgK:7.88(3SF)	5	MGL	11516
Note (9): Mathur R et al., Indian J. Chem., 1981, 20A, 309							
10	35	0.1	KNO3	lgK:8.30(3SF)	6	MGL	2121
11	37	0.15	Blood Plasma	lgK:8.0(2SF)	4	ENS	94
12	40	0.1	KNO3	lgK:8.24(3SF)	6	MGL	2121
13	25	0.1	KNO3	dH:-6.5(2SF)	5	MCL	139
14	25	0.1	KNO3	dH:-5.54(3SF)	6	MCL	2121

Reaction No. 3391							
Ferron-2 + Ca+2 = Ca+2_Ferron-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.07(3SF)	6	MGL	999
2	25	0.1	Unknown	lgK:2.36(3SF)	6	ENS	773
3	25	1	Unknown	lgK:2.01(3SF)	6	ENS	773
4	28	0.1	KNO3	lgK:2.60(3SF)	6	MGL	999

Reaction No. 3392							
2<Ferron-2> + Ca+2 = Ca+2_Ferron-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.0(2SF)	4	MGL	999

Reaction No. 3427							
Oxine-1 + Ca+2 = Ca+2_Oxine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:3.27(3SF)	6	MGL	999
2	20	0.1	Unknown	lgK:2.82(3SF)	6	ENS	773
3	20	1	Unknown	lgK:2.44(3SF)	6	ENS	773
4	25		Acetone	lgK:2.17(0.02SD)	4	MFL	2469
5	25	0.1	Dioxan:Water 60:40Vol NaClO4	lgK:4.40(3SF)	5	MGL	3082
6	25	0.05	Ethanol:Water 95:5Wgt Et4NC1O4	lgK:2.1(0.04SD)	4	MPS	2713
7	25		MeCN	lgK:3.4(0.05SD)	4	MFL	2469
8	25		Methanol	lgK:1.8(0.07SD)	4	MFL	2469

Reaction No. 3460							
Sulfox-2 + Ca+2 = Ca+2_Sulfox-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.52(3SF)	6	MSP	999
2	25	0	Unknown	lgK:3.52(3SF)	6	ENS	773
3	25	0.1	Unknown	lgK:2.66(3SF)	6	ENS	773
4	25	0.1	Dioxan:Water 60:40Wgt NaClO4	lgK:4.53(3SF)	4	MGL	3082

Reaction No. 3559							
Ca+2 + Phenanth = Ca+2_Phenanth							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:1.12(0.05MD)	4	MGL	7090
2	10	0.25	Inert	lgK:1.21(3SF)	6	MGL	1520
3	10	0.5	KCl	lgK:1.21(0.05MD)	5	MGL	7090
4	20	0.1	NaNO3	lgK:0.7(1SF)	4	MGL	999
5	20	0.25	Inert	lgK:0.7(1SF)	4	MGL	1520
6	25	0	Inf. Dilution	lgK:1.03(0.04MD)	4	MGL	7090
7	25	0.1	NaClO4	lgK:1.11(0.02SD)	6	MGL	2961
8	25	0.25	Inert	lgK:1.09(3SF)	6	MGL	1520
9	25	0.5	KCl	lgK:1.00(0.05MD)	5	MGL	7090
10	40	0	Inf. Dilution	lgK:0.95(0.04MD)	4	MGL	7090
11	40	0.25	Inert	lgK:0.97(2SF)	6	MGL	1520
12	40	0.5	KCl	lgK:0.98(0.05MD)	5	MGL	7090
13	25	0.25	Inert	dH:-3.3(2SF)	5	MCL	1520
14	25		Acetone	lgK:3.9(0.06SD)	4	MFL	2469
15	25	0.05	Ethanol:Water 95:5Wgt Et4NC1O4	lgK:2.7(0.04SD)	4	MPS	2713
16	25		MeCN	lgK:4.(1.SD)	4	MFL	2469
17	25		Methanol	lgK:2.1(0.03SD)	4	MFL	2469


Reaction No. 3701							
Ca+2 + H+1_Oxalic-2 = Ca+2_H+1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.5(2SF)	1	EOR	
2	25	0.1	HClO4	lgK:1.38(3SF)	6	MIX	999
3	100	0	Inf. Dilution	lgK:1.3(2SF)	1	EOR	

Reaction No. 3702							
Ca+2 + 2<H+1_Oxalic-2> = Ca+2_H+1(2)_Oxalic-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	HClO4	lgK:1.85(3SF)	6	MIX	999
2	25	0.1	Unknown	lgK:1.8(2SF)	4	ENS	773

Reaction No. 3947							
4<Ca+2> + 4<Ascorbic-2> + OH-1 = Ca+2(4)_OH-1_Ascorbic-2(4)							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	Unknown	lgK:14.7(3SF)	4	ENS	773

Reaction No. 3948




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.10(4SF)	1	ELC	
2	25	3	Unknown	lgK:12.1(3SF)	0	ENS	773

Reaction No. 3949




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Unknown	lgK:0.03(1SF)	4	ENS	773
2	25	3	NaClO4	lgK:0.03(0.03SD)	6	MGL	3492

Reaction No. 3950



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Unknown	lgK:1.4(2SF)	4	MGL	773
2	25	0.16	Unknown	lgK:0.19(2SF)	3	MIX	3478

Reaction No. 4057




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.45(3SF)	4	MCN	999
2	25	0	Inf. Dilution	lgK:1.46(3SF)	5	MSL	7703
3	25	0	Inf. Dilution	lgK:1.29(3SF)	5	MKN	11516

Note (3): Bell R et al., J. Chem. Soc., 1951, 2357


4	30	0	Inf. Dilution	lgK:1.58(3SF)	5	MSL	7703
5	35	0	Inf. Dilution	lgK:1.62(3SF)	5	MSL	7703
6	40	0	Inf. Dilution	lgK:1.75(3SF)	5	MSL	7703
7	45	0	Inf. Dilution	lgK:1.83(3SF)	5	MSL	7703
8	25	0	Inf. Dilution	dG:-8.36(0.06SD)kJ	4	MSL	3094
9	25	0	Inf. Dilution	dH:32.05(0.01SD)kJ	4	MTD	3094

Reaction No. 4073




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:2.04(3SF)	0	MGL	2261
2	25	0	Inf. Dilution	lgK:1.24(3SF)	2	MSL	140

Reaction No. 4109




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:3.51(3SF)	2	MHY	2699
2	20	0.1	KCl	lgK:3.75(3SF)	6	MGL	3486
3	20	0.1	KCl	lgK:3.8(0.1SD)	5	CRV	13242
4	20	0.1	KNO3	lgK:3.75(3SF)	6	MGL	2040
5	20	0.1	Unknown	lgK:3.81(3SF)	5	ENS	773
6	25	0	Inf. Dilution	lgK:4.45(3SF)	4	CRV	552
7	25	0.1	KCl	lgK:3.85(3SF)	3	MGL	999
8	25	0.1	NaClO4	lgK:3.88(3SF)	3	MPL	999
9	25	0.1	NaClO4	lgK:3.9(0.1SD)	3	CRV	13242
10	25	0.1	Unknown	lgK:3.8(0.03SD)	6	CRV	552
11	25	0.1	Unknown	lgK:3.79(3SF)	5	ENS	773
12	20	0.1	KNO3	dG:-5.03(3SF)	6	MGL	2040
13	20	0.1	KNO3	dH:-1.64(3SF)	6	MCL	2040
14	25	0.1	KCl	dH:-1.2(0.1SD)	5	MCL	3215
15	25	0.1	Unknown	dH:-1.4(2SF)	6	CRV	552
16	20	0.1	KNO3	dS:11.58(4SF)	6	EFE	2040

Reaction No. 4110



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:6.60(3SF)	5	ENS	773
2	25	0	Inf. Dilution	lgK:7.36(3SF)	4	CRV	552
3	25	0.1	Unknown	lgK:6.57(3SF)	6	CRV	552


Reaction No. 4260



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:6.10(0.05SD)	5	CRV	13242
2	20	0.1	Unknown	lgK:6.11(3SF)	6	ENS	773
3	25	0.1	KNO3	lgK:6.11(3SF)	6	MGL	189


4	25	0.1	KNO3	lgK:6.10 (3SF)	5	CRV	13242
5	37	0.15	NaCl	lgK:6.00 (0.05SD)	5	CRV	13242

Reaction No. 4313




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.8 (2SF)	4	MGL	1957
2	20	0.1	Unknown	lgK:3.79 (3SF)	6	ENS	773
3	25	0	Inf. Dilution	lgK:3.9 (2SF)	1	ESC	

Reaction No. 4356




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.8 (0.05SD)	4	MGL	2037
2	20	0.1	KNO3	lgK:4.8 (0.1SD)	5	CRV	13242
3	25	0.1	KNO3	lgK:4.87 (3SF)	6	MGL	999

Reaction No. 4357




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.3 (0.1SD)	4	MGL	2037
2	20	0.1	KNO3	lgK:4.2 (0.1SD)	5	CRV	13242
3	25	0.1	KNO3	lgK:4.32 (3SF)	6	MGL	999
4	30	0.1	KCl	lgK:4.10 (3SF)	2	MGL	999

Reaction No. 4358



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.01 (3SF)	6	MGL	999
2	25	0.1	Unknown	lgK:4.0 (2SF)	4	ENS	773

Reaction No. 4596



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:2.5 (2SF)	4	ENS	773
2	20:23	0.1	KCl	lgK:2.5 (2SF)	4	MHY	999

Reaction No. 4663							
SalAld-1 + Ca+2 = Ca+2_SalAld-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:1.1 (0.1SD)	3	MSP	999

Reaction No. 4744							
Ca+2 + 2<e-1> = Ca(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-96.99 (4SF)	4	CRV	32224
2	25	1	Unknown	lgK:-99.5 (3SF)	1	EOR	
3	25	0	Inf. Dilution	dG:132.3 (0.05SD)	3	ENS	3006
4	25	0	Inf. Dilution	dG:132.12 (5SF)	4	CRV	6488
5	25	0	Inf. Dilution	dG:553.6 (4SF) kJ	2	CRV	6494
Note (5): Sign changed							
6	25	0	Inf. Dilution	dG:553.58 (5SF) kJ	3	EFE	7275
7	25	0	Inf. Dilution	dG:553.6 (4SF) kJ	2	CRV	7421
8	25	0	Inf. Dilution	dG:552.8 (4SF) kJ	5	CRV	8739
9	25	0	Inf. Dilution	dG:552.8 (4SF) kJ	6	CRV	8746
10	25	0	Inf. Dilution	dG:552.790 (6SF) kJ	6	CRV	8798
11	25	0	Inf. Dilution	dG:132.160 (6SF)	4	CRV	8875
12	25	0	Inf. Dilution	dG:132.120 (6SF)	4	CRV	9029
13	25	0	Inf. Dilution	dG:132.12 (5SF)	4	CRV	10174
14	25	0	Inf. Dilution	dG:552.790 (6SF) kJ	3	EOD	12843
15	25	0	Inf. Dilution	dG:552.81 (1.050SD) kJ	6	CRV	14923
16	25	0	Inf. Dilution	dG:552.79 (5SF) kJ	3	EOD	23101
17	25	0	Inf. Dilution	dG:552.79 (5SF) kJ	4	CRV	23205
18	25	0	Inf. Dilution	dG:552.790 (6SF) kJ	3	EOD	23205
19	25	0	Inf. Dilution	dG:553.58 (5SF) kJ	2	CRV	28172
20	25	0	Inf. Dilution	dG:553.6 (4SF) kJ	2	EOD	29025
21	25	0	Inf. Dilution	dG:552.81 (5SF) kJ	5	EOD	29520
22	25	0	Inf. Dilution	dG:554.17 (5SF) kJ	2	CRV	29556
23	25	0	Inf. Dilution	dG:132.12 (5SF)	4	EFE	32152
24	25	0	Inf. Dilution/m	dG:553.55 (5SF) kJ	3	EPZ	8833
25	50	0	Inf. Dilution	dG:131.78 (5SF)	0	CRV	10174
26	75	0	Inf. Dilution	dG:131.42 (5SF)	0	CRV	10174
27	100	0	Inf. Dilution	dG:131.05 (5SF)	0	CRV	10174

28	125	0	Inf. Dilution	dG:130.66(5SF)	1	CRV	10174
29	150	0	Inf. Dilution	dG:130.26(5SF)	3	CRV	10174
30	175	0	Inf. Dilution	dG:129.83(5SF)	1	CRV	10174
31	200	0	Inf. Dilution	dG:129.37(5SF)	0	CRV	10174
32	225	0	Inf. Dilution	dG:128.88(5SF)	0	CRV	10174
33	250	0	Inf. Dilution	dG:128.34(5SF)	0	CRV	10174
34	300	0	Inf. Dilution	dG:127.07(5SF)	0	CRV	10174
35	23	0	Inf. Dilution	E:-2.87(3SF)	0	ENS	7276
36	25	0	Inf. Dilution	E:-2.9(0.1SD)	0	MDG	775
37	25	0	Inf. Dilution	E:-2.868(4SF)	3	CRV	6330
38	25	0	Inf. Dilution	E:-2.87(3SF)	0	MEF	7273
39	25	0	Inf. Dilution	E:-2.87(3SF)	0	CRV	7372
40	25	0	Inf. Dilution	E:-2.868(4SF)	2	ENS	7381
41	25	0	Inf. Dilution	E:-2.868(4SF)	3	CRV	7761
42	25	0	Inf. Dilution	E:-2.868(4SF)	3	CRV	22519
43	25	0	Inf. Dilution	E:-2.84(0.01SD)	0	CRV	22551
44	25	0	Inf. Dilution	dH:129.8(0.2SD)	7	CRV	5605
45	25	0	Inf. Dilution	dH:129.8(4SF)	4	CRV	6488
46	25	0	Inf. Dilution	dH:542.83(5SF)kJ	5	EFE	7275
47	25	0	Inf. Dilution	dH:542.7(4SF)kJ	5	CRV	7761
48	25	0	Inf. Dilution	dH:543.0(4SF)kJ	5	CRV	8739
49	25	0	Inf. Dilution	dH:543.0(4SF)kJ	5	CRV	8739
50	25	0	Inf. Dilution	dH:543.0(1.MD)kJ	6	CRV	8746
51	25	0	Inf. Dilution	dH:543.080(6SF)kJ	6	CRV	8798
52	25	0	Inf. Dilution	dH:129.800(6SF)	4	CRV	8875
53	25	0	Inf. Dilution	dH:129.800(6SF)	4	CRV	9029
54	25	0	Inf. Dilution	dH:543.080(6SF)kJ	3	EOD	12843
55	25	0	Inf. Dilution	dH:543.00(1.000SD)kJ	6	CRV	14923
56	25	0	Inf. Dilution	dH:543.07(5SF)kJ	3	EOD	23101
57	25	0	Inf. Dilution	dH:542.83(5SF)kJ	5	CRV	28172
58	25	0	Inf. Dilution	dH:542.8(4SF)kJ	4	EOD	29025
59	25	0	Inf. Dilution	dH:543.0(4SF)kJ	5	EOD	29520
60	25	0	Inf. Dilution	dH:542.8(4SF)kJ	4	EFE	32152
61	25	0	GAMSPATH	dH:542.810(6SF)kJ	3	CRV	12638
62	25	0	Inf. Dilution	Cp:31.5(3SF)J/K	4	EOD	29025

Reaction No. 4915							
IDA-2 + Ca+2 = Ca+2_IDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:3.41 (3SF)	4	MHY	2699
2	20	0.1	KCl	lgK:2.59 (3SF)	6	MHY	999
3	20	0.1	KNO3	lgK:2.59 (3SF)	6	MGL	1956
4	20	0.1	KNO3	lgK:2.59 (0.05SD)	5	CRV	13242
5	20	0.1	NaNO3	lgK:2.59 (3SF)	6	MGL	1506
6	23	0.1	NH4Cl	lgK:4.0 (2SF)	0	MCG	906
7	25	0	Inf. Dilution	lgK:3.47 (3SF)	5	ENS	1384
8	25	0	Inf. Dilution	lgK:3.50 (3SF)	4	MGL	6131
9	25	0.1	Inf. Dilution	lgK:3.4 (0.05SD)	3	CRV	552
10	25	0.1	Unknown	lgK:2.59 (3SF)	6	ENS	773
11	25	1	KNO3	lgK:2.09 (3SF)	6	MGL	999
12	30	0.1	KCl	lgK:2.7 (2SF)	3	MGL	4250
13	30	0.1	Unknown	lgK:2.7 (2SF)	4	MGL	999
14	20	0.1	KNO3	dH:0.3 (1SF)	5	MCL	1956
15	20	0.1	NaNO3	dH:0.3 (1SF)	5	MCL	1506
16	25	0	Inf. Dilution	dH:1.5 (2SF) kJ	4	MCL	6131
17	25	0.1	Unknown	dH:0.6 (1SF)	6	CRV	552


Reaction No. 4952							
AcHydroxam-1 + Ca+2 = Ca+2_AcHydroxam-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:2.4 (2SF)	5	MGL	3676

Reaction No. 5072							
Ca+2_NH3(2) + NH3 = Ca+2_NH3(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.5 (0.05SD)	3	MDS	5084
2	23	2	NH4NO3	lgR:-0.8 (0.05SD)	5	MDS	5084
3	25	0.5	NH4ClO4	lgR:-0.6 (0.05SD)	5	MDS	5084
4	25	1	NH4ClO4	lgR:-0.7 (0.05SD)	5	MDS	5084
5	25	1.5	NH4ClO4	lgR:-0.8 (0.05SD)	8	MDS	5084

Reaction No. 5073							
Ca+2_NH3 + NH3 = Ca+2_NH3(2)							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.3(0.05SD)	5	MDS	5084
2	23	2	NH4NO3	lgR:-0.6(0.05SD)	5	MDS	5084
3	25	0.5	NH4ClO4	lgR:-0.3(0.05SD)	5	MDS	5084
4	25	1	NH4ClO4	lgR:-0.4(0.05SD)	5	MDS	5084
5	25	1.5	NH4ClO4	lgR:-0.5(0.05SD)	5	MDS	5084

Reaction No. 5421




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.9(0.05SD)	3	ENS	94

Reaction No. 5427




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.52(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.8(0.05SD)	4	ENS	94

Reaction No. 5428



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:10.51(0.08MD)	4	MGL	6123
2	25	0	Inf. Dilution	lgK:10.21(0.06MD)	4	MGL	6123
3	37	0.15	Blood Plasma	lgK:10.1(0.05SD)	3	ENS	94
4	40	0	Inf. Dilution	lgK:9.84(0.06MD)	4	MGL	6123
5	50	0	Inf. Dilution	lgK:9.69(0.07MD)	4	MGL	6123
6	25	0	Inf. Dilution	dH:-36.(2SF)kJ	4	MCL	6131


Reaction No. 5429



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:1.23(0.05MD)	4	MPT	6123
2	25	0	Inf. Dilution	lgK:1.3(0.06SD)	4	CRV	552
3	25	0	Inf. Dilution	lgK:1.24(3SF)	6	MGL	2057
4	25	0	Inf. Dilution	lgK:1.36(0.05MD)	4	MPT	6123
5	25	0	Inf. Dilution	lgK:1.36(3SF)	4	MPH	6131


6	25	0	UCT_Sea	lgK:1.24 (0.01SD)	4	EDH	5390
7	25	0.1	UCT_Sea	lgK:0.85 (0.01SD)	4	EDH	5390
8	25	0.2	UCT_Sea	lgK:0.78 (0.01SD)	4	EDH	5390
9	25	0.3	UCT_Sea	lgK:0.73 (0.01SD)	4	EDH	5390
10	25	0.4	UCT_Sea	lgK:0.71 (0.01SD)	4	EDH	5390
11	25	0.5	UCT_Sea	lgK:0.69 (0.01SD)	4	EDH	5390
12	25	0.6	UCT_Sea	lgK:0.68 (0.01SD)	4	EDH	5390
13	25	0.7	UCT_Sea	lgK:0.67 (0.01SD)	4	EDH	5390
14	37	0.15	Blood Plasma	lgK:1.2 (0.05SD)	3	ENS	94
15	37	0.15	NaCl	lgK:1.31 (0.01SD)	6	MGL	937
16	40	0	Inf. Dilution	lgK:1.41 (0.05MD)	4	MPT	6123
17	50	0	Inf. Dilution	lgK:1.54 (0.05MD)	4	MPT	6123
18	25	0	Inf. Dilution	dH:1. (1SF)	3	CRV	552
19	25	0	Inf. Dilution	dH:12. (1.MD) kJ	4	MTD	6123
20	25	0	Inf. Dilution	dH:12. (2SF) kJ	4	MCL	6131

Reaction No. 5458




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.8 (0.05SD)	3	ENS	94

Reaction No. 5460



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.42 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.7 (0.05SD)	3	ENS	94

Reaction No. 5462



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0.5	Many Media	lgK:10.43 (0.04SD)	6	CMN	6128
2	10	0.25	Unknown	lgK:10.2 (0.09SD)	5	MGL	1045
3	15	0.5	Many Media	lgK:10.22 (0.03SD)	6	CMN	6128
4	25	0	Inf. Dilution	lgK:9.99 (3SF)	3	MGL	1045
5	25	0	Inf. Dilution	lgK:10.15 (4SF)	4	MPH	6131
6	25	0.25	Unknown	lgK:9.9 (0.06SD)	3	MGL	1045

7	25	0.5	Many Media	lgK:10.06(0.02SD)	6	CMN	6128
8	25	0.5	Unknown	lgK:10.07(0.05SD)	5	MPT	6128
9	35	0.5	Many Media	lgK:9.93(0.03SD)	6	CMN	6128
10	37	0.15	Blood Plasma	lgK:10.1(0.05SD)	3	ENS	94
11	37	0.15	NaCl	lgK:10.22(0.18SD)	3	MGL	28777
12	37	0.15	NaCl	lgK:9.99(0.11SD)	4	MIS	28777
13	37	0.25	Unknown	lgK:9.7(0.07SD)	3	MGL	1045
14	45	0.5	Many Media	lgK:9.83(0.04SD)	6	CMN	6128
15	25	0	Inf. Dilution	dH:-31.(2SF)kJ	3	MCL	1045
16	25	0	Inf. Dilution	dH:-26.(2SF)kJ	4	MCL	6131

Reaction No. 5804

Cys-2 + Ca+2 + Citric-3 = Ca+2_Cys-2_Citric-3

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.0(2SF)	1	EES	
2	25	0.1	NaClO4	lgK:5.58(3SF)	2	CRV	905
3	25	0.1	NaClO4	lgK:5.58(3SF)	2	MGL	3180

Reaction No. 5805

Cys-2 + Ca+2 + NTA-3 = Ca+2_Cys-2_NTA-3

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.0(2SF)	1	EES	
2	25	0.1	NaClO4	lgK:8.44(3SF)	2	CRV	905
3	25	0.1	NaClO4	lgK:8.44(3SF)	2	MGL	3180

Reaction No. 6244

Formic-1 + Ca+2 = Ca+2_Formic-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.43(0.01SD)	4	MGL	906
2	25	0	Inf. Dilution	lgK:0.80(2SF)	5	MSL	7730
3	25	0.03	NaCl	lgK:0.75(2SF)	5	MIS	11516

Note (3): Emara M et al., Electrochim. Acta, 1981, 26, 1705

4	25	2	NaClO4	lgK:0.48(2SF)	5	MVM	8310
5	30	0.4	NaNO3	lgK:0.3(0.03SD)	4	MGL	382
6	35	0	Inf. Dilution	lgK:1.46(0.01SD)	4	MGL	906
7	25:35	0	Inf. Dilution	dH:0.98(2SF)	4	MGL	906

Reaction No. 6260							
bAla-1 + Ca+2 = Ca+2_bAla-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.7(2SF)	1	EAE	
2	25	0	UCT_Sea	lgK:2.18(0.01SD)	4	EDH	5390
3	25	0.1	UCT_Sea	lgK:1.79(0.01SD)	4	EDH	5390
4	25	0.2	UCT_Sea	lgK:1.71(0.01SD)	4	EDH	5390
5	25	0.3	UCT_Sea	lgK:1.67(0.01SD)	4	EDH	5390
6	25	0.4	UCT_Sea	lgK:1.64(0.01SD)	4	EDH	5390
7	25	0.5	UCT_Sea	lgK:1.62(0.01SD)	4	EDH	5390
8	25	0.6	UCT_Sea	lgK:1.61(0.01SD)	4	EDH	5390
9	25	0.7	UCT_Sea	lgK:1.60(0.01SD)	4	EDH	5390
10	37	0.15	NaCl	lgK:1.64(0.009SD)	6	MGL	937

Reaction No. 6474							
Ca+2 + COOGlu-3 = Ca+2_COOGlu-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaCl	lgK:0.64(2SF)	6	MGL	957


Reaction No. 6475							
Ca+2 + H+1_COOGlu-3 = Ca+2_H+1_COOGlu-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaCl	lgK:0.60(2SF)	6	MGL	957

Reaction No. 6486							
5ATP-4 + Ca+2 = Ca+2_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:4.10(0.02SD)	2	MGL	3482
2	1	0.15	NaCl	lgK:2.65(3SF)	0	MIX	1437
3	10	0	Inf. Dilution	lgK:5.5(2SF)	3	MGL	6175
4	10	0.04	Pr4N+ salt	lgK:4.4(2SF)	4	MGL	6175
5	10	0.16	Pr4N+ salt	lgK:4.0(2SF)	4	MGL	6175
6	10	0.25	Pr4N+ salt	lgK:3.91(3SF)	4	MGL	6175
7	10	0.49	Pr4N+ salt	lgK:3.9(2SF)	4	MGL	6175
8	10	1	Pr4N+ salt	lgK:3.9(2SF)	2	MGL	6175
9	12	0.1	KNO3	lgK:3.99(0.02SD)	2	MGL	3482
10	20	0.1	KCl	lgK:3.60(3SF)	2	MGL	280

11	20	0.24	KCl	lgK:2.60 (3SF)	0	MIS	1437
12	22	0.25	KNO3	lgK:3.4 (2SF)	2	MGL	1437
13	23	0.09	Me4NC1	lgK:3.89 (3SF)	4	MSC	1437
14	23	0.1	NaCl	lgK:3.77 (3SF)	3	MIX	1437
15	23	0.1	NaCl	lgK:3.77 (3SF)	4	MIX	31154
16	23	0.1	Unknown	lgK:3.14 (3SF)	2	MIX	999
17	23	0.15	Na+1 salt	lgK:3.14 (3SF)	0	MIX	1437
18	23	0.15	NaCl	lgK:2.87 (3SF)	0	MIX	1437
19	23	0.25	NaCl	lgK:3.35 (3SF)	0	MIX	1437
20	25	0	Inf. Dilution	lgK:6.6 (0.04SD)	0	MIS	1266
21	25	0	Inf. Dilution	lgK:6.37 (3SF)	3	MIS	1437
22	25	0	Inf. Dilution	lgK:5.26 (3SF)	3	MGL	6175
23	25	0.015	Unknown	lgK:4. (0.4SD)	4	MSP	999
24	25	0.04	Pr4N+ salt	lgK:4.16 (3SF)	4	MGL	6175
25	25	0.1	Et4NBr	lgK:3.9 (0.03SD)	4	MSP	999
26	25	0.1	Et4NC1	lgK:3.92 (3SF)	4	MGL	1437
27	25	0.1	Et4NC1	lgK:3.96 (3SF)	4	MGL	1437
28	25	0.1	Et4NC1	lgK:3.97 (3SF)	4	MIX	1437
29	25	0.1	KCl	lgK:3.73 (3SF)	3	MIX	999
30	25	0.1	KNO3	lgK:3.74 (3SF)	4	MGL	1437
31	25	0.1	KNO3	lgK:3.97 (0.02SD)	5	MGL	3482
32	25	0.1	Me4N+ salt	lgK:4.2 (0.07SD)	5	CIU	1437
33	25	0.1	Na+1 salt	lgK:3.90 (3SF)	4	MSP	1437
34	25	0.1	NaCl	lgK:3.9 (0.08SD)	4	MSP	999
35	25	0.1	NaCl	lgK:3.60 (3SF)	2	MSP	1437
36	25	0.1	NaClO4	lgK:4.0 (0.05SD)	5	MGL	1297
37	25	0.1	NaClO4	lgK:3.91 (0.01SD)	4	MGL	1369
38	25	0.1	NaClO4	lgK:3.70 (3SF)	2	MGL	1483
39	25	0.1	NaClO4	lgK:3.88 (0.02SD)	6	MGL	2961
40	25	0.1	Unknown	lgK:3.45 (3SF)	3	MSP	999
41	25	0.11	Bu3EtNBr	lgK:4.447 (4SF)	3	MSP	2060
42	25	0.12	NaCl	lgK:3.7 (2SF)	4	MGL	1437
43	25	0.16	Pr4N+ salt	lgK:3.75 (3SF)	4	MGL	6175
44	25	0.2	Me4NC1	lgK:3.09 (3SF)	0	MGL	1437
45	25	0.2	Pr4NC1	lgK:3.294 (4SF)	2	MGL	257
46	25	0.25	Pr4N+ salt	lgK:3.70 (0.06SD)	5	MGL	3595

47	25	0.49	Pr4N+ salt	lgK:3.77 (3SF)	4	MGL	6175
48	25	0.5	Inert	lgK:4.1 (0.07SD)	4	CMN	1437
49	25	0.5	Na+1 salt	lgK:4.10 (3SF)	4	MGL	956
50	25	0.5	NaNO3	lgK:4.1 (0.03SD)	4	MGL	956
51	25	1	Pr4N+ salt	lgK:4.02 (3SF)	2	MGL	6175
52	30	0.02	NEtMorph buffer	lgK:4.49 (3SF)	4	MSP	1437
53	30	0.1	Et4NBr	lgK:4.34 (3SF)	2	MGL	999
54	30	0.1	Et4NCl	lgK:4.51 (3SF)	0	MGL	1437
55	35	0	Inf. Dilution	lgK:5.25 (3SF)	3	MGL	6175
56	35	0.04	Pr4N+ salt	lgK:4.16 (3SF)	4	MGL	6175
57	35	0.1	KNO3	lgK:3.91 (3SF)	4	MGL	1437
58	35	0.16	Pr4N+ salt	lgK:3.76 (3SF)	4	MGL	6175
59	35	0.25	Pr4N+ salt	lgK:3.72 (3SF)	4	MGL	6175
60	35	0.49	Pr4N+ salt	lgK:3.84 (3SF)	4	MGL	6175
61	35	1	Pr4N+ salt	lgK:4.24 (3SF)	3	MGL	6175
62	37	0.1	Unknown	lgK:4.06 (3SF)	3	MIX	1437
63	37	0.15	Na+1 salt	lgK:4.0 (0.07SD)	4	CIU	1437
64	40	0.1	KNO3	lgK:3.94 (0.02SD)	5	MGL	3482
65	43	0.15	NaCl	lgK:3.12 (3SF)	0	MIX	1437
66	45	0	Inf. Dilution	lgK:5.38 (3SF)	3	MGL	6175
67	45	0.04	Pr4N+ salt	lgK:4.29 (3SF)	4	MGL	6175
68	45	0.16	Pr4N+ salt	lgK:3.90 (3SF)	4	MGL	6175
69	45	0.25	Pr4N+ salt	lgK:3.87 (3SF)	4	MGL	6175
70	45	0.49	Pr4N+ salt	lgK:4.03 (3SF)	4	MGL	6175
71	45	1	Pr4N+ salt	lgK:4.6 (2SF)	4	MGL	6175
72	10:45	0.25	Pr4N+ salt	dH:-8. (4.SD) kJ	0	MTD	3595
73	25	0.1	Inert	dH:14.2 (0.8SD) kJ	5	CIU	1437
74	25	0.1	KNO3	dH:-0.9 (0.3SD)	0	MCL	3482
75	25	0.1	NaClO4	dH:13.45 (0.10SD) kJ	6	MCL	1483


Reaction No. 6487



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.7 (3SF)	1	ELC	
2	25	0.1	NaClO4	lgK:8.94 (0.02SD)	0	MGL	1297
3	25	0.1	NaClO4	lgK:8.55 (3SF)	0	MGL	1483


4	25	0.25	Pr4N+ salt	lgK:8.37(0.09SD)	0	MGL	3595
5	25	0.5	NaNO3	lgK:8.9(0.04SD)	0	MGL	956
6	10:45	0.25	Pr4N+ salt	dH:-10.(7.SD)kJ	0	MTD	3595
7	25	0.1	NaClO4	dH:-13.04(0.20SD)kJ	4	MCL	1483

Reaction No. 6488




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.2(3SF)	1	ELC	
2	25	0.25	Pr4N+ salt	lgK:11.75(0.15SD)	0	MGL	3595
3	25	0.5	NaNO3	lgK:12.5(0.07SD)	0	MGL	956
4	10:45	0.25	Pr4N+ salt	dH:-26.(12.SD)kJ	2	MTD	3595

Reaction No. 6489




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.8(2SF)	1	ELC	
2	25	0.25	Pr4N+ salt	lgK:4.21(0.1SD)	0	MGL	3595
3	25	0.5	NaNO3	lgK:4.9(0.05SD)	0	MGL	956
4	10:45	0.25	Pr4N+ salt	dH:-14.(10.SD)kJ	2	MTD	3595

Reaction No. 6490



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaNO3	lgK:5.5(0.2SD)	4	MGL	956

Reaction No. 6514



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.25	Many Media	lgK:1.3(0.03SD)	5	MGL	6796
2	10	0.25	Unknown	lgK:1.6(0.04SD)	3	MGL	1045
3	10	0.31	Many Media	lgK:1.4(0.03SD)	5	MGL	6796
4	15	0	Inf. Dilution	lgK:2.47(3SF)	3	MCO	4861
5	20	0.1	NaClO4	lgK:1.85(3SF)	2	MGL	154
6	23	0.035	KCl	lgK:2.35(3SF)	0	MSP	5748
7	25	0	Inf. Dilution	lgK:2.39(3SF)	4	MGL	1045
8	25	0	Inf. Dilution	lgK:2.499(4SF)	4	MCO	4861

9	25	0	Inf. Dilution	lgK:2.4 (0.3SD)	4	MSL	7062
10	25	0	Inf. Dilution	lgK:2.495 (4SF)	4	EOD	12002
11	25	0	Inf. Dilution	lgK:2.60 (3SF)	4	CRV	18273
Note (11): Table 3, p. 85							
12	25	0.04	Unknown	lgK:2.49 (3SF) w	0	MPH	999
13	25	0.1	KCl	lgK:2.50 (3SF)	0	MSL	906
14	25	0.1	NaCl	lgK:1.52 (0.02SD)	3	MIS	3540
15	25	0.1	NaCl	lgK:2.54 (0.01SD)	0	MGL	20992
16	25	0.1	NaCl	lgK:1.75 (3SF)	3	MIS	20992
17	25	0.1	NaClO4	lgK:1.51 (3SF)	3	MGL	476
18	25	0.16	Unknown	lgK:1.36 (3SF)	4	MIX	3478
19	25	0.2	KCl	lgK:1.46 (3SF)	6	MHY	999
20	25	0.25	Many Media	lgK:1.41 (0.02SD)	5	MGL	6796
21	25	0.25	Unknown	lgK:1.6 (0.03SD)	5	MGL	1045
22	25	0.31	Many Media	lgK:1.41 (0.02SD)	5	MGL	6796
23	25	0.72	Many Media	lgK:1.58 (0.02SD)	3	MGL	6796
24	25	1	NaCl	lgK:1.15 (3SF)	6	MGL	957
25	30	0	Inf. Dilution	lgK:2.517 (4SF)	4	MCO	4861
26	30	0.1	KCl	lgK:2.58 (3SF)	0	MSL	906
27	32	0.25	Many Media	lgK:1.5 (0.03SD)	5	MGL	6796
28	35	0	Inf. Dilution	lgK:2.571 (4SF)	4	MCO	4861
29	35	0	Inf. Dilution	lgK:2.4 (0.3SD)	4	MSL	7062
30	35	0.1	KCl	lgK:2.66 (3SF)	0	MSL	906
31	37	0.15	NaCl	lgK:1.49 (3SF)	4	MSL	26689
32	37	0.25	Unknown	lgK:1.7 (0.05SD)	5	MGL	1045
33	40	0.1	KCl	lgK:2.74 (3SF)	0	MSL	906
34	40	0.25	Many Media	lgK:1.6 (0.03SD)	5	MGL	6796
35	40	0.31	Many Media	lgK:1.4 (0.03SD)	5	MGL	6796
36	45	0.25	Unknown	lgK:1.8 (0.06SD)	3	MGL	1045
37	50	0.25	Many Media	lgK:1.7 (0.05SD)	5	MGL	6796
38	80	0	Inf. Dilution	lgK:2.9 (0.3SD)	4	MSL	7062
39	25	0	Inf. Dilution	dH:7. (1SF) kJ	3	MCL	1045
40	25	0	Inf. Dilution	dH:9.6 (2SF) kJ	4	MCL	4861
41	25	0	Inf. Dilution	dH:8. (2.SD) kJ	3	MCO	4861
42	25	0	Inf. Dilution/m	dH:4.45 (3SF)	3	EOD	6366
43	25	0	Many Media	dH:2.4 (2SF)	5	MTD	6796

44	25	0.1	Many Media	dH:2.2 (2SF)	5	MTD	6796
45	25	0.25	Many Media	dH:2.4 (2SF)	5	MTD	6796
46	25	0.5	Many Media	dH:2.8 (2SF)	3	MTD	6796
47	25	0.7	Many Media	dH:3.3 (2SF)	2	MTD	6796
48	25	1	Many Media	dH:3.9 (2SF)	0	MTD	6796

Reaction No. 6528

Gly-1 + Ca+2 = Ca+2_Gly-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0.5	Many Media	lgK:0.93 (0.06SD)	6	CMN	6128
2	10	0.25	Unknown	lgK:1.1 (0.06SD)	5	MGL	1045
3	15	0.5	Many Media	lgK:0.98 (0.04SD)	6	CMN	6128
4	20	0.1	KCl	lgK:1.43 (3SF)	3	MGL	2057
5	20	0.7	Unknown	lgK:1.0 (2SF)	5	CRV	552
6	25	0	Inf. Dilution	lgK:1.4 (0.05SD)	3	MSL	172
7	25	0	Inf. Dilution	lgK:1.38 (3SF)	3	MGL	686
8	25	0	Inf. Dilution	lgK:1.39 (3SF)	3	ENS	1384
9	25	0	Inf. Dilution	lgK:1.36 (3SF)	4	MPH	6131
10	25	0	Inf. Dilution	lgK:1.38 (3SF)	3	CRV	18273

Note (10): Table 3, p. 85

11	25	0	Inf. Dilution	lgK:1.43 (3SF)	4	MGL	21342
12	25	0	Inf. Dilution	lgK:1.35 (3SF)	4	MSL	22560
13	25	0.1	KNO3	lgK:2.86 (3SF)	0	MGL	17698
14	25	0.1	NaNO3	lgK:4.60 (3SF)	0	MPT	1069
15	25	0.1	NaNO3	lgK:5.12 (3SF)	0	MGL	16058
16	25	0.1	Unknown	lgK:1.05 (3SF)	6	CRV	552
17	25	0.25	Unknown	lgK:1.0 (0.04SD)	5	MGL	1045
18	25	0.5	Many Media	lgK:1.04 (0.03SD)	6	CMN	6128
19	25	0.5	Unknown	lgK:1.04 (0.03SD)	5	MPT	6128
20	25	1	Me4NC1	lgK:0.55 (0.01SD)	2	MSP	1529
21	25	3	NaClO4	lgK:0.75 (2SF)	3	CRV	552
22	25	3	NaClO4	lgK:0.75 (2SF)	3	MGL	9683
23	35	0.1	KNO3	lgK:3.58 (3SF)	0	MGL	1187
24	35	0.1	KNO3	lgK:3.6 (0.06SD)	0	MGL	2371
25	35	0.5	Many Media	lgK:1.10 (0.04SD)	6	CMN	6128
26	37	0.15	Blood Plasma	lgK:1.3 (0.05SD)	3	ENS	94

27	37	0.15	NaCl	lgK:1.46(0.01SD)	2	MGL	937
28	37	0.15	NaCl	lgK:2.03(3SF)	0	MGL	22560
29	37	0.15	NaCl	lgK:1.16(0.20SD)	4	MGL	28777
30	37	0.15	NaCl	lgK:1.27(0.10SD)	4	MIS	28777
31	37	0.15	Unknown	lgK:1.03(3SF)	6	CRV	552
32	37	0.25	Unknown	lgK:1.0(0.05SD)	5	MGL	1045
33	45	0.5	Many Media	lgK:1.16(0.06SD)	6	CMN	6128
34	25	0	Inf. Dilution	dH:-1.0(2SF)	3	CRV	552
35	25	0	Inf. Dilution	dH:-2.(1SF)kJ	5	MCL	1045
36	25	0	Inf. Dilution	dH:2.(1SF)kJ	0	MCL	6131

Reaction No. 6810							
Glycolic-1 + Ca+2 = Ca+2_Glycolic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.11(3SF)	5	MHY	4920
2	25	0	Inf. Dilution	lgK:1.6(2SF)	4	ENS	2152
3	25	0	Inf. Dilution	lgK:1.65(3SF)	5	MSL	7703
4	25	0.5	NaClO4	lgK:0.92(0.03MD)	6	MGL	4896
5	25	0.7	KNO3	lgK:1.11(3SF)	5	MIS	9156
6	30	0	Inf. Dilution	lgK:1.75(3SF)	5	MSL	7703
7	35	0	Inf. Dilution	lgK:1.84(3SF)	5	MSL	7703
8	40	0	Inf. Dilution	lgK:1.95(3SF)	5	MSL	7703
9	45	0	Inf. Dilution	lgK:2.02(3SF)	5	MSL	7703
10	25	0	Inf. Dilution	dG:-9.41(0.04SD)kJ	4	MSL	3052
11	25	0	Inf. Dilution	dH:35.52(0.02SD)kJ	4	MTD	3094
12	25	0	Inf. Dilution	dS:37.04(4SF)	4	EFE	3052

Reaction No. 6838							
ClAcet-1 + Ca+2 = Ca+2_ClAcet-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.4	NaNO3	lgK:0.1(0.05SD)	6	MGL	999

Reaction No. 7093							
Ca+2 + H+1_Malonic-2 = Ca+2_H+1_Malonic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.25	Many Media	lgK:0.5(0.04SD)	5	MGL	6796
2	10	0.31	Many Media	lgK:0.4(0.04SD)	5	MGL	6796

3	20	0.1	NaClO ₄	lgK:0.80 (2SF)	3	MGL	154
4	25	0	Inf. Dilution	lgK:0.9 (1SF)	3	CRV	7271
5	25	0.1	Unknown	lgK:0.50 (2SF)	3	CRV	7271
6	25	0.2	KCl	lgK:0.47 (2SF)	5	MHY	999
7	25	0.25	Many Media	lgK:0.4 (0.03SD)	5	MGL	6796
8	25	0.31	Many Media	lgK:0.4 (0.03SD)	5	MGL	6796
9	25	0.72	Many Media	lgK:0.5 (0.04SD)	5	MGL	6796
10	32	0.25	Many Media	lgK:0.3 (0.04SD)	5	MGL	6796
11	40	0.25	Many Media	lgK:0.4 (0.04SD)	5	MGL	6796
12	40	0.31	Many Media	lgK:0.5 (0.04SD)	5	MGL	6796
13	50	0.25	Many Media	lgK:0.4 (0.06SD)	5	MGL	6796
14	25	0	Many Media	dH:-1.0 (2SF)	2	MTD	6796
15	25	0.1	Many Media	dH:-0.9 (1SF)	5	MTD	6796
16	25	0.25	Many Media	dH:-0.2 (1SF)	5	MTD	6796
17	25	0.5	Many Media	dH:1.0 (2SF)	3	MTD	6796
18	25	0.7	Many Media	dH:1.9 (2SF)	2	MTD	6796
19	25	1	Many Media	dH:3.3 (2SF)	0	MTD	6796

Reaction No. 7246

Propanoic-1 + Ca²⁺ = Ca²⁺_Propanoic-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:0.50 (2SF)	5	MHY	4920
2	25	0	Inf. Dilution	lgK:0.68 (2SF)	4	MSL	999
3	25	0	Inf. Dilution	lgK:2.39 (3SF)	5	MSC	4482
4	25	0	UCT_Sea	lgK:0.96 (0.01SD)	4	EDH	5390
5	25	0.03	NaCl	lgK:1.21 (3SF)	5	MIS	11516
Note (5): Emara M et al., Electrochim. Acta, 1981, 26, 1705							
6	25	0.1	UCT_Sea	lgK:0.57 (0.01SD)	4	EDH	5390
7	25	0.2	UCT_Sea	lgK:0.50 (0.01SD)	4	EDH	5390
8	25	0.3	UCT_Sea	lgK:0.45 (0.01SD)	4	EDH	5390
9	25	0.4	UCT_Sea	lgK:0.43 (0.01SD)	4	EDH	5390
10	25	0.5	UCT_Sea	lgK:0.41 (0.01SD)	4	EDH	5390
11	25	0.6	UCT_Sea	lgK:0.40 (0.01SD)	4	EDH	5390
12	25	0.7	UCT_Sea	lgK:0.39 (0.01SD)	4	EDH	5390

Reaction No. 7334

OHEtDiPhos-4 + Ca+2 = Ca+2_OHEtDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:6.04 (3SF)	2	ENS	2756
2	25	0.1	KNO3	lgK:6.48 (3SF)	3	MGL	1599
3	25	0.1	Many Media	lgK:6.4 (0.2SD)	6	CIU	7242
4	25	0.1	Me4NC1	lgK:5.5 (0.04SD)	0	MGL	2495
5	25	0.1	Me4NC1	lgK:6.62 (3SF)	2	MGL	2756
6	25	0.1	Me4NNO3	lgK:6.2 (0.03SD)	3	MGL	1143
7	25	0.5	Me4NC1	lgK:5.74 (0.10SD)	5	MGL	3083
8	25	0.5	Unknown	lgK:5.7 (0.1SD)	6	CIU	7242
9	25	0.5	Me4NC1	dH:-0.52 (2SF)	5	MCL	3083

Reaction No. 7335							
Ca+2 + H+1_OHEtDiPhos-4 = Ca+2_H+1_OHEtDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.8 (2SF)	1	EDH	
2	25	0.1	KNO3	lgK:4.20 (3SF)	0	MGL	1599
3	25	0.1	Many Media	lgK:3.5 (0.1SD)	3	CIU	7242
4	25	0.1	Me4NC1	lgK:3.54 (3SF)	2	MGL	2756
5	25	0.1	Me4NNO3	lgK:3.1 (0.06SD)	0	MGL	1143
6	25	0.5	Me4NC1	lgK:3.58 (0.14SD)	0	MGL	3083
7	25	0.5	Unknown	lgK:3.6 (0.2SD)	2	CIU	7242


Reaction No. 7336							
Ca+2_OHEtDiPhos-4 + Ca+2 = Ca+2(2)_OHEtDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Many Media	lgK:4.6 (0.1SD)	6	CIU	7242
2	25	0.1	Me4NC1	lgK:4.6 (0.06SD)	4	MGL	1143
3	25	0.1	Me4NC1	lgK:5. (0.4SD)	5	MGL	2495

Reaction No. 7748							
25TDDS-4 + Ca+2 = Ca+2_25TDDS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:1. (0.06SD)	4	MPS	1103

Reaction No. 8164							
Ca+2 + Uridine-1 = Ca+2_Uridine-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:3.0(0.03SD)	4	MGL	1275
2	25	0.1	KNO3	lgK:3.1(0.03SD)	4	MGL	1275
3	35	0.1	KNO3	lgK:2.6(0.03SD)	4	MGL	1031
4	45	0.1	KNO3	lgK:3.3(0.03SD)	4	MGL	1275

Reaction No. 8345




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:24.9(0.03SD)	4	MGL	978

Reaction No. 8346




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:5.3(0.04SD)	4	MGL	978

Reaction No. 9213



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-200.39(5SF)	4	CRV	10174
2	50	0	Inf. Dilution	dG:-200.19(5SF)	4	CRV	10174
3	75	0	Inf. Dilution	dG:-200.05(5SF)	4	CRV	10174
4	100	0	Inf. Dilution	dG:-199.95(5SF)	4	CRV	10174
5	125	0	Inf. Dilution	dG:-199.89(5SF)	4	CRV	10174
6	150	0	Inf. Dilution	dG:-199.85(5SF)	4	CRV	10174
7	175	0	Inf. Dilution	dG:-199.84(5SF)	4	CRV	10174
8	200	0	Inf. Dilution	dG:-199.86(5SF)	4	CRV	10174
9	225	0	Inf. Dilution	dG:-199.88(5SF)	4	CRV	10174
10	250	0	Inf. Dilution	dG:-199.92(5SF)	4	CRV	10174
11	300	0	Inf. Dilution	dG:-199.98(5SF)	4	CRV	10174


Reaction No. 9214



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-273.83(5SF)	0	CRV	10174
2	25	0	Inf. Dilution	dG:-1146.00(6SF) kJ	2	EOD	23101
3	25	0	Inf. Dilution	dG:-273.84(5SF)	3	EPZ	23185


4	25	0	Inf. Dilution	dG:-1146.00 (6SF) kJ	2	CRV	23205
5	25	0	Inf. Dilution	dG:-1146.00 (6SF) kJ	2	EOD	23205
6	25	0	Inf. Dilution	dG:-273.83 (5SF)	2	EFE	32152
7	25	0	Inf. Dilution/m	dG:-1241.10 (6SF) kJ	0	CRV	24953
8	50	0	Inf. Dilution	dG:-274.28 (5SF)	2	CRV	10174
9	75	0	Inf. Dilution	dG:-274.83 (5SF)	2	CRV	10174
10	100	0	Inf. Dilution	dG:-275.46 (5SF)	2	CRV	10174
11	125	0	Inf. Dilution	dG:-276.17 (5SF)	3	CRV	10174
12	150	0	Inf. Dilution	dG:-276.93 (5SF)	1	CRV	10174
13	175	0	Inf. Dilution	dG:-277.75 (5SF)	1	CRV	10174
14	200	0	Inf. Dilution	dG:-278.62 (5SF)	1	CRV	10174
15	225	0	Inf. Dilution	dG:-279.53 (5SF)	1	CRV	10174
16	250	0	Inf. Dilution	dG:-280.48 (5SF)	1	CRV	10174
17	300	0	Inf. Dilution	dG:-282.47 (5SF)	0	CRV	10174
18	25	0	Inf. Dilution	dH:-1231.90 (6SF) kJ	0	EOD	23101
19	25	0	Inf. Dilution	Cp:-25.41 (4SF)	3	EPZ	23185

Reaction No. 9215



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-162.55 (5SF)	0	CRV	10174
2	50	0	Inf. Dilution	dG:-162.53 (5SF)	0	CRV	10174
3	75	0	Inf. Dilution	dG:-162.55 (5SF)	0	CRV	10174
4	100	0	Inf. Dilution	dG:-162.61 (5SF)	0	CRV	10174
5	125	0	Inf. Dilution	dG:-162.68 (5SF)	0	CRV	10174
6	150	0	Inf. Dilution	dG:-162.79 (5SF)	0	CRV	10174
7	175	0	Inf. Dilution	dG:-162.91 (5SF)	0	CRV	10174
8	200	0	Inf. Dilution	dG:-163.04 (5SF)	0	CRV	10174
9	225	0	Inf. Dilution	dG:-163.18 (5SF)	0	CRV	10174
10	250	0	Inf. Dilution	dG:-163.32 (5SF)	0	CRV	10174
11	300	0	Inf. Dilution	dG:-163.58 (5SF)	0	CRV	10174


Reaction No. 9216



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-311.57 (5SF)	4	CRV	10174


2	50	0	Inf. Dilution	dG:-312.56(5SF)	4	CRV	10174
3	75	0	Inf. Dilution	dG:-313.85(5SF)	4	CRV	10174
4	100	0	Inf. Dilution	dG:-315.39(5SF)	4	CRV	10174
5	125	0	Inf. Dilution	dG:-317.15(5SF)	4	CRV	10174
6	150	0	Inf. Dilution	dG:-319.11(5SF)	4	CRV	10174
7	175	0	Inf. Dilution	dG:-321.26(5SF)	4	CRV	10174
8	200	0	Inf. Dilution	dG:-323.57(5SF)	4	CRV	10174
9	225	0	Inf. Dilution	dG:-326.04(5SF)	4	CRV	10174
10	250	0	Inf. Dilution	dG:-328.66(5SF)	4	CRV	10174
11	300	0	Inf. Dilution	dG:-334.28(5SF)	4	CRV	10174

Reaction No. 9228



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-221.66(5SF)	4	CRV	10174
2	50	0	Inf. Dilution	dG:-222.05(5SF)	4	CRV	10174
3	75	0	Inf. Dilution	dG:-222.58(5SF)	4	CRV	10174
4	100	0	Inf. Dilution	dG:-223.22(5SF)	4	CRV	10174
5	125	0	Inf. Dilution	dG:-223.97(5SF)	4	CRV	10174
6	150	0	Inf. Dilution	dG:-224.80(5SF)	4	CRV	10174
7	175	0	Inf. Dilution	dG:-225.71(5SF)	4	CRV	10174
8	200	0	Inf. Dilution	dG:-226.69(5SF)	4	CRV	10174
9	225	0	Inf. Dilution	dG:-227.73(5SF)	4	CRV	10174
10	250	0	Inf. Dilution	dG:-228.83(5SF)	4	CRV	10174
11	300	0	Inf. Dilution	dG:-231.14(5SF)	4	CRV	10174

Reaction No. 9595



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.25	Unknown	lgK:5.8(0.06SD)	5	MGL	1045
2	25	0	Inf. Dilution	lgK:6.59(3SF)	6	MGL	1045
3	25	0.25	Unknown	lgK:5.9(0.04SD)	5	MGL	1045
4	37	0.25	Unknown	lgK:6.0(0.05SD)	5	MGL	1045
5	45	0.25	Unknown	lgK:6.0(0.07SD)	5	MGL	1045
6	25	0	Inf. Dilution	dH:5.(1SF)kJ	5	MCL	1045

Reaction No. 9601


Maleic-2 + Ca+2 = Ca+2_Maleic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:2.423(4SF)	5	MCO	4861
2	25	0	Inf. Dilution	lgK:2.40(3SF)	6	MGL	1045
3	25	0	Inf. Dilution	lgK:2.473(4SF)	5	MCO	4861
4	25	0.1	NaCl	lgK:1.85(0.04SD)	3	MGL	20992
5	25	0.1	NaCl	lgK:1.79(0.01SD)	3	MIS	20992
6	25	0.1	Unknown	lgK:1.1(2SF)	2	ESL	1217
7	25	0.15	KNO3	lgK:1.40(3SF)	3	MGL	9980
8	25	0.16	Unknown	lgK:1.10(3SF)	3	MIX	3478
9	25	0.25	Unknown	lgK:1.8(0.05SD)	3	MGL	1045
10	30	0	Inf. Dilution	lgK:2.513(4SF)	5	MCO	4861
11	35	0	Inf. Dilution	lgK:2.550(4SF)	5	MCO	4861
12	40	0	Inf. Dilution	lgK:2.558(4SF)	5	MCO	4861
13	45	0	Inf. Dilution	lgK:2.618(4SF)	5	MCO	4861
14	25	0	Inf. Dilution	dH:8.4(2SF) kJ	4	MCL	4861
15	25	0	Inf. Dilution	dH:9.6(1.2SD) kJ	4	MCO	4861

Reaction No. 9602							
H+1 + Maleic-2 + Ca+2 = Ca+2_H+1_Maleic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.29(3SF)	6	MGL	1045
2	25	0.25	Unknown	lgK:6.7(0.06SD)	5	MGL	1045

Reaction No. 9609							
Diglycol-2 + Ca+2 = Ca+2_Diglycol-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	12.5	0.25	Unknown	lgK:3.6(0.04SD)	3	MGL	1045
2	25	0	Inf. Dilution	lgK:4.28(3SF)	6	MGL	1045
3	25	0.1	KCl	lgK:3.36(3SF)	5	MGL	1257
4	25	0.1	KNO3	lgK:3.39(3SF)	5	MGL	2308
5	25	0.1	KNO3	lgK:3.54(0.02SD)	4	MGL	3519
6	25	0.1	NaCl	lgK:3.24(0.01SD)	3	MGL	20992
7	25	0.1	NaCl	lgK:3.44(3SF)	3	MIS	20992
8	25	0.25	Unknown	lgK:3.5(0.03SD)	3	MGL	1045
9	30	0.1	KCl	lgK:3.4(2SF)	4	MGL	4250


10	37	0.25	Unknown	lgK:3.4 (0.03SD)	3	MGL	1045
11	48	0.25	Unknown	lgK:3.4 (0.04SD)	2	MGL	1045
12	25	0	Inf. Dilution	dH:-10. (2SF) kJ	5	MCL	1045

Reaction No. 9610




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	12.5	0.25	Unknown	lgK:6.6 (0.1SD)	5	MGL	1045
2	25	0	Inf. Dilution	lgK:7.12 (3SF)	6	MGL	1045
3	25	0.1	KNO3	lgK:6.6 (0.04SD)	5	MGL	3519
4	25	0.25	Unknown	lgK:6.4 (0.05SD)	5	MGL	1045
5	37	0.25	Unknown	lgK:6.3 (0.06SD)	5	MGL	1045
6	48	0.25	Unknown	lgK:6.4 (0.06SD)	5	MGL	1045
7	25	0	Inf. Dilution	dH:-15. (2SF) kJ	5	MCL	1045

Reaction No. 9628



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.42 (3SF)	6	MGL	1045
2	25	0	UCT_Sea	lgK:6.43 (0.01SD)	4	EDH	5390
3	25	0.1	UCT_Sea	lgK:5.55 (0.01SD)	4	EDH	5390
4	25	0.2	UCT_Sea	lgK:5.40 (0.01SD)	4	EDH	5390
5	25	0.25	Unknown	lgK:5.7 (0.06SD)	5	MGL	1045
6	25	0.3	UCT_Sea	lgK:5.30 (0.01SD)	4	EDH	5390
7	25	0.4	UCT_Sea	lgK:5.25 (0.01SD)	4	EDH	5390
8	25	0.5	UCT_Sea	lgK:5.20 (0.01SD)	4	EDH	5390
9	25	0.6	UCT_Sea	lgK:5.16 (0.01SD)	4	EDH	5390
10	25	0.7	UCT_Sea	lgK:5.14 (0.01SD)	4	EDH	5390


Reaction No. 9631



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.25	Unknown	lgK:16.1 (0.2SD)	5	MGL	1045
2	25	0	Inf. Dilution	lgK:15.03 (4SF)	4	MGL	1045
3	25	0	Inf. Dilution	lgK:15.40 (4SF)	0	MPH	6131
4	25	0	Inf. Dilution	lgK:15.4 (0.2MD)	4	MGL	6912
5	25	0.25	Unknown	lgK:15.4 (0.1SD)	5	MGL	1045

6	37	0.25	Unknown	lgK:15.0 (0.2SD)	5	MGL	1045
7	10	0.1	HCl	lgR:16.06 (4SF)	5	MGL	6912
8	10	0.5	HCl	lgR:16.29 (4SF)	5	MGL	6912
9	10	1	HCl	lgR:16.54 (4SF)	5	MGL	6912
10	25	0.1	HCl	lgR:15.63 (4SF)	5	MGL	6912
11	25	0.5	HCl	lgR:15.76 (4SF)	5	MGL	6912
12	25	1	HCl	lgR:15.87 (4SF)	5	MGL	6912
13	37	0.1	HCl	lgR:15.29 (4SF)	5	MGL	6912
14	37	0.5	HCl	lgR:15.34 (4SF)	5	MGL	6912
15	37	1	HCl	lgR:15.34 (4SF)	5	MGL	6912
16	45	0.1	HCl	lgR:15.06 (4SF)	5	MGL	6912
17	45	0.5	HCl	lgR:15.06 (4SF)	5	MGL	6912
18	45	1	HCl	lgR:14.98 (4SF)	5	MGL	6912
19	10	0.1	HCl	dH:-10.5 (3SF)	0	MTD	6912
20	10	0.5	HCl	dH:-12.9 (3SF)	4	MTD	6912
21	10	1	HCl	dH:-16.3 (3SF)	0	MTD	6912
22	25	0	Inf. Dilution	dH:-66. (2SF) kJ	0	MCL	1045
23	25	0	Inf. Dilution	dH:-46. (2SF) kJ	4	MCL	6131
24	25	0	Inf. Dilution	dH:-11.0 (0.2SD)	3	MCL	6912
25	25	0.1	HCl	dH:-11.5 (3SF)	4	MTD	6912
26	25	0.5	HCl	dH:-14.3 (3SF)	0	MTD	6912
27	25	1	HCl	dH:-18.2 (3SF)	0	MTD	6912
28	37	0.1	HCl	dH:-12.4 (3SF)	4	MTD	6912
29	37	0.5	HCl	dH:-15.5 (3SF)	0	MTD	6912
30	37	1	HCl	dH:-19.6 (3SF)	0	MTD	6912
31	45	0.1	HCl	dH:-13.1 (3SF)	0	MTD	6912
32	45	0.5	HCl	dH:-16.3 (3SF)	0	MTD	6912
33	45	1	HCl	dH:-20.6 (3SF)	0	MTD	6912


Reaction No. 9995



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Me4NBr	lgK:6.5 (0.1SD)	0	MSC	931
2	25	0.1	KCl	lgK:6.03 (3SF)	6	MGL	999
3	25	0.1	Me4NBr	lgK:6.02 (0.05SD)	4	MSC	931
4	25	0.1	Me4NNO3	lgK:6.0 (0.06SD)	4	MGL	1143


5	25	0.1	Unknown	lgK:5.51 (3SF)	5	MGL	931
6	25	0.5	Me4NC1	lgK:4.70 (0.15SD)	0	MGL	3083
7	25	1	Me4NBr	lgK:5.01 (0.06SD)	4	MSC	931
8	50	0.1	Me4NBr	lgK:5.93 (3SF)	5	MSC	931
9	50	1	Me4NBr	lgK:4.77 (3SF)	5	MSC	931
10	25	0	Unknown	dH:0.0 (2.SD)	4	MCL	931
11	25	0.5	Me4NC1	dH:2.6 (2SF)	0	MCL	3083

Reaction No. 9996




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.88 (3SF)	0	MGL	931
2	25	0.1	Me4NNO3	lgK:2.9 (0.08SD)	4	MGL	1143
3	25	0.1	Unknown	lgK:2.76 (3SF)	5	MGL	931
4	25	0.5	Me4NC1	lgK:2.46 (0.04SD)	4	MGL	3083

Reaction No. 9997




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:3.8 (0.08SD)	4	MGL	1143
2	25	0.1	Unknown	lgK:3.31 (3SF)	5	MGL	931

Reaction No. 10003



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NC1	lgK:5.77 (0.01SD)	6	MGL	2209
2	25	0.1	Me4NNO3	lgK:5.95 (0.01SD)	5	MGL	1143
3	25	0.1	Me4NC1	dG:-7.87 (0.02SD)	6	MGL	2209
4	25	0.1	Me4NC1	dH:2. (0.3SD)	6	MCL	2209
5	25	0.1	Me4NC1	dS:30.6 (0.1SD)	6	EFE	2209


Reaction No. 10004



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NC1	lgK:3.09 (0.02SD)	6	MGL	2209
2	25	0.1	Me4NNO3	lgK:3.2 (0.1SD)	5	MGL	1143
3	25	0.1	Me4NC1	dG:-4.2 (0.03SD)	6	MGL	2209


4	25	0.1	Me4NC1	dH:1.(0.3SD)	6	MCL	2209
5	25	0.1	Me4NC1	dS:18.4(0.1SD)	6	EFE	2209

Reaction No. 10005




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:3.(0.3SD)	4	MGL	1143

Reaction No. 10006




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:5.9(0.07SD)	4	MGL	1143

Reaction No. 10007




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:2.6(0.1SD)	4	MGL	1143

Reaction No. 10008




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:3.(0.3SD)	3	MGL	1143

Reaction No. 10014




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.7(3SF)	1	ELC	
2	25	0.1	KCl	lgK:9.67(3SF)	0	MGL	931
3	25	0.1	Me4NC1	lgK:12.2(3SF)	0	MGL	2756

Reaction No. 10015



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:4.1(0.2SD)	4	MGL	1143


Reaction No. 10016



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0.1	Me4NNO3	lgK:4.2(0.03SD)	4	MGL	1143
---	----	-----	---------	-----------------	---	-----	------

Reaction No. 10017




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:2.9(0.03SD)	4	MGL	1143

Reaction No. 10018




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:3.8(0.07SD)	4	MGL	1143

Reaction No. 10026



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:6.9(0.06SD)	4	MGL	1143


Reaction No. 10027



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:3.7(0.06SD)	0	MGL	1143


Note (1): Thermodynamically isolated

Reaction No. 10030




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:4.06(0.003SD)	6	MGL	1144

Reaction No. 10031



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:5.9(0.03SD)	4	MGL	1144

Reaction No. 10037



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:5.2(0.04SD)	4	MGL	1144

Reaction No. 10038							
$2\text{<DeOxDeMeTetracycline-2>} + \text{Ca}^{+2} = \text{Ca}^{+2}\text{DeOxDeMeTetracycline-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:9.9(0.09SD)	3	MGL	1144

Reaction No. 10039							
$\text{H}^{+1} + \text{DeOxDeMeTetracycline-2} + \text{Ca}^{+2} = \text{Ca}^{+2}\text{H}^{+1}\text{DeOxDeMeTetracycline-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:12.7(0.05SD)	4	MGL	1144

Reaction No. 10040							
$\text{H}^{+1} + 2\text{<DeOxDeMeTetracycline-2>} + \text{Ca}^{+2} = \text{Ca}^{+2}\text{H}^{+1}\text{DeOxDeMeTetracycline-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:19.6(0.02SD)	6	MGL	1144

Reaction No. 10041							
$2\text{<H}^{+1}\text{>} + 2\text{<DeOxDeMeTetracycline-2>} + \text{Ca}^{+2} = \text{Ca}^{+2}\text{H}^{+1(2)}\text{DeOxDeMeTetracycline-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:26.4(0.05SD)	4	MGL	1144

Reaction No. 10164							
$\text{PhenPhos-2} + \text{Ca}^{+2} = \text{Ca}^{+2}\text{PhenPhos-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.4(0.2MD)	3	MGL	1095


Reaction No. 10169							
$[\text{HexPhos}]\text{-2} + \text{Ca}^{+2} = \text{Ca}^{+2}[\text{HexPhos}]\text{-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.7(0.07MD)	6	MGL	1095

Reaction No. 10173							
$\text{tBuPhos-2} + \text{Ca}^{+2} = \text{Ca}^{+2}\text{tBuPhos-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.7(0.08MD)	4	MGL	1095

Reaction No. 10177							
$\text{H}^{+1} + \text{DiMeAmMeEtPhos-2} + \text{Ca}^{+2} = \text{Ca}^{+2}\text{H}^{+1}\text{DiMeAmMeEtPhos-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0.1	KNO3	lgK:13.3 (0.08MD)	4	MGL	1095
---	----	-----	------	-------------------	---	-----	------

Reaction No. 10178




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.2 (0.2MD)	3	MGL	1095

Reaction No. 10185




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.7 (0.1MD)	4	MGL	1095

Reaction No. 10192




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.7 (0.1MD)	4	MGL	1095

Reaction No. 10366



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Pr4NI	lgK:3.2 (0.1SD)	0	MGL	931
2	25	0.1	Unknown	lgK:2.17 (3SF)	6	CRV	552
3	25	0.15	KCl	lgK:2.2 (2SF)	3	MGL	931
4	25	0.15	Unknown	lgK:2.3 (2SF)	3	MGL	140
5	25	0.2	KNO3	lgK:1.59 (0.02SD)	5	MGL	1370
6	37	0.15	KNO3	lgK:2.2 (0.04SD)	5	MGL	906

Reaction No. 10367



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Pr4NI	lgK:2.5 (0.1SD)	0	MGL	931
2	20	0.1	Unknown	lgK:2.5 (0.1SD)	0	MGL	999
3	25	0.15	KCl	lgK:1.43 (3SF)	3	MGL	999
4	25	0.2	KNO3	lgK:1.0 (0.06SD)	3	MGL	1370
5	37	0.15	KNO3	lgK:1.7 (0.1SD)	3	MGL	999

Reaction No. 10368

Ca+2 + H+1(2)_PO4Ser-3 = Ca+2_H+1(2)_PO4Ser-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:1.3(0.1SD)	0	MGL	906
2	37	0.15	Unknown	lgK:4.6(2SF)	6	CRV	552

Reaction No. 10369							
Ca+2 + H+1(2)_PO4Ser-3 + H+1_PO4Ser-3 = Ca+2_H+1(3)_PO4Ser-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:2.(0.3SD)	4	MGL	999

Reaction No. 10370							
2<Ca+2_H+1_PO4Ser-3> = Ca+2(2)_H+1(2)_PO4Ser-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:2.(0.4SD)	4	MGL	999

Reaction No. 10452							
Fumaric-2 + Ca+2 = Ca+2_Fumaric-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.00(3SF)	6	MCN	999
2	25	0.1	Unknown	lgK:0.48(2SF)	3	MIX	3478

Reaction No. 10459							
OxAcet-2 + Ca+2 = Ca+2_OxAcet-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.6(2SF)	4	MGL	999
2	25	0.16	Unknown	lgK:1.6(2SF)	4	MIX	3478

Reaction No. 10460							
Ca+2_OxAcet-2 + Ca+2 = Ca+2(2)_OxAcet-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:2.0(2SF)	4	MGL	999

Reaction No. 10482							
Ca+2 + H+1_Succinic-2 = Ca+2_H+1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:0.54(2SF)	5	MGL	154
2	25	0.2	KCl	lgK:0.52(2SF)	5	MHY	999

Reaction No. 10507							
MeMalon-2 + Ca+2 = Ca+2_MeMalon-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:1.65 (3SF)	6	MGL	476

Reaction No. 10612							
Ca+2 + H+1_Malic-2 = Ca+2_H+1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:1.06 (3SF)	5	MGL	154
2	20	0.1	NaClO4	lgK:1.96 (3SF)	0	MIX	22560
3	25	0.2	KCl	lgK:1.02 (3SF)	5	MHY	999

Reaction No. 10648							
Ca+2 + H+1_Tartaric-2 = Ca+2_H+1_Tartaric-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:1.11 (3SF)	6	MHY	999

Reaction No. 10683							
Butanoic-1 + Ca+2 = Ca+2_Butanoic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.54 (2SF)	6	MSL	999
2	25	0	Inf. Dilution	lgK:2.40 (3SF)	1	MSC	4482
3	25	0.03	NaCl	lgK:1.21 (3SF)	1	MIS	11516
Note (3): Emara M et al., Electrochim. Acta, 1981, 26, 1705							
4	25	0.2	KCl	lgK:0.51 (2SF)	5	MHY	4920

Reaction No. 10789							
3OHButan-1 + Ca+2 = Ca+2_3OHButan-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.82 (2SF)	6	MSL	999
2	25	0	UCT_Sea	lgK:1.06 (0.01SD)	4	EDH	5390
3	25	0.1	UCT_Sea	lgK:0.67 (0.01SD)	4	EDH	5390
4	25	0.2	KCl	lgK:0.60 (2SF)	5	MHY	4920
5	25	0.2	UCT_Sea	lgK:0.60 (0.01SD)	4	EDH	5390
6	25	0.3	UCT_Sea	lgK:0.55 (0.01SD)	4	EDH	5390
7	25	0.4	UCT_Sea	lgK:0.53 (0.01SD)	4	EDH	5390
8	25	0.5	UCT_Sea	lgK:0.51 (0.01SD)	4	EDH	5390

9	25	0.6	UCT_Sea	lgK:0.51(0.01SD)	4	EDH	5390
10	25	0.7	UCT_Sea	lgK:0.50(0.01SD)	4	EDH	5390

Reaction No. 10813							
2OH2MePropan-1 + Ca+2 = Ca+2_2OH2MePropan-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.33(3SF)	3	EOD	29070
2	25	0	UCT_Sea	lgK:1.51(0.01SD)	4	EDH	5390
3	25	0.1	UCT_Sea	lgK:1.12(0.01SD)	4	EDH	5390
4	25	0.2	UCT_Sea	lgK:1.04(0.01SD)	4	EDH	5390
5	25	0.3	UCT_Sea	lgK:1.00(0.01SD)	4	EDH	5390
6	25	0.4	UCT_Sea	lgK:0.97(0.01SD)	4	EDH	5390
7	25	0.5	NaClO4	lgK:1.09(0.03MD)	6	MGL	4896
8	25	0.5	UCT_Sea	lgK:0.95(0.01SD)	4	EDH	5390
9	25	0.6	UCT_Sea	lgK:0.94(0.01SD)	4	EDH	5390
10	25	0.7	UCT_Sea	lgK:0.93(0.01SD)	4	EDH	5390
11	25	1	NaClO4	lgK:0.92(0.02SD)	4	MQH	999

Reaction No. 10814							
2<2OH2MePropan-1> + Ca+2 = Ca+2_2OH2MePropan-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.33(3SF)	3	EOD	29070
2	25	0	UCT_Sea	lgK:2.29(0.01SD)	4	EDH	5390
3	25	0.1	UCT_Sea	lgK:1.70(0.01SD)	4	EDH	5390
4	25	0.2	UCT_Sea	lgK:1.58(0.01SD)	4	EDH	5390
5	25	0.3	UCT_Sea	lgK:1.52(0.01SD)	4	EDH	5390
6	25	0.4	UCT_Sea	lgK:1.48(0.01SD)	4	EDH	5390
7	25	0.5	UCT_Sea	lgK:1.46(0.01SD)	4	EDH	5390
8	25	0.6	UCT_Sea	lgK:1.44(0.01SD)	4	EDH	5390
9	25	0.7	UCT_Sea	lgK:1.43(0.01SD)	4	EDH	5390
10	25	1	NaClO4	lgK:1.42(0.03SD)	3	MQH	999

Reaction No. 10977							
ThioDiAcet-2 + Ca+2 = Ca+2_ThioDiAcet-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KCl	lgK:1.4(2SF)	4	MGL	4250

Reaction No. 11024							
NacGly-1 + Ca+2 = Ca+2_NacGly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.4	NaNO3	lgK:0.29 (0.02SD)	4	MGL	382

Reaction No. 11066							
MeEDTA-4 + Ca+2 = Ca+2_MeEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:11.58 (4SF)	6	MPT	1978
2	25	0.1	KCl	lgK:11.51 (4SF)	4	MGL	2015
3	25	0.5	Me4NCl	lgK:11.41 (4SF)	2	MGL	4556
4	30	0.1	KCl	lgK:11.47 (4SF)	3	MGL	2019
5	20	1	KCl	dH:-3.02 (3SF)	5	MCL	2018

Reaction No. 11454							
DiMeMalon-2 + Ca+2 = Ca+2_DiMeMalon-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:1.52 (3SF)	6	MGL	476

Reaction No. 11471							
EtMalon-2 + Ca+2 = Ca+2_EtMalon-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:2.447 (4SF)	5	MCO	4861
2	25	0	Inf. Dilution	lgK:2.471 (4SF)	5	MCO	4861
3	25	0.1	NaClO4	lgK:1.59 (3SF)	6	MGL	476
4	30	0	Inf. Dilution	lgK:2.502 (4SF)	5	MCO	4861
5	35	0	Inf. Dilution	lgK:2.551 (4SF)	5	MCO	4861
6	25	0	Inf. Dilution	dH:9.6 (2SF) kJ	4	MCL	4861
7	25	0	Inf. Dilution	dH:8.8 (0.5SD) kJ	4	MCO	4861

Reaction No. 11499							
Glutaric-2 + Ca+2 = Ca+2_Glutaric-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.06 (3SF)	5	MGL	2551
2	25	0.16	Unknown	lgK:0.55 (2SF)	3	MIX	3478
3	25	0.2	KCl	lgK:1.06 (3SF)	6	MHY	999

Reaction No. 11500							
Ca+2 + H+1_Glutaric-2 = Ca+2_H+1_Glutaric-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:0.50 (2SF)	6	MHY	999

Reaction No. 11557							
Itaconic-2 + Ca+2 = Ca+2_Itaconic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:1.2 (2SF)	4	CRV	7271
2	25	0.16	Unknown	lgK:1.2 (2SF)	4	MIX	3478
3	25	0.5	Unknown	lgK:0.95 (2SF)	4	CRV	7271
4	25	0.5	Unknown	dH:1.4 (2SF)	4	CRV	7271

Reaction No. 11593							
Pivalic-1 + Ca+2 = Ca+2_Pivalic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.55 (2SF)	6	MSL	999

Reaction No. 11643							
Citraconic-2 + Ca+2 = Ca+2_Citraconic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	Unknown	lgK:1.3 (2SF)	4	MIX	3478


Reaction No. 11679							
Ca+2_MIDA-2 + MIDA-2 = Ca+2_MIDA-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.72 (3SF)	6	MGL	999
2	25	0.1	KCl	dH:-0.74 (0.3SD)	5	MTD	3215

Reaction No. 11737							
Ca+2 + H+1_Orn-1 = Ca+2_H+1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.52 (3SF)	5	MGL	3511
2	25	1	KNO3	lgK:1.68 (3SF)	5	MGL	3511

Reaction No. 12102							
Tricarballic-3 + Ca+2 = Ca+2_Tricarballic-3							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO ₄	lgK:2.17(3SF)	5	MGL	154
2	25	0	Inf. Dilution	lgK:3.17(3SF)	3	MIS	17788
3	25	0.16	Unknown	lgK:1.82(3SF)	5	MIX	3478

Reaction No. 12103




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO ₄	lgK:1.46(3SF)	5	MGL	154

Reaction No. 12104




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO ₄	lgK:0.88(2SF)	5	MGL	154

Reaction No. 12153




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:1.66(0.02SD)	6	MGL	1231

Reaction No. 12213




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	Unknown	lgK:2.47(3SF)	5	MIX	3478

Reaction No. 12251



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.19(3SF)	6	MCN	999

Reaction No. 12297



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0.01	Self Medium	lgK:1.08(0.01SD)	0	MIS	30564
2	20	0.2	KCl	lgK:1.21(3SF)	5	MHY	4920
3	23	0.15	NaCl	lgK:1.28(3SF)	3	MIS	30057
4	23			lgK:2.16(3SF)	0	ENS	4396

5	25	0.1	Unknown	lgK:1.46(3SF)	4	CRV	31120
6	25	0.15	Unknown	lgK:1.15(3SF)	4	MSP	3836
7	25	0.16	Unknown	lgK:1.22(3SF)	5	MIX	3478
8	25	0.5	NaCl	lgK:1.05(3SF)	5	MIS	11516
Note (8): Masone M et al., Ann. Chim. (Rome), 1981, 71, 517							
9	25	0.7	KNO3	lgK:1.31(3SF)	3	MIS	11516
Note (9): Haas J, Marine Chem., 1986, 19, 299							

Reaction No. 12298							
2<Gluconic-1> + Ca+2 = Ca+2_Gluconic-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0.01	Self Medium	lgK:1.61(0.02SD)	0	MIS	30564
2	25	0	Inf. Dilution	lgK:2.16(3SF)	3	MGL	999
3	25	0	Inf. Dilution	lgK:4.64(3SF)	1	MGL	11516
Note (3): Heinz E, Biochem. J., 1951, 321, 314							
4	25	0.16	Unknown	lgK:1.22(3SF)	3	MIX	999
5	25	0.5	NaCl	lgK:1.88(3SF)	5	MIS	11516
Note (5): Masone M et al., Ann. Chim. (Rome), 1981, 71, 517							

Reaction No. 12397							
Picolinic-1 + Ca+2 = Ca+2_Picolinic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:1.81(3SF)	6	MGL	999
2	25	0	Inf. Dilution	lgK:2.22(3SF)	4	MGL	999
3	25	0	Inf. Dilution	lgK:2.2(2SF)	4	ENS	6405

Reaction No. 12398							
2<Picolinic-1> + Ca+2 = Ca+2_Picolinic-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.79(3SF)	4	MGL	999
2	25	0	Inf. Dilution	lgK:3.8(2SF)	4	ENS	6405

Reaction No. 12505							
Tiron-4 + Ca+2 = Ca+2_Tiron-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.80(3SF)	6	MGL	999

Reaction No. 12506							
Ca+2 + H+1_Tiron-4 = Ca+2_H+1_Tiron-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.18 (3SF)	6	MGL	999

Reaction No. 12616							
12BisCOOMeThioEthan-2 + Ca+2 = Ca+2_12BisCOOMeThioEthan-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:1.74 (3SF)	6	MGL	999

Reaction No. 12617							
Ca+2 + H+1_12BisCOOMeThioEthan-2 = Ca+2_H+1_12BisCOOMeThioEthan-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:1.16 (3SF)	6	MGL	999


Reaction No. 12624							
Ca+2_Citrul-1 + Citrul-1 = Ca+2_Citrul-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:0.2 (1SF)	4	MGL	3511

Reaction No. 12776							
HIMDA-2 + Ca+2 = Ca+2_HIMDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.63 (3SF)	3	MGL	3486
2	23	0.1	NH4Cl	lgK:5.3 (2SF)	0	MCG	906
3	25	0	Inf. Dilution	lgK:5.6 (2SF)	1	EDH	
4	25	0.1	Unknown	lgK:4.8 (0.2SD)	6	CRV	552
5	25	0.1	Unknown	lgK:4.58 (3SF)	5	MGL	2261
6	30	0.1	KCl	lgK:4.83 (3SF)	3	MGL	999
7	25	0.1	Unknown	dH:-3.3 (2SF)	6	CRV	552

Reaction No. 12909							
Benzoic-1 + Ca+2 = Ca+2_Benzoic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.32 (3SF)	4	MGL	4503
2	25	0	UCT_Sea	lgK:0.73 (0.01SD)	4	EDH	5390
3	25	0.03	NaCl	lgK:1.27 (3SF)	4	MIS	4503


4	25	0.045	NaCl	lgK:1.21 (3SF)	4	MIS	4503
5	25	0.1	UCT_Sea	lgK:0.34 (0.01SD)	4	EDH	5390
6	25	0.2	UCT_Sea	lgK:0.27 (0.01SD)	4	EDH	5390
7	25	0.3	NaCl	lgK:0.477 (3SF)	4	MIS	4503
8	25	0.3	UCT_Sea	lgK:0.22 (0.01SD)	4	EDH	5390
9	25	0.4	UCT_Sea	lgK:0.20 (0.01SD)	4	EDH	5390
10	25	0.45	NaCl	lgK:0.398 (3SF)	4	MIS	4503
11	25	0.5	UCT_Sea	lgK:0.18 (0.01SD)	4	EDH	5390
12	25	0.6	UCT_Sea	lgK:0.17 (0.01SD)	4	EDH	5390
13	25	0.7	UCT_Sea	lgK:0.16 (0.01SD)	4	EDH	5390
14	30	0.4	KNO3	lgK:0.2 (1SF)	4	MGL	382
15	35	0	Inf. Dilution	lgK:1.35 (3SF)	4	MGL	4503
16	35	0.03	NaCl	lgK:1.30 (3SF)	4	MIS	4503
17	35	0.045	NaCl	lgK:1.24 (3SF)	4	MIS	4503
18	35	0.3	NaCl	lgK:0.511 (3SF)	4	MIS	4503
19	35	0.45	NaCl	lgK:0.423 (3SF)	4	MIS	4503
20	45	0	Inf. Dilution	lgK:1.38 (3SF)	4	MGL	4503
21	45	0.03	NaCl	lgK:1.33 (3SF)	4	MIS	4503
22	45	0.045	NaCl	lgK:1.25 (3SF)	4	MIS	4503
23	45	0.3	NaCl	lgK:0.556 (3SF)	4	MIS	4503
24	45	0.45	NaCl	lgK:0.446 (3SF)	4	MIS	4503
25	25:45	0	Inf. Dilution	dH:-0.503 (3SF)	4	MTD	4503
26	25		Methanol	lgK:4.7 (2SF)	5	MGL	4795

Reaction No. 12918



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:3.06 (3SF)	6	MCO	999
2	30		Water:Dioxan 50:50Wgt	lgK:4.8 (2SF)	5	MGL	140

Reaction No. 13013



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.7 (2SF)	2	MCN	386

Reaction No. 13032

34DHB-3 + Ca+2 = Ca+2_34DHB-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:3.71 (3SF)	5	MGL	140

Reaction No. 13033							
Ca+2_34DHB-3 + 34DHB-3 = Ca+2_34DHB-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:2.65 (3SF)	5	MGL	140

Reaction No. 13210							
23PyridineDiCOO-2 + Ca+2 = Ca+2_23PyridineDiCOO-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.1 (2SF)	4	MGL	999

Reaction No. 13226							
24PyridineDiCOO-2 + Ca+2 = Ca+2_24PyridineDiCOO-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.1 (2SF)	4	MGL	999


Reaction No. 13245							
26PyridineDiCOO-2 + Ca+2 = Ca+2_26PyridineDiCOO-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:4.40 (3SF)	6	MGL	999
2	25	0.1	KNO3	lgK:4.2 (2SF)	4	MGL	999
3	25	0.1	NaCl	lgK:4.6 (0.03SD)	5	MGL	3925
4	25	0.1	Unknown	lgK:4.60 (3SF)	6	MGL	999
5	25	1	KNO3	lgK:4.39 (0.01SD)	6	MPT	999
6	30	0.1	KCl	lgK:4.6 (2SF)	4	MGL	4250

Reaction No. 13246							
Ca+2_26PyridineDiCOO-2 + 26PyridineDiCOO-2 = Ca+2_26PyridineDiCOO-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:2.98 (3SF)	6	MGL	999
2	30	0.1	KCl	lgK:2.6 (2SF)	4	MGL	4250

Reaction No. 13317							
Ca+2 + 2<H+1_26PyridineDiCOO-2> = Ca+2_H+1(2)_26PyridineDiCOO-2(2)							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:2.25 (0.01SD)	6	MPT	999

Reaction No. 13560




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:5.18 (3SF)	4	CRV	552
2	25	0.1	KNO3	lgK:4.8 (0.07SD)	4	MGL	999
3	25	0.1	Unknown	lgK:5. (0.6SD)	6	CRV	552

Reaction No. 13561




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:1.9 (2SF)	4	CRV	552
2	25	0.1	KNO3	lgK:2.02 (3SF)	5	MGL	906
3	25	0.1	KNO3	lgK:2.6 (0.06SD)	0	MGL	999

Reaction No. 13562




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.26 (3SF)	6	MGL	999

Reaction No. 13662




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.70 (2SF)	4	MSL	140

Reaction No. 13756



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.48 (3SF)	4	CRV	552

Reaction No. 13925



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.42 (3SF)	6	MGL	999

Reaction No. 13926

2<2QuinCOO-1> + Ca+2 = Ca+2_2QuinCOO-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.99 (3SF)	6	MGL	999

Reaction No. 13960							
8QuinCOO-1 + Ca+2 = Ca+2_8QuinCOO-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.20 (3SF)	6	MGL	999


Reaction No. 13961							
Ca+2_8QuinCOO-1 + 8QuinCOO-1 = Ca+2_8QuinCOO-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.93 (3SF)	6	MGL	999

Reaction No. 14037							
Ca+2 + H+1_EDTA-4 = Ca+2_H+1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.5 (2SF)	4	MGL	1957
2	20	0.1	KNO3	lgK:3.51 (3SF)	6	MGL	1956
3	25	0.1	KNO3	lgK:3.4 (0.5MD)	5	MGL	6935
4	25	0.5	Me4NCl	lgK:3.53 (3SF)	0	MGL	4556

Reaction No. 14080							
EDDS-4 + Ca+2 = Ca+2_EDDS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.72 (3SF)	0	MGL	2006
2	25	0	Inf. Dilution	lgK:6.34 (3SF)	2	CRV	29666
3	25	0.097	NaCl	lgK:5.13 (0.01SD)	4	MGL	29124
4	25	0.1	KNO3	lgK:4.2 (0.04SD)	0	MGL	999
5	25	0.1	Unknown	lgK:4.6 (0.2SD)	2	CRV	552
6	25	0.1	Unknown	lgK:5.13 (3SF)	4	CRV	31120
7	25	0.15	Cl-1 salt	lgK:5.04 (3SF)	3	MGL	17919
8	25	0.3	NaCl	lgK:4.12 (0.012SD)	0	EOD	29124
9	25	0.494	NaCl	lgK:4.23 (0.01SD)	4	MGL	29124
10	25	0.5	KNO3	lgK:4.4 (0.03SD)	2	MGL	3832
11	25	0.89	NaCl	lgK:3.74 (0.07SD)	4	MGL	29124
12	15	0.5	KNO3	dH:0.0 (1SF)	3	MTD	3832


13	25	0.1	Unknown	dH:0.0 (1SF) kJ	4	CRV	31120
14	25	0.5	KNO3	dH:0.717 (3SF)	3	MTD	3832
15	35	0.5	KNO3	dH:1.393 (4SF)	2	MTD	3832

Reaction No. 14081




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:1.65 (3SF)	0	MGL	2006
2	20	0.1	Unknown	lgK:1.7 (2SF)	0	CRV	552
3	25	0.097	NaCl	lgK:3.38 (0.015SD)	4	MGL	29124
4	25	0.1	KNO3	lgK:2.5 (0.05SD)	0	MGL	999
5	25	0.1	Unknown	lgK:1.4 (2SF)	0	CRV	552
6	25	0.3	NaCl	lgK:1.24 (0.2SD)	0	EOD	29124
7	25	0.494	NaCl	lgK:2.89 (0.01SD)	4	MGL	29124
8	25	0.5	KNO3	lgK:1.0 (0.08SD)	0	MGL	3832
9	25	0.5	Unknown	lgK:1.1 (2SF)	0	CRV	552
10	25	0.89	NaCl	lgK:2.57 (0.075SD)	4	MGL	29124

Reaction No. 14082



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.0 (0.06SD)	4	MGL	999

Reaction No. 14182



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Pr4N+ salt	lgK:1.4 (2SF)	0	MGL	6175
2	10	0.04	Pr4N+ salt	lgK:0.9 (1SF)	0	MGL	6175
3	10	0.16	Pr4N+ salt	lgK:0.7 (1SF)	0	MGL	6175
4	10	0.25	Pr4N+ salt	lgK:0.6 (1SF)	0	MGL	6175
5	10	0.49	Pr4N+ salt	lgK:0.7 (1SF)	0	MGL	6175
6	10	1	Pr4N+ salt	lgK:0.8 (1SF)	0	MGL	6175
7	25	0	Inf. Dilution	lgK:3.04 (3SF)	2	MPT	999
8	25	0	Na+1 salt	lgK:2.36 (3SF)	2	MIS	1266
9	25	0	Na+1 salt	lgK:2.89 (3SF)	2	MIS	1266
10	25	0	Na+1 salt	lgK:2.51 (3SF)	0	MGL	1437
11	25	0	Na+1 salt	lgK:3.04 (3SF)	2	MGL	1437

12	25	0	Pr4N+ salt	lgK:1.2 (2SF)	0	MGL	6175
13	25	0.005	NaNO3	lgK:2.9 (0.04SD)	2	MIS	1266
14	25	0.04	Pr4N+ salt	lgK:0.7 (1SF)	0	MGL	6175
15	25	0.16	Pr4N+ salt	lgK:0.58 (2SF)	0	MGL	6175
16	25	0.25	Pr4N+ salt	lgK:0.51 (2SF)	0	MGL	6175
17	25	0.49	Pr4N+ salt	lgK:0.6 (1SF)	0	MGL	6175
18	25	0.5	Na+1 salt	lgK:0.82 (2SF)	0	MGL	956
19	25	1	Pr4N+ salt	lgK:0.7 (1SF)	0	MGL	6175
20	35	0	Pr4N+ salt	lgK:1.3 (2SF)	0	MGL	6175
21	35	0.04	Pr4N+ salt	lgK:0.7 (1SF)	0	MGL	6175
22	35	0.16	Pr4N+ salt	lgK:0.5 (1SF)	0	MGL	6175
23	35	0.25	Pr4N+ salt	lgK:0.5 (1SF)	0	MGL	6175
24	35	0.49	Pr4N+ salt	lgK:0.6 (1SF)	0	MGL	6175
25	35	1	Pr4N+ salt	lgK:0.9 (1SF)	0	MGL	6175
26	45	0	Pr4N+ salt	lgK:1.4 (2SF)	0	MGL	6175
27	45	0.04	Pr4N+ salt	lgK:0.8 (1SF)	0	MGL	6175
28	45	0.16	Pr4N+ salt	lgK:0.6 (1SF)	0	MGL	6175
29	45	0.25	Pr4N+ salt	lgK:0.6 (1SF)	0	MGL	6175
30	45	0.49	Pr4N+ salt	lgK:0.7 (1SF)	0	MGL	6175
31	45	1	Pr4N+ salt	lgK:1.0 (2SF)	0	MGL	6175

Reaction No. 14190							
Ca+2 + H+1_5ATP-4 = Ca+2_H+1_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:2.34 (0.02SD)	5	MGL	3482
2	10	0	Pr4N+ salt	lgK:3.0 (2SF)	4	MGL	1437
3	10	0.04	Pr4N+ salt	lgK:2.1 (2SF)	4	MGL	1437
4	10	0.16	Pr4N+ salt	lgK:1.8 (2SF)	4	MGL	1437
5	10	0.25	Pr4N+ salt	lgK:1.8 (2SF)	4	MGL	1437
6	10	0.49	Pr4N+ salt	lgK:1.8 (2SF)	4	MGL	1437
7	10	1	Pr4N+ salt	lgK:1.9 (2SF)	4	MGL	1437
8	12	0.1	KNO3	lgK:2.21 (0.02SD)	5	MGL	3482
9	20	0.1	KCl	lgK:1.8 (2SF)	4	MGL	280
10	25	0	Pr4N+ salt	lgK:2.6 (2SF)	4	MGL	1437
11	25	0	Pr4NC1	lgK:3.90 (3SF)	4	MGL	259
12	25	0.02	Unknown	lgK:1. (0.4SD)	4	MRM	906

13	25	0.04	Pr4N+ salt	lgK:1.81 (3SF)	4	MGL	1437
14	25	0.1	KNO3	lgK:1.78 (3SF)	4	MGL	1437
15	25	0.1	KNO3	lgK:2.13 (0.02SD)	5	MGL	3482
16	25	0.1	Me4N+ salt	lgK:2.2 (0.07SD)	8	CIU	1437
17	25	0.1	Me4NCl	lgK:1.45 (3SF)	3	MSC	1437
18	25	0.1	NaClO4	lgK:2.20 (0.025SD)	4	MGL	1369
19	25	0.1	NaClO4	lgK:2.20 (3SF)	4	MGL	1437
20	25	0.1	NaClO4	lgK:2.04 (3SF)	4	MGL	1437
21	25	0.1	NaClO4	lgK:2.31 (3SF)	4	MGL	1437
22	25	0.16	Pr4N+ salt	lgK:1.51 (3SF)	4	MGL	1437
23	25	0.2	Me4NCl	lgK:1.08 (3SF)	4	MGL	1437
24	25	0.2	Pr4NCl	lgK:1.613 (4SF)	5	MGL	257
25	25	0.25	Pr4N+ salt	lgK:1.47 (3SF)	4	MGL	1437
26	25	0.49	Pr4N+ salt	lgK:1.5 (2SF)	4	MGL	1437
27	25	0.5	Inert	lgK:1.9 (0.1SD)	3	CMN	1437
28	25	0.5	Na+1 salt	lgK:1.93 (3SF)	4	MGL	956
29	25	1	Pr4N+ salt	lgK:1.8 (2SF)	4	MGL	1437
30	35	0	Pr4N+ salt	lgK:2.6 (2SF)	4	MGL	1437
31	35	0.04	Pr4N+ salt	lgK:1.8 (2SF)	4	MGL	1437
32	35	0.1	KNO3	lgK:2.16 (3SF)	4	MGL	1437
33	35	0.16	Pr4N+ salt	lgK:1.51 (3SF)	4	MGL	1437
34	35	0.25	Pr4N+ salt	lgK:1.48 (3SF)	4	MGL	1437
35	35	0.49	Pr4N+ salt	lgK:1.6 (2SF)	4	MGL	1437
36	35	1	Pr4N+ salt	lgK:1.9 (2SF)	4	MGL	1437
37	37	0.15	Na+1 salt	lgK:2.2 (0.07SD)	7	CIU	1437
38	40	0.1	KNO3	lgK:2.13 (0.02SD)	4	MGL	3482
39	45	0	Pr4N+ salt	lgK:2.7 (2SF)	4	MGL	1437
40	45	0.04	Pr4N+ salt	lgK:2.0 (2SF)	4	MGL	1437
41	45	0.16	Pr4N+ salt	lgK:1.7 (2SF)	4	MGL	1437
42	45	0.25	Pr4N+ salt	lgK:1.7 (2SF)	4	MGL	1437
43	45	0.49	Pr4N+ salt	lgK:1.8 (2SF)	4	MGL	1437
44	45	1	Pr4N+ salt	lgK:2.2 (2SF)	4	MGL	1437
45	10:45	0.25	Pr4N+ salt	dH:-3.1 (2SF)	4	MTD	1437
46	25	0.1	Inert	dH:7.9 (4.SD) kJ	5	CIU	1437
47	25	0.1	KNO3	dH:-0.3 (0.2SD)	0	MCL	3482
48	25	0.1	NaClO4	dH:1.9 (2SF)	4	MTD	1437

Reaction No. 14225							
2Thenoic-1 + Ca+2 = Ca+2_2Thenoic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.33(3SF)	6	MGL	999

Reaction No. 14329							
TriMDTA-4 + Ca+2 = Ca+2_TriMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:7.12(3SF)	6	MHY	1957
2	20	0.1	KNO3	lgK:7.28(3SF)	6	MGL	1956
3	25	0.1	Unknown	lgK:7.26(3SF)	6	CRV	552
4	20	0.1	KNO3	dH:-1.74(3SF)	5	MCL	1956
5	25	0.1	NaNO3	dH:-1.74(3SF)	5	MCL	1379
6	25	0.1	Unknown	dH:-1.7(2SF)	7	MCL	1384

Reaction No. 14330							
Ca+2 + H+1_TriMDTA-4 = Ca+2_H+1_TriMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.07(3SF)	6	MGL	1957
2	20	0.1	KNO3	lgK:3.16(3SF)	6	MGL	1956

Reaction No. 14426							
2OHTriMDTA-4 + Ca+2 = Ca+2_2OHTriMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:6.90(3SF)	6	MGL	999
2	20	0.1	KNO3	lgK:5.5(2SF)	0	MSC	999
Note (2): Low wgt for internal consistency							
3	23			lgK:6.69(3SF)	0	MSP	3977
4	25	0.1	KNO3	lgK:6.69(0.02SD)	6	MGL	999
5	30	0.1	KCl	lgK:6.52(3SF)	6	MGL	2019

Reaction No. 14427							
Ca+2_2OHTriMDTA-4 + H+1 = Ca+2_H+1_2OHTriMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:6.5(0.04SD)	4	MGL	999

Reaction No. 14449							
Ca+2 + H+1_2OHTriMDTA-4 = Ca+2_H+1_2OHTriMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.20 (3SF)	6	MGL	999

Reaction No. 14488							
dlBDTA-4 + Ca+2 = Ca+2_dlBDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:11.49 (4SF)	0	MGL	1947
2	20	0.1	KCl	lgK:12.34 (4SF)	6	MGL	2000
3	25	0.1	KCl	lgK:12.37 (0.02SD)	6	MGL	128
4	25	0.5	Me4NCl	lgK:13.08 (4SF)	0	MGL	4556

Reaction No. 14547							
mBDTA-4 + Ca+2 = Ca+2_mBDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:9.60 (3SF)	6	MGL	999
2	20	0.1	KCl	lgK:9.67 (3SF)	6	MGL	2000

Reaction No. 14548							
Ca+2 + H+1_mBDTA-4 = Ca+2_H+1_mBDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.76 (3SF)	6	MGL	2000

Reaction No. 14562							
EDDG-4 + Ca+2 = Ca+2_EDDG-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:2.70 (3SF)	6	CRV	552
2	25	0.1	KNO3	lgK:2.6 (0.08SD)	4	MGL	999

Reaction No. 14563							
Ca+2 + H+1_EDDG-4 = Ca+2_H+1_EDDG-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:1.0 (2SF)	6	CRV	552
2	25	0.1	KNO3	lgK:1.6 (0.05SD)	3	MGL	999

Reaction No. 14564							
--------------------	--	--	--	--	--	--	--

Ca+2_EDDG-4 + Ca+2 = Ca+2(2)_EDDG-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.9(0.08SD)	4	MGL	999

Reaction No. 14610							
Pyrid2Azo4DiMeAniline + Ca+2 = Ca+2_Pyrid2Azo4DiMeAniline							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaNO3	lgK:0.0(1SF)	4	MSP	5703

Reaction No. 14748							
Ca+2_DTPA-5 + DTPA-5 = Ca+2_DTPA-5(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.6(2SF)	4	MGL	999
2	37	0.15	NaCl	lgK:2.13(3SF)	5	MGL	1940

Reaction No. 14797							
4NitrPhenOPO3-2 + Ca+2 = Ca+2_4NitrPhenOPO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Unknown	lgK:0.88(2SF)	0	ENS	1249
2	25	0.1	NaNO3	lgK:1.26(0.04MD)	4	MGL	1345

Reaction No. 14802							
NaphOPO3-2 + Ca+2 = Ca+2_NaphOPO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:1.22(0.006SD)	6	MGL	1249

Reaction No. 14808							
PhenOPO3-2 + Ca+2 = Ca+2_PhenOPO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.45(0.01MD)	6	MGL	1345
2	25	0.15	NaCl	lgK:1.4(0.03SD)	3	MGL	1249

Reaction No. 14815							
1GlucoseOPO3-2 + Ca+2 = Ca+2_1GlucoseOPO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.495(4SF)	6	ENS	1249
2	25	0.15	NaCl	lgK:1.77(0.007SD)	6	MGL	1249

Reaction No. 14827							
MeOPO3-2 + Ca+2 = Ca+2_MeOPO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Cl-1 salt	lgK:1.49(3SF)	6	MGL	1249
2	20	0.1	Unknown	lgK:1.49(3SF)	6	MGL	1345
3	25	0.15	NaCl	lgK:1.39(0.009SD)	6	MGL	1249
4	65	0.1	Unknown	lgK:1.74(3SF)	5	MSP	931

Reaction No. 14828							
MeOPO3-2 + Ca+2 = H+1 + Ca+2_H+1(-1)_MeOPO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:-7.09(0.02SD)	4	MGL	1249

Reaction No. 14871							
HexMDTA-4 + Ca+2 = Ca+2_HexMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.40(3SF)	6	MGL	1957
2	20	0.1	KNO3	lgK:4.6(2SF)	4	MGL	1956
3	25	0.1	KNO3	lgK:4.2(0.07SD)	4	MGL	999


Reaction No. 14872							
Ca+2 + H+1_HexMDTA-4 = Ca+2_H+1_HexMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.7(2SF)	4	MGL	1957
2	20	0.1	KNO3	lgK:3.7(2SF)	4	MGL	1956
3	25	0.1	KNO3	lgK:3.3(0.06SD)	4	MGL	999

Reaction No. 14873							
2<Ca+2> + HexMDTA-4 = Ca+2(2)_HexMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.7(0.08SD)	4	MGL	999

Reaction No. 14914							
Ca+2 + H+1_EGTA-4 = Ca+2_H+1_EGTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.33(3SF)	6	MHY	1957
2	20	0.1	KCl	lgK:5.430(4SF)	5	MGL	3584

3	20	0.1	KNO3	lgK:5.3 (2SF)	4	MGL	1956
4	20	0.1	Unknown	lgK:5.20 (3SF)	6	ENS	1539
5	25	0	Inf. Dilution	lgK:5.4 (2SF)	1	ESC	


Reaction No. 14985



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.76 (3SF)	6	MGL	999
2	30	0.1	KCl	lgK:2.4 (2SF)	0	MGL	999


Note (2): Low wgt for internal consistency

Reaction No. 14986




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:8.23 (3SF)	6	MGL	999
2	30	0.1	KCl	lgK:8.07 (3SF)	6	MGL	999

Reaction No. 14989




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:14.2 (3SF)	4	MGL	999

Reaction No. 15056




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:48.9 (0.08SD)	3	MGL	1348

Reaction No. 15057



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:39.9 (0.06SD)	3	MGL	1348

Reaction No. 15058



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:30.1 (0.04SD)	3	MGL	1348

Reaction No. 15059

343LICAMS-12 + 2<Ca+2> = Ca+2(2)_343LICAMS-12							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:16.2(0.2SD)	4	MGL	1348

Reaction No. 15131							
Ca+2 + DHEAMP = Ca+2_DHEAMP							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:1.0(0.1SD)	6	MGL	1350

Reaction No. 15141							
Ca+2 + [18]N2O4:DiPyrid = Ca+2_[18]N2O4:DiPyrid							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:3.63(0.02SD)	6	MGL	1350

Reaction No. 15253							
NTMP-6 + Ca+2 = Ca+2_NTMP-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:7.86(0.02SD)	5	MGL	1338
2	25	1	KNO3	lgK:6.7(0.1SD)	4	MGL	931
3	25	1	Unknown	lgK:6.68(3SF)	5	ENS	773
4	25	0.1	KNO3	dH:-0.14(2SF)	5	MCL	2876

Reaction No. 15254							
Ca+2_NTMP-6 + H+1 = Ca+2_H+1_NTMP-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:8.80(0.02SD)	5	MGL	1338
2	25	1	Unknown	lgK:8.5(2SF)	4	ENS	773
3	25	0.1	KNO3	dH:-4.71(3SF)	5	MCL	2876

Reaction No. 15255							
Ca+2_H+1_NTMP-6 + H+1 = Ca+2_H+1(2)_NTMP-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:6.1(0.04SD)	4	MGL	1338
2	25	1	Unknown	lgK:6.1(2SF)	4	ENS	773
3	25	0.1	KNO3	dH:1.19(3SF)	5	MCL	2876

Reaction No. 15256							
--------------------	--	--	--	--	--	--	--

Ca+2_H+1(2)_NTMP-6 + H+1 = Ca+2_H+1(3)_NTMP-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.9(0.1SD)	4	MGL	1338
2	25	1	Unknown	lgK:4.9(2SF)	4	ENS	773

Reaction No. 15500							
[9]N3:Acet*3-3 + Ca+2 = Ca+2_[9]N3:Acet*3-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	Unknown	lgK:9.01(0.01SD)	4	MGL	1379
2	25	0.05	Unknown	lgK:10.82(4SF)	0	ENS	1354
3	25	0.1	Me4NCl	lgK:8.92(3SF)	6	MSP	1207
4	25	0.1	NaNO3	lgK:8.92(3SF)	6	ENS	1823
5	25	0.1	NaNO3	lgK:8.8(0.03SD)	5	MGL	2031
6	25	0.1	NaNO3	lgK:8.92(0.01SD)	5	CRV	13242
7	25	0.1	Unknown	lgK:8.81(3SF)	5	ENS	1354
8	35	0.1	NaNO3	lgK:8.74(0.01SD)	5	CRV	13242
9	35	0.1	Unknown	lgK:8.74(0.01SD)	4	MGL	1379
10	45	0.1	Unknown	lgK:8.61(0.01SD)	4	MGL	1379
11	55	0.1	Unknown	lgK:8.49(0.01SD)	4	MGL	1379
12	10:60	0.1	Unknown	dH:-6.(1SF)	6	CRV	552
13	25	0.1	NaNO3	dH:-6.(0.3SD)	6	MCL	1379

Reaction No. 15537							
Tetracycline-2 + 2<Ca+2> = Ca+2(2)_Tetracycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:8.671(4SF)	6	MGL	1337

Reaction No. 15538							
2<Tetracycline-2> + Ca+2 = Ca+2_Tetracycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:8.731(4SF)	6	MGL	1337

Reaction No. 15539							
H+1 + 2<Tetracycline-2> + Ca+2 = Ca+2_H+1_Tetracycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:17.618(5SF)	6	MGL	1337

Reaction No. 15540							
$2\text{<H+1>} + 2\text{<Tetracycline-2>} + \text{Ca+2} = \text{Ca+2_H+1(2)_Tetracycline-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:25.540 (5SF)	6	MGL	1337

Reaction No. 15549							
$\text{OxTetracycline-2} + \text{Ca+2} = \text{Ca+2_OxTetracycline-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:4.462 (4SF)	6	MGL	1337

Reaction No. 15550							
$\text{OxTetracycline-2} + 2\text{<Ca+2>} = \text{Ca+2(2)_OxTetracycline-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:7.884 (4SF)	6	MGL	1337

Reaction No. 15551							
$2\text{<OxTetracycline-2>} + \text{Ca+2} = \text{Ca+2_OxTetracycline-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:8.385 (4SF)	6	MGL	1337

Reaction No. 15552							
$\text{H+1} + 2\text{<OxTetracycline-2>} + \text{Ca+2} = \text{Ca+2_H+1_OxTetracycline-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:16.654 (5SF)	6	MGL	1337


Reaction No. 15553							
$2\text{<H+1>} + 2\text{<OxTetracycline-2>} + \text{Ca+2} = \text{Ca+2_H+1(2)_OxTetracycline-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:24.625 (5SF)	6	MGL	1337

Reaction No. 15563							
$\text{Doxycycline-2} + \text{Ca+2} = \text{Ca+2_Doxycycline-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:5.600 (4SF)	6	MGL	1337

Reaction No. 15564							
$\text{Doxycycline-2} + 2\text{<Ca+2>} = \text{Ca+2(2)_Doxycycline-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	37	0.15	NaCl	lgK:8.885 (4SF)	6	MGL	1337
---	----	------	------	-----------------	---	-----	------

Reaction No. 15565




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:13.058 (5SF)	6	MGL	1337

Reaction No. 15566




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:25.263 (5SF)	6	MGL	1337

Reaction No. 15574




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:17.984 (5SF)	6	MGL	1337

Reaction No. 15575




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:25.230 (5SF)	6	MGL	1337

Reaction No. 15623




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.1 (2SF)	1	ELC	
2	25	0.1	KCl	lgK:1.94 (3SF)	0	MGL	1257

Reaction No. 15635



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.62 (3SF)	6	MGL	1257

Reaction No. 15636



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.65 (3SF)	6	MGL	1257

Reaction No. 15659							
Ca+2 + DiTartronic-4 = Ca+2_DiTartronic-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.17 (3SF)	6	MGL	1257

Reaction No. 15660							
Ca+2_DiTartronic-4 + H+1 = Ca+2_H+1_DiTartronic-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.23 (3SF)	6	MGL	1257

Reaction No. 15988							
Ca+2 + TMS-4 = Ca+2_TMS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.20 (3SF)	6	MGL	1217

Reaction No. 15989							
Ca+2_TMS-4 + H+1 = Ca+2_H+1_TMS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.42 (3SF)	6	MGL	1217

Reaction No. 15990							
Ca+2_H+1_TMS-4 + H+1 = Ca+2_H+1(2)_TMS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.96 (3SF)	6	MGL	1217


Reaction No. 16011							
Ca+2 + TDS-6 = Ca+2_TDS-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:6.86 (3SF)	6	MGL	1217

Reaction No. 16012							
Ca+2_TDS-6 + H+1 = Ca+2_H+1_TDS-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.33 (3SF)	6	MGL	1217

Reaction No. 16013							
Ca+2_H+1_TDS-6 + H+1 = Ca+2_H+1(2)_TDS-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0.1	KCl	lgK:4.31 (3SF)	6	MGL	1217
---	----	-----	-----	----------------	---	-----	------

Reaction No. 16014




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.91 (3SF)	6	MGL	1217

Reaction No. 16015




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.36 (3SF)	6	MGL	1217

Reaction No. 16016




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.63 (3SF)	6	MGL	1217

Reaction No. 16095



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.7 (0.2SD)	5	MGL	1716
2	25	0	Inert	lgK:4.39 (3SF)	6	MGL	1306
3	25	0.1	Inert	lgK:3.08 (3SF)	6	MGL	1306
4	25	0.25	Inert	lgK:3.05 (3SF)	6	MGL	1306
5	25	0.5	Inert	lgK:3.36 (3SF)	6	MGL	1306
6	25	0.75	Inert	lgK:3.77 (3SF)	6	MGL	1306
7	25	1	Inert	lgK:4.16 (0.04MD)	4	MGL	1306

Reaction No. 16096



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inert	lgK:9.23 (3SF)	6	MGL	1306
2	25	0.1	Inert	lgK:7.56 (3SF)	6	MGL	1306
3	25	0.25	Inert	lgK:7.47 (3SF)	6	MGL	1306
4	25	0.5	Inert	lgK:7.79 (3SF)	6	MGL	1306
5	25	0.75	Inert	lgK:8.21 (3SF)	6	MGL	1306
6	25	1	Inert	lgK:8.63 (0.03MD)	6	MGL	1306

Reaction No. 16097							
$2\text{<H+1>} + 1245\text{BenzTetrCOO-4} + \text{Ca+2} = \text{Ca+2_H+1(2)_1245BenzTetrCOO-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inert	lgK:12.5(3SF)	4	MGL	1306
2	25	0.1	Inert	lgK:10.7(3SF)	4	MGL	1306
3	25	0.25	Inert	lgK:10.6(3SF)	4	MGL	1306
4	25	0.5	Inert	lgK:11.0(3SF)	4	MGL	1306
5	25	0.75	Inert	lgK:11.5(3SF)	4	MGL	1306
6	25	1	Inert	lgK:12.00(0.04MD)	4	MGL	1306

Reaction No. 16098							
$1245\text{BenzTetrCOO-4} + 2\text{<Ca+2>} = \text{Ca+2(2)_1245BenzTetrCOO-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inert	lgK:8.05(3SF)	6	MGL	1306
2	25	0.1	Inert	lgK:5.96(3SF)	6	MGL	1306
3	25	0.25	Inert	lgK:5.73(3SF)	6	MGL	1306
4	25	0.5	Inert	lgK:5.89(3SF)	6	MGL	1306
5	25	0.75	Inert	lgK:6.19(3SF)	6	MGL	1306
6	25	1	Inert	lgK:6.5(0.07MD)	6	MGL	1306


Reaction No. 16102							
$\text{ICRF198-2} + \text{Ca+2} = \text{Ca+2_ICRF198-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.1(2SF)	1	ESC	
2	37	0.15	NaCl	lgK:6.89(0.004SD)	6	MGL	97

Reaction No. 16103							
$\text{H+1} + \text{ICRF198-2} + \text{Ca+2} = \text{Ca+2_H+1_ICRF198-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.9(2SF)	1	ESC	
2	37	0.15	NaCl	lgK:9.69(0.02SD)	6	MGL	97

Reaction No. 16104							
$2\text{<ICRF198-2>} + \text{Ca+2} = \text{Ca+2_ICRF198-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.4(2SF)	1	ESC	

2	37	0.15	NaCl	lgK:8.2(0.07SD)	4	MGL	97
---	----	------	------	-----------------	---	-----	----

Reaction No. 16124




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.9(2SF)	1	ESC	
2	37	0.15	NaCl	lgK:6.68(0.009SD)	6	MGL	97

Reaction No. 16125




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-4.5(2SF)	1	ESC	
2	37	0.15	NaCl	lgK:-4.5(0.03SD)	6	MGL	97

Reaction No. 16194



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:6.3(0.04SD)	0	MPT	906
2	20	0.1	NH4Cl	lgK:6.09(0.02SD)	0	MCG	906
3	25	0	Inf. Dilution	lgK:12.1(3SF)	1	ELC	
4	25	0.1	KNO3	lgK:9.36(3SF)	2	MGL	1237
5	25	0.1	KNO3	lgK:6.34(3SF)	0	MGL	1595
6	25	0.1	KNO3	lgK:6.93(3SF)	0	MMX	2780
7	25	0.15	NaCl	lgK:8.71(0.05SD)	0	MSP	23315
8	37	0.15	NaCl	lgK:6.41(0.01SD)	0	MGL	4910
9	25	0.1	KNO3	dH:-5.7(0.6SD) kJ	5	MCL	2876

Reaction No. 16195



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:9.42(3SF)	5	MGL	1237
2	25	0.1	KNO3	lgK:10.33(4SF)	0	MMX	2780
3	25	0.1	KNO3	lgK:9.45(0.01SD)	5	MGL	2876
4	25	0.15	NaCl	lgK:8.41(0.02SD)	0	MSP	23315
5	37	0.15	NaCl	lgK:8.94(0.01SD)	3	MGL	4910
6	25	0.1	KNO3	dH:-8.1(0.4SD) kJ	5	MCL	2876

Reaction No. 16196							
Ca+2_H+1_EDTMP-8 + H+1 = Ca+2_H+1(2)_EDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:8.44 (3SF)	5	MGL	1237
2	25	0.1	KNO3	lgK:9.59 (3SF)	0	MMX	2780
3	25	0.1	KNO3	lgK:8.24 (0.01SD)	5	MGL	2876
4	25	0.15	NaCl	lgK:7.36 (0.02SD)	0	MSP	23315
5	37	0.15	NaCl	lgK:8.06 (0.02SD)	5	MGL	4910
6	25	0.1	KNO3	dH:-7.9 (0.4SD) kJ	5	MCL	2876

Reaction No. 16197							
Ca+2_H+1(2)_EDTMP-8 + H+1 = Ca+2_H+1(3)_EDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:6.59 (3SF)	5	MGL	1237
2	25	0.1	KNO3	lgK:7.50 (3SF)	0	MMX	2780
3	25	0.1	KNO3	lgK:6.7 (0.04SD)	5	MGL	2876
4	25	0.15	NaCl	lgK:7.31 (0.03SD)	0	MSP	23315
5	25	0.1	KNO3	dH:-7.7 (0.3SD) kJ	5	MCL	2876

Reaction No. 16198							
Ca+2_H+1(3)_EDTMP-8 + H+1 = Ca+2_H+1(4)_EDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.25 (3SF)	5	MGL	1237
2	25	0.1	KNO3	lgK:6.78 (3SF)	0	MMX	2780
Note (2): Low wgt for internal consistency							
3	25	0.1	KNO3	lgK:5.5 (0.1SD)	5	MGL	2876
4	25	0.1	KNO3	dH:-1.8 (0.5SD) kJ	5	MCL	2876

Reaction No. 16329							
Ca+2 + BIM = Ca+2_BIM							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.2	KNO3	lgK:1.80 (0.02SD)	4	MGL	1258

Reaction No. 16500							
2<H+1> + 2<5ATP-4> + Ca+2 = Ca+2_H+1(2)_5ATP-4(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:17.6 (0.1SD)	5	MGL	1297

Reaction No. 16530							
Dec110DiPhos-4 + Ca+2 = Ca+2_Dec110DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NBr	lgK:0.5 (1SF)	3	MGL	4245

Reaction No. 16531							
Ca+2 + H+1_Dec110DiPhos-4 = Ca+2_H+1_Dec110DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NBr	lgK:1. (1SF)	3	MGL	4245

Reaction No. 16687							
[12]N3:Acet*3-3 + Ca+2 = Ca+2_[12]N3:Acet*3-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NCl	lgK:6.0 (2SF)	4	MSP	1207

Reaction No. 16826							
Ca+2 + H+1(-1)_3Am124Triazole = Ca+2_H+1(-1)_3Am124Triazole							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:1.1 (0.2MD)	3	MGL	1307
2	25	0	Inf. Dilution	lgK:1.1 (0.08MD)	3	MGL	1307
3	37	0	Inf. Dilution	lgK:1.0 (0.1MD)	6	MGL	1307
4	45	0	Inf. Dilution	lgK:1. (0.2MD)	4	MGL	1307

Reaction No. 16827							
Ca+2 + 3Am124Triazole = Ca+2_3Am124Triazole							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:-0.3 (0.2MD)	4	MGL	1307
2	25	0	Inf. Dilution	lgK:-0.3 (0.2MD)	4	MGL	1307
3	37	0	Inf. Dilution	lgK:-0.5 (0.3MD)	4	MGL	1307
4	45	0	Inf. Dilution	lgK:-0.5 (0.3MD)	4	MGL	1307

Reaction No. 16829							
Ca+2 + Pyridine = Ca+2_Pyridine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.48 (2SF)	6	ENS	1307

Reaction No. 16831							
--------------------	--	--	--	--	--	--	--

Ca+2 + Imidazole = Ca+2_Imidazole							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.2(1SF)	4	ENS	1307
2	25	0.16	Unknown	lgK:0.08(1SF)	4	MIX	108

Reaction No. 16888							
PhenEDTA-4 + Ca+2 = Ca+2_PhenEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:11.3(0.03SD)	4	MGL	2010
2	25	0.1	KCl	lgK:10.9(0.03SD)	4	MGL	999

Reaction No. 16903							
mDiPhenEDTA-4 + Ca+2 = Ca+2_mDiPhenEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.67(0.02SD)	6	MGL	1274


Reaction No. 16917							
DiPhenEDTA-4 + Ca+2 = Ca+2_DiPhenEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:12.09(0.02SD)	4	MGL	1274
2	25	0.1	Unknown	lgK:12.11(4SF)	6	CRV	552

Reaction No. 16966							
Ca+2_5ATP-4 + 5ATP-4 = Ca+2_5ATP-4(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.005	NaNO3	lgK:2.3(0.05SD)	0	MIS	1266
2	25	0.25	Pr4N+ salt	lgK:0.5(1SF)	2	EOR	3595

Reaction No. 17049							
5GTP-4 + Ca+2 = Ca+2_5GTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.1	NaCl	lgK:3.58(3SF)	4	MIX	1437
2	25	0.1	KNO3	lgK:4.9(0.06SD)	0	MGL	1972
3	25	0.1	Me4N+ salt	lgK:4.1(0.07SD)	7	CIU	1437
4	25	0.1	NaClO4	lgK:3.73(0.02MD)	5	MGL	2648
5	35	0.1	KNO3	lgK:5.0(0.06SD)	0	MGL	1972
6	45	0.1	KNO3	lgK:4.8(0.06SD)	0	MGL	1972


7	25:45	0.1	KNO3	dH:-1.6(0.1SD)	3	MTD	1972
---	-------	-----	------	----------------	---	-----	------

Reaction No. 17057




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.1	NaCl	lgK:3.76(3SF)	4	MIX	1437
2	25	0.1	KNO3	lgK:3.4(0.06SD)	6	MGL	1972
3	25	0.1	Me4N+ salt	lgK:4.1(0.07SD)	7	CIU	1437
4	25	0.1	NaClO4	lgK:3.73(0.01MD)	5	MGL	2648
5	35	0.1	KNO3	lgK:3.6(0.06SD)	4	MGL	1972
6	45	0.1	KNO3	lgK:3.4(0.06SD)	6	MGL	1972
7	25:45	0.1	KNO3	dH:-1.1(0.1SD)	6	MTD	1972

Reaction No. 17066



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.1	NaCl	lgK:3.81(3SF)	4	MIX	1437
2	25	0.1	KNO3	lgK:5.42(3SF)	0	MGL	1437
3	25	0.1	KNO3	lgK:4.16(3SF)	4	MGL	1437
4	25	0.1	Me4N+ salt	lgK:4.1(0.07SD)	7	CIU	1437
5	25	0.1	NaClO4	lgK:3.85(0.02SD)	4	MGL	1369
6	25	0.1	NaClO4	lgK:3.72(0.03MD)	4	MGL	2648
7	25	0.1	NaNO3	lgK:3.91(3SF)	0	MGL	1437
8	30	0.2	Me4NBr	lgK:4.14(3SF)	4	MCL	1971
9	35	0.1	KNO3	lgK:5.53(3SF)	0	MGL	1437
10	35	0.1	KNO3	lgK:4.1(0.06SD)	3	MGL	3186
11	45	0.1	KNO3	lgK:5.61(3SF)	0	MGL	1437
12	45	0.1	KNO3	lgK:4.03(3SF)	4	MGL	1437
13	25:45	0.1	KNO3	dH:-2.9(2SF)	4	MTD	1437

Reaction No. 17067



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:2.2(0.1SD)	7	CIU	1437
2	25	0.1	NaClO4	lgK:2.21(0.14SD)	4	MGL	1369
3	30	0.2	Me4NBr	lgK:2.46(3SF)	3	MCL	1437
4	35	0.1	KNO3	lgK:3.8(0.06SD)	0	MGL	3186

Note (4): Low wgt for internal consistency							
5	25:45	0.1	KNO3	dH:-3.1(2SF)	4	MTD	1437

Reaction No. 17083							
5UTP-4 + Ca+2 = Ca+2_5UTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.1	NaCl	lgK:3.71(3SF)	4	MIX	1437
2	25	0.1	KNO3	lgK:5.20(3SF)	0	MGL	1437
Note (2): Low wgt for internal consistency							
3	25	0.1	Me4N+ salt	lgK:4.1(0.07SD)	7	CIU	1437
4	25	0.1	NaClO4	lgK:3.94(0.01SD)	4	MGL	1369
5	25	0.1	NaClO4	lgK:3.78(3SF)	0	MGL	1437
6	25	0.1	NaClO4	lgK:3.66(0.01MD)	5	MGL	2648
7	25	0.1	NaNO3	lgK:3.85(3SF)	0	MGL	1437
8	35	0.1	KNO3	lgK:5.1(0.06SD)	0	MGL	3159
Note (8): Low wgt for internal consistency							
9	45	0.1	KNO3	lgK:5.01(3SF)	4	MGL	1437
10	25:45	0.1	KNO3	dH:-4.1(2SF)	0	MTD	1437

Reaction No. 17084							
Ca+2 + H+1_5UTP-4 = Ca+2_H+1_5UTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:2.7(0.1SD)	7	CIU	1437
2	25	0.1	NaClO4	lgK:2.74(0.045SD)	4	MGL	1369

Reaction No. 17096							
5TTP-4 + Ca+2 = Ca+2_5TTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:4.2(0.07SD)	7	CIU	1437
2	25	0.1	NaClO4	lgK:3.85(0.01SD)	6	MGL	1369
3	25	0.1	NaClO4	lgK:3.78(0.03MD)	5	MGL	2648

Reaction No. 17105							
5ADP-3 + Ca+2 = Ca+2_5ADP-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:2.91(0.02SD)	4	MGL	3481
2	12	0.1	KNO3	lgK:2.88(0.02SD)	5	MGL	3481

3	20	0.1	KCl	lgK:2.78 (3SF)	5	MGL	280
4	20	0.2	KCl	lgK:2.60 (3SF)	4	MIS	1437
5	22	0.25	KNO3	lgK:2.2 (2SF)	0	MGL	1437
6	23	0.06	Me4NC1	lgK:2.93 (3SF)	3	MSC	999
7	23	0.09	Me4NC1	lgK:2.93 (3SF)	4	MSC	1437
8	23	0.1	Na+1 salt	lgK:2.84 (3SF)	4	MIX	1437
9	23	0.1	NaCl	lgK:2.82 (3SF)	3	MIX	1437
10	23	0.1	NaCl	lgK:2.82 (3SF)	5	MIX	31154
11	23	0.14	Tris buffer	lgK:2.78 (3SF)	4	MSP	1437
12	25	0	Bu3EtNBr	lgK:3.70 (3SF)	4	MSP	1437
13	25	0	Na+1 salt	lgK:4.46 (3SF)	3	MIS	1437
14	25	0.1	KNO3	lgK:2.86 (0.02SD)	5	MGL	3481
15	25	0.1	Me4N+ salt	lgK:3.1 (0.08SD)	8	CIU	1437
16	25	0.1	NaClO4	lgK:2.90 (3SF)	6	MGL	1483
17	25	0.1	Unknown	lgK:2.86 (3SF)	6	MSP	999
18	25	0.11	Bu3EtNBr	lgK:2.890 (4SF)	5	MDG	2060
19	25	0.2	Me4NC1	lgK:2.65 (3SF)	4	MGL	257
20	25	0.2	Pr4NC1	lgK:2.807 (4SF)	5	MGL	257
21	30	0	NEtMorph buffer	lgK:4.15 (3SF)	4	MSP	1437
22	30	0.02	NEtMorph buffer	lgK:3.34 (3SF)	4	MSP	1437
23	37	0.1	Unknown	lgK:3.74 (3SF)	2	MIX	1437
24	37	0.15	Na+1 salt	lgK:2.9 (0.07SD)	8	CIU	1437
25	40	0.1	KNO3	lgK:2.80 (0.02SD)	4	MGL	3481
26	0:40	0.1	KNO3	dH:-1.2 (2SF)	0	MTD	1437
27	25	0.1	KNO3	dH:-1.2 (0.4SD)	0	MCL	3481
28	25	0.1	NaClO4	dH:13.80 (0.10SD) kJ	6	MCL	1483


Reaction No. 17106							
Ca+2 + H+1_5ADP-3 = Ca+2_H+1_5ADP-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:1.61 (0.02SD)	0	MGL	3481
2	12	0.1	KNO3	lgK:1.60 (0.02SD)	5	MGL	3481
3	23	0.06	Me4NC1	lgK:1.52 (3SF)	4	MSC	999
4	23	0.1	Me4NC1	lgK:1.36 (3SF)	0	MGL	1437
5	25	0	Inf. Dilution	lgK:2.3 (2SF)	1	EDH	
6	25	0.1	KNO3	lgK:1.6 (0.04SD)	5	MGL	3481

7	25	0.1	Me4N ⁺ salt	lgK:1.7 (0.1SD)	7	CIU	1437
8	25	0.1	NaClO ₄	lgK:0.59 (2SF)	0	MGL	1437
9	25	0.2	Me4NC1	lgK:1.20 (3SF)	4	MGL	257
10	25	0.2	Pr4NC1	lgK:1.518 (4SF)	5	MGL	257
11	37	0.15	Na+1 salt	lgK:1.5 (0.07SD)	7	CIU	1437
12	40	0.1	KNO ₃	lgK:1.54 (0.02SD)	5	MGL	3481
13	25	0.1	Inert	dH:6.3 (1.SD) kJ	5	CIU	1437
14	25	0.1	KNO ₃	dH:-0.6 (0.4SD)	0	MCL	3481
15	25	0.1	NaClO ₄	dH:1.5 (2SF)	4	MCL	1437

Reaction No. 17128							
5AMP-2 + Ca+2 = Ca+2_5AMP-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO ₃	lgK:1.88 (0.02SD)	4	MGL	3481
2	12	0.1	KNO ₃	lgK:1.87 (0.02SD)	5	MGL	3481
3	20	0.1	KCl	lgK:1.41 (3SF)	2	MGL	280
4	23	0	NaCl	lgK:2.59 (3SF)	4	MIX	1437
5	23	0.1	NaCl	lgK:1.76 (3SF)	6	MDS	1760
6	25	0	Inf. Dilution	lgK:2.6 (2SF)	1	EDH	
7	25	0	KNO ₃	lgK:2.68 (3SF)	4	MGL	1437
8	25	0	Na+1 salt	lgK:2.59 (3SF)	4	MIS	1437
9	25	0	Pr4NC1	lgK:2.42 (3SF)	3	MGL	257
10	25	0.1	KNO ₃	lgK:1.85 (0.02SD)	5	MGL	3481
11	25	0.1	Me4N ⁺ salt	lgK:1.9 (0.1SD)	8	CIU	1437
12	25	0.1	NaClO ₄	lgK:2.03 (3SF)	0	MGL	1483
13	25	0.1	NaClO ₄	lgK:2.03 (3SF)	0	MPT	1760
14	25	0.1	NaClO ₄	lgK:1.39 (3SF)	2	MGL	6055
15	25	0.1	NaNO ₃	lgK:1.46 (0.01SD)	2	MPT	1760
16	25	0.1	NaNO ₃	lgK:1.46 (0.05MD)	2	MGL	2906
17	25	0.2	Me4NC1	lgK:1.40 (3SF)	3	MGL	257
18	25	0.2	Pr4NC1	lgK:1.431 (4SF)	3	MGL	257
19	37	0.15	Na+1 salt	lgK:1.7 (0.1SD)	7	CIU	1437
20	40	0.1	KNO ₃	lgK:1.83 (0.02SD)	4	MGL	3481
21	0:40	0.1	KNO ₃	dH:-0.6 (1SF)	4	MTD	234
22	12:40	0.1	KNO ₃	dH:-0.6 (0.2SD)	0	MCL	3481
23	25	0.1	Inert	dH:4.2 (1.SD) kJ	5	CIU	1437


24	25	0.1	NaClO4	dH:4.23(0.10SD)kJ	6	MCL	1483
----	----	-----	--------	-------------------	---	-----	------

Reaction No. 17138




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:1.86(0.02SD)	4	MGL	3481
2	12	0.1	KNO3	lgK:1.84(0.02SD)	5	MGL	3481
3	25	0.1	KNO3	lgK:1.80(0.01SD)	5	MGL	3481
4	25	0.1	Me4N+ salt	lgK:1.8(0.1SD)	7	CIU	1437
5	25	0.1	NaNO3	lgK:1.36(0.02MD)	6	MGL	6104
6	40	0.1	KNO3	lgK:1.78(0.02SD)	4	MGL	3481
7	0:40	0.1	KNO3	dH:-0.6(1SF)	4	MTD	234
8	0:40	0.1	KNO3	dH:-0.6(0.2SD)	0	MCL	3481

Reaction No. 17149




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:1.87(0.02SD)	4	MGL	3481
2	12	0.1	KNO3	lgK:1.85(0.02SD)	5	MGL	3481
3	25	0.1	KNO3	lgK:1.83(0.02SD)	5	MGL	3481
4	25	0.1	Me4N+ salt	lgK:1.9(0.1SD)	7	CIU	1437
5	25	0.1	NaNO3	lgK:1.43(0.02MD)	6	MGL	6104
6	40	0.1	KNO3	lgK:1.81(0.02SD)	4	MGL	3481
7	0:40	0.1	KNO3	dH:-0.6(1SF)	4	MTD	234
8	0:40	0.1	KNO3	dH:-0.6(0.2SD)	0	MCL	3481

Reaction No. 17170



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:1.9(0.1SD)	7	CIU	1437
2	25	0.1	NaNO3	lgK:1.40(0.05MD)	6	MGL	1345

Reaction No. 17186



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:1.9(0.1SD)	7	CIU	1437
2	25	0.1	NaNO3	lgK:1.44(0.05MD)	6	MGL	1345

Reaction No. 17196							
5TMP-2 + Ca+2 = Ca+2_5TMP-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:1.9(0.1SD)	7	CIU	1437
2	25	0.1	NaNO3	lgK:1.40(0.06MD)	6	MGL	1345

Reaction No. 17382							
Ca+2_MIDA-2(2) + EDTA-4 = Ca+2_EDTA-4 + 2<MIDA-2>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Unknown	dG:-5.27(3SF)	0	MCL	1394
2	25	0	Unknown	dH:-4.62(3SF)	0	MCL	1394

Reaction No. 17410							
PO4EtAm-2 + Ca+2 = Ca+2_PO4EtAm-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Pr4NI	lgK:2.0(0.1SD)	3	MGL	999
2	25	0.15	KCl	lgK:1.57(3SF)	6	MGL	999
3	25	0.2	KNO3	lgK:1.5(0.05SD)	3	MGL	1370

Reaction No. 17411							
Ca+2 + H+1_PO4EtAm-2 = Ca+2_H+1_PO4EtAm-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Pr4NI	lgK:1.4(0.2SD)	4	MGL	999
2	25	0.15	KCl	lgK:1.11(3SF)	6	MGL	999
3	25	0.2	KNO3	lgK:1.2(0.08SD)	3	MGL	1370

Reaction No. 17446							
Ca+2 + H+1_PO4MeSer-3 = Ca+2_H+1_PO4MeSer-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:1.1(0.1SD)	3	MGL	1370

Reaction No. 17447							
Ca+2 + PO4MeSer-3 = Ca+2_PO4MeSer-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:1.8(0.04SD)	4	MGL	1370

Reaction No. 17464							
--------------------	--	--	--	--	--	--	--

Ca+2 + H+1_PO4Thr-3 = Ca+2_H+1_PO4Thr-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:1.5(0.05SD)	3	MGL	1370

Reaction No. 17465							
Ca+2 + PO4Thr-3 = Ca+2_PO4Thr-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:2.23(0.02SD)	4	MGL	1370

Reaction No. 17466							
Inositol126TriPhos-6 + Ca+2 = Ca+2_Inositol126TriPhos-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Bu4NBr	lgK:5.80(0.01SD)	6	MGL	963
2	37	0.2	KCl	lgK:4.06(0.01SD)	4	MGL	963

Reaction No. 17467							
H+1 + Inositol126TriPhos-6 + 2<Ca+2> = Ca+2(2)_H+1_Inositol126TriPhos-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.5(3SF)	1	ESC	
2	37	0.2	KCl	lgK:14.0(0.03SD)	4	MGL	963

Reaction No. 17468							
H+1 + Inositol126TriPhos-6 + Ca+2 = Ca+2_H+1_Inositol126TriPhos-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Bu4NBr	lgK:13.57(0.01SD)	6	MGL	963

Reaction No. 17469							
2<H+1> + Inositol126TriPhos-6 + Ca+2 = Ca+2_H+1(2)_Inositol126TriPhos-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Bu4NBr	lgK:19.3(0.06SD)	3	MGL	963

Reaction No. 17470							
2<H+1> + Inositol126TriPhos-6 + 2<Ca+2> = Ca+2(2)_H+1(2)_Inositol126TriPhos-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Bu4NBr	lgK:22.2(0.07SD)	4	MGL	963


Reaction No. 17471							
Inositol126TriPhos-6 + 3<Ca+2> = Ca+2(3)_Inositol126TriPhos-6							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Bu4NBr	lgK:11.6(0.09SD)	4	MGL	963

Reaction No. 17751							
Bipy + Ca+2 = Ca+2_Bipy							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0.2	Unknown	lgK:-0.25(2SF)	5	MGL	6125
2	5	0.5	Unknown	lgK:-0.31(2SF)	5	MGL	6125
3	5	0.75	Unknown	lgK:-0.35(2SF)	5	MGL	6125
4	10	0.25	Inert	lgK:0.09(1SF)	3	MGL	1520
5	15	0.2	Unknown	lgK:-0.13(2SF)	5	MGL	6125
6	15	0.5	Unknown	lgK:-0.14(2SF)	5	MGL	6125
7	15	0.75	Unknown	lgK:-0.15(2SF)	5	MGL	6125
8	25	0.2	Unknown	lgK:0.0(1SF)	5	MGL	6125
9	25	0.25	Inert	lgK:-0.05(1SF)	6	MGL	1520
10	25	0.5	Unknown	lgK:0.03(1SF)	5	MGL	6125
11	25	0.75	Unknown	lgK:0.05(1SF)	5	MGL	6125
12	35	0.2	Unknown	lgK:0.12(2SF)	5	MGL	6125
13	35	0.5	Unknown	lgK:0.19(2SF)	5	MGL	6125
14	35	0.75	Unknown	lgK:0.25(2SF)	5	MGL	6125
15	40	0.25	Inert	lgK:-0.19(2SF)	0	MGL	1520
16	45	0.2	Unknown	lgK:0.25(2SF)	5	MGL	6125
17	45	0.5	Unknown	lgK:0.36(2SF)	5	MGL	6125
18	45	0.75	Unknown	lgK:0.46(2SF)	5	MGL	6125
19	5	0.2	Unknown	dH:18.(2SF) kJ	3	MTD	6125
20	5	0.5	Unknown	dH:25.(2SF) kJ	5	MTD	6125
21	5	0.75	Unknown	dH:30.(2SF) kJ	5	MTD	6125
22	15	0.2	Unknown	dH:20.(2SF) kJ	3	MTD	6125
23	15	0.5	Unknown	dH:27.(2SF) kJ	5	MTD	6125
24	15	0.75	Unknown	dH:32.(2SF) kJ	3	MTD	6125
25	25	0.2	Unknown	dH:21.(2SF) kJ	3	MTD	6125
26	25	0.25	Inert	dH:-3.8(2SF)	0	MCL	1520
27	25	0.5	Unknown	dH:28.(2SF) kJ	5	MTD	6125
28	25	0.75	Unknown	dH:34.(2SF) kJ	3	MTD	6125
29	35	0.2	Unknown	dH:23.(2SF) kJ	5	MTD	6125
30	35	0.5	Unknown	dH:30.(2SF) kJ	5	MTD	6125


31	35	0.75	Unknown	dH:37. (2SF) kJ	3	MTD	6125
32	45	0.2	Unknown	dH:24. (2SF) kJ	5	MTD	6125
33	45	0.5	Unknown	dH:32. (2SF) kJ	5	MTD	6125
34	45	0.75	Unknown	dH:39. (2SF) kJ	3	MTD	6125
35	25		Acetone	lgK:2.0 (0.06SD)	4	MFL	2469
36	25	0.05	Ethanol:Water 95:5Wgt Et4NC1O4	lgK:1.97 (0.02SD)	4	MPS	2713
37	25		MeCN	lgK:2.7 (0.04SD)	4	MFL	2469
38	25		Methanol	lgK:1.7 (0.06SD)	4	MFL	2469

Reaction No. 17773




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.56 (0.01MD)	6	MGL	1345

Reaction No. 17783




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.48 (0.01MD)	6	MGL	1345

Reaction No. 18342




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.35 (3SF)	5	MIS	6882
2	25	0.1	KNO3	lgK:3.25 (3SF)	6	MGL	1456
3	25	0.1	KNO3	lgK:3.25 (0.003SD)	5	MGL	6861
4	25	0.1	Many Media	lgK:3.30 (0.05SD)	7	CIU	7242

Reaction No. 18343



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.8 (2SF)	4	MGL	1456


Reaction No. 18436



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.76 (2SF)	6	MGL	1535


2	25	0	Inf. Dilution	dH:-7.4 (2SF)	5	MCL	1535
---	----	---	---------------	---------------	---	-----	------

Reaction No. 18437




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10. (0.3SD)	3	MGL	1535
2	25	0	Inf. Dilution	dH:-16.7 (3SF)	5	MCL	1535

Reaction No. 18623




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	Unknown	lgK:4.9 (0.06SD)	4	MGL	1379
2	25	0.1	NaNO3	lgK:5.06 (0.03SD)	5	CRV	13242
3	25	0.1	Unknown	lgK:5.1 (0.03SD)	5	MGL	1379
4	35	0.1	NaNO3	lgK:5.17 (0.05SD)	5	CRV	13242
5	35	0.1	Unknown	lgK:5.2 (0.05SD)	4	MGL	1379
6	45	0.1	Unknown	lgK:4.9 (0.03SD)	4	MGL	1379
7	55	0.1	Unknown	lgK:4.9 (0.03SD)	4	MGL	1379
8	10:60	0.1	Unknown	dH:-1. (1SF)	6	CRV	552
9	25	0.1	Unknown	dH:-0.8 (1SF)	5	MCL	1379

Reaction No. 18716




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:5.30 (0.02SD)	6	MGL	1467

Reaction No. 18717



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:12.98 (0.009SD)	4	MGL	1467
2	25	0.1	Me4NNO3	dH:-10.1 (3SF)	5	MCL	1467

Reaction No. 18738



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:8.7 (0.04SD)	6	MGL	2016

Reaction No. 18739							
[12]N4:Acet*4-4 + Ca+2 = Ca+2_[12]N4:Acet*4-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:15.85 (4SF)	0	MGL	2016
2	25	0.1	KCl	lgK:16.37 (0.01SD)	3	MGL	2527
3	25	0.1	Me4NNO3	lgK:17.23 (0.005SD)	0	MGL	2016
4	25	0.1	Me4NNO3	lgK:17.2 (0.1SD)	0	CRV	13242
5	25	0.1	Unknown	lgK:16.5 (3SF)	2	ENS	1384
6	25	0.1	Me4NNO3	dH:-11.69 (4SF)	5	MCL	6927

Reaction No. 18775							
[18]N2O4:2OH[Hex]*2 + Ca+2 = Ca+2_[18]N2O4:2OH[Hex]*2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:4.72 (0.01SD)	6	MGL	1711

Reaction No. 18803							
[18]N2O4 + Ca+2 = Ca+2_[18]N2O4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NCl	lgK:1.8 (2SF)	4	MGL	1572
2	25	0.1	NaNO3	lgK:1.74 (3SF)	6	MGL	1711
3	25		Acetone	lgK:4.61 (3SF)	3	MCL	3005
4	25		Acetone	dH:-29.8 (3SF) kJ	3	MCL	3005
5	25		DMF	lgK:2.7 (0.06SD)	4	MPS	3910
6	25		DMSO	lgK:2.4 (0.08SD)	4	MPS	3910
7	23		Methanol	lgK:3.87 (3SF)	4	MCL	4772
8	25		Methanol	lgK:3.5 (2SF)	5	MAG	3857
9	25		Methanol	lgK:3.9 (0.07SD)	4	MPS	3910
10	23		Methanol	dH:-1.338 (4SF)	4	MCL	4772
11	25		Methanol	dH:-2.868 (4SF)	5	MTD	3857
12	25	0.1	Methanol:Water 95:5Vol Me4NCl	lgK:4.04 (3SF)	5	MGL	3712

Reaction No. 18829							
[18]N2O4:2OHEt*2 + Ca+2 = Ca+2_[18]N2O4:2OHEt*2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:4.08 (3SF)	6	MGL	1711
2	25	0.5	LiClO4	lgK:4.08 (0.02MD)	5	MGL	4631

Reaction No. 18845							
Ca+2 + GSH-3 + H2O = Ca+2_OH-1_GSH-3 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-6.4 (2SF)	1	ESC	
2	37	0.15	NaClO4	lgK:-6.5 (0.2SD)	4	MGL	1621

Reaction No. 18850							
Ca+2 + GSH-3 + Zn+2 + H2O = Ca+2_Zn+2_OH-1_GSH-3 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.1 (2SF)	1	ESC	
2	37	0.15	NaClO4	lgK:4.0 (0.2SD)	4	MGL	1621

Reaction No. 18863							
TrimDDA-2 + Ca+2 = Ca+2_TrimDDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.4 (2SF)	4	MGL	1685
2	25	0.1	NaClO4	dH:3.8 (2SF) kJ	5	MCL	1685


Reaction No. 18867							
EDD2P-2 + Ca+2 = Ca+2_EDD2P-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:1.7 (0.08SD)	6	MPT	2004
2	25	0.1	NaClO4	lgK:2.1 (2SF)	4	MGL	1685
3	25	0.1	NaClO4	dH:8.7 (2SF) kJ	5	MCL	1685

Reaction No. 18869							
DiMeEDDA-2 + Ca+2 = Ca+2_DiMeEDDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.91 (0.07SD)	3	MGL	2281
2	25	0.1	NaClO4	lgK:6.0 (2SF)	0	MGL	1685
Note (2): Low wgt for internal consistency							
3	25	0.1	NaClO4	dH:-4.8 (2SF) kJ	3	MCL	1685

Reaction No. 19112							
Ca+2 + H+1_EtPhosphinDiAcet-2 = Ca+2_H+1_EtPhosphinDiAcet-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0.1	NaClO4	lgK:0.7 (0.09SD)	4	MGL	1583
---	----	-----	--------	------------------	---	-----	------

Reaction No. 19459




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:2.3 (0.1SD)	4	MGL	1502

Reaction No. 19460




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:3.12 (0.02SD)	5	MGL	1502

Reaction No. 20011




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.6 (1SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:6.03 (3SF)	0	MGL	999

Reaction No. 20013




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.51 (2SF)	6	MSL	999

Reaction No. 20169




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.04 (3SF)	5	MHY	6833
2	25	0.1	Unknown	dH:-0.3 (1SF)	6	CRV	552

Reaction No. 20295



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.82 (3SF)	6	MGL	1747

Reaction No. 20296



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.43 (3SF)	6	MGL	1747

Reaction No. 20297							
$\text{Ca}+2\text{H}+1\text{mODS-4} + \text{H}+1 = \text{Ca}+2\text{H}+1(2)\text{mODS-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.53(3SF)	6	MGL	1747

Reaction No. 20298							
$\text{Ca}+2\text{H}+1(2)\text{mODS-4} + \text{H}+1 = \text{Ca}+2\text{H}+1(3)\text{mODS-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.41(3SF)	6	MGL	1747

Reaction No. 20340							
$\text{racODS-4} + \text{Ca}+2 = \text{Ca}+2\text{racODS-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.42(3SF)	6	MGL	1747

Reaction No. 20341							
$\text{Ca}+2\text{racODS-4} + \text{H}+1 = \text{Ca}+2\text{H}+1\text{racODS-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.35(3SF)	6	MGL	1747

Reaction No. 20342							
$\text{Ca}+2\text{H}+1\text{racODS-4} + \text{H}+1 = \text{Ca}+2\text{H}+1(2)\text{racODS-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.53(3SF)	6	MGL	1747

Reaction No. 20343							
$\text{Ca}+2\text{H}+1(2)\text{racODS-4} + \text{H}+1 = \text{Ca}+2\text{H}+1(3)\text{racODS-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.72(3SF)	6	MGL	1747

Reaction No. 20720							
$2<26\text{PyridineDiCOO-2}> + \text{Ca}+2 = \text{Ca}+2\text{26PyridineDiCOO-2}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaCl	lgK:7.3(0.07SD)	5	MGL	3925
2	25	0.1	Unknown	lgK:7.58(3SF)	6	ENS	773

Reaction No. 20945							
--------------------	--	--	--	--	--	--	--

Ca+2 + H+1_Adenine-1 = Ca+2_H+1_Adenine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:1.86(3SF)	5	MPT	1760

Reaction No. 20983							
Cytidine + Ca+2 = Ca+2_Cytidine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaNO3	lgK:0.18(0.06MD)	5	MGL	6115
2	35	0.1	KNO3	lgK:2.47(3SF)	3	MGL	1187

Reaction No. 20994							
Cytosine + Ca+2 = Ca+2_Cytosine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:2.14(3SF)	5	MPT	1183
2	45	0.1	KNO3	lgK:2.2(0.1SD)	5	MGL	3853

Reaction No. 21002							
Ca+2 + H+1(-1)_Cytosine = Ca+2_H+1(-1)_Cytosine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:2.5(0.1SD)	5	MGL	3853

Reaction No. 21146							
[18]N2O4:DiMe + Ca+2 = Ca+2_[18]N2O4:DiMe							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:2.06(0.02SD)	4	MGL	1786
2	25		Methanol	lgK:4.2(2SF)	5	MAG	3857
3	25		Methanol	dH:-3.728(4SF)	5	MTD	3857

Reaction No. 21315							
[9]N3:MePhosOEt*3-3 + Ca+2 = Ca+2_[9]N3:MePhosOEt*3-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:5.1(2SF)	4	MPT	1823

Reaction No. 21323							
[9]N3:MePhos*3-6 + Ca+2 = Ca+2_[9]N3:MePhos*3-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:6.4(2SF)	4	MGL	1823

Reaction No. 21381							
Glyceric-1 + Ca+2 = Ca+2_Glyceric-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.18 (3SF)	5	MHY	4920

Reaction No. 21492							
SulfCat-3 + Ca+2 = Ca+2_SulfCat-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:4.40 (3SF)	6	MGL	999

Reaction No. 21493							
Ca+2_SulfCat-3 + SulfCat-3 = Ca+2_SulfCat-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:3.59 (3SF)	6	MGL	999


Reaction No. 21562							
DTPMP-9 + Ca+2 = Ca+2_DTPMP-9							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:6.64 (3SF)	0	MGL	999
2	25	0	Inf. Dilution	lgK:13.26 (4SF)	2	EDH	29755
3	25	0.1	KCl	lgK:7.11 (3SF)	0	MGL	999
4	25	0.125	NaCl	lgK:9.24 (0.28SD)	3	MGL	29755
5	25	0.342	NaCl	lgK:9.18 (0.25SD)	2	MGL	29755
6	25	0.958	NaCl	lgK:9.48 (0.33SD)	3	MGL	29755

Reaction No. 21563							
Ca+2 + H+1_DTPMP-9 = Ca+2_H+1_DTPMP-9							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.96 (3SF)	0	MGL	999
2	25	0	Inf. Dilution	lgK:10.92 (4SF)	2	EDH	29755
3	25	0.1	KCl	lgK:5.42 (3SF)	0	MGL	999
4	25	0.125	NaCl	lgK:7.77 (0.15SD)	3	MGL	29755
5	25	0.342	NaCl	lgK:7.67 (0.12SD)	2	MGL	29755
6	25	0.958	NaCl	lgK:7.79 (0.22SD)	3	MGL	29755

Reaction No. 21564							
Ca+2 + H+1(2)_DTPMP-9 = Ca+2_H+1(2)_DTPMP-9							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.36(3SF)	0	MGL	999
2	25	0	Inf. Dilution	lgK:8.88(3SF)	2	EDH	29755
3	25	0.1	KCl	lgK:4.49(3SF)	0	MGL	999
4	25	0.125	NaCl	lgK:5.60(3SF)	4	MGL	29755
5	25	0.342	NaCl	lgK:5.31(0.10SD)	4	MGL	29755
6	25	0.958	NaCl	lgK:5.35(0.17SD)	4	MGL	29755

Reaction No. 21565




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.16(3SF)	2	EDH	29755
2	25	0.1	KCl	lgK:4.04(3SF)	0	MGL	999
3	25	0.125	NaCl	lgK:4.50(0.12SD)	4	MGL	29755
4	25	0.342	NaCl	lgK:4.18(0.11SD)	4	MGL	29755
5	25	0.958	NaCl	lgK:3.98(0.15SD)	4	MGL	29755

Reaction No. 21566




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.75(3SF)	2	EDH	29755
2	25	0.1	KCl	lgK:3.11(3SF)	0	MGL	999
3	25	0.125	NaCl	lgK:3.73(0.09SD)	4	MGL	29755
4	25	0.342	NaCl	lgK:3.39(0.09SD)	4	MGL	29755
5	25	0.958	NaCl	lgK:3.01(0.12SD)	4	MGL	29755

Reaction No. 21567




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.66(3SF)	2	EDH	29755
2	25	0.1	KCl	lgK:2.29(3SF)	0	MGL	999
3	25	0.125	NaCl	lgK:2.83(0.07SD)	4	MGL	29755
4	25	0.342	NaCl	lgK:2.38(0.05SD)	4	MGL	29755
5	25	0.958	NaCl	lgK:1.96(0.13SD)	4	MGL	29755

Reaction No. 21624




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.38 (0.02SD)	6	MGL	2403
2	25	0.1	NaNO3	lgK:1.47 (3SF)w	5	MPH	906

Reaction No. 21636




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.84 (3SF)	5	MGL	906
2	25	0.1	KNO3	lgK:1.71 (0.04MD)	6	MGL	2408
3	25	0.1	Many Media	lgK:1.67 (0.05SD)	7	CIU	7242
4	25	0.1	NaNO3	lgK:1.62 (0.04MD)w	5	MPH	4478

Reaction No. 21637




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:11.01 (4SF)	5	MGL	906
2	25	0.1	KNO3	lgK:11.14 (0.03MD)	5	MGL	2408
3	25	0.1	Many Media	lgK:11.1 (0.1SD)	6	CIU	7242
4	25	0.1	NaClO4	lgK:9.9 (0.07SD)	0	MGL	6795

Reaction No. 21850




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NC1	lgK:5.21 (0.07SD)	4	MGL	3083
2	25	0.5	Me4NC1	dH:2.2 (2SF)	5	MCL	3083

Reaction No. 21851



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NC1	lgK:2.74 (0.09SD)	4	MGL	3083

Reaction No. 21866



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:2.27 (3SF)	5	MGL	154

Reaction No. 21867

Ca+2 + H+1_Tartronic-2 = Ca+2_H+1_Tartronic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:1.30 (3SF)	5	MGL	154

Reaction No. 21937							
AmMalon-2 + Ca+2 = Ca+2_AmMalon-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:2.51 (3SF)	6	MHY	2699


Reaction No. 21995							
Et12DiPhos-4 + Ca+2 = Ca+2_Et12DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NBr	lgK:2.80 (3SF)	5	MGL	4245

Reaction No. 21996							
Ca+2 + H+1_Et12DiPhos-4 = Ca+2_H+1_Et12DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NBr	lgK:2.60 (3SF)	5	MGL	4245

Reaction No. 22117							
[2.2.2]crypt + Ca+2 = Ca+2_[2.2.2]crypt							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	KCl	lgK:4.4 (2SF)	5	MGL	3283
2	25	0.1	Et4NC1O4	lgK:4.9 (0.05SD)	5	MGL	3920
3	25	0.1	KCl	lgK:4.398 (4SF)	5	MKN	4542
4	25	0.1	Me4NC1	lgK:4.57 (3SF)	6	MGL	1572
5	25	0.1	Me4NOH	lgK:4.447 (4SF)	5	MKN	4931
6	25	0.1	Me4NC1	dH:-0.2 (1SF)	5	MCL	1572
7	25	0.1	Me4NOH	dH:-0.5 (1SF)	4	MTD	4931
8	25		Acetone	lgK:12.9 (3SF)	3	MPT	3005
9	25		Acetone	dH:-73.5 (3SF) kJ	3	MCL	3005
10	25	0.01	DMF Et4NC1O4	lgK:3.84 (3SF)	5	MGL	2931
11	25	0.1	DMF Et4NC1O4	lgK:3.79 (3SF)	5	MAG	2920
12	25	0.1	DMSO Et4NC1O4	lgK:2.1 (2SF)	3	MAG	2920
13	25	0.1	MeCN Et4NC1O4	lgK:10. (0.4SD)	5	MGL	3920


14	25	0.1	MeCN:Water 10:90Wgt Et4NC1O4	lgK:5.8(0.05SD)	5	MGL	3920
15	25	0.1	MeCN:Water 20:80Wgt Et4NC1O4	lgK:6.1(0.05SD)	5	MGL	3920
16	25	0.1	MeCN:Water 30:70Wgt Et4NC1O4	lgK:6.7(0.05SD)	5	MGL	3920
17	25	0.1	MeCN:Water 40:60Wgt Et4NC1O4	lgK:7.0(0.05SD)	5	MGL	3920
18	25	0.1	MeCN:Water 5:95Wgt Et4NC1O4	lgK:5.4(0.05SD)	5	MGL	3920
19	25	0.1	MeCN:Water 50:50Wgt Et4NC1O4	lgK:7.6(0.05SD)	5	MGL	3920
20	25	0.1	MeCN:Water 60:40Wgt Et4NC1O4	lgK:8.1(0.05SD)	5	MGL	3920
21	25	0.1	Methanol Et4NC1O4	lgK:8.14(3SF)	5	MAG	2920
22	25		Methanol	lgK:8.15(3SF)	5	MDG	2511
23	25	0.1	Methanol:Water 95:5Vol Me4NC1	lgK:7.5(2SF)	5	MGL	3712
24	25	0.1	PrCarbonate Et4NC1O4	lgK:10.76(4SF)	5	MAG	2920
25	25		PrCarbonate	lgK:10.8(0.1SD)	5	MPT	4822
26	25	0.01	Water:Methanol 5:95Vol KCl	lgK:7.60(3SF)	5	MGL	3283

Reaction No. 22295



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.38(0.02SD)	6	MGL	1744

Reaction No. 22307



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.43(0.02SD)	6	MGL	1744

Reaction No. 22323

Ca+2_[9]N3:MePhos*3-6 + H+1 = Ca+2_H+1_[9]N3:MePhos*3-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:2.7(2SF)	4	ENS	1823

Reaction No. 22332							
HPEDDA-4 + Ca+2 = Ca+2_HPEDDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:14.36(4SF)	2	MGL	2462
2	25	0.1	KNO3	lgK:15.(0.5SD)	2	MGL	1783

Reaction No. 22354							
[18]dieneN6dipyo + Ca+2 = Ca+2_[18]dieneN6dipyo							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:4.4(2SF)w	4	MPH	1835

Reaction No. 22357							
[18]N6 + Ca+2 = Ca+2_[18]N6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	NaClO4	lgK:2.5(0.2SD)	4	MGL	1674
2	25	0.2	NaClO4	dH:-7.(0.9SD)	4	MTD	1674

Reaction No. 22643							
Croconic-2 + Ca+2 = Ca+2_Croconic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.3	KCl	lgK:1.3(0.03SD)	3	MSL	999


Reaction No. 22685							
Adenine-1 + Ca+2 = Ca+2_Adenine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:2.95(0.02SD)	4	MGL	999

Reaction No. 22806							
AlaGly-1 + Ca+2 = Ca+2_AlaGly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Unknown	lgK:0.66(2SF)	5	MSL	140

Reaction No. 22875							
12BisCOOMeOxEthan-2 + Ca+2 = Ca+2_12BisCOOMeOxEthan-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.9(2SF)	1	EDH	
2	25	0.1	KNO3	lgK:3.15(3SF)	2	MGL	2308
3	25	0.1	Unknown	lgK:4.12(3SF)	2	MGL	999

Reaction No. 22886




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.3	KCl	lgK:-4.05(3SF)	3	MSL	999

Reaction No. 22888




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:6.17(3SF)	3	MGL	999

Reaction No. 23268




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:7.28(0.02SD)	4	MGL	1902

Reaction No. 23418




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.00(3SF)	6	MGL	999

Reaction No. 23569




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.2(0.05SD)	4	MGL	999

Reaction No. 23615



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:9.34(3SF)	6	MGL	999


Reaction No. 23616



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	20	0.1	KCl	lgK:7.77 (3SF)	6	MGL	999
---	----	-----	-----	----------------	---	-----	-----

Reaction No. 23617




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.77 (3SF)	0	MGL	999
2	25	0	Inf. Dilution	lgK:6.48 (3SF)	2	EDH	29755
3	25	0.125	NaCl	lgK:3.44 (0.20SD)	4	MGL	29755
4	25	0.342	NaCl	lgK:3.13 (0.16SD)	3	MGL	29755
5	25	0.958	NaCl	lgK:3.25 (0.09SD)	4	MGL	29755

Reaction No. 23757




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-6.4 (2SF)	1	ELC	
2	25	0.15	NaClO ₄	lgK:-8.2 (0.1SD)	0	MSP	931

Reaction No. 23973




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.05 (3SF)	0	MHY	1957
2	20	0.1	KNO ₃	lgK:5.66 (3SF)	6	MGL	1956
3	20	0.1	KNO ₃	lgK:5.66 (3SF) w	6	MPH	2043
4	25	0.1	Unknown	lgK:5.65 (3SF)	6	CRV	552
5	25	0.5	NaClO ₄	lgK:5.2 (0.2SD)	3	MGL	3938
6	20	0.1	KNO ₃	dH:-0.9 (1SF)	3	MCL	1956
7	25	0.5	NaClO ₄	dH:1.67 (0.12SD)	3	MCL	3938

Reaction No. 23974



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.0 (2SF)	2	MGL	1957
2	20	0.1	KNO ₃	lgK:1.42 (3SF)	3	MGL	1956


Reaction No. 23975



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	20	0.1	KCl	lgK:3.45 (3SF)	6	MGL	1957
2	20	0.1	KNO3	lgK:3.67 (3SF)	6	MGL	1956

Reaction No. 24009




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.87 (3SF)	6	MGL	999
2	20	0.1	KNO3	lgK:4.9 (2SF)	4	MGL	1956

Reaction No. 24058




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:6.21 (3SF)	6	MGL	1957
2	20	0.1	KNO3	lgK:6.21 (3SF)	6	MGL	1956
3	20	0.1	KNO3	dH:-2.5 (2SF)	5	MCL	1956

Reaction No. 24059




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.5 (2SF)	4	MGL	1957
2	20	0.1	KNO3	lgK:3.5 (2SF)	4	MGL	1956

Reaction No. 24149




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:8.27 (0.01SD)	5	MGL	89
2	30	0.1	KCl	lgK:9. (1SF)	3	MGL	999

Reaction No. 24255



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.51 (3SF)	6	MGL	1957
2	20	0.1	KNO3	lgK:4.6 (2SF)	4	MGL	1956


Reaction No. 24256



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	20	0.1	KCl	lgK:3.7 (2SF)	4	MGL	1957
2	20	0.1	KNO3	lgK:3.7 (2SF)	4	MGL	1956

Reaction No. 24280




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.03 (3SF)	6	MGL	1957

Reaction No. 24293




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:9.29 (3SF)	6	MGL	1941

Reaction No. 24294




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.52 (3SF)	6	MGL	1941

Reaction No. 24295




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.02 (3SF)	6	MGL	1941
2	25	0.1	KNO3	dH:2.61 (3SF)	5	MCL	1941

Reaction No. 24332



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.60 (3SF)	2	MGL	1957
2	20	0.1	KNO3	lgK:5.2 (2SF)	2	MGL	1956
3	25	0	Inf. Dilution	lgK:5.2 (2SF)	1	ESC	6422

Reaction No. 24333



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.5 (2SF)	4	MGL	1957
2	20	0.1	KNO3	lgK:3.6 (2SF)	4	MGL	1956

Reaction No. 24349

Ca+2_PentMDTA-4 + Ca+2 = Ca+2(2)_PentMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.6(2SF)	4	MGL	1957

Reaction No. 24352							
Ca+2_HexMDTA-4 + Ca+2 = Ca+2(2)_HexMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.1(2SF)	0	MGL	1957
2	25	0	Inf. Dilution	lgK:-0.9(1SF)	1	ELC	

Reaction No. 24353							
Ca+2_TEDTA-4 + Ca+2 = Ca+2(2)_TEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.2(2SF)	4	MGL	1957

Reaction No. 24374							
2<IDA-2> + Ca+2 = Ca+2_IDA-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.7(2SF)	3	MGL	1956
2	25	0	Inf. Dilution	lgK:5.9(0.2SD)	4	CRV	552
3	25	0.1	Unknown	lgK:3.9(2SF)	3	ENS	1384

Reaction No. 24399							
Chelidam-3 + Ca+2 = Ca+2_Chelidam-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:5.6(2SF)	4	MGL	1982

Reaction No. 24400							
Ca+2_Chelidam-3 + H+1 = Ca+2_H+1_Chelidam-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:6.51(3SF)	6	MGL	1982

Reaction No. 24766							
AcoxAcet-1 + Ca+2 = Ca+2_AcoxAcet-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.4	NaNO3	lgK:0.3(0.04SD)	6	MGL	382

Reaction No. 24856							
--------------------	--	--	--	--	--	--	--

Mg+2 + Ca+2 + Tetracycline-2 = Ca+2_Mg+2_Tetracycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:8.5(0.05SD)	4	MGL	2160

Reaction No. 24857							
Mg+2 + Ca+2 + OxTetracycline-2 = Ca+2_Mg+2_OxTetracycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:8.31(0.02SD)	6	MGL	2160

Reaction No. 24858							
H+1 + Mg+2 + Ca+2 + Minocycline-2 = Ca+2_Mg+2_H+1_Minocycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:16.6(0.03SD)	4	MGL	2160

Reaction No. 24859							
H+1 + Minocycline-2 + Ca+2 = Ca+2_H+1_Minocycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:14.18(0.02SD)	4	MGL	2166

Reaction No. 24860							
Minocycline-2 + Ca+2 = Ca+2_Minocycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:5.981(4SF)	6	MGL	2166

Reaction No. 24866							
2<H+1> + 2<Minocycline-2> + Ca+2 = Ca+2_H+1(2)_Minocycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:27.2(0.04SD)	4	MGL	2166

Reaction No. 24907							
2<H+1> + 2<Demeclocycline-2> + Ca+2 = Ca+2_H+1(2)_Demeclocycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:24.27(0.02SD)	6	MGL	2170

Reaction No. 24908							
H+1 + 2<Demeclocycline-2> + Ca+2 = Ca+2_H+1_Demeclocycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:16.4(0.06SD)	4	MGL	2170

Reaction No. 24909							
Demeclocycline-2 + Ca+2 = Ca+2_Demeclocycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:4.6(0.05SD)	4	MGL	2170

Reaction No. 24910							
Demeclocycline-2 + 2<Ca+2> = Ca+2(2)_Demeclocycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:8.34(0.02SD)	6	MGL	2170


Reaction No. 24936							
2<H+1> + Glu-2 + Ca+2 = Ca+2_H+1(2)_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.2(3SF)	4	MGL	6131
2	37	0.15	NaCl	lgK:13.82(0.08SD)	3	MGL	28777
3	37	0.15	NaCl	lgK:14.18(0.05SD)	3	MIS	28777
4	37	0.15	NaClO4	lgK:14.0(0.07SD)	4	MGL	2181
5	25	0	Inf. Dilution	dH:-48.(2SF)kJ	4	MCL	6131

Reaction No. 24937							
Glu-2 + Ca+2 = H+1 + Ca+2_H+1(-1)_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-8.35(3SF)	2	EAE	
2	37	0.15	NaCl	lgK:-9.68(0.16SD)	2	MGL	28777
3	37	0.15	NaClO4	lgK:-9.07(0.02SD)	2	MGL	2181

Reaction No. 24938							
2<H+1> + Asp-2 + Ca+2 = Ca+2_H+1(2)_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.33(4SF)	3	MGL	6131
2	25	0	Inf. Dilution	lgK:14.3(0.2MD)	3	MGL	6912
3	25	0	NaCl	lgK:14.33(4SF)	3	MGL	6912
4	37	0.15	NaCl	lgK:14.31(0.30SD)	3	MGL	28777
5	37	0.15	NaCl	lgK:14.72(0.13SD)	2	MIS	28777
6	37	0.15	NaClO4	lgK:14.1(0.04SD)	3	MGL	2181
7	10	0.1	HCl	lgR:14.40(4SF)	3	MGL	6912


8	10	0.5	HCl	lgR:14.53(4SF)	3	MGL	6912
9	10	1	HCl	lgR:14.48(4SF)	3	MGL	6912
10	25	0.1	HCl	lgR:13.84(4SF)	3	MGL	6912
11	25	0.5	HCl	lgR:13.93(4SF)	3	MGL	6912
12	25	1	HCl	lgR:14.21(4SF)	3	MGL	6912
13	37	0.1	HCl	lgR:13.38(4SF)	3	MGL	6912
14	37	0.5	HCl	lgR:13.45(4SF)	3	MGL	6912
15	37	1	HCl	lgR:13.99(4SF)	3	MGL	6912
16	45	0.1	HCl	lgR:13.08(4SF)	3	MGL	6912
17	45	0.5	HCl	lgR:13.13(4SF)	3	MGL	6912
18	45	1	HCl	lgR:13.85(4SF)	3	MGL	6912
19	10	0.1	HCl	dH:-13.9(3SF)	0	MTD	6912
20	10	0.5	HCl	dH:-14.6(3SF)	0	MTD	6912
21	10	1	HCl	dH:-6.45(3SF)	0	MTD	6912
22	25	0	Inf. Dilution	dH:-53.8(3SF)	0	MCL	6131
23	25	0	Inf. Dilution	dH:-12.9(3SF)	0	MCL	6912
24	25	0	Inf. Dilution	dH:-54.(2SF)kJ	0	MTD	6912
25	25	0.1	HCl	dH:-15.3(3SF)	0	MTD	6912
26	25	0.5	HCl	dH:-16.3(3SF)	0	MTD	6912
27	25	1	HCl	dH:-7.17(3SF)	0	MTD	6912
28	37	0.1	HCl	dH:-16.5(3SF)	0	MTD	6912
29	37	0.5	HCl	dH:-17.4(3SF)	0	MTD	6912
30	37	1	HCl	dH:-7.89(3SF)	0	MTD	6912
31	45	0.1	HCl	dH:-17.4(3SF)	0	MTD	6912
32	45	0.5	HCl	dH:-18.4(3SF)	0	MTD	6912
33	45	1	HCl	dH:-8.37(3SF)	0	MTD	6912

Reaction No. 24939




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-9.0(2SF)	2	ESC	
2	37	0.15	NaCl	lgK:-9.69(0.08SD)	2	MGL	28777
3	37	0.15	NaClO4	lgK:-9.2(0.02SD)	3	MGL	2181

Reaction No. 24940




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.86(3SF)	2	EAE	
2	37	0.15	NaClO4	lgK:3.9(0.08SD)	6	MGL	2181

Reaction No. 24941




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-7.44(3SF)	2	EAE	
2	37	0.15	NaCl	lgK:-8.79(0.09SD)	3	MGL	28777
3	37	0.15	NaClO4	lgK:-8.395(0.026SD)	3	MGL	2181

Reaction No. 24942




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-18.7(3SF)	2	EAE	
2	37	0.15	NaCl	lgK:-18.64(0.15SD)	3	MGL	28777
3	37	0.15	NaClO4	lgK:-16.808(0.023SD)	0	MGL	2181

Reaction No. 25126




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:4.04(0.007SD)	6	MGL	2182

Reaction No. 25140



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:7.26(0.005SD)	6	MGL	2182

Reaction No. 25200



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.60(0.01SD)	4	MGL	2281

Reaction No. 25201



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.50(0.01SD)	4	MGL	2281

Reaction No. 25227							
[9]N2S:Acet*2-2 + Ca+2 = Ca+2_[9]N2S:Acet*2-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.01(0.08SD)	6	MGL	2281

Reaction No. 25278							
Guanosine-1 + Ca+2 = Ca+2_Guanosine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.7(0.05SD)	5	MGL	2194
2	35	0.1	KNO3	lgK:1.8(0.05SD)	5	MGL	2194
3	37			lgK:1.23(3SF)	4	MMR	906
4	45	0.1	KNO3	lgK:1.9(0.05SD)	5	MGL	2194
5	15:45	0.1	KNO3	dH:13.(1.SD)kJ	5	MCL	2194
6	21		DMSO	lgK:1.06(3SF)	4	MMR	906


Reaction No. 25279							
2<Guanosine-1> + Ca+2 = Ca+2_Guanosine-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:3.49(3SF)	5	MGL	2194
2	25	0.1	KNO3	lgK:3.54(3SF)	5	MGL	2194
3	35	0.1	KNO3	lgK:3.60(3SF)	5	MGL	2194
4	45	0.1	KNO3	lgK:3.65(3SF)	5	MGL	2194
5	15:45	0.1	KNO3	dH:9.5(1.SD)kJ	5	MCL	2194

Reaction No. 25286							
Guanosine-1 + Ca+2 + Bipy = Ca+2_Bipy_Guanosine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:5.2(0.07SD)	5	MGL	2194
2	25	0.1	KNO3	lgK:5.1(0.07SD)	5	MGL	2194
3	35	0.1	KNO3	lgK:5.0(0.07SD)	5	MGL	2194
4	45	0.1	KNO3	lgK:5.0(0.07SD)	5	MGL	2194
5	15:45	0.1	KNO3	dH:-13.(1.SD)kJ	5	MCL	2194

Reaction No. 25293							
Guanosine-1 + Ca+2 + Phenanth = Ca+2_Phenanth_Guanosine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:4.5(0.07SD)	6	MGL	2194


2	25	0.1	KNO3	lgK:4.5(0.07SD)	6	MGL	2194
3	35	0.1	KNO3	lgK:4.6(0.07SD)	6	MGL	2194
4	45	0.1	KNO3	lgK:4.6(0.07SD)	6	MGL	2194
5	25	0.1	KNO3	dH:8.(1.SD)kJ	5	MTD	2194

Reaction No. 25326



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:11.22(4SF)	5	ENS	2350

Reaction No. 25547




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.92(0.02SD)	5	MGL	999
2	20	0.1	NaNO3	lgK:4.91(0.05MD)	5	MPT	6937
3	25	0.1	KCl	lgK:4.80(3SF)	5	MGL	999
4	20	0.1	NaNO3	dH:-1.5(0.1MD)	5	MCL	6937

Reaction No. 25548




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.92(3SF)	5	MGL	999

Reaction No. 25575




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.06(3SF)	5	MHY	6833

Reaction No. 25617




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.36(3SF)	4	MGL	653
2	25	1	NaNO3	lgK:1.56(3SF)	4	MGL	2422
3	25	1	NaNO3	dH:-0.54(0.08SD)kJ	4	MCL	2422

Reaction No. 25626




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:6.46(3SF)	6	MGL	1979

Reaction No. 25639




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:6.40(3SF)	6	MGL	1979

Reaction No. 25652




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.19(3SF)	6	MGL	1979

Reaction No. 25663




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:6.97(0.02SD)	1	MGL	2591
2	20	0.1	KNO3	lgK:6.97(3SF)	1	MGL	1979
3	25	0.05	NaCl	lgK:6.30(0.19SD)	0	MGL	29125
4	25	0.15	NaCl	lgK:6.27(0.16SD)	3	MGL	29125
5	25	0.5	NaCl	lgK:5.39(0.12SD)	1	MGL	29125
6	25	1	NaCl	lgK:5.23(0.17SD)	0	MGL	29125
7	25	0.151	Unknown	dH:-3.6(0.7SD) kJ	3	MCL	29125
8	25	0.42	Unknown	dH:-4.6(0.4SD) kJ	3	MCL	29125
9	25	1.007	Unknown	dH:-6.8(0.3SD) kJ	3	MCL	29125

Reaction No. 25777



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NCl	lgK:8.85(3SF)	3	MGL	2209

Reaction No. 25798



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.4(0.05SD)	6	MGL	1996

Reaction No. 25815

Ca+2 + H+1(2)_[12]N4:Acet*4-4 = Ca+2_H+1(2)_[12]N4:Acet*4-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:3.1(0.06SD)	6	MGL	2016

Reaction No. 25948							
NPhosMeIDA-4 + Ca+2 = Ca+2_NPhosMeIDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:7.18(3SF)	6	MHY	140
2	30	0.1	KCl	lgK:7.1(2SF)	6	MGL	140

Reaction No. 25954							
Ca+2 + H+1_NPhosMeIDA-4 = Ca+2_H+1_NPhosMeIDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.43(3SF)	6	MHY	140
2	20	0.1	KNO3	lgK:2.2(2SF)	6	MEP	2009


Reaction No. 25973							
[13]N4:Acet*4-4 + Ca+2 = Ca+2_[13]N4:Acet*4-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:8.06(3SF)	0	MGL	2016
2	20	0.1	Unknown	lgK:10.4(3SF)	0	MGL	2016
3	25	0.1	K+1 salt	lgK:12.0(0.1SD)	6	CRV	552
4	25	0.1	KCl	lgK:11.99(0.01SD)	6	MGL	2527
5	25	0.1	KNO3	lgK:12.08(0.003SD)	6	MGL	2016
6	25	0.1	KNO3	dH:-6.09(3SF)	5	MCL	6927

Reaction No. 25974							
Ca+2 + H+1_[13]N4:Acet*4-4 = Ca+2_H+1_[13]N4:Acet*4-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.0(3SF)	1	ELC	
2	25	0.1	KNO3	lgK:5.45(0.005SD)	0	MGL	2016

Reaction No. 25997							
[14]N4:Acet*4-4 + Ca+2 = Ca+2_[14]N4:Acet*4-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:9.48(3SF)	0	MGL	2016
2	25	0.1	K+1 salt	lgK:8.4(0.04SD)	5	CRV	552


3	25	0.1	KCl	lgK:8.53(0.01SD)	3	MGL	2527
4	25	0.1	KNO3	lgK:8.32(0.004SD)	5	MGL	2016
5	25	0.1	KNO3	lgK:8.4(0.1SD)	5	CRV	13242
6	25	0.1	Unknown	lgK:8.9(2SF)	1	ENS	1384
7	25	0.1	KNO3	dH:-2.1(2SF)	5	MCL	6927

Reaction No. 25998




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.1(0.05SD)	6	MGL	2016

Reaction No. 26207




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.5(2SF)	1	ELC	
2	25	0.1	NaClO4	lgK:7.00(3SF)	0	MGL	1483
3	25	0.1	NaClO4	dH:-8.62(0.20SD) kJ	2	MCL	1483

Reaction No. 26213




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:2.4(0.1SD)	5	MGL	2326

Reaction No. 26220



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.92(3SF)	5	MPT	1760
2	45	0.1	KNO3	lgK:2.6(0.1SD)	5	MGL	2326

Reaction No. 26359



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:8.69(3SF) w	3	MPH	2043
2	25	0.5	NaClO4	lgK:9.(0.3SD)	2	MGL	3938
3	25	0.5	NaClO4	dH:-28.22(4SF) kJ	2	MCL	3938

Reaction No. 26454

Ca+2 + H+1(2)_OHEtDiPhos-4 = Ca+2_H+1(2)_OHEtDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.63(3SF)	3	MGL	1599

Reaction No. 26758							
Cu+2_HOEDTA-3 + H+1(3)_Tren + Ca+2 = Cu+2_Tren + Ca+2_HOEDTA-3 + 3<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:-18.64(4SF)	6	MTD	2121
2	20	0.1	KNO3	lgK:-18.36(4SF)	6	MTD	2121
3	25	0.1	KNO3	lgK:-18.12(4SF)	6	MTD	2121
4	30	0.1	KNO3	lgK:-17.89(4SF)	6	MTD	2121
5	35	0.1	KNO3	lgK:-17.73(4SF)	6	MTD	2121
6	40	0.1	KNO3	lgK:-17.49(4SF)	6	MTD	2121
7	25	0.1	KNO3	dH:19.(0.5SD)	6	MCL	2121

Reaction No. 27022							
AmPhenMeDiPhos-4 + Ca+2 = Ca+2_AmPhenMeDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:6.56(3SF)	5	MGL	999

Reaction No. 27023							
Ca+2 + H+1_AmPhenMeDiPhos-4 = Ca+2_H+1_AmPhenMeDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.82(3SF)	5	MGL	999


Reaction No. 27055							
SolochromeVR-3 + Ca+2 = Ca+2_SolochromeVR-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.6(0.1SD)	4	MSP	6845

Reaction No. 27056							
Ca+2_SolochromeVR-3 + SolochromeVR-3 = Ca+2_SolochromeVR-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.(1SF)	3	MSP	6845

Reaction No. 27171							
Ca+2 + H+1_Cytosine = Ca+2_H+1_Cytosine							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:2.5(0.06SD)	5	MGL	1892

Reaction No. 27172




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:3.5(0.05SD)	5	MGL	1892

Reaction No. 27186




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:6.(0.2SD)	5	MGL	1892

Reaction No. 27210




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaCl	lgK:0.87(2SF)	1	MGL	9667

Reaction No. 27291




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:3.93(3SF)	6	CRV	552

Reaction No. 27330



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.18(3SF)	6	MGL	2041
2	22	0.1	NaClO4	lgK:5.28(3SF)	5	MGL	999

Reaction No. 27461



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.68(0.03SD)	5	MPT	6298
2	25	0.05	Unknown	lgK:3.67(0.02SD)	5	MIS	6298
3	37	0.15	KNO3	lgK:3.18(3SF)	6	MGL	2141
4	25	0	Inf. Dilution	dH:0.6(0.2SD)	5	MCL	6298

Reaction No. 27462

Ca+2_PhosAcet-3 + PhosAcet-3 = Ca+2_PhosAcet-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:1.2(0.1SD)	6	MGL	2141

Reaction No. 27463							
Ca+2 + H+1_PhosAcet-3 = Ca+2_H+1_PhosAcet-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.6(0.08SD)	5	ENS	3882
2	25	0.05	Unknown	lgK:2.10(0.06SD)	5	MIS	6298
3	37	0.15	KNO3	lgK:1.62(0.06SD)	6	MGL	2141

Reaction No. 27524							
Suberic-2 + Ca+2 = Ca+2_Suberic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.66(3SF)	3	MGL	1716

Reaction No. 27527							
TPhth-2 + Ca+2 = Ca+2_TPhth-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.(0.6SD)	5	MGL	1716

Reaction No. 27553							
Xanthosine-1 + Ca+2 = Ca+2_Xanthosine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.4(0.06SD)	6	MGL	3147
2	25	0.1	NaNO3	lgK:0.6(1SF)	0	MGL	6105
3	35	0.1	KNO3	lgK:2.2(0.06SD)	4	MGL	2371
4	45	0.1	KNO3	lgK:2.3(0.06SD)	6	MGL	1884
5	25	0.1	KNO3	dG:-3.2(0.06SD)	6	MGL	1884
6	25	0.1	KNO3	dH:-1.6(0.1SD)	6	MCL	1884
7	25	0.1	KNO3	dS:5.4(0.2SD)	6	EFE	1884

Reaction No. 27556							
TriClMePhos-2 + Ca+2 = Ca+2_TriClMePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.25(0.02SD)	6	MGL	2403

Reaction No. 27560							
DiClMePhos-2 + Ca+2 = Ca+2_DiClMePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.3(0.03SD)	6	MGL	2403

Reaction No. 27569							
BrMePhos-2 + Ca+2 = Ca+2_BrMePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.3(0.03SD)	6	MGL	2403

Reaction No. 27574							
IMePhos-2 + Ca+2 = Ca+2_IMePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.4(0.03SD)	6	MGL	2403

Reaction No. 27581							
OHMePhos-2 + Ca+2 = Ca+2_OHMePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.68(0.01SD)	6	MGL	2403
2	25	0.1	Me4NC1	lgK:1.87(3SF)	5	MGL	2756


Reaction No. 27585							
MePhos-2 + Ca+2 = Ca+2_MePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.51(0.02SD)	6	MGL	2403
2	25	0.1	Many Media	lgK:1.6(0.1SD)	7	CIU	7242
3	25	0.1	NaNO3	lgK:1.64(0.03MD)	4	MGL	1860
4	25	0.1	NaNO3	lgK:1.49(0.02MD)	5	MGL	6412

Reaction No. 27590							
EtPhos-2 + Ca+2 = Ca+2_EtPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.54(0.02SD)	6	MGL	2403
2	25	0.1	NaNO3	lgK:1.61(0.05MD)	5	MGL	1860

Reaction No. 27613							
H+1 + 2AmEtPhos-2 + Ca+2 = Ca+2_H+1_2AmEtPhos-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:12.2 (0.1MD)	6	MGL	2408

Reaction No. 27614




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.7 (0.1MD)	6	MGL	2408
2	25	0.2	KNO3	lgK:1.43 (0.01SD)	5	MGL	6868

Reaction No. 27637




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:12.37 (0.05MD)	6	MGL	2408

Reaction No. 27638




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.7 (0.07MD)	6	MGL	2408

Reaction No. 27725




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:11.76 (4SF)	3	MGL	1187

Reaction No. 27728




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7 (3SF)	1	ESC	
2	35	0.1	KNO3	lgK:11.51 (4SF)	3	MGL	1187

Reaction No. 27731



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:11.87 (4SF)	3	MGL	1187


Reaction No. 27744



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:9.1 (2SF)	1	ESC	
2	35	0.1	KNO3	lgK:8.80 (3SF)	3	MGL	1187

Reaction No. 27751




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.3 (2SF)	1	ESC	
2	35	0.1	KNO3	lgK:8.72 (3SF)	0	MGL	1187

Reaction No. 27752




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.9 (2SF)	1	ESC	
2	35	0.1	KNO3	lgK:2.79 (3SF)	5	MGL	1187

Reaction No. 27759




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:2.32 (3SF)	0	MGL	1187

Reaction No. 27764




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:8.63 (3SF)	5	MGL	1187

Reaction No. 27765




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:3.13 (3SF)	5	MGL	1187

Reaction No. 27888



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:8.22 (3SF)	5	MPT	1183


Reaction No. 27894



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	35	0.1	KNO3	lgK:3.40 (3SF)	5	MPT	1183
---	----	-----	------	----------------	---	-----	------

Reaction No. 27902




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.7 (2SF)	1	ESC	
2	35	0.1	KNO3	lgK:8.49 (3SF)	5	MPT	1183

Reaction No. 27905




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:7.21 (3SF)	5	MPT	1183

Reaction No. 27908




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:3.22 (3SF)	5	MPT	1183

Reaction No. 28173




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:0.9 (0.03SD)	5	MGL	2406

Reaction No. 28212




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.6 (0.04SD)	6	MGL	2527
2	25	0.1	Me4NNO3	lgK:3.7 (0.1SD)	5	CRV	13242
3	25	0.1	Unknown	lgK:3.54 (3SF)	4	MDG	4891

Reaction No. 28228




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:4.72 (3SF)	0	CRV	552
2	25	0.1	KCl	lgK:8.22 (0.02SD)	6	MGL	2527

Reaction No. 28239




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:7.2(0.2SD)	6	CRV	552
2	25	0.1	KCl	lgK:7.0(0.03SD)	6	MGL	2527
3	25	0.1	KNO3	lgK:7.2(0.2SD)	5	CRV	13242

Reaction No. 28650




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:4.9(2SF)	4	CRV	2556

Reaction No. 28651




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:11.10(4SF)	5	CRV	2556

Reaction No. 28652




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:9.73(3SF)	5	CRV	2556

Reaction No. 28653




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:8.03(3SF)	5	CRV	2556

Reaction No. 28654




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:6.82(3SF)	5	CRV	2556

Reaction No. 28655



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:5.38(3SF)	5	CRV	2556

Reaction No. 28656



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0.1	K+1 salt	lgK:7.68 (3SF)	4	CRV	2556
---	----	-----	----------	----------------	---	-----	------

Reaction No. 28851							
4MePhen1Bu13Dione-1 + Ca+2 = Ca+2_4MePhen1Bu13Dione-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20		Dioxan:Water 3:1Vol	lgK:8.32 (3SF)	5	MGL	2261

Reaction No. 28852							
2<4MePhen1Bu13Dione-1> + Ca+2 = Ca+2_4MePhen1Bu13Dione-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20		Dioxan:Water 3:1Vol	lgK:13.63 (4SF)	5	MGL	2261

Reaction No. 28903							
2BenzNTA-3 + Ca+2 = Ca+2_2BenzNTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:6.29 (3SF)	6	CRV	2556

Reaction No. 28970							
Ca+2 + H+1_MetNNDiAcet-3 = Ca+2_H+1_MetNNDiAcet-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Na+1 salt	lgK:1.35 (3SF)	6	CRV	2556

Reaction No. 28998							
2AmPr13DioicN2Bu14Dioic-4 + Ca+2 = Ca+2_2AmPr13DioicN2Bu14Dioic-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.46 (3SF)	5	MGL	2261

Reaction No. 29094							
Ca+2 + Xanthosine-1 + H+1_TMEDA = Ca+2_H+1_TMEDA_Xanthosine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:5.2 (0.2SD)	5	MGL	1905

Reaction No. 29108							
Ca+2_TriMDTA-4 + H+1 = Ca+2_H+1_TriMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:6.34 (3SF)	5	ENS	2373

Reaction No. 29118							
Ca+2_PentMDTA-4 + H+1 = Ca+2_H+1_PentMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:9.2 (2SF)	5	ENS	2373

Reaction No. 29127							
Di(2MeAc)EDDA-4 + Ca+2 = Ca+2_Di(2MeAc)EDDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:10.01 (0.01SD)	4	MPT	2004
2	30	0.1	KCl	lgK:10.74 (4SF)	3	MGL	2019

Reaction No. 29131							
Di(2EtAc)EDDA-4 + Ca+2 = Ca+2_Di(2EtAc)EDDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:9.02 (3SF)	5	ENS	2373

Reaction No. 29135							
Di(2PrAc)EDDA-4 + Ca+2 = Ca+2_Di(2PrAc)EDDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:9.24 (3SF)	5	ENS	2373


Reaction No. 29139							
Di(2IPrAc)EDDA-4 + Ca+2 = Ca+2_Di(2IPrAc)EDDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:6.05 (3SF)	5	ENS	2373

Reaction No. 29172							
Ca+2_NTA-3 + NTA-3 = Ca+2_NTA-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:3.2 (2SF)	0	MHY	1118
2	20	0	Inf. Dilution	lgK:3.43 (3SF)	0	MEF	11516
Note (2): Schwarzenbach G et al., Helv. Chim. Acta, 1945, 28, 828							
3	20	0.1	KNO3	lgK:2.45 (3SF)	0	MGL	2595
4	25	0	Inf. Dilution	lgK:2.1 (2SF)	1	ELC	

Reaction No. 29313							
CPDTA-4 + Ca+2 = Ca+2_CPDTA-4							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:12.2 (3SF)	0	MGL	140
2	20	0.1	KCl	lgK:11.32 (4SF)	4	MGL	140
3	20	0.1	Unknown	lgK:11.08 (4SF)	4	MGL	931
4	20	0.1	Unknown	lgK:9.45 (3SF)	0	ENS	2366
5	20	1	Unknown	lgK:11.30 (4SF)	6	CRV	552
6	25	0	Inf. Dilution	lgK:12.6 (3SF)	1	EDH	
7	25	0.1	Unknown	lgK:11.20 (4SF)	6	CRV	552
8	20	1	KCl	dH:-4.87 (3SF)	5	MCL	2018

Reaction No. 29318




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:8.0 (2SF)	4	ENS	140

Reaction No. 29635




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0.1	KNO3	lgK:6.0 (0.1SD)	0	MGL	3867
2	25	0.1	KNO3	lgK:5.2 (0.08SD)	5	MGL	3867
3	35	0.1	KNO3	lgK:5.1 (0.07SD)	4	MGL	3867
4	45	0.1	KNO3	lgK:5.6 (0.1SD)	0	MGL	1905
5	25	0.1	KNO3	dH:-0.9 (0.3SD)	5	MCL	3867

Reaction No. 29642



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:2.6 (2SF)	4	MGL	2371

Reaction No. 29646



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	9	0	Inf. Dilution	lgK:-8.409 (4SF)	3	EOD	6467
2	10	0	Inf. Dilution	lgK:-8.40 (0.02SD)	0	MSL	6465
3	15	0	Inf. Dilution	lgK:-8.48 (3SF)	3	MSL	6463
4	15	0	Inf. Dilution	lgK:-8.35 (0.02SD)	3	MSL	6465
5	15	0.15	NaCl	lgK:-8.481 (4SF)	2	MSL	31717

6	20	0	Inf. Dilution	lgK:-8.33(0.01SD)	6	EES	9253
Note (6): Estimated by EK							
7	25	0	Inf. Dilution	lgK:-8.318(4SF)	3	MSL	1847
8	25	0	Inf. Dilution	lgK:-8.32(3SF)	3	MSL	6463
9	25	0	Inf. Dilution	lgK:-8.28(0.02SD)	4	MSL	6465
10	25	0	Inf. Dilution	lgK:-8.24(0.01SD)	6	MSL	6466
11	25	0	Inf. Dilution	lgK:-8.276(4SF)	3	EOD	6467
12	25	0	Inf. Dilution	lgK:-8.24(0.01SD)	6	EES	9253
Note (12): Estimated by EK							
13	25	0	Inf. Dilution	lgK:-8.190(0.02SD)	5	CRV	20830
14	25	0.15	NaCl	lgK:-8.318(4SF)	0	MSL	31717
15	25	0.26	NaCl	lgK:-8.318(4SF)	2	MGL	1847
16	30	0	Inf. Dilution	lgK:-8.19(0.02SD)	4	MSL	6465
17	30	0	Inf. Dilution	lgK:-8.187(4SF)	3	EOD	6467
18	30	0	Inf. Dilution	lgK:-8.12(0.02SD)	6	EES	9253
Note (18): Estimated by EK							
19	37	0	Inf. Dilution	lgK:-8.14(3SF)	3	MSL	6463
20	37	0	Inf. Dilution	lgK:-8.09(0.02SD)	4	MSL	6465
21	37	0	Inf. Dilution	lgK:-8.02(0.02SD)	6	MSL	6466
22	37	0	Inf. Dilution	lgK:-8.086(4SF)	3	EOD	6467
23	37	0	Inf. Dilution	lgK:-8.02(0.02SD)	6	EES	9253
Note (23): Estimated by EK							
24	37	0	Inf. Dilution	lgK:-8.143(4SF)	4	CRV	26737
25	37	0.15	NaCl	lgK:-8.143(4SF)	0	MSL	31717
26	40	0	Inf. Dilution	lgK:-7.97(0.02SD)	6	MSL	6466
27	40	0	Inf. Dilution	lgK:-7.97(0.02SD)	6	EES	9253
Note (27): Estimated by EK							
28	45	0	Inf. Dilution	lgK:-7.917(4SF)	3	EOD	6467
29	50	0	Inf. Dilution	lgK:-7.99(3SF)	0	MSL	6463
30	50	0.15	NaCl	lgK:-7.993(4SF)	0	MSL	31717
31	25	0	Inf. Dilution	dH:30.5(2.3SD)kJ	6	MCL	17594
32	25	0	Inf. Dilution	dH:29.700(0.65SD)kJ	5	CRV	20830

Reaction No. 29660

Ca+2 + Xanthosine-1 + H+1_SulfSal-3 = Ca+2_H+1_Xanthosine-1_SulfSal-3

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0	Inf. Dilution	lgK:2.2 (2SF)	1	ESC	
2	45	0.1	KNO3	lgK:2.22 (0.02SD)	5	MGL	1905

Reaction No. 29667

Ca+2 + Xanthosine-1 + Bipy = Ca+2_Bipy_Xanthosine-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:6. (0.6SD)	5	MGL	1905

Reaction No. 30045

Tris + Ca+2 = Ca+2_Trис

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:0.7 (1SF)	3	MGL	6086
2	25	1	Me4NNO3	lgK:0.25 (0.02SD)	6	MGL	2542
3	25	0.25	DMSO:Water 90:10Vol Me4NNO3	lgK:0.2 (0.1SD)	6	MGL	2542

Reaction No. 30051

TriEtOlAm + Ca+2 = Ca+2_TriEtOlAm

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NNO3	lgK:0.78 (0.01SD)	6	MGL	2542
2	25	0.25	DMSO:Water 90:10Vol Me4NNO3	lgK:0.82 (0.02SD)	6	MGL	2542

Reaction No. 30057

BisTris + Ca+2 = Ca+2_BisTris

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:2.25 (0.02SD)	5	MGL	6089
2	25	1	Me4NNO3	lgK:2.25 (0.02SD)	6	MGL	2542
3	25	0.5	DMSO:Water 75:25Vol Me4NNO3	lgK:2.16 (0.02SD)	6	MGL	2542
4	25	0.25	DMSO:Water 90:10Vol Me4NNO3	lgK:1.64 (0.01SD)	6	MGL	2542
5	25	0.5	Dioxan:Water 50:50Vol Me4NNO3	lgK:2.91 (0.01SD)	6	MGL	2542
6	25	0.5	Methanol:Water 50:50Vol Me4NNO3	lgK:2.94 (0.01SD)	6	MGL	2542

Reaction No. 30145							
$\text{Ca}+2_{\text{HPEDDA-4}} + \text{H}+1 = \text{Ca}+2_{\text{H}+1_{\text{HPEDDA-4}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:7.80 (3SF)	4	MGL	2462

Reaction No. 30146							
$\text{Ca}+2_{\text{H}+1_{\text{HPEDDA-4}}} + \text{H}+1 = \text{Ca}+2_{\text{H}+1(2)_{\text{HPEDDA-4}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:6.56 (3SF)	4	MGL	2462

Reaction No. 30154							
$\text{Ca}+2 + \text{H}+1_{\text{HPEDDA-4}} = \text{Ca}+2_{\text{H}+1_{\text{HPEDDA-4}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:10. (0.3SD)	4	MGL	1783

Reaction No. 30155							
$\text{Ca}+2 + \text{H}+1(2)_{\text{HPEDDA-4}} = \text{Ca}+2_{\text{H}+1(2)_{\text{HPEDDA-4}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:7. (0.3SD)	4	MGL	1783

Reaction No. 30479							
$\text{Ca}+2 + \text{H}+1(2)_{\text{3Am10HPr11DiPhos-4}} = \text{Ca}+2_{\text{H}+1(2)_{\text{3Am10HPr11DiPhos-4}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.85 (3SF)	4	MGL	2261


Reaction No. 30530							
$[\text{Hex}]11\text{AmCOO-1} + \text{Ca}+2 = \text{Ca}+2_{[\text{Hex}]11\text{AmCOO-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.2 (2SF)	6	MGL	2057

Reaction No. 30704							
$11\text{DiMeEDTA-4} + \text{Ca}+2 = \text{Ca}+2_{11\text{DiMeEDTA-4}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:10.37 (4SF)	6	MPT	1978

Reaction No. 30729							
$\text{HexEDTA-4} + \text{Ca}+2 = \text{Ca}+2_{\text{HexEDTA-4}}$							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:11.70 (0.02SD)	6	MPL	1981

Reaction No. 30783




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:4.34 (3SF)	6	CRV	552

Reaction No. 30793




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:11.75 (4SF)	6	MPT	2011

Reaction No. 30994




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NCl	lgK:1.72 (0.01SD)	5	MSL	2495

Reaction No. 30995




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NCl	lgK:-8.60 (0.005SD)	5	MSL	2495

Reaction No. 31154




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NCl	lgK:19. (0.7SD)	5	MGL	2495

Reaction No. 31155



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NCl	lgK:29.1 (0.06SD)	5	MGL	2495

Reaction No. 31156



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NCl	lgK:48. (0.2SD)	5	MGL	2495

Reaction No. 31411							
1Am2MePrPhos-2 + Ca+2 = Ca+2_1Am2MePrPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	24	0.1	KNO3	lgK:3.42 (3SF)	5	MGL	2261

Reaction No. 31422							
NEtIm(MePhos)*2-4 + Ca+2 = Ca+2_NEtIm(MePhos)*2-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	K+1 salt	lgK:3.2 (2SF)	5	CRV	2556
2	25	1	KNO3	lgK:3.14 (3SF)	5	MGL	2261

Reaction No. 31423							
Ca+2 + H+1_NEtIm(MePhos)*2-4 = Ca+2_H+1_NEtIm(MePhos)*2-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:1.66 (3SF)	5	MGL	2261

Reaction No. 31431							
Ca+2_NEtIm(MePhos)*2-4 + H+1 = Ca+2_H+1_NEtIm(MePhos)*2-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	K+1 salt	lgK:10.4 (3SF)	5	CRV	2556

Reaction No. 31451							
4Am1OHBullDiPhos-4 + Ca+2 = Ca+2_4Am1OHBullDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:6.10 (3SF)	5	MGL	2261


Reaction No. 31452							
Ca+2 + H+1_4Am1OHBullDiPhos-4 = Ca+2_H+1_4Am1OHBullDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:6.01 (3SF)	5	MGL	2261

Reaction No. 31453							
Ca+2 + H+1(2)_4Am1OHBullDiPhos-4 = Ca+2_H+1(2)_4Am1OHBullDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.37 (3SF)	5	MGL	2261

Reaction No. 31479							
SHOrotic-2 + Ca+2 = Ca+2_SHOrotic-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:2.95 (3SF)	5	MGL	2261

Reaction No. 31480




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:2.15 (3SF)	5	MGL	2261

Reaction No. 31496




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:3.15 (3SF)	5	MGL	2261

Reaction No. 31497




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:2.26 (3SF)	5	MGL	2261

Reaction No. 32008




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.71 (3SF)	5	MGL	2261

Reaction No. 32009




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.57 (3SF)	5	MGL	2261

Reaction No. 32010



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.38 (3SF)	5	MGL	2261

Reaction No. 32027



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:6.17 (3SF)	5	MGL	2261

Reaction No. 32028							
Ca+2 + H+1_1OH3NEtAmPrDiPhos-4 = Ca+2_H+1_1OH3NEtAmPrDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:6.09 (3SF)	5	MGL	2261

Reaction No. 32029							
Ca+2 + H+1(2)_1OH3NEtAmPrDiPhos-4 = Ca+2_H+1(2)_1OH3NEtAmPrDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.21 (3SF)	5	MGL	2261

Reaction No. 32047							
ADOPPH-5 + Ca+2 = Ca+2_ADOPPH-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:7.40 (3SF)	5	MGL	2261

Reaction No. 32048							
Ca+2 + H+1_ADOPPH-5 = Ca+2_H+1_ADOPPH-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:6.23 (3SF)	5	MGL	2261

Reaction No. 32049							
Ca+2 + H+1(2)_ADOPPH-5 = Ca+2_H+1(2)_ADOPPH-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:4.33 (3SF)	5	MGL	2261

Reaction No. 32050							
Ca+2 + H+1(3)_ADOPPH-5 = Ca+2_H+1(3)_ADOPPH-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:2.9 (2SF)	4	MGL	2261

Reaction No. 32051							
Ca+2 + H+1(4)_ADOPPH-5 = Ca+2_H+1(4)_ADOPPH-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:2.34 (3SF)	5	MGL	2261

Reaction No. 32148							
Phenol-1 + Ca+2 = Ca+2_Phenol-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	20	0.02	Unknown	lgK:1.93 (3SF)	4	MIX	2261
2	25	0	Inf. Dilution	lgK:1.00 (0.07MD)	4	MGL	5989
3	20	0.02	Unknown	dH:13. (2SF)	4	ENS	2261

Reaction No. 32253							
2Am3PhosPr-3 + Ca+2 = Ca+2_2Am3PhosPr-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:1.82 (3SF)	5	MGL	6868

Reaction No. 32254							
Ca+2 + H+1_2Am3PhosPr-3 = Ca+2_H+1_2Am3PhosPr-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:1.0 (0.1SD)	5	MGL	6868

Reaction No. 32401							
N25DiCOOPhenIDA-4 + Ca+2 = Ca+2_N25DiCOOPhenIDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.05 (3SF)	5	CRV	2556
2	25	0.1	KNO3	dH:1.6 (2SF)	5	CRV	2556

Reaction No. 32493							
Ca+2 + H+1_EDTMP-8 = Ca+2_H+1_EDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.3 (0.05SD)	1	MPT	906
2	25	0.1	KNO3	lgK:4.48 (3SF)	2	MGL	1595

Reaction No. 32494							
Ca+2 + H+1(2)_EDTMP-8 = Ca+2_H+1(2)_EDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.4 (0.05SD)	4	MPT	906
2	25	0.1	KNO3	lgK:3.85 (3SF)	3	MGL	1595

Reaction No. 32495							
Ca+2 + H+1(3)_EDTMP-8 = Ca+2_H+1(3)_EDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.22 (3SF)	0	MGL	1595

Reaction No. 32631							
--------------------	--	--	--	--	--	--	--

Acac-1 + Ca+2 = Ca+2_Acac-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.76 (3SF)	5	MGL	3617
2	25	0	UCT_Sea	lgK:2.71 (0.01SD)	4	EDH	5390
3	25	0.1	NaNO3	lgK:2.32 (3SF)	6	MGL	3617
4	25	0.1	UCT_Sea	lgK:2.32 (0.01SD)	4	EDH	5390
5	25	0.2	UCT_Sea	lgK:2.24 (0.01SD)	4	EDH	5390
6	25	0.3	UCT_Sea	lgK:2.20 (0.01SD)	4	EDH	5390
7	25	0.4	UCT_Sea	lgK:2.17 (0.01SD)	4	EDH	5390
8	25	0.5	UCT_Sea	lgK:2.15 (0.01SD)	4	EDH	5390
9	25	0.6	UCT_Sea	lgK:2.14 (0.01SD)	4	EDH	5390
10	25	0.7	UCT_Sea	lgK:2.13 (0.01SD)	4	EDH	5390

Reaction No. 32767							
NNBis2OHEtAla-1 + Ca+2 = Ca+2_NNBis2OHEtAla-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:2.26 (3SF)	6	MEF	1997


Reaction No. 32781							
N2OHEt2MeIDA-2 + Ca+2 = Ca+2_N2OHEt2MeIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.70 (3SF)	6	MEF	1997

Reaction No. 32897							
[18]N2O4:DiMalon-4 + Ca+2 = Ca+2_[18]N2O4:DiMalon-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:7.55 (3SF)	5	MGL	6135
2	25	0.16	NaCl	lgK:7.54 (3SF)	5	MGL	2717

Reaction No. 32907							
[18]N2O4:MeCOO*2-2 + Ca+2 = Ca+2_[18]N2O4:MeCOO*2-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:7.67 (3SF)	0	CRV	552
Note (1): Low wgt for internal consistency							
2	25	0.1	KCl	lgK:8.39 (3SF)	5	MGL	2717
3	25	0.1	Me4NCl	lgK:8.707 (0.003SD)	6	MGL	1007
4	25	0.1	Me4NCl	lgK:8.39 (0.06SD)	5	MGL	6644


5	25	0.1	Me4NNO3	lgK:8.71(0.003SD)	6	MGL	1007
6	25	0.1	NaNO3	lgK:8.57(0.02SD)	6	MGL	3898
7	25	0.1	Unknown	lgK:8.6(2SF)	6	ENS	1384
8	25	0.1	Me4NNO3	dH:-9.0(2SF)	6	CRV	552
9	25	0.1	Me4NNO3	dH:-8.3(2SF)	5	MCL	1007

Reaction No. 32948




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:11.77(4SF)	6	MPT	2011

Reaction No. 32953




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:11.84(4SF)	6	MPT	2011

Reaction No. 33018




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:6.17(0.02SD)	6	MGL	2595

Reaction No. 33023




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:6.05(0.02SD)	6	MGL	2595

Reaction No. 33028




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:6.22(0.01SD)	6	MGL	2595

Reaction No. 33033




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:6.24(0.01SD)	6	MGL	2595

Reaction No. 33185




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:5.6(0.2SD)	6	MGL	2961

Reaction No. 33186



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:1.6(0.1SD)	6	MGL	2961
2	25	0.1	NaClO4	lgK:1.19(0.02SD)	3	MPS	2961


Reaction No. 33411



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:1.3(0.05SD)	0	MPS	2961


Note (1): Thermodynamically isolated

Reaction No. 34233




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:0.7(0.1SD)	5	MSP	931

Reaction No. 34252




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:1.1(0.1SD)	5	MSP	931

Reaction No. 34255




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:0.9(0.1SD)	5	MSP	931

Reaction No. 34258



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:1.74(0.02SD)	5	MSP	931

Reaction No. 34346



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	18:20	0.02	Unknown	lgK:5.4 (2SF)	5	MSP	140
---	-------	------	---------	---------------	---	-----	-----

Reaction No. 34444							
Ca+2 + H+1_GlyGly-1 = Ca+2_H+1_GlyGly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:2.04 (3SF)	5	MGL	3363
2	25	0	Inf. Dilution	lgK:2.1 (2SF)	1	ESC	

Reaction No. 34445							
Ca+2 + H+1_GlyAla-1 = Ca+2_H+1_GlyAla-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:2.02 (3SF)	5	MGL	3363

Reaction No. 34446							
Ca+2 + H+1_GlyLeu-1 = Ca+2_H+1_GlyLeu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.93 (3SF)	5	MGL	3363

Reaction No. 34447							
Ca+2 + H+1_GlyPro-1 = Ca+2_H+1_GlyPro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:2.57 (3SF)	5	MGL	3363

Reaction No. 34448							
Ca+2 + H+1_AlaGly-1 = Ca+2_H+1_AlaGly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.87 (3SF)	5	MGL	3363

Reaction No. 34449							
Ca+2 + H+1_LeuGly-1 = Ca+2_H+1_LeuGly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.74 (3SF)	5	MGL	3363
2	25	0	Inf. Dilution	lgK:1.8 (2SF)	1	ESC	

Reaction No. 34450							
Ca+2 + H+1_ProGly-1 = Ca+2_H+1_ProGly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.50 (3SF)	5	MGL	3363

Reaction No. 34451							
Ca+2 + H+1_AlaAla-1 = Ca+2_H+1_AlaAla-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:2.15 (3SF)	5	MGL	3363

Reaction No. 34452							
Ca+2 + H+1_AlaLeu-1 = Ca+2_H+1_AlaLeu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.74 (3SF)	5	MGL	3363

Reaction No. 34453							
Ca+2 + H+1_ProAla-1 = Ca+2_H+1_ProAla-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.77 (3SF)	5	MGL	3363


Reaction No. 34454							
Ca+2 + H+1_ProLeu-1 = Ca+2_H+1_ProLeu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:2.22 (3SF)	5	MGL	3363

Reaction No. 34690							
Cysam-1 + Ca+2 = Ca+2_Cysam-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:2.60 (0.01SD)	4	EDH	5390
2	25	0.1	KNO3	lgK:2.21 (3SF)	5	MGL	931
3	25	0.1	UCT_Sea	lgK:2.21 (0.01SD)	4	EDH	5390
4	25	0.2	UCT_Sea	lgK:2.13 (0.01SD)	4	EDH	5390
5	25	0.3	UCT_Sea	lgK:2.09 (0.01SD)	4	EDH	5390
6	25	0.4	UCT_Sea	lgK:2.06 (0.01SD)	4	EDH	5390
7	25	0.5	UCT_Sea	lgK:2.04 (0.01SD)	4	EDH	5390
8	25	0.6	UCT_Sea	lgK:2.03 (0.01SD)	4	EDH	5390
9	25	0.7	UCT_Sea	lgK:2.02 (0.01SD)	4	EDH	5390

Reaction No. 35377							
Ca+2 + Cl-1 + NO3-1 = Ca+2_Cl-1_NO3-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:-3.0 (2SF)	1	EES	
---	----	---	---------------	----------------	---	-----	--

Reaction No. 35379




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.07 (1SF)	2	EMS	12547

Reaction No. 35535




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18	0.2	Ba(NO3)2	lgK:-0.3 (1SF)	3	MKN	140

Reaction No. 35559



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.55 (2SF)	4	MGL	140

Reaction No. 35803



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	KCl	lgK:2.50 (3SF)	3	MGL	3283
2	25	0.1	Et4NC1O4	lgK:2.7 (0.2SD)	5	MGL	3920
3	25	0.1	KCl	lgK:3.204 (4SF)	0	MKN	4542
4	25	0.1	Me4NOH	lgK:2.301 (4SF)	0	MKN	4931
5	25			lgK:2.50 (3SF)	5	MGL	2931
6	25	0.1	Me4NOH	dH:-0.3 (1SF)	4	MTD	4931
7	25	0.1	MeCN Et4NC1O4	lgK:8.5 (0.2SD)	5	MGL	3920
8	25	0.1	MeCN:Water 10:90Wgt Et4NC1O4	lgK:3.5 (0.2SD)	5	MGL	3920
9	25	0.1	MeCN:Water 20:80Wgt Et4NC1O4	lgK:4.4 (0.2SD)	5	MGL	3920
10	25	0.1	MeCN:Water 30:70Wgt Et4NC1O4	lgK:4.8 (0.2SD)	5	MGL	3920
11	25	0.1	MeCN:Water 40:60Wgt Et4NC1O4	lgK:5.0 (0.2SD)	5	MGL	3920

12	25	0.1	MeCN:Water 50:50Wgt Et4NC1O4	lgK:5.5 (0.2SD)	5	MGL	3920
13	25	0.1	MeCN:Water 60:40Wgt Et4NC1O4	lgK:6.3 (0.1SD)	5	MGL	3920
14	25	0.1	MeCN:Water 70:30Wgt Et4NC1O4	lgK:6.7 (0.1SD)	5	MGL	3920
15	25	0.1	MeCN:Water 90:10Wgt Et4NC1O4	lgK:7.7 (0.1SD)	5	MGL	3920
16	23		Methanol	lgK:2.53 (3SF)	3	MCL	4772
17	25	0.01	Methanol:Water 95:5Vol KCl	lgK:4.34 (3SF)	3	MGL	3283
18	25	0.1	Methanol:Water 95:5Vol Me4NC1	lgK:4.5 (2SF)	5	MGL	3712
19	25		PrCarbonate	lgK:8.65 (3SF)	5	MGL	2931

Reaction No. 35811							
[2.2.1]crypt + Ca+2 = Ca+2_[2.2.1]crypt							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	KCl	lgK:6.95 (3SF)	5	MGL	3283
2	25	0.1	KCl	lgK:6.792 (4SF)	5	MKN	4542
3	25	0.1	Me4NOH	lgK:6.863 (4SF)	5	MKN	4931
4	25	0.1	Me4NOH	dH:-1.3 (2SF)	4	MTD	4931
5	25	0.1	Unknown	dH:-2.892 (4SF)	4	EMU	5404
6	25	0.01	DMF Et4NC1O4	lgK:6.67 (3SF)	5	MGL	2931
7	25	0.1	DMF Et4NC1O4	lgK:6.58 (3SF)	5	MAG	2920
8	25	0.1	DMSO Et4NC1O4	lgK:3.90 (3SF)	5	MAG	2920
9	25	0.1	DMSO Et4NC1O4	lgK:3.5 (0.05SD)	5	MGL	5404
10	25	0.1	DMSO Et4NC1O4	dH:-6.334 (4SF)	5	MCL	5404
11	25	0.1	Methanol Et4NC1O4	lgK:9.92 (3SF)	5	MAG	2920
12	25	0.01	Methanol:Water 95:5Vol KCl	lgK:9.61 (3SF)	5	MGL	3283

13	25	0.1	PrCarbonate Et4NClO4	lgK:11.48 (4SF)	5	MAG	2920
14	25		PrCarbonate	lgK:11.5 (0.1SD)	5	MPT	4822

Reaction No. 35863							
2<H+1> + 13FDDS-4 + Ca+2 = Ca+2_H+1(2)_13FDDS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:10.90 (0.02SD)	5	MGL	3802

Reaction No. 35864							
H+1 + 13FDDS-4 + Ca+2 = Ca+2_H+1_13FDDS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:6.72 (0.008SD)	5	MGL	3802

Reaction No. 35865							
13FDDS-4 + Ca+2 = Ca+2_13FDDS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:1.58 (0.007SD)	5	MGL	3802


Reaction No. 36077							
Ca+2_5ADP-3 + H+1 = Ca+2_H+1_5ADP-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.4 (2SF)	1	ELC	
2	25	0.1	NaClO4	lgK:4.10 (3SF)	0	MGL	3905
3	25	0.1	NaClO4	dH:-5.18 (3SF) kJ	2	MCL	3905

Reaction No. 36078							
Ca+2_5ATP-4 + H+1 = Ca+2_H+1_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:4.85 (3SF)	5	MGL	3905
2	25	0.1	NaNO3	lgK:4.76 (0.025SD)	5	MGL	6100
3	70	0.2	Me4NCl	lgK:5.6 (2SF)	0	MGL	1437
4	25	0.1	NaClO4	dH:-0.41 (2SF) kJ	5	MCL	3905

Reaction No. 36131							
1PrEDTA-4 + Ca+2 = Ca+2_1PrEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:11.74 (4SF)	6	MPL	2011


2	25	0.1	Unknown	lgK:11.6(3SF)	6	ENS	1384
---	----	-----	---------	---------------	---	-----	------

Reaction No. 36243




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:8.23(0.01SD)	5	MGL	3201
2	20	0.1	Unknown	lgK:8.31(3SF)	6	CRV	552
3	25	0.1	KNO3	lgK:8.15(0.01SD)	5	MGL	3201
4	25	0.1	Me4N+ salt	lgK:8.40(3SF)	6	CRV	552
5	25	0.1	Unknown	lgK:8.2(0.06SD)	6	CRV	552
6	30	0.1	KNO3	lgK:8.06(0.01SD)	5	MGL	3201
7	35	0.1	KNO3	lgK:7.98(0.01SD)	5	MGL	3201
8	40	0.1	KNO3	lgK:7.92(0.01SD)	5	MGL	3201
9	20	0.1	Me4N+ salt	dH:-3.2(2SF)	6	CRV	552
10	20:40	0.1	KNO3	dH:-6.7(0.2SD)	0	MCL	3201
11	25	0.1	KNO3	dH:-2.51(3SF)	5	MTD	6627

Reaction No. 36450




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.0(0.03SD)	6	MPT	3908

Reaction No. 36465




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.0(0.03SD)	6	MPT	3908

Reaction No. 36525



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.1(3SF)	4	ENS	6405

Reaction No. 36544



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.7(0.03SD)	6	MPT	3908

Reaction No. 36862							
2SHPyrimidine-1 + Ca+2 = Ca+2_2SHPyrimidine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:2.41 (0.02SD)	5	MGL	3853

Reaction No. 36868							
6SHPurine-1 + Ca+2 = Ca+2_6SHPurine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:6.4 (0.2SD)	5	MGL	3853

Reaction No. 37085							
Etbis(ImMePhos)-4 + Ca+2 = Ca+2_Etbis(ImMePhos)-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2. (1SF)	3	MGL	931

Reaction No. 37113							
Ca+2 + H+1_Pyruvic-1 = Ca+2_H+1_Pyruvic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:0.80 (2SF)	3	MGL	931
2	25	0	Inf. Dilution	lgK:0.8 (3SF)	2	EAE	

Reaction No. 37119							
2<Ca+2> + H+1(-1)_OHEtDiPhos-4 = Ca+2(2)_H+1(-1)_OHEtDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:15.59 (4SF)	5	MGL	931

Reaction No. 37125							
Ca+2_Tropolone-1 + Tropolone-1 = Ca+2_Tropolone-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 50:50Wgt	lgK:3.2 (2SF)	4	MGL	140

Reaction No. 37193							
DiBenzoylmethane-1 + Ca+2 = Ca+2_DiBenzoylmethane-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:7.17 (3SF)	5	MGL	140

Reaction No. 37194							
--------------------	--	--	--	--	--	--	--

Ca+2_DiBenzoylmethane-1 + DiBenzoylmethane-1 = Ca+2_DiBenzoylmethane-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:6.38(3SF)	5	MGL	140

Reaction No. 37285							
Ca+2 + H+1_Salicylaldoxime-2 = Ca+2_H+1_Salicylaldoxime-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.92(2SF)	4	MGL	140

Reaction No. 37286							
Ca+2 + 2<H+1_Salicylaldoxime-2> = Ca+2_H+1(2)_Salicylaldoxime-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.72(3SF)	4	MGL	140

Reaction No. 37314							
6MePicol-1 + Ca+2 = Ca+2_6MePicol-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:2.25(3SF)	5	MGL	140

Reaction No. 37477							
OPhosSerLys-3 + Ca+2 = Ca+2_OPhosSerLys-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:1.53(3SF)	5	MGL	931

Reaction No. 37483							
12PhenDioxDiacet-2 + Ca+2 = Ca+2_12PhenDioxDiacet-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:3.1(2SF)	5	MGL	931

Reaction No. 37502							
Ca+2_Oxalic-2_(s) = Ca+2 + Oxalic-2							
Note: Not known to precipitate spontaneously from aqueous solutions							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KClO4	lgK:-7.9(2SF)	4	MDS	931
2	20:25	0	Inf. Dilution	lgK:-8.77(3SF)	0	EOD	29438
3	25	0	Inf. Dilution	lgK:-8.9(2SF)	3	ENS	5648
4	25	0	Inf. Dilution	lgK:-8.42(3SF)	3	ENS	7694

5	25	0	Inf. Dilution	lgK:-8.638 (4SF)	5	CRV	22551
6	30	0	Inf. Dilution	lgK:-8.59 (3SF)	3	MCE	8375
7	37	0.15	NaCl	lgK:-7.631 (4SF)	5	MSL	26689

Reaction No. 37556							
CNMeIDA-2 + Ca+2 = Ca+2_CNMeIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.75 (3SF)	6	MGL	3486

Reaction No. 37583							
Piperazine23DiCOO-2 + Ca+2 = Ca+2_Piperazine23DiCOO-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	0.1	KCl	lgK:1. (1SF)	5	MGL	140

Reaction No. 37618							
Piperazine26DiCOO-2 + Ca+2 = Ca+2_Piperazine26DiCOO-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	0.1	KCl	lgK:1. (1SF)	3	MGL	140


Reaction No. 37620							
SulfSal-3 + Ca+2 = Ca+2_SulfSal-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.39 (3SF)	4	MGL	3617
2	25	0.1	NaNO3	lgK:3.07 (3SF)	6	MGL	3617

Reaction No. 37623							
Ca+2 + H+1_SulfSal-3 = Ca+2_H+1_SulfSal-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.3 (2SF)	5	MGL	3617
2	25	1	NaNO3	lgK:0.4 (1SF)	5	MGL	3617

Reaction No. 37721							
CarbMeIDA-2 + Ca+2 = Ca+2_CarbMeIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.96 (3SF)	6	MGL	3486
2	20	0.1	Unknown	lgK:4.0 (0.05SD)	6	CRV	552
3	25	0.1	KNO3	lgK:4.01 (0.01SD)	5	MGL	6631


4	10:40	0.1	Unknown	dH:-2. (1SF)	6	CRV	552
---	-------	-----	---------	--------------	---	-----	-----

Reaction No. 37869




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaClO4	lgK:7.5 (0.2SD)	6	MGL	3938

Reaction No. 38284




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:7.90 (3SF)	0	MPT	1069

Reaction No. 38301




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:5.68 (0.01SD)	5	MGL	3898

Reaction No. 38311




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:4.60 (0.01SD)	5	MGL	3898

Reaction No. 38321




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.68 (3SF)	6	MGL	3486

Reaction No. 38343



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.5 (2SF)	3	MGL	3486
2	25	0.1	KNO3	lgK:1.5 (0.2MD)	5	MGL	2551
3	30	0.1	KCl	lgK:1.5 (2SF)	4	MGL	4250
4	25	0.1	KNO3	dH:1.6 (0.2MD)	5	MCL	2551


Reaction No. 38355



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	20	0.1	KCl	lgK:4.53 (3SF)	6	MGL	3486
2	25	0.1	Unknown	lgK:4.66 (3SF)	6	CRV	552

Reaction No. 38390




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.88 (3SF)	6	MGL	3486

Reaction No. 38391




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.77 (3SF)	6	MGL	3486

Reaction No. 38416




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.34 (3SF)	6	MGL	3486
2	25	0.1	Unknown	lgK:3.41 (3SF)	6	CRV	552

Reaction No. 38444




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.63 (3SF)	6	MGL	3486

Reaction No. 38486




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.88 (3SF)	6	MGL	3486

Reaction No. 38506



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.99 (3SF)	6	MGL	3486

Reaction No. 38575



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0.05	Methanol Et4NC1O4	lgK:3.49 (3SF)	4	MPT	3850
2	25	0.05	Methanol Et4NC1O4	dH:-6.0 (2SF) kJ	4	MCL	3850

Reaction No. 38578							
[2.2.2]crypt:DiLactam + Ca+2 = Ca+2_[2.2.2]crypt:DiLactam							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Methanol Et4NC1O4	lgK:3.58 (3SF)	4	MPT	3850
2	25	0.05	Methanol Et4NC1O4	dH:-18.8 (3SF) kJ	4	MCL	3850


Reaction No. 38589							
[2.2.2]crypt:56Benz + Ca+2 = Ca+2_[2.2.2]crypt:56Benz							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Et4NC1O4	lgK:4.05 (3SF)	5	MAG	2920
2	25	0.1	DMF Et4NC1O4	lgK:2.60 (3SF)	5	MAG	2920
3	25	0.1	DMSO Et4NC1O4	lgK:2. (1SF)	3	MAG	2920
4	25	0.1	Methanol Et4NC1O4	lgK:7.19 (3SF)	5	MAG	2920
5	25	0.1	PrCarbonate Et4NC1O4	lgK:10.10 (4SF)	5	MAG	2920

Reaction No. 38592							
[2.2.2]crypt:DiBenz + Ca+2 = Ca+2_[2.2.2]crypt:DiBenz							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Et4NC1O4	lgK:3.45 (3SF)	5	MAG	2920
2	25	0.1	DMF Et4NC1O4	lgK:2. (1SF)	3	MAG	2920
3	25	0.1	DMSO Et4NC1O4	lgK:2. (1SF)	3	MAG	2920
4	25	0.1	Methanol Et4NC1O4	lgK:5.94 (3SF)	5	MAG	2920
5	25	0.1	PrCarbonate Et4NC1O4	lgK:9.74 (3SF)	5	MAG	2920

Reaction No. 38648							
Lasalocid-1 + Ca+2 = Ca+2_Lasalocid-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	DMF Inf. Dilution	lgK:2.7 (0.2SD)	5	MPT	4763
2	25	0	Ethanol Inf. Dilution	lgK:4.6 (0.2SD)	5	MPT	4763
3	25	0	Methanol Inf. Dilution	lgK:4.7 (0.2SD)	5	MPT	4763
4	25	1	Methanol Tris buffer	lgK:4.57 (3SF)	4	MPH	5674
5	25		Methanol	lgK:5.00 (3SF)	5	MPT	2599
6	25		Methanol	lgK:4.88 (3SF)	4	MPT	2604
7	25		Methanol	dH: -20.7 (3SF) kJ	5	MCL	4795
8	25	0	PrCarbonate Inf. Dilution	lgK:6.4 (0.2SD)	5	MPT	4763

Reaction No. 38686




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Acetone	lgK:1.6 (0.09SD)	4	MFL	2469
2	25		MeCN	lgK:3.7 (0.07SD)	4	MFL	2469
3	25		Methanol	lgK:1.2 (0.05SD)	4	MFL	2469

Reaction No. 38687



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Acetone	lgK:1.00 (0.02SD)	4	MFL	2469
2	25		MeCN	lgK:1.9 (0.06SD)	4	MFL	2469

Reaction No. 38693



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Acetone	lgK:1.2 (0.03SD)	4	MFL	2469
2	25	0.1	Dioxan:Water 60:40Vol NaClO4	lgK:3.61 (3SF)	5	MGL	3082
3	25		MeCN	lgK:2.4 (0.05SD)	4	MFL	2469
4	25		Methanol	lgK:1.1 (0.05SD)	4	MFL	2469


Reaction No. 38699



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25		Acetone	lgK:0.7(0.05SD)	4	MFL	2469
2	25		MeCN	lgK:2.1(0.09SD)	4	MFL	2469
3	25		Methanol	lgK:0.9(0.03SD)	4	MFL	2469

Reaction No. 38700




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		MeCN	lgK:1.0(0.06SD)	4	MFL	2469

Reaction No. 38726



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Acetone	lgK:4.04(3SF)	3	MCL	3005
2	25		Acetone	dH:-26.3(3SF)kJ	3	MCL	3005
3	25		DMF	lgK:2.3(0.08SD)	4	MPS	3910
4	25		DMSO	lgK:2.1(0.05SD)	4	MPS	3910
5	25		Methanol	lgK:2.7(0.06SD)	4	MPS	3910


Reaction No. 38729



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	lgK:0.48(2SF)	5	MPP	5757
2	25	0.1	Many Media	lgK:0.5(0.1SD)	7	CIU	13297
3	25	0.1	Acetone Unknown	lgK:5.07(0.05SD)	6	CIU	13297
4	25		Acetone	lgK:5.07(3SF)	3	MCL	3005
5	25	0.1	Acetone Unknown	dH:-39.(1.SD)kJ	6	CIU	13297
6	25		Acetone	dH:-38.9(3SF)kJ	3	MCL	3005
7	25		DMF	lgK:3.0(0.07SD)	4	MPS	3910
8	25	0.1	DMF Many Media	dH:-3.(1.SD)kJ	8	CIU	13297
9	25		DMSO	lgK:2.5(0.07SD)	4	MPS	3910
10	25	0.1	Methanol Many Media	lgK:4.0(0.2SD)	7	CIU	13297
11	25		Methanol	lgK:3.885(4SF)	5	MDG	2511
12	25		Methanol	lgK:3.90(3SF)	3	MGL	2924
13	25		Methanol	lgK:3.86(0.02SD)	5	MCL	2944


14	25		Methanol	lgK:4.3 (0.1SD)	4	MPS	3910
15	23		Methanol	dH:-2.677 (4SF)	4	MCL	4772
16	25	0.1	Methanol Many Media	dH:-11.3 (0.3SD) kJ	8	CIU	13297
17	25		Methanol	dH:-2.75 (0.07SD)	5	MCL	2944
18	25	0.1	Methanol:Water 70:30Wgt Unknown	lgK:2.51 (0.02SD)	5	MCL	4522
19	25	0.1	Methanol:Water 70:30Wgt Unknown	lgK:2.46 (0.05SD)	8	CIU	13297
20	25	0.1	Methanol:Water 70:30Wgt Unknown	dH:-17.4 (0.5SD) kJ	8	CIU	13297
21	25	0.1	Methanol:Water 90:10Wgt Unknown	lgK:2.97 (0.04SD)	8	CIU	13297
22	25	0.1	Methanol:Water 90:10Wgt Unknown	dH:-8.8 (0.1SD) kJ	8	CIU	13297
23	25	0.1	PrCarbonate Many Media	lgK:3.75 (0.07SD)	7	CIU	13297
24	25	0.1	PrCarbonate Many Media	dH:-38.5 (1.SD)	6	CIU	13297

Reaction No. 38733




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		DMF	lgK:2.0 (0.07SD)	4	MPS	3910
2	25		DMSO	lgK:2.0 (2SF)	3	MPS	3910
3	25		Methanol	lgK:2.8 (0.08SD)	4	MPS	3910

Reaction No. 38743



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:3.64 (3SF)	4	MGL	3565
2	25	0.05	Ethanol:Water 95:5Wgt Et4NC1O4	lgK:1.7 (0.09SD)	4	MPS	2713

Reaction No. 38747



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0.05	Ethanol:Water 95:5Wgt Et4NC1O4	lgK:1.40 (0.01SD)	4	MPS	2713
---	----	------	--------------------------------------	-------------------	---	-----	------

Reaction No. 38751							
2AmPyridine + Ca+2 = Ca+2_2AmPyridine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Ethanol:Water 95:5Wgt Et4NC1O4	lgK:1. (0.05SD)	4	MPS	2713

Reaction No. 39180							
HydrazineNNDiAcet-2 + Ca+2 = Ca+2_HydrazineNNDiAcet-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KCl	lgK:2.9 (2SF)	4	MGL	4250

Reaction No. 39186							
NNitrIDA-2 + Ca+2 = Ca+2_NNitrIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KCl	lgK:1.6 (2SF)	4	MGL	4250

Reaction No. 39191							
NNitrosIDA-2 + Ca+2 = Ca+2_NNitrosIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KCl	lgK:1.3 (2SF)	4	MGL	4250

Reaction No. 39303							
Ca+2 + 2<H+1_AlizarinRedS-3> = Ca+2_H+1 (2)_AlizarinRedS-3 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaCl	lgK:8.1 (0.08SD)	5	MDG	2563

Reaction No. 39344							
Tetraglyme + Ca+2 = Ca+2_Tetraglyme							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Acetone	lgK:2.49 (3SF)	3	MCL	3005
2	25		Acetone	dH:-26.8 (3SF) kJ	3	MCL	3005
3	25		Methanol	lgK:0.1 (1SF)	4	MCL	2522

Reaction No. 39353							
--------------------	--	--	--	--	--	--	--

[2.1.C5]crypt + Ca+2 = Ca+2_[2.1.C5]crypt							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Et4NC1O4	lgK:2.3(0.1SD)	5	MGL	2516
2	25	0.1	Methanol:Water 95:5Vol Et4NC1O4	lgK:3.6(0.1SD)	5	MGL	2516

Reaction No. 39361							
Pentaglyme + Ca+2 = Ca+2_Pentaglyme							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Acetone	lgK:2.51(3SF)	3	MCL	3005
2	25		Acetone	dH:-39.8(3SF)kJ	3	MCL	3005
3	25		Methanol	lgK:2.29(3SF)	5	MCN	2511

Reaction No. 39518							
2<DiBenzoylmethane-1> + Ca+2 = Ca+2_DiBenzoylmethane-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Dioxan:Water 75:25Vol	lgK:14.2(3SF)	5	MGL	2360

Reaction No. 39536							
DGalactCOOThiaproline-2 + Ca+2 = Ca+2_DGalactCOOThiaproline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:1.61(0.10SD)	5	MGL	2292

Reaction No. 39627							
NNDiMeAmMePhos-2 + Ca+2 = Ca+2_NNDiMeAmMePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.7(2SF)	5	MGL	2131

Reaction No. 39659							
Galacturonic-1 + Ca+2 = H+1 + Ca+2_H+1(-1)_Galacturonic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:-10.15(4SF)	4	MPT	2023

Reaction No. 39684							
3OH4Pyridinone-1 + Ca+2 = Ca+2_3OH4Pyridinone-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:3.12(3SF)	6	MGL	2017

Reaction No. 39685							
Ca+2_3OH4Pyridinone-1 + 3OH4Pyridinone-1 = Ca+2_3OH4Pyridinone-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:1.6(0.2SD)	6	MGL	2017

Reaction No. 39692							
Mimosine-2 + Ca+2 = Ca+2_Mimosine-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:3.24(3SF)	6	MGL	2017

Reaction No. 39693							
H+1 + Mimosine-2 + Ca+2 = Ca+2_H+1_Mimosine-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:10.49(4SF)	6	MGL	2017

Reaction No. 39694							
2<Mimosine-2> + Ca+2 = Ca+2_Mimosine-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:5.1(0.06SD)	6	MGL	2017

Reaction No. 39695							
H+1 + 2<Mimosine-2> + Ca+2 = Ca+2_H+1_Mimosine-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:13.(0.3SD)	6	MGL	2017


Reaction No. 39711							
IMimosine-2 + Ca+2 = Ca+2_IMimosine-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:3.32(3SF)	6	MGL	2017

Reaction No. 39712							
H+1 + IMimosine-2 + Ca+2 = Ca+2_H+1_IMimosine-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:11.39(4SF)	6	MGL	2017

Reaction No. 39713							
2<IMimosine-2> + Ca+2 = Ca+2_IMimosine-2(2)							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:5.0(0.2SD)	4	MGL	2017

Reaction No. 39714




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:14.0(0.2SD)	6	MGL	2017

Reaction No. 39726




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:0.4(1SF)	3	MCO	1867
2	37	0.1	NaClO4	lgK:0.2(1SF)	3	MCO	1867

Reaction No. 39728




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:0.5(1SF)	4	MCO	1867
2	37	0.1	NaClO4	lgK:0.3(1SF)	4	MCO	1867

Reaction No. 39887




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:8.06(3SF)	3	CRV	552
2	25	0.1	Me4NCl	lgK:8.7(0.04SD)	2	MGL	1491
3	25	0.1	Me4NNO3	lgK:8.68(0.003SD)	2	MGL	1176
4	25	0.1	Me4NNO3	dH:-3.6(2SF)	2	MCL	1007

Reaction No. 39942



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:11.1(0.07SD)	5	MGL	1318
2	25	1	KNO3	lgK:10.3(3SF)	5	ENS	1318


Reaction No. 39943



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	1	KNO3	lgK:19.82 (4SF)	5	ENS	1318
---	----	---	------	-----------------	---	-----	------

Reaction No. 39944




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:28.34 (4SF)	5	ENS	1318

Reaction No. 39945




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:35.2 (3SF)	5	ENS	1318

Reaction No. 39946




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:45.7 (0.04SD)	5	MGL	1318

Reaction No. 39947




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:18.67 (0.02SD)	5	MGL	1318

Reaction No. 39948




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:28.32 (0.02SD)	5	MGL	1318

Reaction No. 39949



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:36.03 (0.02SD)	5	MGL	1318

Reaction No. 40068



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:2.9 (0.1SD)	4	MGL	931

Reaction No. 40069

Ca+2 + H+1(2)_NTMP-6 = Ca+2_H+1(2)_NTMP-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:2.(0.3SD)	4	MGL	931

Reaction No. 40070							
Ca+2 + H+1(3)_NTMP-6 = Ca+2_H+1(3)_NTMP-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:1.8(0.2SD)	3	MGL	931

Reaction No. 40164							
Ca+2 + H+1_Salicylic-2 = Ca+2_Salicylic-2 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-8.816(4SF)	1	ELC	
2	25	0.5	NaCl	lgK:-10.19(0.03SD)	0	MSP	2260

Reaction No. 40200							
[Bu]11DiCOO-2 + Ca+2 = Ca+2_[Bu]11DiCOO-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:1.54(3SF)	5	MGL	931

Reaction No. 40427							
Pr12DiPhos-4 + Ca+2 = Ca+2_Pr12DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.65(3SF)	5	MGL	931


Reaction No. 40428							
Ca+2 + H+1_Pr12DiPhos-4 = Ca+2_H+1_Pr12DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.7(2SF)	5	MGL	931

Reaction No. 40437							
Pr13DiPhos-4 + Ca+2 = Ca+2_Pr13DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.58(3SF)	5	MGL	931
2	25	0.1	Unknown	lgK:2.6(2SF)	5	MGL	931

Reaction No. 40438							
Ca+2 + H+1_Pr13DiPhos-4 = Ca+2_H+1_Pr13DiPhos-4							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.8 (2SF)	5	MGL	931

Reaction No. 40459




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:6. (0.3SD)	5	MGL	2596

Reaction No. 40460




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:2.9 (0.1SD)	5	MGL	2596

Reaction No. 40461




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:2. (0.3SD)	5	MGL	2596

Reaction No. 40462




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:0.0 (1SF)	3	ENA	2596

Reaction No. 40469




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.3 (2SF)	5	MGL	931

Reaction No. 40563



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:1.77 (3SF)	5	MGL	931

Reaction No. 40564



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:1.48 (3SF)	5	MGL	931

Reaction No. 40571							
OPhosSerGly-3 + Ca+2 = Ca+2_OPhosSerGly-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:1.85 (3SF)	5	MGL	931

Reaction No. 40572							
Ca+2 + H+1_OPhosSerGly-3 = Ca+2_H+1_OPhosSerGly-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:1.30 (3SF)	5	MGL	931

Reaction No. 40600							
N2OxPrIDA-2 + Ca+2 = Ca+2_N2OxPrIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.08 (3SF)	6	MGL	931

Reaction No. 40630							
4ClPyrid26DiCOO-2 + Ca+2 = Ca+2_4ClPyrid26DiCOO-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	0.1	NaClO4	lgK:3.61 (3SF)	5	MGL	931

Reaction No. 40688							
26DiCOOPiperNAcet-3 + Ca+2 = Ca+2_26DiCOOPiperNAcet-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.41 (0.01SD)	6	MGL	931


Reaction No. 40752							
NlCOO[Hept]IDA-3 + Ca+2 = Ca+2_NlCOO[Hept]IDA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:8.24 (0.01SD)	6	MGL	2591

Reaction No. 40826							
[Hex]IDA-2 + Ca+2 = Ca+2_[Hex]IDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.34 (0.02SD)	6	MGL	931
2	25	0	Inf. Dilution	lgK:3.73 (3SF)	4	CRV	552

Reaction No. 40852							
NTetrHyPyran2MeIDA-2 + Ca+2 = Ca+2_NTetrHyPyran2MeIDA-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.86(0.01SD)	6	MGL	931

Reaction No. 40967




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:7.66(0.01SD)	6	MGL	2591

Reaction No. 41091




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.93(3SF)	6	MGL	931

Reaction No. 41146




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:8.22(0.01SD)	6	MGL	2591

Reaction No. 41168




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.85(3SF)	4	ENS	773

Reaction No. 41169




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.74(3SF)	4	ENS	773

Reaction No. 41170



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.50(4SF)	4	ENS	773


Reaction No. 41186



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:2.60(3SF)	5	MGL	6759
2	25			lgK:2.7(0.06SD)	5	MPS	3819


3	25		DMF	lgK:5.0(0.09SD)	5	MPS	3819
4	25		DMSO	lgK:4.6(0.06SD)	5	MPS	3819
5	25	0.05	Ethanol:Water 95:5Wgt Et4NClO4	lgK:6.5(0.08SD)	5	MPS	2713
6	25		Methanol	lgK:6.09(3SF)	5	MPS	3819

Reaction No. 41187




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:9.5(2SF)	5	MGL	6759

Reaction No. 41211




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:3.43(3SF)	6	ENS	233

Reaction No. 41290




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-10.23(4SF)	1	ELC	
2	25	3	NaClO4	lgK:-9.9(0.2SD)	0	MGL	3493

Reaction No. 41291




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO4	lgK:-9.5(0.04SD)	6	MGL	3493

Reaction No. 41292



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO4	lgK:-25.3(0.05SD)	6	MGL	3493

Reaction No. 41293



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO4	lgK:-34.9(0.05SD)	6	MGL	3493

Reaction No. 41294

H+1(3)_Ascorbic-2(3) + 4<Ca+2> + H2O = Ca+2(4)_OH-1_Ascorbic-2(3) + 4<H+1 >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO4	lgK:-36.1(0.07SD)	6	MGL	3493

Reaction No. 41295							
4<Ca+2> + H+1(4)_Ascorbic-2(4) + H2O = Ca+2(4)_OH-1_Ascorbic-2(4) + 5<H+1 >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO4	lgK:-44.9(0.1SD)	6	MGL	3493

Reaction No. 41547							
DTPABMA-3 + Ca+2 = Ca+2_DTPABMA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:7.2(0.04SD)	5	MGL	770
2	25	0.1	NaClO4	dH:-6.190(4SF)	5	MCL	770

Reaction No. 41548							
Ca+2 + H+1_DTPABMA-3 = Ca+2_H+1_DTPABMA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.20(0.02SD)	5	MGL	770
2	25	0.1	NaClO4	dH:-1.267(4SF)	5	MCL	770

Reaction No. 41564							
Aconitic:trans-3 + Ca+2 = Ca+2_Aconitic:trans-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	Unknown	lgK:1.50(3SF)	4	MIX	3478


Reaction No. 41611							
Ca+2_Tetracycline-2 + Gly-1 = Ca+2_Gly-1_Tetracycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:4.10(3SF)	3	MPT	1069

Reaction No. 41612							
Tetracycline-2 + Ca+2 + Gly-1 = Ca+2_Gly-1_Tetracycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:12.00(4SF)	3	MPT	1069

Reaction No. 41625							
Ca+2 + H+1(2)_Olsalazine-4 = Ca+2_H+1_Olsalazine-4 + H+1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:-8.45 (0.04SD)	5	MSP	2260

Reaction No. 41626




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:-18.9 (3SF)	5	MSP	2260

Reaction No. 41742




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.5 (2SF)	5	MHY	931

Reaction No. 41805




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1. (1SF)	3	MGL	140

Reaction No. 41822




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	29.6	0.1	Unknown	lgK:2.65 (3SF)	4	MGL	140

Reaction No. 41893




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	0.1	KCl	lgK:0.8 (1SF)	4	MGL	140

Reaction No. 41949



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:9.60 (3SF)	5	MHY	140

Reaction No. 41950



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.68 (3SF)	5	MHY	140

Reaction No. 41962							
N3COOPhenIDA-3 + Ca+2 = Ca+2_N3COOPhenIDA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.46 (3SF)	5	MHG	140

Reaction No. 41970							
N4COOPhenIDA-3 + Ca+2 = Ca+2_N4COOPhenIDA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.3 (2SF)	5	MHG	140

Reaction No. 42155							
Ca+2 + 2<H+1_AlizarinRedS-3> = Ca+2_AlizarinRedS-3(2) + 2<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaCl	lgK:-10.1 (0.2SD)	5	MPT	2563

Reaction No. 42156							
Ca+2 + H+1_AlizarinRedS-3 = Ca+2_AlizarinRedS-3 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaCl	lgK:-3.7 (0.1SD)	5	MDG	2563

Reaction No. 42178							
2<Lasalocid-1> + Ca+2 = Ca+2_Lasalocid-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:7.5 (2SF)	5	MPT	2599
2	25		Methanol	dH:-31.4 (3SF) kJ	5	MCL	4795


Reaction No. 42183							
5BrLasalocid-1 + Ca+2 = Ca+2_5BrLasalocid-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:4.81 (3SF)	5	MPT	2599

Reaction No. 42184							
2<5BrLasalocid-1> + Ca+2 = Ca+2_5BrLasalocid-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:7.4 (2SF)	5	MPT	2599

Reaction No. 42194							
oAnisic-1 + Ca+2 = Ca+2_oAnisic-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:4.7 (2SF)	5	MPT	2599

Reaction No. 42195




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:7.2 (2SF)	5	MPT	2599

Reaction No. 42786




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20:23	2	NaClO4	lgK:-0.28 (2SF)	5	MSP	906
2	20:23	4	NaClO4	lgK:-0.05 (1SF)	5	MSP	906

Reaction No. 42787




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20:23	2	NaClO4	lgK:-0.890 (3SF)	5	MSP	906
2	20:23	4	NaClO4	lgK:-0.60 (2SF)	5	MSP	906

Reaction No. 42846




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.92 (3SF)	4	MPL	906
2	25	0.1	NH4NO3	lgK:1.74 (3SF)	4	MPL	906

Reaction No. 43170



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NC1	lgK:6.33 (0.12SD)	5	MGL	3083
2	25	0.5	Me4NC1	dH:-1.02 (3SF)	5	MCL	3083

Reaction No. 43171



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NC1	lgK:3.14 (0.05SD)	5	MGL	3083

Reaction No. 43202

8AzaAdenine + Ca+2 = Ca+2_8AzaAdenine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:3.8 (2SF)	5	MGL	906

Reaction No. 43520							
26DiAmPurine-1 + Ca+2 = Ca+2_26DiAmPurine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:2.8 (2SF)	4	MGL	906

Reaction No. 43545							
5IMP-2 + Ca+2 = Ca+2_5IMP-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.50 (0.01MD)	6	MGL	4460

Reaction No. 43552							
5GMP-2 + Ca+2 = Ca+2_5GMP-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.53 (0.01MD)	6	MGL	5995

Reaction No. 43561							
Ca+2_5IMP-2 = Ca+2_H+1(-1)_5IMP-2 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:8.62 (0.04MD)	6	MGL	4460


Reaction No. 43571							
Ca+2_5GMP-2 = Ca+2_H+1(-1)_5GMP-2 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:9.0 (0.2MD)	6	MGL	4460

Reaction No. 43603							
6ClPurine + Ca+2 = Ca+2_6ClPurine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:6.2 (0.2SD)	4	MGL	906

Reaction No. 44155							
Ca+2_EDTMP-8 + Ca+2 = Ca+2(2)_EDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.0 (0.04SD)	3	MPT	906


2	25	0.15	NaCl	lgK:5.15 (3SF)	0	MSP	23315
---	----	------	------	----------------	---	-----	-------

Reaction No. 44609




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.38 (3SF)	4	MGL	906
2	25	1	Unknown	lgK:0.57 (2SF)	6	CRV	552

Reaction No. 44713



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 60:40Wgt NaClO4	lgK:3.48 (3SF)	4	MGL	3082

Reaction No. 45163




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.71 (3SF)	4	CRV	552
2	25	0.1	KCl	lgK:3.4 (2SF)	6	MGL	931

Reaction No. 45164




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.0 (2SF)	5	MGL	931

Reaction No. 45171




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:8.32 (0.01SD)	6	MGL	2591

Reaction No. 45179



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:7.46 (0.01SD)	6	MGL	2591


Reaction No. 45304



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:3.40 (3SF)	4	CRV	2556
---	----	---	---------------	----------------	---	-----	------

Reaction No. 45307



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.22 (3SF)	4	CRV	2556

Reaction No. 45324




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.71 (3SF)	4	ENS	2261

Reaction No. 45325




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.2 (2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:6.91 (3SF)	0	ENS	2261

Reaction No. 45449




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Acetone:Water 75:25Wgt KNO3	lgK:7.0 (0.07SD)	4	MGL	906

Reaction No. 45473




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Acetone:Water 75:25Wgt KNO3	lgK:7.0 (0.07SD)	4	MGL	906

Reaction No. 45500




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:6.0 (0.03SD)	5	MGL	2008

Reaction No. 45527




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:9.24 (0.02SD)	5	MGL	2008

Reaction No. 45560




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.09 (3SF)	4	MGL	906

Reaction No. 45561




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.20 (3SF)	4	MGL	906

Reaction No. 45782




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.0 (1SF)	3	MPP	5757
2	25		Methanol	lgK:2.53 (3SF)	5	MCL	2251
3	25		Methanol	dH:-2.3 (2SF) kJ	4	MCL	2251

Reaction No. 45783



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	dH:-6.6 (2SF) kJ	4	MCL	2251

Reaction No. 45837



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	DMF Inf. Dilution	lgK:6.0 (0.2SD)	5	MPT	4763
2	25	0	DMSO Inf. Dilution	lgK:5.6 (0.2SD)	5	MPT	4763
3	25	0	Ethanol Inf. Dilution	lgK:6.8 (0.2SD)	5	MPT	4763
4	25	0	Methanol Inf. Dilution	lgK:4.4 (0.2SD)	5	MPT	4763
5	25	0	PrCarbonate Inf. Dilution	lgK:11.9 (0.2SD)	5	MPT	4763

Reaction No. 45849

Ca+2_EDTMP-8 + OH-1 = Ca+2_OH-1_EDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:3.33(0.01SD)	5	MGL	4910

Reaction No. 45911							
DRibose + Ca+2 = Ca+2_DRibose							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	-9			lgK:4.6(2SF)	4	MMR	4847

Reaction No. 45921							
BuMalon-2 + Ca+2 = Ca+2_BuMalon-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.491(4SF)	5	MCO	4861
2	25	0	Inf. Dilution	dH:10.8(3SF)kJ	4	MCL	4861

Reaction No. 45924							
DiEtMalon-2 + Ca+2 = Ca+2_DiEtMalon-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:2.49(3SF)	5	MCO	4861
2	20	0	Inf. Dilution	lgK:2.534(4SF)	5	MCO	4861
3	25	0	Inf. Dilution	lgK:2.548(4SF)	5	MCO	4861
4	25	0	UCT_Sea	lgK:2.55(0.01SD)	4	EDH	5390
5	25	0.1	UCT_Sea	lgK:1.77(0.01SD)	4	EDH	5390
6	25	0.2	UCT_Sea	lgK:1.60(0.01SD)	4	EDH	5390
7	25	0.3	UCT_Sea	lgK:1.51(0.01SD)	4	EDH	5390
8	25	0.4	UCT_Sea	lgK:1.44(0.01SD)	4	EDH	5390
9	25	0.5	UCT_Sea	lgK:1.40(0.01SD)	4	EDH	5390
10	25	0.6	UCT_Sea	lgK:1.36(0.01SD)	4	EDH	5390
11	25	0.7	UCT_Sea	lgK:1.33(0.01SD)	4	EDH	5390
12	30	0	Inf. Dilution	lgK:2.583(4SF)	5	MCO	4861
13	35	0	Inf. Dilution	lgK:2.604(4SF)	5	MCO	4861
14	40	0	Inf. Dilution	lgK:2.618(4SF)	5	MCO	4861
15	25	0	Inf. Dilution	dH:10.2(3SF)kJ	4	MCL	4861
16	25	0	Inf. Dilution	dH:10.0(1.6SD)kJ	4	MCO	4861

Reaction No. 45926							
Di2PrMalon-2 + Ca+2 = Ca+2_Di2PrMalon-2							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:2.516(4SF)	5	MCO	4861
2	25	0	Inf. Dilution	lgK:2.551(4SF)	5	MCO	4861
3	30	0	Inf. Dilution	lgK:2.573(4SF)	5	MCO	4861
4	35	0	Inf. Dilution	lgK:2.623(4SF)	5	MCO	4861
5	25	0	Inf. Dilution	dH:9.(2.SD)kJ	4	MCO	4861

Reaction No. 46064							
Bul4DiPhos-4 + Ca+2 = Ca+2_Bul4DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.54(3SF)	5	MGL	931
2	25	0.1	Unknown	lgK:2.5(2SF)	3	MGL	4245

Reaction No. 46065							
Ca+2 + H+1_Bul4DiPhos-4 = Ca+2_H+1_Bul4DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.7(2SF)	5	MGL	931

Reaction No. 46161							
Ca+2_Cytosine + Cytosine = Ca+2_Cytosine(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:3.5(0.05SD)	5	MGL	3853

Reaction No. 46170							
45DiAm6OHPyrimidine-1 + Ca+2 = Ca+2_45DiAm6OHPyrimidine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:2.93(0.02SD)	4	MGL	3853

Reaction No. 46173							
24DiAm6OHPyrimidine-1 + Ca+2 = Ca+2_24DiAm6OHPyrimidine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:2.5(0.1SD)	4	MGL	3853

Reaction No. 46254							
Ca+2 + H+1_AmMePhos-2 = Ca+2_H+1_AmMePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.03(0.03MD)w	5	MPH	4478

Reaction No. 46273							
PhosForm-3 + Ca+2 = Ca+2_PhosForm-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:3.6(0.09MD)w	5	MPH	4478

Reaction No. 46274							
Ca+2 + H+1_PhosForm-3 = Ca+2_H+1_PhosForm-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.7(0.2MD)w	5	MPH	4478

Reaction No. 46331							
2<P3O10-5> + Ca+2 = Ca+2_P3O10-5(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaCl	lgK:9.41(3SF)	4	MDG	3540

Reaction No. 46332							
2<P2O7-4> + Ca+2 = Ca+2_P2O7-4(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaCl	lgK:7.21(0.08SD)	4	MDG	3540

Reaction No. 46358							
2<H+1> + 2<Tartaric-2> + Ca+2 = Ca+2_H+1(2)_Tartaric-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaClO4	lgK:10.8(0.08MD)	6	MGL	4896

Reaction No. 46362							
[15]N2O3 + Ca+2 = Ca+2_[15]N2O3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23		Methanol	lgK:2.56(3SF)	4	MCL	4772
2	23		Methanol	dH:-1.028(4SF)	4	MCL	4772

Reaction No. 46363							
[18]N2O4:DiDec + Ca+2 = Ca+2_[18]N2O4:DiDec							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23		Methanol	lgK:2.51(3SF)	4	MCL	4772
2	23		Methanol	dH:-2.796(4SF)	4	MCL	4772

Reaction No. 46365							
--------------------	--	--	--	--	--	--	--

[21]N2O5 + Ca+2 = Ca+2_[21]N2O5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23		Methanol	lgK:1.86 (3SF)	4	MPT	4772
2	23		Methanol	dH:0.0 (1SF)	4	MCL	4772

Reaction No. 46379							
2<Benzoic-1> + Ca+2 = Ca+2_Benzoic-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:7.3 (2SF)	5	MGL	4795

Reaction No. 46387							
Ca+2 + H+1_His-1 = Ca+2_H+1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:0.29 (2SF)	6	CRV	552
2	35	0.1	KNO3	lgK:3.10 (3SF)	0	MGL	1187
3	37	0.15	Unknown	lgK:0.4 (1SF)	6	CRV	552
4	25	0.1	Unknown	dH:1.0 (2SF)	6	CRV	552

Reaction No. 46394							
Ca+2_His-1 + H+1_Xanthosine-1 = Ca+2_His-1_Xanthosine-1 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.9 (2SF)	1	ESC	
2	35	0.1	KNO3	lgK:2.76 (3SF)	4	MGL	3565


Reaction No. 46404							
Ca+2 + Xanthosine-1 + H+1_Cat-2 = Ca+2_H+1_Xanthosine-1_Cat-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:5.45 (3SF)	4	MGL	3565

Reaction No. 46411							
Ca+2_Oxalic-2 + H+1_Xanthosine-1 = Ca+2_Xanthosine-1_Oxalic-2 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.5 (2SF)	1	ESC	
2	35	0.1	KNO3	lgK:8.22 (3SF)	4	MGL	3565

Reaction No. 46468							
H+1 + bAla-1 + Ca+2 = Ca+2_H+1_bAla-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.9(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:9.70(0.01SD)	3	ETS	94

Reaction No. 46469




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.4(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:1.40(0.01SD)	3	ETS	94

Reaction No. 46470




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.20(0.01SD)	3	ETS	94

Reaction No. 46488




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.20(0.01SD)	3	ETS	94

Reaction No. 46489




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.1(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:3.00(0.01SD)	3	ETS	94

Reaction No. 46490



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.40(0.01SD)	3	ETS	94


Reaction No. 46491



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:4.35(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:4.35(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.15(0.01SD)	3	ETS	94

Reaction No. 46492




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.31(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:4.31(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.35(0.01SD)	3	ETS	94

Reaction No. 46493




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.25(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.05(0.01SD)	3	ETS	94

Reaction No. 46494




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.51(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:4.51(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.55(0.01SD)	3	ETS	94

Reaction No. 46495



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.21(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.25(0.01SD)	3	ETS	94

Reaction No. 46496



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.00(0.01SD)	3	ETS	94

Reaction No. 46497

Ca+2 + Gly-1 + Citric-3 = Ca+2_Gly-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.35(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.15(0.01SD)	3	ETS	94

Reaction No. 46498							
Ca+2 + His-1 + Citric-3 = Ca+2_His-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.20(0.01SD)	3	ETS	94

Reaction No. 46499							
Ca+2 + Met-1 + Citric-3 = Ca+2_Met-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.10(0.01SD)	3	ETS	94

Reaction No. 46500							
Ca+2 + Phe-1 + Citric-3 = Ca+2_Phe-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.10(0.01SD)	3	ETS	94


Reaction No. 46501							
Ca+2 + Ser-1 + Citric-3 = Ca+2_Ser-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.35(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.15(0.01SD)	3	ETS	94

Reaction No. 46502							
Ca+2 + Thr-1 + Citric-3 = Ca+2_Thr-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.00(0.01SD)	3	ETS	94

Reaction No. 46503							
Ca+2 + Trp-1 + Citric-3 = Ca+2_Trp-1_Citric-3							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.10(0.01SD)	3	ETS	94

Reaction No. 46504




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.00(0.01SD)	3	ETS	94

Reaction No. 46505




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.92(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.20(0.01SD)	3	ETS	94

Reaction No. 46506




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.1(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:2.00(0.01SD)	3	ETS	94

Reaction No. 46507




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.12(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.40(0.01SD)	3	ETS	94

Reaction No. 46508



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.87(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.15(0.01SD)	3	ETS	94


Reaction No. 46509



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:3.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.35(0.01SD)	3	ETS	94

Reaction No. 46510




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.77(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.05(0.01SD)	3	ETS	94

Reaction No. 46511




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.51(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.55(0.01SD)	3	ETS	94

Reaction No. 46512




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.21(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.25(0.01SD)	3	ETS	94

Reaction No. 46513




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.72(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.00(0.01SD)	3	ETS	94

Reaction No. 46514



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.87(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.15(0.01SD)	3	ETS	94


Reaction No. 46515



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.92(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:2.20 (0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 46516




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.67 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.95 (0.01SD)	3	ETS	94

Reaction No. 46517




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.72 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.00 (0.01SD)	3	ETS	94

Reaction No. 46518




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.72 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.00 (0.01SD)	3	ETS	94

Reaction No. 46519




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.82 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.10 (0.01SD)	3	ETS	94

Reaction No. 46520



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.82 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.10 (0.01SD)	3	ETS	94

Reaction No. 46521



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.87 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.15 (0.01SD)	3	ETS	94

Reaction No. 46522							
Ca+2 + Thr-1 + Lactic-1 = Ca+2_Lactic-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.72 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.00 (0.01SD)	3	ETS	94

Reaction No. 46523							
Ca+2 + Trp-1 + Lactic-1 = Ca+2_Lactic-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.82 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.10 (0.01SD)	3	ETS	94

Reaction No. 46524							
Ca+2 + Val-1 + Lactic-1 = Ca+2_Lactic-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.72 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.00 (0.01SD)	3	ETS	94

Reaction No. 46525							
Ca+2 + Citric-3 + Lactic-1 = Ca+2_Lactic-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.30 (0.01SD)	3	ETS	94

Reaction No. 46526							
Ca+2 + Ala-1 + Malic-2 = Ca+2_Ala-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.36 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.40 (0.01SD)	3	ETS	94

Reaction No. 46527							
Ca+2 + Arg-1 + Malic-2 = Ca+2_Arg-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.56 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.60 (0.01SD)	3	ETS	94

Reaction No. 46528							
--------------------	--	--	--	--	--	--	--

Ca+2 + Asn-1 + Malic-2 = Ca+2_Asn-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.35(0.01SD)	3	ETS	94

Reaction No. 46529							
Ca+2 + Gln-1 + Malic-2 = Ca+2_Gln-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.16(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.20(0.01SD)	3	ETS	94

Reaction No. 46530							
Ca+2 + Gly-1 + Malic-2 = Ca+2_Gly-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.35(0.01SD)	3	ETS	94

Reaction No. 46531							
Ca+2 + His-1 + Malic-2 = Ca+2_His-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.36(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.40(0.01SD)	3	ETS	94


Reaction No. 46532							
Ca+2 + Phe-1 + Malic-2 = Ca+2_Phe-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.26(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.30(0.01SD)	3	ETS	94

Reaction No. 46533							
Ca+2 + Ser-1 + Malic-2 = Ca+2_Ser-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.35(0.01SD)	3	ETS	94

Reaction No. 46534							
Ca+2 + Thr-1 + Malic-2 = Ca+2_Thr-1_Malic-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.16(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.20(0.01SD)	3	ETS	94

Reaction No. 46535




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.16(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.20(0.01SD)	3	ETS	94

Reaction No. 46536




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.46(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.50(0.01SD)	3	ETS	94

Reaction No. 46537




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.46(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.50(0.01SD)	3	ETS	94

Reaction No. 46538




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.36(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.40(0.01SD)	3	ETS	94

Reaction No. 46539



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.56(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.60(0.01SD)	3	ETS	94


Reaction No. 46540



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:3.31(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:3.31(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:2.35(0.01SD)	3	ETS	94

Reaction No. 46541




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.16(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:3.16(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:2.20(0.01SD)	3	ETS	94

Reaction No. 46542




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.35(0.01SD)	3	ETS	94

Reaction No. 46543




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.36(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:3.36(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:2.40(0.01SD)	3	ETS	94

Reaction No. 46544



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.26(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.30(0.01SD)	3	ETS	94

Reaction No. 46545



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.35(0.01SD)	3	ETS	94

Reaction No. 46546

Ca+2 + Thr-1 + Oxalic-2 = Ca+2_Thr-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.16(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.20(0.01SD)	3	ETS	94

Reaction No. 46547							
Ca+2 + Val-1 + Oxalic-2 = Ca+2_Val-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.16(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.20(0.01SD)	3	ETS	94

Reaction No. 46548							
Ca+2 + Citric-3 + Oxalic-2 = Ca+2_Oxalic-2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.46(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.50(0.01SD)	3	ETS	94

Reaction No. 46549							
Oxalic-2 + Lactic-1 + Ca+2 = Ca+2_Lactic-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.46(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:3.46(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:2.50(0.01SD)	3	ETS	94

Reaction No. 46550							
Oxalic-2 + Malic-2 + Ca+2 = Ca+2_Malic-2_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.66(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:3.66(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:2.70(0.01SD)	3	ETS	94

Reaction No. 46551							
Ca+2 + Lactic-1 + Salicylic-2 = Ca+2_Lactic-1_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.01(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.05(0.01SD)	3	ETS	94

Reaction No. 46552							
Ca+2 + Ala-1 + Succinic-2 = Ca+2_Ala-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.35(0.01SD)	3	ETS	94

Reaction No. 46553							
Ca+2 + Arg-1 + Succinic-2 = Ca+2_Arg-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.51(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.55(0.01SD)	3	ETS	94

Reaction No. 46554							
Ca+2 + Asn-1 + Succinic-2 = Ca+2_Asn-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.26(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.30(0.01SD)	3	ETS	94

Reaction No. 46555							
Ca+2 + Gln-1 + Succinic-2 = Ca+2_Gln-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.11(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.15(0.01SD)	3	ETS	94

Reaction No. 46556							
Ca+2 + Gly-1 + Succinic-2 = Ca+2_Gly-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.26(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.30(0.01SD)	3	ETS	94

Reaction No. 46557							
Ca+2 + His-1 + Succinic-2 = Ca+2_His-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.35(0.01SD)	3	ETS	94

Reaction No. 46558							
--------------------	--	--	--	--	--	--	--

Ca+2 + Phe-1 + Succinic-2 = Ca+2_Phe-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.21(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.25(0.01SD)	3	ETS	94

Reaction No. 46559							
Ca+2 + Ser-1 + Succinic-2 = Ca+2_Ser-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.26(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.30(0.01SD)	3	ETS	94

Reaction No. 46560							
Ca+2 + Thr-1 + Succinic-2 = Ca+2_Thr-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.11(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.15(0.01SD)	3	ETS	94

Reaction No. 46561							
Ca+2 + Val-1 + Succinic-2 = Ca+2_Val-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.11(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.15(0.01SD)	3	ETS	94


Reaction No. 46562							
Ca+2 + Citric-3 + Succinic-2 = Ca+2_Succinic-2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.41(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.45(0.01SD)	3	ETS	94

Reaction No. 46563							
Ca+2 + Lactic-1 + Succinic-2 = Ca+2_Lactic-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.41(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.45(0.01SD)	3	ETS	94

Reaction No. 46564							
Ca+2 + Malic-2 + Succinic-2 = Ca+2_Malic-2_Succinic-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.61(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.65(0.01SD)	3	ETS	94

Reaction No. 46565




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.61(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.65(0.01SD)	3	ETS	94

Reaction No. 46566




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.35(0.01SD)	3	ETS	94

Reaction No. 46567




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.10(0.01SD)	3	ETS	94

Reaction No. 46568




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.40(0.01SD)	3	ETS	94

Reaction No. 46569



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.00(0.01SD)	3	ETS	94


Reaction No. 46570



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:12.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.50 (0.01SD)	3	ETS	94

Reaction No. 46571




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.95 (0.01SD)	3	ETS	94

Reaction No. 46572




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.15 (0.01SD)	3	ETS	94

Reaction No. 46573




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.05 (0.01SD)	3	ETS	94

Reaction No. 46574




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.05 (0.01SD)	3	ETS	94

Reaction No. 46575



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.10 (0.01SD)	3	ETS	94

Reaction No. 46576



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7 (3SF)	2	EAE	

2	37	0.15	Blood Plasma	lgK:10.95(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 46577							
H+1 + Ca+2 + Citric-3 + Ala-1 = Ca+2_H+1_Ala-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.25(0.01SD)	3	ETS	94

Reaction No. 46578							
H+1 + Ca+2 + Lactic-1 + Ala-1 = Ca+2_H+1_Ala-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.25(0.01SD)	3	ETS	94

Reaction No. 46579							
H+1 + Ca+2 + Malic-2 + Ala-1 = Ca+2_H+1_Ala-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.45(0.01SD)	3	ETS	94

Reaction No. 46580							
H+1 + Ca+2 + Oxalic-2 + Ala-1 = Ca+2_H+1_Ala-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.45(0.01SD)	3	ETS	94

Reaction No. 46581							
H+1 + Ca+2 + Succinic-2 + Ala-1 = Ca+2_H+1_Ala-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.40(0.01SD)	3	ETS	94

Reaction No. 46582							
H+1 + Ca+2 + Gln-1 + bAla-1 = Ca+2_H+1_bAla-1_Gln-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.0(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:10.70(0.01SD)	3	ETS	94

Reaction No. 46583							
H+1 + Ca+2 + Citric-3 + bAla-1 = Ca+2_H+1_bAla-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2 (3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:11.90 (0.01SD)	3	ETS	94

Reaction No. 46584							
H+1 + Ca+2 + Lactic-1 + bAla-1 = Ca+2_H+1_bAla-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.2 (3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:10.90 (0.01SD)	3	ETS	94

Reaction No. 46585							
H+1 + Ca+2 + Malic-2 + bAla-1 = Ca+2_H+1_bAla-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.4 (3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:11.10 (0.01SD)	3	ETS	94

Reaction No. 46586							
H+1 + Ca+2 + Oxalic-2 + bAla-1 = Ca+2_H+1_bAla-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.4 (3SF)	1	EAE	
2	25	0	Inf. Dilution	lgK:11.5 (3SF)	1	ESC	
3	37	0.15	Blood Plasma	lgK:11.10 (0.01SD)	3	ETS	94

Reaction No. 46587							
H+1 + Ca+2 + Succinic-2 + bAla-1 = Ca+2_H+1_bAla-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.4 (3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:11.05 (0.01SD)	3	ETS	94

Reaction No. 46588							
2<H+1> + Ca+2 + Ala-1 + bAla-1 = Ca+2_H+1(2)_Ala-1_bAla-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4 (3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.85 (0.01SD)	3	ETS	94

Reaction No. 46589							
H+1 + Ca+2 + Asn-1 + Arg-1 = Ca+2_H+1_Arg-1_Asn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.78 (0.01SD)	3	ETS	94

Reaction No. 46590							
H+1 + Ca+2 + Asp-2 + Arg-1 = Ca+2_H+1_Arg-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.25 (0.01SD)	3	ETS	94

Reaction No. 46591							
H+1 + Ca+2 + Glu-2 + Arg-1 = Ca+2_H+1_Arg-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.45 (0.01SD)	3	ETS	94

Reaction No. 46592							
H+1 + Ca+2 + Gln-1 + Arg-1 = Ca+2_H+1_Arg-1_Gln-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.70 (0.01SD)	3	ETS	94

Reaction No. 46593							
H+1 + Ca+2 + Gly-1 + Arg-1 = Ca+2_H+1_Arg-1_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.30 (0.01SD)	3	ETS	94

Reaction No. 46594							
H+1 + Ca+2 + His-1 + Arg-1 = Ca+2_H+1_Arg-1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.95 (0.01SD)	3	ETS	94

Reaction No. 46595							
--------------------	--	--	--	--	--	--	--

H+1 + Ca+2 + Pro-1 + Arg-1 = Ca+2_H+1_Arg-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.30(0.01SD)	3	ETS	94

Reaction No. 46596							
H+1 + Ca+2 + Ser-1 + Arg-1 = Ca+2_H+1_Arg-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.80(0.01SD)	3	ETS	94

Reaction No. 46597							
H+1 + Ca+2 + Thr-1 + Arg-1 = Ca+2_H+1_Arg-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.75(0.01SD)	3	ETS	94

Reaction No. 46598							
H+1 + Ca+2 + Val-1 + Arg-1 = Ca+2_H+1_Arg-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.10(0.01SD)	3	ETS	94


Reaction No. 46599							
H+1 + Ca+2 + Citric-3 + Arg-1 = Ca+2_H+1_Arg-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.70(0.01SD)	3	ETS	94

Reaction No. 46600							
H+1 + Ca+2 + Lactic-1 + Arg-1 = Ca+2_H+1_Arg-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.70(0.01SD)	3	ETS	94

Reaction No. 46601							
H+1 + Ca+2 + Malic-2 + Arg-1 = Ca+2_H+1_Arg-1_Malic-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.90(0.01SD)	3	ETS	94

Reaction No. 46602




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.90(0.01SD)	3	ETS	94

Reaction No. 46603




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.85(0.01SD)	3	ETS	94

Reaction No. 46604




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.65(0.01SD)	3	ETS	94

Reaction No. 46605




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.30(0.01SD)	3	ETS	94

Reaction No. 46606



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.45(0.01SD)	3	ETS	94


Reaction No. 46607



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:11.8 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:11.8 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:11.05 (0.01SD)	3	ETS	94

Reaction No. 46608




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.05 (0.01SD)	3	ETS	94

Reaction No. 46609




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.50 (0.01SD)	3	ETS	94

Reaction No. 46610




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.85 (0.01SD)	3	ETS	94

Reaction No. 46611




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.2 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:13.2 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:11.50 (0.01SD)	3	ETS	94

Reaction No. 46612




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.50 (0.01SD)	3	ETS	94

Reaction No. 46613




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.70(0.01SD)	3	ETS	94

Reaction No. 46614




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:11.9(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:10.70(0.01SD)	3	ETS	94

Reaction No. 46615




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.65(0.01SD)	3	ETS	94

Reaction No. 46616




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.45(0.01SD)	3	ETS	94

Reaction No. 46617




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.10(0.01SD)	3	ETS	94

Reaction No. 46618




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.90(0.01SD)	3	ETS	94

Reaction No. 46619




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.95(0.01SD)	3	ETS	94

Reaction No. 46620




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.5(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:12.5(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:11.35(0.01SD)	3	ETS	94

Reaction No. 46621




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.95(0.01SD)	3	ETS	94

Reaction No. 46622




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.8(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:13.8(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:12.15(0.01SD)	3	ETS	94

Reaction No. 46623



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.15(0.01SD)	3	ETS	94

Reaction No. 46624



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.35(0.01SD)	3	ETS	94

Reaction No. 46625

Oxalic-2 + Asp-2 + H+1 + Ca+2 = Ca+2_H+1_Asp-2_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.8(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:12.8(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:11.35(0.01SD)	3	ETS	94

Reaction No. 46626							
H+1 + Ca+2 + Succinic-2 + Asp-2 = Ca+2_H+1_Asp-2_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.30(0.01SD)	3	ETS	94

Reaction No. 46627							
2<H+1> + Ca+2 + Ala-1 + Asp-2 = Ca+2_H+1(2)_Ala-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.10(0.01SD)	3	ETS	94

Reaction No. 46628							
2<H+1> + Ca+2 + bAla-1 + Asp-2 = Ca+2_H+1(2)_bAla-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.75(0.01SD)	3	ETS	94

Reaction No. 46629							
2<H+1> + Ca+2 + Arg-1 + Asp-2 = Ca+2_H+1(2)_Arg-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.55(0.01SD)	3	ETS	94

Reaction No. 46630							
2<H+1> + Ca+2 + Asn-1 + Asp-2 = Ca+2_H+1(2)_Asn-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.35(0.01SD)	3	ETS	94

Reaction No. 46631							
--------------------	--	--	--	--	--	--	--

H+1 + Ca+2 + Gln-1 + Citrul-1 = Ca+2_H+1_Citrul-1_Gln-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.35(0.01SD)	3	ETS	94

Reaction No. 46632							
Gly-1 + Citrul-1 + H+1 + Ca+2 = Ca+2_H+1_Citrul-1_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:11.7(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:10.95(0.01SD)	3	ETS	94

Reaction No. 46633							
H+1 + Ca+2 + Pro-1 + Citrul-1 = Ca+2_H+1_Citrul-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.95(0.01SD)	3	ETS	94

Reaction No. 46634							
H+1 + Ca+2 + Citric-3 + Citrul-1 = Ca+2_H+1_Citrul-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.45(0.01SD)	3	ETS	94

Reaction No. 46635							
H+1 + Ca+2 + Lactic-1 + Citrul-1 = Ca+2_H+1_Citrul-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.45(0.01SD)	3	ETS	94

Reaction No. 46636							
H+1 + Ca+2 + Malic-2 + Citrul-1 = Ca+2_H+1_Citrul-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.65(0.01SD)	3	ETS	94

Reaction No. 46637							
--------------------	--	--	--	--	--	--	--

Oxalic-2 + Citrul-1 + H+1 + Ca+2 = Ca+2_H+1_Citrul-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:11.8(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:10.65(0.01SD)	3	ETS	94

Reaction No. 46638							
H+1 + Ca+2 + Succinic-2 + Citrul-1 = Ca+2_H+1_Citrul-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.60(0.01SD)	3	ETS	94

Reaction No. 46639							
2<H+1> + Ca+2 + Ala-1 + Citrul-1 = Ca+2_H+1(2)_Ala-1_Citrul-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.40(0.01SD)	3	ETS	94

Reaction No. 46640							
2<H+1> + Ca+2 + Arg-1 + Citrul-1 = Ca+2_H+1(2)_Arg-1_Citrul-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.85(0.01SD)	3	ETS	94

Reaction No. 46641							
2<H+1> + Ca+2 + Asn-1 + Citrul-1 = Ca+2_H+1(2)_Asn-1_Citrul-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.65(0.01SD)	3	ETS	94

Reaction No. 46642							
2<H+1> + Ca+2 + Asp-2 + Citrul-1 = Ca+2_H+1(2)_Citrul-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.30(0.01SD)	3	ETS	94

Reaction No. 46643							
--------------------	--	--	--	--	--	--	--

H+1 + Ca+2 + Citric-3 + Cys-2 = Ca+2_H+1_Cys-2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.15(0.01SD)	3	ETS	94

Reaction No. 46644							
H+1 + Ca+2 + Lactic-1 + Cys-2 = Ca+2_H+1_Lactic-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.15(0.01SD)	3	ETS	94

Reaction No. 46645							
H+1 + Ca+2 + Malic-2 + Cys-2 = Ca+2_H+1_Cys-2_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.35(0.01SD)	3	ETS	94

Reaction No. 46646							
Oxalic-2 + Cys-2 + H+1 + Ca+2 = Ca+2_H+1_Cys-2_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.8(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:13.8(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:12.35(0.01SD)	3	ETS	94

Reaction No. 46647							
H+1 + Ca+2 + Succinic-2 + Cys-2 = Ca+2_H+1_Cys-2_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.30(0.01SD)	3	ETS	94

Reaction No. 46648							
2<H+1> + Ca+2 + Ala-1 + Cys-2 = Ca+2_H+1(2)_Ala-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.10(0.01SD)	3	ETS	94

Reaction No. 46649							
--------------------	--	--	--	--	--	--	--

2<H+1> + Ca+2 + Arg-1 + Cys-2 = Ca+2_H+1(2)_Arg-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.55(0.01SD)	3	ETS	94

Reaction No. 46650							
H+1 + Ca+2 + Gln-1 + Cis-2 = Ca+2_H+1_Gln-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.98(0.01SD)	3	ETS	94

Reaction No. 46651							
H+1 + Ca+2 + Pro-1 + Cis-2 = Ca+2_H+1_Pro-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.45(0.01SD)	3	ETS	94

Reaction No. 46652							
Citric-3 + Cis-2 + H+1 + Ca+2 = Ca+2_H+1_Cis-2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.7(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:13.7(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:12.05(0.01SD)	3	ETS	94

Reaction No. 46653							
H+1 + Ca+2 + Lactic-1 + Cis-2 = Ca+2_H+1_Lactic-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.05(0.01SD)	3	ETS	94

Reaction No. 46654							
H+1 + Ca+2 + Malic-2 + Cis-2 = Ca+2_H+1_Cis-2_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.25(0.01SD)	3	ETS	94

Reaction No. 46655							
--------------------	--	--	--	--	--	--	--

Oxalic-2 + Cis-2 + H+1 + Ca+2 = Ca+2_H+1_Cis-2_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.7(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:12.7(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:11.25(0.01SD)	3	ETS	94

Reaction No. 46656							
H+1 + Ca+2 + Succinic-2 + Cis-2 = Ca+2_H+1_Cis-2_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.20(0.01SD)	3	ETS	94

Reaction No. 46657							
2<H+1> + Ca+2 + Ala-1 + Cis-2 = Ca+2_H+1(2)_Ala-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.00(0.01SD)	3	ETS	94

Reaction No. 46658							
2<H+1> + Ca+2 + bAla-1 + Cis-2 = Ca+2_H+1(2)_bAla-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.65(0.01SD)	3	ETS	94

Reaction No. 46659							
2<H+1> + Ca+2 + Arg-1 + Cis-2 = Ca+2_H+1(2)_Arg-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.45(0.01SD)	3	ETS	94

Reaction No. 46660							
2<H+1> + Ca+2 + Asn-1 + Cis-2 = Ca+2_H+1(2)_Asn-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.25(0.01SD)	3	ETS	94

Reaction No. 46661							
--------------------	--	--	--	--	--	--	--

2<H+1> + Ca+2 + Asp-2 + Cis-2 = Ca+2_H+1(2)_Asp-2_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.90(0.01SD)	3	ETS	94

Reaction No. 46662							
2<H+1> + Ca+2 + Citrul-1 + Cis-2 = Ca+2_H+1(2)_Citrul-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.20(0.01SD)	3	ETS	94

Reaction No. 46663							
H+1 + Ca+2 + Gln-1 + Glu-2 = Ca+2_H+1_Gln-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.05(0.01SD)	3	ETS	94

Reaction No. 46664							
H+1 + Ca+2 + Citric-3 + Glu-2 = Ca+2_H+1_Glu-2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.35(0.01SD)	3	ETS	94


Reaction No. 46665							
H+1 + Ca+2 + Lactic-1 + Glu-2 = Ca+2_H+1_Lactic-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.35(0.01SD)	3	ETS	94

Reaction No. 46666							
H+1 + Ca+2 + Malic-2 + Glu-2 = Ca+2_H+1_Glu-2_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.55(0.01SD)	3	ETS	94

Reaction No. 46667							
Oxalic-2 + Glu-2 + H+1 + Ca+2 = Ca+2_H+1_Glu-2_Oxalic-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.0(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:13.0(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:11.55(0.01SD)	3	ETS	94

Reaction No. 46668




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.50(0.01SD)	3	ETS	94

Reaction No. 46669




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.30(0.01SD)	3	ETS	94

Reaction No. 46670




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.5(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.95(0.01SD)	3	ETS	94

Reaction No. 46671




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.75(0.01SD)	3	ETS	94

Reaction No. 46672




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.55(0.01SD)	3	ETS	94

Reaction No. 46673




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.20(0.01SD)	3	ETS	94

Reaction No. 46674




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.50(0.01SD)	3	ETS	94

Reaction No. 46675




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.10(0.01SD)	3	ETS	94

Reaction No. 46676




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.6(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:11.6(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:10.90(0.01SD)	3	ETS	94

Reaction No. 46677




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.63(0.01SD)	3	ETS	94

Reaction No. 46678




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.70(0.01SD)	3	ETS	94

Reaction No. 46679




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.80 (0.01SD)	3	ETS	94

Reaction No. 46680




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.80 (0.01SD)	3	ETS	94

Reaction No. 46681




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.53 (0.01SD)	3	ETS	94

Reaction No. 46682




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.53 (0.01SD)	3	ETS	94

Reaction No. 46683




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.90 (0.01SD)	3	ETS	94

Reaction No. 46684



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.53 (0.01SD)	3	ETS	94


Reaction No. 46685



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:11.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.43(0.01SD)	3	ETS	94

Reaction No. 46686




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.65(0.01SD)	3	ETS	94

Reaction No. 46687




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.70(0.01SD)	3	ETS	94

Reaction No. 46688




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.50(0.01SD)	3	ETS	94

Reaction No. 46689




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.50(0.01SD)	3	ETS	94

Reaction No. 46690



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.70(0.01SD)	3	ETS	94


Reaction No. 46691



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9(4SF)	1	EOR	


2	25	0	Inf. Dilution	lgK:11.9(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:10.70(0.01SD)	3	ETS	94

Reaction No. 46692




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.65(0.01SD)	3	ETS	94

Reaction No. 46693




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.45(0.01SD)	3	ETS	94

Reaction No. 46694




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.10(0.01SD)	3	ETS	94

Reaction No. 46695




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.90(0.01SD)	3	ETS	94

Reaction No. 46696



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.70(0.01SD)	3	ETS	94

Reaction No. 46697



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.5(3SF)	2	EAE	

2	37	0.15	Blood Plasma	lgK:19.35(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 46698							
2<H+1> + Ca+2 + Citrul-1 + Gln-1 = Ca+2_H+1(2)_Citrul-1_Gln-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.65(0.01SD)	3	ETS	94

Reaction No. 46699							
2<H+1> + Ca+2 + Cys-2 + Gln-1 = Ca+2_H+1(2)_Gln-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.35(0.01SD)	3	ETS	94

Reaction No. 46700							
2<H+1> + Ca+2 + Cis-2 + Gln-1 = Ca+2_H+1(2)_Gln-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.25(0.01SD)	3	ETS	94


Reaction No. 46701							
Ca+2 + 2<H+1> + Glu-2 + Gln-1 = Ca+2_H+1(2)_Gln-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.0(3SF)	1	EES	
2	37	0.15	Blood Plasma	lgK:19.55(0.01SD)	0	ETS	94
3	37	0.15	NaCl	lgK:21.65(4SF)	2	MGL	22560

Reaction No. 46702							
H+1 + Ca+2 + His-1 + Gly-1 = Ca+2_H+1_Gly-1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.20(0.01SD)	3	ETS	94

Reaction No. 46703							
H+1 + Ca+2 + Met-1 + Gly-1 = Ca+2_H+1_Gly-1_Met-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:11.10(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 46704




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.05(0.01SD)	3	ETS	94

Reaction No. 46705




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.00(0.01SD)	3	ETS	94

Reaction No. 46706




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.20(0.01SD)	3	ETS	94

Reaction No. 46707




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.20(0.01SD)	3	ETS	94

Reaction No. 46708



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.40(0.01SD)	3	ETS	94

Reaction No. 46709



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.40(0.01SD)	3	ETS	94

Reaction No. 46710							
$\text{H}+1 + \text{Ca}+2 + \text{Succinic-2} + \text{Gly-1} = \text{Ca}+2_ \text{H}+1_ \text{Gly-1_ Succinic-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.35 (0.01SD)	3	ETS	94

Reaction No. 46711							
$2<\text{H}+1> + \text{Ca}+2 + \text{Ala-1} + \text{Gly-1} = \text{Ca}+2_ \text{H}+1(2)_ \text{Ala-1_ Gly-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.15 (0.01SD)	3	ETS	94

Reaction No. 46712							
$2<\text{H}+1> + \text{Ca}+2 + \text{bAla-1} + \text{Gly-1} = \text{Ca}+2_ \text{H}+1(2)_ \text{bAla-1_ Gly-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3 (3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.80 (0.01SD)	3	ETS	94

Reaction No. 46713							
$2<\text{H}+1> + \text{Ca}+2 + \text{Arg-1} + \text{Gly-1} = \text{Ca}+2_ \text{H}+1(2)_ \text{Arg-1_ Gly-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.60 (0.01SD)	3	ETS	94

Reaction No. 46714							
$\text{Gly-1} + \text{Asn-1} + 2<\text{H}+1> + \text{Ca}+2 = \text{Ca}+2_ \text{H}+1(2)_ \text{Asn-1_ Gly-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:19.9 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:19.40 (0.01SD)	3	ETS	94

Reaction No. 46715							
$\text{Gly-1} + \text{Asp-2} + 2<\text{H}+1> + \text{Ca}+2 = \text{Ca}+2_ \text{H}+1(2)_ \text{Gly-1_ Asp-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.2 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:21.2 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:20.05 (0.01SD)	3	ETS	94

Reaction No. 46716							
Gly-1 + Citrul-1 + 2<H+1> + Ca+2 = Ca+2_H+1(2)_Citrul-1_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:19.35(0.01SD)	3	ETS	94

Reaction No. 46717							
Gly-1 + Cys-2 + 2<H+1> + Ca+2 = Ca+2_H+1(2)_Gly-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.2(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:22.2(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:21.05(0.01SD)	3	ETS	94

Reaction No. 46718							
Gly-1 + Cis-2 + 2<H+1> + Ca+2 = Ca+2_H+1(2)_Gly-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.1(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:21.1(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:19.95(0.01SD)	3	ETS	94

Reaction No. 46719							
Gly-1 + Glu-2 + 2<H+1> + Ca+2 = Ca+2_H+1(2)_Gly-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.4(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:21.4(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:20.25(0.01SD)	3	ETS	94

Reaction No. 46720							
Gly-1 + Gln-1 + 2<H+1> + Ca+2 = Ca+2_H+1(2)_Gln-1_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:19.40(0.01SD)	3	ETS	94

Reaction No. 46721							
--------------------	--	--	--	--	--	--	--

H+1 + Ca+2 + Pro-1 + His-1 = Ca+2_H+1_His-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.10(0.01SD)	3	ETS	94

Reaction No. 46722							
H+1 + Ca+2 + Thr-1 + His-1 = Ca+2_H+1_His-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.68(0.01SD)	3	ETS	94

Reaction No. 46723							
H+1 + Ca+2 + Citric-3 + His-1 = Ca+2_H+1_His-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.75(0.01SD)	3	ETS	94

Reaction No. 46724							
H+1 + Ca+2 + Lactic-1 + His-1 = Ca+2_H+1_His-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.75(0.01SD)	3	ETS	94

Reaction No. 46725							
H+1 + Ca+2 + Malic-2 + His-1 = Ca+2_H+1_His-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.95(0.01SD)	3	ETS	94

Reaction No. 46726							
Oxalic-2 + His-1 + H+1 + Ca+2 = Ca+2_H+1_His-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:12.1(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:10.95(0.01SD)	3	ETS	94

Reaction No. 46727							
--------------------	--	--	--	--	--	--	--

H+1 + Ca+2 + Succinic-2 + His-1 = Ca+2_H+1_His-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.90(0.01SD)	3	ETS	94

Reaction No. 46728							
2<H+1> + Ca+2 + Ala-1 + His-1 = Ca+2_H+1(2)_Ala-1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.70(0.01SD)	3	ETS	94

Reaction No. 46729							
2<H+1> + Ca+2 + bAla-1 + His-1 = Ca+2_H+1(2)_bAla-1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	1	EAE	
2	25	0	Inf. Dilution	lgK:19.7(3SF)	1	ESC	
3	37	0.15	Blood Plasma	lgK:19.35(0.01SD)	3	ETS	94

Reaction No. 46730							
2<H+1> + Ca+2 + Arg-1 + His-1 = Ca+2_H+1(2)_Arg-1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.15(0.01SD)	3	ETS	94

Reaction No. 46731							
2<H+1> + Ca+2 + Asn-1 + His-1 = Ca+2_H+1(2)_Asn-1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.95(0.01SD)	3	ETS	94

Reaction No. 46732							
2<H+1> + Ca+2 + Asp-2 + His-1 = Ca+2_H+1(2)_His-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.60(0.01SD)	3	ETS	94

Reaction No. 46733							
--------------------	--	--	--	--	--	--	--

2<H+1> + Ca+2 + Citrul-1 + His-1 = Ca+2_H+1(2)_Citrul-1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.90 (0.01SD)	3	ETS	94

Reaction No. 46734							
2<H+1> + Ca+2 + Cys-2 + His-1 = Ca+2_H+1(2)_His-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.60 (0.01SD)	3	ETS	94

Reaction No. 46735							
2<H+1> + Ca+2 + Cys-2 + His-1 = Ca+2_H+1(2)_His-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.50 (0.01SD)	3	ETS	94

Reaction No. 46736							
2<H+1> + Ca+2 + Glu-2 + His-1 = Ca+2_H+1(2)_His-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80 (0.01SD)	3	ETS	94


Reaction No. 46737							
2<H+1> + Ca+2 + Gln-1 + His-1 = Ca+2_H+1(2)_Gln-1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.95 (0.01SD)	3	ETS	94

Reaction No. 46738							
2<H+1> + Ca+2 + Gly-1 + His-1 = Ca+2_H+1(2)_Gly-1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.65 (0.01SD)	3	ETS	94

Reaction No. 46739							
H+1 + Ca+2 + Citric-3 + Hyp-1 = Ca+2_H+1_Hyp-1_Citric-3							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.00 (0.01SD)	3	ETS	94

Reaction No. 46740




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.00 (0.01SD)	3	ETS	94

Reaction No. 46741




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.20 (0.01SD)	3	ETS	94

Reaction No. 46742




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:12.4 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:11.20 (0.01SD)	3	ETS	94

Reaction No. 46743




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.15 (0.01SD)	3	ETS	94

Reaction No. 46744




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.95 (0.01SD)	3	ETS	94

Reaction No. 46745




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.40(0.01SD)	3	ETS	94

Reaction No. 46746




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.20(0.01SD)	3	ETS	94

Reaction No. 46747




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.15(0.01SD)	3	ETS	94

Reaction No. 46748




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.75(0.01SD)	3	ETS	94

Reaction No. 46749




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.05(0.01SD)	3	ETS	94

Reaction No. 46750



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.20(0.01SD)	3	ETS	94


Reaction No. 46751



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:20.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.90 (0.01SD)	3	ETS	94

Reaction No. 46752




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.45 (0.01SD)	3	ETS	94

Reaction No. 46753




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.10 (0.01SD)	3	ETS	94

Reaction No. 46754




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.10 (0.01SD)	3	ETS	94

Reaction No. 46755




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.30 (0.01SD)	3	ETS	94

Reaction No. 46756



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.5 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:12.5 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:11.30 (0.01SD)	3	ETS	94


Reaction No. 46757



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:12.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.25 (0.01SD)	3	ETS	94

Reaction No. 46758




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.05 (0.01SD)	3	ETS	94

Reaction No. 46759




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2 (3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.70 (0.01SD)	3	ETS	94

Reaction No. 46760




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.50 (0.01SD)	3	ETS	94

Reaction No. 46761




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.30 (0.01SD)	3	ETS	94

Reaction No. 46762



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.95 (0.01SD)	3	ETS	94


Reaction No. 46763



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7 (3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:19.25(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 46764




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.85(0.01SD)	3	ETS	94

Reaction No. 46765




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.15(0.01SD)	3	ETS	94

Reaction No. 46766




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.30(0.01SD)	3	ETS	94

Reaction No. 46767




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.00(0.01SD)	3	ETS	94

Reaction No. 46768



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.55(0.01SD)	3	ETS	94

Reaction No. 46769



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80(0.01SD)	3	ETS	94

Reaction No. 46770							
H+1 + Ca+2 + Citric-3 + Leu-1 = Ca+2_H+1_Leu-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.10(0.01SD)	3	ETS	94

Reaction No. 46771							
H+1 + Ca+2 + Lactic-1 + Leu-1 = Ca+2_H+1_Lactic-1_Leu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.10(0.01SD)	3	ETS	94

Reaction No. 46772							
H+1 + Ca+2 + Malic-2 + Leu-1 = Ca+2_H+1_Leu-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.30(0.01SD)	3	ETS	94

Reaction No. 46773							
Oxalic-2 + Leu-1 + H+1 + Ca+2 = Ca+2_H+1_Leu-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.5(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:12.5(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:11.30(0.01SD)	3	ETS	94

Reaction No. 46774							
H+1 + Ca+2 + Succinic-2 + Leu-1 = Ca+2_H+1_Leu-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.25(0.01SD)	3	ETS	94

Reaction No. 46775							
2<H+1> + Ca+2 + Ala-1 + Leu-1 = Ca+2_H+1(2)_Ala-1_Leu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.05(0.01SD)	3	ETS	94

Reaction No. 46776							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{bAla-1} + \text{Leu-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{bAla-1}}_{\text{Leu-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.70(0.01SD)	3	ETS	94

Reaction No. 46777							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Arg-1} + \text{Leu-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Arg-1}}_{\text{Leu-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.50(0.01SD)	3	ETS	94

Reaction No. 46778							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Asn-1} + \text{Leu-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Asn-1}}_{\text{Leu-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.30(0.01SD)	3	ETS	94

Reaction No. 46779							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Asp-2} + \text{Leu-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Leu-1}}_{\text{Asp-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.95(0.01SD)	3	ETS	94

Reaction No. 46780							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Citru1-1} + \text{Leu-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Citru1-1}}_{\text{Leu-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.25(0.01SD)	3	ETS	94

Reaction No. 46781							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Cys-2} + \text{Leu-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Leu-1}}_{\text{Cys-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.95(0.01SD)	3	ETS	94

Reaction No. 46782							
--------------------	--	--	--	--	--	--	--

2<H+1> + Ca+2 + Cis-2 + Leu-1 = Ca+2_H+1(2)_Leu-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.85(0.01SD)	3	ETS	94

Reaction No. 46783							
2<H+1> + Ca+2 + Glu-2 + Leu-1 = Ca+2_H+1(2)_Leu-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.15(0.01SD)	3	ETS	94

Reaction No. 46784							
2<H+1> + Ca+2 + Gln-1 + Leu-1 = Ca+2_H+1(2)_Gln-1_Leu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.30(0.01SD)	3	ETS	94

Reaction No. 46785							
2<H+1> + Ca+2 + Gly-1 + Leu-1 = Ca+2_H+1(2)_Gly-1_Leu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.00(0.01SD)	3	ETS	94


Reaction No. 46786							
2<H+1> + Ca+2 + His-1 + Leu-1 = Ca+2_H+1(2)_His-1_Leu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.55(0.01SD)	3	ETS	94

Reaction No. 46787							
2<H+1> + Ca+2 + Hyp-1 + Leu-1 = Ca+2_H+1(2)_Hyp-1_Leu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80(0.01SD)	3	ETS	94

Reaction No. 46788							
2<H+1> + Ca+2 + Ile-1 + Leu-1 = Ca+2_H+1(2)_Ile-1_Leu-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.90 (0.01SD)	3	ETS	94

Reaction No. 46789




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.9 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.20 (0.01SD)	3	ETS	94

Reaction No. 46790




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.9 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.20 (0.01SD)	3	ETS	94

Reaction No. 46791




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.40 (0.01SD)	3	ETS	94

Reaction No. 46792




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.6 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:13.6 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:12.40 (0.01SD)	3	ETS	94

Reaction No. 46793




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.35 (0.01SD)	3	ETS	94

Reaction No. 46794




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.65(0.01SD)	3	ETS	94

Reaction No. 46795




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.65(0.01SD)	3	ETS	94

Reaction No. 46796




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.85(0.01SD)	3	ETS	94

Reaction No. 46797




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:10.85(0.01SD)	3	ETS	94

Reaction No. 46798




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.80(0.01SD)	3	ETS	94

Reaction No. 46799




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.60(0.01SD)	3	ETS	94

Reaction No. 46800




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.25(0.01SD)	3	ETS	94

Reaction No. 46801




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.05(0.01SD)	3	ETS	94

Reaction No. 46802




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.85(0.01SD)	3	ETS	94

Reaction No. 46803




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.50(0.01SD)	3	ETS	94

Reaction No. 46804




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.80(0.01SD)	3	ETS	94

Reaction No. 46805



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.40(0.01SD)	3	ETS	94


Reaction No. 46806



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:20.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.70(0.01SD)	3	ETS	94

Reaction No. 46807




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.85(0.01SD)	3	ETS	94

Reaction No. 46808




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.55(0.01SD)	3	ETS	94

Reaction No. 46809




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.10(0.01SD)	3	ETS	94

Reaction No. 46810




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.35(0.01SD)	3	ETS	94

Reaction No. 46811



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.45(0.01SD)	3	ETS	94

Reaction No. 46812



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	

2	37	0.15	Blood Plasma	lgK:19.45(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 46813							
H+1 + Ca+2 + Citric-3 + Orn-1 = Ca+2_H+1_Orn-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.95(0.01SD)	3	ETS	94

Reaction No. 46814							
H+1 + Ca+2 + Lactic-1 + Orn-1 = Ca+2_H+1_Lactic-1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.95(0.01SD)	3	ETS	94

Reaction No. 46815							
2<H+1> + Ca+2 + Ala-1 + Orn-1 = Ca+2_H+1(2)_Ala-1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.90(0.01SD)	3	ETS	94

Reaction No. 46816							
2<H+1> + Ca+2 + Gln-1 + Orn-1 = Ca+2_H+1(2)_Gln-1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.15(0.01SD)	3	ETS	94

Reaction No. 46817							
H+1 + Ca+2 + Citric-3 + Phe-1 = Ca+2_H+1_Phe-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.60(0.01SD)	3	ETS	94

Reaction No. 46818							
H+1 + Ca+2 + Lactic-1 + Phe-1 = Ca+2_H+1_Lactic-1_Phe-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.60(0.01SD)	3	ETS	94

Reaction No. 46819							
H+1 + Ca+2 + Malic-2 + Phe-1 = Ca+2_H+1_Phe-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.80(0.01SD)	3	ETS	94

Reaction No. 46820							
H+1 + Ca+2 + Oxalic-2 + Phe-1 = Ca+2_H+1_Phe-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.80(0.01SD)	3	ETS	94

Reaction No. 46821							
H+1 + Ca+2 + Succinic-2 + Phe-1 = Ca+2_H+1_Phe-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.75(0.01SD)	3	ETS	94

Reaction No. 46822							
2<H+1> + Ca+2 + Ala-1 + Phe-1 = Ca+2_H+1(2)_Ala-1_Phe-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.55(0.01SD)	3	ETS	94

Reaction No. 46823							
2<H+1> + Ca+2 + bAla-1 + Phe-1 = Ca+2_H+1(2)_bAla-1_Phe-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.20(0.01SD)	3	ETS	94

Reaction No. 46824							
2<H+1> + Ca+2 + Arg-1 + Phe-1 = Ca+2_H+1(2)_Arg-1_Phe-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.00(0.01SD)	3	ETS	94

Reaction No. 46825							
--------------------	--	--	--	--	--	--	--

2<H+1> + Ca+2 + Asn-1 + Phe-1 = Ca+2_H+1(2)_Asn-1_Phe-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.80(0.01SD)	3	ETS	94

Reaction No. 46826							
2<H+1> + Ca+2 + Asp-2 + Phe-1 = Ca+2_H+1(2)_Phe-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.45(0.01SD)	3	ETS	94

Reaction No. 46827							
2<H+1> + Ca+2 + Citrul-1 + Phe-1 = Ca+2_H+1(2)_Citrul-1_Phe-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.75(0.01SD)	3	ETS	94

Reaction No. 46828							
2<H+1> + Ca+2 + Cis-2 + Phe-1 = Ca+2_H+1(2)_Phe-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.35(0.01SD)	3	ETS	94


Reaction No. 46829							
2<H+1> + Ca+2 + Glu-2 + Phe-1 = Ca+2_H+1(2)_Phe-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.65(0.01SD)	3	ETS	94

Reaction No. 46830							
2<H+1> + Ca+2 + Gln-1 + Phe-1 = Ca+2_H+1(2)_Gln-1_Phe-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.80(0.01SD)	3	ETS	94

Reaction No. 46831							
2<H+1> + Ca+2 + Gly-1 + Phe-1 = Ca+2_H+1(2)_Gly-1_Phe-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.50(0.01SD)	3	ETS	94

Reaction No. 46832




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.05(0.01SD)	3	ETS	94

Reaction No. 46833




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.30(0.01SD)	3	ETS	94

Reaction No. 46834




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.40(0.01SD)	3	ETS	94

Reaction No. 46835




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.40(0.01SD)	3	ETS	94

Reaction No. 46836



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.95(0.01SD)	3	ETS	94


Reaction No. 46837



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:12.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.05(0.01SD)	3	ETS	94

Reaction No. 46838




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.90(0.01SD)	3	ETS	94

Reaction No. 46839




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.20(0.01SD)	3	ETS	94

Reaction No. 46840




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.20(0.01SD)	3	ETS	94

Reaction No. 46841




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.40(0.01SD)	3	ETS	94

Reaction No. 46842



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.40(0.01SD)	3	ETS	94


Reaction No. 46843



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.5(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:12.35(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 46844




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.15(0.01SD)	3	ETS	94

Reaction No. 46845




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.3(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:20.80(0.01SD)	3	ETS	94

Reaction No. 46846




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.60(0.01SD)	3	ETS	94

Reaction No. 46847




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.40(0.01SD)	3	ETS	94

Reaction No. 46848



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.05(0.01SD)	3	ETS	94

Reaction No. 46849



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.35(0.01SD)	3	ETS	94

Reaction No. 46850							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Cys-2} + \text{Pro-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Pro-1}}_{\text{Cys-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.05(0.01SD)	3	ETS	94

Reaction No. 46851							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Cis-2} + \text{Pro-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Pro-1}}_{\text{Cis-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.95(0.01SD)	3	ETS	94

Reaction No. 46852							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Glu-2} + \text{Pro-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Pro-1}}_{\text{Glu-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.25(0.01SD)	3	ETS	94

Reaction No. 46853							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Gln-1} + \text{Pro-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Gln-1}}_{\text{Pro-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.40(0.01SD)	3	ETS	94

Reaction No. 46854							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Gly-1} + \text{Pro-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Gly-1}}_{\text{Pro-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.10(0.01SD)	3	ETS	94

Reaction No. 46855							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{His-1} + \text{Pro-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{His-1}}_{\text{Pro-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.65(0.01SD)	3	ETS	94

Reaction No. 46856							
--------------------	--	--	--	--	--	--	--

2<H+1> + Ca+2 + Hyp-1 + Pro-1 = Ca+2_H+1(2)_Hyp-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.90 (0.01SD)	3	ETS	94

Reaction No. 46857							
2<H+1> + Ca+2 + Ile-1 + Pro-1 = Ca+2_H+1(2)_Ile-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.00 (0.01SD)	3	ETS	94

Reaction No. 46858							
2<H+1> + Ca+2 + Leu-1 + Pro-1 = Ca+2_H+1(2)_Leu-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.00 (0.01SD)	3	ETS	94

Reaction No. 46859							
2<H+1> + Ca+2 + Met-1 + Pro-1 = Ca+2_H+1(2)_Met-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.55 (0.01SD)	3	ETS	94


Reaction No. 46860							
2<H+1> + Ca+2 + Phe-1 + Pro-1 = Ca+2_H+1(2)_Phe-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.50 (0.01SD)	3	ETS	94

Reaction No. 46861							
H+1 + Ca+2 + Citric-3 + Ser-1 = Ca+2_H+1_Ser-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.60 (0.01SD)	3	ETS	94

Reaction No. 46862							
H+1 + Ca+2 + Lactic-1 + Ser-1 = Ca+2_H+1_Lactic-1_Ser-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.60(0.01SD)	3	ETS	94

Reaction No. 46863




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.80(0.01SD)	3	ETS	94

Reaction No. 46864




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.80(0.01SD)	3	ETS	94

Reaction No. 46865




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.75(0.01SD)	3	ETS	94

Reaction No. 46866




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.55(0.01SD)	3	ETS	94

Reaction No. 46867



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.20(0.01SD)	3	ETS	94


Reaction No. 46868



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:19.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.00(0.01SD)	3	ETS	94

Reaction No. 46869




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.80(0.01SD)	3	ETS	94

Reaction No. 46870




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.45(0.01SD)	3	ETS	94

Reaction No. 46871




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.75(0.01SD)	3	ETS	94

Reaction No. 46872




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.45(0.01SD)	3	ETS	94

Reaction No. 46873



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.35(0.01SD)	3	ETS	94

Reaction No. 46874



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.8(3SF)	2	EAE	

2	37	0.15	Blood Plasma	lgK:19.65 (0.01SD)	3	ETS	94
---	----	------	--------------	--------------------	---	-----	----

Reaction No. 46875							
2<H+1> + Ca+2 + Gln-1 + Ser-1 = Ca+2_H+1(2)_Gln-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.80 (0.01SD)	3	ETS	94

Reaction No. 46876							
2<H+1> + Ca+2 + Gly-1 + Ser-1 = Ca+2_H+1(2)_Gly-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.50 (0.01SD)	3	ETS	94

Reaction No. 46877							
2<H+1> + Ca+2 + His-1 + Ser-1 = Ca+2_H+1(2)_His-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.05 (0.01SD)	3	ETS	94

Reaction No. 46878							
2<H+1> + Ca+2 + Hyp-1 + Ser-1 = Ca+2_H+1(2)_Hyp-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.30 (0.01SD)	3	ETS	94

Reaction No. 46879							
2<H+1> + Ca+2 + Ile-1 + Ser-1 = Ca+2_H+1(2)_Ile-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.40 (0.01SD)	3	ETS	94

Reaction No. 46880							
2<H+1> + Ca+2 + Leu-1 + Ser-1 = Ca+2_H+1(2)_Leu-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.40 (0.01SD)	3	ETS	94

Reaction No. 46881							
2<H+1> + Ca+2 + Met-1 + Ser-1 = Ca+2_H+1(2)_Met-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.95(0.01SD)	3	ETS	94

Reaction No. 46882							
2<H+1> + Ca+2 + Phe-1 + Ser-1 = Ca+2_H+1(2)_Phe-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.90(0.01SD)	3	ETS	94

Reaction No. 46883							
2<H+1> + Ca+2 + Pro-1 + Ser-1 = Ca+2_H+1(2)_Pro-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.50(0.01SD)	3	ETS	94

Reaction No. 46884							
H+1 + Ca+2 + Citric-3 + Thr-1 = Ca+2_H+1_Thr-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.55(0.01SD)	3	ETS	94

Reaction No. 46885							
H+1 + Ca+2 + Lactic-1 + Thr-1 = Ca+2_H+1_Lactic-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.55(0.01SD)	3	ETS	94

Reaction No. 46886							
H+1 + Ca+2 + Malic-2 + Thr-1 = Ca+2_H+1_Thr-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.75(0.01SD)	3	ETS	94

Reaction No. 46887							
--------------------	--	--	--	--	--	--	--

H+1 + Ca+2 + Oxalic-2 + Thr-1 = Ca+2_H+1_Thr-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.75(0.01SD)	3	ETS	94

Reaction No. 46888							
H+1 + Ca+2 + Succinic-2 + Thr-1 = Ca+2_H+1_Thr-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.70(0.01SD)	3	ETS	94

Reaction No. 46889							
2<H+1> + Ca+2 + Ala-1 + Thr-1 = Ca+2_H+1(2)_Ala-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.50(0.01SD)	3	ETS	94

Reaction No. 46890							
2<H+1> + Ca+2 + bAla-1 + Thr-1 = Ca+2_H+1(2)_bAla-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.15(0.01SD)	3	ETS	94


Reaction No. 46891							
2<H+1> + Ca+2 + Arg-1 + Thr-1 = Ca+2_H+1(2)_Arg-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.95(0.01SD)	3	ETS	94

Reaction No. 46892							
2<H+1> + Ca+2 + Asn-1 + Thr-1 = Ca+2_H+1(2)_Asn-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.75(0.01SD)	3	ETS	94

Reaction No. 46893							
2<H+1> + Ca+2 + Asp-2 + Thr-1 = Ca+2_H+1(2)_Thr-1_Asp-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.40(0.01SD)	3	ETS	94

Reaction No. 46894




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.70(0.01SD)	3	ETS	94

Reaction No. 46895




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.40(0.01SD)	3	ETS	94

Reaction No. 46896




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.30(0.01SD)	3	ETS	94

Reaction No. 46897




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.60(0.01SD)	3	ETS	94

Reaction No. 46898



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.75(0.01SD)	3	ETS	94


Reaction No. 46899



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.45(0.01SD)	3	ETS	94

Reaction No. 46900




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.00(0.01SD)	3	ETS	94

Reaction No. 46901




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.25(0.01SD)	3	ETS	94

Reaction No. 46902




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.35(0.01SD)	3	ETS	94

Reaction No. 46903




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.35(0.01SD)	3	ETS	94

Reaction No. 46904



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.90(0.01SD)	3	ETS	94


Reaction No. 46905



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.3(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:18.85(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 46906




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.45(0.01SD)	3	ETS	94

Reaction No. 46907




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.85(0.01SD)	3	ETS	94

Reaction No. 46908




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.85(0.01SD)	3	ETS	94

Reaction No. 46909




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.85(0.01SD)	3	ETS	94

Reaction No. 46910



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.05(0.01SD)	3	ETS	94

Reaction No. 46911



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.05(0.01SD)	3	ETS	94

Reaction No. 46912							
H+1 + Ca+2 + Succinic-2 + Trp-1 = Ca+2_H+1_Trp-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.00(0.01SD)	3	ETS	94

Reaction No. 46913							
2<H+1> + Ca+2 + Ala-1 + Trp-1 = Ca+2_H+1(2)_Ala-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80(0.01SD)	3	ETS	94

Reaction No. 46914							
2<H+1> + Ca+2 + Arg-1 + Trp-1 = Ca+2_H+1(2)_Arg-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.25(0.01SD)	3	ETS	94

Reaction No. 46915							
2<H+1> + Ca+2 + Asn-1 + Trp-1 = Ca+2_H+1(2)_Asn-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.05(0.01SD)	3	ETS	94

Reaction No. 46916							
2<H+1> + Ca+2 + Citrul-1 + Trp-1 = Ca+2_H+1(2)_Citrul-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.00(0.01SD)	3	ETS	94

Reaction No. 46917							
2<H+1> + Ca+2 + Cis-2 + Trp-1 = Ca+2_H+1(2)_Trp-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.60(0.01SD)	3	ETS	94

Reaction No. 46918							
--------------------	--	--	--	--	--	--	--

2<H+1> + Ca+2 + Glu-2 + Trp-1 = Ca+2_H+1(2)_Trp-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.90(0.01SD)	3	ETS	94

Reaction No. 46919							
2<H+1> + Ca+2 + Gln-1 + Trp-1 = Ca+2_H+1(2)_Gln-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.05(0.01SD)	3	ETS	94

Reaction No. 46920							
2<H+1> + Ca+2 + Gly-1 + Trp-1 = Ca+2_H+1(2)_Gly-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.75(0.01SD)	3	ETS	94

Reaction No. 46921							
2<H+1> + Ca+2 + His-1 + Trp-1 = Ca+2_H+1(2)_His-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.30(0.01SD)	3	ETS	94


Reaction No. 46922							
2<H+1> + Ca+2 + Ile-1 + Trp-1 = Ca+2_H+1(2)_Ile-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.65(0.01SD)	3	ETS	94

Reaction No. 46923							
2<H+1> + Ca+2 + Leu-1 + Trp-1 = Ca+2_H+1(2)_Leu-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.65(0.01SD)	3	ETS	94

Reaction No. 46924							
2<H+1> + Ca+2 + Met-1 + Trp-1 = Ca+2_H+1(2)_Met-1_Trp-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.20(0.01SD)	3	ETS	94

Reaction No. 46925




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.15(0.01SD)	3	ETS	94

Reaction No. 46926




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.75(0.01SD)	3	ETS	94

Reaction No. 46927




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.15(0.01SD)	3	ETS	94

Reaction No. 46928




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.10(0.01SD)	3	ETS	94

Reaction No. 46929



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.60(0.01SD)	3	ETS	94


Reaction No. 46930



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:13.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.00 (0.01SD)	3	ETS	94

Reaction No. 46931




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.00 (0.01SD)	3	ETS	94

Reaction No. 46932




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.20 (0.01SD)	3	ETS	94

Reaction No. 46933




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.20 (0.01SD)	3	ETS	94

Reaction No. 46934




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.15 (0.01SD)	3	ETS	94

Reaction No. 46935



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.95 (0.01SD)	3	ETS	94


Reaction No. 46936



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1 (3SF)	1	EAE	


2	37	0.15	Blood Plasma	lgK:19.60(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 46937




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.40(0.01SD)	3	ETS	94

Reaction No. 46938




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.20(0.01SD)	3	ETS	94

Reaction No. 46939




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.85(0.01SD)	3	ETS	94

Reaction No. 46940




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.15(0.01SD)	3	ETS	94

Reaction No. 46941



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.85(0.01SD)	3	ETS	94

Reaction No. 46942



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.75(0.01SD)	3	ETS	94

Reaction No. 46943							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Glu-2} + \text{Val-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Val-1}}_{\text{Glu-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.05(0.01SD)	3	ETS	94

Reaction No. 46944							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Gln-1} + \text{Val-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Gln-1}}_{\text{Val-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.20(0.01SD)	3	ETS	94

Reaction No. 46945							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Gly-1} + \text{Val-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Gly-1}}_{\text{Val-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.90(0.01SD)	3	ETS	94

Reaction No. 46946							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{His-1} + \text{Val-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{His-1}}_{\text{Val-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.45(0.01SD)	3	ETS	94

Reaction No. 46947							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Hyp-1} + \text{Val-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Hyp-1}}_{\text{Val-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.70(0.01SD)	3	ETS	94

Reaction No. 46948							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Ile-1} + \text{Val-1} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Ile-1}}_{\text{Val-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80(0.01SD)	3	ETS	94

Reaction No. 46949							
--------------------	--	--	--	--	--	--	--

2<H+1> + Ca+2 + Leu-1 + Val-1 = Ca+2_H+1(2)_Leu-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80(0.01SD)	3	ETS	94

Reaction No. 46950							
2<H+1> + Ca+2 + Met-1 + Val-1 = Ca+2_H+1(2)_Met-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.35(0.01SD)	3	ETS	94

Reaction No. 46951							
2<H+1> + Ca+2 + Phe-1 + Val-1 = Ca+2_H+1(2)_Phe-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.30(0.01SD)	3	ETS	94

Reaction No. 46952							
2<H+1> + Ca+2 + Pro-1 + Val-1 = Ca+2_H+1(2)_Pro-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.90(0.01SD)	3	ETS	94


Reaction No. 46953							
2<H+1> + Ca+2 + Ser-1 + Val-1 = Ca+2_H+1(2)_Ser-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.30(0.01SD)	3	ETS	94

Reaction No. 46954							
2<H+1> + Ca+2 + Thr-1 + Val-1 = Ca+2_H+1(2)_Thr-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.25(0.01SD)	3	ETS	94

Reaction No. 46955							
2<H+1> + Ca+2 + Trp-1 + Val-1 = Ca+2_H+1(2)_Trp-1_Val-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.55(0.01SD)	3	ETS	94

Reaction No. 46956




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.85(0.01SD)	3	ETS	94

Reaction No. 46957




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.0(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:13.65(0.01SD)	3	ETS	94

Reaction No. 46958




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.05(0.01SD)	3	ETS	94

Reaction No. 46959




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.80(0.01SD)	3	ETS	94

Reaction No. 46960



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.00(0.01SD)	3	ETS	94


Reaction No. 46961



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:15.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.70 (0.01SD)	3	ETS	94

Reaction No. 46962




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.9 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.20 (0.01SD)	3	ETS	94

Reaction No. 46963




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.90 (0.01SD)	3	ETS	94

Reaction No. 46964




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.65 (0.01SD)	3	ETS	94

Reaction No. 46965




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.80 (0.01SD)	3	ETS	94

Reaction No. 46966



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.85 (0.01SD)	3	ETS	94

Reaction No. 46967



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.3 (3SF)	2	EAE	

2	37	0.15	Blood Plasma	lgK:13.60 (0.01SD)	3	ETS	94
---	----	------	--------------	--------------------	---	-----	----

Reaction No. 46968							
H+1 + Ca+2 + Ile-1 + PO4-3 = Ca+2_H+1_Ile-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.65 (0.01SD)	3	ETS	94

Reaction No. 46969							
H+1 + Ca+2 + Leu-1 + PO4-3 = Ca+2_H+1_Leu-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.65 (0.01SD)	3	ETS	94

Reaction No. 46970							
H+1 + Ca+2 + Met-1 + PO4-3 = Ca+2_H+1_Met-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.75 (0.01SD)	3	ETS	94

Reaction No. 46971							
H+1 + Ca+2 + Phe-1 + PO4-3 = Ca+2_H+1_Phe-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.75 (0.01SD)	3	ETS	94

Reaction No. 46972							
H+1 + Ca+2 + Ser-1 + PO4-3 = Ca+2_H+1_Ser-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.80 (0.01SD)	3	ETS	94

Reaction No. 46973							
H+1 + Ca+2 + Thr-1 + PO4-3 = Ca+2_H+1_Thr-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.65 (0.01SD)	3	ETS	94

Reaction No. 46974							
H+1 + Ca+2 + Trp-1 + PO4-3 = Ca+2_H+1_Trp-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.75 (0.01SD)	3	ETS	94

Reaction No. 46975							
H+1 + Ca+2 + Val-1 + PO4-3 = Ca+2_H+1_Val-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.65 (0.01SD)	3	ETS	94

Reaction No. 46976							
H+1 + Ca+2 + Citric-3 + PO4-3 = Ca+2_H+1_Citric-3_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.9 (3SF)	1	ELC	
Note (1): See comments for rxn Ca+2 + Citric-3 + H+1_PO4-3 = Ca+2_H+1_Citric-3_PO4-3							
2	37	0.15	Blood Plasma	lgK:14.95 (0.01SD)	0	ETS	94

Reaction No. 46977							
H+1 + Ca+2 + Lactic-1 + PO4-3 = Ca+2_H+1_Lactic-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.95 (0.01SD)	3	ETS	94

Reaction No. 46978							
H+1 + Ca+2 + Malic-2 + PO4-3 = Ca+2_H+1_Malic-2_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.15 (0.01SD)	3	ETS	94

Reaction No. 46979							
H+1 + Ca+2 + Oxalic-2 + PO4-3 = Ca+2_H+1_Oxalic-2_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.15 (0.01SD)	3	ETS	94

Reaction No. 46980							
$H+1 + Ca+2 + Succinic-2 + PO4-3 = Ca+2_H+1_Succinic-2_PO4-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.10(0.01SD)	3	ETS	94

Reaction No. 46981							
$2<H+1> + Ca+2 + Ala-1 + PO4-3 = Ca+2_H+1(2)_Ala-1_PO4-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.90(0.01SD)	3	ETS	94

Reaction No. 46982							
$2<H+1> + Ca+2 + bAla-1 + PO4-3 = Ca+2_H+1(2)_bAla-1_PO4-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.2(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:22.55(0.01SD)	3	ETS	94

Reaction No. 46983							
$2<H+1> + Ca+2 + Arg-1 + PO4-3 = Ca+2_H+1(2)_Arg-1_PO4-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.35(0.01SD)	3	ETS	94

Reaction No. 46984							
$2<H+1> + Ca+2 + Asn-1 + PO4-3 = Ca+2_H+1(2)_Asn-1_PO4-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.15(0.01SD)	3	ETS	94

Reaction No. 46985							
$2<H+1> + Ca+2 + Asp-2 + PO4-3 = Ca+2_H+1(2)_Asp-2_PO4-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.80(0.01SD)	3	ETS	94

Reaction No. 46986							
--------------------	--	--	--	--	--	--	--

2<H+1> + Ca+2 + Citrul-1 + PO4-3 = Ca+2_H+1(2)_Citrul-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.10(0.01SD)	3	ETS	94

Reaction No. 46987							
2<H+1> + Ca+2 + Cys-2 + PO4-3 = Ca+2_H+1(2)_Cys-2_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.80(0.01SD)	3	ETS	94

Reaction No. 46988							
2<H+1> + Ca+2 + Cis-2 + PO4-3 = Ca+2_H+1(2)_Cis-2_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.70(0.01SD)	3	ETS	94

Reaction No. 46989							
2<H+1> + Ca+2 + Glu-2 + PO4-3 = Ca+2_H+1(2)_Glu-2_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.00(0.01SD)	3	ETS	94


Reaction No. 46990							
2<H+1> + Ca+2 + Gln-1 + PO4-3 = Ca+2_H+1(2)_Gln-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.15(0.01SD)	3	ETS	94

Reaction No. 46991							
2<H+1> + Ca+2 + Gly-1 + PO4-3 = Ca+2_H+1(2)_Gly-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.85(0.01SD)	3	ETS	94

Reaction No. 46992							
2<H+1> + Ca+2 + His-1 + PO4-3 = Ca+2_H+1(2)_His-1_PO4-3							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.40(0.01SD)	3	ETS	94

Reaction No. 46993




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.65(0.01SD)	3	ETS	94

Reaction No. 46994




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.75(0.01SD)	3	ETS	94

Reaction No. 46995




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.75(0.01SD)	3	ETS	94

Reaction No. 46996




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.85(0.01SD)	3	ETS	94

Reaction No. 46997



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.30(0.01SD)	3	ETS	94


Reaction No. 46998



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:25.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.60 (0.01SD)	3	ETS	94

Reaction No. 46999




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.25 (0.01SD)	3	ETS	94

Reaction No. 47000




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.85 (0.01SD)	3	ETS	94

Reaction No. 47001




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.25 (0.01SD)	3	ETS	94

Reaction No. 47002




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.20 (0.01SD)	3	ETS	94

Reaction No. 47003



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.50 (0.01SD)	3	ETS	94


Reaction No. 47004



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.4 (3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:23.25(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 47005




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.65(0.01SD)	3	ETS	94

Reaction No. 47006




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.15(0.01SD)	3	ETS	94

Reaction No. 47007




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.15(0.01SD)	3	ETS	94

Reaction No. 47008




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.35(0.01SD)	3	ETS	94

Reaction No. 47009



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.35(0.01SD)	3	ETS	94

Reaction No. 47010



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.30(0.01SD)	3	ETS	94

Reaction No. 47011							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Ala-1} + \text{SiH}_2\text{O}_4\text{-2} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Ala-1}}\text{SiH}_2\text{O}_4\text{-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.10(0.01SD)	3	ETS	94

Reaction No. 47012							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{bAla-1} + \text{SiH}_2\text{O}_4\text{-2} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{bAla-1}}\text{SiH}_2\text{O}_4\text{-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.4(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:22.75(0.01SD)	3	ETS	94

Reaction No. 47013							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Arg-1} + \text{SiH}_2\text{O}_4\text{-2} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Arg-1}}\text{SiH}_2\text{O}_4\text{-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.55(0.01SD)	3	ETS	94

Reaction No. 47014							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Asn-1} + \text{SiH}_2\text{O}_4\text{-2} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Asn-1}}\text{SiH}_2\text{O}_4\text{-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.35(0.01SD)	3	ETS	94

Reaction No. 47015							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Asp-2} + \text{SiH}_2\text{O}_4\text{-2} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Asp-2}}\text{SiH}_2\text{O}_4\text{-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.00(0.01SD)	3	ETS	94

Reaction No. 47016							
$2\text{<H+1>} + \text{Ca}^{+2} + \text{Citrul-1} + \text{SiH}_2\text{O}_4\text{-2} = \text{Ca}^{+2}_{\text{H+1}(2)}_{\text{Citrul-1}}\text{SiH}_2\text{O}_4\text{-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.29(0.01SD)	3	ETS	94

Reaction No. 47017							
--------------------	--	--	--	--	--	--	--

2<H+1> + Ca+2 + Cis-2 + SiH2O4-2 = Ca+2_H+1(2)_Cis-2_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.90(0.01SD)	3	ETS	94

Reaction No. 47018							
2<H+1> + Ca+2 + Glu-2 + SiH2O4-2 = Ca+2_H+1(2)_Glu-2_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.20(0.01SD)	3	ETS	94

Reaction No. 47019							
2<H+1> + Ca+2 + Gln-1 + SiH2O4-2 = Ca+2_H+1(2)_Gln-1_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.35(0.01SD)	3	ETS	94

Reaction No. 47020							
2<H+1> + Ca+2 + Gly-1 + SiH2O4-2 = Ca+2_H+1(2)_Gly-1_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.05(0.01SD)	3	ETS	94


Reaction No. 47021							
2<H+1> + Ca+2 + His-1 + SiH2O4-2 = Ca+2_H+1(2)_His-1_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.60(0.01SD)	3	ETS	94

Reaction No. 47022							
2<H+1> + Ca+2 + Hyp-1 + SiH2O4-2 = Ca+2_H+1(2)_Hyp-1_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.85(0.01SD)	3	ETS	94

Reaction No. 47023							
2<H+1> + Ca+2 + Ile-1 + SiH2O4-2 = Ca+2_H+1(2)_Ile-1_SiH2O4-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.94(0.01SD)	3	ETS	94

Reaction No. 47024




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.94(0.01SD)	3	ETS	94

Reaction No. 47025




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.50(0.01SD)	3	ETS	94

Reaction No. 47026




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.44(0.01SD)	3	ETS	94

Reaction No. 47027




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:24.05(0.01SD)	3	ETS	94

Reaction No. 47028



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.44(0.01SD)	3	ETS	94


Reaction No. 47029



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:23.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.40(0.01SD)	3	ETS	94

Reaction No. 47030




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.70(0.01SD)	3	ETS	94

Reaction No. 47031




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.85(0.01SD)	3	ETS	94

Reaction No. 47033




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.30(0.01SD)	3	ETS	94

Reaction No. 47034




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.50(0.01SD)	3	ETS	94

Reaction No. 47035



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.50(0.01SD)	3	ETS	94


Reaction No. 47036



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.1(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:9.45(0.01SD)	3	ETS	94
---	----	------	--------------	------------------	---	-----	----

Reaction No. 47037




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.25(0.01SD)	3	ETS	94

Reaction No. 47038




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.3(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:17.90(0.01SD)	3	ETS	94

Reaction No. 47039




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:17.70(0.01SD)	3	ETS	94

Reaction No. 47040




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:19.4(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:17.50(0.01SD)	3	ETS	94

Reaction No. 47041



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:18.15(0.01SD)	3	ETS	94


Reaction No. 47042



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:19.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:17.45 (0.01SD)	3	ETS	94

Reaction No. 47043




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:20.2 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:18.05 (0.01SD)	3	ETS	94

Reaction No. 47044




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.35 (0.01SD)	3	ETS	94

Reaction No. 47045




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:17.50 (0.01SD)	3	ETS	94

Reaction No. 47046




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.20 (0.01SD)	3	ETS	94

Reaction No. 47047



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:17.75 (0.01SD)	3	ETS	94


Reaction No. 47048



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.00(0.01SD)	3	ETS	94

Reaction No. 47049




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.10(0.01SD)	3	ETS	94

Reaction No. 47050




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.10(0.01SD)	3	ETS	94

Reaction No. 47051




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:17.65(0.01SD)	3	ETS	94

Reaction No. 47052




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:17.60(0.01SD)	3	ETS	94

Reaction No. 47053



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.20(0.01SD)	3	ETS	94


Reaction No. 47054



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:17.60(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 47055




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:17.55(0.01SD)	3	ETS	94

Reaction No. 47056




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:17.85(0.01SD)	3	ETS	94

Reaction No. 47057




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.00(0.01SD)	3	ETS	94

Reaction No. 47058




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.95(0.01SD)	3	ETS	94

Reaction No. 48513



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-410.220(6SF)	5	CRV	406

Reaction No. 49887



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0	Inf. Dilution	lgK:-21.071(5SF)	0	CRV	8798
2	25	0	Inf. Dilution	lgK:-19.1(3SF)	1	ELC	
3	25	0	Inf. Dilution	lgK:-20.484(5SF)	0	CRV	8798

4	25	0	Inf. Dilution	lgK:-54.579 (5SF)	0	CRV	25435
Note (4): Given as log K, v. prob. should be ln K but -54.6/2.3 = -23.7 still bad							
5	50	0	Inf. Dilution	lgK:-19.857 (5SF)	0	CRV	8798
6	100	0	Inf. Dilution	lgK:-18.960 (5SF)	0	CRV	8798
7	150	0	Inf. Dilution	lgK:-18.514 (5SF)	0	CRV	8798
8	200	0	Inf. Dilution	lgK:-18.485 (5SF)	0	CRV	8798
9	250	0	Inf. Dilution	lgK:-18.839 (5SF)	0	CRV	8798
10	300	0	Inf. Dilution	lgK:-19.547 (5SF)	0	CRV	8798
11	350	0	Inf. Dilution	lgK:-20.586 (5SF)	0	CRV	8798

Reaction No. 52295							
Ca+2 + 23DiOH2MeButan-1 = Ca+2_23DiOH2MeButan-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:1.64 (0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:1.26 (0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:1.18 (0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:1.14 (0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:1.11 (0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:1.09 (0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:1.08 (0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:1.07 (0.01SD)	4	EDH	5390

Reaction No. 52597							
4ClPhenDTA-4 + Ca+2 = Ca+2_4ClPhenDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:7.68 (0.01SD)	5	MGL	89

Reaction No. 53440							
P3O9-3 + Ca+2 = Ca+2_P3O9-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:3.4 (2SF)	4	MCE	5398
2	20	0.05	NaCl	lgK:2.32 (3SF)	5	MCE	2343
3	20	0.05	NaCl	lgK:2.32 (3SF)	5	MCE	5398
4	20	0.1	NaCl	lgK:2.06 (3SF)	5	MCE	2343
5	20	0.15	NaCl	lgK:1.96 (3SF)	5	MCE	2343
6	20	0.2	NaCl	lgK:1.81 (3SF)	5	MCE	2343
7	23	0.1	NH4Cl	lgK:1.68 (3SF)	3	MSP	140

8	25	0	Inf. Dilution	lgK:3.45 (3SF)	4	MCN	140
9	25	0	Inf. Dilution	lgK:3.48 (3SF)	4	MSL	389
10	25	0.1	Na+1 salt	lgK:2.09 (3SF)	6	CRV	552
11	25	1	Me4N+ salt	lgK:1.64 (3SF)	6	CRV	552
12	25	1	Me4NCl	lgK:1.64 (3SF)	5	MIS	385
13	25	1	Me4NNO3	lgK:1.64 (3SF)	3	MIS	5398
14	37	0.15	NaCl	lgK:2.50 (3SF)	4	MCE	140

Reaction No. 53510							
2<CO3-2> + Ca+2 = Ca+2_CO3-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.3 (2SF)	1	EOR	
2	25	1	NaCl	lgK:1.38 (3SF)	5	MDS	5398
3	200			lgK:4.5 (2SF)	0	MSL	5398
4	300			lgK:3.8 (2SF)	0	MSL	5398
5	350			lgK:3.3 (2SF)	0	MSL	5398

Reaction No. 53957							
Ca+2_P3O10-5 + H+1 = Ca+2_H+1_P3O10-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Me4NNO3	lgK:6.54 (3SF)	0	MGL	931
2	25	0	Inf. Dilution	lgK:7.5 (2SF)	1	ELC	
3	25	0.1	KCl	lgK:5.90 (0.06SD)	0	MGL	277

Reaction No. 54004							
S2O3-2 + Ca+2 = Ca+2_S2O3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.0 (0.03SD)	6	CMN	140
2	25	0	Inf. Dilution	lgK:1.98 (3SF)	4	MSL	140
3	25	0	Inf. Dilution	lgK:2.05 (3SF)	4	MSL	140
4	25	0	Inf. Dilution	lgK:1.91 (3SF)	4	MSP	140
5	25	0	Inf. Dilution	lgK:1.983 (4SF)	4	EOD	12002
6	25	0	Inf. Dilution	lgK:1.98 (3SF)	4	CRV	18273
Note (6): Table 3, p. 85							
7	25	0.5	NO3-1 salt	lgK:0.70 (0.01SD)	6	MCL	4609
8	25			lgK:1.90 (3SF)	4	MEF	931
9	25	0.5	NO3-1 salt	dH:0.64 (0.01SD)	6	MCL	4609

10	25		Ethanol:Water 44:56Wgt	lgK:3.49 (3SF)	5	MCN	140
----	----	--	---------------------------	----------------	---	-----	-----

Reaction No. 54005							
2<S2O3-2> + Ca+2 = Ca+2_S2O3-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:3.98 (3SF)	4	MEF	931


Reaction No. 54436							
Ca+2_CO3-2 + H+1 = Ca+2_H+1_CO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	0.152	NaCl	lgK:7.90 (3SF)	0	MGL	140
2	25	0	Inf. Dilution	lgK:8.2 (2SF)	1	ELC	

Reaction No. 54517							
Ca+2 + 2<F-1> = Ca+2_F-1 (2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	P=25 Inf. Dilution	lgK:11.66 (4SF)	5	MSL	26782
2	23	0	P=55 Inf. Dilution	lgK:11.54 (4SF)	5	MSL	26782
3	23	0	P=225 Inf. Dilution	lgK:11.42 (4SF)	5	MSL	26782
4	23	0	P=330 Inf. Dilution	lgK:11.35 (4SF)	5	MSL	26782
5	25	0	P=410 Inf. Dilution	lgK:11.36 (4SF)	5	MSL	26782
6	23	0	P=510 Inf. Dilution	lgK:11.24 (4SF)	5	MSL	26782
7	25	0	P=518 Inf. Dilution	lgK:11.26 (4SF)	5	MSL	26782
8	23	0	P=640 Inf. Dilution	lgK:11.12 (4SF)	5	MSL	26782
9	25	0	P=690 Inf. Dilution	lgK:11.20 (4SF)	5	MSL	26782
10	23	0	P=790 Inf. Dilution	lgK:11.02 (4SF)	5	MSL	26782
11	25	0	P=950 Inf. Dilution	lgK:10.97 (4SF)	5	MSL	26782
12	25	0	Inf. Dilution	lgK:8.28 (3SF)	0	CRV	
Note (12): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
13	25	0	Inf. Dilution	lgK:10.50 (4SF)	3	CRV	552

14	25	0	Inf. Dilution	lgK:10.6(0.05SD)	3	CMN	5434
15	25	0	Inf. Dilution	lgK:9.3(2SF)	0	ENS	5648
16	25	0	Inf. Dilution	lgK:9.84(3SF)	0	CRV	6330
Note (16): p. 8-58							
17	25	0	Inf. Dilution	lgK:10.4(3SF)	3	ENS	6405
18	25	0	Inf. Dilution	lgK:10.6(3SF)	3	ENS	6496
19	25	0	Inf. Dilution	lgK:10.49(4SF)	3	ENS	7694
20	25	0	Inf. Dilution	lgK:10.41(4SF)	4	CRV	9402
21	25	0	Inf. Dilution	lgK:10.96(4SF)	2	MSL	21870
22	25	0	Inf. Dilution	lgK:10.41(4SF)	3	CRV	22551
23	25	0	Inf. Dilution	lgK:11.09(4SF)	1	CRV	28992
24	25	0	Inf. Dilution	lgK:10.5(3SF)	3	EOD	31694
Note (24): from McCann, 1968							
25	25	0	Inf. Dilution	lgK:10.16(4SF)	2	CRV	32224
26	25	0	CHEMVAL1	lgK:10.50(0.01SD)	0	ENS	5156
27	25	0	CHEMVAL2	lgK:10.50(0.01SD)	0	ENS	5156
28	25	0	CHEMVAL3	lgK:10.50(0.01SD)	0	ENS	5156
29	25	0	CHEMVAL4	lgK:10.60(0.01SD)	3	ENS	5156
30	30	0	Inf. Dilution	lgK:10.41(4SF)	5	MSL	29953
31	50	0	Inf. Dilution	lgK:10.92(4SF)	2	CRV	28992
32	50	0	Inf. Dilution	lgK:10.30(4SF)	3	MSL	29953
33	100	0	Inf. Dilution	lgK:10.87(4SF)	2	CRV	28992
34	100	0	Inf. Dilution	lgK:10.41(4SF)	3	EOD	29953
35	150	0	Inf. Dilution	lgK:11.15(4SF)	0	CRV	28992
36	200	0	Inf. Dilution	lgK:11.79(4SF)	0	CRV	28992
37	200	0	Inf. Dilution	lgK:10.80(4SF)	5	MSL	29953
38	250	0	Inf. Dilution	lgK:12.8(3SF)	0	CRV	28992
39	260	0	Inf. Dilution	lgK:11.22(4SF)	5	MSL	29953
40	23	0	Inf. Dilution	dG:-15.25(0.03SD)	0	EOD	9155
41	25	0	Inf. Dilution	dG:-15.28(0.03SD)	0	EOD	9155
42	26.6	0	Inf. Dilution	dG:-15.31(0.03SD)	0	EOD	9155
43	39	0	Inf. Dilution	dG:-15.53(0.02SD)	2	EOD	9155
44	50	0	Inf. Dilution	dG:-15.81(0.02SD)	3	EOD	9155
45	61	0	Inf. Dilution	dG:-16.14(0.02SD)	3	EOD	9155
46	76.1	0	Inf. Dilution	dG:-16.67(0.02SD)	3	EOD	9155
47	86.5	0	Inf. Dilution	dG:-17.12(0.03SD)	3	EOD	9155


48	98.5	0	Inf. Dilution	dG:-17.66(0.05SD)	3	EOD	9155
49	100	0	Inf. Dilution	dG:-17.70(4SF)	3	MSL	9155
50	200	0	Inf. Dilution	dG:-23.4(0.1SD)	3	MSL	9155
51	260	0	Inf. Dilution	dG:-27.3(0.4SD)	0	MSL	9155
52	0:40	0	Inf. Dilution	dH:-2.(1SF)	0	CRV	2556
53	23	0	Inf. Dilution	dH:11.4(0.4SD)	0	EOD	9155
54	25	0	Inf. Dilution	dH:-4.69(3SF)	0	ENS	6496
55	25	0	Inf. Dilution	dH:-2.(1SF)	0	CRV	7271
56	25	0	Inf. Dilution	dH:11.0(0.4SD)	0	EOD	9155
57	25	0	Inf. Dilution	dH:-3.80(3SF)	0	CRV	9402
58	26.6	0	Inf. Dilution	dH:10.7(0.3SD)	0	EOD	9155
59	39	0	Inf. Dilution	dH:8.7(0.2SD)	0	EOD	9155
60	50	0	Inf. Dilution	dH:6.92(0.03SD)	0	EOD	9155
61	61	0	Inf. Dilution	dH:5.3(0.1SD)	0	EOD	9155
62	76.1	0	Inf. Dilution	dH:3.2(0.3SD)	0	EOD	9155
63	86.5	0	Inf. Dilution	dH:1.8(0.4SD)	2	EOD	9155
64	98.5	0	Inf. Dilution	dH:0.4(0.4SD)	3	EOD	9155
65	100	0	Inf. Dilution	dH:0.3(0.1SD)	3	MTD	9155
66	200	0	Inf. Dilution	dH:-6.8(1.1SD)	0	MTD	9155
67	260	0	Inf. Dilution	dH:-7.1(2.1SD)	0	MTD	9155
68	25	0	Inf. Dilution	Cp:74.40(4SF)	4	CRV	9402

Reaction No. 54525



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-16.5(0.05SD)	3	ENS	5484
2	25	0	Inf. Dilution	lgK:-16.54(4SF)	3	ENS	6496
3	25	0	Inf. Dilution	dH:-11.1(0.1SD)	3	ENS	5484
4	25	0	Inf. Dilution	dH:-11.09(4SF)	3	ENS	6496

Reaction No. 54527




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0	Inf. Dilution	lgK:58.53(4SF)	3	MSL	6471
2	15	0	Inf. Dilution	lgK:58.49(4SF)	5	MSL	6471
3	20:25	0	Inf. Dilution	lgK:55.96(4SF)	0	EOD	29438

4	25	0	Inf. Dilution	lgK:36.0(3SF)	0	CRV	
Note (4): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
5	25	0	Inf. Dilution	lgK:57.5(0.1SD)	0	ENS	5199
6	25	0	Inf. Dilution	lgK:55.6(3SF)	0	CRV	6405
7	25	0	Inf. Dilution	lgK:58.52(4SF)	5	MSL	6471
8	25	0	Inf. Dilution	lgK:58.3(3SF)	3	EOD	29070
9	25	0	Inf. Dilution	lgK:54.6(3SF)	0	EOD	31694
Note (9): from Moreno, Gregory & Brown, 1968							
10	25	0	Inf. Dilution	lgK:58.33(4SF)	2	EOD	31716
Note (10): Dubious confirmation of results from [77MGB_6471]							
11	25	0	Inf. Dilution	lgK:58.4(3SF)	4	CRV	31723
Note (11): 116.8 / 2							
12	25	0	Inf. Dilution	lgK:57.65(0.2MD)	4	MSL	31745
13	25	0	Inf. Dilution	lgK:58.4(3SF)	5	CRV	31748
Note (13): 116.8/2							
14	25	0	Inf. Dilution	lgK:58.4(3SF)	4	EOD	31761
Note (14): 116.8/2							
15	25	0	CHEMVAL4	lgK:48.6(0.05SD)	0	ENS	5156
16	37	0	Inf. Dilution	lgK:58.63(4SF)	3	MSL	6471
17	37	0	Inf. Dilution	lgK:58.63(4SF)	4	CRV	26737
18	37	0	Inf. Dilution	lgK:58.63(4SF)	2	EOD	31716
Note (18): Authoritative confirmation of results from [77MGB_6471]							
19	37	0	Inf. Dilution	lgK:58.6(3SF)	4	CRV	31723
Note (19): 117.2 / 2							

Reaction No. 54530							
Ca+2 + B(OH)4-1 = Ca+2_B(OH)4-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.152(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:1.45(3SF)	3	CRV	406
3	25	0	Inf. Dilution	lgK:1.80(3SF)	4	CRV	406
4	25	0	Inf. Dilution	lgK:1.83(3SF)	4	CRV	406
5	25	0	Inf. Dilution	lgK:1.80(0.03SD)	4	CMN	7391
6	25	0	UCT_Sea	lgK:1.80(0.01SD)	4	EDH	5390
7	25	0.1	UCT_Sea	lgK:1.40(0.01SD)	4	EDH	5390
8	25	0.16	Cl-1 salt	lgK:1.8(0.05SD)w	5	MPH	373


9	25	0.2	UCT_Sea	lgK:1.29(0.01SD)	4	EDH	5390
10	25	0.3	UCT_Sea	lgK:1.23(0.01SD)	4	EDH	5390
11	25	0.4	UCT_Sea	lgK:1.18(0.01SD)	4	EDH	5390
12	25	0.5	UCT_Sea	lgK:1.13(0.01SD)	4	EDH	5390
13	25	0.6	UCT_Sea	lgK:1.09(0.01SD)	4	EDH	5390
14	25	0.7	NaCl	lgK:1.1(0.03SD)	5	MPS	769
15	25	0.7	UCT_Sea	lgK:1.06(0.01SD)	4	EDH	5390
16	25	0.7	Unknown	lgK:1.6(0.2SD)	5	CMN	406
17	25	0.7	Unknown	lgK:1.11(0.02SD)	6	CMN	7391
18	25	0.7	Unknown	lgK:0.41(2SF)	3	ENS	7391
19	25	0.7	Unknown	lgK:0.73(2SF)	3	ENS	7391
20	25	0.7	Unknown	lgK:1.11(3SF)	4	ENS	7391
21	10:50	0.16	Cl-1 salt	dH:-0.9(0.6SD)	5	MPH	373

Reaction No. 54554




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.0(2SF)	2	EDH	
2	25	1	NaClO ₄	lgK:0.4(0.05SD)	4	MIS	455

Reaction No. 54555




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.5(2SF)	1	EOR	
2	25	1	NaClO ₄	lgK:2.9(0.05SD)	2	MIS	455

Reaction No. 54556



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-7.2(0.1SD)	4	MSL	456

Reaction No. 54557



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-13.4(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-13.6(0.05SD)	0	ENS	440
3	25	0	Inf. Dilution	lgK:-13.64(4SF)	0	CRV	6405

Note (3): p. 245							
4	25	0	Inf. Dilution	lgK:-12.99(4SF)	0	EOD	23102
5	25	0	Inf. Dilution	lgK:-13.73(4SF)	2	CRV	32224
6	25	0	CHEMVAL1	lgK:-14.61(0.01SD)	0	ENS	5156
7	25	0	CHEMVAL2	lgK:-14.61(0.01SD)	0	ENS	5156
8	25	0	CHEMVAL3	lgK:-14.61(0.01SD)	0	ENS	5156
9	25	0	CHEMVAL4	lgK:-13.10(0.01SD)	0	ENS	5156


Reaction No. 54558							
Ca+2 + Mg+2 + 2<H+1(2)_SiH2O4-2> - 2<H2O> = CaO.MgO.2SiO2(s) + 4<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-21.7(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-21.2(0.1SD)	0	ENS	440
3	25	0	Inf. Dilution	lgK:-21.20(4SF)	0	CRV	6405
Note (3): p. 246							
4	25	0	Inf. Dilution	lgK:-21.07(4SF)	0	CRV	32224
5	25	0	CHEMVAL1	lgK:-23.70(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL2	lgK:-23.70(0.01SD)	0	ENS	5156
7	25	0	CHEMVAL3	lgK:-23.70(0.01SD)	0	ENS	5156
8	25	0	CHEMVAL4	lgK:-19.90(0.01SD)	0	ENS	5156

Reaction No. 54559							
2CaO.5MgO.8SiO2.H2O(s) + 14<H+1> = 2<Ca+2> + 5<Mg+2> + 8<H+1(2)_SiH2O4-2> - 8<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:66.1(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:62.4(0.1SD)	0	ENS	440
3	25	0	Inf. Dilution	lgK:62.44(4SF)	0	CRV	6405
Note (3): p. 246							
4	25	0	Inf. Dilution	lgK:61.85(4SF)	0	CRV	32224
5	25	0	CHEMVAL1	lgK:67.61(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL2	lgK:67.61(0.01SD)	0	ENS	5156
7	25	0	CHEMVAL3	lgK:67.61(0.01SD)	0	ENS	5156

Reaction No. 54618							
Ca(s) + 3.5<O2(g)> + 4<Al(s)> = CaO.2Al2O3(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:669.0(4SF)	4	ENS	6422

2	27	0	Inf. Dilution	lgK:664.7 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:489.4 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:384.220 (6SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:314.1 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-901.2 (0.05SD)	0	ENS	802
Note (6): Low wgt for internal consistency							
7	25	0	Inf. Dilution	dG:-912.7 (4SF)	4	ENS	6422
8	25	0	Inf. Dilution	dH:-950.7 (0.1SD)	0	ENS	802
9	25	0	Inf. Dilution	dH:-962.2 (4SF)	4	MTD	6422
10	127	0	Inf. Dilution	dH:-962.5 (4SF)	4	MTD	6422
11	227	0	Inf. Dilution	dH:-962.4 (4SF)	4	MTD	6422
12	327	0	Inf. Dilution	dH:-962.1 (4SF)	4	MTD	6422


Reaction No. 54632



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2365.4 (5SF) kJ	3	EOD	12955


Note (1): From Wagman

Reaction No. 54652




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:597.7 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:593.9 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:437.7 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:344.0 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:281.6 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-815.4 (0.05SD)	4	ENS	802
7	25	0	Inf. Dilution	dG:-815.4 (4SF)	4	ENS	6422
8	25	0	Inf. Dilution	dH:-857.5 (0.1SD)	4	ENS	802
9	25	0	Inf. Dilution	dH:-857.5 (4SF)	4	MTD	6422
10	127	0	Inf. Dilution	dH:-857.3 (4SF)	4	MTD	6422
11	227	0	Inf. Dilution	dH:-856.8 (4SF)	4	MTD	6422
12	327	0	Inf. Dilution	dH:-856.3 (4SF)	4	MTD	6422

Reaction No. 54681




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:387.0(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:384.5(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:283.2(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:222.4(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:181.9(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-527.9(0.05SD)	3	ENS	802
7	25	0	Inf. Dilution	dG:-527.9(4SF)	4	ENS	6422
8	25	0	Inf. Dilution	dH:-556.0(0.1SD)	3	ENS	802
9	25	0	Inf. Dilution	dH:-556.0(4SF)	4	MTD	6422
10	127	0	Inf. Dilution	dH:-556.1(4SF)	4	MTD	6422
11	227	0	Inf. Dilution	dH:-555.9(4SF)	4	MTD	6422
12	327	0	Inf. Dilution	dH:-555.8(4SF)	4	MTD	6422

Reaction No. 54716



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:-18.2(0.05SD)	0	ENS	5468
2	25	0	Inf. Dilution	lgK:-19.8(3SF)	1	ELC	

Reaction No. 54775



Note: This is a classic case where medium effects are critical at moderate or high ionic strengths. Note the differences even between chloride and perchlorate mediums, given that the constants have been measured by highly reputable laboratories and are considered accurate. The impressive study by Marshall and Slusher [66MaS_8399] dominates the available literature data, as reflected below. However, accurate predictions of gypsum solubility are not possible at the current state of the art (unless simplicity is assumed and parameterised!)

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:4.6326(5SF)	4	CRV	31793
2	0	0	Inf. Dilution/m	lgK:4.68(3SF)	4	MSL	8671
3	0	0	Inf. Dilution/m	lgK:4.693(4SF)	3	EOD	19094
4	0	0.229	NaNO ₃ /m	lgK:3.416(4SF)	5	MSL	8616
5	0	0.503	NaNO ₃ /m	lgK:3.063(4SF)	5	MSL	8616
6	0	1.02	NaNO ₃ /m	lgK:2.726(4SF)	5	MSL	8616
7	0	2.14	NaNO ₃ /m	lgK:2.376(4SF)	5	MSL	8616
8	0	6.02	NaNO ₃ /m	lgK:2.210(4SF)	5	MSL	8616
9	0.5	0	Inf. Dilution/m	lgK:4.465(4SF)	3	MSL	8399

9	0.5	0	Inf. Dilution/m	lgK:4.465 (4SF)	3	MSL	8399
10	0.5	0.1	NaCl/m	lgK:3.604 (4SF)	5	MSL	8399
11	0.5	0.2	NaCl/m	lgK:3.380 (4SF)	5	MSL	8399
12	0.5	0.5	NaCl/m	lgK:3.043 (4SF)	5	MSL	8399
13	0.5	0.7	NaCl/m	lgK:2.907 (4SF)	5	MSL	8399
14	0.5	1	NaCl/m	lgK:2.750 (4SF)	5	MSL	8399
15	0.5	1.2	NaCl/m	lgK:2.663 (4SF)	5	MSL	8399
16	0.5	1.5	NaCl/m	lgK:2.547 (4SF)	5	MSL	8399
17	0.5	2	NaCl/m	lgK:2.374 (4SF)	5	MSL	8399
18	0.5	3	NaCl/m	lgK:2.053 (4SF)	5	MSL	8399
19	0.5	4	NaCl/m	lgK:1.724 (4SF)	3	MSL	8399
20	0.5	5	NaCl/m	lgK:1.369 (4SF)	3	MSL	8399
21	5	0	Inf. Dilution/m	lgK:4.434 (4SF)	3	MSL	8399
22	5	0.1	NaCl/m	lgK:3.572 (4SF)	5	MSL	8399
23	5	0.2	NaCl/m	lgK:3.351 (4SF)	5	MSL	8399
24	5	0.5	NaCl/m	lgK:3.022 (4SF)	5	MSL	8399
25	5	0.7	NaCl/m	lgK:2.891 (4SF)	5	MSL	8399
26	5	1	NaCl/m	lgK:2.744 (4SF)	5	MSL	8399
27	5	1.2	NaCl/m	lgK:2.663 (4SF)	5	MSL	8399
28	5	1.5	NaCl/m	lgK:2.558 (4SF)	5	MSL	8399
29	5	2	NaCl/m	lgK:2.403 (4SF)	5	MSL	8399
30	5	3	NaCl/m	lgK:2.124 (4SF)	5	MSL	8399
31	5	4	NaCl/m	lgK:1.844 (4SF)	5	MSL	8399
32	5	5	NaCl/m	lgK:1.544 (4SF)	3	MSL	8399
33	10	0	Inf. Dilution	lgK:4.5907 (5SF)	4	CRV	31793
34	10	0	Inf. Dilution/m	lgK:4.406 (4SF)	3	MSL	8399
35	10	0.1	NaCl/m	lgK:3.541 (4SF)	5	MSL	8399
36	10	0.2	NaCl/m	lgK:3.321 (4SF)	5	MSL	8399
37	10	0.5	NaCl/m	lgK:2.996 (4SF)	5	MSL	8399
38	10	0.7	NaCl/m	lgK:2.869 (4SF)	5	MSL	8399
39	10	1	NaCl/m	lgK:2.727 (4SF)	5	MSL	8399
40	10	1.2	NaCl/m	lgK:2.650 (4SF)	5	MSL	8399
41	10	1.5	NaCl/m	lgK:2.551 (4SF)	5	MSL	8399
42	10	2	NaCl/m	lgK:2.408 (4SF)	5	MSL	8399
43	10	3	NaCl/m	lgK:2.153 (4SF)	5	MSL	8399
44	10	4	NaCl/m	lgK:1.902 (4SF)	5	MSL	8399

45	10	5	NaCl/m	lgK:1.635 (4SF)	4	MSL	8399
46	15	0	Inf. Dilution/m	lgK:4.388 (4SF)	3	MSL	8399
47	15	0.1	NaCl/m	lgK:3.519 (4SF)	5	MSL	8399
48	15	0.2	NaCl/m	lgK:3.299 (4SF)	5	MSL	8399
49	15	0.5	NaCl/m	lgK:2.978 (4SF)	5	MSL	8399
50	15	0.7	NaCl/m	lgK:2.854 (4SF)	5	MSL	8399
51	15	1	NaCl/m	lgK:2.716 (4SF)	5	MSL	8399
52	15	1.2	NaCl/m	lgK:2.643 (4SF)	5	MSL	8399
53	15	1.5	NaCl/m	lgK:2.548 (4SF)	5	MSL	8399
54	15	2	NaCl/m	lgK:2.414 (4SF)	5	MSL	8399
55	15	3	NaCl/m	lgK:2.180 (4SF)	5	MSL	8399
56	15	4	NaCl/m	lgK:1.953 (4SF)	5	MSL	8399
57	15	5	NaCl/m	lgK:1.714 (4SF)	5	MSL	8399
58	20	0	Inf. Dilution	lgK:4.5764 (5SF)	4	CRV	31793
59	20	0	Inf. Dilution/m	lgK:4.380 (4SF)	3	MSL	8399
60	20	0	Inf. Dilution/m	lgK:4.64 (3SF)	4	MSL	8671
61	20	0.1	NaCl/m	lgK:3.507 (4SF)	5	MSL	8399
62	20	0.2	NaCl/m	lgK:3.288 (4SF)	5	MSL	8399
63	20	0.5	NaCl/m	lgK:2.970 (4SF)	5	MSL	8399
64	20	0.7	NaCl/m	lgK:2.847 (4SF)	5	MSL	8399
65	20	1	NaCl/m	lgK:2.713 (4SF)	5	MSL	8399
66	20	1.2	NaCl/m	lgK:2.642 (4SF)	5	MSL	8399
67	20	1.5	NaCl/m	lgK:2.552 (4SF)	5	MSL	8399
68	20	2	NaCl/m	lgK:2.425 (4SF)	5	MSL	8399
69	20	3	NaCl/m	lgK:2.208 (4SF)	5	MSL	8399
70	20	4	NaCl/m	lgK:2.002 (4SF)	5	MSL	8399
71	20	5	NaCl/m	lgK:1.786 (4SF)	5	MSL	8399
72	25	0	Inf. Dilution	lgK:4.58 (3SF)	3	EOD	29419
73	25	0	Inf. Dilution	lgK:4.581 (4SF)	5	CRV	31308
74	25	0	Inf. Dilution	lgK:4.5768 (5SF)	4	CRV	31793
75	25	0	Inf. Dilution	lgK:4.85 (3SF)	4	CRV	32224
76	25	0	Inf. Dilution/m	lgK:4.38 (0.005SD)	5	ENS	5202
77	25	0	Inf. Dilution/m	lgK:4.62 (3SF)	5	CRV	6405
78	25	0	Inf. Dilution/m	lgK:4.58 (3SF)	4	ENS	6496
79	25	0	Inf. Dilution/m	lgK:4.86 (3SF)	3	CRV	9402
80	25	0	Inf. Dilution/m	lgK:4.62 (3SF)	4	CRV	22551

Note (80): p. 23							
81	25	0	Inf. Dilution/m	lgK:4.64 (3SF)	3	EOD	23102
82	25	0	CHEMVAL1/m	lgK:4.39 (0.01SD)	0	ENS	5156
83	25	0	CHEMVAL2/m	lgK:4.39 (0.01SD)	0	ENS	5156
84	25	0	CHEMVAL3/m	lgK:4.39 (0.01SD)	0	ENS	5156
85	25	0	CHEMVAL4/m	lgK:4.34 (0.01SD)	5	ENS	5156
86	25	0	Inf. Dilution/m	lgK:4.374 (4SF)	3	MSL	8399
87	25	0	Inf. Dilution/m	lgK:4.58 (0.02SD)	5	MSL	12549
88	25	0	Inf. Dilution/m	lgK:4.604 (4SF)	3	EOD	19094
89	25	0.1	NaCl/m	lgK:3.496 (4SF)	5	MSL	8399
90	25	0.2	NaCl/m	lgK:3.277 (4SF)	5	MSL	8399
91	25	0.236	NaNO3/m	lgK:3.365 (4SF)	5	MSL	8616
92	25	0.47	NaClO4/m	lgK:3.3 (0.05SD)	3	MSL	369
93	25	0.5	NaCl/m	lgK:2.960 (4SF)	5	MSL	8399
94	25	0.504	NaNO3/m	lgK:3.055 (4SF)	5	MSL	8616
95	25	0.7	NaCl/m	lgK:3.54 (3SF)	0	MSL	7229
96	25	0.7	NaCl/m	lgK:2.839 (4SF)	5	MSL	8399
97	25	1	NaCl/m	lgK:2.708 (4SF)	5	MSL	8399
98	25	1	NaClO4/m	lgK:2.92 (0.05SD)	3	MSL	330
99	25	1.01	NaNO3/m	lgK:2.765 (4SF)	5	MSL	8616
100	25	1.2	NaCl/m	lgK:2.639 (4SF)	5	MSL	8399
101	25	1.5	NaCl/m	lgK:2.552 (4SF)	5	MSL	8399
102	25	2	NaCl/m	lgK:2.432 (4SF)	5	MSL	8399
103	25	2	NaClO4/m	lgK:3.1 (0.05SD)	2	MSL	369
104	25	2.1	NaNO3/m	lgK:2.478 (4SF)	5	MSL	8616
105	25	3	NaCl/m	lgK:2.230 (4SF)	5	MSL	8399
106	25	3.5	NaClO4/m	lgK:3.16 (0.05SD)	2	MSL	330
107	25	4	NaCl/m	lgK:2.041 (4SF)	5	MSL	8399
108	25	5	NaCl/m	lgK:1.845 (4SF)	5	MSL	8399
109	25	6	NaNO3/m	lgK:2.269 (4SF)	5	MSL	8616
110	30	0	Inf. Dilution	lgK:4.5814 (5SF)	4	CRV	31793
111	30	0	Inf. Dilution/m	lgK:4.38 (0.005SD)	5	ENS	5202
112	30	0	Inf. Dilution/m	lgK:4.372 (4SF)	3	MSL	8399
113	30	0.1	NaCl/m	lgK:3.490 (4SF)	5	MSL	8399
114	30	0.2	NaCl/m	lgK:3.271 (4SF)	5	MSL	8399
115	30	0.5	NaCl/m	lgK:2.956 (4SF)	5	MSL	8399

116	30	0.7	NaCl/m	lgK:2.837(4SF)	5	MSL	8399
117	30	1	NaCl/m	lgK:2.708(4SF)	5	MSL	8399
118	30	1.2	NaCl/m	lgK:2.641(4SF)	5	MSL	8399
119	30	1.5	NaCl/m	lgK:2.557(4SF)	5	MSL	8399
120	30	2	NaCl/m	lgK:2.441(4SF)	5	MSL	8399
121	30	3	NaCl/m	lgK:2.248(4SF)	5	MSL	8399
122	30	4	NaCl/m	lgK:2.069(4SF)	5	MSL	8399
123	30	5	NaCl/m	lgK:1.884(4SF)	5	MSL	8399
124	35	0	Inf. Dilution/m	lgK:4.374(4SF)	3	MSL	8399
125	35	0.1	NaCl/m	lgK:3.487(4SF)	5	MSL	8399
126	35	0.2	NaCl/m	lgK:3.268(4SF)	5	MSL	8399
127	35	0.5	NaCl/m	lgK:2.954(4SF)	5	MSL	8399
128	35	0.7	NaCl/m	lgK:2.836(4SF)	5	MSL	8399
129	35	1	NaCl/m	lgK:2.710(4SF)	5	MSL	8399
130	35	1	NaClO4/m	lgK:2.91(0.05SD)	3	MSL	330
131	35	1.2	NaCl/m	lgK:2.644(4SF)	5	MSL	8399
132	35	1.5	NaCl/m	lgK:2.562(4SF)	5	MSL	8399
133	35	2	NaCl/m	lgK:2.450(4SF)	5	MSL	8399
134	35	3	NaCl/m	lgK:2.267(4SF)	5	MSL	8399
135	35	3.5	NaClO4/m	lgK:3.09(0.05SD)	2	MSL	330
136	35	4	NaCl/m	lgK:2.098(4SF)	5	MSL	8399
137	35	5	NaCl/m	lgK:1.926(4SF)	5	MSL	8399
138	40	0	Inf. Dilution	lgK:4.6005(5SF)	4	CRV	31793
139	40	0	Inf. Dilution/m	lgK:4.39(0.005SD)	4	ENS	5202
140	40	0	Inf. Dilution/m	lgK:4.382(4SF)	3	MSL	8399
141	40	0	Inf. Dilution/m	lgK:4.67(3SF)	4	MSL	8671
142	40	0.1	NaCl/m	lgK:3.488(4SF)	5	MSL	8399
143	40	0.2	NaCl/m	lgK:3.268(4SF)	5	MSL	8399
144	40	0.5	NaCl/m	lgK:2.954(4SF)	5	MSL	8399
145	40	0.7	NaCl/m	lgK:2.837(4SF)	5	MSL	8399
146	40	1	NaCl/m	lgK:2.711(4SF)	5	MSL	8399
147	40	1.2	NaCl/m	lgK:2.646(4SF)	5	MSL	8399
148	40	1.5	NaCl/m	lgK:2.565(4SF)	5	MSL	8399
149	40	2	NaCl/m	lgK:2.456(4SF)	5	MSL	8399
150	40	3	NaCl/m	lgK:2.278(4SF)	5	MSL	8399
151	40	4	NaCl/m	lgK:2.116(4SF)	5	MSL	8399

152	40	5	NaCl/m	lgK:1.951(4SF)	5	MSL	8399
153	45	0	Inf. Dilution/m	lgK:4.39(0.005SD)	4	ENS	5202
154	50	0	Inf. Dilution	lgK:4.6310(5SF)	4	CRV	31793
155	50	0	Inf. Dilution/m	lgK:4.41(0.005SD)	3	ENS	5202
156	50	0	Inf. Dilution/m	lgK:4.414(4SF)	3	MSL	8399
157	50	0.1	NaCl/m	lgK:3.506(4SF)	5	MSL	8399
158	50	0.2	NaCl/m	lgK:3.284(4SF)	5	MSL	8399
159	50	0.5	NaCl/m	lgK:2.968(4SF)	5	MSL	8399
160	50	0.7	NaCl/m	lgK:2.850(4SF)	5	MSL	8399
161	50	1	NaCl/m	lgK:2.724(4SF)	5	MSL	8399
162	50	1.2	NaCl/m	lgK:2.660(4SF)	5	MSL	8399
163	50	1.5	NaCl/m	lgK:2.580(4SF)	5	MSL	8399
164	50	2	NaCl/m	lgK:2.474(4SF)	5	MSL	8399
165	50	3	NaCl/m	lgK:2.304(4SF)	5	MSL	8399
166	50	4	NaCl/m	lgK:2.152(4SF)	5	MSL	8399
167	50	5	NaCl/m	lgK:1.999(4SF)	5	MSL	8399
168	60	0	Inf. Dilution	lgK:4.6702(5SF)	4	CRV	31793
169	60	0	Inf. Dilution/m	lgK:4.45(0.005SD)	3	ENS	5202
170	60	0	Inf. Dilution/m	lgK:4.445(4SF)	3	MSL	8399
171	60	0	Inf. Dilution/m	lgK:4.76(3SF)	4	MSL	8671
172	60	0.1	NaCl/m	lgK:3.521(4SF)	5	MSL	8399
173	60	0.2	NaCl/m	lgK:3.295(4SF)	5	MSL	8399
174	60	0.5	NaCl/m	lgK:2.975(4SF)	5	MSL	8399
175	60	0.7	NaCl/m	lgK:2.856(4SF)	5	MSL	8399
176	60	1	NaCl/m	lgK:2.730(4SF)	5	MSL	8399
177	60	1.2	NaCl/m	lgK:2.666(4SF)	5	MSL	8399
178	60	1.5	NaCl/m	lgK:2.586(4SF)	5	MSL	8399
179	60	2	NaCl/m	lgK:2.481(4SF)	5	MSL	8399
180	60	3	NaCl/m	lgK:2.316(4SF)	5	MSL	8399
181	60	4	NaCl/m	lgK:2.172(4SF)	5	MSL	8399
182	60	5	NaCl/m	lgK:2.029(4SF)	5	MSL	8399
183	70	0	Inf. Dilution	lgK:4.7167(5SF)	4	CRV	31793
184	70	0	Inf. Dilution/m	lgK:4.489(4SF)	3	MSL	8399
185	70	0.1	NaCl/m	lgK:3.547(4SF)	5	MSL	8399
186	70	0.2	NaCl/m	lgK:3.317(4SF)	5	MSL	8399
187	70	0.5	NaCl/m	lgK:2.992(4SF)	5	MSL	8399

188	70	0.7	NaCl/m	lgK:2.872 (4SF)	5	MSL	8399
189	70	1	NaCl/m	lgK:2.745 (4SF)	5	MSL	8399
190	70	1.2	NaCl/m	lgK:2.681 (4SF)	5	MSL	8399
191	70	1.5	NaCl/m	lgK:2.601 (4SF)	5	MSL	8399
192	70	2	NaCl/m	lgK:2.497 (4SF)	5	MSL	8399
193	70	3	NaCl/m	lgK:2.338 (4SF)	5	MSL	8399
194	70	4	NaCl/m	lgK:2.203 (4SF)	5	MSL	8399
195	70	5	NaCl/m	lgK:2.073 (4SF)	5	MSL	8399
196	75	1	NaClO ₄ /m	lgK:2.94 (0.05SD)	3	MSL	330
197	75	3.5	NaClO ₄ /m	lgK:3.34 (0.05SD)	0	MSL	330
198	80	0	Inf. Dilution	lgK:4.7685 (5SF)	4	CRV	31793
199	80	0	Inf. Dilution/m	lgK:4.545 (4SF)	3	MSL	8399
200	80	0	Inf. Dilution/m	lgK:4.89 (3SF)	3	MSL	8671
201	80	0.1	NaCl/m	lgK:3.582 (4SF)	5	MSL	8399
202	80	0.2	NaCl/m	lgK:3.348 (4SF)	5	MSL	8399
203	80	0.5	NaCl/m	lgK:3.019 (4SF)	5	MSL	8399
204	80	0.7	NaCl/m	lgK:2.897 (4SF)	5	MSL	8399
205	80	1	NaCl/m	lgK:2.769 (4SF)	5	MSL	8399
206	80	1.2	NaCl/m	lgK:2.704 (4SF)	5	MSL	8399
207	80	1.5	NaCl/m	lgK:2.625 (4SF)	5	MSL	8399
208	80	2	NaCl/m	lgK:2.523 (4SF)	5	MSL	8399
209	80	3	NaCl/m	lgK:2.371 (4SF)	5	MSL	8399
210	80	4	NaCl/m	lgK:2.247 (4SF)	5	MSL	8399
211	80	5	NaCl/m	lgK:2.133 (4SF)	5	MSL	8399
212	90	0	Inf. Dilution	lgK:4.8248 (5SF)	4	CRV	31793
213	90	0	Inf. Dilution/m	lgK:4.591 (4SF)	3	MSL	8399
214	90	0.1	NaCl/m	lgK:3.606 (4SF)	5	MSL	8399
215	90	0.2	NaCl/m	lgK:3.367 (4SF)	5	MSL	8399
216	90	0.5	NaCl/m	lgK:3.032 (4SF)	5	MSL	8399
217	90	0.7	NaCl/m	lgK:2.908 (4SF)	5	MSL	8399
218	90	1	NaCl/m	lgK:2.779 (4SF)	5	MSL	8399
219	90	1.2	NaCl/m	lgK:2.714 (4SF)	5	MSL	8399
220	90	1.5	NaCl/m	lgK:2.636 (4SF)	5	MSL	8399
221	90	2	NaCl/m	lgK:2.536 (4SF)	5	MSL	8399
222	90	3	NaCl/m	lgK:2.393 (4SF)	5	MSL	8399
223	90	4	NaCl/m	lgK:2.284 (4SF)	5	MSL	8399

224	90	5	NaCl/m	lgK:2.188 (4SF)	5	MSL	8399
225	100	0	Inf. Dilution	lgK:4.8844 (5SF)	4	CRV	31793
226	100	0	Inf. Dilution/m	lgK:4.627 (4SF)	3	MSL	8399
227	100	0	Inf. Dilution/m	lgK:5.06 (3SF)	0	MSL	8671
228	100	0.1	NaCl/m	lgK:3.619 (4SF)	5	MSL	8399
229	100	0.2	NaCl/m	lgK:3.376 (4SF)	5	MSL	8399
230	100	0.5	NaCl/m	lgK:3.033 (4SF)	5	MSL	8399
231	100	0.7	NaCl/m	lgK:2.908 (4SF)	5	MSL	8399
232	100	1	NaCl/m	lgK:2.777 (4SF)	5	MSL	8399
233	100	1.2	NaCl/m	lgK:2.712 (4SF)	5	MSL	8399
234	100	1.5	NaCl/m	lgK:2.634 (4SF)	5	MSL	8399
235	100	2	NaCl/m	lgK:2.536 (4SF)	5	MSL	8399
236	100	3	NaCl/m	lgK:2.402 (4SF)	5	MSL	8399
237	100	4	NaCl/m	lgK:2.306 (4SF)	5	MSL	8399
238	100	5	NaCl/m	lgK:2.229 (4SF)	5	MSL	8399
239	110	0	Inf. Dilution/m	lgK:4.710 (4SF)	3	MSL	8399
240	110	0	Inf. Dilution/m	lgK:5.18 (3SF)	0	MSL	8671
241	110	0.1	NaCl/m	lgK:3.677 (4SF)	5	MSL	8399
242	110	0.2	NaCl/m	lgK:3.427 (4SF)	5	MSL	8399
243	110	0.5	NaCl/m	lgK:3.077 (4SF)	5	MSL	8399
244	110	0.7	NaCl/m	lgK:2.948 (4SF)	5	MSL	8399
245	110	1	NaCl/m	lgK:2.815 (4SF)	5	MSL	8399
246	110	1.2	NaCl/m	lgK:2.749 (4SF)	5	MSL	8399
247	110	1.5	NaCl/m	lgK:2.670 (4SF)	5	MSL	8399
248	110	2	NaCl/m	lgK:2.572 (4SF)	5	MSL	8399
249	110	3	NaCl/m	lgK:2.440 (4SF)	5	MSL	8399
250	110	4	NaCl/m	lgK:2.351 (4SF)	5	MSL	8399
251	110	5	NaCl/m	lgK:2.283 (4SF)	5	MSL	8399
252	0	0	Inf. Dilution/m	dH:4.526 (4SF) kJ	3	MTD	8671
253	20	0	Inf. Dilution/m	dH:2.84 (3SF) kJ	4	MTD	8671
254	25	0	Inf. Dilution/m	dH:-0.13 (0.01SD)	5	ENS	5202
255	25	0	Inf. Dilution/m	dH:0.109 (3SF)	4	ENS	6496
256	25	0	Inf. Dilution/m	dH:-0.22 (2SF)	4	CRV	9402
257	30	0	Inf. Dilution/m	dH:0.16 (0.01SD)	5	ENS	5202
258	40	0	Inf. Dilution/m	dH:0.74 (0.01SD)	4	ENS	5202
259	40	0	Inf. Dilution/m	dH:-4.999 (4SF) kJ	0	MTD	8671

260	45	0	Inf. Dilution/m	dH:1.04 (0.01SD)	0	ENS	5202
261	50	0	Inf. Dilution/m	dH:1.35 (0.01SD)	0	ENS	5202
262	60	0	Inf. Dilution/m	dH:1.97 (0.01SD)	0	ENS	5202
263	60	0	Inf. Dilution/m	dH:-11.345 (5SF) kJ	0	MTD	8671
264	80	0	Inf. Dilution/m	dH:-18.75 (4SF) kJ	0	MTD	8671
265	100	0	Inf. Dilution/m	dH:-27.204 (5SF) kJ	0	MTD	8671
266	110	0	Inf. Dilution/m	dH:-31.818 (5SF) kJ	0	MTD	8671
267	25	0	Inf. Dilution/m	Cp:57. (1.SD)	4	ENS	5202
268	25	0	Inf. Dilution/m	Cp:57.20 (4SF)	4	CRV	9402
269	30	0	Inf. Dilution/m	Cp:57. (1.SD)	4	ENS	5202
270	40	0	Inf. Dilution/m	Cp:59. (1.SD)	4	ENS	5202
271	45	0	Inf. Dilution/m	Cp:60. (1.SD)	4	ENS	5202
272	50	0	Inf. Dilution/m	Cp:61. (1.SD)	3	ENS	5202
273	60	0	Inf. Dilution/m	Cp:63. (1.SD)	3	ENS	5202

Reaction No. 54776							
Ca+2 + SO4-2 + 0.5<H2O> = Ca+2_SO4-2_H2O(0.5)_(alpha,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:3.7286 (5SF)	3	CRV	31793
2	10	0	Inf. Dilution	lgK:3.7612 (5SF)	4	CRV	31793
3	20	0	Inf. Dilution	lgK:3.8274 (5SF)	4	CRV	31793
4	25	0	Inf. Dilution	lgK:3.5 (0.05SD)	1	ENS	5458
5	25	0	Inf. Dilution	lgK:3.8722 (5SF)	4	CRV	31793
Note (5): prob. refers to (and should have referred to) alpha form							
6	25	0	Inf. Dilution	lgK:5.52 (3SF)	2	CRV	32224
7	25	0	CHEMVAL1	lgK:3.52 (0.01SD)	0	ENS	5156
8	25	0	CHEMVAL2	lgK:3.52 (0.01SD)	0	ENS	5156
9	25	0	CHEMVAL3	lgK:3.52 (0.01SD)	0	ENS	5156
10	25	0	CHEMVAL4	lgK:3.52 (0.01SD)	1	ENS	5156
11	30	0	Inf. Dilution	lgK:3.9234 (5SF)	4	CRV	31793
12	40	0	Inf. Dilution	lgK:4.0425 (5SF)	4	CRV	31793
13	50	0	Inf. Dilution	lgK:4.1741 (5SF)	4	CRV	31793
14	60	0	Inf. Dilution	lgK:4.3036 (5SF)	4	CRV	31793
15	70	0	Inf. Dilution	lgK:4.4194 (5SF)	4	CRV	31793
16	80	0	Inf. Dilution	lgK:4.5245 (5SF)	4	CRV	31793
17	90	0	Inf. Dilution	lgK:4.6498 (5SF)	4	CRV	31793

18	100	0	Inf. Dilution	lgK:4.8847(5SF)	3	CRV	31793
----	-----	---	---------------	-----------------	---	-----	-------

Reaction No. 54777



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.4(0.05SD)	4	ENS	5458
2	25	0	Inf. Dilution	lgK:3.35(3SF)	4	CRV	32224

Reaction No. 54847




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.4(2SF)	1	ELC	
2	37	0.15	KNO3	lgK:2.4(0.9SD)	3	MPS	255
3	100	0	Inf. Dilution	lgK:2.4(2SF)	1	ELC	

Reaction No. 54848




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.(1SF)	1	EES	
2	37	0.15	KNO3	lgK:3.7(0.9SD)	3	MPS	255

Reaction No. 54939



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.15(3SF)	1	CRV	
Note (1): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
2	25	0	Inf. Dilution	lgK:2.3(0.05SD)	0	ENS	766
3	25	0	Inf. Dilution	lgK:3.2(2SF)	3	ENS	5648
4	25	0	Inf. Dilution	lgK:1.64(3SF)	0	ENS	7694
5	25	0	Inf. Dilution	lgK:3.149(4SF)	5	CRV	22551
6	25	0	Inf. Dilution	dH:6.4(0.1SD)	4	ENS	766

Reaction No. 55020



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.4(2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:0.2(0.05SD)	0	ENS	557


Reaction No. 55021							
$\text{Ca}+2 + \text{H}+1(2)\text{PO}_4-3 = \text{Ca}+2\text{H}+1\text{PO}_4-3(\text{s}) + \text{H}+1$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: -0.3(0.05\text{SD})$	4	ENS	557
2	25	3	Inert	$\lg K: 0.6(1\text{SF})$	1	EES	
3	100	0	Inf. Dilution	$\lg K: -1.1(2\text{SF})$	1	EES	

Reaction No. 55022							
$\text{Ca}+2 + 2\text{H}+1(2)\text{PO}_4-3 + \text{H}_2\text{O} = \text{Ca}+2\text{H}+1(4)\text{PO}_4-3(2)\text{H}_2\text{O}(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 1.2(0.05\text{SD})$	3	ENS	557
2	25	0	Inf. Dilution	$\lg K: 1.14(3\text{SF})$	4	EOD	31761

Reaction No. 55024							
$\text{Ca}+2\text{Mg}+2\text{CO}_3-2(2)(\text{ord.},\text{s}) = \text{Ca}+2 + \text{Mg}+2 + 2\text{CO}_3-2$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: -16.6(3\text{SF})$	1	EES	
2	25	0	Inf. Dilution	$\lg K: -17.10(0.02\text{SD})$	3	ENS	5484
3	25	0	Inf. Dilution	$\lg K: -17.09(4\text{SF})$	3	ENS	6496
4	25	0	CHEMVAL1	$\lg K: -16.98(0.01\text{SD})$	0	ENS	5156
5	25	0	CHEMVAL2	$\lg K: -16.98(0.01\text{SD})$	0	ENS	5156
6	25	0	CHEMVAL3	$\lg K: -16.98(0.01\text{SD})$	0	ENS	5156
7	25	0	CHEMVAL4	$\lg K: -17.10(0.01\text{SD})$	3	ENS	5156
8	25	3	Inert	$\lg K: -14.0(3\text{SF})$	1	EES	
9	50	0.1056	NaCl/m	$\lg K: -15.96(4\text{SF})$	4	CRV	26086
10	50.6	0.1056	NaCl/m	$\lg K: -15.86(4\text{SF})$	4	CRV	26086
11	50.6	0.1067	NaCl/m	$\lg K: -15.70(4\text{SF})$	3	CRV	26086
12	74.7	0.1045	NaCl/m	$\lg K: -16.73(4\text{SF})$	4	CRV	26086
13	75.9	0.1051	NaCl/m	$\lg K: -16.79(4\text{SF})$	4	CRV	26086
14	99.2	0.1038	NaCl/m	$\lg K: -17.73(4\text{SF})$	3	CRV	26086
15	99.8	0.1041	NaCl/m	$\lg K: -17.60(4\text{SF})$	4	CRV	26086
16	100.5	0.1048	NaCl/m	$\lg K: -17.23(4\text{SF})$	3	CRV	26086
17	124.2	0.1038	NaCl/m	$\lg K: -18.33(4\text{SF})$	4	CRV	26086
18	124.7	0.1029	NaCl/m	$\lg K: -18.28(4\text{SF})$	4	CRV	26086
19	125	0.1029	NaCl/m	$\lg K: -18.76(4\text{SF})$	2	CRV	26086
20	125.2	0.1034	NaCl/m	$\lg K: -18.41(4\text{SF})$	4	CRV	26086


21	139.4	0.1043	NaCl/m	lgK:-21.45 (4SF)	0	CRV	26086
22	148.6	0.103	NaCl/m	lgK:-19.19 (4SF)	4	CRV	26086
23	152.1	0.1029	NaCl/m	lgK:-19.06 (4SF)	4	CRV	26086
24	152.2	0.1031	NaCl/m	lgK:-19.61 (4SF)	2	CRV	26086
25	174.4	0.1028	NaCl/m	lgK:-19.92 (4SF)	4	CRV	26086
26	174.6	0.1025	NaCl/m	lgK:-19.68 (4SF)	2	CRV	26086
27	175.1	0.1027	NaCl/m	lgK:-20.27 (4SF)	4	CRV	26086
28	175.5	0.1019	NaCl/m	lgK:-19.77 (4SF)	2	CRV	26086
29	176.5	0.1022	NaCl/m	lgK:-19.86 (4SF)	3	CRV	26086
30	180.7	0.1043	NaCl/m	lgK:-23.15 (4SF)	0	CRV	26086
31	199.4	0.1048	NaCl/m	lgK:-21.02 (4SF)	4	CRV	26086
32	221.2	0.1045	NaCl/m	lgK:-25.22 (4SF)	0	CRV	26086
33	227.2	0.1032	NaCl/m	lgK:-21.99 (4SF)	4	CRV	26086
34	228.2	0.1077	NaCl/m	lgK:-22.43 (4SF)	2	CRV	26086
35	247.5	0.1052	NaCl/m	lgK:-23.62 (4SF)	0	CRV	26086
36	252.5	0.1038	NaCl/m	lgK:-26.44 (4SF)	0	CRV	26086
37	25	0	Inf. Dilution	dH:-9.4 (0.1SD)	3	ENS	5484
38	25	0	Inf. Dilution	dH:-9.436 (4SF)	3	ENS	6496

Reaction No. 55045



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.3 (2SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:7.17 (3SF)	0	CRV	
Note (2): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
3	25	0	Inf. Dilution	lgK:6.5 (0.05SD)	0	MSL	140
4	25	1	NaClO4	lgK:4.8 (0.05SD)	3	MSL	140
5	25	3.5	NaClO4	lgK:5.0 (0.05SD)	0	MSL	140

Reaction No. 55054



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:157.4 (4SF)	3	ENS	6422
2	25	0	Inf. Dilution	lgK:157.3 (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:156.3 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:156.3 (4SF)	0	ENS	6494

5	127	0	Inf. Dilution	lgK:113.4 (4SF)	2	ENS	6422
6	127	0	Inf. Dilution	lgK:113.4 (4SF)	2	ENS	6494
7	227	0	Inf. Dilution	lgK:87.72 (4SF)	3	ENS	6422
8	227	0	Inf. Dilution	lgK:87.64 (4SF)	1	ENS	6494
9	327	0	Inf. Dilution	lgK:70.61 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:70.52 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-214.8 (0.05SD)	2	ENS	802
12	25	0	Inf. Dilution	dG:-897.5 (4SF) kJ	3	CRV	6330
13	25	0	Inf. Dilution	dG:-214.7 (4SF)	4	EFE	6422
14	25	0	Inf. Dilution	dG:-214.6 (4SF)	4	EFE	6494
15	25	0	Inf. Dilution	dG:-898.49 (5SF) kJ	3	ENS	7381
16	25	0	Inf. Dilution	dG:-897.3 (4SF) kJ	2	CRV	8739
17	25	0	Inf. Dilution	dG:-897.0 (4SF) kJ	1	EOD	23101
18	25	0	Inf. Dilution	dG:-897.010 (6SF) kJ	2	CRV	23205
19	25	0	Inf. Dilution	dG:-897.010 (6SF) kJ	2	EOD	23205
20	25	0	Inf. Dilution	dG:-897.7 (4SF) kJ	4	EOD	29025
21	25	0	Inf. Dilution	dG:-898.33 (5SF) kJ	5	EOD	29520
22	25	0	Inf. Dilution	dG:-898.42 (5SF) kJ	5	CRV	29556
23	25	0	Inf. Dilution	dG:-897.01 (5SF) kJ	5	CRV	31308
24	25	0	Inf. Dilution/m	dG:-898.4 (4SF) kJ	3	EPZ	9073
25	25	0	Inf. Dilution	dH:-235.7 (0.05SD)	4	ENS	802
26	25	0	Inf. Dilution	dH:-985.2 (4SF) kJ	5	CRV	6330
27	25	0	Inf. Dilution	dH:-235.7 (4SF)	4	MTD	6422
28	25	0	Inf. Dilution	dH:-235.7 (4SF)	4	MTD	6494
29	25	0	Inf. Dilution	dH:-986.09 (5SF) kJ	4	ENS	7381
30	25	0	Inf. Dilution	dH:-985.00 (5SF) kJ	5	CRV	8739
31	25	0	Inf. Dilution	dH:-985. (3SF) kJ	3	EOD	23101
32	25	0	Inf. Dilution	dH:-986.6 (4SF) kJ	4	EOD	29025
33	25	0	Inf. Dilution	dH:-986.00 (5SF) kJ	5	EOD	29520
34	25	0	Inf. Dilution	dH:-986.09 (5SF) kJ	5	CRV	29556
35	25	0	Inf. Dilution	dH:-985. (3SF) kJ	5	CRV	31308
36	127	0	Inf. Dilution	dH:-235.5 (4SF)	4	MTD	6422
37	127	0	Inf. Dilution	dH:-235.5 (4SF)	4	MTD	6494
38	227	0	Inf. Dilution	dH:-235.1 (4SF)	3	MTD	6422
39	227	0	Inf. Dilution	dH:-235.2 (4SF)	1	MTD	6494
40	327	0	Inf. Dilution	dH:-234.7 (4SF)	0	MTD	6422

41	327	0	Inf. Dilution	dH:-234.8 (4SF)	0	MTD	6494
42	25	0	Inf. Dilution	Cp:87.5 (3SF) J/K	4	EOD	29025

Reaction No. 55075							
Ca(s) + F2(g) = Ca+2_F-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-265.6 (0.05SD)	2	ENS	802
Note (1): Data for Ca+2_F-1(2) are all over the place (unsurprisingly)							
2	25	0	Inf. Dilution	dH:-288.7 (0.05SD)	2	ENS	802

Reaction No. 55076							
Ca(s) + Cl2(g) = Ca+2_Cl-1(2)							
Note: Implausible species: Ca+2_Cl-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-195.0 (0.05SD)	0	ENS	802
2	25	0	Inf. Dilution	dG:-194.00 (5SF)	0	CRV	10174
3	50	0	Inf. Dilution	dG:-194.19 (5SF)	0	CRV	10174
4	75	0	Inf. Dilution	dG:-194.43 (5SF)	0	CRV	10174
5	100	0	Inf. Dilution	dG:-194.73 (5SF)	0	CRV	10174
6	125	0	Inf. Dilution	dG:-195.08 (5SF)	0	CRV	10174
7	150	0	Inf. Dilution	dG:-195.47 (5SF)	0	CRV	10174
8	175	0	Inf. Dilution	dG:-195.90 (5SF)	0	CRV	10174
9	200	0	Inf. Dilution	dG:-196.36 (5SF)	0	CRV	10174
10	225	0	Inf. Dilution	dG:-196.87 (5SF)	0	CRV	10174
11	250	0	Inf. Dilution	dG:-197.41 (5SF)	0	CRV	10174
12	300	0	Inf. Dilution	dG:-198.58 (5SF)	0	CRV	10174
13	25	0	Inf. Dilution	dH:-209.6 (0.05SD)	0	ENS	802

Reaction No. 55077							
Ca(s) + N2(g) + 4<O2(g)> + 2<H2(g)> = Ca+2_NO3-1(2)_H2O(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:215.3 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:213.7 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:146.6 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:106.4 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:79.71 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-293.8 (0.05SD)	4	ENS	802

7	25	0	Inf. Dilution	dG:-293.7 (4SF)	4	ENS	6422
8	25	0	Inf. Dilution	dH:-368.2 (0.05SD)	4	ENS	802
9	25	0	Inf. Dilution	dH:-368.3 (4SF)	4	MTD	6422
10	27	0	Inf. Dilution	dH:-368.2 (4SF)	0	MTD	6422
11	127	0	Inf. Dilution	dH:-367.9 (4SF)	4	MTD	6422
12	227	0	Inf. Dilution	dH:-367.3 (4SF)	4	MTD	6422
13	327	0	Inf. Dilution	dH:-366.3 (4SF)	4	MTD	6422

Reaction No. 55078							
Ca(s) + N2(g) + 4.5<O2(g)> + 3<H2(g)> = Ca+2_NO3-1(2)_H2O(3)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:257.8 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:255.8 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:175.8 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:127.9 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:95.91 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-352. (0.5SD)	4	ENS	802
7	25	0	Inf. Dilution	dG:-351.7 (4SF)	4	ENS	6422
8	25	0	Inf. Dilution	dH:-439. (0.5SD)	4	ENS	802
9	25	0	Inf. Dilution	dH:-439.3 (4SF)	4	MTD	6422
10	127	0	Inf. Dilution	dH:-439.2 (4SF)	4	MTD	6422
11	227	0	Inf. Dilution	dH:-438.7 (4SF)	4	MTD	6422
12	327	0	Inf. Dilution	dH:-438.0 (4SF)	4	MTD	6422

Reaction No. 55079							
Ca(s) + N2(g) + 5<O2(g)> + 4<H2(g)> = Ca+2_NO3-1(2)_H2O(4)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:300.1 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:297.8 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:205.0 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:149.3 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:112.2 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-409.5 (0.05SD)	4	ENS	802
7	25	0	Inf. Dilution	dG:-409.4 (4SF)	4	ENS	6422
8	25	0	Inf. Dilution	dH:-509.6 (0.05SD)	4	ENS	802
9	25	0	Inf. Dilution	dH:-509.6 (4SF)	4	MTD	6422

10	127	0	Inf. Dilution	dH:-509.8 (4SF)	4	MTD	6422
11	227	0	Inf. Dilution	dH:-509.6 (4SF)	4	MTD	6422
12	327	0	Inf. Dilution	dH:-509.1 (4SF)	4	MTD	6422


Reaction No. 55080							
Ca(s) + 1.5<O2(g)> + Si(s) = CaO.SiO2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:271.5 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:271.4 (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:269.7 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:269.6 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:198.6 (4SF)	2	ENS	6422
6	127	0	Inf. Dilution	lgK:198.5 (4SF)	2	ENS	6494
7	227	0	Inf. Dilution	lgK:155.9 (4SF)	1	ENS	6422
8	227	0	Inf. Dilution	lgK:155.8 (4SF)	1	ENS	6494
9	327	0	Inf. Dilution	lgK:127.4 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:127.3 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-370.4 (0.05SD)	4	ENS	802
12	25	0	Inf. Dilution	dG:-370.4 (4SF)	4	EFE	6422
13	25	0	Inf. Dilution	dG:-369.53 (5SF)	2	EFE	6482
14	25	0	Inf. Dilution	dG:-370.2 (4SF)	4	EFE	6494
15	25	0	Inf. Dilution	dG:-1549.0 (5SF) kJ	5	CRV	8695
16	25	0	Inf. Dilution	dG:-370.22 (5SF)	4	EFE	32152
17	25	0	Inf. Dilution	dH:-390.8 (0.05SD)	4	ENS	802
18	25	0	Inf. Dilution	dH:-390.8 (4SF)	4	MTD	6422
19	25	0	Inf. Dilution	dH:-390.0 (4SF)	3	ENS	6437
20	25	0	Inf. Dilution	dH:-389.94 (5SF)	2	EFE	6482
21	25	0	Inf. Dilution	dH:-390.7 (4SF)	4	MTD	6494
22	25	0	Inf. Dilution	dH:-1634.90 (6SF) kJ	5	CRV	8695
23	127	0	Inf. Dilution	dH:-390.7 (4SF)	1	MTD	6422
24	127	0	Inf. Dilution	dH:-390.7 (4SF)	1	MTD	6494
25	227	0	Inf. Dilution	dH:-390.5 (4SF)	0	MTD	6422
26	227	0	Inf. Dilution	dH:-390.5 (4SF)	0	MTD	6494
27	327	0	Inf. Dilution	dH:-390.2 (4SF)	0	MTD	6422
28	327	0	Inf. Dilution	dH:-390.3 (4SF)	0	MTD	6494

Reaction No. 55081							
$2\text{Ca(s)} + 2\text{O}_2\text{(g)} + \text{Si(s)} = 2\text{CaO.SiO}_2\text{(beta,s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:383.7(4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:383.9(4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:381.2(4SF)	4	ENS	6422
4	27	0	Inf. Dilution	lgK:381.4(4SF)	4	ENS	6494
5	127	0	Inf. Dilution	lgK:280.9(4SF)	4	ENS	6422
6	127	0	Inf. Dilution	lgK:281.0(4SF)	4	ENS	6494
7	227	0	Inf. Dilution	lgK:220.8(4SF)	4	ENS	6422
8	227	0	Inf. Dilution	lgK:220.8(4SF)	4	ENS	6494
9	327	0	Inf. Dilution	lgK:180.7(4SF)	4	ENS	6422
10	327	0	Inf. Dilution	lgK:180.7(4SF)	4	ENS	6494
11	25	0	Inf. Dilution	dG:-524.(0.5SD)	4	ENS	802
12	25	0	Inf. Dilution	dG:-523.5(4SF)	4	EFE	6422
13	25	0	Inf. Dilution	dG:-523.7(4SF)	4	EFE	6494
14	25	0	Inf. Dilution	dH:-551.(0.5SD)	4	ENS	802
15	25	0	Inf. Dilution	dH:-550.9(4SF)	4	MTD	6422
16	25	0	Inf. Dilution	dH:-551.3(4SF)	4	MTD	6494
17	127	0	Inf. Dilution	dH:-550.7(4SF)	4	MTD	6422
18	127	0	Inf. Dilution	dH:-551.2(4SF)	4	MTD	6494
19	227	0	Inf. Dilution	dH:-550.4(4SF)	4	MTD	6422
20	227	0	Inf. Dilution	dH:-550.9(4SF)	4	MTD	6494
21	327	0	Inf. Dilution	dH:-550.0(4SF)	4	MTD	6422
22	327	0	Inf. Dilution	dH:-550.6(4SF)	4	MTD	6494

Reaction No. 55082							
$2\text{Ca(s)} + 2\text{O}_2\text{(g)} + \text{Si(s)} = 2\text{CaO.SiO}_2\text{(gamma,s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:385.2(4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:385.2(4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:382.7(4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:382.7(4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:281.9(4SF)	4	ENS	6422
6	127	0	Inf. Dilution	lgK:281.9(4SF)	4	ENS	6494
7	227	0	Inf. Dilution	lgK:221.5(4SF)	4	ENS	6422

8	227	0	Inf. Dilution	lgK:221.4 (4SF)	4	ENS	6494
9	327	0	Inf. Dilution	lgK:181.2 (4SF)	4	ENS	6422
10	327	0	Inf. Dilution	lgK:181.1 (4SF)	4	ENS	6494
11	25	0	Inf. Dilution	dG:-526. (0.5SD)	4	ENS	802
12	25	0	Inf. Dilution	dG:-525.5 (4SF)	4	EFE	6422
13	25	0	Inf. Dilution	dG:-525.5 (4SF)	4	EFE	6494
14	25	0	Inf. Dilution	dH:-554. (0.5SD)	4	ENS	802
15	25	0	Inf. Dilution	dH:-553.3 (4SF)	4	MTD	6422
16	25	0	Inf. Dilution	dH:-553.7 (4SF)	4	MTD	6494
17	27	0	Inf. Dilution	dH:-553.4 (4SF)	0	MTD	6422
18	127	0	Inf. Dilution	dH:-553.3 (4SF)	4	MTD	6422
19	127	0	Inf. Dilution	dH:-553.6 (4SF)	4	MTD	6494
20	227	0	Inf. Dilution	dH:-553.1 (4SF)	4	MTD	6422
21	227	0	Inf. Dilution	dH:-553.4 (4SF)	4	MTD	6494
22	327	0	Inf. Dilution	dH:-552.8 (4SF)	4	MTD	6422
23	327	0	Inf. Dilution	dH:-553.2 (4SF)	4	MTD	6494

Reaction No. 55083



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:487.7 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:488.2 (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:484.6 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:485.0 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:357.1 (4SF)	3	ENS	6422
6	127	0	Inf. Dilution	lgK:357.3 (4SF)	3	ENS	6494
7	227	0	Inf. Dilution	lgK:280.6 (4SF)	2	ENS	6422
8	227	0	Inf. Dilution	lgK:280.8 (4SF)	2	ENS	6494
9	327	0	Inf. Dilution	lgK:229.7 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:229.8 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-665. (0.5SD)	4	ENS	802
12	25	0	Inf. Dilution	dG:-665.4 (4SF)	4	EFE	6422
13	25	0	Inf. Dilution	dG:-666.0 (4SF)	4	EFE	6494
14	25	0	Inf. Dilution	dH:-700. (0.5SD)	4	ENS	802
15	25	0	Inf. Dilution	dH:-700.1 (4SF)	4	MTD	6422
16	25	0	Inf. Dilution	dH:-701.0 (4SF)	4	MTD	6494


17	127	0	Inf. Dilution	dH:-699.8 (4SF)	2	MTD	6422
18	127	0	Inf. Dilution	dH:-700.8 (4SF)	2	MTD	6494
19	227	0	Inf. Dilution	dH:-699.2 (4SF)	0	MTD	6422
20	227	0	Inf. Dilution	dH:-700.4 (4SF)	0	MTD	6494
21	327	0	Inf. Dilution	dH:-698.6 (4SF)	0	MTD	6422
22	327	0	Inf. Dilution	dH:-699.8 (4SF)	0	MTD	6494

Reaction No. 55084							
3<Ca(s)> + 3.5<O2(g)> + 2<Si(s)> = 3CaO.2SiO2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:659.1 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:659.0 (4SF)	0	ENS	6422
3	25	0	Inf. Dilution	lgK:656.6 (4SF)	0	ENS	6494
4	27	0	Inf. Dilution	lgK:654.7 (4SF)	0	ENS	6422
5	27	0	Inf. Dilution	lgK:652.4 (4SF)	0	ENS	6494
6	127	0	Inf. Dilution	lgK:482.3 (4SF)	1	ENS	6422
7	127	0	Inf. Dilution	lgK:480.5 (4SF)	1	ENS	6494
8	227	0	Inf. Dilution	lgK:378.9 (4SF)	0	ENS	6422
9	227	0	Inf. Dilution	lgK:377.4 (4SF)	0	ENS	6494
10	327	0	Inf. Dilution	lgK:310.0 (4SF)	0	ENS	6422
11	327	0	Inf. Dilution	lgK:308.7 (4SF)	0	ENS	6494
12	25	0	Inf. Dilution	dG:-899. (0.5SD)	0	ENS	802
13	25	0	Inf. Dilution	dG:-899.0 (4SF)	0	EFE	6422
14	25	0	Inf. Dilution	dG:-895.8 (4SF)	0	EFE	6494
15	25	0	Inf. Dilution	dH:-947. (0.5SD)	0	ENS	802
16	25	0	Inf. Dilution	dH:-946.7 (4SF)	0	MTD	6422
17	25	0	Inf. Dilution	dH:-943.8 (4SF)	0	MTD	6494
18	127	0	Inf. Dilution	dH:-946.5 (4SF)	0	MTD	6422
19	127	0	Inf. Dilution	dH:-943.7 (4SF)	0	MTD	6494
20	227	0	Inf. Dilution	dH:-945.9 (4SF)	0	MTD	6422
21	227	0	Inf. Dilution	dH:-943.3 (4SF)	0	MTD	6494
22	327	0	Inf. Dilution	dH:-945.3 (4SF)	0	MTD	6422
23	327	0	Inf. Dilution	dH:-942.9 (4SF)	0	MTD	6494

Reaction No. 55099							
Ca(s) + Si(s) + 1.5<O2(g)> = CaO.SiO2(Pseudo.,s)							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:270.6(4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:270.4(4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:268.9(4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:268.6(4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:198.0(4SF)	2	ENS	6422
6	127	0	Inf. Dilution	lgK:197.8(4SF)	2	ENS	6494
7	227	0	Inf. Dilution	lgK:155.5(4SF)	1	ENS	6422
8	227	0	Inf. Dilution	lgK:155.3(4SF)	1	ENS	6494
9	327	0	Inf. Dilution	lgK:127.2(4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:127.0(4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-369.(0.5SD)	4	ENS	802
12	25	0	Inf. Dilution	dG:-369.2(4SF)	4	EFE	6422
13	25	0	Inf. Dilution	dG:-368.81(5SF)	4	EFE	6482
14	25	0	Inf. Dilution	dG:-368.9(4SF)	4	EFE	6494
15	25	0	Inf. Dilution	dH:-389.(0.5SD)	4	ENS	802
16	25	0	Inf. Dilution	dH:-389.2(4SF)	4	MTD	6422
17	25	0	Inf. Dilution	dH:-388.96(5SF)	4	EFE	6482
18	25	0	Inf. Dilution	dH:-389.0(4SF)	4	MTD	6494
19	127	0	Inf. Dilution	dH:-389.1(4SF)	1	MTD	6422
20	127	0	Inf. Dilution	dH:-388.9(4SF)	1	MTD	6494
21	227	0	Inf. Dilution	dH:-388.9(4SF)	0	MTD	6422
22	227	0	Inf. Dilution	dH:-388.8(4SF)	0	MTD	6494
23	327	0	Inf. Dilution	dH:-388.7(4SF)	0	MTD	6422
24	327	0	Inf. Dilution	dH:-388.6(4SF)	0	MTD	6494


Reaction No. 55101



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-22.7(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-22.9(0.05SD)	0	ENS	4998
3	25	0	Inf. Dilution	lgK:-22.8(0.02SD)	0	CRV	6478
4	25	0	Inf. Dilution	lgK:-22.8(3SF)	0	ENS	6496
5	25	0	Inf. Dilution	lgK:-22.80(4SF)	0	MSL	7062
6	25	0	Inf. Dilution	lgK:-22.80(4SF)	3	CRV	9402
7	25	0	Inf. Dilution	lgK:-22.68(4SF)	2	EOD	23102


8	25	0	Inf. Dilution	lgK:-22.8 (3SF)	3	EOD	30627
9	25	0	Inf. Dilution	lgK:-22.68 (4SF)	4	CRV	32224
10	25	0	CHEMVAL1	lgK:-22.65 (0.01SD)	0	ENS	5156
11	25	0	CHEMVAL2	lgK:-22.65 (0.01SD)	0	ENS	5156
12	25	0	CHEMVAL3	lgK:-22.65 (0.01SD)	0	ENS	5156
13	25	0	CHEMVAL4	lgK:-22.70 (0.01SD)	3	ENS	5156
14	25	0.1	Unknown	lgK:-23.0 (3SF)	4	CRV	31724
15	35	0	Inf. Dilution	lgK:-22.09 (4SF)	0	MSL	7062
16	80	0	Inf. Dilution	lgK:-19.38 (4SF)	0	MSL	7062
17	25	0	Inf. Dilution	dH:31.08 (0.05SD)	1	CRV	6478
18	25	0	Inf. Dilution	dH:31.0 (3SF)	1	ENS	6496
19	25	0	Inf. Dilution	dH:31.00 (4SF)	1	CRV	9402

Reaction No. 55142



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	LiClO4	lgK:-1.05 (0.05SD)	2	MSL	5055
2	25	4	LiClO4	lgK:-0.72 (0.05SD)	2	MSL	5055


Reaction No. 55171



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:251.5 (4SF)	3	ENS	6422
2	27	0	Inf. Dilution	lgK:249.8 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:182.7 (4SF)	3	ENS	6422
4	227	0	Inf. Dilution	lgK:142.5 (4SF)	2	ENS	6422
5	327	0	Inf. Dilution	lgK:115.7 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-342.9 (0.05SD)	2	ENS	802
7	25	0	Inf. Dilution	dG:-343.1 (4SF)	2	ENS	6422
8	25	0	Inf. Dilution	dG:-344.0 (4SF)	3	EFE	30708
9	25	0	Inf. Dilution	dG:-1437.60 (1.113SD) kJ	5	MSL	30809
10	25	0	Inf. Dilution	dH:-368.4 (0.1SD)	2	ENS	802
11	25	0	Inf. Dilution	dH:-368.6 (4SF)	3	MTD	6422
12	25	0	Inf. Dilution	dH:-369.5 (4SF)	4	EOD	30708
13	25	0	Inf. Dilution	dH:-1544.90 (1.045SD) kJ	5	MSL	30809
14	127	0	Inf. Dilution	dH:-368.3 (4SF)	1	MTD	6422

15	227	0	Inf. Dilution	dH:-367.8 (4SF)	0	MTD	6422
16	327	0	Inf. Dilution	dH:-367.3 (4SF)	0	MTD	6422
17	25	0	Inf. Dilution	Cp:114.5 (4SF) J/K	5	MSL	30809

Reaction No. 55182



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-332.2 (0.05SD)	5	ENS	802
2	25	0	Inf. Dilution	dH:-368.2 (0.1SD)	5	ENS	802

Reaction No. 55323



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	200	0	P=300 Inf. Dilution	lgK:-7.961 (4SF)	3	EOD	29559
2	100	0	P=500 Inf. Dilution/m	lgK:-10.04 (4SF)	3	MSL	4914
3	200	0	P=500 Inf. Dilution/m	lgK:-8.20 (3SF)	3	MSL	4914
4	300	0	P=500 Inf. Dilution/m	lgK:-6.88 (3SF)	3	MSL	4914
5	5	0.15	Inert	lgK:-13.7 (0.1SD)	4	MIS	5574
6	15	0.15	Inert	lgK:-13.3 (0.1SD)	4	MIS	5574
7	25	0	Inf. Dilution	lgK:-12.85 (4SF)	4	CRV	6478
8	25	0	Inf. Dilution	lgK:-12.78 (4SF)	4	ENS	6496
9	25	0	Inf. Dilution	lgK:-12.70 (4SF)	5	CRV	9402
10	25	0	Inf. Dilution	lgK:-12.833 (5SF)	4	EOD	29559
11	25	0	Inf. Dilution	lgK:-12.78 (4SF)	3	EOD	30627
12	25	0	Inf. Dilution	lgK:-12.85 (0.025SD)	4	EOD	31301
13	25	0	Inf. Dilution	lgK:-12.67 (4SF)	4	CRV	32224
14	25	0	CHEMVAL1	lgK:-12.79 (0.01SD)	0	ENS	5156
15	25	0	CHEMVAL2	lgK:-12.70 (0.01SD)	0	ENS	5156
16	25	0	CHEMVAL3	lgK:-12.70 (0.01SD)	0	ENS	5156
17	25	0	CHEMVAL4	lgK:-12.70 (0.01SD)	3	ENS	5156
18	25	0	UCT_Sea	lgK:-12.70 (0.01SD)	4	EDH	5390
19	25	0.1	UCT_Sea	lgK:-12.89 (0.01SD)	4	EDH	5390
20	25	0.15	Inert	lgK:-12.9 (0.1SD)	4	MIS	5574
21	25	0.2	UCT_Sea	lgK:-12.94 (0.01SD)	4	EDH	5390

22	25	0.3	UCT_Sea	lgK:-12.98(0.01SD)	4	EDH	5390
23	25	0.4	UCT_Sea	lgK:-13.00(0.01SD)	4	EDH	5390
24	25	0.5	UCT_Sea	lgK:-13.03(0.01SD)	4	EDH	5390
25	25	0.6	UCT_Sea	lgK:-13.05(0.01SD)	4	EDH	5390
26	25	0.7	UCT_Sea	lgK:-13.08(0.01SD)	4	EDH	5390
27	25	0.7	Unknown	lgK:-12.2(3SF)	0	EOD	5644
28	25	3	ClO4-1 salt	lgK:-13.4(0.05SD)	5	MGL	3492
29	35	0.15	Inert	lgK:-12.5(0.1SD)	4	MIS	5574
30	37	0.15	Blood Plasma	lgK:-11.7(3SF)	0	CRV	22388
31	45	0.15	Inert	lgK:-12.1(0.1SD)	3	MIS	5574
32	90	0	Inf. Dilution	lgK:-10.433(5SF)	4	EOD	29559
33	150	0	Inf. Dilution	lgK:-8.903(4SF)	4	EOD	29559
34	210	0	Inf. Dilution	lgK:-7.757(4SF)	4	EOD	29559
35	25	0	Inf. Dilution	dH:15.5(3SF)	3	CRV	6478
36	25	0	Inf. Dilution	dH:15.6(0.7SD)	5	CRV	6478
37	25	0	Inf. Dilution	dH:15.30(4SF)	5	CRV	9402

Reaction No. 55362



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.8(0.05SD)	4	MDS	5084
2	23	2	NH4NO3	lgR:-1.1(0.05SD)	5	MDS	5084
3	25	0.5	NH4ClO4	lgR:-0.8(0.05SD)	5	MDS	5084
4	25	1	NH4ClO4	lgR:-0.9(0.05SD)	5	MDS	5084
5	25	1.5	NH4ClO4	lgR:-1.0(0.05SD)	5	MDS	5084

Reaction No. 55363



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.3(3SF)	2	EAE	
2	23	2	NH4NO3	lgR:-1.3(0.05SD)	5	MDS	5084

Reaction No. 55364



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.7(3SF)	2	EAE	
2	23	2	NH4NO3	lgR:-1.7(0.05SD)	5	MDS	5084

Reaction No. 55496							
Ca+2 + Fe+2_CN-1(6) = Ca+2_Fe+2_CN-1(6)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Cl-1 salt	lgK:3.57(0.03SD)	5	MIS	5378
2	15.2	0	Inf. Dilution	lgK:3.6(0.05SD)	5	MPT	5593
3	20	0	Cl-1 salt	lgK:3.60(0.02SD)	5	MIS	5378
4	24.8	0	Inf. Dilution	lgK:3.7(0.05SD)	5	MPT	5593
5	25	0	Inf. Dilution	lgK:3.8(0.04SD)	5	CMN	222
6	25	0	Cl-1 salt	lgK:3.63(0.02SD)	5	MIS	5378
7	30	0	Cl-1 salt	lgK:3.65(0.02SD)	5	MIS	5378
8	35	0	Inf. Dilution	lgK:3.8(0.05SD)	5	MPT	5593
9	35	0	Cl-1 salt	lgK:3.67(0.02SD)	5	MIS	5378
10	25	0	Inf. Dilution	dH:3.1(0.2SD)	4	MAC	5593

Reaction No. 55500							
Fe+3_CN-1(6) + Ca+2 = Fe+3_Ca+2_CN-1(6)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.8(0.03SD)	4	MCN	222
2	25	0.1	NO3-1 salt	lgK:1.48(0.01SD)	6	MCL	5304
3	25	3	Li+1 salt	lgK:0.23(2SF)	0	CRV	552
4	25	0.1	NO3-1 salt	dH:0.60(0.1SD)	6	MCL	5304
5	25	0.1	Unknown	dH:0.3(1SF)	4	CRV	552


Reaction No. 55592							
Ca+2_H+1(4)_AsO4-3(2)_(s) = Ca+2 + 2<H+1(2)_AsO4-3>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.1(0.1SD)	4	ENS	5522

Reaction No. 55593							
Ca+2(5)_H+1(2)_AsO4-3(4)_(s) + 2<H+1> = 5<Ca+2> + 4<H+1_AsO4-3>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.8(0.1SD)	4	ENS	5522

Reaction No. 55594							
Ca+2(3)_AsO4-3(2)_(s) + 2<H+1> = 3<Ca+2> + 2<H+1_AsO4-3>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:3.4 (2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:5.2 (0.1SD)	0	ENS	5522

Reaction No. 55595




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.9 (0.1SD)	4	ENS	5522

Reaction No. 55633




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	Cl-1 salt	lgK:0.4 (0.05SD)	5	MSL	5148
2	20	3	Cl-1 salt	lgK:0.3 (0.05SD)	5	MSL	5148
3	25	0	Inf. Dilution	lgK:3.36 (3SF)	2	EAE	

Reaction No. 55744



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.18 (4SF)	3	ENS	6422
2	27	0	Inf. Dilution	lgK:23.99 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:16.26 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:11.59 (4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:8.468 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-35.2 (0.1SD)	0	ENS	3006
7	25	0	Inf. Dilution	dG:-142.5 (4SF) kJ	0	CRV	6330
8	25	0	Inf. Dilution	dG:-32.99 (4SF)	3	EFE	6422
9	25	0	Inf. Dilution	dH:-44.5 (0.1SD)	0	ENS	3006
10	25	0	Inf. Dilution	dH:-181.5 (4SF) kJ	5	CRV	6330
11	25	0	Inf. Dilution	dH:-42.3 (3SF)	3	MTD	6422
12	127	0	Inf. Dilution	dH:-42.6 (3SF)	2	MTD	6422
13	227	0	Inf. Dilution	dH:-42.8 (3SF)	1	MTD	6422
14	327	0	Inf. Dilution	dH:-43.0 (3SF)	0	MTD	6422

Reaction No. 55751



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:378.9 (4SF)	1	ELC	

2	25	0	Inf. Dilution	lgK:379.0 (4SF)	0	ENS	6422
3	27	0	Inf. Dilution	lgK:376.5 (4SF)	0	ENS	6422
4	127	0	Inf. Dilution	lgK:275.3 (4SF)	1	ENS	6422
5	227	0	Inf. Dilution	lgK:214.6 (4SF)	1	ENS	6422
6	327	0	Inf. Dilution	lgK:174.1 (4SF)	0	ENS	6422
7	25	0	Inf. Dilution	dG:-517.1 (4SF)	0	EFE	6422
8	25	0	Inf. Dilution	dG:-2147.8 (5SF) kJ	0	MEF	18180
9	25	0	Inf. Dilution	dG:-2148.9 (5SF) kJ	0	EMD	18180
10	25	0	Inf. Dilution	dG:-2160.9 (2.SD) kJ	6	EFE	26086
11	25	0	Inf. Dilution	dH:-556.0 (4SF)	0	MTD	6422
12	25	0	Inf. Dilution	dH:-555.86 (5SF)	0	ENS	6437
13	25	0	Inf. Dilution	dH:-2323.1 (2.SD) kJ	6	EFE	26086
14	127	0	Inf. Dilution	dH:-555.8 (4SF)	0	MTD	6422
15	227	0	Inf. Dilution	dH:-555.6 (4SF)	0	MTD	6422
16	327	0	Inf. Dilution	dH:-555.3 (4SF)	0	MTD	6422
17	25	0	Inf. Dilution	Cp:37.65 (0.01SD)	2	ENS	802

Reaction No. 55752

$$\text{C(s)} + \text{Ca(s)} + 1.5\text{O}_2\text{(g)} = \text{Ca}_2\text{CO}_3\text{-(Calc.,s)}$$

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:197.8 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:197.7 (4SF)	2	ENS	6494
3	27	0	Inf. Dilution	lgK:196.5 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:196.4 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:143.9 (4SF)	3	ENS	6422
6	127	0	Inf. Dilution	lgK:143.9 (4SF)	3	ENS	6494
7	227	0	Inf. Dilution	lgK:112.5 (4SF)	2	ENS	6422
8	227	0	Inf. Dilution	lgK:112.4 (4SF)	2	ENS	6494
9	327	0	Inf. Dilution	lgK:91.51 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:91.40 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-1129.1 (5SF) kJ	5	CRV	6330
12	25	0	Inf. Dilution	dG:-269.8 (4SF)	4	EFE	6422
13	25	0	Inf. Dilution	dG:-269.67 (5SF)	2	EFE	6482
14	25	0	Inf. Dilution	dG:-269.7 (4SF)	2	EFE	6494
15	25	0	Inf. Dilution	dG:-1128.8 (5SF) kJ	5	EFE	7275
16	25	0	Inf. Dilution	dG:-1129. (4SF) kJ	5	CRV	8739

17	25	0	Inf. Dilution	dG:-1129.20 (6SF) kJ	4	CRV	23205
18	25	0	Inf. Dilution	dG:-1129.20 (6SF) kJ	3	EOD	23205
19	25	0	Inf. Dilution	dG:-1128.80 (6SF) kJ	4	CRV	25435
20	25	0	Inf. Dilution	dG:-1129.4 (5SF) kJ	4	EOD	29025
21	25	0	Inf. Dilution	dG:-1129.5 (5SF) kJ	5	EOD	29520
22	25	0	Inf. Dilution	dG:-269.88 (5SF)	3	EFE	32152
23	25	0	GAMSPATH	dG:-1130. (4SF) kJ	2	CRV	12638
24	25	0	Inf. Dilution	dH:-1207.6 (5SF) kJ	5	CRV	6330
25	25	0	Inf. Dilution	dH:-288.5 (4SF)	4	MTD	6422
26	25	0	Inf. Dilution	dH:-288.24 (5SF)	2	ENS	6437
27	25	0	Inf. Dilution	dH:-288.44 (5SF)	4	EFE	6482
28	25	0	Inf. Dilution	dH:-288.6 (4SF)	4	MTD	6494
29	25	0	Inf. Dilution	dH:-1206.9 (5SF) kJ	5	EFE	7275
30	25	0	Inf. Dilution	dH:-1207.60 (6SF) kJ	5	CRV	8739
31	25	0	Inf. Dilution	dH:-1207.50 (6SF) kJ	4	CRV	25435
32	25	0	Inf. Dilution	dH:-1207.4 (5SF) kJ	4	EOD	29025
33	25	0	Inf. Dilution	dH:-1208.0 (5SF) kJ	5	EOD	29520
34	25	0	GAMSPATH	dH:-1208.20 (6SF) kJ	3	CRV	12638
35	127	0	Inf. Dilution	dH:-288.2 (4SF)	2	MTD	6422
36	127	0	Inf. Dilution	dH:-288.3 (4SF)	4	MTD	6494
37	227	0	Inf. Dilution	dH:-287.9 (4SF)	2	MTD	6422
38	227	0	Inf. Dilution	dH:-288.0 (4SF)	2	MTD	6494
39	327	0	Inf. Dilution	dH:-287.5 (4SF)	0	MTD	6422
40	327	0	Inf. Dilution	dH:-287.6 (4SF)	0	MTD	6494
41	25	0	Inf. Dilution	Cp:19.57 (0.01SD)	4	ENS	802
42	25	0	Inf. Dilution	Cp:83.5 (3SF) J/K	4	EOD	29025

Reaction No. 55753

$$\text{Ca}+2_ \text{Mg}+2_ \text{CO}_3-2(2)_(\text{ord.},\text{s}) + 4\text{<H+1>} = \text{Ca}+2 + \text{Mg}+2 + 2\text{<CO}_2(\text{g})> + 2\text{<H}_2\text{O}>$$

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4 (3SF)	1	EOR	
2	25	3	NaClO4	lgK:18.2 (0.05SD)	3	MSL	5398


Reaction No. 55790

$$\text{Ca}+2 + \text{H}+1(2)_ \text{SiH}_2\text{O}_4-2 = \text{Ca}+2_ \text{SiH}_2\text{O}_4-2 + 2\text{<H+1>}$$

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:-18.7(3SF)	1	ELC	
2	25	0	CHEMVAL1	lgK:-19.87(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:-19.87(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:-19.87(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:-17.30(0.01SD)	0	ENS	5156

Reaction No. 55791



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-8.8(2SF)	1	ELC	
2	25	0	CHEMVAL1	lgK:-9.08(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:-9.08(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:-9.08(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:-8.84(0.01SD)	0	ENS	5156

Reaction No. 55792



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-16.2(3SF)	1	ELC	
2	25	0	CHEMVAL1	lgK:-16.05(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:-16.05(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:-16.06(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:-15.80(0.01SD)	0	ENS	5156

Reaction No. 55937



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:285.0(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:294.5(4SF)	0	ENS	6422
3	27	0	Inf. Dilution	lgK:292.6(4SF)	0	ENS	6422
4	127	0	Inf. Dilution	lgK:215.7(4SF)	0	ENS	6422
5	227	0	Inf. Dilution	lgK:169.6(4SF)	0	ENS	6422
6	327	0	Inf. Dilution	lgK:138.9(4SF)	0	ENS	6422
7	25	0	Inf. Dilution	dG:-401.8(0.05SD)	0	ENS	802
8	25	0	Inf. Dilution	dG:-401.8(4SF)	0	EFE	6422
9	25	0	Inf. Dilution	dH:-422.3(0.1SD)	2	ENS	802
10	25	0	Inf. Dilution	dH:-422.3(4SF)	2	MTD	6422

11	127	0	Inf. Dilution	dH:-422.1(4SF)	0	MTD	6422
12	227	0	Inf. Dilution	dH:-421.8(4SF)	0	MTD	6422
13	327	0	Inf. Dilution	dH:-421.4(4SF)	0	MTD	6422

Reaction No. 56076							
Ca+2 + NO3-1 + 9<H+1> + 8<e-1> = Ca+2_NH3 + 3<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:110.1(4SF)	1	ELC	
2	25	0	CHEMVAL4	lgK:110.0(0.05SD)	0	ENS	5156

Reaction No. 56077							
Ca+2 + 2<NO3-1> + 18<H+1> + 16<e-1> = Ca+2_NH3(2) + 6<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:219.5(4SF)	1	EES	
2	25	0	CHEMVAL4	lgK:219.0(0.05SD)	0	ENS	5156


Reaction No. 56078							
Ca+2 + 3<NO3-1> + 27<H+1> + 24<e-1> = Ca+2_NH3(3) + 9<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:329.1(4SF)	1	ELC	
2	25	0	CHEMVAL4	lgK:328.0(0.05SD)	0	ENS	5156

Reaction No. 56091							
CaO.(Al2O3)7.(SiO2)22.6H2O(s) + 44<H+1> + 16<H2O> = Ca+2 + 14<Al+3> + 22<H+1(2)_SiH2O4-2 >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:36.84(0.01SD)	0	ENS	5156
2	25	0	CHEMVAL2	lgK:36.84(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:36.84(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:36.80(0.01SD)	4	ENS	5156

Reaction No. 56094							
Fe+3(4)_Ca+2_OH-1(8)_PO4-3(2)_H2O(7)_ (s) + 8<H+1> + 4<e-1> = Ca+2 + 4<Fe+2> + 2<PO4-3 > + 15<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-25.14(4SF)	4	CRV	32224
2	25	0	CHEMVAL2	lgK:-25.10(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:-25.10(0.01SD)	0	ENS	5156


4	25	0	CHEMVAL4	lgK:-25.10 (0.01SD)	4	ENS	5156
---	----	---	----------	---------------------	---	-----	------

Reaction No. 56095




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-27.24 (4SF)	4	CRV	32224
2	25	0	CHEMVAL2	lgK:-27.24 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:-27.24 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:-27.20 (0.01SD)	4	ENS	5156

Reaction No. 56143



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:35.681 (5SF)	2	CRV	25435
2	25	0	Inf. Dilution	lgK:32.576 (5SF)	3	CRV	25435
3	25	0	Inf. Dilution	lgK:32.71 (4SF)	4	CRV	32224
4	25	0	CHEMVAL1	lgK:32.76 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL2	lgK:32.76 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL3	lgK:32.76 (0.01SD)	0	ENS	5156
7	25	0	CHEMVAL4	lgK:32.80 (0.01SD)	4	ENS	5156
8	25	3	Inert	lgK:38.5 (3SF)	1	EOR	
9	60	0	Inf. Dilution	lgK:29.011 (5SF)	3	CRV	25435
10	100	0	Inf. Dilution	lgK:26.0 (3SF)	1	EOR	
11	100	0	Inf. Dilution	lgK:25.7560 (6SF)	2	CRV	25435
12	150	0	Inf. Dilution	lgK:22.545 (5SF)	1	CRV	25435
13	200	0	Inf. Dilution	lgK:19.988 (5SF)	1	CRV	25435
14	250	0	Inf. Dilution	lgK:17.875 (5SF)	0	CRV	25435
15	300	0	Inf. Dilution	lgK:16.058 (5SF)	0	CRV	25435

Reaction No. 56144



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.2 (3SF)	1	ELC	
2	25	0	CHEMVAL1	lgK:17.29 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:17.29 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:17.29 (0.01SD)	0	ENS	5156

5	25	0	CHEMVAL4	lgK:17.30(0.01SD)	2	ENS	5156
---	----	---	----------	-------------------	---	-----	------

Reaction No. 56145							
$2\text{CaO} \cdot \text{Fe}_2\text{O}_3(\text{s}) + 10\langle\text{H}+1\rangle = 2\langle\text{Ca}+2\rangle + 2\langle\text{Fe}+3\rangle + 5\langle\text{H}_2\text{O}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:56.4(3SF)	1	ELC	
2	25	0	CHEMVAL1	lgK:52.65(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:52.65(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:52.65(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:52.60(0.01SD)	0	ENS	5156

Reaction No. 56146							
$\text{Ca}+2_F-1(2)_H2O(6)_(\text{s}) = \text{Ca}+2 + 2\langle F-1\rangle + 6\langle\text{H}_2\text{O}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:5.48(0.01SD)	4	ENS	5156
2	25	0	CHEMVAL2	lgK:5.48(0.01SD)	4	ENS	5156
3	25	0	CHEMVAL3	lgK:5.48(0.01SD)	4	ENS	5156
4	25	0	CHEMVAL4	lgK:5.48(0.01SD)	4	ENS	5156

Reaction No. 56147							
$\text{Ca}+2_S-2_(\text{s}) + \text{H}+1 = \text{Ca}+2 + \text{H}+1_S-2$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-33.3(0.05SD)	0	ENS	5156
2	25	0	CHEMVAL1	lgK:-37.85(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:-37.85(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:-37.85(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:-33.30(0.01SD)	0	ENS	5156

Reaction No. 56148							
$2\text{CaO} \cdot \text{SiO}_2(\text{gamma},\text{s}) + 4\langle\text{H}+1\rangle = 2\langle\text{Ca}+2\rangle + \text{H}+1(2)_SiH2O4-2$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:38.0(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:37.67(4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:39.01(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:39.01(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:39.01(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:40.40(0.01SD)	0	ENS	5156

Reaction No. 56149							
$2\text{CaO.SiO}_2(\text{beta}, \text{s}) + 4\text{H}^+ = 2\text{Ca}^{2+} + \text{H}_2\text{SiO}_4^{2-}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:39.3(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:39.16(4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:40.46(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:40.46(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:40.46(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:39.20(0.01SD)	0	ENS	5156


Reaction No. 56150							
$3\text{CaO.2SiO}_2(\text{s}) + \text{H}_2\text{O} + 6\text{H}^+ = 3\text{Ca}^{2+} + 2\text{H}_2\text{SiO}_4^{2-}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:50.0(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:48.62(4SF)	4	CRV	32224
3	25	0	CHEMVAL1	lgK:51.77(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:51.77(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:51.77(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:51.80(0.01SD)	0	ENS	5156

Reaction No. 56151							
$3\text{CaO.SiO}_2(\text{s}) + 6\text{H}^+ = 3\text{Ca}^{2+} + \text{H}_2\text{SiO}_4^{2-} + \text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:73.7(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:73.84(4SF)	4	CRV	32224
3	25	0	CHEMVAL1	lgK:75.42(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:75.42(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:75.42(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:75.40(0.01SD)	0	ENS	5156

Reaction No. 56152							
$\text{CaO.MgO.SiO}_2(\text{s}) + 4\text{H}^+ = \text{Ca}^{2+} + \text{Mg}^{2+} + \text{H}_2\text{SiO}_4^{2-}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:31.4(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:29.85(4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:30.27(0.01SD)	0	ENS	5156

4	25	0	CHEMVAL2	lgK:30.27(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:30.27(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:30.30(0.01SD)	0	ENS	5156

Reaction No. 56153




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:47.4(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:45.39(4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:48.74(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:48.74(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:48.74(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:45.80(0.01SD)	0	ENS	5156

Reaction No. 56154



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:69.0(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:68.55(4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:71.54(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:71.54(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:71.54(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:68.70(0.01SD)	0	ENS	5156


Reaction No. 56155



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:11.85(0.01SD)	0	ENS	5156
2	25	0	CHEMVAL2	lgK:11.85(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:11.85(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:11.80(0.01SD)	1	ENS	5156

Note (4): query mineral "laumontite"

Reaction No. 56156



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:26.2(3SF)	1	ELC	

2	25	0	Inf. Dilution	lgK:27.19(4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:27.06(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:27.06(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:27.06(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:23.00(0.01SD)	0	ENS	5156

Reaction No. 56157							
CaO.Al ₂ O ₃ .4SiO ₂ .H ₂ O(s) + 8<H+1> + 3<H ₂ O> = Ca+2 + 2<Al+3> + 4<H+1(2)_SiH ₂ O ₄ -2 >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:17.46(0.01SD)	0	ENS	5156
2	25	0	CHEMVAL2	lgK:17.46(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:17.46(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:17.50(0.01SD)	3	ENS	5156

Reaction No. 56158							
CaO.Al ₂ O ₃ .2SiO ₂ .2H ₂ O(s) + 8<H+1> = Ca+2 + 2<Al+3> + 2<H+1(2)_SiH ₂ O ₄ -2> + 2<H ₂ O >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:22.81(4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:22.06(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:22.06(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:22.06(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:17.00(0.01SD)	0	ENS	5156

Reaction No. 56159							
2CaO.Al ₂ O ₃ .SiO ₂ (s) + 10<H+1> = 2<Ca+2> + 2<Al+3> + H+1(2)_SiH ₂ O ₄ -2 + 3<H ₂ O >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:57.0(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:56.88(4SF)	4	CRV	32224
3	25	0	CHEMVAL1	lgK:56.42(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:56.42(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:56.42(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:52.00(0.01SD)	0	ENS	5156

Reaction No. 56160							
Ca ₂ Al ₂ Si ₃ O ₁₀ (OH) ₂ (s) + 10<H+1> = 2<Ca+2> + 2<Al+3> + 3<H+1(2)_SiH ₂ O ₄ -2 >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0	Inf. Dilution	lgK:34.6(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:33.51(4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:32.41(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:32.41(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:32.41(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:32.40(0.01SD)	0	ENS	5156

Reaction No. 56161							
$\text{Ca}_2\text{Al}_3\text{Si}_3\text{O}_{12}(\text{OH}) (\text{ortho}, \text{s}) + 13\text{H}^+ = 2\text{Ca}^{2+} + 3\text{Al}^{3+} + 3\text{H}_2\text{SiO}_4^{2-} + \text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:41.2(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:44.20(4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:39.83(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:39.83(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:39.83(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:39.80(0.01SD)	0	ENS	5156

Reaction No. 56162							
$\text{Ca}_2\text{Al}_4\text{Si}_8\text{O}_{24} \cdot 7\text{H}_2\text{O}(\text{s}) + 16\text{H}^+ + \text{H}_2\text{O} = 2\text{Ca}^{2+} + 4\text{Al}^{3+} + 8\text{H}_2\text{SiO}_4^{2-}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:25.06(0.01SD)	0	ENS	5156
2	25	0	CHEMVAL2	lgK:25.06(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:25.06(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:16.60(0.01SD)	3	ENS	5156

Reaction No. 56163							
$\text{Ca}_2\text{Cl}_2(\text{s}) = \text{Ca}^{2+} + 2\text{Cl}^-$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.08(3SF)	0	CRV	
Note (1): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
2	25	0	Inf. Dilution	lgK:11.92(4SF)	4	CRV	32224
3	25	0	CHEMVAL1	lgK:11.90(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:11.90(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:11.90(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:11.90(0.01SD)	1	ENS	5156

Reaction No. 56164							
--------------------	--	--	--	--	--	--	--

3CaO.Al ₂ O ₃ .3SiO ₂ (s) + 12<H+1> = 3<Ca+2> + 2<Al+3> + 3<H+1(2)_SiH ₂ O ₄ -2 >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:51.4 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:52.47 (4SF)	4	CRV	32224
3	25	0	CHEMVAL1	lgK:57.21 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:57.21 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:57.21 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:52.60 (0.01SD)	0	ENS	5156


Reaction No. 56165							
CaO.Fe _{0.2} SiO ₂ (s) + 2<H ₂ O> + 4<H+1> = Ca+2 + Fe+2 + 2<H+1(2)_SiH ₂ O ₄ -2 >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:18.40 (4SF)	0	CRV	6405
Note (2): p. 246							
3	25	0	Inf. Dilution	lgK:17.35 (4SF)	0	CRV	32224
4	25	0	CHEMVAL1	lgK:20.51 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL2	lgK:20.51 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL3	lgK:20.51 (0.01SD)	0	ENS	5156
7	25	0	CHEMVAL4	lgK:20.50 (0.01SD)	0	ENS	5156

Reaction No. 56166							
3CaO.Fe ₂ O ₃ .3SiO ₂ (s) + 12<H+1> = 3<Ca+2> + 2<Fe+3> + 3<H+1(2)_SiH ₂ O ₄ -2 >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:28.7 (3SF)	1	ELC	
2	25	0	CHEMVAL1	lgK:59.55 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:59.55 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:59.55 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:59.60 (0.01SD)	0	ENS	5156

Reaction No. 56167							
Ca+2_H+1_PO4-3_(s) = Ca+2 + H+1 + PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-18.93 (4SF)	2	CRV	9402
2	25	0	Inf. Dilution	lgK:-19.05 (4SF)	4	CRV	32224
3	25	0	CHEMVAL2	lgK:-19.05 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:-19.05 (0.01SD)	0	ENS	5156


5	25	0	CHEMVAL4	lgK:-19.10(0.01SD)	0	ENS	5156
6	25	0.1	Unknown	lgK:-12.57(4SF)	0	CRV	31724
7	25	0	Inf. Dilution	dH:4.50(3SF)	2	CRV	9402

Reaction No. 56168



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-19.0(3SF)	3	EOD	29070
2	25	0	Inf. Dilution	lgK:-18.91(4SF)	4	CRV	32224
3	25	0	CHEMVAL2	lgK:-18.93(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:-18.93(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:-18.90(0.01SD)	4	ENS	5156
6	25	0.1	Unknown	lgK:-17.48(4SF)	3	CRV	31724


Reaction No. 56169



Note: Presumably should mean $\text{Ca}+2(4)_ \text{H}+1_ \text{PO4}-3(3)_ \text{H2O}(3)_(\text{s})$


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL2	lgK:-40.26(0.01SD)	0	ENS	5156
2	25	0	CHEMVAL3	lgK:-40.26(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL4	lgK:-40.30(0.01SD)	0	ENS	5156

Reaction No. 56170



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:34.2(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:36.59(4SF)	4	CRV	32224
3	25	0	CHEMVAL1	lgK:33.71(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:33.71(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:33.71(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:33.60(0.01SD)	0	ENS	5156

Reaction No. 56171



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	4	0	Inf. Dilution	lgK:-48.3(0.2SD)	6	MSL	6473
2	4.8	0	Inf. Dilution	lgK:-48.3(0.2SD)	6	MSL	6473

3	6	0	Inf. Dilution	lgK:-48.2(3SF)	6	MSL	6473
4	18	0	Inf. Dilution	lgK:-48.3(3SF)	6	MSL	6473
5	20:25	0	Inf. Dilution	lgK:-47.63(4SF)	0	EOD	29438
Note (5): May refer to the hydrate Ca+2(4)_H+1_PO4-3(3)_H2O(3)_(s)							
6	23.5	0	Inf. Dilution	lgK:-48.4(0.1SD)	6	MSL	6473
7	25	0	Inf. Dilution	lgK:-46.90(4SF)	0	CRV	9402
8	25	0	Inf. Dilution	lgK:-47.1(3SF)	0	EOD	31694
Note (8): from Bjerrum, 1949							
9	25	0	Inf. Dilution	lgK:-48.3(3SF)	4	EOD	31761
Note (9): -96.6/2							
10	25	0	CHEMVAL2	lgK:-48.20(0.01SD)	0	ENS	5156
11	25	0	CHEMVAL3	lgK:-48.20(0.01SD)	0	ENS	5156
12	25	0	CHEMVAL4	lgK:-48.20(0.01SD)	4	ENS	5156
13	30	0	Inf. Dilution	lgK:-46.6(3SF)	0	MSL	27777
14	37	0	Inf. Dilution	lgK:-48.7(0.2SD)	6	MSL	6473
15	37	0	Inf. Dilution	lgK:-47.0(3SF)	0	MSL	27777
16	42	0	Inf. Dilution	lgK:-47.2(3SF)	0	MSL	27777


Reaction No. 56177							
Ca+2_Mg+2(3)_CO3-2(4)_(s) = Ca+2 + 3<Mg+2> + 4<CO3-2>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:-30.01(0.01SD)	0	ENS	5156
2	25	0	CHEMVAL2	lgK:-30.01(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:-30.01(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:-30.50(0.01SD)	4	ENS	5156

Reaction No. 56249							
Ca+2_UO2+2(2)_PO4-3(2)_H2O(7)_(s) = Ca+2 + 2<UO2+2> + 2<PO4-3> + 7<H2O >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL4	lgK:-48.20(0.01SD)	4	ENS	5156

Reaction No. 56251							
CaUO4(s) + 4<H+1> = Ca+2 + UO2+2 + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.0(3SF)	1	ELC	
2	25	0	CHEMVAL1	lgK:15.00(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:15.00(0.01SD)	0	ENS	5156


4	25	0	CHEMVAL3	lgK:15.00(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:15.00(0.01SD)	0	ENS	5156

Reaction No. 56255




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:-36.95(0.01SD)	0	ENS	5156
2	25	0	CHEMVAL2	lgK:-36.95(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:-36.95(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:-37.00(0.01SD)	4	ENS	5156

Reaction No. 56257



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:-37.86(0.01SD)	0	ENS	5156
2	25	0	CHEMVAL2	lgK:-37.86(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:-37.86(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:-37.90(0.01SD)	4	ENS	5156

Reaction No. 56287



Note: Ca+2(3)_PO4-3(2)_(alpha,s) is more soluble than beta form - see Refs.
 [11CaD_31722 & 08WaN_31723] Ca+2(3)_PO4-3(2)_(alpha,s) used here as surrogate for
 biol. ppt.

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-25.0(3SF)	2	CRV	22551
2	25	0	Inf. Dilution	lgK:-25.23(4SF)	3	MSL	31718
3	25	0	Inf. Dilution	lgK:-25.5(3SF)	4	CRV	31723
4	25	0	Inf. Dilution	lgK:-25.5(3SF)	4	EOD	31761
5	25	0	Inf. Dilution	lgK:-31.02(4SF)	0	CRV	32224
6	25	0	CHEMVAL2	lgK:-31.02(0.01SD)	0	ENS	5156
7	25	0	CHEMVAL3	lgK:-31.02(0.01SD)	0	ENS	5156
8	25	0	CHEMVAL4	lgK:-31.10(0.01SD)	0	ENS	5156
9	25	0.1	Unknown	lgK:-25.44(4SF)	0	CRV	31724
Note (9): Assume alpha-form (matches lgK approximately - but not well enough)							
10	37	0	Inf. Dilution	lgK:-28.5(3SF)	4	CRV	31723

Reaction No. 56288

Ca+2(5)_Cl-1_PO4-3(3)_(s) = 5<Ca+2> + 3<PO4-3> + Cl-1							
Note: Solid is v. odd; extremely supersat'd; seemingly no supporting evidence; concluded that no such reaction occurs in solution PMM (8/7/14)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL2	lgK:-66.15(0.01SD)	0	ENS	5156
2	25	0	CHEMVAL3	lgK:-66.15(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL4	lgK:-66.20(0.01SD)	0	ENS	5156

Reaction No. 56289							
Ca+2(5)_F-1_PO4-3(3)_(s) = 5<Ca+2> + 3<PO4-3> + F-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-60.0(3SF)	2	CRV	
Note (1): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
2	25	0	Inf. Dilution	lgK:-59.6(3SF)	2	EOD	31694
Note (2): from McCann, 1968							
3	25	0	Inf. Dilution	lgK:-60.0(3SF)	4	CRV	31723
Note (3): 120.0 / 2							
4	25	0	Inf. Dilution	lgK:-59.96(4SF)	5	MSL	31741
5	25	0	Inf. Dilution	lgK:-54.53(4SF)	0	CRV	32224
6	25	0	CHEMVAL2	lgK:-61.52(0.01SD)	0	ENS	5156
7	25	0	CHEMVAL3	lgK:-61.52(0.01SD)	0	ENS	5156
8	25	0	CHEMVAL4	lgK:-68.10(0.01SD)	0	ENS	5156
9	25	0.1	Unknown	lgK:-55.5(3SF)	3	CRV	31724
10	35	0	Inf. Dilution	lgK:-60.82(4SF)	5	MSL	31741
11	37	0	Inf. Dilution	lgK:-61.15(4SF)	4	CRV	31723
Note (11): 122.3 / 2							
12	45	0	Inf. Dilution	lgK:-61.10(4SF)	5	MSL	31741

Reaction No. 56290							
Ca+2(2)_Fe+2_PO4-3(2)_H2O(4)_(s) = 2<Ca+2> + Fe+2 + 2<PO4-3> + 4<H2O >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-34.14(4SF)	4	CRV	32224
2	25	0	CHEMVAL2	lgK:-34.14(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:-34.14(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:-34.10(0.01SD)	4	ENS	5156

Reaction No. 56297							
--------------------	--	--	--	--	--	--	--

U+4_Ca+2_PO4-3(2)_H2O(2)_(s) = U+4 + Ca+2 + 2<PO4-3> + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-54.1(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:-55.920(5SF)	2	CRV	31231
3	25	0	CHEMVAL2	lgK:-54.14(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:-54.14(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:-54.10(0.01SD)	1	ENS	5156

Reaction No. 56312							
Ca+2_I-1(2)_(s) = Ca+2 + 2<I-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.16(3SF)	0	CRV	
Note (1): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
2	25	0	Inf. Dilution	lgK:20.7(3SF)	0	ERG	
3	25	0	Inf. Dilution	lgK:22.52(4SF)	4	CRV	32224
4	25	0	CHEMVAL4	lgK:22.50(0.01SD)	1	ENS	5156

Reaction No. 56313							
Ca+2_NO3-1(2)_(s) = Ca+2 + 2<NO3-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.88(3SF)	4	CRV	32224
2	25	0	CHEMVAL4	lgK:5.89(0.01SD)	4	ENS	5156
3	25	1	Unknown	lgK:8.1(2SF)	1	EOR	

Reaction No. 56332							
Ca+2 + 4<NO3-1> + 36<H+1> + 32<e-1> = Ca+2_NH3(4) + 12<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:438.3(4SF)	1	ELC	
2	25	0	CHEMVAL4	lgK:437.00(0.01SD)	0	ENS	5156

Reaction No. 56416							
Ca+2 + 2<VO3-1> + 4<H2O> = Ca+2_VO3-1(2)_H2O(4)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	1	NaCl	lgK:4.10(0.02SD)	6	MSP	5147
2	22	3	NaCl	lgK:3.7(0.06SD)	5	MSP	5147
3	25	0	Inf. Dilution	lgK:5.39(3SF)	2	EAE	

Reaction No. 56417							
$3\text{Ca}^{2+} + 2\text{VO}_4^{3-} + 4\text{H}_2\text{O} = \text{Ca}_2(\text{VO}_4)_3 \cdot 2\text{H}_2\text{O} (\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	1	NaCl	lgK:17.5(0.07SD)	5	MSP	5147
2	22	3	NaCl	lgK:17.4(0.06SD)	5	MSP	5147
3	25	0	Inf. Dilution	lgK:23.0(3SF)	2	EAE	

Reaction No. 56418							
$2\text{Ca}^{2+} + \text{V}_2\text{O}_7^{4-} + 2\text{H}_2\text{O} = \text{Ca}_2(\text{VO}_7)_2 \cdot 2\text{H}_2\text{O} (\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	1	NaCl	lgK:7.24(0.01SD)	6	MSP	5147
2	22	3	NaCl	lgK:7.1(0.04SD)	6	MSP	5147
3	25	0	Inf. Dilution	lgK:11.7(3SF)	2	EAE	

Reaction No. 56419							
$\text{V}_{10}\text{O}_{28}^{6-} + 3\text{Ca}^{2+} = \text{Ca}_3(\text{V}_{10}\text{O}_{28})_6 (\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	1	Cl-1 salt	lgK:5.2(0.04SD)	6	MSL	5150
2	25	0	Inf. Dilution	lgK:12.3(3SF)	2	EAE	

Reaction No. 56421							
$\text{Ca}_2(\text{VO}_6)_2 (\text{s}) + 8\text{H}^+ = 6\text{VO}_2^{+} + \text{Ca}^{2+} + 4\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	1	Cl-1 salt	lgK:0.041(0.04SD)	7	MSL	5150
2	25	0	Inf. Dilution	lgK:-0.257(3SF)	2	EAE	

Reaction No. 56689							
$\text{Ca} (\text{s}) + 3\text{O}_2 (\text{g}) + 2\text{V} (\text{s}) = \text{Ca}_2\text{VO}_3 (\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:382.5(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:380.1(4SF)	0	ENS	6422
3	27	0	Inf. Dilution	lgK:377.6(4SF)	0	ENS	6422
4	127	0	Inf. Dilution	lgK:276.2(4SF)	0	ENS	6422
5	227	0	Inf. Dilution	lgK:215.4(4SF)	0	ENS	6422
6	327	0	Inf. Dilution	lgK:174.9(4SF)	0	ENS	6422
7	25	0	Inf. Dilution	dG:-518.6(0.05SD)	0	ENS	3006
8	25	0	Inf. Dilution	dG:-518.5(4SF)	0	EFE	6422

9	25	0	Inf. Dilution	dG:-518.6(4SF)	0	CRV	22971
10	25	0	Inf. Dilution	dH:-556.6(0.1SD)	0	ENS	3006
11	25	0	Inf. Dilution	dH:-556.7(4SF)	2	MTD	6422
12	25	0	Inf. Dilution	dH:-556.7(4SF)	2	CRV	22971
13	127	0	Inf. Dilution	dH:-566.4(4SF)	0	MTD	6422
14	227	0	Inf. Dilution	dH:-566.0(4SF)	0	MTD	6422
15	327	0	Inf. Dilution	dH:-555.5(4SF)	0	MTD	6422

Reaction No. 56690							
2<Ca(s)> + 2<V(s)> + 3.5<O2(g)> = Ca+2(2)_V2O7-4_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:506.9(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:503.5(4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:369.3(4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:288.9(4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:235.2(4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-691.0(0.1SD)	4	ENS	3006
7	25	0	Inf. Dilution	dG:-691.5(4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dG:-691.5(4SF)	5	CRV	22971
9	25	0	Inf. Dilution	dH:-737.0(0.2SD)	4	ENS	3006
10	25	0	Inf. Dilution	dH:-736.9(4SF)	4	MTD	6422
11	25	0	Inf. Dilution	dH:-736.9(4SF)	5	CRV	22971
12	127	0	Inf. Dilution	dH:-736.6(4SF)	1	MTD	6422
13	227	0	Inf. Dilution	dH:-736.2(4SF)	0	MTD	6422
14	327	0	Inf. Dilution	dH:-735.7(4SF)	0	MTD	6422

Reaction No. 56691							
3<Ca(s)> + 2<V(s)> + 4<O2(g)> = Ca+2(3)_VO4-3(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:623.9(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:619.8(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:455.4(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:356.8(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:291.0(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-851.0(0.1SD)	4	ENS	3006
7	25	0	Inf. Dilution	dG:-851.1(4SF)	4	EFE	6422

8	25	0	Inf. Dilution	dH:-903.0(0.1SD)	4	ENS	3006
9	25	0	Inf. Dilution	dH:-902.9(4SF)	4	MTD	6422
10	127	0	Inf. Dilution	dH:-902.6(4SF)	4	MTD	6422
11	227	0	Inf. Dilution	dH:-902.2(4SF)	4	MTD	6422
12	327	0	Inf. Dilution	dH:-901.8(4SF)	4	MTD	6422

Reaction No. 56759							
$3\text{Ca}^{2+} + 2\text{VO}_2 + 4\text{H}_2\text{O} = \text{Ca}_3\text{V}_2\text{O}_8(\text{s}) + 8\text{H}^+$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-38.96(0.01SD)	4	ENS	766
2	25	0	Inf. Dilution	dH:70.14(0.01SD)	4	ENS	766

Reaction No. 56760							
$\text{Ca}^{2+} + 2\text{VO}_2 + 2\text{H}_2\text{O} = \text{Ca}_2\text{V}_2\text{O}_7(\text{s}) + 4\text{H}^+$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-3.4(2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-5.66(0.01SD)	0	ENS	766
3	25	0	Inf. Dilution	dH:20.26(0.01SD)	3	ENS	766


Reaction No. 56761							
$2\text{Ca}^{2+} + 2\text{VO}_2 + 3\text{H}_2\text{O} = \text{Ca}_2\text{V}_2\text{O}_7(\text{s}) + 6\text{H}^+$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-17.5(0.1SD)	4	ENS	766
2	25	0	Inf. Dilution	dH:38.12(0.01SD)	4	ENS	766

Reaction No. 56772							
$\text{H}^+ + \text{V}_2\text{O}_3(\text{s}) + \text{Ca}^{2+} = \text{CaV}_2\text{O}_7(\text{s}) + 2\text{H}^+$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	0.01:0.5	HNO3	lgK:1.2(0.03SD)	6	MSL	5167
2	25	0	Inf. Dilution	lgK:1.46(3SF)	2	EAE	

Reaction No. 56773							
$\text{CaV}_2\text{O}_7(\text{s}) + 14\text{H}^+ = 12\text{VO}_2 + \text{Ca}^{2+} + 7\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	0.01:0.5	HNO3	lgK:-6.3(0.1SD)	0	MSL	5167
Note (1): Low wgt for internal consistency							
2	22	1	Cl-1 salt	lgK:-4.0(0.05SD)	0	MSL	5150


3	25	0	Inf. Dilution	lgK:-9.7 (2SF)	1	ELC	
---	----	---	---------------	----------------	---	-----	--

Reaction No. 57061



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:82.02 (4SF)	3	ENS	6422
2	27	0	Inf. Dilution	lgK:81.51 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:60.90 (4SF)	3	ENS	6422
4	227	0	Inf. Dilution	lgK:48.46 (4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:40.14 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-114.1 (0.1SD)	2	ENS	3006
7	25	0	Inf. Dilution	dG:-477.4 (4SF) kJ	2	CRV	6330
8	25	0	Inf. Dilution	dG:-111.9 (4SF)	3	EFE	6422
9	25	0	Inf. Dilution	dH:-115.3 (0.1SD)	3	ENS	3006
10	25	0	Inf. Dilution	dH:-482.4 (4SF) kJ	3	CRV	6330
11	25	0	Inf. Dilution	dH:-113.9 (4SF)	3	ENS	6422
12	27	0	Inf. Dilution	dH:-113.1 (4SF)	3	ENS	6422
13	127	0	Inf. Dilution	dH:-113.7 (4SF)	1	ENS	6422
14	227	0	Inf. Dilution	dH:-114.0 (4SF)	0	ENS	6422
15	327	0	Inf. Dilution	dH:-114.4 (4SF)	0	ENS	6422


Reaction No. 57157



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:0.82 (2SF)	3	EES	140
2	18	0	Inf. Dilution	lgK:0.89 (2SF)	4	MCN	140
3	25	0	Inf. Dilution	lgK:0.40 (2SF)	0	EBU	6372
4	25	0	UCT_Sea	lgK:0.89 (0.01SD)	4	EDH	5390
5	25	0.1	UCT_Sea	lgK:0.51 (0.01SD)	4	EDH	5390
6	25	0.2	UCT_Sea	lgK:0.43 (0.01SD)	4	EDH	5390
7	25	0.3	UCT_Sea	lgK:0.39 (0.01SD)	4	EDH	5390
8	25	0.4	UCT_Sea	lgK:0.36 (0.01SD)	4	EDH	5390
9	25	0.5	UCT_Sea	lgK:0.34 (0.01SD)	4	EDH	5390
10	25	0.6	UCT_Sea	lgK:0.33 (0.01SD)	4	EDH	5390
11	25	0.7	UCT_Sea	lgK:0.32 (0.01SD)	4	EDH	5390
12	25	1	NaClO4	lgK:0.5 (0.05SD)	6	MSE	5193


13	40	0	Inf. Dilution	lgK:0.94 (2SF)	3	EES	140
14	25	1	NaClO4	dG:-0.7 (0.07SD)	6	MSE	5193
15	25	1	NaClO4	dH:0.3 (0.07SD)	5	MCL	5193

Reaction No. 57159




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:-0.07 (0.06SD)	5	MSE	5193
2	25	1	NaClO4	dG:0.1 (0.08SD)	4	MSE	5193
3	25	1	NaClO4	dH:-0.3 (0.1SD)	5	MCL	5193

Reaction No. 57161




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:-0.5 (0.1SD)	5	MSE	5193
2	25	1	NaClO4	dG:0.7 (0.2SD)	4	MSE	5193
3	25	1	NaClO4	dH:-0.5 (0.1SD)	5	MCL	5193

Reaction No. 57613



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-90.1 (3SF)	2	EAE	
2	35	0	Inf. Dilution	lgK:-90.4 (0.05SD)	6	MSL	5330
3	40	0	Inf. Dilution	lgK:-90.6 (0.05SD)	6	MSL	5330
4	45	0	Inf. Dilution	lgK:-90.7 (0.05SD)	6	MSL	5330
5	50	0	Inf. Dilution	lgK:-90.9 (0.05SD)	6	MSL	5330


Reaction No. 57641



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	5.8	ClO4-1 salt	lgK:-0.28 (0.02SD)	5	MRM	5374
2	25	5.8	Unknown	lgK:0.52 (2SF)	0	MSP	2261

Note (2): In error - value not logged


Reaction No. 57685



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0	Inf. Dilution	lgK:-3.09(0.02SD)	4	MSL	140
2	25	0	Inf. Dilution	lgK:-4.40(3SF)	0	ENS	773
3	25	0	Inf. Dilution	lgK:-3.09(3SF)	3	EOD	32222
4	25	0	Inf. Dilution	dG:4.77(3SF)	4	ENS	12931
5	25	0	Inf. Dilution	dH:-1.95(0.02SD)	4	MSL	140
6	25	0	Inf. Dilution	dH:-7.109(1.013SD)kJ	3	EOD	32222


Reaction No. 57720



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	5.8	ClO4-1 salt	lgK:-0.74(0.02SD)	5	MRM	5374
2	25	5.8	Unknown	lgK:0.18(2SF)	0	MSP	2261

Note (2): In error - value not logged


Reaction No. 57961



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:105.7(4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:105.7(4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:105.0(4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:105.0(4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:77.409(5SF)	3	ENS	6422
6	127	0	Inf. Dilution	lgK:77.33(4SF)	4	ENS	6494
7	227	0	Inf. Dilution	lgK:60.84(4SF)	3	ENS	6422
8	227	0	Inf. Dilution	lgK:60.76(4SF)	3	ENS	6494
9	327	0	Inf. Dilution	lgK:49.80(4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:49.72(4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-603.3(4SF)kJ	5	CRV	6330
12	25	0	Inf. Dilution	dG:-144.2(4SF)	4	ENS	6422
13	25	0	Inf. Dilution	dG:-144.20(5SF)	4	EFE	6482
14	25	0	Inf. Dilution	dG:-144.1(4SF)	3	EFE	6494
15	25	0	Inf. Dilution	dG:-604.03(5SF)kJ	1	EFE	7275
16	25	0	Inf. Dilution	dG:-603.3(4SF)kJ	6	CRV	8746
17	25	0	Inf. Dilution	dG:-603.30(0.916SD)kJ	6	CRV	14923
18	25	0	Inf. Dilution	dG:-604.0(4SF)kJ	1	EOD	23101
19	25	0	Inf. Dilution	dG:-603.30(5SF)kJ	5	EOD	29520


20	25	0	Inf. Dilution	dG:-144.23 (5SF)	3	CRV	31291
21	25	0	Inf. Dilution	dG:-604.03 (5SF) kJ	5	CRV	31308
22	25	0	Inf. Dilution	dH:-151.8 (0.2SD)	7	CRV	5605
23	25	0	Inf. Dilution	dH:-634.9 (4SF) kJ	5	CRV	6330
24	25	0	Inf. Dilution	dH:-151.8 (4SF)	4	MTD	6422
25	25	0	Inf. Dilution	dH:-151.6 (4SF)	3	ENS	6437
26	25	0	Inf. Dilution	dH:-151.79 (5SF)	4	EFE	6482
27	25	0	Inf. Dilution	dH:-151.8 (4SF)	4	MTD	6494
28	25	0	Inf. Dilution	dH:-635.09 (5SF) kJ	3	EFE	7275
29	25	0	Inf. Dilution	dH:-634.92 (0.90MD) kJ	6	CRV	8746
30	25	0	Inf. Dilution	dH:-634.92 (0.900SD) kJ	6	CRV	14923
31	25	0	Inf. Dilution	dH:-635. (3SF) kJ	3	EOD	23101
32	25	0	Inf. Dilution	dH:-634.92 (5SF) kJ	5	EOD	29520
33	25	0	Inf. Dilution	dH:-151.79 (5SF)	3	CRV	31291
34	25	0	Inf. Dilution	dH:-635. (3SF) kJ	5	CRV	31308
35	127	0	Inf. Dilution	dH:-151.7 (4SF)	4	MTD	6422
36	127	0	Inf. Dilution	dH:-151.7 (4SF)	4	MTD	6494
37	227	0	Inf. Dilution	dH:-151.6 (4SF)	3	MTD	6422
38	227	0	Inf. Dilution	dH:-151.6 (4SF)	3	MTD	6494
39	327	0	Inf. Dilution	dH:-151.4 (4SF)	0	MTD	6422
40	327	0	Inf. Dilution	dH:-151.5 (4SF)	0	MTD	6494
41	25	0	Inf. Dilution	Cp:42.049 (0.2SD) J/K	5	CRV	27292

Reaction No. 57969



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-7. (1SF)	1	EES	
2	100	0	Inf. Dilution	lgK:-6.27 (3SF)	4	MSL	24807


Reaction No. 57999



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:144.0 (4SF) kJ	5	CRV	6330
2	25	0	Inf. Dilution	dG:144.3 (4SF) kJ	3	EFE	7275
3	25	0	Inf. Dilution	dG:144.0 (4SF) kJ	6	CRV	8746
4	25	0	Inf. Dilution	dG:144.02 (0.809SD) kJ	6	CRV	14923


5	25	0	Inf. Dilution	dH:42.5(0.2SD)	7	CRV	5605
6	25	0	Inf. Dilution	dH:177.8(4SF)kJ	5	CRV	6330
7	25	0	Inf. Dilution	dH:178.2(4SF)kJ	3	EFE	7275
8	25	0	Inf. Dilution	dH:177.8(0.8MD)kJ	6	CRV	8746
9	25	0	Inf. Dilution	dH:177.80(0.800SD)kJ	6	CRV	14923
10	25	0	Inf. Dilution	Cp:20.786(0.001SD)J/K	5	CRV	27292

Reaction No. 58067




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:4.18(0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:3.40(0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:3.25(0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:3.16(0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:3.11(0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:3.07(0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:3.04(0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:3.02(0.01SD)	4	EDH	5390

Reaction No. 58082



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0	Inf. Dilution	lgK:-78.77(4SF)	3	ENS	
Note (1): http://www.fipr.state.fl.us/fipr100.htm							
2	25	0	Inf. Dilution	lgK:-78.8(3SF)	2	EAE	

Reaction No. 58170



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:2.78(0.07SD)	5	MGL	1275
2	25	0.1	KNO3	lgK:2.85(0.07SD)	5	MGL	1275
3	35	0.1	KNO3	lgK:2.94(0.07SD)	5	MGL	1275
4	45	0.1	KNO3	lgK:3.01(0.07SD)	5	MGL	1275
5	25	0.1	KNO3	dH:13.6(3SF)kJ	5	MTD	1275

Reaction No. 58334

N2H4 + Ca+2 = Ca+2_N2H4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.8	Ca(NO3)2	lgK:-0.16(2SF)	4	MDS	140

Reaction No. 58335							
Ca+2_N2H4 + N2H4 = Ca+2_N2H4(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.8	Ca(NO3)2	lgK:-0.64(2SF)	4	MDS	140

Reaction No. 58336							
Ca+2_N2H4(2) + N2H4 = Ca+2_N2H4(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.8	Ca(NO3)2	lgK:-1.11(3SF)	4	MDS	140

Reaction No. 58602							
PhosCreatine-3 + Ca+2 = Ca+2_PhosCreatine-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	Pr4NCl	lgK:1.146(4SF)	4	MGL	257

Reaction No. 58683							
Hex16DiPhos-4 + Ca+2 = Ca+2_Hex16DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.(1SF)	3	MGL	931


Reaction No. 58851							
[14]N2O3:MeCOO*2-2 + 2<Ca+2> = Ca+2(2)_[14]N2O3:MeCOO*2-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:9.9(0.2SD)	5	MGL	1176

Reaction No. 58863							
2<DTPA-5> + Ca+2 = Ca+2_DTPA-5(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:12.34(4SF)	5	MGL	189
2	37	0.15	NaCl	lgK:11.95(0.008SD)	5	MGL	1940

Reaction No. 58903							
CaO(s) + 2<H+1> + 2<e-1> = Ca(s) + H2O							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:-64.2 (3SF)	1	ERG	
2	25	0	Inf. Dilution	E:-1.902 (4SF)	1	MEF	778

Reaction No. 58904




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:41.5 (3SF)	2	EOR	
2	25	3	Inert	lgK:40.5 (3SF)	1	EOR	
3	100	0	Inf. Dilution	lgK:32.2 (3SF)	1	EOR	
4	25	0	Inf. Dilution	E:1.260 (4SF)	0	MEF	778

Reaction No. 58905




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:51.4 (3SF)	1	ELC	
2	25	0	Inf. Dilution	E:1.547 (4SF)	0	MEF	778

Reaction No. 58906



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	Inert	lgK:-103.7 (4SF)	1	EOR	
2	25	0	Inf. Dilution	E:-2.906 (4SF)	4	MEF	778
3	25	0	Inf. Dilution	E:-2.902 (4SF)	5	CRV	7761
4	25	0	Inf. Dilution	dH:533.5 (4SF) kJ	5	CRV	7761

Reaction No. 58907



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-74.2 (3SF)	1	ELC	
2	25	0	Inf. Dilution	E:-2.189 (4SF)	0	MEF	778

Reaction No. 58908



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-102.2 (4SF)	1	ELC	
2	25	0	Inf. Dilution	E:-3.02 (3SF)	0	MEF	778
3	25	0	Inf. Dilution	E:-3.02 (3SF)	0	CRV	6330

4	25	0	Inf. Dilution	E:-3.022 (4SF)	0	CRV	7761
5	25	0	Inf. Dilution	E:-3.02 (3SF)	0	CRV	22519
6	25	0	Inf. Dilution	E:-3.026 (4SF)	0	CRV	22551
7	25	0	Inf. Dilution	dH:526.1 (4SF) kJ	2	CRV	7761

Reaction No. 58916							
SCN-1 + Ca+2 = Ca+2_SCN-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO4	lgK:-1. (1SF)	3	EES	

Reaction No. 59146							
[15]O5 + Ca+2 = Ca+2_[15]O5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	lgK:0.0 (1SF)	3	MPP	5757
2	25	0.1	Acetone Unknown	lgK:4.01 (0.05SD)	6	CIU	13297
3	25		Acetone	lgK:4.01 (3SF)	3	MCL	3005
4	25	0.1	Acetone Unknown	dH:-35. (1.SD) kJ	6	CIU	13297
5	25		Acetone	dH:-35.2 (3SF) kJ	3	MCL	3005
6	25	0.1	Methanol Many Media	lgK:2.21 (0.16SD)	7	CIU	13297
7	25		Methanol	lgK:2.36 (3SF)	3	MGL	2924
8	25		Methanol	lgK:2.18 (0.02SD)	5	MCL	2944
9	25	0.1	Methanol Many Media	dH:-7.7 (2.SD) kJ	7	CIU	13297
10	25		Methanol	dH:-1.45 (0.14SD)	5	MCL	2944

Reaction No. 59203							
2SHSuccin-3 + Ca+2 = Ca+2_2SHSuccin-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	KNO3	lgK:2.84 (3SF)	4	MGL	3549
2	37	0.15	KNO3	lgK:2.79 (3SF)	4	MGL	3549

Reaction No. 59316							
Cys-2 + Ca+2 + PO4-3 = Ca+2_Cys-2_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.0 (3SF)	1	EES	
Note (1): Minimum value given m+lh+x = 8.5 from [3180] Ramamoorthy & Manning							

2	25	0.1	NaClO4	lgK:8.49(3SF)	0	CRV	905
Note (2): NDP error							

Reaction No. 59320							
Ca+2 + PO4-3 + Citric-3 = Ca+2_Citric-3_PO4-3							
Note: Rxn is problematic. This is a (rather pathetic) compromise between Ca+2 + Citric-3 + H+1_PO4-3 = Ca+2_H+1_Citric-3_PO4-3 (Rxn 59,332) as measured by R&M and my opinion that their value is too high.							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.7(3SF)	1	EES	
Note (1): Min value given m.lh.x = 10.7 from [3180] Ramamoorthy & Manning							
2	37	0.1	KCl	lgK:8.3(0.8SD)	2	MGL	32047

Reaction No. 59332							
Ca+2 + Citric-3 + H+1_PO4-3 = Ca+2_H+1_Citric-3_PO4-3							
Note: This reaction is particularly difficult. B120 for citrate is uncertain but probably around lgK=5.8 B120 for phosphate is unavailable (either as L-3 or L-2); prob. insol. so it cannot be estimated in the usual way B110 for citrate has lgK = 4.8 B110 for hydrogen phosphate has lgK = 2.6 The above data suggest that this rxn will be rather weak; lgK < 8 (unless there is a remarkable synergistic effect). The choice is thus between a measurement by often-unreliable researchers (Ramamoorthy and Manning) and the above tenuous estimate. Sticking with R&M for the time being (15/9/19).							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.0(3SF)	1	EES	
2	25	0.1	NaClO4	lgK:10.72(4SF)	2	MGL	3180


Reaction No. 59333							
Ca+2 + NTA-3 + H+1_PO4-3 = Ca+2_H+1_NTA-3_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.(2SF)	1	EES	
2	25	0.1	NaClO4	lgK:14.50(4SF)	2	MGL	3180

Reaction No. 59334							
Ca+2 + Cys-2 + H+1_PO4-3 = Ca+2_H+1_Cys-2_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.0(2SF)	2	EES	
2	25	0.1	NaClO4	lgK:8.49(3SF)	2	MGL	3180

Reaction No. 59673							
Ca+2 + H+1(2)_5ATP-4 = Ca+2_H+1(2)_5ATP-4							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Pr4N+ salt	lgK:2.0 (2SF)	4	MGL	1437
2	10	0.04	Pr4N+ salt	lgK:1.4 (2SF)	4	MGL	1437
3	10	0.16	Pr4N+ salt	lgK:1.3 (2SF)	4	MGL	1437
4	10	0.25	Pr4N+ salt	lgK:1.3 (2SF)	4	MGL	1437
5	10	0.49	Pr4N+ salt	lgK:1.3 (2SF)	4	MGL	1437
6	10	1	Pr4N+ salt	lgK:1.4 (2SF)	4	MGL	1437
7	25	0	Pr4N+ salt	lgK:1.6 (2SF)	4	MGL	1437
8	25	0.04	Pr4N+ salt	lgK:1.1 (2SF)	4	MGL	1437
9	25	0.16	Pr4N+ salt	lgK:0.9 (1SF)	4	MGL	1437
10	25	0.2	Pr4NC1	lgK:1.71 (3SF)	4	MGL	257
11	25	0.25	Pr4N+ salt	lgK:0.9 (1SF)	4	MGL	1437
12	25	0.49	Pr4N+ salt	lgK:0.9 (1SF)	4	MGL	1437
13	25	0.5	Na+1 salt	lgK:1.54 (3SF)	4	MGL	956
14	25	1	Pr4N+ salt	lgK:1.1 (2SF)	4	MGL	1437
15	35	0	Pr4N+ salt	lgK:1.6 (2SF)	4	MGL	1437
16	35	0.04	Pr4N+ salt	lgK:1.1 (2SF)	4	MGL	1437
17	35	0.16	Pr4N+ salt	lgK:0.9 (1SF)	4	MGL	1437
18	35	0.25	Pr4N+ salt	lgK:0.9 (1SF)	4	MGL	1437
19	35	0.49	Pr4N+ salt	lgK:1.0 (2SF)	4	MGL	1437
20	35	1	Pr4N+ salt	lgK:1.3 (2SF)	4	MGL	1437
21	45	0	Pr4N+ salt	lgK:1.9 (2SF)	4	MGL	1437
22	45	0.04	Pr4N+ salt	lgK:1.4 (2SF)	4	MGL	1437
23	45	0.16	Pr4N+ salt	lgK:1.2 (2SF)	4	MGL	1437
24	45	0.25	Pr4N+ salt	lgK:1.2 (2SF)	4	MGL	1437
25	45	0.49	Pr4N+ salt	lgK:1.3 (2SF)	4	MGL	1437
26	45	1	Pr4N+ salt	lgK:1.6 (2SF)	4	MGL	1437

Reaction No. 59674



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.0 (2SF)	4	MGL	1437


Reaction No. 59677



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	30	0.2	Me4NBr	lgK:-9.31 (3SF)	4	MCL	1971
---	----	-----	--------	-----------------	---	-----	------

Reaction No. 59678



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Na+1 salt	lgK:2.47 (3SF)	4	MIS	1437
2	25	0	Na+1 salt	lgK:2.24 (3SF)	4	MIS	1437


Reaction No. 59735



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.66 (3SF)	0	MSL	140


Note (1): Appears to be in error. Probably m2l/ml.m

Reaction No. 59985




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.338 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-2.60 (3SF)	0	CRV	9402

Reaction No. 59986




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.6285 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-1.50 (3SF)	0	CRV	9402

Reaction No. 60220



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7 (3SF)	2	EAE	
2	35	0.1	KNO3	lgK:12.13 (4SF)	3	CRV	5406

Reaction No. 60260



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Unknown	lgK:-9.4 (2SF)	4	ENS	6325

Reaction No. 60261

Ca+2(2)_V207-4_(s) + 2<H+1> + H2O = 2<Ca+2> + 2<H+1(2)_VO4-3>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.7(2SF)	1	ELC	
2	25	0	Unknown	lgK:2.7(2SF)	0	ENS	6325

Reaction No. 60262							
Ca+2(3)_VO4-3(2)_(s) + 4<H+1> = 3<Ca+2> + 2<H+1(2)_VO4-3>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:26.0(3SF)	1	ELC	
2	25	0	Unknown	lgK:24.2(3SF)	0	ENS	6325


Reaction No. 60324							
Ca+2_S-2_(s) + 2<H+1> = Ca+2 + H+1(2)_S-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.2(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:18.2(3SF)	0	CRV	2556

Reaction No. 60635							
Ca+2_H+1_PO4-3_(s) = Ca+2 + H+1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-7.00(3SF)	1	CRV	
Note (1): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
2	25	0	Inf. Dilution	lgK:-6.90(3SF)	4	CRV	2556
3	25	0	Inf. Dilution	lgK:-5.3(2SF)	0	CRV	22551
4	25	0	Inf. Dilution	lgK:-6.90(3SF)	4	CRV	31723
5	25	0	Inf. Dilution	lgK:-6.90(3SF)	4	EOD	31761
6	25	3	Inert	lgK:-8.1(2SF)	1	EOR	
7	37	0	Inf. Dilution	lgK:-7.04(3SF)	3	CRV	2556
8	37	0	Inf. Dilution	lgK:-6.04(3SF)	0	CRV	31723
Note (8): Typo (corrected in 11CaD_31722)							
9	37	0	Inf. Dilution	lgK:-7.04(3SF)	3	CRV	31723
Note (9): As corrected in 11CaD_31722							
10	10:40	0	Inf. Dilution	dH:4.(1SF)	4	CRV	2556

Reaction No. 60636							
Ca+2 + H+1_CO3-2 = Ca+2_CO3-2_(Arag.,s) + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0	Inf. Dilution	lgK:-2.0 (2SF)	1	EES	
---	----	---	---------------	----------------	---	-----	--


Reaction No. 60637



Note: This solid is (all but) Hydroxyapatite. Ref. (Crit. Stab.) checked.


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-58.33 (4SF)	4	CRV	2556
2	37	0	Inf. Dilution	lgK:-58.63 (4SF)	4	CRV	2556

Reaction No. 60768




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.7 (2SF)	1	EOR	
2	25	3	(Na)ClO4	lgK:10.17 (4SF)	3	MSL	6214

Reaction No. 60778



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8 (3SF)	1	ELC	
2	50	3	NaClO4/m	lgK:10.36 (0.03SD)	6	MSL	6218

Reaction No. 60779




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-251.9 (4SF)	3	EFE	336
2	25	0	Inf. Dilution	dG:-249.8 (4SF)	5	EFE	6218
3	25	0	Inf. Dilution	dG:-249.4 (4SF)	5	EFE	6347
4	25	0	Inf. Dilution	dG:-1048.9 (6.4SD) kJ	5	MEF	6659
5	25	0	Inf. Dilution	dG:-1052. (4SF) kJ	5	CRV	8739
6	25	0	GAMSPATH	dG:-1128.8 (5SF) kJ	0	CRV	12638

Note (6): Low wgt for internal consistency

7	25	0	Inf. Dilution	dH:-1133.20 (6SF) kJ	5	CRV	8739
8	25	0	GAMSPATH	dH:-1132.40 (6SF) kJ	3	CRV	12638


Reaction No. 60785



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0	Inf. Dilution	lgK:1.31 (3SF)	4	MGL	4503
2	25	0.03	NaCl	lgK:1.27 (3SF)	4	MIS	4503
3	25	0.045	NaCl	lgK:1.21 (3SF)	4	MIS	4503
4	25	0.3	NaCl	lgK:0.38 (2SF)	4	MIS	4503
5	25	0.45	NaCl	lgK:0.362 (3SF)	4	MIS	4503
6	35	0	Inf. Dilution	lgK:1.34 (3SF)	4	MGL	4503
7	35	0.03	NaCl	lgK:1.30 (3SF)	4	MIS	4503
8	35	0.045	NaCl	lgK:1.24 (3SF)	4	MIS	4503
9	35	0.3	NaCl	lgK:0.436 (3SF)	4	MIS	4503
10	35	0.45	NaCl	lgK:0.373 (3SF)	4	MIS	4503
11	45	0	Inf. Dilution	lgK:1.36 (3SF)	4	MGL	4503
12	45	0.03	NaCl	lgK:1.33 (3SF)	4	MIS	4503
13	45	0.045	NaCl	lgK:1.25 (3SF)	4	MIS	4503
14	45	0.3	NaCl	lgK:0.487 (3SF)	4	MIS	4503
15	45	0.45	NaCl	lgK:0.398 (3SF)	4	MIS	4503
16	25:45	0	Inf. Dilution	dH:-0.518 (3SF)	4	MTD	4503

Reaction No. 60786



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.15 (3SF)	4	MGL	4503
2	25	0.03	NaCl	lgK:1.057 (4SF)	4	MIS	4503
3	25	0.045	NaCl	lgK:1.01 (3SF)	4	MIS	4503
4	25	0.3	NaCl	lgK:0.398 (3SF)	4	MIS	4503
5	25	0.45	NaCl	lgK:0.342 (3SF)	4	MIS	4503
6	35	0	Inf. Dilution	lgK:1.17 (3SF)	4	MGL	4503
7	35	0.03	NaCl	lgK:1.08 (3SF)	4	MIS	4503
8	35	0.045	NaCl	lgK:1.02 (3SF)	4	MIS	4503
9	35	0.3	NaCl	lgK:0.415 (3SF)	4	MIS	4503
10	35	0.45	NaCl	lgK:0.369 (3SF)	4	MIS	4503
11	45	0	Inf. Dilution	lgK:1.20 (3SF)	4	MGL	4503
12	45	0.03	NaCl	lgK:1.11 (3SF)	4	MIS	4503
13	45	0.045	NaCl	lgK:1.05 (3SF)	4	MIS	4503
14	45	0.3	NaCl	lgK:0.449 (3SF)	4	MIS	4503
15	45	0.45	NaCl	lgK:0.389 (3SF)	4	MIS	4503
16	25:45	0	Inf. Dilution	dH:-0.45 (2SF)	4	MTD	4503

Reaction No. 61395							
Ca+2 + H+1_Gly-1 = Ca+2_H+1_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:0.30 (2SF)	6	CRV	552
2	37	0.15	Unknown	lgK:0.45 (2SF)	6	CRV	552
3	25	0	Inf. Dilution	dH:2. (1SF)	3	CRV	552

Reaction No. 61568							
Ca+2 + H+1_Lys-1 = Ca+2_H+1_Lys-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.7	KCl	lgK:0.72 (2SF)	3	MGL	6000
2	37	0.7	KCl	lgK:0.72 (2SF)	3	MGL	6000

Reaction No. 61621							
Ca+2 + H+1_Ala-1 = Ca+2_H+1_Ala-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.35 (2SF)	5	CRV	552
2	25	0	Inf. Dilution	dH:2. (1SF)	3	CRV	552
3	25	0	Inf. Dilution	dH:6. (2.MD) kJ	4	MTD	6123


Reaction No. 61705							
Ca+2 + H+1_Glu-2 = Ca+2_H+1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.17 (3SF)	4	CRV	552
2	37	0.15	Unknown	lgK:1.20 (3SF)	6	CRV	552

Reaction No. 61712							
Ca+2_PO4Ser-3 + H+1 = Ca+2_H+1_PO4Ser-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:8.93 (3SF)	6	CRV	552
2	37	0.15	Unknown	lgK:9.0 (2SF)	6	CRV	552

Reaction No. 61786							
Ca+2 + H+1_Asp-2 = Ca+2_H+1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.0 (2SF)	1	EES	


2	37	0.15	Unknown	lgK:1.2(0.04SD)	1	CRV	552
---	----	------	---------	-----------------	---	-----	-----

Reaction No. 62047




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Unknown	lgK:7.13(3SF)	6	CRV	552

Reaction No. 62048




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Unknown	lgK:7.9(2SF)	6	CRV	552

Reaction No. 62054




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Unknown	lgK:7.95(3SF)	6	CRV	552

Reaction No. 62055




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Unknown	lgK:8.0(2SF)	4	CRV	552

Reaction No. 62109




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.87(0.02SD)	5	MGL	6861
2	25	0.1	Unknown	lgK:5.87(3SF)	6	CRV	552

Reaction No. 62110



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:8.(0.6SD)	6	CRV	552

Reaction No. 62322



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:8.69(3SF)	6	CRV	552

Reaction No. 62323							
Ca+2_H+1_HBED-4 + H+1 = Ca+2_H+1(2)_HBED-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:7.50 (3SF)	6	CRV	552

Reaction No. 62385							
Ca+2_ICRF198-2 + H+1 = Ca+2_H+1_ICRF198-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.8 (2SF)	1	ESC	
2	37	0.15	Unknown	lgK:2.80 (3SF)	6	CRV	552

Reaction No. 62424							
Ca+2_[14]N2O3:MeCOO*2-2 + Ca+2 = Ca+2(2)_[14]N2O3:MeCOO*2-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:1.2 (2SF)	6	CRV	552

Reaction No. 62440							
Ca+2_[12]N3O:Acet*3-3 + H+1 = Ca+2_H+1_[12]N3O:Acet*3-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:3.93 (3SF)	6	CRV	552

Reaction No. 62452							
Ca+2_H+1_[12]N4:Acet*4-4 + H+1 = Ca+2_H+1(2)_[12]N4:Acet*4-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:4.18 (3SF)	4	CRV	552

Reaction No. 62525							
CarbMeAsp-3 + Ca+2 = Ca+2_CarbMeAsp-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:3.71 (3SF)	6	CRV	552

Reaction No. 62560							
IDS-4 + Ca+2 = Ca+2_IDS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.01 (3SF)	3	CRV	29666
2	25	0.1	Unknown	lgK:4.42 (3SF)	4	CRV	552
3	25	0.1	Unknown	lgK:5.09 (0.02SD)	3	ENS	7168

Reaction No. 62599							
NEtIDA-2 + Ca+2 = Ca+2_NEtIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.92 (3SF)	4	CRV	552

Reaction No. 62603							
2<NPrIDA-2> + Ca+2 = Ca+2_NPrIDA-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:5.4 (2SF)	6	CRV	552

Reaction No. 62609							
N2PrIDA-2 + Ca+2 = Ca+2_N2PrIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.77 (3SF)	4	CRV	552

Reaction No. 62611							
NBuIDA-2 + Ca+2 = Ca+2_NBuIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.01 (3SF)	4	CRV	552

Reaction No. 62612							
2<NBuIDA-2> + Ca+2 = Ca+2_NBuIDA-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.77 (3SF)	4	CRV	552


Reaction No. 62615							
2<tBuIDA-2> + Ca+2 = Ca+2_tBuIDA-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.91 (3SF)	4	CRV	552

Reaction No. 62626							
2<[Hex]IDA-2> + Ca+2 = Ca+2_[Hex]IDA-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.49 (3SF)	3	CRV	552

Reaction No. 62629							
NallylIDA-2 + Ca+2 = Ca+2_NallylIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0.1	Unknown	lgK:3.4 (2SF)	6	CRV	552
---	----	-----	---------	---------------	---	-----	-----

Reaction No. 62630




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:5.3 (2SF)	6	CRV	552

Reaction No. 62634




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:3.2 (0.04SD)	6	CRV	552
2	30	0.1	KCl	lgK:3.3 (0.07SD)	5	MGL	2086

Reaction No. 62835




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	K+1 salt	lgK:6.47 (3SF)	6	CRV	552

Reaction No. 62865




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:7.10 (3SF)	6	CRV	552

Reaction No. 62870




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:6.01 (3SF)	6	CRV	552

Reaction No. 62874



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	K+1 salt	lgK:6.74 (3SF)	6	CRV	552

Reaction No. 62875



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	K+1 salt	lgK:8.06 (3SF)	6	CRV	552

Reaction No. 63054							
$\text{N2PrAmidoIDA-2} + \text{Ca}^{+2} = \text{Ca}^{+2}\text{N2PrAmidoIDA-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:3.93(3SF)	6	CRV	552
2	25	0.1	Unknown	lgK:3.91(3SF)	6	CRV	552
3	10:40	0.1	Unknown	dH:-2.(1SF)	6	CRV	552

Reaction No. 63071							
$2<\text{UramilIDA-3}> + \text{Ca}^{+2} = \text{Ca}^{+2}\text{UramilIDA-3}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:13.58(4SF)	6	CRV	552
2	25	0.1	Me4N+ salt	lgK:13.90(4SF)	6	CRV	552

Reaction No. 63089							
$\text{Ca}^{+2}\text{N2SHetIDA-2} + \text{H}^{+1} = \text{Ca}^{+2}\text{H}^{+1}\text{N2SHetIDA-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:8.68(3SF)	6	CRV	552

Reaction No. 65551							
$\text{I-1} + \text{Ca}^{+2} = \text{Ca}^{+2}\text{I-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-3.(1SF)	1	EES	
2	25	0	Inf. Dilution	lgK:0.14(2SF)	0	EBU	6372

Reaction No. 65552							
$2<\text{I-1}> + \text{Ca}^{+2} = \text{Ca}^{+2}\text{I-1}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.02(1SF)	0	EBU	6372

Reaction No. 65553							
$3<\text{I-1}> + \text{Ca}^{+2} = \text{Ca}^{+2}\text{I-1}(3)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.37(2SF)	0	EBU	6372

Reaction No. 65554							
$4<\text{I-1}> + \text{Ca}^{+2} = \text{Ca}^{+2}\text{I-1}(4)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0	Inf. Dilution	lgK:-0.84 (2SF)	0	EBU	6372
---	----	---	---------------	-----------------	---	-----	------

Reaction No. 65555							
5<I-1> + Ca+2 = Ca+2_I-1 (5)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.43 (3SF)	0	EBU	6372

Reaction No. 65556							
6<I-1> + Ca+2 = Ca+2_I-1 (6)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.09 (3SF)	0	EBU	6372

Reaction No. 65557							
2<IO3-1> + Ca+2 = Ca+2_IO3-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.32 (2SF)	0	EBU	6372


Reaction No. 65558							
3<IO3-1> + Ca+2 = Ca+2_IO3-1 (3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.93 (3SF)	0	EBU	6372

Reaction No. 65559							
4<IO3-1> + Ca+2 = Ca+2_IO3-1 (4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-4.30 (3SF)	0	EBU	6372

Reaction No. 65642							
Ca+2_MoO4-2_(s) = Ca+2 + MoO4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-8.0 (2SF)	3	CRV	552
2	25	0	Inf. Dilution	lgK:-8.50 (3SF)	4	CRV	28992
3	25	0	Inf. Dilution	lgK:-8. (1SF)	4	EOD	30708
4	25	0	Inf. Dilution	lgK:-7.95 (0.025SD)	4	CRV	31301
5	25	0	Inf. Dilution	lgK:-8.71 (3SF)	4	CRV	32224
6	50	0	Inf. Dilution	lgK:-8.56 (3SF)	4	CRV	28992
7	100	0	Inf. Dilution	lgK:-8.97 (3SF)	3	CRV	28992


8	150	0	Inf. Dilution	lgK:-9.81(3SF)	3	CRV	28992
9	200	0	Inf. Dilution	lgK:-10.88(4SF)	2	CRV	28992
10	25	0	Inf. Dilution	dH:-0.7(1SF)	4	CRV	552

Reaction No. 65672




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.8(0.04SD)	0	CRV	552
2	25	0.7	Unknown	lgK:1.1(0.03SD)	0	CRV	552
3	25	3	NaClO ₄	lgK:0.99(2SF)	0	CRV	552
4	10:50	0	Inf. Dilution	dH:1.(1SF)	0	CRV	552

Reaction No. 65824




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.6(3SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:11.9(3SF)	3	CRV	552
3	25	3	Inert	lgK:13.4(3SF)	1	EOR	
4	100	0	Inf. Dilution	lgK:9.9(2SF)	1	EOR	

Reaction No. 65848




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.5(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:11.7(3SF)	0	CRV	552

Reaction No. 65863



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me ₄ N ⁺ salt	lgK:9.(0.3SD)	6	CRV	552

Reaction No. 65881



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.0(0.08SD)	4	CRV	552

Reaction No. 65991

Ca+2_I03-1(2)_(s) = Ca+2 + 2<I03-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-6.15(3SF)	1	CRV	
Note (1): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
2	25	0	Inf. Dilution	lgK:-6.15(0.02SD)	4	CRV	552
3	25	0	Inf. Dilution	lgK:-6.00(3SF)	4	MGL	5055
4	25	0	Inf. Dilution	lgK:-5.19(3SF)	3	CRV	6330
Note (4): p. 8-58							
5	25	0	Inf. Dilution	lgK:-6.12(3SF)	5	MSL	6836
6	25	0	Inf. Dilution	lgK:-6.15(3SF)	5	MSL	6836
Note (6): Value of Bell & George (1953)							
7	25	0	Inf. Dilution	lgK:-5.71(3SF)	3	CRV	22551
8	25	0.5	Unknown	lgK:-5.07(3SF)	6	CRV	552
9	25	1	Unknown	lgK:-4.89(3SF)	6	CRV	552
10	25	2	Unknown	lgK:-4.70(3SF)	5	CRV	552
11	25	3	Unknown	lgK:-4.84(3SF)	6	CRV	552
12	25	4	Unknown	lgK:-5.06(3SF)	6	CRV	552
13	0:90	0	Inf. Dilution	dH:20.(2SF)	4	CRV	552


Reaction No. 66054							
H+1 + P207-4 + Ca+2 = Ca+2_H+1_P207-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.0(3SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:13.4(3SF)	3	ENS	6405
3	25	3	Inert	lgK:12.3(3SF)	1	EOR	
4	100	0	Inf. Dilution	lgK:15.2(3SF)	1	EOR	

Reaction No. 66055							
Ca+2(2)_P207-4_(s) = 2<Ca+2> + P207-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-17.3(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-7.9(2SF)	0	ENS	773
3	25	0	Inf. Dilution	lgK:-14.7(3SF)	0	ENS	6405

Reaction No. 66082							
CaO.Al2O3.2SiO2(s) + 2<H+1> + 6<H2O> = 2<Al+3_OH-1(3)_(Gibbsite,s)> + 2<H+1(2)_SiH2O4-2 > + Ca+2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:11.16(4SF)	0	ENS	6405

Reaction No. 66083




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.0(3SF)	4	ENS	6405

Reaction No. 66207



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:7.1(0.2SD)	6	CRV	552

Reaction No. 66498




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2301.(4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:2286.(4SF)	0	ENS	6494
3	127	0	Inf. Dilution	lgK:1681.(4SF)	4	ENS	6494
4	227	0	Inf. Dilution	lgK:1319.(4SF)	4	ENS	6494
5	327	0	Inf. Dilution	lgK:1077.(4SF)	4	ENS	6494
6	25	0	Inf. Dilution	dG:-3132.4(5SF)	0	EFE	6482

Note (6): Low wgt for internal consistency

7	25	0	Inf. Dilution	dG:-3139.(4SF)	4	EFE	6494
8	25	0	Inf. Dilution	dH:-3315.3(5SF)	4	ENS	6437
9	25	0	Inf. Dilution	dH:-3310.2(5SF)	0	EFE	6482
10	25	0	Inf. Dilution	dH:-3318.(4SF)	4	MTD	6494
11	127	0	Inf. Dilution	dH:-3318.(4SF)	4	MTD	6494
12	227	0	Inf. Dilution	dH:-3317.(4SF)	4	MTD	6494
13	327	0	Inf. Dilution	dH:-3315.(4SF)	4	MTD	6494

Reaction No. 66541



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:536.6(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:533.1(4SF)	0	ENS	6422

3	127	0	Inf. Dilution	lgK:389.5 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:303.4 (4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:246.1 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-732.1 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-788.4 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-788.0 (4SF)	1	MTD	6422
9	227	0	Inf. Dilution	dH:-787.3 (4SF)	0	MTD	6422
10	327	0	Inf. Dilution	dH:-786.5 (4SF)	0	MTD	6422

Reaction No. 66542							
Br ₂ (l) + Ca(s) = Ca+2_Br-1(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:116.4 (4SF)	2	ENS	6422
2	27	0	Inf. Dilution	lgK:115.6 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:85.08 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:66.49 (4SF)	3	ENS	6422
5	327	0	Inf. Dilution	lgK:54.12 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-663.6 (4SF) kJ	2	CRV	6330
7	25	0	Inf. Dilution	dG:-158.7 (4SF)	2	EFE	6422
8	25	0	Inf. Dilution	dG:-663.6 (4SF) kJ	2	EFE	7275
9	25	0	Inf. Dilution	dG:-656.1 (4SF) kJ	3	EOD	29025
10	25	0	Inf. Dilution	dH:-682.8 (4SF) kJ	2	CRV	6330
11	25	0	Inf. Dilution	dH:-163.3 (4SF)	2	MTD	6422
12	25	0	Inf. Dilution	dH:-682.8 (4SF) kJ	2	EFE	7275
13	25	0	Inf. Dilution	dH:-674.9 (4SF) kJ	3	EOD	29025
14	127	0	Inf. Dilution	dH:-170.3 (4SF)	2	MTD	6422
15	227	0	Inf. Dilution	dH:-170.0 (4SF)	1	MTD	6422
16	327	0	Inf. Dilution	dH:-169.6 (4SF)	0	MTD	6422

Reaction No. 66543							
2<C(s)> + Ca(s) = CaC2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.37 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:11.304 (5SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:8.740 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:7.250 (4SF)	4	ENS	6422

5	327	0	Inf. Dilution	lgK:6.282 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-15.51 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dG:-64.9 (3SF) kJ	4	ENS	7381
8	25	0	Inf. Dilution	dH:-14.3 (3SF)	4	MTD	6422
9	25	0	Inf. Dilution	dH:-59.8 (3SF) kJ	4	ENS	7381
10	127	0	Inf. Dilution	dH:-13.8 (3SF)	4	MTD	6422
11	227	0	Inf. Dilution	dH:-13.4 (3SF)	4	MTD	6422
12	327	0	Inf. Dilution	dH:-13.1 (3SF)	4	MTD	6422

Reaction No. 66544							
Ca(s) + C(s) + N2(g) = Ca2_CN2-2_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:53.22 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:52.838 (5SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:37.62 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:28.55 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:22.54 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-72.60 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-83.8 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-83.3 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-82.7 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-82.2 (3SF)	4	MTD	6422


Reaction No. 66545							
C(s) + Ca(s) + 1.5<O2(g)> = Ca2_CO3-2_(Arag.,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:197.6 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:197.5 (4SF)	2	ENS	6494
3	27	0	Inf. Dilution	lgK:196.3 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:196.2 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:143.7 (4SF)	2	ENS	6422
6	127	0	Inf. Dilution	lgK:143.7 (4SF)	2	ENS	6494
7	227	0	Inf. Dilution	lgK:112.2 (4SF)	2	ENS	6422
8	227	0	Inf. Dilution	lgK:112.2 (4SF)	2	ENS	6494
9	327	0	Inf. Dilution	lgK:91.27 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:91.17 (4SF)	0	ENS	6494

11	25	0	Inf. Dilution	dG:-1128.2 (5SF) kJ	5	CRV	6330
12	25	0	Inf. Dilution	dG:-269.5 (4SF)	2	EFE	6422
13	25	0	Inf. Dilution	dG:-269.5 (4SF)	2	EFE	6494
14	25	0	Inf. Dilution	dG:-1127.8 (5SF) kJ	2	EFE	7275
15	25	0	Inf. Dilution	dG:-1128. (4SF) kJ	5	CRV	8739
16	25	0	Inf. Dilution	dG:-1128.40 (6SF) kJ	4	CRV	23205
17	25	0	Inf. Dilution	dG:-1128.40 (6SF) kJ	3	EOD	23205
18	25	0	Inf. Dilution	dG:-1128.3 (5SF) kJ	4	EOD	29025
19	25	0	GAMSPATH	dG:-1129. (4SF) kJ	0	CRV	12638
20	25	0	Inf. Dilution	dH:-1207.8 (5SF) kJ	5	CRV	6330
21	25	0	Inf. Dilution	dH:-288.5 (4SF)	3	MTD	6422
22	25	0	Inf. Dilution	dH:-288.76 (5SF)	3	ENS	6437
23	25	0	Inf. Dilution	dH:-288.6 (4SF)	4	MTD	6494
24	25	0	Inf. Dilution	dH:-1207.1 (5SF) kJ	3	EFE	7275
25	25	0	Inf. Dilution	dH:-1207.80 (6SF) kJ	5	CRV	8739
26	25	0	Inf. Dilution	dH:-1207.4 (5SF) kJ	4	EOD	29025
27	25	0	GAMSPATH	dH:-1208.00 (6SF) kJ	3	CRV	12638
28	127	0	Inf. Dilution	dH:-288.3 (4SF)	2	MTD	6422
29	127	0	Inf. Dilution	dH:-288.4 (4SF)	2	MTD	6494
30	227	0	Inf. Dilution	dH:-288.1 (4SF)	1	MTD	6422
31	227	0	Inf. Dilution	dH:-288.2 (4SF)	1	MTD	6494
32	327	0	Inf. Dilution	dH:-287.8 (4SF)	0	MTD	6422
33	327	0	Inf. Dilution	dH:-287.9 (4SF)	0	MTD	6494
34	25	0	Inf. Dilution	Cp:82.3 (3SF) J/K	4	EOD	29025

Reaction No. 66546							
Ca(s) + Cl ₂ (g) = Ca+2_Cl-1(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:131.1 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:131.0 (4SF)	2	ENS	6494
3	27	0	Inf. Dilution	lgK:130.2 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:130.1 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:95.60 (4SF)	2	ENS	6422
6	127	0	Inf. Dilution	lgK:95.52 (4SF)	2	ENS	6494
7	227	0	Inf. Dilution	lgK:74.86 (4SF)	3	ENS	6422
8	227	0	Inf. Dilution	lgK:74.78 (4SF)	3	ENS	6494

9	327	0	Inf. Dilution	lgK:61.07 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:60.99 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-748.8 (4SF) kJ	2	CRV	6330
12	25	0	Inf. Dilution	dG:-178.8 (4SF)	4	EFE	6422
13	25	0	Inf. Dilution	dG:-178.7 (4SF)	2	EFE	6494
14	25	0	Inf. Dilution	dG:-748.1 (4SF) kJ	5	EFE	7275
15	25	0	Inf. Dilution	dG:-748.1 (4SF) kJ	4	EOD	29025
16	25	0	Inf. Dilution	dH:-795.4 (4SF) kJ	5	CRV	6330
17	25	0	Inf. Dilution	dH:-190.2 (4SF)	4	MTD	6422
18	25	0	Inf. Dilution	dH:-190.2 (4SF)	4	MTD	6494
19	25	0	Inf. Dilution	dH:-795.8 (4SF) kJ	5	EFE	7275
20	25	0	Inf. Dilution	dH:-795.8 (4SF) kJ	4	EOD	29025
21	127	0	Inf. Dilution	dH:-189.9 (4SF)	4	MTD	6422
22	127	0	Inf. Dilution	dH:-189.9 (4SF)	4	MTD	6494
23	227	0	Inf. Dilution	dH:-189.5 (4SF)	3	MTD	6422
24	227	0	Inf. Dilution	dH:-189.6 (4SF)	3	MTD	6494
25	327	0	Inf. Dilution	dH:-189.2 (4SF)	0	MTD	6422
26	327	0	Inf. Dilution	dH:-189.3 (4SF)	0	MTD	6494
27	25	0	Inf. Dilution	Cp:72.9 (3SF) J/K	4	EOD	29025


Reaction No. 66547



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:205.6 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:205.9 (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:204.3 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:204.6 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:150.9 (4SF)	2	ENS	6422
6	127	0	Inf. Dilution	lgK:151.1 (4SF)	2	ENS	6494
7	227	0	Inf. Dilution	lgK:119.0 (4SF)	1	ENS	6422
8	227	0	Inf. Dilution	lgK:119.1 (4SF)	1	ENS	6494
9	327	0	Inf. Dilution	lgK:97.69 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:97.77 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-1175.6 (5SF) kJ	3	CRV	6330
12	25	0	Inf. Dilution	dG:-280.5 (4SF)	3	EFE	6422
13	25	0	Inf. Dilution	dG:-280.9 (4SF)	3	EFE	6494


14	25	0	Inf. Dilution	dG:-1167.3 (5SF) kJ	0	EFE	7275
15	25	0	Inf. Dilution	dG:-280.08 (5SF)	5	MSL	21870
16	25	0	GAMSPATH	dG:-1174. (4SF) kJ	0	CRV	12638
17	25	0	Inf. Dilution	dH:-1228.0 (5SF) kJ	3	CRV	6330
18	25	0	Inf. Dilution	dH:-293.0 (4SF)	3	MTD	6422
19	25	0	Inf. Dilution	dH:-293.5 (4SF)	3	MTD	6494
20	25	0	Inf. Dilution	dH:-1219.6 (5SF) kJ	0	EFE	7275
21	25	0	Inf. Dilution	dH:-292.59 (5SF)	5	MSL	21870
22	25	0	GAMSPATH	dH:-1225.90 (6SF) kJ	0	CRV	12638
23	127	0	Inf. Dilution	dH:-292.7 (4SF)	1	MTD	6422
24	127	0	Inf. Dilution	dH:-293.3 (4SF)	1	MTD	6494
25	227	0	Inf. Dilution	dH:-292.3 (4SF)	0	MTD	6422
26	227	0	Inf. Dilution	dH:-293.0 (4SF)	0	MTD	6494
27	327	0	Inf. Dilution	dH:-292.0 (4SF)	0	MTD	6422
28	327	0	Inf. Dilution	dH:-292.5 (4SF)	0	MTD	6494

Reaction No. 66548



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:295.6 (4SF)	1	ERG	
2	25	0	Inf. Dilution	lgK:294.5 (4SF)	0	ENS	6422
3	27	0	Inf. Dilution	lgK:292.6 (4SF)	0	ENS	6422
4	127	0	Inf. Dilution	lgK:213.6 (4SF)	0	ENS	6422
5	227	0	Inf. Dilution	lgK:166.2 (4SF)	0	ENS	6422
6	327	0	Inf. Dilution	lgK:134.6 (4SF)	0	ENS	6422
7	25	0	Inf. Dilution	dG:-401.8 (4SF)	0	EFE	6422
8	25	0	Inf. Dilution	dH:-433.6 (4SF)	0	MTD	6422
9	127	0	Inf. Dilution	dH:-433.8 (4SF)	0	MTD	6422
10	227	0	Inf. Dilution	dH:-433.5 (4SF)	0	MTD	6422
11	327	0	Inf. Dilution	dH:-432.9 (4SF)	0	MTD	6422

Reaction No. 66549



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:378.6 (4SF)	1	ERG	
2	25	0	Inf. Dilution	lgK:377.5 (4SF)	0	ENS	6422


3	27	0	Inf. Dilution	lgK:374.9 (4SF)	0	ENS	6422
4	127	0	Inf. Dilution	lgK:270.2 (4SF)	0	ENS	6422
5	227	0	Inf. Dilution	lgK:207.4 (4SF)	0	ENS	6422
6	327	0	Inf. Dilution	lgK:165.6 (4SF)	0	ENS	6422
7	25	0	Inf. Dilution	dG:-515.0 (4SF)	0	EFE	6422
8	25	0	Inf. Dilution	dH:-574.5 (4SF)	0	MTD	6422
9	127	0	Inf. Dilution	dH:-574.7 (4SF)	0	MTD	6422
10	227	0	Inf. Dilution	dH:-574.4 (4SF)	0	MTD	6422
11	327	0	Inf. Dilution	dH:-573.9 (4SF)	0	MTD	6422

Reaction No. 66550							
Ca(s) + I2(s) = Ca+2_I-1(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:93.40 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:92.82 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:69.38 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:54.50 (4SF)	3	ENS	6422
5	327	0	Inf. Dilution	lgK:44.13 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-528.9 (4SF) kJ	3	CRV	6330
7	25	0	Inf. Dilution	dG:-127.4 (4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dH:-533.5 (4SF) kJ	3	CRV	6330
9	25	0	Inf. Dilution	dH:-128.3 (4SF)	4	MTD	6422
10	127	0	Inf. Dilution	dH:-132.2 (4SF)	4	MTD	6422
11	227	0	Inf. Dilution	dH:-142.5 (4SF)	3	MTD	6422
12	327	0	Inf. Dilution	dH:-142.1 (4SF)	0	MTD	6422

Reaction No. 66551							
3<Ca(s)> + N2(g) = Ca3N2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:64.47 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:64.01 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:45.27 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:34.07 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:26.64 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-87.96 (4SF)	4	ENS	6422
7	25	0	Inf. Dilution	dH:-103.0 (4SF)	4	MTD	6422


8	127	0	Inf. Dilution	dH:-102.7 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-102.2 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-101.8 (4SF)	4	MTD	6422

Reaction No. 66552



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:130.2 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:130.1 (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:129.2 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:129.1 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:88.35 (4SF)	4	ENS	6422
6	127	0	Inf. Dilution	lgK:88.27 (4SF)	4	ENS	6494
7	227	0	Inf. Dilution	lgK:63.93 (4SF)	3	ENS	6422
8	227	0	Inf. Dilution	lgK:63.85 (4SF)	3	ENS	6494
9	327	0	Inf. Dilution	lgK:47.72 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:47.64 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-742.8 (4SF) kJ	5	CRV	6330
12	25	0	Inf. Dilution	dG:-177.6 (4SF)	4	ENS	6422
13	25	0	Inf. Dilution	dG:-177.5 (4SF)	4	EFE	6494
14	25	0	Inf. Dilution	dH:-938.2 (4SF) kJ	5	CRV	6330
15	25	0	Inf. Dilution	dH:-224.3 (4SF)	4	MTD	6422
16	25	0	Inf. Dilution	dH:-224.3 (4SF)	4	MTD	6494
17	127	0	Inf. Dilution	dH:-223.8 (4SF)	4	MTD	6422
18	127	0	Inf. Dilution	dH:-223.9 (4SF)	4	MTD	6494
19	227	0	Inf. Dilution	dH:-223.0 (4SF)	3	MTD	6422
20	227	0	Inf. Dilution	dH:-223.0 (4SF)	3	MTD	6494
21	327	0	Inf. Dilution	dH:-221.8 (4SF)	0	MTD	6422
22	327	0	Inf. Dilution	dH:-221.9 (4SF)	0	MTD	6494


Reaction No. 66553



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:105.8 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:105.1 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:76.78 (4SF)	4	ENS	6422


4	25	0	Inf. Dilution	dG:-144.4 (4SF)	4	ENS	6422
5	25	0	Inf. Dilution	dH:-156.0 (4SF)	4	MTD	6422
6	127	0	Inf. Dilution	dH:-155.3 (4SF)	4	MTD	6422

Reaction No. 66554




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:490.8 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:487.6 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:358.8 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:281.6 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:230.2 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-669.6 (4SF)	4	ENS	6422
7	25	0	Inf. Dilution	dH:-707.0 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-706.9 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-706.5 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-706.1 (4SF)	4	MTD	6422

Reaction No. 66555



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3235. (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:3214. (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:2369. (4SF)	1	ENS	6422
4	227	0	Inf. Dilution	lgK:1861. (4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:1523. (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-4414. (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-4644. (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-4643. (4SF)	1	MTD	6422
9	227	0	Inf. Dilution	dH:-4642. (4SF)	0	MTD	6422
10	327	0	Inf. Dilution	dH:-4640. (4SF)	0	MTD	6422

Reaction No. 66556



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:877.0 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:871.0 (4SF)	4	ENS	6422

3	127	0	Inf. Dilution	lgK:629.4 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:484.5 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:388.0 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-1196. (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-1326. (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-1326. (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-1326. (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-1324. (4SF)	4	MTD	6422

Reaction No. 66557							
Ca(s) + 2<Al(s)> + Si(s) + 3<O2(g)> = CaO.Al2O3.SiO2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:544.7 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:547.0 (4SF)	0	ENS	6422
3	25	0	Inf. Dilution	lgK:548.3 (4SF)	0	ENS	6494
4	27	0	Inf. Dilution	lgK:543.4 (4SF)	0	ENS	6422
5	27	0	Inf. Dilution	lgK:544.7 (4SF)	0	ENS	6494
6	127	0	Inf. Dilution	lgK:399.8 (4SF)	0	ENS	6422
7	127	0	Inf. Dilution	lgK:400.8 (4SF)	0	ENS	6494
8	227	0	Inf. Dilution	lgK:313.7 (4SF)	0	ENS	6422
9	227	0	Inf. Dilution	lgK:314.4 (4SF)	0	ENS	6494
10	327	0	Inf. Dilution	lgK:256.4 (4SF)	0	ENS	6422
11	327	0	Inf. Dilution	lgK:256.9 (4SF)	0	ENS	6494
12	25	0	Inf. Dilution	dG:-746.2 (4SF)	0	EFE	6422
13	25	0	Inf. Dilution	dG:-746.25 (5SF)	0	EFE	6482
14	25	0	Inf. Dilution	dG:-748.0 (4SF)	0	EFE	6494
15	25	0	Inf. Dilution	dH:-788.3 (4SF)	2	MTD	6422
16	25	0	Inf. Dilution	dH:-788.42 (5SF)	0	EFE	6482
17	25	0	Inf. Dilution	dH:-790.2 (4SF)	0	MTD	6494
18	127	0	Inf. Dilution	dH:-788.2 (4SF)	0	MTD	6422
19	127	0	Inf. Dilution	dH:-790.4 (4SF)	0	MTD	6494
20	227	0	Inf. Dilution	dH:-787.8 (4SF)	0	MTD	6422
21	227	0	Inf. Dilution	dH:-790.2 (4SF)	0	MTD	6494
22	327	0	Inf. Dilution	dH:-787.1 (4SF)	0	MTD	6422
23	327	0	Inf. Dilution	dH:-789.7 (4SF)	0	MTD	6494

Reaction No. 66558							
2<Al(s)> + Ca(s) + 4<O2(g)> + 2<Si(s)> = CaO.Al2O3.2SiO2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:701.2(4SF)	0	ENS	6422
2	25	0	Inf. Dilution	lgK:702.2(4SF)	0	ENS	6494
3	27	0	Inf. Dilution	lgK:696.6(4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:697.6(4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:512.6(4SF)	3	ENS	6422
6	127	0	Inf. Dilution	lgK:513.2(4SF)	0	ENS	6494
7	227	0	Inf. Dilution	lgK:402.1(4SF)	0	ENS	6422
8	227	0	Inf. Dilution	lgK:402.7(4SF)	1	ENS	6494
9	327	0	Inf. Dilution	lgK:328.6(4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:329.0(4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-956.6(4SF)	0	EFE	6422
12	25	0	Inf. Dilution	dG:-956.8(4SF)	0	EFE	6482
13	25	0	Inf. Dilution	dG:-957.9(4SF)	0	EFE	6494
14	25	0	Inf. Dilution	dG:-4002.10(6SF)kJ	6	EFE	8798
Note (14): To avoid confusion note source units (J/mol) & value c.a.= -4 million							
15	25	0	Inf. Dilution	dG:-4002.1(5SF)kJ	4	MTD	12843
16	25	0	Inf. Dilution	dH:-1010.(4SF)	4	MTD	6422
17	25	0	Inf. Dilution	dH:-1011.6(5SF)	0	ENS	6437
18	25	0	Inf. Dilution	dH:-1010.7(5SF)	0	EFE	6482
19	25	0	Inf. Dilution	dH:-1012.(4SF)	0	MTD	6494
20	25	0	Inf. Dilution	dH:-4227.80(6SF)kJ	6	EFE	8798
21	25	0	Inf. Dilution	dH:-4227.8(5SF)kJ	4	MTD	12843
22	25	0	GAMSPATH	dH:-4216.5(5SF)kJ	0	CRV	12638
23	127	0	Inf. Dilution	dH:-1011.(4SF)	2	MTD	6422
24	127	0	Inf. Dilution	dH:-1012.(4SF)	2	MTD	6494
25	227	0	Inf. Dilution	dH:-1010.(4SF)	1	MTD	6422
26	227	0	Inf. Dilution	dH:-1012.(4SF)	1	MTD	6494
27	327	0	Inf. Dilution	dH:-1010.(4SF)	0	MTD	6422
28	327	0	Inf. Dilution	dH:-1011.(4SF)	0	MTD	6494

Reaction No. 66559							
2<Ca(s)> + 2<Al(s)> + Si(s) + 3.5<O2(g)> = 2CaO.Al2O3.SiO2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0	Inf. Dilution	lgK:662.7 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:663.2 (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:658.4 (4SF)	4	ENS	6422
4	27	0	Inf. Dilution	lgK:658.9 (4SF)	4	ENS	6494
5	127	0	Inf. Dilution	lgK:485.1 (4SF)	4	ENS	6422
6	127	0	Inf. Dilution	lgK:485.4 (4SF)	4	ENS	6494
7	227	0	Inf. Dilution	lgK:381.2 (4SF)	4	ENS	6422
8	227	0	Inf. Dilution	lgK:381.3 (4SF)	4	ENS	6494
9	327	0	Inf. Dilution	lgK:311.9 (4SF)	4	ENS	6422
10	327	0	Inf. Dilution	lgK:312.0 (4SF)	4	ENS	6494
11	25	0	Inf. Dilution	dG:-904.1 (4SF)	4	EFE	6422
12	25	0	Inf. Dilution	dG:-904.86 (5SF)	4	EFE	6482
13	25	0	Inf. Dilution	dG:-904.8 (4SF)	4	EFE	6494
14	25	0	Inf. Dilution	dH:-951.6 (4SF)	4	MTD	6422
15	25	0	Inf. Dilution	dH:-950.7 (4SF)	4	ENS	6437
16	25	0	Inf. Dilution	dH:-953.19 (5SF)	4	EFE	6482
17	25	0	Inf. Dilution	dH:-952.4 (4SF)	4	MTD	6494
18	127	0	Inf. Dilution	dH:-951.5 (4SF)	4	MTD	6422
19	127	0	Inf. Dilution	dH:-952.6 (4SF)	4	MTD	6494
20	227	0	Inf. Dilution	dH:-951.0 (4SF)	4	MTD	6422
21	227	0	Inf. Dilution	dH:-952.4 (4SF)	4	MTD	6494
22	327	0	Inf. Dilution	dH:-950.4 (4SF)	4	MTD	6422
23	327	0	Inf. Dilution	dH:-952.0 (4SF)	4	MTD	6494


Reaction No. 66560							
3<Ca(s)> + 2<Al(s)> + 3<Si(s)> + 6<O2(g)> = 3CaO.Al2O3.3SiO2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1098.0 (5SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:1100. (4SF)	0	ENS	6422
3	25	0	Inf. Dilution	lgK:1100. (4SF)	0	ENS	6494
4	27	0	Inf. Dilution	lgK:1093. (4SF)	0	ENS	6422
5	27	0	Inf. Dilution	lgK:1093. (4SF)	0	ENS	6494
6	127	0	Inf. Dilution	lgK:803.8 (4SF)	0	ENS	6422
7	127	0	Inf. Dilution	lgK:803.7 (4SF)	0	ENS	6494
8	227	0	Inf. Dilution	lgK:630.2 (4SF)	0	ENS	6422
9	227	0	Inf. Dilution	lgK:630.3 (4SF)	0	ENS	6494

10	327	0	Inf. Dilution	lgK:514.6(4SF)	0	ENS	6422
11	327	0	Inf. Dilution	lgK:514.7(4SF)	0	ENS	6494
12	25	0	Inf. Dilution	dG:-1501.(4SF)	0	EFE	6422
13	25	0	Inf. Dilution	dG:-1498.8(5SF)	0	EFE	6482
14	25	0	Inf. Dilution	dG:-1501.(4SF)	0	EFE	6494
15	25	0	Inf. Dilution	dH:-1588.(4SF)	2	MTD	6422
16	25	0	Inf. Dilution	dH:-1585.6(5SF)	0	ENS	6437
17	25	0	Inf. Dilution	dH:-1585.3(5SF)	0	EFE	6482
18	25	0	Inf. Dilution	dH:-1587.(4SF)	0	MTD	6494
19	127	0	Inf. Dilution	dH:-1589.(4SF)	0	MTD	6422
20	127	0	Inf. Dilution	dH:-1587.(4SF)	0	MTD	6494
21	227	0	Inf. Dilution	dH:-1588.0(5SF)	0	MTD	6422
22	227	0	Inf. Dilution	dH:-1587.(4SF)	0	MTD	6494
23	327	0	Inf. Dilution	dH:-1587.(4SF)	0	MTD	6422
24	327	0	Inf. Dilution	dH:-1586.(4SF)	0	MTD	6494

Reaction No. 66561							
Ca(s) + 2<Al(s)> + 2<Si(s)> + 5<O2(g)> + 2<H2(g)> = CaO.Al2O3.2SiO2.2H2O(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:789.3(4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:790.6(4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:784.0(4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:785.4(4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:572.4(4SF)	2	ENS	6422
6	127	0	Inf. Dilution	lgK:573.4(4SF)	2	ENS	6494
7	227	0	Inf. Dilution	lgK:445.4(4SF)	1	ENS	6422
8	227	0	Inf. Dilution	lgK:446.2(4SF)	1	ENS	6494
9	327	0	Inf. Dilution	lgK:360.7(4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:361.4(4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-1077.(4SF)	4	EFE	6422
12	25	0	Inf. Dilution	dG:-1077.90(6SF)	4	EFE	6482
13	25	0	Inf. Dilution	dG:-1079.(4SF)	4	EFE	6494
14	25	0	Inf. Dilution	dH:-1161.2(5SF)	4	MTD	6422
15	25	0	Inf. Dilution	dH:-1163.5(5SF)	4	ENS	6437
16	25	0	Inf. Dilution	dH:-1162.9(5SF)	4	EFE	6482
17	25	0	Inf. Dilution	dH:-1164.(4SF)	4	MTD	6494


18	127	0	Inf. Dilution	dH:-1162.(4SF)	1	MTD	6422
19	127	0	Inf. Dilution	dH:-1164.(4SF)	1	MTD	6494
20	227	0	Inf. Dilution	dH:-1163.(4SF)	0	MTD	6422
21	227	0	Inf. Dilution	dH:-1164.(4SF)	0	MTD	6494
22	327	0	Inf. Dilution	dH:-1163.(4SF)	0	MTD	6422
23	327	0	Inf. Dilution	dH:-1163.(4SF)	0	MTD	6494

Reaction No. 66562




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:337.1(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:334.9(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:246.5(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:193.5(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:158.1(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-459.9(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-485.4(4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-485.3(4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-485.1(4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-484.9(4SF)	4	MTD	6422

Reaction No. 66563



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:554.9(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:551.2(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:404.9(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:317.2(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:258.7(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-756.9(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-803.1(4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-803.2(4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-802.9(4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-802.5(4SF)	4	MTD	6422

Reaction No. 66564




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:454.9 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:452.0 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:332.9 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:261.6 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:214.0 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-620.6 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-653.5 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-653.3 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-652.9 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-652.4 (4SF)	4	MTD	6422

Reaction No. 66565							
$3\text{Ca(s)} + 2\text{B(s)} + 3\text{O}_2\text{(g)} = \text{Ca}_3\text{B}_2\text{O}_6\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:571.1 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:567.4 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:418.2 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:328.7 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:269.0 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-779.12 (5SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-819.6 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-819.3 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-818.8 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-818.2 (4SF)	4	MTD	6422

Reaction No. 66566							
$\text{Ca(s)} + \text{Cl}_2\text{(g)} + 0.5\text{O}_2\text{(g)} = \text{Ca(OC l)Cl(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:117.5 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:116.7 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:84.25 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:64.87 (4SF)	1	ENS	6422
5	25	0	Inf. Dilution	dG:-160.3 (4SF)	4	EFE	6422
6	25	0	Inf. Dilution	dH:-178.4 (4SF)	2	MTD	6422
7	127	0	Inf. Dilution	dH:-177.7 (4SF)	1	MTD	6422


8	227	0	Inf. Dilution	dH:-177.0 (4SF)	0	MTD	6422
---	-----	---	---------------	-----------------	---	-----	------

Reaction No. 66567



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:251.5 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:247.5 (4SF)	0	ENS	6422
3	25	0	Inf. Dilution	lgK:247.4 (4SF)	0	ENS	6494
4	27	0	Inf. Dilution	lgK:245.9 (4SF)	0	ENS	6422
5	27	0	Inf. Dilution	lgK:245.8 (4SF)	0	ENS	6494
6	127	0	Inf. Dilution	lgK:179.7 (4SF)	0	ENS	6422
7	127	0	Inf. Dilution	lgK:179.7 (4SF)	0	ENS	6494
8	227	0	Inf. Dilution	lgK:140.1 (4SF)	0	ENS	6422
9	227	0	Inf. Dilution	lgK:140.0 (4SF)	0	ENS	6494
10	327	0	Inf. Dilution	lgK:113.8 (4SF)	0	ENS	6422
11	327	0	Inf. Dilution	lgK:113.7 (4SF)	0	ENS	6494
12	25	0	Inf. Dilution	dG:-337.7 (4SF)	0	EFE	6422
13	25	0	Inf. Dilution	dG:-337.6 (4SF)	0	EFE	6494
14	25	0	Inf. Dilution	dH:-363.4 (4SF)	2	MTD	6422
15	25	0	Inf. Dilution	dH:-363.4 (4SF)	0	MTD	6494
16	127	0	Inf. Dilution	dH:-362.8 (4SF)	0	MTD	6422
17	127	0	Inf. Dilution	dH:-362.8 (4SF)	0	MTD	6494
18	227	0	Inf. Dilution	dH:-362.1 (4SF)	0	MTD	6422
19	227	0	Inf. Dilution	dH:-362.3 (4SF)	0	MTD	6494
20	327	0	Inf. Dilution	dH:-361.4 (4SF)	0	MTD	6422
21	327	0	Inf. Dilution	dH:-361.9 (4SF)	0	MTD	6494

Reaction No. 66568



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:350.7 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:350.4 (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:348.4 (4SF)	4	ENS	6422
4	27	0	Inf. Dilution	lgK:348.1 (4SF)	4	ENS	6494
5	127	0	Inf. Dilution	lgK:255.3 (4SF)	4	ENS	6422
6	127	0	Inf. Dilution	lgK:255.0 (4SF)	4	ENS	6494


7	227	0	Inf. Dilution	lgK:199.5 (4SF)	4	ENS	6422
8	227	0	Inf. Dilution	lgK:199.3 (4SF)	4	ENS	6494
9	327	0	Inf. Dilution	lgK:162.4 (4SF)	4	ENS	6422
10	327	0	Inf. Dilution	lgK:162.2 (4SF)	4	ENS	6494
11	25	0	Inf. Dilution	dG:-478.4 (4SF)	4	EFE	6422
12	25	0	Inf. Dilution	dG:-478.0 (4SF)	4	EFE	6494
13	25	0	Inf. Dilution	dH:-511.3 (4SF)	4	MTD	6422
14	25	0	Inf. Dilution	dH:-511.1 (4SF)	4	MTD	6494
15	127	0	Inf. Dilution	dH:-510.7 (4SF)	4	MTD	6422
16	127	0	Inf. Dilution	dH:-510.4 (4SF)	4	MTD	6494
17	227	0	Inf. Dilution	dH:-509.9 (4SF)	4	MTD	6422
18	227	0	Inf. Dilution	dH:-509.5 (4SF)	4	MTD	6494
19	327	0	Inf. Dilution	dH:-509.1 (4SF)	4	MTD	6422
20	327	0	Inf. Dilution	dH:-508.8 (4SF)	4	MTD	6494

Reaction No. 66569



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:302.8 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:300.9 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:222.1 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:174.9 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:143.6 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-413.1 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-433.0 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-431.9 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-431.0 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-430.3 (4SF)	4	MTD	6422


Reaction No. 66570



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:206.8 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:205.5 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:151.3 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:118.9 (4SF)	4	ENS	6422

5	327	0	Inf. Dilution	lgK:97.224 (5SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-282.1 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-297.3 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-297.2 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-297.0 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-296.8 (4SF)	4	MTD	6422

Reaction No. 66571



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:374.6 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:375.9 (4SF)	3	ENS	6422
3	25	0	Inf. Dilution	lgK:373.6 (4SF)	3	ENS	6494
4	27	0	Inf. Dilution	lgK:373.5 (4SF)	0	ENS	6422
5	27	0	Inf. Dilution	lgK:371.2 (4SF)	0	ENS	6494
6	127	0	Inf. Dilution	lgK:275.0 (4SF)	1	ENS	6422
7	127	0	Inf. Dilution	lgK:273.2 (4SF)	1	ENS	6494
8	227	0	Inf. Dilution	lgK:215.9 (4SF)	0	ENS	6422
9	227	0	Inf. Dilution	lgK:214.4 (4SF)	0	ENS	6494
10	327	0	Inf. Dilution	lgK:176.5 (4SF)	0	ENS	6422
11	327	0	Inf. Dilution	lgK:175.3 (4SF)	0	ENS	6494
12	25	0	Inf. Dilution	dG:-512.8 (4SF)	0	EFE	6422
13	25	0	Inf. Dilution	dG:-509.61 (5SF)	0	EFE	6482
14	25	0	Inf. Dilution	dG:-509.8 (4SF)	0	EFE	6494
15	25	0	Inf. Dilution	dH:-540.9 (4SF)	0	MTD	6422
16	25	0	Inf. Dilution	dH:-536.9 (4SF)	0	ENS	6437
17	25	0	Inf. Dilution	dH:-537.77 (5SF)	0	EFE	6482
18	25	0	Inf. Dilution	dH:-538.0 (4SF)	0	MTD	6494
19	127	0	Inf. Dilution	dH:-540.8 (4SF)	0	MTD	6422
20	127	0	Inf. Dilution	dH:-538.0 (4SF)	0	MTD	6494
21	227	0	Inf. Dilution	dH:-540.6 (4SF)	0	MTD	6422
22	227	0	Inf. Dilution	dH:-537.7 (4SF)	0	MTD	6494
23	327	0	Inf. Dilution	dH:-540.2 (4SF)	0	MTD	6422
24	327	0	Inf. Dilution	dH:-537.4 (4SF)	0	MTD	6494


Reaction No. 66572

Ca (s) + Mg (s) + 3<O2 (g)> + 2<Si (s)> = CaO.MgO.2SiO2 (s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:531.2 (4SF)	2	ENS	6422
2	25	0	Inf. Dilution	lgK:382.6 (4SF)	0	ENS	6437
3	25	0	Inf. Dilution	lgK:530.3 (4SF)	4	ENS	6494
4	27	0	Inf. Dilution	lgK:527.7 (4SF)	0	ENS	6422
5	27	0	Inf. Dilution	lgK:526.8 (4SF)	0	ENS	6494
6	127	0	Inf. Dilution	lgK:388.1 (4SF)	1	ENS	6422
7	127	0	Inf. Dilution	lgK:387.5 (4SF)	3	ENS	6494
8	227	0	Inf. Dilution	lgK:304.4 (4SF)	2	ENS	6422
9	227	0	Inf. Dilution	lgK:303.9 (4SF)	2	ENS	6494
10	327	0	Inf. Dilution	lgK:248.6 (4SF)	0	ENS	6422
11	327	0	Inf. Dilution	lgK:248.1 (4SF)	0	ENS	6494
12	25	0	Inf. Dilution	dG:-724.7 (4SF)	2	EFE	6422
13	25	0	Inf. Dilution	dG:-723.28 (5SF)	3	EFE	6482
14	25	0	Inf. Dilution	dG:-723.4 (4SF)	4	EFE	6494
15	25	0	Inf. Dilution	dG:-3026.8 (5SF) kJ	3	EOD	12843
16	25	0	Inf. Dilution	dH:-766.3 (4SF)	2	MTD	6422
17	25	0	Inf. Dilution	dH:-764.96 (5SF)	4	EFE	6482
18	25	0	Inf. Dilution	dH:-765.2 (4SF)	4	MTD	6494
19	25	0	Inf. Dilution	dH:-3201.5 (5SF) kJ	3	EOD	12843
20	127	0	Inf. Dilution	dH:-766.4 (4SF)	2	MTD	6422
21	127	0	Inf. Dilution	dH:-765.2 (4SF)	2	MTD	6494
22	227	0	Inf. Dilution	dH:-766.1 (4SF)	2	MTD	6422
23	227	0	Inf. Dilution	dH:-764.9 (4SF)	2	MTD	6494
24	327	0	Inf. Dilution	dH:-765.6 (4SF)	0	MTD	6422
25	327	0	Inf. Dilution	dH:-764.4 (4SF)	0	MTD	6494

Reaction No. 66573							
2<Ca (s)> + Mg (s) + 2<Si (s)> + 3.5<O2 (g)> = 2CaO.MgO.2SiO2 (s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:643.3 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:644.7 (4SF)	3	ENS	6422
3	25	0	Inf. Dilution	lgK:642.5 (4SF)	3	ENS	6494
4	27	0	Inf. Dilution	lgK:640.5 (4SF)	0	ENS	6422
5	27	0	Inf. Dilution	lgK:638.4 (4SF)	0	ENS	6494

6	127	0	Inf. Dilution	lgK:471.7 (4SF)	1	ENS	6422
7	127	0	Inf. Dilution	lgK:470.2 (4SF)	1	ENS	6494
8	227	0	Inf. Dilution	lgK:370.5 (4SF)	0	ENS	6422
9	227	0	Inf. Dilution	lgK:369.3 (4SF)	0	ENS	6494
10	327	0	Inf. Dilution	lgK:303.0 (4SF)	0	ENS	6422
11	327	0	Inf. Dilution	lgK:302.1 (4SF)	0	ENS	6494
12	25	0	Inf. Dilution	dG:-879.5 (4SF)	0	EFE	6422
13	25	0	Inf. Dilution	dG:-875.66 (5SF)	0	EFE	6482
14	25	0	Inf. Dilution	dG:-876.6 (4SF)	0	EFE	6494
15	25	0	Inf. Dilution	dH:-926.7 (4SF)	0	MTD	6422
16	25	0	Inf. Dilution	dH:-924.4 (4SF)	0	ENS	6437
17	25	0	Inf. Dilution	dH:-922.67 (5SF)	0	MTD	6482
18	25	0	Inf. Dilution	dH:-923.7 (4SF)	0	MTD	6494
19	127	0	Inf. Dilution	dH:-926.6 (4SF)	0	MTD	6422
20	127	0	Inf. Dilution	dH:-923.6 (4SF)	0	MTD	6494
21	227	0	Inf. Dilution	dH:-926.2 (4SF)	0	MTD	6422
22	227	0	Inf. Dilution	dH:-923.3 (4SF)	0	MTD	6494
23	327	0	Inf. Dilution	dH:-925.7 (4SF)	0	MTD	6422
24	327	0	Inf. Dilution	dH:-923.0 (4SF)	0	MTD	6494


Reaction No. 66574



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2038. (4SF)	0	ENS	6422
2	25	0	Inf. Dilution	lgK:2028. (4SF)	0	ENS	6494
3	27	0	Inf. Dilution	lgK:2025. (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:2014. (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:1487. (4SF)	0	ENS	6422
6	127	0	Inf. Dilution	lgK:1479. (4SF)	1	ENS	6494
7	227	0	Inf. Dilution	lgK:1164. (4SF)	0	ENS	6422
8	227	0	Inf. Dilution	lgK:1158. (4SF)	4	ENS	6494
9	327	0	Inf. Dilution	lgK:948.6 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:943.5 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-2780. (4SF)	0	EFE	6422
12	25	0	Inf. Dilution	dG:-2767.3 (5SF)	3	EFE	6482
13	25	0	Inf. Dilution	dG:-2766. (4SF)	0	EFE	6494

14	25	0	Inf. Dilution	dH:-2954.(4SF)	0	MTD	6422
15	25	0	Inf. Dilution	dH:-2943.(4SF)	2	ENS	6437
16	25	0	Inf. Dilution	dH:-2941.1(5SF)	3	EFE	6482
17	25	0	Inf. Dilution	dH:-2941.(4SF)	0	MTD	6494
18	127	0	Inf. Dilution	dH:-2954.(4SF)	0	MTD	6422
19	127	0	Inf. Dilution	dH:-2941.(4SF)	0	MTD	6494
20	227	0	Inf. Dilution	dH:-2954.(4SF)	0	MTD	6422
21	227	0	Inf. Dilution	dH:-2940.(4SF)	0	MTD	6494
22	327	0	Inf. Dilution	dH:-2952.2(5SF)	0	MTD	6422
23	327	0	Inf. Dilution	dH:-2938.(4SF)	0	MTD	6494

Reaction No. 66575



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:503.4(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:500.0(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:363.3(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:281.2(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:226.4(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-686.8(4SF)	4	ENS	6422
7	25	0	Inf. Dilution	dH:-750.0(4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-751.3(4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-752.1(4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-752.8(4SF)	4	MTD	6422


Reaction No. 66576



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:795.6(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:790.3(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:576.1(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:447.5(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:361.8(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-1085.(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-1176.(4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-1177.(4SF)	4	MTD	6422


9	227	0	Inf. Dilution	dH:-1176.(4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-1176.(4SF)	4	MTD	6422

Reaction No. 66577



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:434.5(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:431.6(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:315.5(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:245.9(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:199.5(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-592.7(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-637.0(4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-637.1(4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-636.9(4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-636.5(4SF)	4	MTD	6422

Reaction No. 66578



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:771.6(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:766.5(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:558.3(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:433.4(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:350.2(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-1053.(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-1143.0(5SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-1143.(4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-1142.(4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-1141.(4SF)	4	MTD	6422


Reaction No. 66579



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:988.6(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:982.1(4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:720.0(4SF)	4	ENS	6422


4	227	0	Inf. Dilution	lgK:562.8 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:458.0 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-1349. (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-1439.0 (5SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-1439. (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-1439. (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-1438. (4SF)	4	MTD	6422

Reaction No. 66580



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1622. (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:1611. (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:1179. (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:919.7 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:746.9 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-2213. (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-2373. (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-2373. (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-2372. (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-2371. (4SF)	4	MTD	6422

Reaction No. 66581



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1729. (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:1718. (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:1253. (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:973.5 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:787.6 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-2359. (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-2554. (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-2554. (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-2553. (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-2551. (4SF)	4	MTD	6422

Reaction No. 66582


5<Ca(s)> + 6<Si(s)> + 13.75<O2(g)> + 10.5<H2(g)> = 5CaO.6SiO2.21by2H2O(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1940.(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:1927.(4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:1397.(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:1079.(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:866.9(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-2647.(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-2911.(4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-2911.(4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-2910.(4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-2906.5(5SF)	4	MTD	6422

Reaction No. 66583							
6<Ca(s)> + 6<Si(s)> + 9.5<O2(g)> + H2(g) = 6CaO.6SiO2.H2O(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1655.(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:1644.(4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:1208.(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:946.3(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:771.8(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-2258.(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-2396.(4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-2396.(4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-2396.(4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-2395.(4SF)	4	MTD	6422

Reaction No. 66584							
Ca(s) + Ti(s) + 1.5<O2(g)> = CaO.TiO2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:283.0(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:276.0(4SF)	0	ENS	6422
3	25	0	Inf. Dilution	lgK:275.9(4SF)	0	ENS	6494
4	27	0	Inf. Dilution	lgK:274.2(4SF)	0	ENS	6422
5	27	0	Inf. Dilution	lgK:274.1(4SF)	0	ENS	6494
6	127	0	Inf. Dilution	lgK:201.9(4SF)	0	ENS	6422

7	127	0	Inf. Dilution	lgK:201.8 (4SF)	0	ENS	6494
8	227	0	Inf. Dilution	lgK:158.6 (4SF)	0	ENS	6422
9	227	0	Inf. Dilution	lgK:158.5 (4SF)	0	ENS	6494
10	327	0	Inf. Dilution	lgK:129.7 (4SF)	0	ENS	6422
11	327	0	Inf. Dilution	lgK:129.7 (4SF)	0	ENS	6494
12	25	0	Inf. Dilution	dG:-376.5 (4SF)	0	EFE	6422
13	25	0	Inf. Dilution	dG:-376.4 (4SF)	0	EFE	6494
14	25	0	Inf. Dilution	dH:-396.9 (4SF)	2	MTD	6422
15	25	0	Inf. Dilution	dH:-396.9 (4SF)	0	MTD	6494
16	127	0	Inf. Dilution	dH:-396.7 (4SF)	0	MTD	6422
17	127	0	Inf. Dilution	dH:-396.6 (4SF)	0	MTD	6494
18	227	0	Inf. Dilution	dH:-396.3 (4SF)	0	MTD	6422
19	227	0	Inf. Dilution	dH:-396.2 (4SF)	0	MTD	6494
20	327	0	Inf. Dilution	dH:-395.9 (4SF)	0	MTD	6422
21	327	0	Inf. Dilution	dH:-395.8 (4SF)	0	MTD	6494

Reaction No. 66585



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:671.2 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:657.2 (4SF)	0	ENS	6422
3	27	0	Inf. Dilution	lgK:652.9 (4SF)	0	ENS	6422
4	127	0	Inf. Dilution	lgK:481.0 (4SF)	0	ENS	6422
5	227	0	Inf. Dilution	lgK:377.9 (4SF)	0	ENS	6422
6	327	0	Inf. Dilution	lgK:309.3 (4SF)	0	ENS	6422
7	25	0	Inf. Dilution	dG:-896.5 (4SF)	0	EFE	6422
8	25	0	Inf. Dilution	dH:-944.2 (4SF)	2	MTD	6422
9	127	0	Inf. Dilution	dH:-943.6 (4SF)	0	MTD	6422
10	227	0	Inf. Dilution	dH:-942.8 (4SF)	0	MTD	6422
11	327	0	Inf. Dilution	dH:-941.9 (4SF)	0	MTD	6422

Reaction No. 66586



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:943.8 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:937.6 (4SF)	0	ENS	6422

3	127	0	Inf. Dilution	lgK:690.8 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:542.8 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:444.3 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-1287. (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-1356. (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-1355. (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-1353.5 (5SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-1352. (4SF)	4	MTD	6422

Reaction No. 66587							
Ca(s) + Si(s) + Ti(s) + 2.5<O2(g)> = CaO.SiO2.TiO2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:431.3 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:430.0 (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:428.5 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:427.2 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:315.2 (4SF)	2	ENS	6422
6	127	0	Inf. Dilution	lgK:314.2 (4SF)	2	ENS	6494
7	227	0	Inf. Dilution	lgK:247.2 (4SF)	1	ENS	6422
8	227	0	Inf. Dilution	lgK:246.4 (4SF)	1	ENS	6494
9	327	0	Inf. Dilution	lgK:201.9 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:201.2 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-588.4 (4SF)	4	EFE	6422
12	25	0	Inf. Dilution	dG:-586.79 (5SF)	5	EFE	6482
13	25	0	Inf. Dilution	dG:-586.7 (4SF)	4	EFE	6494
14	25	0	Inf. Dilution	dH:-622.2 (4SF)	4	MTD	6422
15	25	0	Inf. Dilution	dH:-620.61 (5SF)	5	EFE	6482
16	25	0	Inf. Dilution	dH:-620.6 (4SF)	4	MTD	6494
17	127	0	Inf. Dilution	dH:-622.1 (4SF)	1	MTD	6422
18	127	0	Inf. Dilution	dH:-620.5 (4SF)	1	MTD	6494
19	227	0	Inf. Dilution	dH:-621.7 (4SF)	0	MTD	6422
20	227	0	Inf. Dilution	dH:-620.2 (4SF)	0	MTD	6494
21	327	0	Inf. Dilution	dH:-621.3 (4SF)	0	MTD	6422
22	327	0	Inf. Dilution	dH:-619.8 (4SF)	0	MTD	6494

Reaction No. 66588


Ca (s) + 2<O2 (g)> + U (s) = CaUO4 (s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:331.2 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:329.0 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:242.1 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:190.0 (4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:155.3 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-451.8 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dG:-1888.70 (1.2SD) kJ	5	CRV	20827
8	25	0	GAMSPATH	dG:-1889. (4SF) kJ	3	CRV	12638
9	25	0	Inf. Dilution	dH:-477.4 (4SF)	3	MTD	6422
10	25	0	Inf. Dilution	dH:-2002.3 (1.1SD) kJ	5	CRV	20827
11	25	0	GAMSPATH	dH:-2002.30 (6SF) kJ	3	CRV	12638
12	127	0	Inf. Dilution	dH:-476.9 (4SF)	1	MTD	6422
13	227	0	Inf. Dilution	dH:-476.5 (4SF)	0	MTD	6422
14	327	0	Inf. Dilution	dH:-476.0 (4SF)	0	MTD	6422
15	25	0	Inf. Dilution	Cp:123.800 (6SF) J/K	5	CRV	20827

Reaction No. 66589							
3<Ca (s)> + 2<P (s)> = Ca3P2 (s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:84.38 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:83.84 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:61.73 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:48.43 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:39.54 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-115.1 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-121.0 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-121.6 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-121.9 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-122.3 (4SF)	4	MTD	6422

Reaction No. 66590							
2<Ca (s)> + 2<P (s)> + 3.5<O2 (g)> = Ca+2 (2)_P2O7-4_ (s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:547.8 (4SF)	4	ENS	6422

2	27	0	Inf. Dilution	lgK:544.2 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:399.0 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:311.9 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:253.9 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-747.3 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-796.7 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-797.1 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-796.8 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-796.3 (4SF)	4	MTD	6422

Reaction No. 66591



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:678.9 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:680.6 (4SF)	0	ENS	6422
3	25	0	Inf. Dilution	lgK:680.4 (4SF)	0	ENS	6494
4	27	0	Inf. Dilution	lgK:676.2 (4SF)	0	ENS	6422
5	27	0	Inf. Dilution	lgK:675.9 (4SF)	0	ENS	6494
6	127	0	Inf. Dilution	lgK:496.7 (4SF)	0	ENS	6422
7	127	0	Inf. Dilution	lgK:496.5 (4SF)	0	ENS	6494
8	227	0	Inf. Dilution	lgK:389.0 (4SF)	0	ENS	6422
9	227	0	Inf. Dilution	lgK:388.8 (4SF)	0	ENS	6494
10	327	0	Inf. Dilution	lgK:317.2 (4SF)	0	ENS	6422
11	327	0	Inf. Dilution	lgK:317.1 (4SF)	0	ENS	6494
12	25	0	Inf. Dilution	dG:-928.5 (4SF)	0	EFE	6422
13	25	0	Inf. Dilution	dG:-928.2 (4SF)	0	EFE	6494
14	25	0	Inf. Dilution	dH:-984.9 (4SF)	4	MTD	6422
15	25	0	Inf. Dilution	dH:-984.9 (4SF)	4	MTD	6494
16	127	0	Inf. Dilution	dH:-985.5 (4SF)	4	MTD	6422
17	127	0	Inf. Dilution	dH:-985.3 (4SF)	4	MTD	6494
18	227	0	Inf. Dilution	dH:-985.6 (4SF)	3	MTD	6422
19	227	0	Inf. Dilution	dH:-985.2 (4SF)	3	MTD	6494
20	327	0	Inf. Dilution	dH:-985.6 (4SF)	0	MTD	6422
21	327	0	Inf. Dilution	dH:-984.8 (4SF)	0	MTD	6494


Reaction No. 66592

Ca(s) + S(s) + 1.5O ₂ (g) = Ca ₂ SO ₃ -2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:188.5(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:187.3(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:136.8(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:106.4(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:86.17(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-257.2(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-277.1(4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-277.6(4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-277.9(4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-278.1(4SF)	4	MTD	6422

Reaction No. 66593							
Ca(s) + 2O ₂ (g) + S(s) = Ca ₂ SO ₄ -2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:231.9(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:231.6(4SF)	0	ENS	6422
3	25	0	Inf. Dilution	lgK:231.6(4SF)	0	ENS	6494
4	27	0	Inf. Dilution	lgK:230.0(4SF)	0	ENS	6422
5	27	0	Inf. Dilution	lgK:230.0(4SF)	0	ENS	6494
6	127	0	Inf. Dilution	lgK:167.6(4SF)	0	ENS	6422
7	127	0	Inf. Dilution	lgK:167.6(4SF)	0	ENS	6494
8	227	0	Inf. Dilution	lgK:130.0(4SF)	0	ENS	6422
9	227	0	Inf. Dilution	lgK:130.0(4SF)	0	ENS	6494
10	327	0	Inf. Dilution	lgK:105.0(4SF)	0	ENS	6422
11	327	0	Inf. Dilution	lgK:105.0(4SF)	0	ENS	6494
12	25	0	Inf. Dilution	dG:-1322.0(5SF) kJ	0	CRV	6330
13	25	0	Inf. Dilution	dG:-315.9(4SF)	0	EFE	6422
14	25	0	Inf. Dilution	dG:-315.9(4SF)	0	EFE	6494
15	25	0	Inf. Dilution	dG:-1321.80(6SF) kJ	0	CRV	8695
16	25	0	Inf. Dilution	dG:-1332.1(5SF) kJ	0	EOD	23101
17	25	0	Inf. Dilution	dG:-1323.1(5SF) kJ	4	EOD	29025
18	25	0	Inf. Dilution	dG:-1322.5(5SF) kJ	5	MSL	29947
19	25	0	Inf. Dilution	dG:-1322.1(5SF) kJ	5	CRV	31308
20	25	0	GAMSPATH	dG:-1321.(4SF) kJ	0	CRV	12638


21	25	0	Inf. Dilution/m	dG:-1323.30 (6SF) kJ	3	EPZ	8833
22	25	0	Inf. Dilution	dH:-1434.5 (5SF) kJ	3	CRV	6330
23	25	0	Inf. Dilution	dH:-342.8 (4SF)	0	MTD	6422
24	25	0	Inf. Dilution	dH:-342.8 (4SF)	0	MTD	6494
25	25	0	Inf. Dilution	dH:-1435. (4SF) kJ	0	EOD	23101
26	25	0	Inf. Dilution	dH:-1423.7 (5SF) kJ	0	EOD	29025
27	25	0	Inf. Dilution	dH:-1433.8 (3.2SD) kJ	2	MCL	29612
28	25	0	Inf. Dilution	dH:-1444.0 (5SF) kJ	0	MSL	29947
29	25	0	Inf. Dilution	dH:-1434.6 (5SF) kJ	5	CRV	31308
30	25	0	GAMSPATH	dH:-1433.30 (6SF) kJ	0	CRV	12638
31	27	0	Inf. Dilution	dH:-342.9 (4SF)	0	MTD	6494
32	127	0	Inf. Dilution	dH:-343.4 (4SF)	0	MTD	6422
33	127	0	Inf. Dilution	dH:-343.4 (4SF)	0	MTD	6494
34	227	0	Inf. Dilution	dH:-343.7 (4SF)	0	MTD	6422
35	227	0	Inf. Dilution	dH:-343.5 (4SF)	0	MTD	6494
36	327	0	Inf. Dilution	dH:-343.8 (4SF)	0	MTD	6422
37	327	0	Inf. Dilution	dH:-343.5 (4SF)	0	MTD	6494
38	25	0	Inf. Dilution	Cp:99.7 (3SF) J/K	4	EOD	29025

Reaction No. 66594



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:210.1 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:208.7 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:151.6 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:117.3 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:94.36 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-286.7 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-313.5 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-314.1 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-314.4 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-314.6 (4SF)	4	MTD	6422

Reaction No. 66595




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0	Inf. Dilution	lgK:251.7 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:250.0 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:181.3 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:140.1 (4SF)	2	ENS	6422
5	327	0	Inf. Dilution	lgK:112.6 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-343.4 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dG:-1437.7 (5SF) kJ	3	MSL	29947
Note (7): prob. refers to (and should have referred to) alpha form							
8	25	0	Inf. Dilution	dG:-1436.3 (5SF) kJ	4	CRV	31308
9	25	0	Inf. Dilution	dH:-376.8 (4SF)	4	MTD	6422
10	25	0	Inf. Dilution	dH:-1585.7 (5SF) kJ	3	MSL	29947
11	25	0	Inf. Dilution	dH:-1575.3 (5SF) kJ	5	CRV	31308
12	127	0	Inf. Dilution	dH:-377.5 (4SF)	2	MTD	6422
13	227	0	Inf. Dilution	dH:-377.6 (4SF)	0	MTD	6422
14	327	0	Inf. Dilution	dH:-377.0 (4SF)	0	MTD	6422

Reaction No. 66596							
Ca(s) + 2<H2(g)> + 3<O2(g)> + S(s) = Ca+2_SO4-2_H2O(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:315. (3SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:314.9 (4SF)	2	ENS	6422
3	27	0	Inf. Dilution	lgK:312.7 (4SF)	0	ENS	6422
4	127	0	Inf. Dilution	lgK:224.6 (4SF)	0	ENS	6422
5	227	0	Inf. Dilution	lgK:171.8 (4SF)	0	ENS	6422
6	327	0	Inf. Dilution	lgK:136.6 (4SF)	0	ENS	6422
7	25	0	Inf. Dilution	dG:-429.53 (5SF)	2	EFE	6422
8	25	0	Inf. Dilution	dG:-1797.30 (6SF) kJ	0	CRV	8695
9	25	0	Inf. Dilution	dG:-1797.8 (5SF) kJ	2	EOD	23101
10	25	0	Inf. Dilution	dG:-1797.2 (5SF) kJ	3	CRV	29556
11	25	0	Inf. Dilution	dG:-1797.6 (5SF) kJ	5	MSL	29947
12	25	0	Inf. Dilution	dG:-1797.8 (5SF) kJ	5	CRV	31308
13	25	0	GAMSPATH	dG:-1796. (4SF) kJ	0	CRV	12638
14	25	0	Inf. Dilution/m	dG:-1798.9 (5SF) kJ	2	EPZ	8833
15	25	0	Inf. Dilution/m	dG:-1798.6 (5SF) kJ	3	EPZ	9073
16	25	0	Inf. Dilution	dH:-483.4 (4SF)	0	MTD	6422
17	25	0	Inf. Dilution	dH:-2023. (4SF) kJ	3	EOD	23101


18	25	0	Inf. Dilution	dH:-2022.2 (5SF) kJ	2	CRV	29556
19	25	0	Inf. Dilution	dH:-2032.4 (5SF) kJ	2	MSL	29947
20	25	0	Inf. Dilution	dH:-2023.4 (5SF) kJ	5	CRV	31308
21	25	0	GAMSPATH	dH:-2005.5 (5SF) kJ	0	CRV	12638
22	127	0	Inf. Dilution	dH:-483.8 (4SF)	0	MTD	6422
23	227	0	Inf. Dilution	dH:-483.4 (4SF)	0	MTD	6422
24	327	0	Inf. Dilution	dH:-482.2 (4SF)	0	MTD	6422

Reaction No. 66597



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:63.63 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:63.24 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:47.20 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:37.560 (5SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:31.02 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-86.81 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-88.0 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-88.1 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-89.7 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-90.0 (3SF)	4	MTD	6422

Reaction No. 66598



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:50.56 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:50.24 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:37.48 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:29.78 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:24.63 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-68.98 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-70.0 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-70.3 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-70.6 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-70.9 (3SF)	4	MTD	6422

Reaction No. 66599

Ca(s) + W(s) + 2<O2(g)> = Ca+2_WO4-2_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:266.3(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:269.5(4SF)	0	ENS	6422
3	27	0	Inf. Dilution	lgK:267.7(4SF)	0	ENS	6422
4	127	0	Inf. Dilution	lgK:196.2(4SF)	0	ENS	6422
5	227	0	Inf. Dilution	lgK:153.3(4SF)	0	ENS	6422
6	327	0	Inf. Dilution	lgK:124.7(4SF)	0	ENS	6422
7	25	0	Inf. Dilution	dG:-367.7(4SF)	0	EFE	6422
8	25	0	Inf. Dilution	dH:-393.2(4SF)	0	MTD	6422
9	127	0	Inf. Dilution	dH:-392.8(4SF)	0	MTD	6422
10	227	0	Inf. Dilution	dH:-392.4(4SF)	0	MTD	6422
11	327	0	Inf. Dilution	dH:-391.9(4SF)	0	MTD	6422

Reaction No. 66600							
3<Ca(s)> + W(s) + 3<O2(g)> = 3CaO.WO3(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:493.6(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:490.4(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:360.4(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:282.4(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:230.5(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-673.4(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-714.1(4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-713.6(4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-712.8(4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-712.0(4SF)	4	MTD	6422

Reaction No. 66786							
5<Ca(s)> + C(s) + 2<Si(s)> + 5.5<O2(g)> = CaCO3.4CaO.2SiO2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:968.0(4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:961.7(4SF)	0	ENS	6494
3	127	0	Inf. Dilution	lgK:707.5(4SF)	3	ENS	6494
4	227	0	Inf. Dilution	lgK:555.1(4SF)	3	ENS	6494
5	327	0	Inf. Dilution	lgK:453.6(4SF)	3	ENS	6494

6	25	0	Inf. Dilution	dG:-1321.(4SF)	4	EFE	6494
7	25	0	Inf. Dilution	dH:-1395.8(5SF)	3	ENS	6437
8	25	0	Inf. Dilution	dH:-1396.(4SF)	4	MTD	6494
9	127	0	Inf. Dilution	dH:-1395.(4SF)	3	MTD	6494
10	227	0	Inf. Dilution	dH:-1394.(4SF)	0	MTD	6494
11	327	0	Inf. Dilution	dH:-1393.(4SF)	0	MTD	6494

Reaction No. 66796

Na(s) + 2<Ca(s)> + 5<Mg(s)> + 7<Si(s)> + Al(s) + 12<O2(g)> + H2(g) =
NaCa2Mg5Si7AlO22(OH)2(s)

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-3006.8(5SF)	4	ENS	6437

Reaction No. 66802

2<Ca(s)> + 4<Fe(s)> + 2<Al(s)> + 7<Si(s)> + 12<O2(g)> + H2(g) =
Ca2Fe4Al2Si7O22(OH)2(s)

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-2629.(4SF)	4	ENS	6437

Reaction No. 66803

2<Ca(s)> + 4<Mg(s)> + 2<Al(s)> + 7<Si(s)> + 12<O2(g)> + H2(g) =
Ca2Mg4Al2Si7O22(OH)2(s)

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-2968.5(5SF)	4	ENS	6437

Reaction No. 66805

2<Ca(s)> + 5<Fe(s)> + 8<Si(s)> + 12<O2(g)> + H2(g) = 2CaO.5FeO.8SiO2.H2O(s)

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-2520.(3SF)	4	ENS	6437

Reaction No. 66807

Na(s) + 2<Ca(s)> + 4<Mg(s)> + 3<Al(s)> + 6<Si(s)> + 12<O2(g)> + H2(g) =
NaCa2Mg4Al3Si6O22(OH)2(s)

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-3040.1(5SF)	4	ENS	6437

Reaction No. 66809

Ca(s) + 4<Al(s)> + 2<Si(s)> + 6<O2(g)> + H2(g) = CaAl4Si2O10(OH)2(s)

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0	Inf. Dilution	lgK:1026.(4SF)	1	ENS	6494
2	27	0	Inf. Dilution	lgK:1020.(4SF)	0	ENS	6494
3	127	0	Inf. Dilution	lgK:747.8(4SF)	0	ENS	6494
4	227	0	Inf. Dilution	lgK:584.7(4SF)	0	ENS	6494
5	327	0	Inf. Dilution	lgK:476.0(4SF)	0	ENS	6494
6	25	0	Inf. Dilution	dG:-1398.70(6SF)	1	EFE	6482
7	25	0	Inf. Dilution	dG:-1400.(4SF)	4	EFE	6494
8	25	0	Inf. Dilution	dH:-1492.5(5SF)	4	ENS	6437
9	25	0	Inf. Dilution	dH:-1490.6(5SF)	4	EFE	6482
10	25	0	Inf. Dilution	dH:-1492.(4SF)	1	MTD	6494
11	127	0	Inf. Dilution	dH:-1493.(4SF)	0	MTD	6494
12	227	0	Inf. Dilution	dH:-1493.(4SF)	0	MTD	6494
13	327	0	Inf. Dilution	dH:-1492.(4SF)	0	MTD	6494

Reaction No. 66810

2<Al(s)> + 2<Ca(s)> + Fe(s) + 0.5<H₂(g)> + 6.5<O₂(g)> + 3<Si(s)> =
Ca₂FeAl₂Si₃O₁₂(OH)(s)

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	GAMSPATH	dG:-6072.(4SF) kJ	1	CRV	12638
2	25	0	Inf. Dilution	dH:-1544.5(5SF)	3	ENS	6437
3	25	0	GAMSPATH	dH:-6461.90(6SF) kJ	2	CRV	12638

Note (3): c.f. dG = -6072 & dH = -6462 kJ for 'Ordered Epidote'


Reaction No. 66811

3<Ca(s)> + Mg(s) + 2<Si(s)> + 4<O₂(g)> = 3CaO.MgO.2SiO₂(s)

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:760.4(4SF)	2	ENS	6422
2	25	0	Inf. Dilution	lgK:754.7(4SF)	0	ENS	6494
3	27	0	Inf. Dilution	lgK:755.5(4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:749.8(4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:556.7(4SF)	4	ENS	6422
6	127	0	Inf. Dilution	lgK:552.3(4SF)	0	ENS	6494
7	227	0	Inf. Dilution	lgK:437.4(4SF)	4	ENS	6422
8	227	0	Inf. Dilution	lgK:433.9(4SF)	0	ENS	6494
9	327	0	Inf. Dilution	lgK:358.0(4SF)	4	ENS	6422
10	327	0	Inf. Dilution	lgK:355.0(4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-1037.(4SF)	4	EFE	6422


12	25	0	Inf. Dilution	dG:-1030.00 (6SF)	0	EFE	6482
13	25	0	Inf. Dilution	dG:-1030. (4SF)	0	EFE	6494
14	25	0	Inf. Dilution	dH:-1092. (4SF)	2	MTD	6422
15	25	0	Inf. Dilution	dH:-1084.4 (5SF)	2	ENS	6437
16	25	0	Inf. Dilution	dH:-1084.5 (5SF)	0	EFE	6482
17	25	0	Inf. Dilution	dH:-1084. (4SF)	0	MTD	6494
18	127	0	Inf. Dilution	dH:-1092. (4SF)	0	MTD	6422
19	127	0	Inf. Dilution	dH:-1084. (4SF)	0	MTD	6494
20	227	0	Inf. Dilution	dH:-1091. (4SF)	0	MTD	6422
21	227	0	Inf. Dilution	dH:-1084. (4SF)	0	MTD	6494
22	327	0	Inf. Dilution	dH:-1090. (4SF)	0	MTD	6422
23	327	0	Inf. Dilution	dH:-1083. (4SF)	0	MTD	6494

Reaction No. 66813



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2658. (4SF) kJ	3	CRV	8739
2	25	0	Inf. Dilution/m	dG:-2660.2 (5SF) kJ	3	EPZ	9073
3	25	0	Inf. Dilution	dH:-2955.80 (6SF) kJ	3	CRV	8739


Reaction No. 66817



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1140. (4SF)	1	EDH	
2	25	0	Inf. Dilution	lgK:1140. (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:1132. (4SF)	0	ENS	6494
4	127	0	Inf. Dilution	lgK:831.7 (4SF)	2	ENS	6494
5	227	0	Inf. Dilution	lgK:651.4 (4SF)	1	ENS	6494
6	327	0	Inf. Dilution	lgK:531.3 (4SF)	0	ENS	6494
7	25	0	Inf. Dilution	dG:-1552.1 (5SF)	0	EFE	6482
8	25	0	Inf. Dilution	dG:-1555. (4SF)	4	EFE	6494
9	25	0	GAMSPATH	dG:-6502. (4SF) kJ	0	CRV	12638
10	25	0	Inf. Dilution	dH:-1648.9 (5SF)	2	ENS	6437
11	25	0	Inf. Dilution	dH:-1646.6 (5SF)	0	EFE	6482
12	25	0	Inf. Dilution	dH:-1649. (4SF)	4	MTD	6494
13	25	0	GAMSPATH	dH:-6879.00 (6SF) kJ	0	CRV	12638


14	127	0	Inf. Dilution	dH:-1650. (4SF)	1	MTD	6494
15	227	0	Inf. Dilution	dH:-1649. (4SF)	0	MTD	6494
16	327	0	Inf. Dilution	dH:-1649. (4SF)	0	MTD	6494

Reaction No. 66819



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1020. (4SF)	3	ENS	6494
2	27	0	Inf. Dilution	lgK:1014. (4SF)	0	ENS	6494
3	127	0	Inf. Dilution	lgK:743.7 (4SF)	2	ENS	6494
4	227	0	Inf. Dilution	lgK:581.7 (4SF)	1	ENS	6494
5	327	0	Inf. Dilution	lgK:473.8 (4SF)	0	ENS	6494
6	25	0	Inf. Dilution	dG:-1391.1 (5SF)	5	EFE	6482
7	25	0	Inf. Dilution	dG:-1392. (4SF)	3	EFE	6494
8	25	0	GAMSPATH	dG:-5813. (4SF) kJ	2	CRV	12638
9	25	0	Inf. Dilution	dH:-1481.8 (5SF)	3	ENS	6437
10	25	0	Inf. Dilution	dH:-1481.5 (5SF)	5	EFE	6482
11	25	0	Inf. Dilution	dH:-1483. (4SF)	3	MTD	6494
12	127	0	Inf. Dilution	dH:-1483. (4SF)	1	MTD	6494
13	227	0	Inf. Dilution	dH:-1482. (4SF)	0	MTD	6494
14	327	0	Inf. Dilution	dH:-1481. (4SF)	0	MTD	6494


Reaction No. 66829



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:955.5 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:950.8 (4SF)	0	ENS	6494
3	27	0	Inf. Dilution	lgK:944.5 (4SF)	0	ENS	6494
4	127	0	Inf. Dilution	lgK:693.3 (4SF)	0	ENS	6494
5	227	0	Inf. Dilution	lgK:542.7 (4SF)	0	ENS	6494
6	327	0	Inf. Dilution	lgK:442.3 (4SF)	0	ENS	6494
7	25	0	Inf. Dilution	dG:-1297. (4SF)	0	EFE	6494
8	25	0	Inf. Dilution	dH:-1379.0 (5SF)	2	ENS	6437
9	25	0	Inf. Dilution	dH:-1379. (4SF)	0	MTD	6494
10	127	0	Inf. Dilution	dH:-1379. (4SF)	0	MTD	6494
11	227	0	Inf. Dilution	dH:-1378. (4SF)	0	MTD	6494


12	327	0	Inf. Dilution	dH:-1377.(4SF)	0	MTD	6494
----	-----	---	---------------	----------------	---	-----	------

Reaction No. 66831




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:468.9(4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:465.8(4SF)	0	ENS	6494
3	127	0	Inf. Dilution	lgK:342.2(4SF)	2	ENS	6494
4	227	0	Inf. Dilution	lgK:268.1(4SF)	1	ENS	6494
5	327	0	Inf. Dilution	lgK:218.7(4SF)	0	ENS	6494
6	25	0	Inf. Dilution	dG:-639.7(4SF)	4	EFE	6494
7	25	0	Inf. Dilution	dG:-2676.3(5SF) kJ	3	EOD	12843
8	25	0	Inf. Dilution	dH:-339.2(4SF)	0	ENS	6437
9	25	0	Inf. Dilution	dH:-678.8(4SF)	4	MTD	6494
10	25	0	Inf. Dilution	dH:-2839.9(5SF) kJ	3	EOD	12843
11	127	0	Inf. Dilution	dH:-678.6(4SF)	1	MTD	6494
12	227	0	Inf. Dilution	dH:-678.2(4SF)	0	MTD	6494
13	327	0	Inf. Dilution	dH:-677.7(4SF)	0	MTD	6494

Reaction No. 66835



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:-10.4(3SF)	4	ENS	773

Reaction No. 67251



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:-7.739(4SF)	7	MSL	6346
2	15.3	0	Inf. Dilution	lgK:-7.837(4SF)	7	MSL	6346
3	25	0	Inf. Dilution	lgK:-7.91(3SF)	3	CRV	6232
4	25	0	Inf. Dilution	lgK:-7.91(0.02SD)	4	MGL	6346
5	25	0	Inf. Dilution	lgK:-7.77(3SF)	4	ENS	7694
6	25	0	Inf. Dilution	lgK:-7.73(3SF)	4	CRV	32224
7	25			lgK:-7.91(3SF)	0	ENS	5181
8	25.1	0	Inf. Dilution	lgK:-7.902(4SF)	7	MSL	6346
9	35	0	Inf. Dilution	lgK:-8.021(4SF)	7	MSL	6346
10	45	0	Inf. Dilution	lgK:-8.127(4SF)	7	MSL	6346

11	55	0	Inf. Dilution	lgK:-8.232 (4SF)	7	MSL	6346
12	65	0	Inf. Dilution	lgK:-8.364 (4SF)	7	MSL	6346
13	80	0	Inf. Dilution	lgK:-8.570 (4SF)	7	MSL	6346
14	90	0	Inf. Dilution	lgK:-8.690 (4SF)	7	MSL	6346

Reaction No. 67298							
Ca+2_Oxalic-2_H2O_(s) = Ca+2 + Oxalic-2 + H2O							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	9	0	Inf. Dilution	lgK:-8.860 (4SF)	3	EOD	6467
2	15	0	Inf. Dilution	lgK:-8.92 (3SF)	4	MSL	6463
3	15	0	Inf. Dilution	lgK:-8.81 (3SF)	3	MSL	6464
4	15	0.15	NaCl	lgK:-8.917 (4SF)	0	MSL	31717
5	20	0	Inf. Dilution	lgK:-8.84 (0.02SD)	6	EES	9253
Note (5): Estimated by EK							
6	25	0	Inf. Dilution	lgK:-7.71 (3SF)	0	CRV	
Note (6): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
7	25	0	Inf. Dilution	lgK:-8.63 (3SF)	3	CRV	6330
Note (7): p. 8-58							
8	25	0	Inf. Dilution	lgK:-8.78 (3SF)	4	MSL	6463
9	25	0	Inf. Dilution	lgK:-8.70 (3SF)	4	MSL	6464
10	25	0	Inf. Dilution	lgK:-8.77 (0.01SD)	6	MSL	6466
11	25	0	Inf. Dilution	lgK:-8.699 (4SF)	3	EOD	6467
12	25	0	Inf. Dilution	lgK:-8.77 (0.01SD)	6	EES	9253
Note (12): Estimated by EK							
13	25	0	Inf. Dilution	lgK:-8.730 (0.03SD)	5	CRV	20830
14	25	0	Inf. Dilution	lgK:-8.65 (3SF)	3	EOD	23272
15	25	0	Inf. Dilution	lgK:-8.67 (3SF)	3	MSL	24712
16	25	0	Inf. Dilution	lgK:-8.7 (2SF)	3	EOD	29070
17	25	0	Inf. Dilution/m	lgK:-8.64 (3SF)	3	EOD	6366
18	25	0.15	NaCl	lgK:-8.780 (4SF)	0	MSL	31717
19	25	0.5	Me4NC1	lgK:-7.58 (0.08SD)	2	MSL	26686
20	25	1	NaCl	lgK:-7.07 (0.05SD)	2	MSL	26686
21	25	1	NaClO4	lgK:-7.35 (0.1SD)	3	MSL	26686
22	30	0	Inf. Dilution	lgK:-8.656 (4SF)	3	EOD	6467
23	30	0	Inf. Dilution	lgK:-8.71 (0.01SD)	6	EES	9253
Note (23): Estimated by EK							

24	35	0	Inf. Dilution	lgK:-8.61 (3SF)	4	MSL	6464
25	37	0	Inf. Dilution	lgK:-8.69 (3SF)	4	MSL	6463
26	37	0	Inf. Dilution	lgK:-8.7 (0.03SD)	3	MSL	6466
27	37	0	Inf. Dilution	lgK:-8.600 (4SF)	3	EOD	6467
28	37	0	Inf. Dilution	lgK:-8.55 (3SF)	3	MSL	6468
29	37	0	Inf. Dilution	lgK:-8.65 (3SF)	4	MSL	6469
30	37	0	Inf. Dilution	lgK:-8.65 (0.03SD)	6	EES	9253
Note (30): Estimated by EK							
31	37	0	Inf. Dilution	lgK:-8.642 (4SF)	4	CRV	26737
32	37	0.03	KCl	lgK:-8.01 (3SF)	0	MSL	6468
33	37	0.05	KCl	lgK:-7.92 (3SF)	3	MSL	6468
34	37	0.1	KCl	lgK:-7.75 (3SF)	4	MSL	6468
35	37	0.15	NaCl	lgK:-8.658 (4SF)	0	MSL	31717
36	37	0.2	KCl	lgK:-7.59 (3SF)	4	MSL	6468
37	37	0.3	KCl	lgK:-7.53 (3SF)	3	MSL	6468
38	37	0.35	Unknown	lgK:-7.43 (3SF)	3	EOD	29777
39	37	0.5	KCl	lgK:-7.51 (3SF)	0	MSL	6468
40	38	0	Inf. Dilution	lgK:-8.62 (3SF)	3	CRV	8692
41	40	0	Inf. Dilution	lgK:-8.62 (0.02SD)	6	MSL	6466
42	40	0	Inf. Dilution	lgK:-8.62 (0.02SD)	6	EES	9253
Note (42): Estimated by EK							
43	45	0	Inf. Dilution	lgK:-8.55 (3SF)	4	MSL	6464
44	45	0	Inf. Dilution	lgK:-8.545 (4SF)	3	EOD	6467
45	50	0	Inf. Dilution	lgK:-8.57 (3SF)	3	MSL	6463
46	50	0.15	NaCl	lgK:-8.572 (4SF)	0	MSL	31717
47	25	0	Inf. Dilution	dH:20.8 (0.8SD) kJ	4	EOD	17594
Note (47): Konigsberger E & Wolf G, unpublished							
48	25	0	Inf. Dilution	dH:19.8 (1.2SD) kJ	4	EOD	17594
Note (48): Sohnle et al., Thermochim Acta, 1997, 306, 7							
49	25	0	Inf. Dilution	dH:21.500 (0.25SD) kJ	4	CRV	20830
50	25	0	Inf. Dilution/m	dH:5.09 (3SF)	3	EOD	6366
51	37	0	Inf. Dilution	dH:16.7 (0.6SD) kJ	2	EOD	17594
Note (51): Sohnle et al., Thermochim Acta, 1997, 306, 7							

Reaction No. 67299

Ca+2_Oxalic-2_H2O(2)_(s) = Ca+2 + Oxalic-2 + 2<H2O>


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:-8.49(3SF)	3	MSL	6461
2	20	0	Inf. Dilution	lgK:-8.42(0.02SD)	6	EES	9253
Note (2): Estimated by EK							
3	25	0	Inf. Dilution	lgK:-8.38(3SF)	3	MSL	6461
4	25	0	Inf. Dilution	lgK:-8.34(0.02SD)	3	MSL	6466
5	25	0	Inf. Dilution	lgK:-8.34(0.02SD)	6	EES	9253
Note (5): Estimated by EK							
6	25	0	Inf. Dilution	lgK:-8.30(0.03SD)	5	CRV	20830
7	30	0	Inf. Dilution	lgK:-8.26(0.03SD)	6	EES	9253
Note (7): Estimated by EK							
8	37	0	Inf. Dilution	lgK:-8.32(3SF)	3	MSL	6461
9	37	0	Inf. Dilution	lgK:-8.2(0.03SD)	3	MSL	6466
10	37	0	Inf. Dilution	lgK:-8.17(0.03SD)	6	EES	9253
Note (10): Estimated by EK							
11	37	0	Inf. Dilution	lgK:-8.305(4SF)	4	CRV	26737
12	37	0.35	Unknown	lgK:-7.06(3SF)	3	EOD	29777
13	40	0	Inf. Dilution	lgK:-8.1(0.04SD)	3	MSL	6466
14	40	0	Inf. Dilution	lgK:-8.13(0.04SD)	6	EES	9253
Note (14): Estimated by EK							
15	50	0	Inf. Dilution	lgK:-8.20(3SF)	0	MSL	6461
16	25	0	Inf. Dilution	dH:24.3(1.4SD) kJ	4	EOD	17594
Note (16): Streit, PhD Thesis, Univ. Pardubice							
17	25	0	Inf. Dilution	dH:25.200(0.55SD) kJ	5	CRV	20830

Reaction No. 67300							
Oxalic-2 + 2<Ca+2> = Ca+2(2)_Oxalic-2							
Note: This dinuclear calcium-oxalate species should be treated with suspicion; it derives from Finlayson alone, it seems.							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	Inert	lgK:5.4(2SF)	0	ELC	
2	37	0	Inf. Dilution	lgK:5.29(3SF)	0	CRV	28703
3	38	0	Inf. Dilution	lgK:5.29(3SF)	0	MSL	6475

Reaction No. 67306							
Ca+2_Uric-1(2)_H2O(6)_s = Ca+2 + 2<Uric-1> + 6<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	15	0	Inf. Dilution	lgK:-10.12(4SF)	5	MSL	6476
2	25	0	Inf. Dilution	lgK:-9.81(3SF)	5	MSL	6476
3	37	0	Inf. Dilution	lgK:-9.28(3SF)	5	MSL	6476
4	45	0	Inf. Dilution	lgK:-9.01(3SF)	5	MSL	6476

Reaction No. 67395



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-3373.(4SF) kJ	5	CRV	8739
2	25	0	Inf. Dilution/m	dG:-3372.6(5SF) kJ	3	EPZ	9073
3	25	0	Inf. Dilution	dH:-3834.40(6SF) kJ	5	CRV	8739

Reaction No. 67402



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:378.6(4SF)	3	ENS	6494
2	27	0	Inf. Dilution	lgK:376.1(4SF)	0	ENS	6494
3	127	0	Inf. Dilution	lgK:275.0(4SF)	2	ENS	6494
4	227	0	Inf. Dilution	lgK:214.3(4SF)	1	ENS	6494
5	327	0	Inf. Dilution	lgK:173.9(4SF)	0	ENS	6494
6	25	0	Inf. Dilution	dG:-516.82(5SF)	3	EFE	6482
7	25	0	Inf. Dilution	dG:-516.6(4SF)	3	EFE	6494
8	25	0	Inf. Dilution	dG:-2172.(4SF) kJ	0	CRV	8739
9	25	0	Inf. Dilution	dG:-2161.7(5SF) kJ	3	CRV	24235
10	25	0	Inf. Dilution	dG:-2161.50(6SF) kJ	3	CRV	25435
11	25	0	GAMSPATH	dG:-2167.(4SF) kJ	2	CRV	12638
12	25	0	Inf. Dilution/m	dG:-2161.6(5SF) kJ	3	EPZ	9073
13	25	0	Inf. Dilution	dH:-555.75(5SF)	3	EFE	6482
14	25	0	Inf. Dilution	dH:-555.6(4SF)	3	MTD	6494
15	25	0	Inf. Dilution	dH:-2334.80(6SF) kJ	0	CRV	8739
16	25	0	Inf. Dilution	dH:-2324.5(5SF) kJ	3	CRV	24235
17	25	0	Inf. Dilution	dH:-2324.60(6SF) kJ	3	CRV	25435
18	25	0	GAMSPATH	dH:-2329.90(6SF) kJ	2	CRV	12638
19	127	0	Inf. Dilution	dH:-555.3(4SF)	2	MTD	6494
20	227	0	Inf. Dilution	dH:-554.8(4SF)	1	MTD	6494
21	327	0	Inf. Dilution	dH:-554.2(4SF)	0	MTD	6494


Reaction No. 67412							
$2\text{Al(s)} + 2\text{Ca(s)} + \text{H}_2\text{(g)} + 4\text{O}_2\text{(g)} + \text{Si(s)} = \text{Ca}_2\text{Al}_2\text{SiO}_6\text{(OH)}_2\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:713.6(4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:708.9(4SF)	4	ENS	6494
3	127	0	Inf. Dilution	lgK:519.9(4SF)	4	ENS	6494
4	227	0	Inf. Dilution	lgK:406.5(4SF)	4	ENS	6494
5	327	0	Inf. Dilution	lgK:330.9(4SF)	4	ENS	6494
6	25	0	Inf. Dilution	dG:-973.5(4SF)	4	EFE	6494
7	25	0	Inf. Dilution	dH:-1038.(4SF)	4	MTD	6494
8	127	0	Inf. Dilution	dH:-1038.(4SF)	4	MTD	6494
9	227	0	Inf. Dilution	dH:-1038.(4SF)	4	MTD	6494
10	327	0	Inf. Dilution	dH:-1037.(4SF)	4	MTD	6494

Reaction No. 67413							
$2\text{Al(s)} + \text{Ca(s)} + 4\text{O}_2\text{(g)} + 2\text{Si(s)} = \text{CaO}.\text{Al}_2\text{O}_3.2\text{SiO}_2\text{(glass,s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:691.7(4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:687.2(4SF)	4	ENS	6494
3	127	0	Inf. Dilution	lgK:506.0(4SF)	4	ENS	6494
4	227	0	Inf. Dilution	lgK:397.3(4SF)	4	ENS	6494
5	327	0	Inf. Dilution	lgK:324.8(4SF)	4	ENS	6494
6	25	0	Inf. Dilution	dG:-943.7(4SF)	4	EFE	6494
7	25	0	Inf. Dilution	dH:-995.0(4SF)	4	MTD	6494
8	127	0	Inf. Dilution	dH:-995.2(4SF)	4	MTD	6494
9	227	0	Inf. Dilution	dH:-994.9(4SF)	4	MTD	6494
10	327	0	Inf. Dilution	dH:-994.4(4SF)	4	MTD	6494

Reaction No. 67415							
$\text{Ca(s)} + \text{Mg(s)} + 3\text{O}_2\text{(g)} + 2\text{Si(s)} = \text{CaO}.\text{MgO}.2\text{SiO}_2\text{(glass,s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:523.5(4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:520.1(4SF)	4	ENS	6494
3	127	0	Inf. Dilution	lgK:382.7(4SF)	4	ENS	6494
4	227	0	Inf. Dilution	lgK:300.3(4SF)	4	ENS	6494
5	327	0	Inf. Dilution	lgK:245.4(4SF)	4	ENS	6494


6	25	0	Inf. Dilution	dG:-714.2 (4SF)	4	EFE	6494
7	25	0	Inf. Dilution	dH:-754.3 (4SF)	4	MTD	6494
8	127	0	Inf. Dilution	dH:-754.3 (4SF)	4	MTD	6494
9	227	0	Inf. Dilution	dH:-754.0 (4SF)	4	MTD	6494
10	327	0	Inf. Dilution	dH:-753.5 (4SF)	4	MTD	6494

Reaction No. 67416



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:267.5 (4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:265.8 (4SF)	4	ENS	6494
3	127	0	Inf. Dilution	lgK:195.7 (4SF)	4	ENS	6494
4	227	0	Inf. Dilution	lgK:153.7 (4SF)	4	ENS	6494
5	327	0	Inf. Dilution	lgK:125.7 (4SF)	4	ENS	6494
6	25	0	Inf. Dilution	dG:-364.9 (4SF)	4	EFE	6494
7	25	0	Inf. Dilution	dH:-384.5 (4SF)	4	MTD	6494
8	127	0	Inf. Dilution	dH:-384.4 (4SF)	4	MTD	6494
9	227	0	Inf. Dilution	dH:-384.3 (4SF)	4	MTD	6494
10	327	0	Inf. Dilution	dH:-384.1 (4SF)	4	MTD	6494

Reaction No. 67418



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1054. (4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:1047. (4SF)	0	ENS	6494
3	127	0	Inf. Dilution	lgK:769.3 (4SF)	4	ENS	6494
4	227	0	Inf. Dilution	lgK:603.0 (4SF)	4	ENS	6494
5	327	0	Inf. Dilution	lgK:492.2 (4SF)	4	ENS	6494
6	25	0	Inf. Dilution	dG:-1437. (4SF)	4	EFE	6494
7	25	0	Inf. Dilution	dH:-1523. (4SF)	4	MTD	6494
8	127	0	Inf. Dilution	dH:-1522. (4SF)	4	MTD	6494
9	227	0	Inf. Dilution	dH:-1521. (4SF)	4	MTD	6494
10	327	0	Inf. Dilution	dH:-1520. (4SF)	4	MTD	6494


Reaction No. 67419



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:855.3(4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:849.7(4SF)	4	ENS	6494
3	127	0	Inf. Dilution	lgK:623.4(4SF)	4	ENS	6494
4	227	0	Inf. Dilution	lgK:487.7(4SF)	4	ENS	6494
5	327	0	Inf. Dilution	lgK:397.2(4SF)	4	ENS	6494
6	25	0	Inf. Dilution	dG:-1167.(4SF)	4	EFE	6494
7	25	0	Inf. Dilution	dH:-1242.(4SF)	4	MTD	6494
8	127	0	Inf. Dilution	dH:-1243.(4SF)	4	MTD	6494
9	227	0	Inf. Dilution	dH:-1242.(4SF)	4	MTD	6494
10	327	0	Inf. Dilution	dH:-1242.(4SF)	4	MTD	6494

Reaction No. 67420



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:602.1(4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:598.1(4SF)	4	ENS	6494
3	127	0	Inf. Dilution	lgK:437.5(4SF)	4	ENS	6494
4	227	0	Inf. Dilution	lgK:341.1(4SF)	4	ENS	6494
5	327	0	Inf. Dilution	lgK:277.0(4SF)	4	ENS	6494
6	25	0	Inf. Dilution	dG:-821.5(4SF)	4	EFE	6494
7	25	0	Inf. Dilution	dH:-882.6(4SF)	4	MTD	6494
8	127	0	Inf. Dilution	dH:-881.8(4SF)	4	MTD	6494
9	227	0	Inf. Dilution	dH:-880.9(4SF)	4	MTD	6494
10	327	0	Inf. Dilution	dH:-879.8(4SF)	4	MTD	6494

Reaction No. 67421



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:406.1(4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:403.4(4SF)	0	ENS	6494
3	127	0	Inf. Dilution	lgK:295.6(4SF)	3	ENS	6494
4	227	0	Inf. Dilution	lgK:230.8(4SF)	2	ENS	6494
5	327	0	Inf. Dilution	lgK:187.7(4SF)	0	ENS	6494
6	25	0	Inf. Dilution	dG:-554.0(4SF)	4	EFE	6494
7	25	0	Inf. Dilution	dH:-592.2(4SF)	4	MTD	6494
8	127	0	Inf. Dilution	dH:-592.4(4SF)	3	MTD	6494


9	227	0	Inf. Dilution	dH:-592.3(4SF)	2	MTD	6494
10	327	0	Inf. Dilution	dH:-592.0(4SF)	0	MTD	6494

Reaction No. 67427							
5<Ca(s)> + 0.5<H2(g)> + 6.5<O2(g)> + 3<P(s)> = Ca+2(5)_OH-1_PO4-3(3)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1110.0(5SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:1110.(4SF)	0	ENS	6494
3	27	0	Inf. Dilution	lgK:1103.(4SF)	0	ENS	6494
4	127	0	Inf. Dilution	lgK:809.6(4SF)	0	ENS	6494
5	227	0	Inf. Dilution	lgK:633.5(4SF)	0	ENS	6494
6	327	0	Inf. Dilution	lgK:516.3(4SF)	0	ENS	6494
7	25	0	Inf. Dilution	dG:-1515.(4SF)	0	EFE	6494
8	25	0	Inf. Dilution	dG:-6337.1(5SF)kJ	0	EOD	12843
9	25	0	Inf. Dilution	dG:-6310.5(5SF)kJ	0	MSL	31745
10	25	0	Inf. Dilution	dH:-1610.(4SF)	0	MTD	6494
11	25	0	Inf. Dilution	dH:-6738.5(5SF)kJ	0	EOD	12843
12	25	0	Inf. Dilution	dH:-6699.5(5SF)kJ	0	MTD	22282
Note (12): -13399/2 abstract							
13	127	0	Inf. Dilution	dH:-1611.(4SF)	0	MTD	6494
14	227	0	Inf. Dilution	dH:-1610.(4SF)	0	MTD	6494
15	327	0	Inf. Dilution	dH:-1609.(4SF)	0	MTD	6494

Reaction No. 67428							
5<Ca(s)> + 0.5<F2(g)> + 6<O2(g)> + 3<P(s)> = Ca+2(5)_F-1_PO4-3(3)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1133.(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:1136.(4SF)	0	ENS	6494
3	27	0	Inf. Dilution	lgK:1130.(4SF)	0	ENS	6494
4	127	0	Inf. Dilution	lgK:830.3(4SF)	0	ENS	6494
5	227	0	Inf. Dilution	lgK:650.8(4SF)	0	ENS	6494
6	327	0	Inf. Dilution	lgK:531.2(4SF)	0	ENS	6494
7	25	0	Inf. Dilution	dG:-1551.(4SF)	0	EFE	6494
8	25	0	Inf. Dilution	dG:-6489.7(5SF)kJ	0	EOD	12843
9	25	0	Inf. Dilution	dH:-1642.(4SF)	4	MTD	6494
10	25	0	Inf. Dilution	dH:-6872.0(5SF)kJ	3	EOD	12843


11	127	0	Inf. Dilution	dH:-1643.(4SF)	2	MTD	6494
12	227	0	Inf. Dilution	dH:-1642.(4SF)	1	MTD	6494
13	327	0	Inf. Dilution	dH:-1641.(4SF)	0	MTD	6494

Reaction No. 67432




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1137.(4SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-1552.7(5SF)	0	EFE	6482
3	25	0	GAMSPATH	dG:-6484.(4SF) kJ	0	CRV	12638
4	25	0	Inf. Dilution	dH:-1647.9(5SF)	2	EFE	6482
5	25	0	GAMSPATH	dH:-6879.40(6SF) kJ	0	CRV	12638

Reaction No. 67741




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:8.4(0.05SD)	5	MGL	6515

Reaction No. 67742




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.61(3SF)	5	MGL	6515

Reaction No. 67743




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:10.72(4SF)	5	MGL	6515

Reaction No. 67744



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:9.59(3SF)	5	MGL	6515


Reaction No. 67791



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0	Inf. Dilution	lgK:1.65(3SF)	4	MCN	1926


2	30		Propan-2-ol	lgK:2.92 (3SF)	4	MCN	1926
---	----	--	-------------	----------------	---	-----	------

Reaction No. 68073




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:12.51 (0.02SD)	5	ENS	7168

Reaction No. 68074




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:16. (0.2SD)	5	ENS	7168

Reaction No. 68119



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:3.55 (0.05MD)	5	MPT	6937

Reaction No. 68208



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Dioxan:Water 70:30Vol KNO3	lgK:3.61 (3SF)	5	MGL	6908
2	30	0	Dioxan:Water 70:30Vol Inf. Dilution	lgK:9.40 (3SF)	5	MGL	6908
3	30	0.05	Dioxan:Water 70:30Vol KNO3	lgK:5.91 (3SF)	5	MGL	6908
4	30	0.1	Dioxan:Water 70:30Vol KNO3	lgK:4.42 (3SF)	5	MGL	6908
5	30	0.15	Dioxan:Water 70:30Vol KNO3	lgK:3.25 (3SF)	5	MGL	6908
6	40	0.1	Dioxan:Water 70:30Vol KNO3	lgK:5.16 (3SF)	5	MGL	6908
7	30	0.1	Dioxan:Water 70:30Vol KNO3	dH:-32.95 (4SF)	5	MTD	6908

Reaction No. 68233

Ca+2 + H+1_Glyphosate-3 = Ca+2_H+1_Glyphosate-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.04 (3SF)	5	MIS	6882

Reaction No. 68234							
Ca+2_H+1_Glyphosate-3_(s) = Ca+2 + H+1_Glyphosate-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:-5.32 (3SF)	5	MIS	6882

Reaction No. 68312							
1AmEtPhos-2 + Ca+2 = Ca+2_1AmEtPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:1.43 (0.01SD)	5	MGL	6868

Reaction No. 68313							
Ca+2 + H+1_1AmEtPhos-2 = Ca+2_H+1_1AmEtPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:1.02 (0.02SD)	5	MGL	6868

Reaction No. 68322							
Ca+2 + H+1_2AmEtPhos-2 = Ca+2_H+1_2AmEtPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:1.09 (0.02SD)	5	MGL	6868


Reaction No. 68343							
H+1 + Glyphosate-3 + Ca+2 = Ca+2_H+1_Glyphosate-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:11.48 (0.02SD)	5	MGL	6861
2	25	0.1	Many Media	lgK:11.5 (0.1SD)	6	CIU	7242

Reaction No. 68791							
Ca+2_H+1_Purpur-3 + H+1 = Ca+2_H+1(2)_Purpur-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:8.2 (2SF)	5	MGL	6759

Reaction No. 69172							
[12]N4:Acet*3-3 + Ca+2 = Ca+2_[12]N4:Acet*3-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0.1	Me4NC1	lgK:11.74 (0.02SD)	5	MGL	4891
---	----	-----	--------	--------------------	---	-----	------

Reaction No. 69182




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NC1	lgK:14.8 (0.09SD)	5	MGL	4891

Reaction No. 69807




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0	Inf. Dilution	lgK:1.59 (3SF)	4	MCN	1926

Reaction No. 69810




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Propan-2-ol	lgK:2.75 (3SF)	3	MCN	1926

Reaction No. 69853




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.05	NaCl	lgK:5.13 (3SF)	5	MCE	2343
2	20	0.1	NaCl	lgK:4.59 (3SF)	5	MCE	2343
3	20	0.15	NaCl	lgK:4.31 (3SF)	5	MCE	2343
4	20	0.2	NaCl	lgK:4.11 (3SF)	5	MCE	2343

Reaction No. 69854



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.05	NaCl	lgK:5.79 (3SF)	5	MCE	2343
2	20	0.1	NaCl	lgK:5.18 (3SF)	5	MCE	2343
3	20	0.15	NaCl	lgK:4.84 (3SF)	5	MCE	2343
4	20	0.2	NaCl	lgK:4.62 (3SF)	5	MCE	2343


Reaction No. 69965



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.70 (3SF)	4	MPT	386


2	25	0	Inf. Dilution	lgK:2.66 (3SF)	4	MSL	389
---	----	---	---------------	----------------	---	-----	-----

Reaction No. 69973




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1361. (4SF) kJ	5	CRV	8739
2	25	0	Inf. Dilution	dH:-1498.00 (6SF) kJ	5	CRV	8739

Reaction No. 69974




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:446.2 (4SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-2542. (4SF) kJ	0	CRV	8739
3	25	0	Inf. Dilution	dH:-2971.70 (6SF) kJ	3	CRV	8739

Reaction No. 69975




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1126. (4SF) kJ	5	CRV	8739
2	25	0	Inf. Dilution	dH:-1204.00 (6SF) kJ	5	CRV	8739

Reaction No. 69976



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:125.8 (4SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-716.3 (4SF) kJ	0	CRV	8739
3	25	0	Inf. Dilution	dG:-717.02 (5SF) kJ	0	EOD	23101
4	25	0	Inf. Dilution	dG:-717.020 (6SF) kJ	0	CRV	23205
5	25	0	Inf. Dilution	dG:-717.020 (6SF) kJ	0	EOD	23205
6	25	0	Inf. Dilution	dH:-764.65 (5SF) kJ	2	CRV	8739
7	25	0	Inf. Dilution	dH:-751.65 (5SF) kJ	0	EOD	23101

Reaction No. 71141



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:-3.80 (3SF)	4	CRV	6330
2	25	0	Inf. Dilution	E:-3.80 (3SF)	4	CRV	22519

Reaction No. 71186							
$\text{Ca}^{+2} + \text{H}_2(\text{g}) + 2\text{e}^{-1} = \text{CaH}_2(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: -72.7(3\text{SF})$	1	EOR	
2	25	3	Inert	$\lg K: -79.0(3\text{SF})$	1	EOR	
3	25	0	Inf. Dilution	$E: -2.105(4\text{SF})$	0	CRV	7761
4	25	0	Inf. Dilution	$\text{dH}: 356.7(4\text{SF}) \text{ kJ}$	3	CRV	7761

Reaction No. 71187							
$\text{Ca}^{+2}_{\text{OH}-1} + \text{H}^{+1} + 2\text{e}^{-1} = \text{Ca}(\text{s}) + \text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: -84.2(3\text{SF})$	1	ELC	
2	25	0	Inf. Dilution	$E: -2.488(4\text{SF})$	0	CRV	7761
3	25	0	Inf. Dilution	$\text{dH}: 477.2(4\text{SF}) \text{ kJ}$	2	CRV	7761

Reaction No. 71222							
$3\text{Ca}(\text{s}) + 2\text{P}(\text{s}) + 4\text{O}_2(\text{g}) = \text{Ca}_3(\text{PO}_4)_2(\alpha, \text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 675.2(4\text{SF})$	1	ELC	
2	25	0	Inf. Dilution	$\text{dG}: -3884.7(5\text{SF}) \text{ kJ}$	0	CRV	6330
3	25	0	Inf. Dilution	$\text{dH}: -4120.8(5\text{SF}) \text{ kJ}$	0	CRV	6330

Reaction No. 71568							
$\text{PMEDAP-2} + \text{Ca}^{+2} = \text{Ca}^{+2}_{\text{PMEDAP-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO_3	$\lg K: 1.67(0.04\text{MD}) \text{ w}$	5	MPH	8309

Reaction No. 71569							
$\text{Ca}^{+2} + \text{H}^{+1}_{\text{PMEDAP-2}} = \text{Ca}^{+2}_{\text{H}^{+1}_{\text{PMEDAP-2}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO_3	$\lg K: 0.4(0.3\text{MD}) \text{ w}$	5	MPH	8309

Reaction No. 71588							
$\text{Barbital-1} + \text{Ca}^{+2} = \text{Ca}^{+2}_{\text{Barbital-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	$\lg K: 0.7(1\text{SF})$	5	CRV	7271

Reaction No. 71720							
$\text{Ca}+2_ \text{CO}3-2_ \text{H}2\text{O}(6)_ (\text{s}) = \text{Ca}+2 + \text{CO}3-2 + 6<\text{H}2\text{O}>$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:-7.244 (4SF)	3	MSL	2269
2	25	0	Inf. Dilution	lgK:-7.46 (3SF)	3	MSL	2269
3	25	0	Inf. Dilution	lgK:-6.62 (3SF)	0	CRV	6232
4	40	0	Inf. Dilution	lgK:-7.72 (3SF)	3	MSL	2269

Reaction No. 71741							
$2<\text{C}(\text{s})> + \text{Ca}(\text{s}) + \text{Mg}(\text{s}) + 3<\text{O}2(\text{g})> = \text{Ca}+2_ \text{Mg}+2_ \text{CO}3-2(2)_ (\text{disord.}, \text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2157.10 (6SF) kJ	4	CRV	23205
2	25	0	Inf. Dilution	dG:-2157.10 (6SF) kJ	3	EOD	23205
3	25	0	GAMSPATH	dG:-2158. (4SF) kJ	2	CRV	12638
4	25	0	GAMSPATH	dH:-2317.60 (6SF) kJ	2	CRV	12638

Reaction No. 71769							
$\text{C}(\text{s}) + \text{Ca}(\text{s}) + 1.5<\text{O}2(\text{g})> = \text{Ca}+2_ \text{CO}3-2$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1099. (4SF) kJ	2	CRV	8739
2	25	0	Inf. Dilution	dG:-262.85 (5SF)	4	CRV	10174
3	25	0	Inf. Dilution	dG:-1099.20 (6SF) kJ	3	EOD	23101
4	25	0	Inf. Dilution	dG:-262.70 (5SF)	3	EPZ	23185
5	25	0	Inf. Dilution	dG:-1099.20 (6SF) kJ	4	CRV	23205
6	25	0	Inf. Dilution	dG:-1099.20 (6SF) kJ	3	EOD	23205
7	25	0	Inf. Dilution	dG:-1099.8 (5SF) kJ	4	EOD	29025
8	25	0	GAMSPATH	dG:-1099. (4SF) kJ	2	CRV	12638
9	25	0	Inf. Dilution/m	dG:-1081.40 (6SF) kJ	0	CRV	24953
10	50	0	Inf. Dilution	dG:-262.89 (5SF)	1	CRV	10174
11	75	0	Inf. Dilution	dG:-262.89 (5SF)	0	CRV	10174
12	100	0	Inf. Dilution	dG:-262.86 (5SF)	0	CRV	10174
13	125	0	Inf. Dilution	dG:-262.81 (5SF)	1	CRV	10174
14	150	0	Inf. Dilution	dG:-262.74 (5SF)	1	CRV	10174
15	175	0	Inf. Dilution	dG:-262.66 (5SF)	4	CRV	10174
16	200	0	Inf. Dilution	dG:-262.56 (5SF)	1	CRV	10174
17	225	0	Inf. Dilution	dG:-262.44 (5SF)	0	CRV	10174

18	250	0	Inf. Dilution	dG:-262.32 (5SF)	0	CRV	10174
19	300	0	Inf. Dilution	dG:-262.05 (5SF)	0	CRV	10174
20	25	0	Inf. Dilution	dH:-1203.00 (6SF) kJ	5	CRV	8739
21	25	0	Inf. Dilution	dH:-1201.90 (6SF) kJ	3	EOD	23101
22	25	0	Inf. Dilution	dH:-1202.4 (5SF) kJ	4	EOD	29025
23	25	0	GAMSPATH	dH:-1207.0 (5SF) kJ	0	CRV	12638
24	25	0	Inf. Dilution/m	dH:-1220.00 (6SF) kJ	0	CRV	24953
25	25	0	Inf. Dilution	Cp:-29.6 (3SF)	3	EOD	23185
Note (25): Sverjensky et al. [97SSH_6495]							
26	25	0	Inf. Dilution	Cp:5.22 (3SF)	0	EPZ	23185
27	25	0	Inf. Dilution	Cp:-123.8 (4SF) J/K	4	EOD	29025

Reaction No. 71770							
Ca(s) + 2CO ₂ (g) + S(s) = Ca+2_SO4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-312.93 (5SF)	3	CRV	10174
2	25	0	Inf. Dilution	dG:-1310.40 (6SF) kJ	0	EOD	23101
3	25	0	GAMSPATH	dG:-1311. (4SF) kJ	0	CRV	12638
4	50	0	Inf. Dilution	dG:-313.03 (5SF)	0	CRV	10174
5	75	0	Inf. Dilution	dG:-313.10 (5SF)	0	CRV	10174
6	100	0	Inf. Dilution	dG:-313.14 (5SF)	0	CRV	10174
7	125	0	Inf. Dilution	dG:-313.16 (5SF)	0	CRV	10174
8	150	0	Inf. Dilution	dG:-313.17 (5SF)	0	CRV	10174
9	175	0	Inf. Dilution	dG:-313.15 (5SF)	0	CRV	10174
10	200	0	Inf. Dilution	dG:-313.13 (5SF)	0	CRV	10174
11	225	0	Inf. Dilution	dG:-313.09 (5SF)	0	CRV	10174
12	250	0	Inf. Dilution	dG:-313.03 (5SF)	0	CRV	10174
13	300	0	Inf. Dilution	dG:-312.89 (5SF)	0	CRV	10174
14	25	0	Inf. Dilution	dH:-1448.40 (6SF) kJ	3	EOD	23101
15	25	0	GAMSPATH	dH:-1444.90 (6SF) kJ	0	CRV	12638

Reaction No. 71868							
Ca+2_CO3-2_(Calc.,s) + H+1 = H+1_CO3-2 + Ca+2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0	Inf. Dilution	lgK:2.2 (2SF)	5	CRV	6496
2	10	0	Inf. Dilution	lgK:2.13 (3SF)	5	CRV	6496

3	15	0	Inf. Dilution	lgK:2.06(3SF)	5	CRV	6496
4	20	0	Inf. Dilution	lgK:1.99(3SF)	5	CRV	6496
5	25	0	Inf. Dilution	lgK:1.91(3SF)	5	CRV	6496
6	25	3	Inert	lgK:2.3(2SF)	2	EOR	
7	40	0	Inf. Dilution	lgK:1.69(3SF)	5	CRV	6496

Reaction No. 71869							
Ca+2_CO3-2_(Calc.,s) + Mg+2_CO3-2_(s) = Ca+2_Mg+2_CO3-2(2)_(disord.,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.08(1SF)	3	CRV	6405
2	100	0	Inf. Dilution	lgK:-1.4(2SF)	1	EOR	

Reaction No. 71875							
CaO.Al2O3.2SiO2(s) + 2<H+1> + H2O = Al2Si2O5(OH)4(Kaol.,s) + Ca+2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.3(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:19.66(4SF)	0	CRV	6405

Reaction No. 71878							
CaO.(Al2O3)7.(SiO2)22.6H2O(s) + 2<H+1> + 23<H2O> = 7<Al2Si2O5(OH)4(Kaol.,s)> + 8<H+1(2)_SiH2O4-2> + Ca+2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-13.3(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-15.4(3SF)	0	CRV	6405
Note (2): p. 246 - comment re inconsistency with Stumm & Morgan data							

Reaction No. 71952							
Ca+2 + Ca+2_Oxalic-2 = Ca+2(2)_Oxalic-2							
Note: This dinuclear calcium-oxalate species should be treated with suspicion; it derives from Finlayson alone, it seems.							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.85(3SF)	0	EAE	
2	38	0	Inf. Dilution	lgK:1.85(3SF)	0	CRV	8692
Note (2): Eqm. reaction not clear							
3	38	0	Inf. Dilution	lgK:1.85(3SF)	0	EOD	16641
Note (3): Finlayson et. al, Proc. Renal Stone Symp., 1972 (well def. eqm.)							
4	38	0	Inf. Dilution	lgK:1.85(3SF)	0	MSL	26858

Reaction No. 72395							
Ca+2_CO3-2_(Arag.,s) = Ca+2_CO3-2_(Calc.,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0.3	Ca+2 salt	dG:-0.743 (3SF) kJ	7	MHY	9058
2	5	0.6	Ca+2 salt	dG:-0.753 (3SF) kJ	7	MHY	9058
3	5	0.9	Ca+2 salt	dG:-0.753 (3SF) kJ	7	MHY	9058
4	15	0.3	Ca+2 salt	dG:-0.791 (3SF) kJ	7	MHY	9058
5	15	0.6	Ca+2 salt	dG:-0.791 (3SF) kJ	7	MHY	9058
6	15	0.6	Ca+2 salt	dG:-0.801 (3SF) kJ	7	MHY	9058
7	25	0	Inf. Dilution	dG:-1.730 (4SF) kJ	0	MPT	9059
Note (7): ?Inf. Dil. (Data cited otherwise by Konigsberger et al, GCA,89,53,2807)							
8	25	0.3:1.2	Ca+2 salt	dG:-0.830 (0.020SD) kJ	7	MHY	9058
9	25	0.3	Ca+2 salt	dG:-0.830 (3SF) kJ	7	MHY	9058
10	25	0.6	Ca+2 salt	dG:-0.810 (3SF) kJ	7	MHY	9058
11	25	0.9	Ca+2 salt	dG:-0.830 (3SF) kJ	7	MHY	9058
12	25	1.2	Ca+2 salt	dG:-0.820 (3SF) kJ	7	MHY	9058
13	35	0.3	Ca+2 salt	dG:-0.888 (3SF) kJ	7	MHY	9058
14	35	0.6	Ca+2 salt	dG:-0.868 (3SF) kJ	7	MHY	9058
15	35	0.6	Ca+2 salt	dG:-0.888 (3SF) kJ	7	MHY	9058
16	45	0.3	Ca+2 salt	dG:-0.926 (3SF) kJ	7	MHY	9058
17	45	0.6	Ca+2 salt	dG:-0.926 (3SF) kJ	7	MHY	9058
18	45	0.6	Ca+2 salt	dG:-0.946 (3SF) kJ	7	MHY	9058
19	45	0.9	Ca+2 salt	dG:-0.946 (3SF) kJ	7	MHY	9058
20	25	0.3:1.2	Ca+2 salt	dH:0.540 (0.060SD) kJ	7	MTD	9058

Reaction No. 72439							
Ca+2_SO3-2_H2O(0.5)_ (s) + SO2(g) + 0.5<H2O> = Ca+2 + 2<H+1_SO3-2>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.5 (1SF)	1	EOR	
2	25	1	NaClO4/m	lgK:0.09 (1SF)	3	MSL	330
3	25	3.5	NaClO4/m	lgK:-0.52 (2SF)	3	MSL	330
4	35	1	NaClO4/m	lgK:-0.26 (2SF)	3	MSL	330
5	35	3.5	NaClO4/m	lgK:-0.91 (2SF)	3	MSL	330
6	75	1	NaClO4/m	lgK:-1.30 (3SF)	3	MSL	330
7	75	3.5	NaClO4/m	lgK:-1.89 (3SF)	3	MSL	330

Reaction No. 72440							
Ca+2_CO3-2_(Calc.,s) + CO2(g) + H2O = Ca+2 + 2<H+1_CO3-2>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-5.9(2SF)	1	ELC	
2	25	1	NaClO4/m	lgK:-4.91(3SF)	0	MSL	330
3	25	3.5	NaClO4/m	lgK:-5.50(3SF)	0	MSL	330
4	35	1	NaClO4/m	lgK:-5.10(3SF)	0	MSL	330
5	35	3.5	NaClO4/m	lgK:-5.80(3SF)	0	MSL	330
6	75	1	NaClO4/m	lgK:-5.56(3SF)	5	MSL	330
7	75	3.5	NaClO4/m	lgK:-6.49(3SF)	5	MSL	330

Reaction No. 72446							
Ca+2_SO4-2 + SO4-2 = Ca+2_SO4-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:0.18(2SF)	4	MDG	8675
2	25	0	Inf. Dilution	lgK:0.18(2SF)	4	MDG	8675

Reaction No. 72498							
2<Cl-1> + Ca+2 = Ca+2_Cl-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	200	0	P=300 Inf. Dilution	lgK:0.672(3SF)	0	EOD	29559
2	25	0	Inf. Dilution	lgK:-0.644(3SF)	0	EOD	29559
3	150	0	HCl/m	lgK:0.24(0.01SD)	0	MSL	12189
4	200	0	HCl/m	lgK:0.94(0.01SD)	0	MSL	12189
5	250	0	HCl/m	lgK:2.48(0.01SD)	0	MSL	12189
6	300	0	Inf. Dilution/m	lgK:1.49(3SF)	0	MCL	12628
7	305	0	HCl/m	lgK:3.48(0.01SD)	0	MSL	12189
8	360	0	HCl/m	lgK:4.70(0.05SD)	0	MSL	12189
9	300	0	Inf. Dilution/m	dH:241.(3SF)kJ	0	MCL	12628

Reaction No. 72571							
123BenzTriCOO-3 + Ca+2 = Ca+2_123BenzTriCOO-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Et4NI	lgK:4.28(0.03MD)	4	MPT	5773

Reaction No. 72572							
--------------------	--	--	--	--	--	--	--

H+1 + 123BenzTriCOO-3 + Ca+2 = Ca+2_H+1_123BenzTriCOO-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Et4NI	lgK:9.35 (0.02MD)	4	MPT	5773

Reaction No. 72573							
2<H+1> + 123BenzTriCOO-3 + Ca+2 = Ca+2_H+1(2)_123BenzTriCOO-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Et4NI	lgK:13.05 (0.02MD)	4	MPT	5773

Reaction No. 72574							
123BenzTriCOO-3 + 2<Ca+2> = Ca+2(2)_123BenzTriCOO-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Et4NI	lgK:6.57 (0.06MD)	4	MPT	5773

Reaction No. 72858							
oCresol-1 + Ca+2 = Ca+2_oCresol-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.04 (0.05MD)	4	MGL	5989

Reaction No. 72862							
pCresol-1 + Ca+2 = Ca+2_pCresol-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.03 (0.05MD)	5	MGL	5989

Reaction No. 72866							
2NitrPhenol-1 + Ca+2 = Ca+2_2NitrPhenol-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.95 (0.05MD)	5	MGL	5989

Reaction No. 72870							
4NitrPhenol-1 + Ca+2 = Ca+2_4NitrPhenol-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.95 (0.04MD)	5	MGL	5989

Reaction No. 72901							
Ca+2_5ATP-4 + BisTris = Ca+2_BisTris_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:1.85 (0.09SD)	5	MGL	6089

Reaction No. 72938							
$\text{Ca}^{+2}\text{Se-2}_{(s)} = \text{Ca}^{+2} + \text{Se-2}$							
Note: The Se-2 species probably does not exist [18Mar_30641]							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.87(4SF)	2	ENS	12931

Reaction No. 72945							
$\text{Ca}^{+2}\text{SeO3-2}_{(s)} = \text{Ca}^{+2} + \text{SeO3-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18	0.01	Unknown	lgK:-5.74(0.12SD)	2	MSL	12931
2	20	0	Inf. Dilution	lgK:-5.53(0.15SD)	2	MSL	12931
3	25	0	Inf. Dilution	lgK:-7.65(3SF)	2	ENS	12931

Reaction No. 72956							
$\text{Ca}^{+2}\text{SeO3-2}_{\text{H2O}(2)}_{(s)} = \text{Ca}^{+2} + \text{SeO3-2} + 2\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-5.44(3SF)	0	ENS	12931
2	25	0	Inf. Dilution	lgK:-7.76(0.18SD)	4	ENS	12931
3	25	0	Inf. Dilution	lgK:-7.06(0.22SD)	3	EOD	32222
4	25	0	Inf. Dilution	lgK:-5.46(3SF)	0	CRV	32224


Reaction No. 72968							
$\text{Ca}^{+2}\text{SeO4-2}_{\text{H2O}(2)}_{(s)} = \text{Ca}^{+2} + \text{SeO4-2} + 2\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-3.09(3SF)	4	MCL	12931

Reaction No. 72984							
$\text{Ca}^{+2}\text{SeO4-2} = \text{Ca}^{+2} + \text{SeO4-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.00(3SF)	3	EOD	32222
2	25	0	NaNO3	lgK:-2.0(2SF)	4	MPT	12931
3	25	0	Inf. Dilution	dH:16.314(5SF) kJ	3	EOD	32222

Reaction No. 73021							
$\text{Ca}^{+2}\text{5CTP-4} + \text{H}^{+1} = \text{Ca}^{+2}\text{H}^{+1}\text{5CTP-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0.1	NaNO3	lgK:4.91(0.14SD)	5	MGL	6100
---	----	-----	-------	------------------	---	-----	------

Reaction No. 73029




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:5.25(0.045SD)	5	MGL	6100

Reaction No. 73143




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.50(0.10SD)	4	MGL	6124
2	25	0.04	Unknown	lgK:3.37(0.10SD)	5	MGL	6124
3	25	0.09	Unknown	lgK:3.08(0.10SD)	5	MGL	6124
4	25	0.25	Unknown	lgK:2.80(0.10SD)	5	MGL	6124
5	25	0.49	Unknown	lgK:2.83(0.10SD)	5	MGL	6124
6	25	0.64	Unknown	lgK:2.91(0.10SD)	5	MGL	6124
7	25	1	Unknown	lgK:3.17(0.10SD)	5	MGL	6124

Reaction No. 73144



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.55(0.08SD)	4	MGL	6124
2	25	0.04	Unknown	lgK:9.14(0.08SD)	5	MGL	6124
3	25	0.09	Unknown	lgK:8.77(0.08SD)	5	MGL	6124
4	25	0.25	Unknown	lgK:8.45(0.08SD)	5	MGL	6124
5	25	0.49	Unknown	lgK:8.49(0.08SD)	5	MGL	6124
6	25	0.64	Unknown	lgK:8.61(0.08SD)	5	MGL	6124
7	25	1	Unknown	lgK:8.96(0.08SD)	5	MGL	6124


Reaction No. 73145



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.80(0.04SD)	4	MGL	6124
2	25	0.04	Unknown	lgK:14.26(0.04SD)	5	MGL	6124
3	25	0.09	Unknown	lgK:13.85(0.04SD)	5	MGL	6124
4	25	0.25	Unknown	lgK:13.51(0.04SD)	5	MGL	6124
5	25	0.49	Unknown	lgK:13.58(0.04SD)	5	MGL	6124


6	25	0.64	Unknown	lgK:13.72 (0.04SD)	5	MGL	6124
7	25	1	Unknown	lgK:14.13 (0.04SD)	5	MGL	6124

Reaction No. 73146




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.45 (0.06SD)	4	MGL	6124
2	25	0.04	Unknown	lgK:17.92 (0.06SD)	5	MGL	6124
3	25	0.09	Unknown	lgK:17.52 (0.06SD)	5	MGL	6124
4	25	0.25	Unknown	lgK:17.19 (0.06SD)	5	MGL	6124
5	25	0.49	Unknown	lgK:17.28 (0.06SD)	5	MGL	6124
6	25	0.64	Unknown	lgK:17.44 (0.06SD)	5	MGL	6124
7	25	1	Unknown	lgK:17.88 (0.06SD)	5	MGL	6124

Reaction No. 73147



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.74 (0.05SD)	4	MGL	6124
2	25	0.04	Unknown	lgK:6.05 (0.05SD)	5	MGL	6124
3	25	0.09	Unknown	lgK:5.60 (0.05SD)	5	MGL	6124
4	25	0.25	Unknown	lgK:5.20 (0.05SD)	5	MGL	6124
5	25	0.49	Unknown	lgK:5.25 (0.05SD)	5	MGL	6124
6	25	0.64	Unknown	lgK:5.38 (0.05SD)	5	MGL	6124
7	25	1	Unknown	lgK:5.79 (0.05SD)	5	MGL	6124

Reaction No. 73148



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.23 (0.10SD)	4	MGL	6124
2	25	0.04	Unknown	lgK:11.55 (0.10SD)	5	MGL	6124
3	25	0.09	Unknown	lgK:11.11 (0.10SD)	5	MGL	6124
4	25	0.25	Unknown	lgK:10.73 (0.10SD)	5	MGL	6124
5	25	0.49	Unknown	lgK:10.80 (0.10SD)	5	MGL	6124
6	25	0.64	Unknown	lgK:10.95 (0.10SD)	5	MGL	6124
7	25	1	Unknown	lgK:11.38 (0.10SD)	5	MGL	6124

Reaction No. 73149

Bu1234TetrCOO-4 + Ca+2 + Na+1 = Ca+2_Na+1_Bu1234TetrCOO-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.7(0.15SD)	4	MGL	6124
2	25	0.04	Unknown	lgK:4.2(0.15SD)	5	MGL	6124
3	25	0.09	Unknown	lgK:3.9(0.15SD)	5	MGL	6124
4	25	0.25	Unknown	lgK:3.5(0.15SD)	5	MGL	6124
5	25	0.49	Unknown	lgK:3.6(0.15SD)	5	MGL	6124
6	25	0.64	Unknown	lgK:3.7(0.15SD)	5	MGL	6124
7	25	1	Unknown	lgK:4.1(0.15SD)	5	MGL	6124

Reaction No. 73150							
H+1 + Bu1234TetrCOO-4 + Ca+2 + Na+1 = Ca+2_H+1_Na+1_Bu1234TetrCOO-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.2(0.2SD)	4	MGL	6124
2	25	0.04	Unknown	lgK:9.7(0.2SD)	5	MGL	6124
3	25	0.09	Unknown	lgK:9.3(0.2SD)	5	MGL	6124
4	25	0.25	Unknown	lgK:8.9(0.2SD)	5	MGL	6124
5	25	0.49	Unknown	lgK:9.0(0.2SD)	5	MGL	6124
6	25	0.64	Unknown	lgK:9.1(0.2SD)	5	MGL	6124
7	25	1	Unknown	lgK:9.5(0.2SD)	5	MGL	6124

Reaction No. 73179							
H+1 + IDA-2 + Ca+2 = Ca+2_H+1_IDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.11(4SF)	4	MGL	6131
2	25	0	Inf. Dilution	dH:30.(2SF)kJ	4	MCL	6131

Reaction No. 73180							
2<H+1> + IDA-2 + Ca+2 = Ca+2_H+1(2)_IDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.85(4SF)	4	MGL	6131
2	25	0	Inf. Dilution	dH:35.(2SF)kJ	4	MCL	6131

Reaction No. 73191							
[18]N2O4:EtCOO*2-2 + Ca+2 = Ca+2_[18]N2O4:EtCOO*2-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KCl	lgK:7.10(3SF)	5	MGL	6135

Reaction No. 73328							
[18]O6:Benzo + Ca+2 = Ca+2_[18]O6:Benzo							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Acetone	lgK:6.05(3SF)	3	MCL	3005
2	25		Acetone	dH:-40.7(3SF) kJ	3	MCL	3005

Reaction No. 73331							
Hexaglyme + Ca+2 = Ca+2_Hexaglyme							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Acetone	lgK:2.43(3SF)	3	MCL	3005
2	25		Acetone	dH:-44.7(3SF) kJ	3	MCL	3005

Reaction No. 73335							
[24]O8 + Ca+2 = Ca+2_[24]O8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:2.66(3SF)	3	MGL	2924

Reaction No. 73396							
Clodronic-4 + Ca+2 = Ca+2_Clodronic-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:5.83(0.08SD)	7	CIU	7242

Reaction No. 73397							
Ca+2 + H+1_Clodronic-4 = Ca+2_H+1_Clodronic-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:3.12(0.05SD)	7	CIU	7242

Reaction No. 73398							
Ca+2_Clodronic-4 + Ca+2 = Ca+2(2)_Clodronic-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:3.3(0.3SD)	6	CIU	7242

Reaction No. 73562							
Ca+2 + H+1_Oxonic-3 = Ca+2_H+1_Oxonic-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	Inf. Dilution	lgK:2.96(0.11SD)	4	MPH	1853

Reaction No. 73571							
Ca+2 + H+1(2)_Oxonic-3 = Ca+2_H+1(2)_Oxonic-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	Inf. Dilution	lgK:1.81(0.20SD)	4	MPH	1853

Reaction No. 73654							
Ca+2 + 2<H+1> + BIDPAP = Ca+2_H+1(2)_BIDPAP							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:19.636(0.034SD)	7	MGL	20878

Reaction No. 73655							
Ca+2 + H+1 + BIDPAP = Ca+2_H+1_BIDPAP							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:10.808(0.116SD)	7	MGL	20878

Reaction No. 73656							
Ca+2 + BIDPAP = Ca+2_BIDPAP							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:2.424(0.046SD)	7	MGL	20878

Reaction No. 73657							
Ca+2 + BIDPAP = Ca+2_BIDPAP-1 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:-8.857(0.052SD)	7	MGL	20878

Reaction No. 74014							
Ca+2_H+1(4)_PO4-3(2)_(s) = Ca+2 + 2<H+1(2)_PO4-3>							
Note: Not precipitated from aqueous solution [20NVM_31761]							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-3.0(2SF)	0	CRV	22551
2	25	0	Inf. Dilution	lgK:-1.14(3SF)	4	EOD	31761

Reaction No. 74335							
Ca+2 + 2<H+1(2)_PO4-3> = Ca+2_H+1_PO4-3 + H+1(3)_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.372(4SF)	1	ELC	
2	25	3	NaClO4	lgK:-3.612(4SF)	0	MGL	6142

Reaction No. 74336							
$\text{Ca}+2 + 3\text{H}+1(2)\text{PO}_4-3 = \text{Ca}+2\text{H}+1(3)\text{PO}_4-3(2) + \text{H}+1(3)\text{PO}_4-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.4515(4SF)	1	ELC	
2	25	3	NaClO4	lgK:-2.982(4SF)	0	MGL	6142

Reaction No. 74337							
$\text{Ca}+2 + 2\text{H}+1(2)\text{PO}_4-3 = \text{Ca}+2\text{H}+1(4)\text{PO}_4-3(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.69(3SF)	3	MGL	6170
2	25	0	Inf. Dilution/m	lgK:1.36(0.1MD)	3	EDH	6142
3	25	3	NaClO4	lgK:0.336(3SF)	3	MGL	6142
4	25	3	NaClO4	lgK:0.67(2SF)	3	MSL	6170

Reaction No. 74338							
$\text{Ca}+2 + \text{H}+1\text{PO}_4-3 + \text{H}+1(2)\text{PO}_4-3 = \text{Ca}+2\text{H}+1(3)\text{PO}_4-3(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.563(0.05MD)	1	ELC	


Reaction No. 74597							
$2\text{Ca}(s) + 6\text{O}_2(g) + 3\text{Si}(s) + \text{Zr}(s) = \text{Ca}_2\text{ZrSi}_3\text{O}_{12}(s)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-5951.5(15.0MD)kJ	6	CRV	20829
2	25	0	Inf. Dilution	dH:-6283.0(15.0MD)kJ	6	CRV	20829
3	25	0	Inf. Dilution	Cp:252.500(2.5MD)J/K	6	CRV	20829

Reaction No. 74598							
$3\text{Ca}(s) + 4.5\text{O}_2(g) + 2\text{Si}(s) + \text{Zr}(s) = \text{Ca}_3\text{ZrSi}_2\text{O}_9(s)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-4769.3(10.0MD)kJ	6	CRV	20829
2	25	0	Inf. Dilution	dH:-5029.0(10.0MD)kJ	6	CRV	20829
3	25	0	Inf. Dilution	Cp:238.100(1.5MD)J/K	6	CRV	20829

Reaction No. 74667							
$\text{Ca}+2(3)\text{Citric-3}(2)\text{H}_2\text{O}(4)(s) = 3\text{Ca}+2 + 2\text{Citric-3} + 4\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-17.900(0.05SD)	6	CRV	20830


2	25	0.1:3.5	NaClO ₄ /m	lgK:-17.81(4SF)	0	MGL	22656
---	----	---------	-----------------------	-----------------	---	-----	-------

Reaction No. 74668




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.79(3SF)	4	MGL	22560

Reaction No. 74760




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO ₃	lgK:8.24(3SF)	4	MGL	1187

Reaction No. 74761




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO ₃	lgK:3.63(3SF)	4	MGL	1187

Reaction No. 74783




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	NaCl	lgK:1.15(3SF)	4	MGL	21108

Reaction No. 74784




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.8(2SF)	1	EES	
2	25	0.1	NaClO ₄	lgK:4.35(3SF)	3	MGL	3180

Reaction No. 74847



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.2(2SF)	1	ELC	
2	37	0.15	Inert	lgK:7.90(3SF)	4	CRV	29801
3	37	0.15	KCl	lgK:7.90(3SF)	3	MGL	6468

Reaction No. 74931



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

Reaction No. 75164							
$\text{Ca(s)} + 6\text{O}_2(\text{g}) + 2\text{P(s)} + 2\text{U(s)} = \text{Ca}_2\text{UO}_2\text{2(2)}_{\text{PO}_4\text{-3(2)}}(\text{s})$							
Note: Langmuir [78Lan_13532] give 'Autunite' without H ₂ O; this might be problematic for this dG(formation) reaction							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1135.(4SF)	5	EOD	13532
2	25	0	Inf. Dilution	dH:-1213.(4SF)	5	EOD	13532

Reaction No. 75171							
$\text{Ca(s)} + 6\text{O}_2(\text{g}) + 2\text{U(s)} + 2\text{V(s)} = \text{Ca}_2\text{UO}_2\text{2(2)}_{\text{VO}_4\text{-3(2)}}(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1090.(4SF)	5	EOD	13532
2	25	0	Inf. Dilution	dH:-1164.(4SF)	5	EOD	13532

Reaction No. 75172							
$\text{Ca(s)} + \text{H}_2(\text{g}) + 6\text{O}_2(\text{g}) + 2\text{Si(s)} + 2\text{U(s)} = \text{Ca(UO}_2\text{)}_2\text{(SiO}_4\text{H)}_2(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1189.(4SF)	5	EOD	13532

Reaction No. 75217							
$\text{Ba}_2(0.5)_{\text{Ca}_2(0.5)}\text{SO}_4\text{-2(s)} = 0.5\text{Ba}_2 + 0.5\text{Ca}_2 + \text{SO}_4\text{-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-7.41(3SF)	0	EOD	23102
Note (1): Source refers to this as a 'solid solution'							

Reaction No. 75218							
$\text{Ca}_2(4)_{\text{Cd}_2}\text{OH-1}_{\text{PO}_4\text{-3(3)}}(\text{s}) + \text{H}_2\text{O} = 4\text{Ca}_2 + \text{Cd}_2 + 3\text{PO}_4\text{-3} + \text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-39.23(4SF)	3	EOD	23102

Reaction No. 75219							
$\text{Ca}_6\text{Al}_2\text{SO}_4\text{*3OH*12.26H}_2\text{O(s)} = 6\text{Ca}_2 + 2\text{Al}_3\text{OH-1(4)} + 3\text{SO}_4\text{-2} + 4\text{OH-1} + 26\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0	Inf. Dilution	lgK:-47.3(3SF)	4	MSL	8775
2	25	0	Inf. Dilution	lgK:-44.7(3SF)	3	MSL	8775
3	25	0	Inf. Dilution	lgK:-44.9(3SF)	3	MSL	8775
Note (3): Value in text appears to differ slightly from Eqn in Figure							

4	25	0	Inf. Dilution	lgK:-44.9(3SF)	3	EOD	23102
5	25	0	Inf. Dilution	lgK:-44.9(3SF)	5	CRV	31308
6	50	0	Inf. Dilution	lgK:-41.9(3SF)	4	MSL	8775
7	75	0	Inf. Dilution	lgK:-39.6(3SF)	4	MSL	8775

Reaction No. 75220							
$\text{CaAl}_2\text{Si}_4\text{O}_{12} \cdot 2\text{H}_2\text{O}(\text{s}) + 8\text{H}^+ + 2\text{H}_2\text{O} = \text{Ca}^{2+} + 2\text{Al}^{3+} + 4\text{H}_2\text{SiO}_4^{2-}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.87(4SF)	0	EOD	23102
2	25	0	Inf. Dilution	lgK:14.42(4SF)	3	CRV	27383
3	25	0	Inf. Dilution	lgK:18.68(4SF)	0	CRV	32224

Reaction No. 75221							
$\text{Ca}^{2+} \text{Zn}^{2+}(\text{2})_{\text{OH}-1(6)} \text{H}_2\text{O}(\text{2})_{\text{(s)}} + 6\text{H}^+ = \text{Ca}^{2+} + 2\text{Zn}^{2+} + 8\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:43.9(3SF)	3	MSL	
Note (1): Ziegler & Johnson, Cement Concrete Res., 2001, 31, 1327							
2	25	0	Inf. Dilution	lgK:43.9(3SF)	3	EOD	23102

Reaction No. 75225							
$\text{Al}^{3+}(\text{2})_{\text{Ca}^{2+}(\text{4})_{\text{Cl}-1(2)}_{\text{OH}-1(12)}_{\text{H}_2\text{O}(\text{4})_{\text{(s)}}} = 4\text{Ca}^{2+} + 2\text{Al}^{3+}_{\text{OH}-1(4)} + 2\text{Cl}^{-1} + 4\text{OH}^{-1} + 4\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-28.(2SF)	1	MSL	23099
Note (1): Value within the range $-28.8 < \lg K < -27.6$							
2	25	0	Inf. Dilution	lgK:-27.27(4SF)	5	CRV	31308

Reaction No. 75246							
$\text{H}^+ + \text{SeO}_4^{2-} + \text{Ca}^{2+} = \text{Ca}^{2+} \text{H}^+ \text{SeO}_4^{2-}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaClO ₄	lgK:3.93(0.08SD)	5	MGL	23134
2	25	0	Inf. Dilution	lgK:4.83(3SF)	2	EAE	

Reaction No. 75269							
$\text{UO}_2^{2+} + \text{Ca}^{2+} + 3\text{CO}_3^{2-} = \text{Ca}^{2+} \text{UO}_2^{2+} \text{CO}_3^{2-}(\text{3})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:27.18(4SF)	5	EOD	23204
2	25	0	Inf. Dilution	lgK:25.4(0.25SD)	0	EOD	27392

3	25	0	Inf. Dilution	lgK:26.93(0.25SD)	2	EOD	27392
4	25	0	Inf. Dilution	lgK:27.27(0.14SD)	3	EOD	27392
5	25	0	Inf. Dilution	lgK:26.93(4SF)	2	EOD	29484
6	25	0	Inf. Dilution	lgK:27.18(4SF)	2	EOD	29484
7	25	0	Inf. Dilution	lgK:27.27(0.14SD)	3	EOD	30627
8	25	0	Inf. Dilution	lgK:27.18(4SF)	5	CRV	31231
9	25	0	Inf. Dilution	dH:0.0(1SF)kJ	2	EOD	23204

Reaction No. 75270							
UO2+2 + 2<Ca+2> + 3<CO3-2> = Ca+2(2)_UO2+2_CO3-2(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:30.7(3SF)	5	EOD	23204
2	25	0	Inf. Dilution	lgK:30.79(0.29SD)	0	EOD	27392
3	25	0	Inf. Dilution	lgK:29.81(0.19SD)	1	EOD	27392
4	25	0	Inf. Dilution	lgK:29.4(0.7SD)	0	EOD	27392
5	25	0	Inf. Dilution	lgK:29.8(0.7SD)	0	EOD	27392
6	25	0	Inf. Dilution	lgK:30.55(0.25SD)	2	EOD	27392
7	25	0	Inf. Dilution	lgK:30.7(3SF)	2	EOD	29484
8	25	0	Inf. Dilution	lgK:30.79(4SF)	2	EOD	29484
9	25	0	Inf. Dilution	lgK:29.81(0.19SD)	1	EOD	30627
10	25	0	Inf. Dilution	lgK:30.6(3SF)	5	CRV	31231
11	25	0	Inf. Dilution	dH:0.0(1SF)kJ	2	EOD	23204


Reaction No. 75308							
2<PO4-3> + 2<Ca+2> + 2<H+1> = Ca+2(2)_H+1(2)_PO4-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:32.9(3SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:16.3(3SF)	0	CRV	22388

Reaction No. 75317							
2<Malic-2> + Ca+2 + H+1 = Ca+2_H+1_Malic-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.36(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:7.856(4SF)	5	CRV	22388

Reaction No. 75327							
Tartaric-2 + 2<Ca+2> = Ca+2(2)_Tartaric-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:3.661(4SF)	5	CRV	22388

Reaction No. 75332




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.5(3SF)	5	CRV	22388

Reaction No. 75359




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.7(2SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:3.549(4SF)	5	CRV	22388

Reaction No. 75360




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.3(2SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:9.005(4SF)	5	CRV	22388

Reaction No. 75361




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.0(2SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:3.798(4SF)	5	CRV	22388

Reaction No. 75368



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:7.468(4SF)	5	CRV	22388

Reaction No. 75369



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:3.068(4SF)	5	CRV	22388

Reaction No. 75370

1GlycerolOPO3-2 + Ca+2 + H2O = Ca+2_OH-1_1GlycerolOPO3-2 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:-6.667 (4SF)	5	CRV	22388

Reaction No. 75376							
2GlycerolOPO3-2 + Ca+2 = Ca+2_2GlycerolOPO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:2.144 (4SF)	5	CRV	22388

Reaction No. 75377							
2GlycerolOPO3-2 + Ca+2 + H+1 = Ca+2_H+1_2GlycerolOPO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:8.045 (4SF)	5	CRV	22388

Reaction No. 75378							
2<2GlycerolOPO3-2> + Ca+2 = Ca+2_2GlycerolOPO3-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:3.738 (4SF)	5	CRV	22388

Reaction No. 75379							
2<2GlycerolOPO3-2> + Ca+2 + H+1 = Ca+2_H+1_2GlycerolOPO3-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:9.846 (4SF)	5	CRV	22388

Reaction No. 75380							
2GlycerolOPO3-2 + Ca+2 + H2O = Ca+2_OH-1_2GlycerolOPO3-2 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:-7.423 (4SF)	5	CRV	22388

Reaction No. 75390							
EtMalon-2 + Ca+2 + H+1 = Ca+2_H+1_EtMalon-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:6.304 (4SF)	5	CRV	22388

Reaction No. 75391							
2<EtMalon-2> + Ca+2 = Ca+2_EtMalon-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:2.835 (4SF)	5	CRV	22388

Reaction No. 75434							
$\text{Ca}+2(2)\text{_EDTMP-8} + \text{H}+1 = \text{Ca}+2(2)\text{_H}+1\text{_EDTMP-8}$							
Note: Weighted out coz its thermodynamically isolated; not nec. bad data							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:7.56(0.03SD)	0	MSP	23315

Reaction No. 75438							
$\text{Sm}+3\text{_EDTMP-8} + \text{Ca}+2 = \text{Sm}+3\text{_Ca}+2\text{_EDTMP-8}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:3.47(0.05SD)	5	MSP	23315

Reaction No. 75439							
$\text{Sm}+3\text{_Ca}+2\text{_EDTMP-8} + \text{H}+1 = \text{Sm}+3\text{_Ca}+2\text{_H}+1\text{_EDTMP-8}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:6.22(0.08SD)	5	MSP	23315

Reaction No. 75440							
$\text{Y}+3\text{_EDTMP-8} + \text{Ca}+2 = \text{Y}+3\text{_Ca}+2\text{_EDTMP-8}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:3.91(0.04SD)	5	MSP	23315

Reaction No. 75441							
$\text{Y}+3\text{_Ca}+2\text{_EDTMP-8} + \text{H}+1 = \text{Y}+3\text{_Ca}+2\text{_H}+1\text{_EDTMP-8}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:6.62(0.06SD)	5	MSP	23315

Reaction No. 75554							
$\text{Br}2(1) + \text{Ca}(s) + 6\text{H}2(g) + 3\text{O}2(g) = \text{Ca}+2\text{_Br-1}(2)\text{_H}2\text{O}(6)\text{_(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:377.0(4SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-2151.9(5SF)kJ	3	EOD	12955
Note (2): From Wagman							
3	25	0	Inf. Dilution	dG:-2152.8(5SF)kJ	0	CRV	24003
4	25	0	Inf. Dilution	dG:-2152.8(5SF)kJ	2	EOD	24807
Note (4): From Wagman et al., [82WEP_9015]							
5	25	0	Inf. Dilution	dG:-2150.80(6SF)kJ	3	EOD	24807

Note (5): From Mikulin, Vop. Fiz. Khim. Elec., Izd. Khim., 1968, p. 417							
6	25	0	Inf. Dilution	dG:-2151.90 (6SF) kJ	3	EOD	24807
Note (6): From "prev. studies"							
7	25	0	Inf. Dilution	dG:-2151.60 (6SF) kJ	5	EAC	24807
8	25	0	Inf. Dilution	dG:-2123.7 (5SF) kJ	0	CRV	29025
9	25	0	Inf. Dilution	dH:-2486.3 (5SF) kJ	1	CRV	29025

Reaction No. 75558							
Creatinine + Ca+2 = Ca+2_Creatinine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	Na+1 salt	lgK:0.0 (1SF)	1	MIX	108
Note (1): Looks very unreliable							

Reaction No. 75633							
1.7<Al(s)> + 0.7<Ca(s)> + 0.3<Na(s)> + 4<O2(g)> + Si(s) = Plagioclase(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-3906.5 (5SF) kJ	5	CRV	25435
2	25	0	Inf. Dilution	dH:-4108.2 (5SF) kJ	5	CRV	25435

Reaction No. 75634							
0.35<Ca(s)> + 0.23<Fe(s)> + 0.42<Mg(s)> + 1.5<O2(g)> + Si(s) = Augite(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2835.3 (5SF) kJ	3	CRV	25435
2	25	0	Inf. Dilution	dH:-2888.5 (5SF) kJ	3	CRV	25435

Reaction No. 75823							
Ca+2_Asp-2 + Asp-2 = Ca+2_Asp-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.79 (3SF)	2	EAE	
2	37	0.15	NaClO4	lgK:2.72 (3SF)	1	MGL	2181

Reaction No. 75880							
Ca+2_Citric-3 + Citric-3 = Ca+2_Citric-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.949 (3SF)	2	EAE	
2	37	0.15	NaClO4	lgK:1.60 (3SF)	5	MGL	2181

Reaction No. 75909							
Ca+2_Lactic-1 + Lactic-1 = Ca+2_Lactic-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:0.70(2SF)	5	MIS	11516
Note (1): Masone M et al., Ann. Chim. (Rome), 1981, 71, 517							
2	25	1	Unknown	lgK:0.34(2SF)	5	MQH	11516
Note (2): Verbeek F et al., Anal. Chim. Acta, 1965, 33, 378							

Reaction No. 75929							
Ca+2_Oxalic-2 + Oxalic-2 = Ca+2_Oxalic-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.6(2SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:0.830(0.10SD)	3	CRV	20830
3	25	1	NaClO4	lgK:1.03(3SF)	5	MDS	11516
Note (3): Hasegawa Y et al., Bull. Chem. Soc. Jpn., 1967, 40, 1845							
4	25	1	NaNO3	lgK:1.35(3SF)	0	MVM	1720
5	38	0	Inf. Dilution	lgK:0.79(2SF)	2	EOD	16641
Note (5): Calculated from solubility data of Nydahl [51Nyd_24712]							

Reaction No. 75969							
Ca+2_CO3-2 + CO3-2 = Ca+2_CO3-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaCl	lgK:0.16(2SF)	5	MDS	11516
Note (1): Hasegawa Y et al., Bull. Chem. Soc. Jpn., 1970, 43, 1718							

Reaction No. 76096							
Ca+1 + Hyp-1 = Ca+1_Hyp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.0(2SF)	1	EES	

Reaction No. 76233							
Ca+2_Formic-1 + Formic-1 = Ca+2_Formic-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	2	NaClO4	lgK:0.63(2SF)	5	MVM	8310

Reaction No. 76328							
Ca+2_Gluconic-1 + Gluconic-1 = Ca+2_Gluconic-1(2)							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.48(3SF)	1	MGL	11516
Note (1): Heinz E, Biochem. J., 1951, 321, 314							
2	25	0.5	NaCl	lgK:0.83(2SF)	5	MIS	11516
Note (2): Masone M et al., Ann. Chim. (Rome), 1981, 71, 517							

Reaction No. 76378							
Ca+2 + Valeric-1 = Ca+2_Valeric-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.30(2SF)	5	MSL	7730

Reaction No. 76384							
Ca+2 + IValer-1 = Ca+2_IValer-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.20(2SF)	5	MSL	7730

Reaction No. 76424							
Ca+2 + DSorbitol = Ca+2_DSorbitol							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.7	KNO3	lgK:-0.52(2SF)	5	MIS	11516
Note (1): Haas J, Marine Chem., 1986, 19, 299							
2	36	0	Inf. Dilution	lgK:-0.22(2SF)	5	MMR	2805


Reaction No. 76426							
Ca+2 + DMannitol = Ca+2_DMannitol							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.7	KNO3	lgK:-0.62(2SF)	5	MIS	11516
Note (1): Haas J, Marine Chem., 1986, 19, 299							

Reaction No. 76427							
Ca+2 + pTol-1 = Ca+2_pTol-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.03	NaCl	lgK:1.27(3SF)	5	MIS	4503

Reaction No. 76502							
2<B(s)> + Ca(s) + 4<O2(g)> + 2<Si(s)> = CaB2Si2O8(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:644.2(4SF)	3	CRV	6494
2	25	0	Inf. Dilution	dG:-3677.0(5SF)kJ	3	CRV	6494
3	25	0	Inf. Dilution	dH:-3902.8(5SF)kJ	3	CRV	6494

Reaction No. 76503




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:980.7(4SF)	3	CRV	6494
2	25	0	Inf. Dilution	dG:-5597.6(5SF)kJ	3	CRV	6494
3	25	0	Inf. Dilution	dG:-5597.9(5.0SD)kJ	5	MCL	29317
4	25	0	Inf. Dilution	dH:-6049.0(5SF)kJ	3	CRV	6494
5	25	0	Inf. Dilution	dH:-6049.00(5.5SD)kJ	4	CRV	27383
6	25	0	Inf. Dilution	dH:-6049.0(5.0SD)kJ	5	CRV	29317

Reaction No. 76510




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.700(0.15SD)	5	CRV	20830

Reaction No. 76511




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-10.400(0.25SD)	4	CRV	20830

Reaction No. 76512




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.400(0.1SD)	4	CRV	20830

Reaction No. 76526



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.08(4SF)	5	CRV	26565

Reaction No. 76527



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0	Inf. Dilution	lgK:6.31(3SF)	5	CRV	26565
---	----	---	---------------	---------------	---	-----	-------


Reaction No. 76556							
Ca+2_Br-1(2)_(s) = Ca+2 + 2<Br-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.16(3SF)	0	CRV	
Note (1): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
2	25	0	Inf. Dilution	lgK:16.9(3SF)	0	ERG	
Note (2): Was lgK=16.0 prev iter							
3	25	0	Inf. Dilution	lgK:17.16(4SF)	4	CRV	32224

Reaction No. 76557							
Ca+2(3)_PO4-3(2)_(am.,s) = 3<Ca+2> + 2<PO4-3>							
Note: Form of solid is often unspecified but, with lgK0 < -29 is taken to refer to amorphous calcium phosphate Wide range of reported Ksps. (-26:-33 [20NVM_31761]) Precipitated pH = 5:12 when Ca/P = 1.2:2.2 [20NVM_31761]							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	19	0	Inf. Dilution	lgK:-28.70(4SF)	3	MSL	
Note (1): Zharovskii FG, Trudy Kom. Anal. Khim., Akad. Nauk SSSR, 1951, 3, 101							
2	25	0	Inf. Dilution	lgK:-26.0(3SF)	0	CRV	
Note (2): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
3	25	0	Inf. Dilution	lgK:-28.7(3SF)	2	EAE	
4	25	0	Inf. Dilution	lgK:-32.6(3SF)	0	CRV	6330
Note (4): p. 8-58							
5	25	0	Inf. Dilution	lgK:-28.9(3SF)	3	EOD	29070
6	25	0	Inf. Dilution	lgK:-25.46(4SF)	0	EOD	29583
Note (6): Citing Visual MINTEQ (Version 3.0, Royal Inst. Technol. (KTH)).							
7	25	0	Inf. Dilution	lgK:-25.2(3SF)	0	EOD	31694
Note (7): from Mayer & Eanes, 1978							
8	25	0	Inf. Dilution	lgK:-26.(2SF)	0	EOD	31761
9	25	0	Inf. Dilution	lgK:-33.(2SF)	0	EOD	31761
10	25	0	Inf. Dilution	lgK:-29.(2SF)	4	EOD	31761
11	37	0	Inf. Dilution	lgK:-31.8(3SF)	2	MSL	27777
12	42	0	Inf. Dilution	lgK:-32.1(3SF)	2	MSL	27777

Reaction No. 76585							
Ca+2_Cl-1(2)_H2O(6)_(s) = Ca+2 + 2<Cl-1> + 6<H2O>							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	lgK:4.108(4SF)	3	MSL	12955
2	25	0	Inf. Dilution	dH:-15.77(4SF)kJ	1	EOD	29284

Reaction No. 76586




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.727(4SF)	4	MSL	24807
2	25	0	Inf. Dilution	lgK:5.67(3SF)	3	EOD	24807
Note (2): "prev. study"							
3	25	0	Inf. Dilution	lgK:5.48(3SF)	4	CRV	32224
4	25	0	Inf. Dilution/m	lgK:5.668(4SF)	3	MSL	12955

Reaction No. 76587




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	lgK:5.715(4SF)	3	MSL	12955

Reaction No. 76588




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	lgK:15.035(5SF)	3	MSL	12955

Reaction No. 76589



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	lgK:10.597(5SF)	3	MSL	12955


Reaction No. 76628



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-5.3(2SF)	1	ELC	
2	25	0	Inf. Dilution/m	lgK:-3.24(3SF)	0	CRV	24953
3	50	0	Inf. Dilution/m	lgK:-3.74(3SF)	0	CRV	24953
4	75	0	Inf. Dilution/m	lgK:-3.79(3SF)	0	CRV	24953
5	100	0	Inf. Dilution/m	lgK:-3.87(3SF)	0	CRV	24953
6	150	0	Inf. Dilution/m	lgK:-4.08(3SF)	0	CRV	24953

7	200	0	Inf. Dilution/m	lgK:-4.35(3SF)	0	CRV	24953
8	250	0	Inf. Dilution/m	lgK:-4.64(3SF)	0	CRV	24953
9	300	0	Inf. Dilution/m	lgK:-4.94(3SF)	0	CRV	24953

Reaction No. 76658




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2215.4(5SF)kJ	3	EOD	12955
Note (1): From Wagman							
2	25	0	Inf. Dilution	dG:-2215.3(5SF)kJ	4	EOD	29025
3	25	0	Inf. Dilution/m	dG:-2215.30(6SF)kJ	3	EPZ	8833
4	25	0	Inf. Dilution	dH:-2607.9(5SF)kJ	4	EOD	29025
5	25	0	Inf. Dilution	Cp:323.2(4SF)J/K	4	EOD	29025

Reaction No. 76663




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	dG:-2597.0(5SF)kJ	4	EPZ	8833
2	25	0	Inf. Dilution/m	dG:-2596.6(5SF)kJ	3	EPZ	9073

Reaction No. 76667




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	dG:-4342.2(5SF)kJ	4	EPZ	8833
2	25	0	Inf. Dilution/m	dG:-4341.8(5SF)kJ	3	EPZ	9073

Reaction No. 76671



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	dG:-5659.0(5SF)kJ	4	EPZ	8833
2	25	0	Inf. Dilution/m	dG:-5658.2(5SF)kJ	3	EPZ	9073


Reaction No. 76673



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	dG:-2887.5(5SF)kJ	4	EPZ	8833
2	25	0	Inf. Dilution/m	dG:-2887.5(5SF)kJ	3	EPZ	9073


3	25	0	Inf. Dilution	dH:-3172.(4SF)kJ	5	CRV	31308
---	----	---	---------------	------------------	---	-----	-------

Reaction No. 76674



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	dG:-4997.3(5SF)kJ	4	EPZ	8833
2	25	0	Inf. Dilution/m	dG:-4997.3(5SF)kJ	3	EPZ	9073

Reaction No. 76675




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1731.9(5SF)kJ	3	EOD	12955

Note (1): From Wagman


2	25	0	Inf. Dilution	dG:-1732.0(5SF)kJ	4	EOD	29025
3	25	0	Inf. Dilution/m	dG:-1732.1(5SF)kJ	4	EPZ	9073
4	25	0	Inf. Dilution	dH:-2009.6(5SF)kJ	4	EOD	29025
5	25	0	Inf. Dilution	Cp:239.8(4SF)J/K	4	EOD	29025

Reaction No. 76676




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	dG:-6615.(4SF)kJ	1	EPZ	9073

Reaction No. 76677



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	dG:-1929.7(5SF)kJ	1	EPZ	9073


Reaction No. 76684



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2665.(4SF)	0	EDH	
2	25	0	Inf. Dilution	lgK:2667.(4SF)	1	ELC	
3	25	0	Inf. Dilution	dG:-1.5211E+4(18.5MD)kJ	0	MSL	8775
4	25	0	Inf. Dilution	dG:-1.5205E+4(5SF)kJ	0	CRV	31308
5	25	0	Inf. Dilution	dH:-1.7550E+4(12.MD)kJ	0	CRV	8775
6	25	0	Inf. Dilution	dH:-1.7535E+4(5SF)kJ	3	CRV	31308

7	25	0	Inf. Dilution	Cp:590.(143.MD)J/K	2	CRV	8775
---	----	---	---------------	--------------------	---	-----	------

Reaction No. 76712




Note: Query the stoichiometry of CaF(g)? Data for CaF(g) are carried through the NEA Critirical Reviews referencing [03GFF_20827] which cites several primary sources associated with UF6(g) processing

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-302.120(2.55SD)kJ	0	CRV	27292

Note (1): Refers to monovalent Ca in source; here only as a marker


Reaction No. 76713



Note: Query the stoichiometry of CaF(g)? Data are carried through the NEA Critirical Reviews referencing [03GFF_20827] which cites several primary sources associated with UF6(g) processing

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-302.120(2.55SD)kJ	1	CRV	27292
2	25	0	Inf. Dilution	dH:-276.400(2.55SD)kJ	1	CRV	27292
3	25	0	Inf. Dilution	Cp:33.671(0.25SD)J/K	1	CRV	27292


Reaction No. 76714



Note: Query the stoichiometry of CaCl(g) and CaF(g)? Data are carried through the NEA Critirical Reviews referencing [03GFF_20827] which cites several primary sources associated with UF6(g) processing


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-129.790(2.55SD)kJ	1	CRV	27292
2	25	0	Inf. Dilution	dH:-103.400(2.5SD)kJ	1	CRV	27292
3	25	0	Inf. Dilution	Cp:35.687(0.005SD)J/K	1	CRV	27292

Reaction No. 76767




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1806.(4SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-1.03050E+4(7.SD)kJ	0	CRV	20827

Reaction No. 76940




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:6.53 (3SF)	3	CRV	7271

Reaction No. 76941




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:7.16 (3SF)	3	CRV	7271

Reaction No. 76970




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:6.52 (3SF)	3	CRV	7271

Reaction No. 76971




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:7.82 (3SF)	3	CRV	7271

Reaction No. 77046




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:231.7 (4SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-1314.50 (6SF) kJ	0	CRV	29482
3	25	0	Inf. Dilution	dH:-1456.10 (6SF) kJ	2	CRV	29482

Reaction No. 77410




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-4. (1SF)	1	EES	

Reaction No. 77411



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2. (1SF)	1	EES	

Reaction No. 77434



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:189.2(4SF)	1	ELC	

Reaction No. 77435

$2\text{Fe}^{+3} + \text{Ca}^{+2} + 2\text{OH}^{-1} + 2\text{PO}_4^{-3} + 8\text{H}_2\text{O} = \text{Fe}_2(\text{OH})_2(\text{PO}_4)_3 \cdot 8\text{H}_2\text{O}(\text{s})$

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:81.3(3SF)	1	ELC	

Reaction No. 77642

$\text{S}^{-2} + \text{Ca}^{+2} = \text{CaS}(\text{s})$

Note: The species S-2 does not exist in aqueous solution See reaction: $\text{H}^{+1} + \text{S}^{-2} = \text{HS}^{-1}$

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.7542(4SF)	0	ELC	

Reaction No. 77658

$2\text{F}^{-1} + \text{Ca}^{+2} = \text{CaF}_2(\text{s})$

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.8455(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:5.70(3SF)	0	MSL	12941

Note (2): Unexpectedly high result from an unusual procedure

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
3	25	0	Inf. Dilution	lgK:5.7(2SF)	0	EOD	29891

Note (3): Taken uncritically from [00FoG_12941]

Reaction No. 77709

$4\text{H}^{+1} + \text{Ca}^{+2} + 2\text{AsO}_4^{-3} = \text{Ca}_2(\text{HAsO}_4)_4(\text{s})$

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:35.86(4SF)	1	ELC	

Reaction No. 77747

$2\text{H}^{+1} + 5\text{Ca}^{+2} + 4\text{AsO}_4^{-3} = \text{Ca}_5(\text{H}_2\text{AsO}_4)_4(\text{s})$

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:48.08(4SF)	1	ELC	


Reaction No. 77763

$\text{OH}^{-1} + 2\text{Ca}^{+2} + \text{AsO}_4^{-3} = \text{Ca}_2(\text{OH})\text{AsO}_4(\text{s})$

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:13.1(4SF)	1	ELC	
---	----	---	---------------	---------------	---	-----	--

Reaction No. 77774




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-3.509(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-3.76(3SF)	4	CRV	32224

Reaction No. 77782




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.5(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-2.81(3SF)	4	CRV	32224

Reaction No. 77783



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:40.24(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:40.26(4SF)	4	CRV	32224

Reaction No. 77791



Note: Freyer and Voigt [03FrV_17504] provide an excellent review on crystallization and phase stability of CaSO₄ systems, with emphasis on transition temperatures.

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.131(3SF)	1	ELC	
2	25	0	Inf. Dilution	dG:0.913(3SF)kJ	5	MCL	12436
3	30	0	Inf. Dilution	dG:0.643(3SF)kJ	5	MCL	12436
4	35	0	Inf. Dilution	dG:0.368(3SF)kJ	5	MCL	12436
5	40	0	Inf. Dilution	dG:0.087(2SF)kJ	5	MCL	12436
6	45	0	Inf. Dilution	dG:-0.198(3SF)kJ	5	MCL	12436
7	50	0	Inf. Dilution	dG:-0.489(3SF)kJ	5	MCL	12436
8	25	0	Inf. Dilution	dH:16.862(5SF)kJ	5	MCL	12436
9	30	0	Inf. Dilution	dH:17.183(5SF)kJ	5	MCL	12436
10	35	0	Inf. Dilution	dH:17.498(5SF)kJ	5	MCL	12436
11	40	0	Inf. Dilution	dH:17.809(5SF)kJ	5	MCL	12436
12	45	0	Inf. Dilution	dH:18.115(5SF)kJ	5	MCL	12436

13	50	0	Inf. Dilution	dH:18.416(5SF)kJ	5	MCL	12436
----	----	---	---------------	------------------	---	-----	-------

Reaction No. 77798							
2<NO3-1> + 4<H2O> + Ca+2 = Ca+2_NO3-1(2)_H2O(4)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.765(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-2.04(3SF)	4	CRV	32224

Reaction No. 77892							
2<OH-1> + 10<Ca+2> + 6<AsO4-3> = Ca+2(10)_OH-1(2)_AsO4-3(6)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:118.1(4SF)	1	ELC	

Reaction No. 77893							
5<NH3> + Ca+2 = Ca+2_NH3(5)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-3.086(4SF)	1	ELC	

Reaction No. 77897							
6<NH3> + Ca+2 = Ca+2_NH3(6)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-4.786(4SF)	1	ELC	


Reaction No. 78146							
Ca+2 + Tartaric-2 + H+1_PO4-3 = Ca+2_H+1_Tartaric-2_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.2(3SF)	1	EES	
2	25	0.1	NaClO4	lgK:9.69(3SF)	3	MGL	3180

Reaction No. 78483							
3<Oxalic-2> + Co+3 + Ca+2 = Co+3_Ca+2_Oxalic-2(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-8.922(4SF)	1	ELC	

Reaction No. 78521							
2<H+1> + 2<Oxalic-2> + Ca+2 = Ca+2_H+1(2)_Oxalic-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.0(4SF)	1	ELC	


2	37	0	Inf. Dilution	lgK:11.1(3SF)	2	CRV	28703
---	----	---	---------------	---------------	---	-----	-------

Reaction No. 78587




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.8(4SF)	1	ELC	

Reaction No. 78588




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.91(4SF)	1	ELC	

Reaction No. 78663




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.102(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:7.63(3SF)	4	CRV	32224

Reaction No. 78940



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.924(4SF)	1	ELC	

Reaction No. 79155




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.526(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:7.144(4SF)	4	EOD	29583

Note (2): Citing Visual MINTEQ (Version 3.0, Royal Inst. Technol. (KTH)).


3	25	0	Inf. Dilution	lgK:7.54(3SF)	4	CRV	32224
---	----	---	---------------	---------------	---	-----	-------

Reaction No. 79276




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.507(4SF)	1	ELC	

Reaction No. 79287




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-17.09(4SF)	3	EOD	29419

Reaction No. 79346




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:40.1(3SF)	1	ELC	

Reaction No. 79351




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:40.6(4SF)	1	ELC	

Reaction No. 79386




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:41.7(3SF)	1	ELC	

Reaction No. 79430




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.876(4SF)	1	ELC	

Reaction No. 79520



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-3556.7(7.6SD)kJ	5	MSL	28760


Reaction No. 79528



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-6.12(3SF)	3	CRV	6330

Note (1): p. 8-58


Reaction No. 79544



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-994.1(4SF)kJ	4	EOD	29025


2	25	0	Inf. Dilution	dH:-1109.2 (5SF) kJ	4	EOD	29025
3	25	0	Inf. Dilution	Cp:114.6 (4SF) J/K	4	EOD	29025

Reaction No. 79545




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1240.1 (5SF) kJ	4	EOD	29025
2	25	0	Inf. Dilution	dH:-1402.9 (5SF) kJ	4	EOD	29025
3	25	0	Inf. Dilution	Cp:156.3 (4SF) J/K	4	EOD	29025

Reaction No. 79546




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1798.6 (5SF) kJ	4	EOD	29025
2	25	0	Inf. Dilution	dH:-2021.1 (5SF) kJ	4	EOD	29025
3	25	0	Inf. Dilution	Cp:186.0 (4SF) J/K	4	EOD	29025

Reaction No. 79573




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-5.22 (3SF)	1	ELC	
2	25	0	Inf. Dilution	dH:16.3 (3SF) kJ	1	ELC	

Reaction No. 79582



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.80 (3SF)	4	CRV	28992
2	50	0	Inf. Dilution	lgK:8.55 (3SF)	3	CRV	28992
3	100	0	Inf. Dilution	lgK:8.59 (3SF)	3	CRV	28992
4	150	0	Inf. Dilution	lgK:9.19 (3SF)	2	CRV	28992
5	200	0	Inf. Dilution	lgK:10.1 (3SF)	2	CRV	28992

Reaction No. 79587



Note: Called 'Octacalcium phosphate' [85VVM 29070], this has five H2O whereas six is more conventional - see $\text{Ca}_2(4)\text{H}_2\text{P}_6\text{O}_{23}$

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0	Inf. Dilution	lgK:93.8 (3SF)	0	EOD	29070
2	25	0	Inf. Dilution	lgK:96.6 (3SF)	4	CRV	31723
3	25	0	Inf. Dilution	lgK:96.6 (3SF)	4	CRV	31748
4	25	0	Inf. Dilution	lgK:93.80 (4SF)	0	CRV	32224
5	37	0	Inf. Dilution	lgK:98.6 (3SF)	0	CRV	2556
Note (5): From Ksp of Ca+2(4)_H+1_PO4-3(3)_H2O(2.5)_ (s) * -2							
6	37	0	Inf. Dilution	lgK:98.6 (3SF)	0	CRV	31723

Reaction No. 79589							
Ca+2 + H+1(2)_EDDS-4 = Ca+2_H+1(2)_EDDS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.097	NaCl	lgK:3.08 (0.015SD)	4	MGL	29124
2	25	0.494	NaCl	lgK:2.69 (0.01SD)	4	MGL	29124
3	25	0.89	NaCl	lgK:2.62 (0.02SD)	4	MGL	29124


Reaction No. 79613							
Ca+2 + 2<OH-1> = Ca+2_OH-1(2)							
Note: Poor model selection in ref. [16KGP_29203]							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	1	NaCl	lgK:0.51 (2SF)	0	MSL	29203
2	25	0	Inf. Dilution	lgK:0.1 (1SF)	1	EES	
Note (2): Doubtful species							
3	25	1	NaCl	lgK:0.67 (2SF)	0	MSL	29203
4	25	4	NaCl	lgK:0.88 (2SF)	0	MSL	29203
5	50	1	NaCl	lgK:0.86 (2SF)	0	MSL	29203
6	75	1	NaCl	lgK:1.05 (3SF)	0	MSL	29203

Reaction No. 79614							
Al+3_Ca+2(2)_OH-1(7)_H2O_(s) = 2<Ca+2> + Al+3_OH-1(4) + 3<OH-1> + H2O							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-11.4 (0.5SD)	3	MSL	28806
2	50	0	Inf. Dilution	lgK:-11.6 (0.5SD)	3	MSL	28806
3	75	0	Inf. Dilution	lgK:-12.1 (3SF)	3	MSL	28806

Reaction No. 79615							
Ca+2 + Tartaric-2 + H2O = Ca+2_OH-1_Tartaric-2 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	4	NaCl	lgK:-11.2(0.01SD)	4	MGL	29206
---	----	---	------	-------------------	---	-----	-------

Reaction No. 79616




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4	NaCl	lgK:-25.3(3SF)	2	MGL	29206

Reaction No. 79620




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-7.1(2SF)	1	EES	

Reaction No. 79622




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.4(2SF)	1	EES	

Reaction No. 79655




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.5(2SF)	1	ELC	

Reaction No. 79657




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.1(2SF)	1	ELC	

Reaction No. 79668



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-5513.2(5.4SD)kJ	5	MCL	29317
2	25	0	Inf. Dilution	dH:-5947.1(5.4SD)kJ	5	CRV	29317

Reaction No. 79669



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.51(4SF)	4	CRV	27383

Reaction No. 79670							
$\text{Ca}_2\text{Al}_4\text{Si}_4\text{O}_{16} \cdot 9\text{H}_2\text{O}(\text{s}) + 16\text{H}^+ = 2\text{Ca}^{2+} + 4\text{Al}^{3+} + 4\text{H}_2\text{SiO}_4^{2-} + 9\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 38.96(4\text{SF})$	4	CRV	27383

Reaction No. 79677							
$\text{Ca}^{2+} + \text{H}^+_{\text{Cis-2}} = \text{Ca}^{2+}_{\text{H}^+_{\text{Cis-2}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	$\lg K: 2.68(0.05\text{SD})$	4	MGL	29298
2	25	1	NaCl	$\lg K: 2.06(0.05\text{SD})$	4	MGL	29298

Reaction No. 79679							
$\text{H}^+ + 2\text{MeNTA-3} + \text{Ca}^{2+} = \text{Ca}^{2+}_{\text{H}^+_{2\text{MeNTA-3}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	NaCl	$\lg K: 2.14(0.07\text{SD})$	4	MGL	29125
2	25	0.15	NaCl	$\lg K: 1.85(0.06\text{SD})$	4	MGL	29125
3	25	0.5	NaCl	$\lg K: 1.54(3\text{SF})$	4	MGL	29125
4	25	1	NaCl	$\lg K: 1.45(3\text{SF})$	4	MGL	29125

Reaction No. 79680							
$2\text{MeNTA-3} + 2\text{Ca}^{2+} = \text{Ca}^{2+}_{(2)}_{2\text{MeNTA-3}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	NaCl	$\lg K: 2.05(0.09\text{SD})$	1	MGL	29125
2	25	0.15	NaCl	$\lg K: 2.05(0.08\text{SD})$	4	MGL	29125
3	25	0.5	NaCl	$\lg K: 1.83(0.09\text{SD})$	3	MGL	29125
4	25	1	NaCl	$\lg K: 1.86(0.20\text{SD})$	4	MGL	29125

Reaction No. 79700							
$\text{Ca}^{2+}_{\text{H}^+_{\text{DTPA-5}}} + \text{H}^+ = \text{Ca}^{2+}_{\text{H}^+_{(2)}_{\text{DTPA-5}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 4.6(2\text{SF})$	1	EES	
2	37	0.15	NaCl	$\lg K: 4.40(3\text{SF})$	5	CRV	13242

Reaction No. 79701							
$\text{Ca}^{2+}_{\text{H}^+_{(2)}_{\text{DTPA-5}}} + \text{H}^+ = \text{Ca}^{2+}_{\text{H}^+_{(3)}_{\text{DTPA-5}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:4.0 (2SF)	1	EES	
2	37	0.15	NaCl	lgK:3.70 (3SF)	5	CRV	13242

Reaction No. 79754




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:225.2 (4SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-1280.50 (6SF) kJ	0	CRV	29482
3	25	0	Inf. Dilution	dH:-1440.70 (6SF) kJ	3	CRV	29482

Reaction No. 79766




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1233.90 (6SF) kJ	5	CRV	29482
2	25	0	Inf. Dilution	dH:-1351.90 (6SF) kJ	5	CRV	29482

Reaction No. 79779




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1150.30 (6SF) kJ	5	CRV	29482
2	25	0	Inf. Dilution	dH:-1263.00 (6SF) kJ	5	CRV	29482

Reaction No. 79898




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1717.8 (5SF) kJ	4	CRV	29375

Reaction No. 79899



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2443.0 (5SF) kJ	4	CRV	29375

Reaction No. 79900



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-3339.5 (5SF) kJ	4	CRV	29375

Reaction No. 80005

2<Sb+5_OH-1(6)> + Ca+2 = Ca[Sb(OH)6]2(s)							
Note: Ca antimonate (romeite) incongruent dissolution; Ca:Sb ratio in solid depends on Ca present							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Self Medium	lgK:9.8(2SF)	3	MSL	31676
Note (1): most soluble case							
2	25	0	Self Medium	lgK:9.57(0.08SD)	3	MSL	31677
Note (2): most soluble case							
3	25	0	Unknown	lgK:12.55(4SF)	0	MSL	23091
Note (3): possibly a bit aged							

Reaction No. 80061							
Ca+2 + Ca+2_H+1(2)_DTPMP-9 = Ca+2(2)_H+1(2)_DTPMP-9							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.74(3SF)	2	EDH	29755
2	25	0.125	NaCl	lgK:3.73(0.13SD)	4	MGL	29755
3	25	0.342	NaCl	lgK:2.98(0.11SD)	4	MGL	29755
4	25	0.958	NaCl	lgK:2.87(0.10SD)	4	MGL	29755

Reaction No. 80087							
7<Ca(s)> + 8.5<O2(g)> + 4<V(s)> = Ca7V4O17(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-8375.9(5SF)kJ	4	ETR	30066
2	25	0	Inf. Dilution	dH:-8209.0(5SF)kJ	4	ETR	30066

Reaction No. 80237							
Ca(s) + 0.5<H2(g)> + 2.25<O2(g)> + S(s) = Ca+2_SO4-2_H2O(0.5)_ (s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1437.7(5SF)kJ	5	MSL	29947
Note (1): prob. refers to alpha form (and is duplicated there)							
2	25	0	Inf. Dilution	dH:-1585.7(5SF)kJ	5	MSL	29947

Reaction No. 80241							
AsO4-3 + Ca+2 = Ca+2_AsO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.33(0.03SD)	1	MPH	29969
2	25	0	Inf. Dilution	lgK:6.47(0.015SD)	3	EDH	29940

3	25	0.1	NaCl	lgK:5.41(0.025SD)	3	MGL	29940
4	25	0.25	NaCl	lgK:5.39(0.01SD)	4	MGL	29940
5	25	0.5	NaCl	lgK:5.63(0.01SD)	5	MGL	29940
6	25	1	NaCl	lgK:6.57(0.02SD)	5	MGL	29940
7	25	0.7	NaCl	dH:-4.(1.SD)kJ	4	MCL	29940

Reaction No. 80242							
H+1 + AsO4-3 + Ca+2 = Ca+2_H+1_AsO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:12.54(0.02SD)	1	MPH	29969
2	25	0	Inf. Dilution	lgK:15.14(0.035SD)	3	EDH	29940
3	25	0.1	NaCl	lgK:13.85(0.02SD)	3	MGL	29940
4	25	0.25	NaCl	lgK:13.37(0.01SD)	3	MGL	29940
5	25	0.5	NaCl	lgK:13.21(0.015SD)	4	MGL	29940
6	25	1	NaCl	lgK:13.56(0.02SD)	4	MGL	29940
7	25	0.7	NaCl	dH:-13.(1.SD)kJ	4	MCL	29940

Reaction No. 80243							
2<H+1> + AsO4-3 + Ca+2 = Ca+2_H+1(2)_AsO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.70(0.005SD)	3	EDH	29940
2	25	0.1	NaCl	lgK:20.20(0.015SD)	5	MGL	29940
3	25	0.25	NaCl	lgK:19.73(0.01SD)	5	MGL	29940
4	25	0.5	NaCl	lgK:19.42(0.01SD)	5	MGL	29940
5	25	1	NaCl	lgK:19.15(0.01SD)	5	MGL	29940

Reaction No. 80267							
Ca+2_UO2+2(2)_PO4-3(2)_H2O(3)_(s) = 2<UO2+2> + Ca+2 + 2<PO4-3> + 3<H2O >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-48.36(4SF)	3	CRV	30195
Note (1): Value given (to high precision) but without much supporting detail							
2	25	0	Inf. Dilution	lgK:-48.360(5SF)	3	CRV	31231

Reaction No. 80269							
Ca+2_UO2+2_Na+1(2)_CO3-2(3)_H2O(6)_(s) = 2<Na+1> + Ca+2 + UO2+2 + 3<CO3-2> + 6<H2O >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-107.8(4SF)	1	ELC	

2	25	0	Inf. Dilution	lgK:-37.5 (3SF)	0	CRV	30195
Note (2): Value given without much supporting detail							

Reaction No. 80270							
Ca+2(2)_UO2+2_CO3-2(3)_H2O(10) = 2<Ca+2> + UO2+2 + 3<CO3-2> + 10<H2O >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-36.9 (3SF)	3	CRV	30195
Note (1): Value given without much supporting detail							

Reaction No. 80284							
Ca+2_OH-1(2)_(s) + CO2(g) = Ca+2_CO3-2_(Calc.,s) + H2O							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.0 (3SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-83.28 (4SF) kJ	0	CRV	30199

Reaction No. 80285							
2CaO.SiO2(beta,s) + 2<CO2(g)> = 2<Ca+2_CO3-2_(Calc.,s)> + SiO2(am.,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.7 (3SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-142.06 (5SF) kJ	0	CRV	30199

Reaction No. 80340							
CaU6O19.11H2O(s) + 14<H+1> = 6<UO2+2> + Ca+2 + 18<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:40.5 (1.6SD)	3	EOD	30627
2	25	0	Inf. Dilution	lgK:40.500 (5SF)	3	CRV	31231

Reaction No. 80504							
CaU2O7.3H2O(s) + 6<H+1> = Ca+2 + 2<UO2+2> + 6<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.400 (5SF)	5	CRV	31231

Reaction No. 80527							
Ca+2 + Lactic-1 + OH-1 = Ca+2_Lactic-1_OH-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4	NaCl	lgK:1.35 (0.09SD)	4	MMX	31270

Reaction No. 80528							
--------------------	--	--	--	--	--	--	--

Ca+2 + Lactic-1 + 2<OH-1> = Ca+2_Lactic-1_OH-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4	NaCl	lgK:1.43(0.006SD)	4	MMX	31270

Reaction No. 80587							
Th+4 + 8<OH-1> + 4<Ca+2> = Th+4_Ca+2(4)_OH-1(8)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:49.3(0.45SD)	5	CRV	31301

Reaction No. 80660							
C(s) + 15<H2(g)> + 3<Ca(s)> + 12.5<O2(g)> + S(s) + Si(s) = Ca3Si(OH)6CO3SO4.12H2O(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-7564.5(5SF)kJ	5	CRV	31308
2	25	0	Inf. Dilution	dH:-8700.(4SF)kJ	5	CRV	31308

Reaction No. 80662							
Ca3Si(OH)6CO3SO4.12H2O(s) = 3<Ca+2> + H+1_SiH2O4-2 + SO4-2 + CO3-2 + OH-1 + 13<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-24.75(4SF)	5	CRV	31308

Reaction No. 80663							
Al+3(2)_Ca+2(4)_Cl-1_OH-1(12)_SO4-2(0.5)_H2O(6)_ (s) = 4<Ca+2> + 2<Al+3_OH-1(4)> + Cl-1 + 0.5 <SO4-2> + 4<OH-1> + 6<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-28.53(4SF)	5	CRV	31308

Reaction No. 80664							
Ca+2_K+1(2)_SO4-2(2)_H2O_(s) = 2<K+1> + Ca+2 + 2<SO4-2> + H2O							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-7.20(3SF)	5	CRV	31308

Reaction No. 80665							
Ca(s) + H2(g) + 2<K(s)> + 4.5<O2(g)> + 2<S(s)> = Ca+2_K+1(2)_SO4-2(2)_H2O_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2884.9(5SF)kJ	5	CRV	31308

Reaction No. 80691							
Zr+4 + 6<OH-1> + 3<Ca+2> = Zr+4_Ca+2(3)_OH-1(6)							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:57.00(0.22SD)	4	CRV	31367
Note (1): SIT fit							
2	25	0	Inf. Dilution	lgK:57.47(0.20SD)	4	CRV	31367
Note (2): Pitzer fit							

Reaction No. 80703							
Glp-1 + Ca+2 = Ca+2_Glp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.8(1SF)	0	ESC	28777
2	37	0.15	NaCl	lgK:0.73(0.07SD)	3	MGL	28777
3	37	0.15	NaCl	lgK:0.69(0.08SD)	3	MIS	28777

Reaction No. 80704							
Glp-1 + Ca+2 = H+1 + Ca+2_H+1(-1)_Glp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-10.8(3SF)	1	ESC	
2	37	0.15	NaCl	lgK:-10.61(0.11SD)	3	MGL	28777

Reaction No. 80706							
Pyridoxine-1 + Ca+2 = Ca+2_Pyridoxine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.7(1SF)	1	ESC	
2	37	0.15	NaCl	lgK:0.57(0.08SD)	3	MGL	28777
3	37	0.15	NaCl	lgK:0.58(0.06SD)	3	MIS	28777

Reaction No. 80710							
Gly-1 + Ca+2 = H+1 + Ca+2_H+1(-1)_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-9.3(2SF)	1	ESC	
2	37	0.15	NaCl	lgK:-9.46(0.03SD)	2	MGL	28777

Reaction No. 80846							
5<Ca+2> + 3<PO4-3> - H+1 + H2O = Ca+2(5)_OH-1_PO4-3(3)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:44.4(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:40.35(4SF)	0	CRV	32224

3	25	0.1	Unknown	lgK:38.97 (4SF)	0	CRV	31724
---	----	-----	---------	-----------------	---	-----	-------

Reaction No. 80847							
$5\text{Ca(s)} + 0.5\text{Cl}_2\text{(g)} + 6\text{O}_2\text{(g)} + 3\text{P(s)} = \text{Ca}_2\text{(5)}_{\text{Cl-1}}_{\text{PO}_4\text{-3(3)}}\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-6615.5 (5SF) kJ	2	MTD	22282
Note (1): -13231/2 abstract							

Reaction No. 80848							
$5\text{Ca(s)} + 0.5\text{I}_2\text{(s)} + 6\text{O}_2\text{(g)} + 3\text{P(s)} = \text{Ca}_2\text{(5)}_{\text{I-1}}_{\text{PO}_4\text{-3(3)}}\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-6474.5 (5SF) kJ	2	MTD	22282
Note (1): -12949/2							

Reaction No. 80849							
$0.5\text{Br}_2\text{(l)} + 5\text{Ca(s)} + 6\text{O}_2\text{(g)} + 3\text{P(s)} = \text{Ca}_2\text{(5)}_{\text{Br-1}}_{\text{PO}_4\text{-3(3)}}\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-6531.5 (5SF) kJ	5	MTD	22282
Note (1): -13063/2 abstract							

Reaction No. 80868							
$10\text{Ca}^{+2} + 6\text{PO}_4\text{-3} + 0.5\text{CO}_3\text{-2} + \text{OH-1} = \text{Ca}_2\text{(10)}_{\text{OH-1}}_{\text{CO}_3\text{-2(0.5)}}_{\text{PO}_4\text{-3(6)}}\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:85.1 (3SF)	5	CRV	31748

Reaction No. 80869							
$\text{Ca}_2\text{(9)}_{\text{Mg}^{+2}}_{\text{H}^{+1}}_{\text{PO}_4\text{-3(7)}}\text{(s)} = 9\text{Ca}^{+2} + \text{Mg}^{+2} + \text{H}^{+1} + 7\text{PO}_4\text{-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-113.75 (5SF)	5	MSL	31749
2	37	0	Inf. Dilution	lgK:-106.34 (5SF)	2	EOD	31749
Note (2): Indicative only							

Reaction No. 80870							
$\text{Ca}_2\text{(4)}_{\text{H}^{+1}}_{\text{PO}_4\text{-3(3)}}_{\text{H}_2\text{O(2.5)}}\text{(s)} + 2\text{H}^{+1} = 4\text{Ca}^{+2} + 3\text{H}^{+1}_{\text{PO}_4\text{-3}} + 2.5\text{H}_2\text{O}$							
Note: Presumably should mean $\text{Ca}_2\text{(4)}_{\text{H}^{+1}}_{\text{PO}_4\text{-3(3)}}_{\text{H}_2\text{O(3)}}\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.4	Unknown	lgK:-7.09 (3SF)	0	EOD	29777

Reaction No. 80940							
HydroxyCitric-3 + Ca+2 = Ca+2_HydroxyCitric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:3.93(0.01SD)	5	MGL	32051

Reaction No. 80941							
H+1 + HydroxyCitric-3 + Ca+2 = Ca+2_H+1_HydroxyCitric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:8.44(0.01SD)	5	MGL	32051

Reaction No. 80942							
2<H+1> + HydroxyCitric-3 + Ca+2 = Ca+2_H+1(2)_HydroxyCitric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:11.76(0.02SD)	5	MGL	32051

Reaction No. 80960							
1.5<Br2(1)> + Ca(s) + 5<H2(g)> + Li(s) + 2.5<O2(g)> = Ca+2_Li+1_Br-1(3)_H2O(5)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2257.2(5SF)kJ	3	EOD	12955
Note (1): From Wagman							

Reaction No. 80989							
Ca+2 + H+1_Se-2 = Ca+2_Se-2_(s) + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-25.53(1.43SD)	3	EOD	32222
2	25	0	Inf. Dilution	dH:158.900(1.010SD)kJ	3	EOD	32222

Reaction No. 81007							
SeO3-2 + Ca+2 = Ca+2_SeO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.17(3SF)	3	EOD	32222

Reaction No. 81019							
Ca+2 + SeO3-2 + H2O = Ca+2_SeO3-2_H2O_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.76(0.18SD)	3	EOD	32222

Reaction No. 81327							
--------------------	--	--	--	--	--	--	--

Ba+2_Ca+2_CO3-2(2)_(tricl.,s) = Ba+2 + Ca+2 + 2<CO3-2>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-17.99(4SF)	4	CRV	32224

Reaction No. 81328							
Ba+2_Ca+2_CO3-2(2)_(monocl.,s) = Ba+2 + Ca+2 + 2<CO3-2>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-17.84(4SF)	4	CRV	32224

Reaction No. 81337							
Ca+2_S-2_(s) + 4<H2O> = Ca+2 + SO4-2 + 8<H+1> + 8<e-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-21.07(4SF)	4	CRV	32224

Reaction No. 81338							
Ca+2(10)_OH-1(2)_PO4-3(6) + 2<H+1> = 10<Ca+2> + 6<PO4-3> + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:28.17(4SF)	4	CRV	32224

Reaction No. 81339							
Ca+2_Se-2_(s) + 3<H2O> = Ca+2 + SeO3-2 + 6<H+1> + 6<e-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-27.76(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-26.49(4SF)	0	CRV	32224


Reaction No. 81340							
Ca+2_SeO4-2_H2O(2)_(s) + 2<H+1> + 2<e-1> = Ca+2 + SeO3-2 + 3<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.9(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:25.90(4SF)	0	CRV	32224

Reaction No. 81341							
CaFe2O4(s) + 8<H+1> + 2<e-1> = Ca+2 + 2<Fe+2> + 4<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:43.31(4SF)	4	CRV	32224

Reaction No. 81342							
2CaO.Fe2O3(s) + 10<H+1> + 2<e-1> = 2<Ca+2> + 2<Fe+2> + 5<H2O>							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:78.67 (4SF)	4	CRV	32224

Reaction No. 81343




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:28.54 (4SF)	4	CRV	32224

Reaction No. 81344




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.171 (3SF)	4	CRV	32224

Reaction No. 81345




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:32.919 (5SF)	4	CRV	32224

Reaction No. 81346




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:54.81 (4SF)	4	CRV	32224

Reaction No. 81347




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.87 (4SF)	4	CRV	32224

Reaction No. 81348



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.4 (2SF)	1	ELC	32224
2	25	0	Inf. Dilution	lgK:-9.140 (4SF)	0	CRV	32224

Reaction No. 81349



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.66 (4SF)	6	CRV	27383

2	25	0	Inf. Dilution	lgK:14.25(4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:11.85(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:11.85(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:11.85(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:11.80(0.01SD)	1	ENS	5156

Note (6): query mineral name "laumontite"

Reaction No. 81350							
$\text{CaAl}_4\text{Si}_2\text{O}_{10}(\text{OH})_2(\text{s}) + 14\text{H}^+ = \text{Ca}^{2+} + 4\text{Al}^{3+} + 2\text{H}_2\text{SiO}_4^{2-} + 4\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:42.33(4SF)	4	CRV	32224

Reaction No. 81351							
$\text{Ca}_2\text{Al}_3\text{Si}_3\text{O}_{12}(\text{OH})(\text{clino},\text{s}) + 13\text{H}^+ = 2\text{Ca}^{2+} + 3\text{Al}^{3+} + 3\text{H}_2\text{SiO}_4^{2-} + \text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:44.16(4SF)	4	CRV	32224

Reaction No. 81352							
$\text{Ca}_2\text{FeAl}_2\text{Si}_3\text{O}_{12}(\text{OH})(\text{s}) + 13\text{H}^+ + \text{e}^- = 2\text{Ca}^{2+} + 2\text{Al}^{3+} + \text{Fe}^{2+} + 3\text{H}_2\text{SiO}_4^{2-} + \text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:44.29(4SF)	4	CRV	32224

Reaction No. 81353							
$\text{Ca}^{2+}\text{UO}_2^{2+}2(\text{VO}_4^{3-})_2(\text{s}) + 8\text{H}^+ + 4\text{e}^- = \text{Ca}^{2+} + 2\text{U}^{4+} + 2\text{VO}_4^{3-} + 4\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-36.9(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-34.74(4SF)	0	CRV	32224

Note (2): source indicate uncertainty

Reaction No. 81354							
$\text{Ca}^{2+}2(\text{UO}_2^{2+}\text{CO}_3^{2-})_2\text{H}_2\text{O}(10) + 4\text{H}^+ + 2\text{e}^- = 2\text{Ca}^{2+} + \text{U}^{4+} + 3\text{CO}_3^{2-} + 12\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-27.75(4SF)	1	CRV	32224

Note (1): balanced rxn badly conceived

Reaction No. 81355							
--------------------	--	--	--	--	--	--	--

$\text{Ca}+2_ \text{Mg}+2_ \text{UO}_2+2_ \text{CO}_3-2(3)_ \text{H}_2\text{O}(12)_ (\text{s}) = \text{Ca}+2 + \text{Mg}+2 + \text{UO}_2+2 + 3<\text{CO}_3-2> + 12<\text{H}_2\text{O}>$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-37.7(3SF)	3	EES	

Reaction No. 81356							
$\text{Ca}+2_ \text{Mg}+2_ \text{UO}_2+2_ \text{CO}_3-2(3)_ \text{H}_2\text{O}(12)_ (\text{s}) + 4<\text{H}+1> + 2<\text{e}-1> = \text{Ca}+2 + \text{Mg}+2 + \text{U}+4 + 3<\text{CO}_3-2> + 14<\text{H}_2\text{O}>$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-28.66(4SF)	1	CRV	32224
Note (1): not best form of rxn							

Reaction No. 81357							
$\text{Ca}+2_ \text{Mn}+2_ \text{CO}_3-2(2)_ (\text{s}) = \text{Ca}+2 + \text{Mn}+2 + 2<\text{CO}_3-2>$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-21.81(4SF)	3	EOD	
Note (1): R.C. Aller, in Treatise on Geochemistry (Second Edition), 2014							

Reaction No. 81358							
$\text{Ca}(\text{UO}_2)_2.(\text{SiO}_4\text{H})_2(\text{s}) + 14<\text{H}+1> + 4<\text{e}-1> = \text{Ca}+2 + 2<\text{U}+4> + 2<\text{H}+1(2)_ \text{SiH}_2\text{O}_4-2> + 4<\text{H}_2\text{O}>$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:35.85(4SF)	4	CRV	32224

Reaction No. 81506							
$\text{NaCa}_2\text{Mg}_4\text{Al}_3\text{Si}_6\text{O}_{22}(\text{OH})_2(\text{s}) + 22<\text{H}+1> = \text{Na}+1 + 2<\text{Ca}+2> + 4<\text{Mg}+2> + 3<\text{Al}+3> + 6<\text{H}+1(2)_ \text{SiH}_2\text{O}_4-2>$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:103.45(5SF)	4	CRV	32224

Reaction No. 81507							
$\text{Ca}+2_ \text{UO}_2+2_ \text{Na}+1(2)_ \text{CO}_3-2(3)_ \text{H}_2\text{O}(6)_ (\text{s}) + 4<\text{H}+1> + 2<\text{e}-1> = 2<\text{Na}+1> + \text{Ca}+2 + \text{U}+4 + 3<\text{CO}_3-2> + 8<\text{H}_2\text{O}>$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-98.73(4SF)	4	CRV	32224

Data Assessment

Weight	Assessment
9	highest accuracy
8	multi-determined; excellent dependability
7	trustworthy; outstanding single determination
6	better than average reliability
5	average single determination
4	some doubt
3	poorly known
2	guess to achieve consistency (or just as bad)
1	no information but consistent
0	problematic/inconsistent

Techniques

Abbrev	Method
CIU	Critical IUPAC publication (crit.)
CMN	Several experimental values (crit.)
CRV	Critical review
CSM	Smith & Martell Vols 1-6 (crit.)
EAC	Activity Coefficient
EAE	Automated extrapolation
EBU	Brown's Unified Theory
EDH	Debye-Hueckel corrections
EES	Personal estimate
EEX	One experiment
EFE	Free Energy relations
EIE	Interpolation/Extrapolation (not Debye-Hueckel)
EIU	Critical IUPAC review (estim.)
ELC	Linear Combination of Reactions
EMD	Molecular Dynamics
EMS	Mean Spherical Approximation
EMU	Method unknown
ENA	Nearest available constant
ENS	Not specified

EOD	Calculated from data of others
EOR	Other Reaction Constants
EPZ	Pitzer model correction
ERG	Relative Gibbs energy
ERS	Rough subjective
ESC	Standard conditions anchor
ESL	Similar Ligand
ETR	Thermodynamic relationships
ETS	Ternary (statistical)
EVK	Variation of lgK with T
MAC	Activity coefficient (not specified)
MAG	Silver electrode e.m.f.
MCE	Cation exchange
MCG	Chromatography, Gel
MCL	Calorimetry
MCN	Conductivity
MCO	Colorimetry (often for measuring pH)
MCT	Coulometric titration
MDG	Combination of Thermodynamic Data
MDS	Distribution between two phases
MEF	Electromotoric force, not specified
MEP	Electrophoresis
MFL	Fluorescence
MFP	Freezing point
MGL	Glass electrode
MHG	Emf with amalgam electrode
MHY	Emf with hydrogen electrode
MIS	Ion selective electrode
MIX	Ion exchange
MKN	Rate of reaction
MMC	Metal competition
MMR	Nuclear magnetic resonance
MMX	Mixed techniques
MPH	pH method, not specified
MPL	Polarography
MPP	Partial pressure

MPS	Potentiometry and Spectrophotometry
MPT	Potentiometry
MQH	Quinhydrone electrode
MRM	Raman spectra
MRX	Emf with redox electrode
MSC	Miscellaneous
MSE	Solvent Extraction
MSL	Solubility
MSP	Spectroscopy
MTD	Temperature difference
MTN	Tyndallometry, nephelometry
MTP	Migration or transference number
MVM	Voltametric Methods

References

Reference No.: 5(69Hel)

Am. J. Sci., 1969, 267, 729 - 804; Helgeson HC; Thermodynamics of Hydrothermal Systems at Elevated Temperatures and Pressures

Reference No.: 8(76SmM)

Critical Stability Constants, Vol. 4, 1976 Smith RM; Martell AE; Plenum, New York

Reference No.: 19(60GrC)

J. Phys. Chem., 1960, 64, 1057 - 1059; Greenberg SA; Copeland LE; The Thermodynamic Functions for the Solution of Calcium Hydroxide in Water

Reference No.: 53(57Bje)

Metal Ammine Formation in Aqueous Solution, 1957 Bjerrum J; P.Haase and Son, Copenhagen

Reference No.: 68(67Hel)

J. Phys. Chem., 1967, 71, 3121 - 3136; Helgeson HC; Thermodynamics of Complex Dissociation in Aqueous Solution at Elevated Temperatures

Reference No.: 69(53BeG)

Trans. Faraday Soc., 1953, 49, 619 - 627; Bell RP; George JHB; The Incomplete Dissociation of Some Thallous and Calcium Salts at Different Temperatures

Reference No.: 83(76Kat)

J. Solution Chem., 1976, 5, 241 - 248; Katayama S; Conductimetric Determination of Ion-Association Constants for Calcium, Cobalt, Zinc, and Cadmium Sulfates in Aqueous Solution at Various Temperatures between 0C and 45C

Reference No.: 89(95SDM)

Annu. Cong. Gruppo Therm. Complessi - XXII, Urbino, 1995, 93 - 96; Sanchiz J; Dominguez

S; Mederos A; Brito F; A Study of the Complexes Formed by Cu(II) and Fe(III) with Orthophenylenediamine-N,N,N',N'-Tetraacetic and 4-Chloro-Orthophenylenediamine-N,N,N',N'-Tetraacetic Acids

Reference No.: 93(70LiN)

J. Cryst. Growth, 1970, 6, 281 - 289; Liu S-T; Nancollas GH; The Kinetics of Crystal Growth of Calcium Sulfate Dihydrate

Reference No.: 94(77MLW)

J. Chem. Soc., Dalton Trans., 1977,, 588 - 595; May PM; Linder PW; Williams DR; Computer Simulation of Metal-ion Equilibria in Biofluids: Models for the Low-Molecular-Weight Complex Distribution of Calcium(II), Magnesium(II), Manganese(II), Iron(III), Copper(II), Zinc(II), and Lead(II) Ions in Human Blood Plasma

Reference No.: 97(82HMQ)

Agents Actions, 1982, 12, 536 - 542; Huang Z-X; May PM; Quinlan KM; Williams DR; Creighton AM; Metal Binding by Pharmaceuticals. Part 2. Interactions of Ca(II), Cu(II), Fe(II), Mg(II), Mn(II) and Zn(II) with the Intracellular Hydrolysis Products of the Antitumour Agent ICRF 159 and its Inactive Homologue ICRF 192

Reference No.: 101(46Jos)

J. Biol. Chem., 1946, 164, 529 - 541; Joseph NR; The Dissociation Constants of Organic Calcium Complexes

Reference No.: 107(78AKW)

J. Inorg. Nucl. Chem., 1978, 40, 1221 - 1226; Arena G; Kavu G; Williams DR; Metal-ligand Complexes Involved in Rheumatoid Arthritis. V. Formation Constants for Calcium(II)-, Magnesium(II), and Copper(II)-Salicylate and Acetylsalicylate Interactions

Reference No.: 108(54Sch)

J. Am. Chem. Soc., 1954, 76, 3442 - 3444; Schubert J; Complexes of Alkaline Earth Cations Including Radium with Amino Acids and Related Compounds Complexes of Alkaline Earth Cations Including Radium with Amino Acids and Related Compounds

Reference No.: 128(70ABP)

J. Chem. Soc. (A), 1970,, 2691 Advani AT; Barnes DS; Pettit LD; Absence of Stereoselectivity in Complexes of Optically Active and Racemic 1,2-Diamines

Reference No.: 135(68WiR)

Suomen Kemi., 1968, B41, 177 - 183; Wikberg H; Ringbom A; Stability Constants of the Silver Complexes of Some Polyaminopolycarboxylic Acids

Reference No.: 139(65WHR)

Anal. Chem., 1965, 37, 884 Wright DL; Holloway JH; Reilley CN; Heats and Entropies of Formation of Metal Chelates of Polyamine and Polyaminocarboxylate Ligands

Reference No.: 140(64SiM)

Stability Constants of Metal-ion Complexes SP17, 1964 Sillen LG; Martell AE; The Chemical Soc., London

Reference No.: 149(73HaR)

Talanta, 1973, 20, 1105 - 1115; Hansen EH; Ruzicka J; Selectrode. Universal Ion-selective Electrode. V. Complex Formation Studies with the Copper(II) Selectrode

Reference No.: 154(64COM)

J. Inorg. Nucl. Chem., 1964, 26, 553 - 564; Campi E; Ostacoli G; Meirone M; Saini G; Stability of the Complexes of Tricarballic and Citric Acids with Bivalent Metal Ions in Aqueous Solution

Reference No.: 172(38Dav)

J. Chem. Soc., 1938,, 277 - 281; Davies CW; The Extent of Dissociation of Salts in Water. Part VI. Some Calcium Salts of Organic Acids

Reference No.: 189(59CFD)

J. Inorg. Nucl. Chem., 1959, 11, 184 - 196; Chabarek S; Frost AE; Doran MA; Bicknell NJ; Interaction of some Divalent Metal Ions with Diethylenetriamine- pentaacetic Acid

Reference No.: 190(59ANM)

Helv. Chim. Acta, 1959, 42, 827 - 836; Anderegg G; Nageli P; Muller F; Schwarzenbach G; Complexions. XXX. Diethylenetriaminepentaacetic acid (DTPA)

Reference No.: 197(54SGA)

Helv. Chim. Acta, 1954, 37, 937 - 957; Schwarzenbach G; Gut R; Anderegg G; Complexons. XXV. Polarographic Study of Exchange Equilibria. New Data on the Formation Constants of Metal Complexes of Ethylenediaminetetraacetic Acid and 1, 2-Diaminocyclohexanetetraacetic Acid (Komplexone XXV. Die Prographische Unterscuchung von Austauschgleichgewichten Neue Daten der Bildungskonstanten von Metallkomplexen der Athylendiamin-tetraessigsaeure und der 1,2-Diaminocyclohexan-tetraessigsaeure)

Reference No.: 222(87Bec)

Pure Appl. Chem., 1987, 59, 1703 - 1720; Beck MT; Critical Survey of Stability Constants of Cyano Complexes

Reference No.: 233(89SmM)

Critical Stability Constants, Vol. 6, 1989 Smith RM; Martell AE; Plenum, New York

Reference No.: 234(67SBM)

Biochim. Biophys. Acta, 1967, 148, 655 - 664; Sigel H; Becker K; McCormick DB; Ternary Complexes in Solution. Influence of 2,2'Bipyridyl on the Stability of 1:1 Complexes of Cobalt(II), Nickel(II), Copper(II), and Zinc(II) with Hydrogen Phosphate, Adenosine 5'-monophosphate and Adenosine 5'-triphosphate

Reference No.: 245(68CMN)

J. Phys. Chem., 1968, 72, 208 - 211; Chughtai A; Marshall R; Nancollas GH; Complexes in Calcium Phosphate Solutions

Reference No.: 246(57SNL)

J. Phys. Chem., 1957, 61, 279 - 282; Strates BS; Neuman WF; Levinskas GJ; The Solubility of Bone Mineral. II. Precipitation of Near-Neutral Solutions of Calcium and Phosphate

Reference No.: 247(70GMB)

J. Res. Natl. Bur. Stand., 1970, 74A, 461 - 475; Gregory TM; Moreno EC; Brown WE; Solubility of CaHPO₄.2H₂O in the System Ca(OH)₂-H₃PO₄-H₂O at 5, 15, 25, and 37.5 degrees Celsius

Reference No.: 250(40GRK)

J. Biol. Chem., 1940, 135, 65 - 76; Greenwald I; Redish J; Kibrick AC; Dissociation of Calcium and Magnesium Phosphates

Reference No.: 251(70Mad)

Acta Chem. Scand., 1970, 24, 1671 - 1676; Madsen HEL; Ionic Concentrations in Calcium Phosphate Solutions I. Solutions Saturated with Respect to Brushite or Tetracalcium Monohydrogen Phosphate at 37 degrees Celsius

Reference No.: 253(60MBO)

Soil Sci. Soc. Am. Proc., 1960, 24, 99 - 102; Moreno EC; Brown WE; Osborn G; Stability of Dicalcium Phosphate Dihydrate in Aqueous Solutions and Solubility of Octocalcium Phosphate

Reference No.: 255(70Chi)

Inorg. Chem., 1970, 9, 2465 - 2469; Childs CW; A Potentiometric Study of Equilibria in Aqueous Divalent Metal Orthophosphate Solutions

Reference No.: 257(56SmA)

J. Am. Chem. Soc., 1956, 78, 2376 - 2380; Smith RM; Alberty RA; The Apparent Stability Constants of Ionic Complexes of Various Adenosine Phosphates with Divalent Cations

Reference No.: 259(72FrS)

J. Am. Chem. Soc., 1972, 94, 8898 - 8904; Frey CM; Stuehr JE; Interactions of Divalent Metal Ions with Inorganic and Nucleoside Phosphates. I. Thermodynamics

Reference No.: 267(59WoO)

Recueil. Trav. Chim. Pays-Bas, 1959, 78, 759 - 782; Wolhoff JA; Overbeek JTG; Equilibrium Constants for a Number of Metal-phosphate Complexes

Reference No.: 268(60IrC)

J. Phys. Chem., 1960, 64, 1398 - 1407; Irani RR; Callis CF; Metal Complexing by Phosphorous Compounds. I. The Thermodynamics of Association with Linear Polyphosphates with Calcium

Reference No.: 269(59WaL)

J. Am. Chem. Soc., 1959, 81, 3201 - 3203; Watters JI; Lambert SM; The Complexes of Calcium Ion with Pyrophosphate and Triphosphate Ions

Reference No.: 277(64ElM)

J. Inorg. Nucl. Chem., 1964, 26, 1555 - 1560; Ellison H; Martell AE; Chelating Tendencies of Tripolyphosphate Ions

Reference No.: 280(56MaS)

Helv. Chim. Acta, 1956, 39, 653 - 661; Martell AE; Schwarzenbach G; Adenosinephosphate and Adenosinetriphosphate as Complexing Agents for Calcium and Magnesium

Reference No.: 281(73KhR)

J. Inorg. Nucl. Chem., 1973, 35, 179 - 186; Khan MMT; Reddy PR; Thermodynamic Quantities Associated with the Interaction of Tripolyphosphoric Acid with Metal Ions

Reference No.: 284(65And)

Helv. Chim. Acta, 1965, 48, 1712 - 1717; Anderegg G; Entropy-Conditioned Complex Formation. Thermodynamic Data Concerning Complex Formation by the Tripolyphosphate Ion Entropiebedingte Komplexbildung. Thermodynamische Daten der Komplexbildung mit dem Tripolyphosphat-Ion

Reference No.: 309(69AzL)

Anal. Chim. Acta, 1969, 47, 49 Aziz A; Lyle SJ; Applications of the Fluoride-Sensitive Electrode to the Study of Metal-Fluoride Ion Association Constants

Reference No.: 310(68TWC)

J. Inorg. Nucl. Chem., 1968, 30, 2067 - 2070; Tanner SP; Walker JB; Choppin GR; Thermodynamic Parameters of the Alkaline Earth Monofluorides

Reference No.: 312(71BoH)

J. Inorg. Nucl. Chem., 1971, 33, 429 - 434; Bond AM; Hefter G; Use of the Fluoride Ion-selective Electrode for the Detection of Weak Fluoride Complexes

Reference No.: 315(69PaS)

Can. J. Chem., 1969, 47, 3851 - 3858; Patil SK; Sharma HD; Ion Exchange and Solvent Extraction Equilibria in Mixed Electrolytes

Reference No.: 330(58NRS)

Acta Chem. Scand., 1958, 12, 868 - 872; Nilsson G; Rengemo T; Sillen LG; Some Solution Equilibria Involving Calcium Sulfate and Carbonate Simple Solubility Equilibria of CO₂, SO₂, CaCO₃, and CaSO₄

Reference No.: 332(74JaL)

Geochim. Cosmochim. Acta, 1974, 38, 301 - 318; Jacobson RL; Langmuir D; Dissociation Constants of Calcite and Calcium Bicarbonate Ion from 0 to 50C

Reference No.: 334(41Gre)

J. Biol. Chem., 1941, 141, 789 - 796; Greenwald I; The Dissociation of Calcium and Magnesium Carbonates and Bicarbonates

Reference No.: 335(71Lan)

Geochim. Cosmochim. Acta, 1971, 35, 1023 - 1045; Langmuir D; Geochemistry of Some Carbonate Groundwaters in Central Pennsylvania

Reference No.: 336(60GTS)

Am. J. Sci., 1960, 258, 402 - 418; Garrels RM; Thompson ME; Siever R; Stability of some Carbonates at 25C and One Atmosphere Total Pressure

Reference No.: 353(74FRS)

Zh. Neorg. Khim., 1974, 19, 1746(E:950) - 1750; Fedorov VA; Robov AM; Shmydko II; Vorontsova NA; Mironov VE; Interaction of Alkaline Earth Metal Ions with Nitrite Ions in Aqueous Solutions

Reference No.: 369(73KYM)

J. Chem. Thermodyn., 1973, 5, 899 - 909; Kalyanaraman R; Yeatts LB; Marshall WL; Solubility of Calcium Sulfate and Association Equilibria in CaSO₄ + Na₂SO₄ + NaClO₄ + H₂O at 273 to 623 K

Reference No.: 373(76Rea)

Chem. Geol., 1976, 18, 309 - 325; Reardon EJ; Dissociation Constants for Alkali Earth and Sodium Borate Ion Pairs from 10 to 50 degrees Celsius

Reference No.: 380(56Nan)

J. Chem. Soc., 1956,, 744 - 749; Nancollas GH; Thermodynamics of Ion Association. Part II. Alkaline-earth Acetates and Formates

Reference No.: 381(64ArM)

J. Chem. Soc., 1964,, 3117 - 3122; Archer DW; Monk CB; Ion-association Constants of Some Acetates by pH (Glass Electrode) Measurements

Reference No.: 382(70BuT)

Can. J. Chem., 1970, 48, 1654 - 1656; Bunting JW; Thong KM; Stability Constants for Some 1:1 Metal-carboxylate Complexes

Reference No.: 385(69WKM)

J. Inorg. Nucl. Chem., 1969, 31, 3823 - 3829; Watters JI; Kalliney S; Machen RC; Potentiometric Investigation of Calcium Complexes with Tri- and Tetrametaphosphate using a Calcium Selective Liquid Ion-Exchange Membrane Electrode - II

Reference No.: 386(50JoM)

J. Chem. Soc., 1950,, 3475 - 3478; Jones HW; Monk CB; The Condensed Phosphoric Acids and Their Salts. Part V. Dissociation Constants of Some Tetrametaphosphates

Reference No.: 388(68WaM)

J. Inorg. Nucl. Chem., 1968, 30, 2163 Watters JI; Machen RC; A Study of the Complexes of Tetraphosphate with Alkaline Earth Metal Ions by Acidimetric PH Titrations

Reference No.: 389(49DaM)

J. Chem. Soc., 1949,, 413 - 422; Davies CW; Monk CB; The Condensed Phosphoric Acids and Their Salts. Part 1. Metaphosphates

Reference No.: 404(74GMP)

J. Res. Natl. Bur. Stand., 1974, 78A, 667 - 674; Gregory TM; Moreno EC; Patel JM; Brown WE; Solubility of beta-Ca₃(PO₄)₂ in the System Ca(OH)₂-H₃PO₄-H₂O at 5,15,25,37 degrees Celsius

Reference No.: 406(80Bas)

Geochim. Cosmochim. Acta, 1980, 44, 1151 - 1160; Bassett RL; A Critical Evaluation of the Thermodynamic Data for Boron Ions, Ion pairs, Complexes, and Polyanions in Aqueous Solution at 298.5K and 1 bar

Reference No.: 437(80BoH)

IUPAC Chemical Data Series No. 27, 1980 Bond AM; Hefter GT; Critical Survey of Stability Constants and Related Thermodynamic Data of Fluoride Complexes in Aqueous Solution; Pergamon, Oxford, U.K.

Reference No.: 440(78HDN)

Am. J. Sci., 1978, 278, 1 - 229; Helgeson HC; Delany JM; Nesbitt HW; Bird DK; Summary and Critique of the Thermodynamic Properties of Rock-forming Minerals

Reference No.: 455(74SaS)

J. Chem. Soc., Dalton Trans., 1974,, 181 - 184; Santschi PH; Schindler PW; Complex Formation in the Ternary Systems Ca+2-H₄SiO₄-H₂O and Mg+2-H₄SiO₄-H₂O

Reference No.: 456(65GrC)

J. Phys. Chem., 1965, 69, 182 - 188; Greenberg SA; Chang TN; Investigation of the Colloidal Hydrated Calcium Silicates. II. Solubility Relationships in the Calcium Oxide-Water System at 25 C

Reference No.: 457(84DSR)

Thermochim. Acta, 1984, 74, 343 - 355; De Robertis A; Sammartano S; Rigano C; WECO: A Computer Program for Calculating Thermodynamic Parameters of Simple Weak Complexes, Temperature and Ionic Strength Dependence of the Ionic Product of Water and of Hydrolysis Constants of Na+1 and Ca+2

Reference No.: 476(68OVR)

Ric. Sci., 1968, 38, 318 - 321; Ostacoli G; Vanni A; Roletto E; Complex Formation between Alkyl-substituted Malonic Acids and Bivalent Metal ions in Aqueous Solutions

Reference No.: 552(95SMM)

NIST Critical Stability Constants of Metal Complexes Database, 1995 Smith RM; Martell AE; Motekaitis RJ; Version 2.0; National Institute of Standards and Technology, Gaithersburg, USA

Reference No.: 557(79Lin)

Chemical Equilibria in Soils, 1979 Lindsay WL; Wiley-Interscience, New York

Reference No.: 653(72TuL)

Suomen Kemi., 1972, 45B, 21 - 27; Tummavuori J; Lumme P; Solubility Product of Silver Nitrite and the Stability Constants of Silver-nitrite Complexes in Aqueous Sodium Nitrite Solutions at Different Temperatures

Reference No.: 686(38Dav)

J. Chem. Soc., 1938,, 2093 - 2098; Davies CW; The Extent of Dissociation of Salts in Water. Part VIII. An Equation for the Mean Ionic Activity Coefficient of an Electrolyte in Water, and a Revision of the Dissociation Constants of Some Sulphates

Reference No.: 766(87BrA)

Report EPA/600/3-87/012, 1987 Brown DS; Allison JD; MINTEQA1, An Equilibrium Metal Speciation Model: Users Manual; U.S. Environmental Protection Agency, Athens, Georgia 30613

Reference No.: 769(88RoV)

Talanta, 1988, 35, 271 - 275; Rogers HR; van den Berg CMG; Determination of Borate Ion-Pair Stability Constants by Potentiometry and Non-approximative Linearization of Titration Data

Reference No.: 770(93RCC)

Inorg. Chem., 1993, 32, 582 - 586; Rizkalla EN; Choppin GR; Cacheris WP; Thermodynamics, PMR, and Fluorescence Studies for the Complexation of Trivalent Lanthanides, Ca²⁺, Cu²⁺, and Zn²⁺ by Diethylenetriaminepentaacetic Acid Bis(methylamide)

Reference No.: 773(85KoS)

Handbook of Chemical Equilibria in Analytical Chemistry, 1985 Kotrly S; Sucha L; Ellis Horwood Series in Anal. Chem.; Eds. Chalmers RA & Masson M; Ellis Horwood, Chichester

Reference No.: 775(71CCM)

Selected Constants, 1971 Charlot G; Collumeau A; Marchon MJC; Oxidation-Reduction Potentials of Inorganic Substances in Aqueous Solution; Butterworths, London

Reference No.: 778(78MiC)

Tables of Standard Electrode Potentials, 1978 Milazzo G; Caroli S; Wiley, N.Y.

Reference No.: 802(90Wea)

CRC Handbook of Chemistry and Physics, 70th Edn., 1990 Weast RC; A Ready-Reference Book of Chemical and Physical Data; CRC Press, Cleveland, Ohio

Reference No.: 903(77And)

Critical Survey of Stability Constants of EDTA Complexes, 1977 Anderegg G; IUPAC Chemical Data Series. 14; Pergamon Press, Oxford

Reference No.: 905(95Ber)

Pure Appl. Chem., 1995, 67, 1117 - 143; Berthon G; Critical Review of Formation Constants of Selected Amino Acids with Polar Side Chains

Reference No.: 906(79Per)

IUPAC Chemical Data Series No. 22, 1979 Perrin DD; Stability Constants of Metal-Ion Complexes, First Edition Part B, Organic Ligands; Pergamon, Oxford

Reference No.: 931(71SiM)

Stability Constants of Metal-ion Complexes SP25, 1971 Sillen LG; Martell AE; Supplement No 1 to Special Publication No 25; Chemical Society, London

Reference No.: 937(90MOT)

J. Chem. Soc., Dalton Trans., 1990,, 2337 - 2339; Maeda M; Okada K; Tsukamoto Y; Wakabayashi K; Ito K; Complex Formation of Calcium(II) with Amino Acids under Physiological Conditions

Reference No.: 956(88GDS)

J. Chem. Res. (S), 1988,, 12 - 13; Gianguzza A; Dia G; Sammartano S; De Stefano C; Mixed-metal Complexes in Solution. Formation and Stability of Homobinuclear and Heterobinuclear Species in the Ca²⁺-Mg²⁺-ATP System

Reference No.: 957(88BSV)

Inorg. Chim. Acta, 1988, 152, 233 - 239; Burger K; Sipos P; Veber M; Horvath I; Noszal

B; Low M; Formation Microequilibria of Proton, Calcium and Magnesium Complexes of the gamma-Carboxyglutamate Ion and Related Compounds

Reference No.: 963(90BJS)

J. Inorg. Biochem., 1990, 39, 59 - 73; Bieth H; Jost P; Spiess B; Complexation Studies on Inositol-Phosphates. I. Ca(II) and Mg(II) Complexes of D-Myo-inositol 1,2,6-Triphosphate

Reference No.: 978(88LaB)

Inorg. Chim. Acta, 1988, 151, 33 - 43; Lambs L; Berthon G; Metal Ion- Tetracycline Interactions in Biological Fluids. Part 7. Quantitative Investigation of Methacycline Complexes with Ca(II), Mg(II), Cu(II) and Zn(II) Ions and Assessment of their Biological Significance

Reference No.: 999(91MaM)

Estimation of Constants for JESS Database, 1991 May PM; May RF

Reference No.: 1007(89DDV)

J. Chem. Soc., Dalton Trans., 1989,, 133 - 137; Delgado R; da Silva JJRF; Vaz MCTA; Paoletti P; Micheloni M; Thermodynamics of the Formation of Metal Complexes of 1,4,10-Trioxa-7,13-diazacyclopentadecane-N,N'-diacetic acid and of 1,4,10,13-Tetraoxa-7,16-diazacyclo-octadecane-N,N'-diacetic acid

Reference No.: 1031(86ReR)

J. Chem. Soc., Dalton Trans., 1986,, 2331 - 2334; Reddy PR; Rao VBM; Metal Complexes of Uridine in Solution

Reference No.: 1045(85DDD)

J. Chem. Soc., Dalton Trans., 1985,, 2353 - 2361; Daniele PG; De Robertis A; De Stefano C; Sammartano S; Rigano C; On the Possibility of Determining the Thermodynamic Parameters for the Formation of Weak Complexes using a Simple Model for the Dependence on Ionic Strength of Activity Coefficients: Na⁺, K⁺, and Ca²⁺ Complexes of Low Molecular Weight Ligands in Aqueous Solution

Reference No.: 1069(89GAH)

Polyhedron, 1989, 8, 189 - 195; Ghandour MA; Azab HA; Hassan A; Ali AM; Potentiometric Studies on the Mixed Ligand Complexes in Solution: M II-Tetracycline-glycine Systems

Reference No.: 1089(90RAA)

Polyhedron, 1990, 9, 665 - 668; Rey F; Antelo JM; Arce F; Penedo FJ; Equilibrium Constants of Metal Amino Acid Complexes

Reference No.: 1095(81WoN)

J. Chem. Soc., Dalton Trans., 1981,, 2423 - 2428; Wozniak M; Nowogrocki G; Phosphonate Complexes. Part 6. Influence of Steric Effects, Solvation, and Chelation on Stability

Reference No.: 1103(89FRR)

Polyhedron, 1989, 8, 1365 - 1370; Fuentes J; Reboso R; Rodriguez A; 2,5-Toluenediamine-N,N'-Disuccinic Acid. Preparation, Dissociation Constants and Coordinating Capacity with Divalent Cations

Reference No.: 1118(82And)

Pure Appl. Chem., 1982, 54, 2693 - 2758; Anderegg G; Critical Survey of Stability Constants of NTA Complexes

Reference No.: 1143(84ClV)

J. Inorg. Biochem., 1984, 21, 73 - 82; Claessens RAMJ; van der Linden JGM; Stability Constants of Tin(II) and Calcium Diphosphonate Complexes

Reference No.: 1144(88LVD)

J. Inorg. Biochem., 1988, 33, 193 - 210; Lambs L; Venturini M; Decock-Le Reverend B; Kozlowski H; Berthon G; Metal Ion-Tetracycline Interactions in Biological Fluids. Part 8. Potentiometric and Spectroscopic Studies on the Formation of Ca(II) and Mg(II) Complexes with 4-Dedimethylamino-Tetracycline and 6-Desoxy-6-Demethyl-Tetracycline

Reference No.: 1176(87DDV)

Polyhedron, 1987, 6, 29 - 38; Delgado R; da Silva JJRF; Vaz MCTA; Metal Complexes of 1,4,10-Trioxa-7,13-Diazacyclopentadecane- N,N"-Diacetic Acid

Reference No.: 1183(86ReR)

Polyhedron, 1986, 5, 1947 - 1952; Reddy PR; Reddy BM; Ternary Complexes of 5'-Cytidine Monophosphate and Cytosine with some Biologically Important Secondary Ligands

Reference No.: 1187(85ReR)

Polyhedron, 1985, 4, 1603 - 1609; Reddy PR; Rao VBM; Role of Secondary Ligands in the Structure and Stability of Metal-Cytidine Complexes in Solution

Reference No.: 1207(90CBG)

Inorg. Chem., 1990, 29, 5 - 9; Cortes S; Brucher E; Geraldles CFGC; Sherry AD; Potentiometry and NMR Studies of 1,5,9-Triazacyclododecane- N,N',N"-triacetic Acid and Its Metal Ion Complexes

Reference No.: 1217(89MoM)

Inorg. Chem., 1989, 28, 3499 - 3503; Motekaitis RJ; Martell AE; Potentiometry of Mixtures: Metal Chelate Stability Constants of 1-Hydroxy-3-oxapentane-1,2,4,5-tetracarboxylic Acid and 3,6-Dioxaoctane-1,2,4,5,7,8-hexacarboxylic Acid

Reference No.: 1231(81HMW)

Inorg. Chim. Acta, 1981, 56, 41 - 44; Huang Z-X; May PM; Williams DR; Metal Complexing Ability of Two Inducers of Reverse Transformation

Reference No.: 1237(76MMM)

Inorg. Chem., 1976, 15, 2303 - 2306; Motekaitis RJ; Murase I; Martell AE; Equilibria of EDTPO with Cu(II), Ni(II), Co(II), Zn(II), Mg(II), Ca(II), and Fe(III) Ions in Aqueous Solution

Reference No.: 1249(90KrL)

J. Coord. Chem., 1990, 22, 139 - 143; Kramer-Schnabel U; Linder PW; Complexation of Zinc(II) and Calcium(II) Ions with Organic Monophosphate Esters

Reference No.: 1257(84MoM)

J. Coord. Chem., 1984, 13, 265 - 271; Motekaitis RJ; Martell AE; New Multidentate Ligands. XXV. The Coordination Chemistry of Divalent Metal Ions with Diglycolic Acid, Carboxymethyltartronic Acid and Ditartronic Acid

Reference No.: 1258(89RVM)

J. Coord. Chem., 1989, 20, 69 - 72; Rao AK; Venkataiah P; Mohan MS; Studies on Biologically Relevant Binary and Ternary Metal Complexes. IV. Stability of Binary and Ternary Metal Complexes Containing Bis(Imidazol-2-yl)Methane and Amino Acids

Reference No.: 1266(85OcM)

J. Coord. Chem., 1985, 14, 83 - 86; Ochiai E-I; Morand R; Formation Constant of the Calcium (ATP)₂ Complex

Reference No.: 1274(89SLN)

J. Coord. Chem., 1989, 19, 359 - 369; Strasak M; Lucansky J; Novomesky P; Dvorakova E; Diastereoselectivity in Metal Complexes of some Phenyl- substituted Ethylenediamine-N,N,N,N'-Tetraacetate Derivatives

Reference No.: 1275(87KRZ)

J. Coord. Chem., 1987, 16, 237 - 244; Khan BT; Raju RM; Zakeeruddin SM; Binary and Ternary Metal Complexes of Uridine and Thermodynamic Quantities Associated with the Interaction of Uridine with Bivalent Metal Ions in Solution

Reference No.: 1276(88BFJ)

J. Coord. Chem., 1988, 17, 245 - 253; Bottari E; Festa MR; Jasionowska R; Serine as a Ligand: Complex Formation with Cadmium(II)

Reference No.: 1297(86CCS)

Inorg. Chim. Acta, 1986, 123, 69 - 73; Cini R; Cinquantini A; Seeber R; Complexes of Magnesium(II) and other Divalent Metal Ions with Adenosine 5'-Triphosphate and 2,2'-Dipyridylamine in Aqueous Solution

Reference No.: 1306(91DeD)

Talanta, 1991, 38, 439 - 444; De Robertis A; De Stefano C; Studies of Polyfunctional O-Ligands: Formation and Stability of Mg+2 and Ca+2 Complexes of 1,2,4,5-Benzenetetracarboxylic Acid in Aqueous Solution at 25 degrees

Reference No.: 1307(91AMR)

Talanta, 1991, 38, 449 - 453; Abate L; Maggiore R; Rigano C; De Stefano C; Protonation and Complex Formation Constants of 3-Amino-1,2,4-Triazole in NaCl and CaCl₂ Media at Different Temperatures and Ionic Strengths

Reference No.: 1318(90DSK)

Helv. Chim. Acta, 1990, 73, 140 - 148; Delgado R; Siegfried LC; Kaden TA; Metal Complexes with Macrocyclic Ligands. Part XXXI. Protonation Studies and Complexation Properties of Tetraazamacrocyclic Methylenephosphonates with Earth-Alkali-Ions

Reference No.: 1337(88LDK)

Inorg. Chem., 1988, 27, 3001 - 3012; Lambs L; Decock-Le Reverend B; Kozlowski H; Berthon G; Metal Ion-Tetracycline Interactions in Biological Fluids. 9. Circular Dichroism Spectra of Calcium and Magnesium Complexes with Tetracycline, Oxytetracycline, Doxycycline and Chlortetra- cycline and Discussion of their Binding Modes

Reference No.: 1338(87SAS)

Inorg. Chem., 1987, 26, 1199 - 1204; Sawada K; Araki T; Suzuki T; Complex Formation of Amino Polyphosphonates. 1. Potentiometric and Nuclear Magnetic Resonance Studies of Nitrilotris(methylenephosphonato) Complexes of the Alkaline-Earth-Metal Ions

Reference No.: 1345(88MaS)

Inorg. Chem., 1988, 27, 1447 - 1453; Massoud SS; Sigel H; Metal Ion Coordinating Properties of Pyrimidine-Nucleoside 5'-Monophosphates (CMP,UMP,TMP) and of Simple Phosphate Monoesters, Including D-Ribose 5'-Monophosphate. Establish- ment of Relations between Complex Stability and Phosphate Basicity

Reference No.: 1348(82KaR)

Inorg. Chem., 1982, 21, 3437 - 3442; Kappel MJ; Raymond KN; Ferric Ion Sequestering Agents. 10. Selectivity of Sulfonated Poly(catechoylamides) for Ferric Ion

Reference No.: 1350(86DSM)

Inorg. Chem., 1986, 25, 3879 - 3883; Damu KV; Shaikjee MS; Michael JP; Howard AS; Hancock RD; Control of Metal Ion Selectivity in Ligands Containing Neutral Oxygen and Pyridyl Groups

Reference No.: 1354(87ChW)

Prog. Inorg. Chem., 1987, 35, 329 - 435; Chaudhuri P; Weighardt K; The Chemistry of 1,4,7-Triazacyclononane and Related Tridentate Macrocyclic Compounds

Reference No.: 1369(87STM)

Inorg. Chem., 1987, 26, 2149 - 2157; Sigel H; Tribolet R; Malini-Balakrishnan R; Martin RB; Comparison of the Stabilities of Monomeric Metal Ion Complexes Formed with Adenosine 5'-Triphosphate (ATP) and Pyrimidine-Nucleoside 5'-Triphosphates (CTP, UTP, TTP) and Evaluation of the Isomeric Equilibria in the Complexes of ATP and CTP

Reference No.: 1370(78MoA)

Inorg. Chem., 1978, 17, 2203 - 2207; Mohan MS; Abbott EH; Metal Complexes of Amino Acid Phosphate Esters

Reference No.: 1379(87BGH)

Inorg. Chem., 1987, 26, 2699 - 2706; Bevilacqua A; Gelb RI; Hebard WB; Zompa LJ; Equilibrium and Thermodynamic Study of the Aqueous Complexation of 1,4,7-Triazacyclononane-N,N',N''-triacetic Acid with Protons, Alkaline-Earth-Metal Cations, and Copper(II)

Reference No.: 1384(89HaM)

Chem. Rev., 1989, 89, 1875 - 1914; Hancock RD; Martell AE; Ligand Design for Selective Complexation of Metal Ions in Aqueous Solution

Reference No.: 1394(70Nan)

Coord. Chem. Rev., 1970, 5, 379 - 415; Nancollas GH; The Thermodynamics of Metal-Complex and Ion-Pair Formation

Reference No.: 1437(91SMC)

Pure Appl. Chem., 1991, 63, 1015 - 1080; Smith RM; Martell AE; Chen YT; Critical Evaluation of Stability Constants for Nucleotide Complexes with Protons and Metal Ions

Reference No.: 1456(78MCG)

Acta Chem. Scand., 1978, A32, 79 - 83; Madsen HEL; Christensen HH; Gottlieb-Petersen C; Stability Constants of Copper(II), Zinc(II), Manganese(II), Calcium(II), and Magnesium(II) Complexes of N-(Phosphonomethyl)glycine (Glyphosphate)

Reference No.: 1458(78FGU)

Acta Chem. Scand., 1978, A32, 345 - 352; Forsberg O; Gelland B; Ulmgren P; Wahlberg O; Equilibrium Studies of the Pyruvate Protonation and Metal Pyruvate Complexes in Aqueous Solutions

Reference No.: 1467(88ADD)

Talanta, 1988, 35, 741 - 745; Amorim MTS; Delgado R; da Silva JJRF; Vaz MCTA; Vilhena MF; Metal Complexes of 1-Oxa-4,7,10-Triazacyclododecane- N,N',N''-Triacetic Acid

Reference No.: 1483(87ShC)

Inorg. Chim. Acta, 1987, 139, 119 - 120; Shanbhag SM; Choppin GR; Thermodynamics of Ln(III) Complexation with AMP and ATP

Reference No.: 1491(86ChO)

Inorg. Chem., 1986, 25, 355 - 358; Chang CA; Ochaya VO; Potential Lanthanide Selective Reagents. 3. 1,2 Metal Complex Formation with 1,7-Diaza-4,10,13-trioxacyclopentadecane- N,N'-diacetic Acid

Reference No.: 1502(86TSH)

Inorg. Chem., 1986, 25, 2992 - 3000; Thom VJ; Shaikjee MS; Hancock RD; Small Macrocylic Ligands with Mixed Nitrogen- and Oxygen-Donor Atoms

Reference No.: 1506(80Aru)

Inorg. Chem., 1980, 19, 2895 - 2896; Aruga R; Association Reactions of Magnesium(II), Calcium(II), Strontium(II), and Barium(II) with Malate Ion in Aqueous Solution. Influence of Enthalpy and Entropy Factors on the Stability Order of the Complexes

Reference No.: 1520(85CDD)

Talanta, 1985, 32, 675 - 677; Capone S; De Robertis A; De Stefano C; Scarcella R; Thermodynamics of Formation of Magnesium, Calcium, Strontium and Barium Complexes with 2,2'-Bipyridyl and 1,10-Phenanthroline at Different Ionic Strengths in Aqueous Solution

Reference No.: 1529(87Har)

Talanta, 1987, 34, 817 - 820; Harju L; Determination of Stability Constants for Alkaline- Earth and Alkali Metal Ion Complexes of Glycine by Spectrophotometry

Reference No.: 1535(91ADM)

J. Chem. Res. (S), 1991,, 76 - 77; Abate L; De Stefano C; Mineo P; Complexing Ability of Pesticides and Related Compounds. Protonation of 1,2,4-Triazole in Aqueous Solutions of Sodium Perchlorate and Calcium Chloride at Different Temperatures and Ionic Strengths

Reference No.: 1539(78Kra)

Atlas of Metal-Ligand Equilibria in Aqueous Solution, 1978 Kragten J; Ellis Horwood, Chichester UK

Reference No.: 1541(80HaM)

Inorg. Chem., 1980, 19, 2709 - 2714; Hancock RD; Marsicano F; Parametric Correlation of Formation Constants in Aqueous Solution. 2. Ligands with Large Donor Atoms

Reference No.: 1572(75And)

Helv. Chim. Acta, 1975, 58, 1218 - 1225; Anderegg G; Thermodynamik der Metallkomplexbildung mit Polyoxadiazamacrocyclen

Reference No.: 1583(83NoP)

Polyhedron, 1983, 2, 349 - 351; Noskova D; Podlahova J; Ethylphosphinediacetic Acid: Synthesis, Characterization and Coordinating Behavior towards Ca(II), Ni(II) and Hg(II) Ions in Solution

Reference No.: 1595(79RiK)

Talanta, 1979, 26, 507 - 510; Rizkalla EN; Kazi MTM; Metal Chelates of Phosphonate-containing Ligands - I Stability of Some N,N,N',N'-Ethylenediaminetetra(methylene-phosphonic) Acid Metal Chelates

Reference No.: 1599(80RZI)

Talanta, 1980, 27, 715 - 719; Rizkalla EN; Zaki MTM; Ismail MI; Metal Chelates of Phosphonate-containing Ligands - V Stability of Some 1-Hydroxyethane-1,1-Diphosphonic Acid Metal Chelates

Reference No.: 1621(76ToW)

J. Chem. Soc., Dalton Trans., 1976,, 1355 - 1359; Touche MLD; Williams DR; Thermodynamic Considerations in Co-ordination. Part XXV. Formation of Ternary Complexes containing Two Dissimilar Metal Ions and the Implication for Metal-Metal Stimulation Phenomena in vivo

Reference No.: 1674(80KKY)

J. Chem. Soc., Dalton Trans., 1980,, 2536 - 2538; Kodama M; Kimura E; Yamaguchi S; Complexation of the Macrocyclic Hexa-amine Ligand 1,4,7,10,13,16-Hexa-azacyclo-octadecane ('18-Azacrown-6')

Reference No.: 1685(83EwH)

J. Chem. Soc., Dalton Trans., 1983,, 865 - 868; Ewin G; Hill JO; A Thermometric Titrimetric Study of the Complexation of Alkaline-earth Metals by Linear Poly(aminocarboxylic) Acids

Reference No.: 1711(91DCW)

Inorg. Chem., 1991, 30, 3525 - 3529; de Sousa A; Croft GJB; Wagner CA; Michael JP;

Hancock RD; Effect of Cyclohexylene Bridges on the Metal Ion Size Selectivity of Ligands in Aqueous Solution

Reference No.: 1716(84TaW)

J. Chem. Soc., Faraday Trans. 1, 1984, 80, 2255 - 2267; Tam S-C; Williams RJP; Electrostatic Interactions between Organic Ions

Reference No.: 1720(85Kil)

J. Chem. Soc., Faraday Trans. 1, 1985, 81, 2659 - 2666; Killa HM; Determination of Stability Constants using Linear-scan and Cyclic Voltammograms

Reference No.: 1744(92LCB)

J. Am. Chem. Soc., 1992, 114, 7780 - 7785; Liang G; Chen D; Bastian M; Sigel H; Metal Ion Binding Properties of Dihydroxyacetone Phosphate and Glycerol 1-Phosphate

Reference No.: 1747(92MoM)

Inorg. Chem., 1992, 31, 11 - 15; Motekaitis RJ; Martell AE; Stabilities of Metal Complexes of the Meso and SS Isomers of Oxydisuccinic Acid

Reference No.: 1760(90Bur)

Biocoordination Chemistry, 1990 Burger K; Coordination Equilibria in Biologically Active Systems; Ellis Horwood

Reference No.: 1779(81JMW)

J. Inorg. Nucl. Chem., 1981, 43, 825 - 829; Jackson GE; May PM; Williams DR; Metal-Ligand Complexes Involved in Rheumatoid Arthritis - VII Formation of Binary and Ternary Complexes between 2,3-Diamino- Propionic Acid, Histidine and Cu(II), Ni(II) and Zn(II)

Reference No.: 1783(92GiV)

J. Chem. Soc., Dalton Trans., 1992,, 1375 - 1379; Gibson JF; Vaughan OJ; Chelating Tendencies of N,N'-Bis(2-hydroxyphenyl)-ethylenediamine- N,N'-diacetic Acid

Reference No.: 1786(91DMH)

J. Chem. Soc., Dalton Trans., 1991,, 2717 - 2721; Damu KV; Maumela H; Hancock RD; Boeyens JCA; Dobson SM; Structural and Thermodynamic Study of the Effect of Sterically Hindering Alkyl Groups on Complex Stability

Reference No.: 1823(92LRB)

Inorg. Chim. Acta, 1992, 195, 89 - 93; Lazar I; Ramasamy R; Brucher E; Geraldès CFGC; Sherry AD; NMR and Potentiometric Studies of 1,4,7-triazacyclononane-N,M',N''-tris(Methylenephosphonate monoethylester) and its Complexes with Metal Ions

Reference No.: 1835(92RMH)

Inorg. Chem., 1992, 31, 4854 - 4859; Rothermel GL Jr.; Miao L; Hill AL; Jackels SC; Macrocyclic Ligands with 18-Membered Rings Containing Pyridine or Furan Groups: Preparation, Protonation, and Complexation by Metal Ions

Reference No.: 1847(88MaF)

J. Chem. Soc., Faraday Trans. 1, 1988, 84, 1301 - 1310; Markovic M; Furedi-Milhofer H; Precipitation of Calcium Oxalates from High-ionic-strength Solutions Part 6. - Kinetics of Precipitation from Solutions Supersaturated in Calcium Oxalates and Phosphates

Reference No.: 1853(81LDD)

J. Inorg. Nucl. Chem., 1981, 43, 2429 - 2432; Lalart D; Dodin G; Dubois J-E; Complexation between Oxonic Acid and Divalent Metal Cations. Influence of Metal Salt Addition on Decarboxylation Kinetics under Acidic Conditions

Reference No.: 1860(92SCC)

Helv. Chim. Acta, 1992, 75, 2634 - 2656; Sigel H; Chen D; Corfu NA; Holy A; Strasak B;

Metal-Ion-Coordinating Properties of Various Phosphonate Derivatives including 9-[2-(Phosphonylmethoxy)ethyl]adenine (PMEA)- Adenosine Monophosphate (AMP) Analogue with Antiviral Properties

Reference No.: 1867(92GHN)

Talanta, 1992, 39, 1555 - 1559; Glab S; Hulanicki A; Nowicka U; Coulometric Titration in the Study of Metal Ion-Ligand Equilibria

Reference No.: 1884(78RRK)

J. Inorg. Nucl. Chem., 1978, 40, 1265 - 1267; Reddy PR; Reddy KV; Khan MMT; Thermodynamic Quantities Associated with the Interaction of Xanthosine with Metal Ions

Reference No.: 1892(78KhJ)

J. Inorg. Nucl. Chem., 1978, 40, 1731 - 1733; Khan MMT; Jyoti MS; Mixed Ligand Ternary Chelates of Metal-Cytosine Complexes

Reference No.: 1902(79PoB)

J. Inorg. Nucl. Chem., 1979, 41, 205 - 207; Poldoski JE; Bydalek TJ; Metal Ion Complexes of Ethylene-Bis-N,N'-(2,6-Dicarboxy)Piperidine

Reference No.: 1905(79RRK)

J. Inorg. Nucl. Chem., 1979, 41, 423 - 427; Reddy PR; Reddy KV; Khan MMT; Ternary Complexes of Xanthosine in Solution

Reference No.: 1926(79PSJ)

J. Inorg. Nucl. Chem., 1979, 41, 1759 - 1763; Poonia NS; Sarad SK; Jayakumar A; Kumar GC; Coordination Chemistry of Alkali and Alkaline Earth Cations - 1. Lower Glycols as Ligands

Reference No.: 1940(84DMW)

J. Inorg. Biochem., 1984, 20, 199 - 214; Duffield JR; May PM; Williams DR; Computer Simulation of Metal Ion Equilibria in Biofluids. IV. Plutonium Speciation in Human Blood Plasma and Chelation Therapy Using Polyaminopolycarboxylic Acids

Reference No.: 1941(67LMM)

J. Am. Chem. Soc., 1967, 89, 837 - 843; L'Eplattenier F; Murase I; Martell AE; New Multidentate Ligands. VI. Chelating Tendencies of N,N'-Di(2-hydroxybenzyl)ethylenediamine-N,N'-diacetic Acid

Reference No.: 1947(66IrP)

J. Inorg. Nucl. Chem., 1966, 28, 1629 - 1631; Irving HMNH; Parkins R; Meso- and dl-2,3-Diaminobutane-NNN'N'-Tetra-Acetic Acid and their Metal Complexes

Reference No.: 1956(64And)

Helv. Chim. Acta, 1964, 47, 1801 - 1814; Anderegg G; Komplexe XXXVI. Reaktionsenthalpie und -entropie bei der Bildung der Metalkomplexe der höheren EDTA-Homologen

Reference No.: 1957(57SSA)

Helv. Chim. Acta, 1957, 40, 1886 - 1900; Schwarzenbach G; Senn H; Anderegg G; Complexones. XXIX. A Large Chelation Effect of a Special Sort (Komplexe XXIX. Ein Grosser Chelateffekt besonderer Art)

Reference No.: 1963(63And)

Helv. Chim. Acta, 1963, 46, 1833 - 1842; Anderegg G; Komplexe XXXVIII. Reaktionsenthalpie und -entropie bei der Bildung der Metallkomplexe von Athylendiamin- und Diaminocyclohexan-tetra-essigsäure

Reference No.: 1971(73SaB)

J. Am. Chem. Soc., 1973, 95, 7491 - 7500; Sari JC; Belaich JP; Microcalorimetric Studies on the Formation of Magnesium Complexes with 5' Ribonucleotides of Guanine, Uracil, and Hypoxanthine

Reference No.: 1972(73KhR)

J. Inorg. Nucl. Chem., 1973, 35, 2813 - 2819; Khan HMT; Reddy PR; Thermodynamic Quantities Associated with the Interaction of Guanosine Triphosphate and Inosine Triphosphate with Bivalent Metal Ions

Reference No.: 1978(78NLM)

Chem. Zvesti, 1978, 32, 19 - 26; Novak V; Lucansky J; Majer J; Neue Komplexe. XXXII. Synthese und Studium der Eigenschaften der 2-Methyl-1,2-diaminopropan-N,N',N'-tetraessigsäure

Reference No.: 1979(74RMB)

Chem. Zvesti, 1974, 28, 332 - 335; Riečanská E; Majer J; Bumbalová A; Kalina M; Neue Komplexe. XXIX. Potentiometrisches Studium chelatbildender Eigenschaften von N,N-Biskarboxymethyl-2-aminoalkansäuren

Reference No.: 1981(79MBN)

Chem. Zvesti, 1979, 33, 742 - 748; Majer J; Butvin P; Novak V; Svěčková M; Fuleová E; Valasková I; Novak J; New Complexes. XXXV. Properties of 1,2-Diaminooctane-N,N,N',N'-tetraacetic Acid

Reference No.: 1982(63And)

Helv. Chim. Acta, 1963, 46, 1011 - 1017; Anderegg G; Pyridinderivate als Komplexbildner IV. Die Metalkomplexe der Chelidamsäure

Reference No.: 1996(80MRP)

Chem. Zvesti, 1980, 34, 93 - 103; Majer J; Riečanská E; Pikulíková Z; Svěčková M; Neue Komplexe. XXXVIII. d,l-N-(2,3-Dihydroxypropyl)-N-karboxy-methylaminoessigsäure Synthese, Studium der azidobasischen Eigenschaften, Chelatbildung mit Kationen der Erdalkalimetalle und mit zweiwertigen Kationen von Schwermetallen

Reference No.: 1997(68MaR)

Chem. Zvesti, 1968, 22, 15 - 24; Majer J; Riečanská E; Nove Komplexy (XI). Komplexotvorné Vlastnosti Kyseliny beta-hydroxyetylaminomonopropionové- α -monooctové a N,N-bishydroxy-etylalaninu- α

Reference No.: 2000(63MaD)

Chem. Zvesti, 1963, 17, 402 - 410; Majer J; Dvoráková E; Nove Komplexy. (I). Komplexy mezo-kyseliny a Racemickej Kyseliny 2,3-diaminobutan-N,N,N',N'-tetraoctové s Kovmi Alkalických Zemin

Reference No.: 2004(66MKD)

Chem. Zvesti, 1966, 20, 242 - 251; Majer J; Kotouček M; Dvoráková E; Nove Komplexy. (V). Komplexy Kyseliny Ethylendiamin-N,N'-dipropionové- α,α' a Kyseliny Ethylendiamin-N,N'-dipropionové- α,α' -N,N'-dioctové s Kationy Alkalických Zemin a s Nekterými Dalsími Dvojmocnými Kationy

Reference No.: 2006(68MJD)

Chem. Zvesti, 1968, 22, 415 - 423; Majer J; Jokl V; Dvoráková E; Jurcova M; Nove Komplexy. (XIII). Potenciometrické a Elektroforetické Studium Kyseliny Ethylendiamin-N,N'-dijantarové a jej Kovových Chelátov

Reference No.: 2008(69NDS)

Chem. Zvesti, 1969, 23, 861 - 868; Novak V; Dvoráková E; Svěčková M; Majer J; New Complexes. XIX. Complex-forming Properties of Ethylenediamine-N,N'-diacetic-N,N'-(2,2'-dialkanecarboxylic) Acids

Reference No.: 2009(80MVV)

Chem. Zvesti, 1980, 34, 637 - 644; Majer J; van Quy T; Valaskova I; Elektrophoretisches Studium der Komplexbildenden Eigenschaften der N-(Methylphosphon)iminodiessigsäure und der Glycin-N,N-bis(methyl- phosphonsäure)

Reference No.: 2010(69NDS)

Chem. Zvesti, 1969, 23, 330 - 335; Novak V; Dvorakova E; Svicekova M; Majer J; Neue Komplexe. XVII. Studium der Chelate der Phenylathylendiamin- tetraessigsäure

Reference No.: 2011(69NDM)

Chem. Zvesti, 1969, 23, 161 - 165; Novak V; Dvorakova E; Majer J; Neue Komplexe. XVI. Acidobasische und Chelatbildende Eigenschaften der Komplexe vom Typ der 1,2-Diaminoalkan- und 1,2-Diaminoiso- alkan-N,N,N',N'-tetraessigsäuren

Reference No.: 2015(70AIP)

J. Chem. Soc. (A), 1970,, 2649 - 2651; Advani AT; Irving HMNH; Pettit LD; Formation Constants of Bis- and Tris-complexes of Optically Active Bidentate Ligands

Reference No.: 2016(82DeF)

Talanta, 1982, 29, 815 - 822; Delgado R; Frausto da Silva JJR; Metal Complexes of Cyclic Tetra-azatetra-acetic Acids

Reference No.: 2017(80SHP)

Aust. J. Chem., 1980, 33, 2207 - 2220; Stunzi H; Harris RLN; Perrin DD; Teitei T; Stability Constants for Metal Complexation by Isomers of Mimosine and Related Compounds

Reference No.: 2018(69SSP)

J. Inorg. Nucl. Chem., 1969, 31, 2085 - 2090; Simeon VI; Svirg B; Paulic N; Thermodynamics of Co-ordination of Alkaline-earth Cations to some C.C'-Substituted EDTA Derivatives

Reference No.: 2019(63GHW)

J. Inorg. Nucl. Chem., 1963, 25, 1225 - 1238; Grimes JH; Huggard AJ; Wilford SP; The Stabilities of the Alkaline Earth Chelates of some Polyaminopolycarboxylic Acids

Reference No.: 2023(77MCS)

Bull. Soc. Chim. Fr., 1977,, 59 - 63; Makridou C; Cromer-Morin M; Scharff J-P; Complexation de Quelques Ions Metalliques par les Acides Galacturonique et Glucuronique

Reference No.: 2031(85VBH)

Inorg. Chem., 1985, 24, 1208 - 1213; van der Merwe M; Boeyens JCA; Hancock RD; Crystallographic and Thermodynamic Study of Metal Ion Size Selectivity in the Ligand 1,4,7-Triazacyclononane-N,N',N''-triacetate

Reference No.: 2037(70VdA)

Helv. Chim. Acta, 1970, 53, 569 - 576; v.d. Linden W; Anderegg G; Komplexe XLIV. Die Komplexe der Anionen der Triäthylentetramin- hexa-Essigsäure mit Calcium(II), Kupfer(II) und Zink(II)

Reference No.: 2038(70AnM)

Helv. Chim. Acta, 1970, 53, 564 - 569; Anderegg G; Malik S; Komplexe XLIII. Die Komplexe des Dreiwertigen Antimons mit Polyaminocarboxylaten

Reference No.: 2039(68And)

Helv. Chim. Acta, 1968, 51, 1856 - 1863; Anderegg G; Zur Deutung der thermodynamischen Daten von Komplexbildungs- reaktionen I

Reference No.: 2040(65And)

Helv. Chim. Acta, 1965, 48, 1718 - 1721; Anderegg G; Komplexe XXXVIII.

Reaktionsenthalpie und -entropie bei der Bildung der 1:1- und 1:2-Metallkomplexe von Methyliminodiessigsäure

Reference No.: 2041(65AnB)

Helv. Chim. Acta, 1965, 48, 887 - 892; Anderegg G; Bottari E; Pyridinderivate als Komplexbildner VII. Über die Koordinationstendenz von substituierten Dipicolinat-Ionen

Reference No.: 2043(64LeA)

Helv. Chim. Acta, 1964, 47, 1792 - 1800; L'Eplattenier F; Anderegg G; Komplexe XXXV. Die Metallkomplexe der Tri- und der Tetramethylen-diamin-NN'-tetraessigsäure

Reference No.: 2057(63IrP)

J. Chem. Soc., 1963, 1546 - 1553; Irving H; Pettit LD; The Stabilities of Metal Complexes of Some C-Substituted Derivatives of Glycine

Reference No.: 2060(59Bur)

Biochem. J., 1959, 71, 388 - 395; Burton K; Formation Constants for the Complexes of Adenosine Di- or Tri-phosphate with Magnesium or Calcium Ions

Reference No.: 2086(66Sht)

J. Inorg. Nucl. Chem., 1966, 28, 845 - 861; Shtacher G; Potentiometric Determination of Stability Constants of Metal Complexes with Certain Amino Dicarboxylic Acids

Reference No.: 2117(59Per)

J. Chem. Soc., 1959, 290 - 296; Perrin DD; The Stability of Iron Complexes. Part III. A Comparison of 1:1 Ferric and Ferrous Amino-acid Complexes

Reference No.: 2121(61MoF)

J. Inorg. Nucl. Chem., 1961, 20, 261 - 273; Moller T; Ferrus R; Observations on the Rare Earths - LXXVIII. The Heat and Entropy of Formation of the 1:1 Chelates of N-Hydroxyethylethylenediaminetri-acetic Acid with the Tripositive Cations

Reference No.: 2131(93SKN)

J. Chem. Soc., Dalton Trans., 1993, 2557 - 2562; Sawada K; Kanda T; Naganuma Y; Suzuki T; Formation and Protonation of Aminopolyphosphonate Complexes of Alkaline-earth and Divalent Transition-metal Ions in Aqueous Solution

Reference No.: 2141(79StP)

J. Inorg. Biochem., 1979, 10, 309 - 316; Stunzi H; Perrin DD; Stability Constants of Metal Complexes of Phosphonoacetic Acid

Reference No.: 2152(83Mor)

Principles of Aquatic Chemistry, 1983 Morel FMM; John Wiley & Sons

Reference No.: 2160(84LBB)

Agents Actions, 1984, 14, 743 - 750; Lambs L; Brion M; Berthon G; Metal Ion-tetracycline Interactions in Biological Fluids. Part 3. Formation of Mixed-metal Ternary Complexes in Tetracycline, Oxytetracycline, Doxycycline and Minocycline with Calcium and Magnesium, and their Involvement in the Bioavailability of these Antibiotics in Blood Plasma

Reference No.: 2166(81BBF)

Inorg. Chim. Acta, 1981, 55, 47 - 56; Brion M; Berthon G; Fourtillan J-B; Metal Ion-Tetracyclines Interactions in Biological Fluids. Potentiometric Study of Calcium Complexes with Tetracycline, Oxytetracycline, Doxycycline and Minocycline and Simulation of their Distributions under Physiological Conditions

Reference No.: 2170(85LBB)

Inorg. Chim. Acta, 1985, 106, 151 - 158; Lambs L; Brion M; Berthon G; Metal Ion-Tetracycline Interactions in Biological Fluids. Part 4. Potential Influence of Ca²⁺ and Mg²⁺ Ions on the Bioavailability of Chlortetracycline and Demethylchlortetracycline, as Expected from their Computer-Simulated Distributions in Blood Plasma

Reference No.: 2174(77MaW)

J. Inorg. Nucl. Chem., 1977, 39, 201 - 204; Makar GKR; Williams DR; A Study of the Bio-availability of Dietary Zinc using Computer Simulation Models of the Co-ordination Equilibria Involved

Reference No.: 2181(87BlB)

Inorg. Chim. Acta, 1987, 135, 179 - 189; Blaquiere C; Berthon G; Speciation Studies in Relation to Magnesium Bioavailability. Formation of Mg(II) Complexes with Glutamate, Aspartate, Glycinate, Lactate, Pyroglutamate, Pyridoxine and Citrate, and Appraisal of their Potential Significance towards Magnesium Gastrointestinal Absorption

Reference No.: 2182(85HCW)

Inorg. Chim. Acta, 1985, 107, L29 - L32; Huang Z-X; Creighton AM; Williams DR; Metal Binding Properties of Two Homologues of Razoxane, a Bisdioxopiperazine Antitumour Drug

Reference No.: 2194(88KRZ)

J. Chem. Soc., Dalton Trans., 1988,, 67 - 71; Khan BT; Raju M; Zakeeruddin SM; Binary and Ternary Complexes of Guanosine: Stability and Thermodynamic Parameters

Reference No.: 2209(93KLR)

Talanta, 1993, 40, 999 - 1003; Kaila L; Lajunen LHJ; Rizkalla EN; Eloranta J; Thermodynamics of Complexation of Magnesium and Calcium Ions with Dichloromethylenediphosphonate

Reference No.: 2251(87Bus)

J. Solution Chem., 1987, 16, 181 - 190; Buschmann H-J; Stability Constants and Thermodynamic Data for Complexes of 12-Crown-4 with Alkali Metal and Alkaline-Earth Cations in Methanol Solutions

Reference No.: 2260(90DaO)

Acta Chem. Scand., 1990, 44, 321 - 327; Dahlund M; Olin A; A Spectrophotometric Study of the Complexation of Olsalazine and Salicylic Acid with Calcium and Magnesium

Reference No.: 2261(93PeP)

IUPAC Stability Constants Database, 1993 Pettit LD; Powell HKJ; IUPAC (in co-operation with Academic Software), Otley, UK

Reference No.: 2269(93BrN)

Acta Chem. Scand., 1993, 47, 668 - 673; Brecevic L; Nielsen AE; Solubility of Calcium Carbonate Hexahydrate

Reference No.: 2281(93WLH)

J. Chem. Soc., Dalton Trans., 1993,, 2017 - 2021; Wambeke DM; Lippens W; Herman GG; Goeminne AM; Metal-ion Complexation in Aqueous Solutions of 1-Thia-4,7-diazacyclononane-, 1-Thia-4,8-diazacyclodecane- and 2,5-Diazaheptane-N,N-diacetic Acid

Reference No.: 2292(92GMR)

J. Chem. Soc., Dalton Trans., 1992,, 475 - 479; Gajda T; Nagy L; Rozlosnik N; Korecz L; Burger K; Equilibrium and Spectroscopic Studies of Transition Metal Complexes of Sugar-containing Thiazolidine Derivatives

Reference No.: 2308(74MSM)

J. Inorg. Nucl. Chem., 1974, 36, 2033 - 2038; Miyazaki M; Shimoishi Y; Miyata H; Toei

K; The Reaction of Dicarboxylic Acids Containing Ether Linkages with Alkaline Earth Metals

Reference No.: 2326(74KhK)

J. Inorg. Nucl. Chem., 1974, 36, 711 - 714; Khan MMT; Krishnamoorthy CR; Interactions of Metal Ions with Pyrimidines

Reference No.: 2343(74KOK)

J. Inorg. Nucl. Chem., 1974, 36, 1605 - 1609; Kura G; Ohashi S; Kura S; Complex Formation of Cyclic Phosphate Anions with Bivalent Cations

Reference No.: 2350(89Lau)

Comprehensive Coordination Chemistry, Vol. 2, 1989, 739 - 776; Laurie SH; Amino Acids, Peptides and Proteins

Reference No.: 2360(83Van)

Polyhedron, 1983, 2, 285 - 289; van Uitert LG; Chelate Compound Stability Constant Calculations on Metal Diketonate Complexes

Reference No.: 2366(87WGM)

Comprehensive Coordination Chemistry, Vol. 2, 1987 Wilkinson G; Gillard RD; McCleverty JA; The Synthesis, Reactions, Properties and Applications of Coordination Compounds; Pergamon, Oxford

Reference No.: 2371(83ReR)

Polyhedron, 1983, 2, 1171 - 1175; Reddy PR; Reddy MH; Ternary Complexes of Mixed N/O Donor Ligands in Solution

Reference No.: 2373(89And)

Comprehensive Coordination Chemistry, Vol. 2, 1989, 777 - 792; Anderegg G; Complexones

Reference No.: 2403(79WoN)

Talanta, 1979, 26, 381 - 388; Wozniak M; Nowogrocki G; Acidites et Complexes des Acides (Alkyl- et Aminoalkyl-) Phosphoniques - III. Alkylphosphonates substitues de Calcium(II) et Cuivre(II)

Reference No.: 2406(79VST)

Talanta, 1979, 26, 982 - 983; Verma HS; Singh SP; Tandon JP; Formation Constants of Ternary Complexes of Vanadium(IV) with Picolinic Acid and Salicylic or 5-Sulphosalicylic Acid

Reference No.: 2408(79WoN)

Talanta, 1979, 26, 1135 - 1141; Wozniak M; Nowogrocki G; Acidites et Complexes des Acides (Alkyl- et Aminoalkyl-) Phosphoniques -IV. Acides Aminoalkylphosphoniques R1R2N(CH2)nCR3R4PO3H2

Reference No.: 2422(81Aru)

Aust. J. Chem., 1981, 34, 501 - 506; Aruga R; Coordinating Properties of Pyrrolic and Pyridinic Nitrogen with Metals in Aqueous Solution. A Calorimetric Study

Reference No.: 2462(93MaM)

Inorg. Chim. Acta, 1993, 209, 71 - 78; Ma R; Martell AE; Protonation Constants and Metal Ion Binding Constants of N,N'-Bis(2-hydroxyphenyl)-N,N'-ethylenediaminediacetic Acid

Reference No.: 2469(92GhS)

J. Coord. Chem., 1992, 26, 337 - 344; Ghasemi J; Shamsipur M; Fluorimetric Study of Complexation of Alkali and Alkaline Earth Cations with 1,10-Phenanthroline, 2,2'-Bipyridine and 8-Hydroxy-Quinoline in Nonaqueous Solvents

Reference No.: 2495(71GrC)

J. Phys. Chem., 1971, 75, 676 - 682; Grabenstetter RJ; Cilley WA; Polynuclear Complex Formation in Solutions of Calcium Ion and Ethane-1-hydroxy-1,1-diphosphonic Acid. I. Complexometric and pH Titrations

Reference No.: 2511(92Bus)

Inorg. Chim. Acta, 1992, 195, 51 - 61; Buschmann H-J; A Comparison of Different Experimental Techniques for the Determination of the Stabilities of Polyether, Crown Ether and Cryptand Complexes in Solution

Reference No.: 2516(91DLL)

Inorg. Chim. Acta, 1991, 188, 55 - 59; Duckworth PA; Lincoln SF; Lucas J; The Complexation of Divalent Metal Ions by the Cryptand 4,7,13-Trioxa-1,10-diazabicyclo[8.5.5]eicosane (C21C5) in Water and 95% Methanol/Water Solutions

Reference No.: 2522(91VNS)

Inorg. Chim. Acta, 1991, 184, 59 - 65; van Truong Ng.; Norris AR; Shin HS; Buncel E; Bannard RAB; Purdon JG; Selectivities and Thermodynamic Parameters of Alkali-metal and Alkaline-earth-metal Complexes of Polyethylene Glycol Dimethyl Ethers in Methanol and Acetonitrile

Reference No.: 2527(91ClM)

Inorg. Chim. Acta, 1991, 190, 27 - 36; Clarke ET; Martell AE; Stabilities of the Alkaline Earth and Divalent Transition Metal Complexes of the Tetraazamacrocyclic Tetraacetic Acid Ligands

Reference No.: 2542(82SSP)

Inorg. Chim. Acta, 1982, 66, 147 - 155; Sigel H; Scheller KH; Prus B; Metal Ion/Buffer Interactions. Stability of Alkali and Alkaline Earth Ion Complexes with Triethanolamine (Tea), 2-Amino-2(hydroxy-methyl)-1,3-Propanediol (Tris) and 2-[Bis(2-hydroxyethyl)amino]2 (hydroxymethyl)-1,3-propanediol (Bistris) in Aqueous and Mixed Solvents

Reference No.: 2551(91And)

Inorg. Chim. Acta, 1991, 180, 69 - 72; Anderegg G; Correlation between Thermodynamic Functions of Metal Complex Formation and Basicities of the Iminodiacetate Derivatives

Reference No.: 2556(93MSM)

NIST Critical Stability Constants of Metal Complexes Database, 1993 Martell AE; Smith RM; Motekaitis RJ; Version 1.0; National Institute of Standards and Technology, Gaithersburg, USA

Reference No.: 2558(54Cha)

J. Am. Chem. Soc., 1954, 76, 5854 - 5858; Charles RG; Heats and Entropies of Reaction of Metal Ions with Ethylenediaminetetraacetate

Reference No.: 2563(92WuF)

Acta Chem. Scand., 1992, 46, 418 - 422; Wu L; Forsling W; Potentiometric and Spectrophotometric Study of Calcium and Alizarin Red S Complexation

Reference No.: 2591(66IrM)

J. Chem. Soc. (A), 1966,, 1268 - 1275; Irving HMNH; Miles MG; Analogues of Nitrilotriacetic Acid, and the Stabilities of their Proton and Metal Complexes

Reference No.: 2595(66IrM)

J. Chem. Soc. (A), 1966,, 727 - 732; Irving HMNH; Miles MG; Aryl Derivatives of Nitrilotriacetic Acid, and the Stability of Their Proton and Metal Complexes

Reference No.: 2596(67CCI)

Inorg. Chem., 1967, 6, 943 - 946; Carter RP; Crutchfield MM; Irani RR;

Nitrilotri(methylenephosphonic acid)N-Oxide and Nitrilotriacetic Acid N-Oxide: Acidity and Complexing of Calcium and Magnesium Ions

Reference No.: 2599(88JTJ)

J. Chem. Soc., Faraday Trans. 1, 1988, 84, 951 - 958; Juillard J; Tissier C; Jeminet G; Interactions between Metal Cations and the Ionophore Lasalocid Part 1. Complexation of Alkaline-earth-metal Cations by Lasalocid, Bromolasalocid and Salicylic Acid in Methanol

Reference No.: 2603(56CaS)

J. Chem. Soc., 1956,, 4571 - 4579; Care RA; Staveley LAK; The Thermodynamics of the Formation of Complex Ions of Ethylenediaminetetra-acetic Acid and Bivalent Cations

Reference No.: 2604(82BDJ)

Can. J. Chem., 1982, 60, 981 - 989; Bolte J; Demuyne C; Jeminet G; Juillard J; Tissier C; Etude Comparee de Trois Antibiotiques Ionophores: X.537 A (Lasalocid), A.23187 (Calcimycine) et X.14547 A. Complexation des Cations IA et IIA, Transport de Ca++

Reference No.: 2648(77Sig)

J. Inorg. Nucl. Chem., 1977, 39, 1903 - 1911; Sigel H; Comparison of the Stabilities of Binary and Ternary Complexes of Divalent Metal Ions with the 5'-Triphosphates of Adenosine, Inosine, Guanosine, Cytidine, Uridine and Thymidine

Reference No.: 2699(45SKS)

Helv. Chim. Acta, 1945, 28, 1133 - 1143; Schwarzenbach G; Kampitsch E; Steiner R; Komplexe II. Das Komplexbildungsvermogen von Iminodiessigsaeure, Methylimino-diessigsaeure, Aminomalonsaeure und Aminomalonsaeure -diessigsaeure

Reference No.: 2712(76PaA)

Inorg. Chim. Acta, 1976, 17, 213 - 216; Parthasarathy S; Ambujavalli S; Energetics of Complex Formation of Calcium and Magnesium Ions with O-Donor Ligands

Reference No.: 2713(93GhS)

J. Coord. Chem., 1993, 28, 231 - 236; Ghasemi J; Shamsipur M; Spectrophotometric Study of Complex Formation between some Alkali and Alkaline Earth Cations and Several Conventional (N,N), (N,O) and (O,O) Ligands in 95% Ethanol

Reference No.: 2717(93BGE)

J. Chem. Soc., Chem. Commun., 1993,, 574 - 575; Brucher E; Gyori B; Emri J; Solymosi P; Sztanyik LB; Varga L; 1,10-Diaza-4,7,13,16-tetraoxacyclooctadecane-1,10-bis(malonate), a Ligand With High Sr²⁺/Ca²⁺ and Pb²⁺/Zn²⁺ Selectivities in Aqueous Solution

Reference No.: 2756(72WaF)

Anal. Chem., 1972, 44, 1640 - 1643; Wada H; Fernando Q; Interaction of Methanediethoxyphosphonic Acid and Ethane-1-hydroxy-1,1-diphosphonic Acid with Alkali and Alkaline Earth Metal Ions

Reference No.: 2780(80RiZ)

Talanta, 1980, 27, 769 - 770; Rizkalla EN; Zaki MTM; Metal Chelates of Phosphonate-containing Ligands - VI. Complexes of Ethylenediaminetetra(methylenephosphonic) Acid with Cd, Mg, Ca and Ba

Reference No.: 2804(80Pea)

Aust. J. Chem., 1980, 33, 1511 - 1517; Pearce KN; Formation Constants for Magnesium and Calcium Citrate Complexes

Reference No.: 2805(81BeK)

Aust. J. Chem., 1981, 34, 2563 - 2568; Beattie JK; Kelso MT; Equilibrium and Dynamics of the Binding of Calcium Ion to Sorbitol (D-Glucitol)

Reference No.: 2876(93SMS)

J. Chem. Soc., Dalton Trans., 1993,, 3777 - 3784; Sawada K; Miyagawa T; Sakaguchi T; Doi K; Structure and Thermodynamic Properties of Aminopolyphosphonate Complexes of the Alkaline-earth Metal Ions

Reference No.: 2906(88SMT)

J. Am. Chem. Soc., 1988, 110, 6857 - 6865; Sigel H; Massoud SS; Tribolet R; Comparison of the Metal Ion Coordinating Properties of Tubercidin 5'-Monophosphate (7-Deaza-AMP) with Those of Adenosine 5'-Monophosphate (AMP) and 1,N6-Ethenoadenosine 5'-Monophosphate (epsilon-AMP). Definite Evidence for Metal Ion-Base Backbinding to N-7 and Extent of Macrochelate Formation in M(AMP) and M(epsilon-AMP)

Reference No.: 2920(84CVS)

J. Am. Chem. Soc., 1984, 106, 1273 - 1280; Cox BG; van Truong Ng.; Schneider H; Alkaline Earth Cryptands: Dynamics and Stabilities in Different Solvents

Reference No.: 2924(83GGM)

J. Am. Chem. Soc., 1983, 105, 6786 - 6788; Gokel GW; Goli DM; Minganti C; Echegoyen L; Clarification of the Hole-Size Cation-Diameter Relationship in Crown Ethers and a New Method for Determining Calcium Cation Homogeneous Equilibrium Binding Constants

Reference No.: 2931(81CGS)

J. Am. Chem. Soc., 1981, 103, 1384 - 1389; Cox BG; Garcia-Rosas J; Schneider H; Solvent Dependence of the Stability of Cryptate Complexes

Reference No.: 2944(80LIS)

J. Am. Chem. Soc., 1980, 102, 475 - 479; Lamb JD; Izatt RM; Swain CS; Christensen JJ; A Systematic Study of the Effect of Macrocyclic Ring Size and Donor Atom Type on the Log K, delta H, and T delta S of Reactions at 25 C in Methanol of Mono- and Divalent Cations with Crown Ethers

Reference No.: 2961(78MiS)

J. Am. Chem. Soc., 1978, 100, 1564 - 1570; Mitchell PR; Sigel H; Enhanced Stability of Ternary Metal Ion/Adenosine 5'-Triphosphate Complexes. Cooperative Effects Caused by Stacking Interactions in Complexes Containing Adenosine Triphosphate, Phenanthroline, and Magnesium, Calcium, or Zinc Ions

Reference No.: 3005(93BDS)

J. Coord. Chem., 1993, 30, 311 - 316; Buschmann H-J; Dong H; Schollmyer E; Complexation of Alkaline Earth Cations by Noncyclic Polyethers, Crown Ethers, and Cryptands in Acetone

Reference No.: 3006(85BPJ)

Standard Potentials in Aqueous Solution, 1985 Bard AJ; Parsons R; Jordan J; Monographs in Electroanalytical Chemistry and Electrochemistry; Marcel Dekker Inc., New York and Basel

Reference No.: 3052(74AnW)

Finn. Chem. Lett., 1974,, 156 - 158; Antikainen PJ; Witikainen U; The Oxyanion Chelates of o-Diphenols. Part VIII. The Chelation of Boric Acid with Dopamine

Reference No.: 3082(73StC)

J. Inorg. Nucl. Chem., 1973, 35, 1621 - 1636; Steger HF; Corsini A; Stability of Metal Oxinates - I. Effect of Ligand Basicity

Reference No.: 3083(68CaI)

J. Inorg. Nucl. Chem., 1968, 30, 2971 - 2976; Carroll RL; Irani RR; On the deltaH and deltaS of Metal Ion Interaction with Substituted Methylene Diphosphonates

Reference No.: 3094(75DaN)

J. Inorg. Nucl. Chem., 1975, 37, 991 - 993; Das AR; Nair VSK; Studies on Metal Complexes in Aqueous Solution - VIII. Glycollates of Copper and Calcium and Mandelates of Calcium

Reference No.: 3147(76RRK)

J. Inorg. Nucl. Chem., 1976, 38, 1923 - 1924; Reddy PR; Reddy KV; Khan MMT; Interaction of Metal Ions with Xanthosine

Reference No.: 3154(76MKD)

J. Inorg. Nucl. Chem., 1976, 38, 1207 - 1210; McDowell WJ; Keller OL Jr; Dittner PE; Tarrant JR; Case GN; Nobelium Chemistry: Aqueous Complexing with Carboxylate Ions

Reference No.: 3159(76KhR)

J. Inorg. Nucl. Chem., 1976, 38, 1234 - 1236; Khan MMT; Reddy PR; Interaction of Metal Ions with Uridine Triphosphate

Reference No.: 3180(75RaM)

J. Inorg. Nucl. Chem., 1975, 37, 363 - 367; Ramamoorthy S; Manning PG; Equilibrium Studies of Solutions Containing Al³⁺, Ca²⁺ or Cd²⁺ and Cysteine, Orthophosphate and a Carboxylic Acid

Reference No.: 3181(75DRK)

J. Inorg. Nucl. Chem., 1975, 37, 369 - 374; Davankov VA; Rogozhin SV; Kurganov AA; Zhuchkova IYa; Stereoselectivity in bis(alpha-Amino Acid)Copper(II) Complexes - II Spectrophotometric and Spectropolarimetric Investigation of the Solvent Effect

Reference No.: 3186(75KhR)

J. Inorg. Nucl. Chem., 1975, 37, 771 - 774; Khan MMT; Reddy PR; Interaction of Metal Ions with Cytidinetriphosphate

Reference No.: 3201(77DCV)

J. Inorg. Nucl. Chem., 1977, 39, 613 - 619; da Silva JJRF; Candida M; Vaz TA; The Thermodynamics of Complex Formation between Uramildiacetic Acid and the Alkaline-Earth Metals

Reference No.: 3215(68NaP)

Inorg. Chem., 1968, 7, 58 - 62; Nancollas GH; Park AC; Thermodynamics of Ion Association. XVI. Bivalent Metal Complexes Involving Nitrogen and Oxygen Coordination

Reference No.: 3283(75LeS)

J. Am. Chem. Soc., 1975, 97, 6700 - 6707; Lehn J-M; Sauvage JP; [2]-Cryptates: Stability and Selectivity of Alkali and Alkaline-Earth Macrobicyclic Complexes

Reference No.: 3363(82RaR)

Monatsh. Chem., 1982, 113, 399 - 407; Rainer MJA; Rode BM; The Complex Formation of Calcium with Aliphatic Dipeptides

Reference No.: 3478(52ScL)

J. Am. Chem. Soc., 1952, 74, 3529 - 3532; Schubert J; Lindenbaum A; Stability of Alkaline Earth-Organic Acid Complexes Measured by Ion Exchange

Reference No.: 3481(67KhM)

J. Am. Chem. Soc., 1967, 89, 5585 - 5590; Khan MMT; Martell AE; Thermodynamic Quantities Associated with the Interaction of Adenosinediphosphoric and Adenosinemonophosphoric Acids with Metal Ions

Reference No.: 3482(66KhM)

J. Am. Chem. Soc., 1966, 88, 668 - 671; Khan MMT; Martell AE; Thermodynamic Quantities Associated with the Interaction of Adenosine Triphosphate with Metal Ions

Reference No.: 3486(55SAS)

Helv. Chim. Acta, 1955, 38, 1147 Schwarzenbach G; Anderegg G; Schneider W; Senn H; Complexons. XXVI. The Co-ordination Tendency of N-Substituted Iminoacetic Acids (Komplexe XXVI. Über die Koordinationstendenz von N-Substituierten Iminodiestersäuren)

Reference No.: 3492(73FJU)

Chem. Scr., 1973, 3, 153 - 158; Fosberg O; Johansson K; Ulmgren P; Wahlberg O; Equilibrium Studies of L-Ascorbate Ions. VI. Calcium Complexes; Strategy and Experiments. The Weak Complex Formation Complex Formation

Reference No.: 3493(73ULW)

Chem. Scr., 1973, 3, 193 - 200; Ulmgren P; Wahlberg O; Equilibrium Studies of L-Ascorbate Ions. VIII. Calcium Complexes; Application of the LETAGROP Method

Reference No.: 3504(68Doo)

Pharm. Weekbl., 1968, 103, 1213 - 1227; Doornbos DA; Stability Constants of Metal Complexes of L-Cysteine, D-Penicillamine and N-Acetyl-D-Penicillamine and Some Biguanidides

Reference No.: 3511(70CLM)

J. Inorg. Nucl. Chem., 1970, 32, 911 Clarke ER; Martell AE; Metal Chelates of Arginine and Related Ligands

Reference No.: 3519(75FCM)

Anal. Chim. Acta, 1975, 74, 101 Field TB; Coburn J; McCourt JL; McBryde WAE; Composition and Stability of Some Metal Citrate and Diglycolate Complexes in Aqueous Solution

Reference No.: 3520(74Mey)

Anal. Biochem., 1974, 62, 295 Meyer JL; Formation Constants for Interaction of Citrate with Calcium and Magnesium Ions

Reference No.: 3540(79CMT)

Analyst, 1979, 104, 961 - 972; Craggs A; Moody GJ; Thomas JDR; Calcium Ion-selective Electrode Measurements in the Presence of Complexing Ligands

Reference No.: 3549(79ZJD)

J. Pharm. Sci., 1979, 68, 426 - 432; Zucconi TD; Janauer GE; Donahe S; Lewkowicz C; Acid Dissociation and Metal Complex Formation Constants of Penicillamine, Cysteine, and Antiarthritic Gold Complexes at Simulated Biological Conditions

Reference No.: 3565(85ReR)

J. Chem. Soc., Dalton Trans., 1985,, 239 - 242; Reddy PR; Reddy MH; Influence of Secondary Ligands on the Stability of Metal-Xanthosine Complexes in Solution

Reference No.: 3572(63ALS)

Helv. Chim. Acta, 1963, 46, 1400 - 1408; Anderegg G; L'Eplattenier F; Schwarzenbach G; Hydroxamatkomplexe II. Die Anwendung der pH-Methode

Reference No.: 3584(85SmM)

Biochim. Biophys. Acta, 1985, 839, 287 - 299; Smith GL; Miller DJ; Potentiometric Measurements and Constants of EGTA for Protons and Divalent Ions including Calcium

Reference No.: 3595(86DDS)

J. Chem. Res. (S), 1986,, 164 - 165; De Robertis A; De Stefano C; Sammartano S; Cali R; Purrello R; Rigano C; Alkali-metal and Alkaline-earth-metal Ion Complexes with Adenosine 5'-triphosphate in Aqueous Solution. Thermodynamic Parameters and their Dependence on Temperature and Ionic Strength

Reference No.: 3617(82HaN)

S. Afr. J. Chem., 1982, 35, 153 - 156; Hancock RD; Nankani BS; Linear Free Energy Relationships and the Chelate Effect in Oxygen Donor Ligands

Reference No.: 3621(75DaN)

J. Inorg. Nucl. Chem., 1975, 37, 2121 - 1408; Das AR; Nair VSK; Studies on Metal Complexes in Aqueous Solution - X. Malates of Copper and Calcium

Reference No.: 3676(63SSA)

Helv. Chim. Acta, 1963, 46, 1391 - 1423; Schwarzenbach G; Schwarzenbach K; Anderegg G; L'Eplattenier F; Hydroxamatkomplexe I. Die Stabilität der Eisen(III)-Komplexe einfacher Hydroxamsäuren und des Ferrioxamine B and Hydroxamatkomplexe II. Die Anwendung der pH-Methode and Hydroxamatkomplexe III. Eisen(III)-Austausch zwischen Sideraminen und Komplexonen. Diskussion der Bildungskonstanten der Hydroxamatkomplexe

Reference No.: 3683(64HDS)

J. Chem. Soc., 1964,, 5422 - 5425; Hull JA; Davies RH; Staveley LAK; Thermodynamics of the Formation of Complexes of Nitrilotriacetic Acid and Bivalent Cations

Reference No.: 3712(81And)

Helv. Chim. Acta, 1981, 64, 1790 - 1795; Anderegg G; The Stability of Divalent 3d- and Trivalent 4f-Metal Complexes with Diazapolyoxa Macrocyclic Ligands

Reference No.: 3802(89FRR)

Polyhedron, 1989, 8, 2693 - 2699; Fuentes J; Reboso R; Rodriguez A; Binary and Ternary Complexes of 1,3-Phenylenediamine-N,N'-Disuccinic Acid with Divalent Cations

Reference No.: 3819(88KGM)

Polyhedron, 1988, 7, 1227 - 1230; Kashanian S; Gholivand MB; Madaeni S; Nikrahi A; Shamsipur M; Spectrophotometric Study of the Complexation Reactions between Alkaline Earth Cations and Murexide in some Non-Aqueous Solutions

Reference No.: 3832(90KLV)

Russ. J. Inorg. Chem., 1990, 35, 73 - 75; Kozlovskii EV; Ledenkov SF; Vasil'ev VP; Thermodynamics of the Formation of Calcium and Magnesium Ethylenediaminedisuccinates in Solution

Reference No.: 3836(93WSS)

Coord. Chem. Rev., 1993, 122, 171 - 225; Whitfield DM; Stojkovski S; Sarkar B; Metal Coordination to Carbohydrates. Structures and Function

Reference No.: 3850(86Bus)

Inorg. Chim. Acta, 1986, 120, 125 - 129; Buschmann H-J; The Macrocyclic and Cryptate Effect. 7. Influence of Structural Changes on the Complexation Behaviour of Aza Crown Ethers and Cryptands in Different Solvents

Reference No.: 3853(86KhZ)

Inorg. Chim. Acta, 1986, 124, 5 - 11; Khan BT; Zakeeruddin SM; Metal Complexes of Substituted Pyrimidines

Reference No.: 3857(83CFS)

Inorg. Chim. Acta, 1983, 69, 161 - 166; Cox BG; Firman P; Schneider H; Thermodynamic and Kinetic Studies on Complex Formation of Alkaline Earth Metal Ions with Diaza-Crown Ethers in Methanol

Reference No.: 3867(83ReR)

Inorg. Chim. Acta, 1983, 80, 95 - 98; Reddy PR; Reddy KV; Stabilities and thermodynamic Parameters of 1:2 Metal-Xanthosine Complexes in Solution

Reference No.: 3882(82FaP)

Inorg. Chim. Acta, 1982, 59, 87 - 91; Farmer RM; Popov AI; ESR Study of Manganese(II) Complexes in Aqueous Solutions

Reference No.: 3898(88HSD)

Inorg. Chim. Acta, 1988, 154, 229 - 238; Hancock RD; Shaikjee MS; Dobson SM; Boeyens JCA; The Stereochemical Activity or Non-activity of the 'Inert' Pair of Electrons on Lead(II) in Relation to its Complex Stability and Structural Properties. Some Considerations in Ligand Design

Reference No.: 3905(87ShC)

Inorg. Chim. Acta, 1987, 138, 187 - 192; Shanbhag SM; Choppin GR; Thermodynamics of Mg and Ca Complexation with AMP, ADP,ATP

Reference No.: 3908(87AKB)

Inorg. Chim. Acta, 1987, 127, 183 - 188; Anderegg G; Koch E; Bayer E; N-Hydroxy-alpha,alpha'-iminodipropionic and N-Hydroxyiminodiacetic Acid as Complexing Agents and an Example for Selective Coordination of the Vanadyl Ion VO²⁺ in Amavadin

Reference No.: 3910(89KaS)

Inorg. Chim. Acta, 1989, 155, 203 - 206; Kashanian S; Shamsipur M; Complex Formation of Alkaline Earth Cations with Benzo-15-Crown-5 and some 18-Crowns in methanol, Dimethylformamide and Dimethyl sulfoxide Solutions

Reference No.: 3920(87CSS)

Inorg. Chim. Acta, 1987, 128, 207 - 213; Cox BG; Stroka J; Schneider H; Thermodynamic and Kinetic Studies on Calcium(II)-Cryptates in Acetonitrile and Water Mixtures

Reference No.: 3925(85RAA)

Inorg. Chim. Acta, 1985, 96, 171 - 178; Rizkalla EN; Antonious MS; Anis SS; X-Ray Photoelectron and Potentiometric Studies of Some Calcium Complexes

Reference No.: 3938(85ChB)

Inorg. Chim. Acta, 1985, 109, 99 - 104; Choppin GR; Brock JL; Thermodynamics of Lanthanide TMEDTA Complexation

Reference No.: 3977(77MoF)

Anal. Chem., 1977, 49, 418 - 423; Moyers EM; Fritz JS; Preparation and Analytical Applications of a Propylenediaminetetraacetic Acid Resin

Reference No.: 4245(62IrM)

J. Phys. Chem., 1962, 66, 1349 - 1353; Irani RR; Moedritzer K; Metal Complexing by Phosphorus Compounds. VI Acidity Constants and Calcium and Magnesium Complexing by Mono- and Polymethylene Diphosphonates

Reference No.: 4250(57TiB)

J. Am. Chem. Soc., 1957, 79, 1293 - 1296; Tichane RM; Bennett WE; Coordination Compounds of Metal Ions with Derivatives and Analogs of Ammoniacetic Acid

Reference No.: 4396(64Saw)

Chem. Rev., 1964, 64, 633 - 643; Sawyer DT; Metal-Gluconate Complexes

Reference No.: 4460(94SMC)

J. Am. Chem. Soc., 1994, 116, 2958 - 2971; Sigel H; Massoud SS; Corfu NA; Comparison of the Extent of Macrochelate Formation in Complexes of Divalent Metal Ions with Guanosine

(GMP-2), Inosine (IMP-2) and Adenosine 5'-Monophosphate (AMP-2). The Crucial Role of N-7 Basicity in Metal Ion-Nucleic Base Recognition

Reference No.: 4478(94SCB)

Helv. Chim. Acta, 1994, 77, 1738 - 1756; Song B; Chen D; Bastian M; Martin RB; Sigel H; Metal-Ion-Coordinating Properties of a Viral Inhibitor, a Pyrophosphate Analogue, and a Herbicide Metabolite, a Glycinate Analogue: The Solution Properties of the Potentially Five-Membered Chelates Derived from Phosphonoformic Acid and (Aminomethyl)phosphonic Acid

Reference No.: 4482(94She)

J. Chem. Soc., Faraday Trans., 1994, 90, 3401 - 3404; Shehata HA; Conductometric Study of Association Phenomena of Some Metal(II) Complexes in Water at Different Temperatures

Reference No.: 4484(94PiR)

Inorg. Chem., 1994, 33, 4985 - 4990; Pizer RD; Ricatto PJ; Ternary Alkaline Earth Metal Complex Ions in the M+2/Borate/ Tartrate System As Studied by ¹¹B NMR

Reference No.: 4503(82EFW)

Electrochim. Acta, 1982, 27, 647 - 651; Emara MM; Farid NA; Wasfi AM; Thermodynamics of Ionic-Association in Aqueous Solutions of Ca and Mg Organic Salts using Ion-Selective Electrode Technique - II. Benzoate, o-Toluate, o-Chlorobenzoate and Salicylate

Reference No.: 4522(76ITN)

J. Am. Chem. Soc., 1976, 98, 7626 - 7630; Izatt RM; Terry RE; Nelson DP; Chan Y; Eatough DJ; Bradshaw JS; Hansen LD; Christensen JJ; Calorimetric Titration Study of the Interaction of Some Uni- and Bivalent Cations with Benzo-15-crown-5, 18-Crown-6, Dibenzo-24-crown-8, and Dibenzo-27-crown-9 in Methanol-Water Solvents, at 25 C and $\mu = 0.1$

Reference No.: 4542(75LWP)

J. Am. Chem. Soc., 1975, 97, 7382 - 7383; Loyola VM; Wilkins RG; Pizer R; The Kinetics of Complexing of Calcium Ion with Several Cryptands

Reference No.: 4556(75CaS)

J. Am. Chem. Soc., 1975, 97, 315 - 321; Carr JD; Swartzfager DG; Kinetics of the Ligand Exchange and Dissociation Reactions of Calcium-Aminocarboxylate Complexes

Reference No.: 4609(74Aru)

J. Inorg. Nucl. Chem., 1974, 36, 3779 - 3782; Aruga R; Thermodynamics of Association of Thiosulphate Ion with Several Mono- and Bivalent Metal Ions

Reference No.: 4631(81KuM)

J. Inorg. Nucl. Chem., 1981, 43, 1299 - 1304; Kulstad S; Malmsten LA; Diaza-Crown Ethers -V. Stability Constants of N,N'-Disubstituted Diaza-Crown Ether Complexes with Various Metal Ions

Reference No.: 4763(84CVR)

J. Chem. Soc., Faraday Trans. 1, 1984, 80, 3275 - 3284; Cox BG; van Truong Ng.; Rzeszotarska J; Schneider H; Stability Constants of Complexes of Monensin and Lasalocid with Alkali-metal and Alkaline-earth-metal Ions in Protic and Polar Aprotic Solvents

Reference No.: 4772(86Bus)

J. Solution Chem., 1986, 15, 453 - 461; Buschmann H-J; Complex Formation of Alkaline-Earth Cations with Crown Ethers and Cryptands in Methanol Solutions

Reference No.: 4795(88PPJ)

J. Chem. Soc., Faraday Trans. 1, 1988, 84, 1713 - 1722; Pointud Y; Passelaigue E; Juillard J; Interactions between Metal Cations and the Ionophore Lasalocid Part 4

deltaH and deltaS for Formation of 1-1 and 2-1 Complexes of the Lasalocid Anion and Salicylate with Alkaline-earth Metal Cations in Methanol

Reference No.: 4822(80CGS)

J. Phys. Chem., 1980, 84, 3178 - 3183; Cox BG; Garcia-Rosas J; Schneider H; Kinetics and Equilibria of Cryptate Formation in Propylene Carbonate

Reference No.: 4847(82SBP)

J. Chem. Soc., Faraday Trans. 1, 1982, 78, 3671 - 3677; Symons MCR; Benbow JA; Pelmore H; Study of Calcium Ion Binding to D-Ribose in Aqueous Solutions using Hydroxy-proton Resonance Shifts

Reference No.: 4861(76K1O)

J. Chem. Soc., Faraday Trans. 1, 1976, 72, 513 - 525; Klaning UK; Osterby O; Hydration and Ion Pairing of Maleinates, Malonates, and Substituted Malonates in Aqueous Solution

Reference No.: 4891(95KTM)

Inorg. Chem., 1995, 34, 6472 - 6480; Kumar K; Tweedle MF; Malley MF; Gougoutas JZ; Synthesis, Stability, and Crystal Structure Studies of Some Ca²⁺, Cu²⁺, and Zn²⁺ Complexes of Macrocyclic Polyamino Carboxylates

Reference No.: 4896(95PiL)

Acta Chem. Scand., 1995, 49, 235 - 240; Piispanen J; Lajunen LHJ; Complex Formation Equilibria of Some Aliphatic alpha-Hydroxycarboxylic Acids. 1. The Determination of Protonation Constants and the Study of Calcium(II) and Magnesium(II) Complexes

Reference No.: 4910(95JWJ)

J. Chem. Soc., Dalton Trans., 1995,, 1411 - 1415; Jarvis NV; Wagener JM; Jackson GE; Metal-ion Speciation in Blood Plasma as a Tool for Elucidating the in vivo Behaviour of Radiopharmaceuticals Containing Sm and Ho

Reference No.: 4914(94CIO)

Chem. Rev., 1994, 94, 467 - 517; Chen X; Izatt RM; Oscarson JL; Thermodynamic Data for Ligand Interaction with Protons and Metal Ions in Aqueous Solutions at High Temperatures

Reference No.: 4920(38CaK)

J. Am. Chem. Soc., 1938, 60, 2314 - 2320; Cannan K; Kibrick AC; Complex Formation between Carboxylic Acids and Divalent Metal Cations

Reference No.: 4931(77LPW)

J. Am. Chem. Soc., 1977, 99, 7185 - 7188; Loyola VM; Pizer RD; Wilkins RG; The Kinetics of Complexing of the Alkaline-Earth Ions with Several Cryptands

Reference No.: 4996(74PyH)

Limnol. Oceanogr., 1974, 19, 223 - 234; Pytkowicz RM; Hawley JE; Bicarbonate and Carbonate Ion-pairs and a Model of Seawater at 25C

Reference No.: 4998(86BaM)

The Hydrolysis of Cations, 1986 Baes CF Jr; Mesmer RE; Robert E. Krieger Publ. Co. Malabar, Florida

Reference No.: 5019(82MaS)

Talanta, 1982, 29, 145 - 148; Majer V; Stulik K; A Study of the Stability of Alkaline-Earth Metal Complexes with Fluoride and Chloride Ions at various Temperatures by Potentiometry with Ion-Selective Electrodes

Reference No.: 5055(74FRS)

Russ. J. Inorg. Chem., 1974, 19, 950 - 953; Fedorov VA; Robov AM; Shmydko II;

Vorontsova NA; Mironov VE; Interaction of Alkaline Earth Element Ions with Nitrate Ions in Aqueous Solutions

Reference No.: 5068(91ZEN)

J. Solution Chem., 1991, 20, 455 - 465; Zhang J; Ebrahimpour A; Nancollas GH; Ion Association in Calcium Phosphate Solutions at 37 degrees Celsius

Reference No.: 5072(84PBM)

J. Solution Chem., 1984, 13, 647 - 661; Patterson CS; Busey RH; Mesmer RE; Second Ionization of Carbonic Acid in NaCl Media to 250C

Reference No.: 5078(54GiM)

Trans. Faraday Soc., 1954, 50, 965 - 972; Gimblett FGR; Monk CB; EMF Studies of Electrolytic Dissociation Part 7. Some Alkali and Alkaline Earth Metal Hydroxides in Water

Reference No.: 5084(90PSI)

Russ. J. Inorg. Chem., 1990, 35, 925 - 927; Padar TG; Stupko TV; Isaev ID; Pashkov GL; Mironov VE; The Formation of Ammine Complexes of Alkaline Earth Metals in Aqueous Solution

Reference No.: 5090(79ELW)

Mar. Chem., 1979, 7, 273 - 280; Elgquist B; Wedborg M; Stability of the Calcium Sulphate Ion Pair at the Ionic Strength of Seawater by Potentiometry

Reference No.: 5107(76KhF)

Russ. J. Inorg. Chem., 1976, 21, 1652 - 1654; Khokhlova AI; Fedorov VA; Complex Formation by Calcium Ions with the Anions of Various Mono-carboxylic Acids

Reference No.: 5147(76ICP)

Russ. J. Inorg. Chem., 1976, 21, 971 - 973; Ivakin AA; Chufarova IG; Petunina NI; Conditions of Formation of Calcium, Strontium, and Barium Meta-, Pyro-, and Ortho-Vanadates

Reference No.: 5148(74IGG)

Russ. J. Inorg. Chem., 1974, 19, 1309 - 1313; Ivakin AA; Gurevich VA; Glazyrin MP; Determination of the Degree of Condensation of the Metavanadate Ion on the Basis of a Study of the Solubility of Alkaline Earth Metal Vanadates

Reference No.: 5150(77ICP)

Russ. J. Inorg. Chem., 1977, 22, 1470 - 803; Ivakin AA; Chufarova IG; Petunina NI; Conditions of Formation of Calcium, Strontium, and Barium Deca-, Hexa-, and Dodeca-vanadates

Reference No.: 5156(91ReB)

Radiochim. Acta, 1991, 52/53, 453 - 456; Read D; Broyd TW; Recent Progress in Testing Chemical Equilibrium Models: The CHEMVAL Project

Reference No.: 5167(76ICP)

Russ. J. Inorg. Chem., 1976, 21, 1759 - 1761; Ivakin AA; Chufarova IG; Petunina NI; Solubility and Ion-Exchange Properties of Alkaline Earth Element Polyvanadates of the type MV12O31

Reference No.: 5181(83PaV)

Chem. Rev., 1983, 83, 651 - 731; Palmer DA; van Eldik R; The Chemistry of Metal Carbonato and Carbon Dioxide Complexes

Reference No.: 5193(92CKR)

J. Coord. Chem., 1992, 26, 243 - 250; Choppin GR; Khalili FI; Rizkalla EN; The Nature of Calcium and Thorium Complexation by Halate Ligands

Reference No.: 5199(93DBN)

Russ. J. Phys. Chem., 1993, 67, 2399 - 2344; Durov VA; Bursulaya BD; Novikov AI; Matkovskaya TA; Mathematical Simulation of Chemical Equilibria in Prototypes of Biological Media

Reference No.: 5202(75Mar)

J. Inorg. Nucl. Chem., 1975, 37, 2155 - 2163; Marshall WL; Thermodynamic Functions at Saturation of Several Metal Sulfates in Aqueous Sulfuric and Deuteriosulfuric Acids at Temperatures up to 350 C

Reference No.: 5230(70GhN)

J. Inorg. Nucl. Chem., 1970, 32, 3041 - 3051; Ghosh R; Nair VSK; Studies on Metal Complexes in Aqueous Solution III. The Biselenate Ion and Transition Metal Selenates

Reference No.: 5262(78KaH)

Anal. Chem., 1978, 50, 1209 - 1212; Karweik DH; Huber CO; Polyphosphate Currents at the Lead Dioxide Electrode for Hydrolysis Rate in Instability Constant Measurements

Reference No.: 5304(82Aru)

Can. J. Chem., 1982, 60, 1828 - 1831; Aruga R; Solute-Solvent Interactions in the Association of Hexacyanoferrate(III) with Group IIA Cations. A Calorimetric Study

Reference No.: 5322(79JoW)

Mar. Chem., 1979, 8, 57 - 69; Johansson O; Wedborg M; Stability Constants of Phosphoric Acid in Seawater of 5-40% Salinity and Temperatures of 5-25C

Reference No.: 5330(87MMM)

Polyhedron, 1987, 6, 1049 - 1052; Mahapatra PP; Mahapatra LM; Mishra B; Arsenate Hydroxyapatite: A Physico-Chemical and Thermodynamic Investigation

Reference No.: 5366(94VVC)

Mar. Chem., 1994, 47, 65 - 79; van der Weijden RD; van der Weijden CH; Comans RNJ; Sorption and Sorption Reversibility of Cd on Calcite under Simulated Riverine, Estuarine and Marine Conditions

Reference No.: 5374(80BrD)

J. Solution Chem., 1980, 9, 279 - 288; Brooker MH; DeYoung BS; Measurement of the Stability Constants for Aqueous Calcium and Magnesium Nitrite by Raman Spectroscopic Methods

Reference No.: 5378(74HaI)

J. Solution Chem., 1974, 3, 57 - 70; Hanania GIH; Israelian SA; Thermodynamics of the Association of Aqueous Calcium and Hexacyanoferrate Ions

Reference No.: 5390(95Woo)

Thesis, Univ. Cape Town, 1995 Woolard C; A Computer Simulation of the Trace Metal Speciation in Seawater; Univ. Cape Town, South Africa

Reference No.: 5398(82Hog)

IUPAC Chemical Data Series No. 21, 1982 Hogfeldt E; Stability Constants of Metal-ion Complexes, 2nd Suppl., Part A, Inorganic Ligands; Pergamon, Oxford

Reference No.: 5404(95CDF)

J. Chem. Soc., Dalton Trans., 1995,, 2689 - 2696; Cassol A; Di Bernardo P; Pilloni G;

Tolazzi M; Zanonato PL; Thermodynamic and Electrochemical Studies of Lanthanide and Alkaline-earth-metal Cryptates in Dimethyl Sulfoxide

Reference No.: 5406(97Sjo)

Pure Appl. Chem., 1997, 69, 1549 - 1570; Sjoberg S; Critical Evaluation of Stability Constants of Metal-Imidazole and Metal-Histamine Systems

Reference No.: 5416(86Chi)

ISEI Tech. Report, Ser. B, No. 3, 1986 Chiba H; Compilation of Dissociation Constants of Major Aqueous Species Present in Geothermal Fluids. Comparison of Thermodynamic Data Base of Aqueous Speciation Codes.; Inst. Study Earth's Interior, Okayama Univ., Japan

Reference No.: 5428(57Lam)

Thesis, Ohio State Univ., 1957 Lambert SM

Reference No.: 5433(55Pau)

Thesis, Univ. California, Berkley, 1955 Paul AD

Reference No.: 5434(62SmE)

Izv. Vyssh. Ucheb. Zaved., 1962, 5, 871 Smyshlyaev SI; Edeleva NP

Reference No.: 5458(80BeT)

Report LBL-11448, 1980 Benson LV; Teague LS; Tabulation of Thermodynamic Data for Chemical Reactions Involving 58 Elements Common to Radioactive Waste

Reference No.: 5468(77Wag)

Water Res., 1977, 12, 139 - 145; Wagemann R; Some Theoretical Aspects of Stability and Solubility of Inorganic Arsenic in the Fresh Water Environment

Reference No.: 5484(90NPL)

ACS Symp. Ser., 1990, 416, 398 - 413; Nordstrom DK; Plummer LN; Langmuir D; Busenberg E; May HM; Jones BF; Parkhurst DL; Revised Chemical Equilibrium Data for Major Water-Mineral Reactions and their Limitations

Reference No.: 5522(88NIT)

Arsenic Metallurgy Fundamentals and Applications, 1988, 77 - 98; Nishimura T; Itoh CT; Tozawa K; Stabilities and Solubilities of Metal Arsenites and Arsenates in Water and Effect of Sulfate and Carbonate Ions on their Solubilities

Reference No.: 5574(94DDS)

Chem. Speciation Bioavail., 1994, 6, 65 - 84; De Robertis A; De Stefano C; Sammartano S; Gianguzza A; Equilibrium Studies in Natural Fluids: a Chemical Speciation Model for the Major Constituents of Sea Water

Reference No.: 5593(75JaL)

J. Solution Chem., 1975, 4, 1023 - 1031; Jackman FA; Lister MW; The Association of Hexacyanoferrate(II) Ions and Group IIA Cations

Reference No.: 5605(78CDH)

J. Chem. Thermodyn., 1978, 10, 903 - 906; Cox JD; Drowart J; Heppler LG; Medvedev VA; Wagman DD; CODATA recommended Key Values for Thermodynamics, 1977. Report of the CODATA Task Group on Key Values for Thermodynamics, 1977

Reference No.: 5644(87MoM)

Mar. Chem., 1987, 21, 101 - 116; Motekaitis RJ; Martell AE; Speciation of Metals in the Oceans. I. Inorganic Complexes in Seawater, and Influence of Added Chelating Agents

Reference No.: 5648(72MoO)

Ions in Aqueous Systems, 1972 Moller T; O'Connor R; An Introduction to Chemical Equilibrium and Solution Chemistry; McGraw-Hill Book Co., N.Y.

Reference No.: 5674(74DeF)

Biochemistry, 1974, 13, 5022 - 5032; Degani H; Friedman HL; Ion Binding by X-537A. Formulas, Formation Constants, and Spectra of Complexes

Reference No.: 5703(53KlM)

J. Am. Chem. Soc., 1953, 75, 4159 - 4162; Klotz IM; Ming WCL; Stability Constants for Some Metal Chelates of Pyridine-2-azo-rho-dimethylaniline

Reference No.: 5748(62JoS)

J. Chem. Soc., 1962,, 306 - 311; Jones RH; Stock DI; The Dissociation Constants in Water of Some Bivalent Metal Alkanedicarboxylates

Reference No.: 5757(79HRB)

J. Solution Chem., 1979, 8, 779 - 792; Hoiland H; Ringseth JA; Brun TS; Cation-Crown Ether Complex Formation in Water. II. Alkali and Alkaline Earth Cations and 12-Crown-4, 15-Crown-5, and 18-Crown-6

Reference No.: 5773(95DGS)

Talanta, 1995, 42, 1651 - 1662; De Robertis A; Gianguzza A; Sammartano S; Solubility of some Calcium - Carboxylic Ligand Complexes in Aqueous Solution

Reference No.: 5829(95AnK)

Talanta, 1995, 42, 1067 - 1079; Anderegg G; Kholeif S; Extrapolation of Molar Equilibrium Constants to Zero Ionic Strength and Parameters Dependent on it. Copper(II), Nickel(II), Hydrogen(I) Complexes with Glycinate Ion and Calcium(II), Hydrogen(I) Complexes with Nitrilotriacetate Ion

Reference No.: 5989(95DDG)

Environ. Toxicol. Chem., 1995, 14, 767 - 773; Demianov P; De Stefano C; Gianguzza A; Sammartano S; Equilibrium Studies in Natural Waters: Speciation of Phenolic Compounds in Synthetic Seawater at Different Salinities

Reference No.: 5995(88MaS)

Bull. Chem. Soc. Ethiop., 1988, 2, 9 - 14; Massoud SS; Sigel H; Comparison of the Properties of the Ca²⁺ and Cd²⁺ Complexes of Guanosine 5'-Monophosphate (GMP) in Aqueous Solution

Reference No.: 6000(96YaO)

Pure Appl. Chem., 1996, 68, 469 - 496; Yamauchi O; Odani A; Stability Constants of Metal Complexes of Amino Acids with Charged Side Chains - Part I: Positively Charged Side Chains

Reference No.: 6055(64SiB)

Helv. Chim. Acta, 1964, 47, 1701 - 1717; Sigel H; Brintzinger H; Adenosin-5'-Monophosphat-N(1)-Oxid Ein (Ambivalentes) Ligandssystem

Reference No.: 6086(79FHT)

Eur. J. Biochem., 1979, 94, 523 - 530; Fischer BE; Haring UK; Tribolet R; Sigel H; Metal Ion/Buffer Interactions. Stability of Binary and Ternary Complexes Containing 2-Amino-2(hydroxymethyl)-1,3-Propanediol (Tris) and Adenosine 5'-Triphosphate (ATP)

Reference No.: 6089(80SAP)

Eur. J. Biochem., 1980, 107, 455 - 466; Scheller KH; Abel THJ; Polanyi PE; Wenk PK; Fischer BE; Sigel H; Metal Ion/Buffer Interactions. Stability of Binary and Ternary Complexes Containing 2-[Bis(2-Hydroxyethyl) Amino]-2(Hydroxymethyl)-1,3-Propanediol (Bis-Tris) and Adenosine 5'-Triphosphate (ATP)

Reference No.: 6100(87Sig)

Eur. J. Biochem., 1987, 165, 65 - 72; Sigel H; Isomeric Equilibria in Complexes of Adenosine 5'-Triphosphate with Divalent Metal Ions. Solution Structures of M(ATP)-2 Complexes

Reference No.: 6104(89MaS)

Eur. J. Biochem., 1989, 179, 451 - 458; Massoud SS; Sigel H; Evaluation of the Metal-ion-coordinating Differences between the 2'-, 3'- and 5'-Monophosphates of Adenosine

Reference No.: 6105(89KTC)

Inorg. Chem., 1989, 28, 1480 - 1489; Kinjo Y; Tribolet R; Corfu NA; Sigel H; Stability and Structure of Xanthosine-Metal Ion Complexes in Aqueous Solution, Together with Intramolecular Adenosine-Metal Ion Equilibria

Reference No.: 6115(92KJC)

Inorg. Chem., 1992, 31, 5588 - 5596; Kinjo Y; Ji L-N; Corfu NA; Sigel H; Ambivalent Metal Ion Binding Properties of Cytidine in Aqueous Solution

Reference No.: 6123(89CDD)

Thermochim. Acta, 1989, 140, 59 - 66; Casale A; De Robertis A; De Stefano C; Gianguzza A; Thermodynamic Parameters for the Formation of Calcium alpha-Alaninate Complexes in Aqueous Solution

Reference No.: 6124(93DFG)

Ann. Chim. (Rome), 1993, 83, 485 - 497; De Robertis A; Foti C; Gianguzza A; Studies on Polyfunctional O-Ligands. Alkali and Alkaline Earth Metal Complexes of Butanetetracarboxylate in Aqueous Solution

Reference No.: 6125(93DGS)

Thermochim. Acta, 1993, 214, 325 - 338; De Stefano C; Gianguzza A; Sammartano S; Protonation Thermodynamics of 2,2'-Bipyridyl in Aqueous Solution. Salt Effects and Weak Complex Formation

Reference No.: 6128(95CDD)

Thermochim. Acta, 1995, 255, 109 - 141; Casale A; De Robertis A; De Stefano C; Gianguzza A; Patane G; Rigano C; Sammartano S; Thermodynamic Parameters for the Formation of Glycine Complexes with Magnesium(II), Calcium(II), Lead(II), Manganese(II), Cobalt(II), Nickel(II), Zinc(II) and Cadmium(II) at Different Temperatures and Ionic Strengths, with Particular Reference to Natural Fluid Conditions

Reference No.: 6131(95DFG)

Chem. Speciation Bioavail., 1995, 7, 1 - 8; De Stefano C; Foti C; Gianguzza A; Rigano C; Sammartano S; Chemical Speciation of Amino Acids in Electrolyte Solutions Containing Major Components of Natural Fluids

Reference No.: 6135(95BGE)

J. Chem. Soc., Dalton Trans., 1995,, 3353 - 3357; Brucher E; Gyori B; Emri J; Jakab S; Kovacs Z; Solymosi P; Toth I; Complexation Properties of 1,4,10,13-Tetraoxa-7,16-diazacyclo-octadecane-7-malonate, -7,16-bis(Malonate) and -7,16-bis (alpha-Methylacetate)

Reference No.: 6142(91CIP)

Ann. Chim. (Rome), 1991, 81, 243 - 258; Ciavatta L; Iuliano M; Porto R; Complex Formation Equilibria in Calcium Phosphate Solutions

Reference No.: 6170(95Por)

Ann. Chim. (Rome), 1995, 85, 55 - 67; Porto R; The Dihydrogen Phosphate Ion as Ligand. Complexation Equilibria with Ba(II), Ca(II) and Co(II) Ions

Reference No.: 6175(95MMC)

Ann. Chim. (Rome), 1995, 85, 621 - 631; Melis S; Muscas L; Cao G; Simulation of Lead Adsorption and Transport through a Natural Porous Medium

Reference No.: 6213(79GaR)

Environ. Internat., 1979, 2, 419 - 424; Gamsjager H; Reiterer F; Investigation of Equilibria Involving Carbon Dioxide, Carbonates and Water

Reference No.: 6214(73GRS)

Chem. Thermodyn., Proc. 3rd Int. Conf, 1973, 6, 115 - 122; Gamsjager H; Riesen W; Schindler PW; Thermodynamic Studies of Complex Formations and Solubilities in the System Ca(II) - Mg(II) - CO₂ - H₂O

Reference No.: 6218(87KoG)

Ber. Bunsenges. Phys. Chem., 1987, 91, 785 - 790; Konigsberger E; Gamsjager H; Solid-Solute Phase Equilibria in Aqueous Solution Solubility Constant and Free Enthalpy of Formation of Huntite

Reference No.: 6232(96GBT)

Talanta, 1996, 43, 1497 - 1509; Gal J-Y; Bollinger J-C; Tolosa H; Gache N; Calcium Carbonate Solubility: a Reappraisal of Scale Formation and Inhibition

Reference No.: 6298(81FHP)

J. Solution Chem., 1981, 10, 523 - 532; Farmer RM; Heubel P-H C; Popov AI; Complexation Properties of Phosphonocarboxylic Acids in Aqueous Solutions

Reference No.: 6325(88Sad)

Mar. Chem., 1988, 23, 87 - 96; Sadiq M; Thermodynamic Solubility Relationships of Inorganic Vanadium in the Marine Environment

Reference No.: 6330(95LiF)

CRC Handbook of Chemistry and Physics, 76th Edn., 1995 Lide DR; Frederikse HPR; A Ready-Reference Book of Chemical and Physical Data; CRC Press, Cleveland, Ohio, U.S.A.

Reference No.: 6346(82PlB)

Geochim. Cosmochim. Acta, 1982, 46, 1011 - 1040; Plummer LN; Busenberg E; The Solubilities of Calcite, Aragonite and Vaterite in CO₂-H₂O Solutions between 0 and 90C, and an Evaluation of an Aqueous Model for the System CaCO₃-CO₂-H₂O

Reference No.: 6347(75ScD)

C. R. Acad. Sci., Ser. C, 1975, 288, 1247 Schott J; Dandurand JL

Reference No.: 6350(74ReL)

Am. J. Sci., 1974, 274, 599 - 612; Reardon EJ; Langmuir D; Thermodynamic Properties of the Ion Pairs MgCO₃ and CaCO₃ from 10 to 50C

Reference No.: 6366(95KPW)

Geochim. Cosmochim. Acta, 1995, 59, 3843 - 3851; Kettler RM; Palmer DA; Wesolowski DJ; Comment on "Predictions of Diagenetic Reactions in the Presence of Organic Acids" by W.J.Harrison and D.G.Thyne

Reference No.: 6372(87BrW)

OECD NEA Report, 1987 Brown PL; Wanner H; Predicted Formation Constants Using the Unified Theory of Metal Ion Complexation; Nuclear Energy Authority, Paris

Reference No.: 6405(93MoH)

Principles and Applications of Aquatic Chemistry, 1993 Morel FMM; Hering JG; John Wiley & Sons, Inc

Reference No.: 6412(96SSJ)

J. Biol. Inorg. Chem., 1996, 1, 231 - 238; Saha A; Saha N; Ji L-N; Zhao J; Gregan F; Sajadi SAA; Song B; Sigel H; Stability of Metal Ion Complexes Formed with Methyl Phosphate and Hydrogen Phosphate

Reference No.: 6422(95BaP)

Thermochemical Data of Pure Substances, 3rd Edn., 1995 Barin I; Platzki G; Weinheim, Germany

Reference No.: 6426(97GSH)

Hydrothermal Reactions, Proc. 5th Int. Symp., 1997, 52 - 55; Giordano TH; Syracuse M; Hilton R; Boyers C; Calcium and Magnesium Acetate Complexing in Hydrothermal Solutions

Reference No.: 6437(97Sax)

Modelling in Aquatic Chemistry, 1997, 289 - 323; Saxena SP; Systematization and Estimation of Thermochemical Data on Silicates

Reference No.: 6461(80ToN)

Invest. Urol., 1980, 18, 97 - 101; Tomazic BB; Nancollas GH; The Kinetics of Dissolution of Calcium Oxalate Hydrates. II. The Dihydrate

Reference No.: 6463(79ToN)

J. Cryst. Growth, 1979, 46, 355 - 361; Tomazic B; Nancollas GH; The Kinetics of Dissolution of Calcium Oxalate Hydrates

Reference No.: 6464(74NaG)

J. Cryst. Growth, 1974, 21, 267 Nancollas GH; Gardner GL; Kinetics of Crystal Growth of Calcium Oxalate Monohydrate

Reference No.: 6465(75Gar)

J. Cryst. Growth, 1975, 30, 158 Gardner GL; Nucleation and Crystal Growth of Calcium Oxalate Trihydrate

Reference No.: 6466(92ShS)

Am. Mineral., 1992, 77, 1038 - 1049; Shi P; Saxena SK; Thermodynamic Modelling of the C-H-O-S Fluid System

Reference No.: 6467(82GBM)

J. Cryst. Growth, 1982, 57, 233 Garside J; Brecevic L; Mullin JW; The Effect of Temperature on the Precipitation of Calcium Oxalate

Reference No.: 6468(85DSR)

Ann. Chim. (Rome), 1985, 75, 245 Daniele PG; Sonogo S; Ronzani M; Marangella M; Ionic Strength Dependence of Formation Constants. Part 8. Solubility of Calcium Oxalate Monohydrate and Calcium Hydrogenphosphate Dihydrate in Aqueous Solution, at 37 C and Different Ionic Strengths

Reference No.: 6469(80Hod)

Invest. Urol., 1980, 18, 123 Hodgkinson A; Solubility of Calcium Oxalate in Human Urine, Simulated Urine, and Water

Reference No.: 6471(77MGB)

J. Res. Natl. Bur. Stand., 1977, 81A, 27 McDowell H; Gregory TM; Brown WE; Solubility of $\text{Ca}_5(\text{PO}_4)_3\text{OH}$ in the System $\text{Ca}(\text{OH})_2\text{-H}_3\text{PO}_4\text{-H}_2\text{O}$ at 5, 15, 25, and 37 C

Reference No.: 6473(88TES)

J. Res. Natl. Bur. Stand., 1988, 93, 613 Tung MS; Eidelman N; Sieck B; Brown WE; Octacalcium Phosphate Solubility Product from 4 to 37 C

Reference No.: 6475(72FRD)

Urinary Calculi, Int. Symp. Renal Stone Res., Madrid, 1972, 1 Finlayson B; Roth R; DuBois L; Calcium Oxalate Solubility Studies

Reference No.: 6476(92BFB)

J. Res. Natl. Inst. Stand. Technol., 1992, 97, 365 Babic-Ivancic V; Furedi-Milhofer H; Brnicevic N; Markovic M; Precipitation and Solubility of Calcium Hydrogenurate Hexahydrate

Reference No.: 6478(81BaM)

Am. J. Sci., 1981, 281, 935 - 962; Baes CF Jr; Mesmer RE; The Thermodynamics of Cation Hydrolysis

Reference No.: 6482(88Ber)

J. Petrology, 1988, 29, 445 - 522; Berman RG; Internally-Consistent Thermodynamic Data for Minerals in the System Na₂O-K₂O-CaO-MgO-FeO-Fe₂O₃-Al₂O₃-SiO₂-TiO₂-H₂O-CO₂

Reference No.: 6488(88ShH)

Geochim. Cosmochim. Acta, 1988, 52, 2009 - 2036; Shock EL; Helgeson HC; Calculation of the Thermodynamic and Transport Properties of Aqueous Species at High Pressures and Temperatures: Correlation Algorithms for Ionic Species and Equation of State Predictions to 5 kb and 1000 C

Reference No.: 6494(95RoH)

U.S. Geol. Surv. Bull. 2131, 1995 Robie RA; Hemingway BS; Thermodynamic Properties of Minerals and Related Substances at 298.15 K and 1 Bar (10⁵ Pascals) Pressure and at Higher Temperatures; U.S. Government Printing Office, Washington, U.S.A

Reference No.: 6495(97SSH)

Geochim. Cosmochim. Acta, 1997, 61, 1359 - 1412; Sverjensky DA; Shock EL; Helgeson HC; Prediction of the Thermodynamic Properties of Aqueous Metal Complexes to 1000C and 5kb

Reference No.: 6496(96StM)

Aquatic Chemistry, 3rd Edn., 1996 Stumm W; Morgan JJ; Chemical Equilibria and Rates in Natural Waters; John Wiley & Sons, Inc., New York

Reference No.: 6515(75MMM)

Inorg. Chem., 1975, 14, 468 - 473; MacMillan DT; Murase I; Martell AE; New Multidentate Ligands. XIV. Aqueous Coordination Chemistry of N,N'-Bis(2-hydroxybenzyl)ethylenediamine-N,N'-bis(methylphosphonic) Acid

Reference No.: 6627(81CVD)

J. Inorg. Nucl. Chem., 1981, 43, 1573 - 1578; Candida M; Vaz TA; da Silva JJRF; Thermodynamic Parameters for the Reactions of Uramildiacetic Acid with Transition Metal Ions

Reference No.: 6631(83LRN)

Anal. Biochem., 1983, 133, 492 - 501; Lance EA; Rhodes CW III; Nakon R; Free Metal Ion Depletion by "Goods" Buffers. III. N-(2-Acetamido)iminodiacetic Acid, 2:1 Complexes with Zinc(II), Cobalt(II), Nickel(II), and Copper(II); Amide Deprotonation by Zn(II), Co(II), and Cu(II)

Reference No.: 6644(83ChR)

Inorg. Chem., 1983, 22, 3866 - 3869; Chang CA; Rowland ME; Metal Complex Formation with 1,10-Diaza-4,7,13,16-tetraoxacyclo-octadecane-N,N'-diacetic Acid. An Approach to Potential Lanthanide Ion Selection Reagents

Reference No.: 6659(95WRC)

Am. Mineral., 1995, 80, 355 - 360; Walling EM; Rock PA; Casey WH; The Gibbs Energy of

Formation of Huntite, $\text{CaMg}_3(\text{CO}_3)_4$, at 298K and 1 bar from Electrochemical Cell Measurements

Reference No.: 6710(53LuM)

J. Phys. Chem., 1953, 57, 690 - 693; Lumb RF; Martell AE; Metal Chelating Tendencies of Glutamic and Aspartic Acids

Reference No.: 6759(49ScG)

Helv. Chim. Acta, 1949, 32, 1314 - 1325; Schwarzenbach G; Gysling H; Metallindikatoren. I. Murexid als Indikator auf Calcium- und andere Metall-Ionen. Komplexbildung und Lichtabsorption

Reference No.: 6795(76SOT)

Yakugaku Zasshi, 1976, 96, 242 - 245; Sakurai H; Okumura H; Takeshima S; Stability Constants of Metal Complexes of 2-Aminoethylphosphonic Acid and Its Related Compounds

Reference No.: 6796(84DDS)

Thermochim. Acta, 1984, 72, 305 - 322; Daniele PG; De Robertis A; Sammartano S; Rigano C; Calcium-malonate Complexes in Aqueous Solution. Thermodynamic Parameters and their Ionic Strength Dependence

Reference No.: 6806(52Sch)

J. Phys. Chem., 1952, 56, 113 - 118; Schubert J; Ion Exchange Studies of Complex Ions as a Function of Temperature, Ionic Strength, and Presence of Formaldehyde

Reference No.: 6833(67UhK)

J. Inorg. Nucl. Chem., 1967, 29, 1164 - 1168; Uhlig E; Krannich R; Stabilitätsmessungen an Metallchelaten vierzahliger Aminopolycarbonsäuren

Reference No.: 6836(70GhN)

J. Inorg. Nucl. Chem., 1970, 32, 3025 - 3032; Ghosh R; Nair VSK; Studies of Metal Complexes in Aqueous Solution. I. Calcium and Copper Lactates

Reference No.: 6845(62CoR)

Trans. Faraday Soc., 1962, 58, 2058 - 2065; Coates E; Rigg B; Complex Formation Solochrome Violet R. Part 4 - Some Metal-Dye Stability Constants

Reference No.: 6861(85MoM)

J. Coord. Chem., 1985, 14, 139 - 149; Motekaitis RJ; Martell AE; Metal Chelate Formation by N-Phosphonomethylglycine and Related Ligands

Reference No.: 6868(78MoA)

J. Coord. Chem., 1978, 8, 175 - 182; Mohan MS; Abbott EH; Metal Complexes of Biologically Occurring Aminophosphonic Acids

Reference No.: 6882(88SmR)

Inorg. Chem., 1988, 27, 1056 - 1061; Smith PH; Raymond KN; Solid-State and Solution Chemistry of Calcium N-(Phosphonomethyl)- glycinate

Reference No.: 6908(76SaS)

Thermochim. Acta, 1976, 17, 325 - 328; Sandhu RS; Singh K; A Thermodynamic Study of the Complexation Reaction of Beryllium(II), Magnesium(II) and Calcium(II) with 3-Hydroxy-2-naphthoic Acid

Reference No.: 6912(91DDG)

Thermochim. Acta, 1991, 177, 39 - 57; De Robertis A; De Stefano C; Gianguzza A; Salt Effects on the Protonation of L-Histidine and L-Aspartic Acid: A Complex Formation Model

Reference No.: 6927(84DFC)

Inorg. Chim. Acta, 1984, 90, 185 - 190; Delgado R; Frausto da Silva JJR; Candida M; Vaz TA; The Thermodynamics of Complex Formation of Cyclic Tetra-aza-tetracetic Acids

Reference No.: 6935(75APB)

J. Coord. Chem., 1975, 4, 267 - 275; Anderegg G; Podder NG; Blauenstein P; Hangartner M; Stunzi H; Pyridine Derivatives as Complexing Agents. X. Thermodynamics of Complex Formation of N,N'-Bis(2-pyridylmethyl)-ethylenediamine and of Two Higher Homologues

Reference No.: 6937(81And)

J. Coord. Chem., 1981, 11, 171 - 175; Anderegg G; Pyridine Derivatives as Complexing Agents. XII. Thermodynamics of Complex Formation with 2-Pyridylmethyl-iminodiacetic Acid and its 6-Methyl Substitute

Reference No.: 7062(95FYJ)

Geochim. Cosmochim. Acta, 1995, 59, 1053 - 1062; Fein JB; Yane L; Jyoti A; Handa T; Experimental Study of Aluminium and Calcium Malonate Complexation at 25, 35, and 80 C

Reference No.: 7090(96DFG)

J. Solution Chem., 1996, 25, 597 - 606; De Robertis A; Foti C; Gianguzza A; Rigano C; Protonation Thermodynamics of 1,10-Phenanthroline in Aqueous Solution. Salt Effects and Weak Complex Formation

Reference No.: 7168(97GaW)

Chem. Speciation Bioavail., 1997, 91, 37 Gangoda CK; Williams DR; Linear Free Energy Relationships and the Chemical Speciation of Amino-carboxylate Ligand Complexes

Reference No.: 7177(76ACP)

Mar. Chem., 1976, 4, 243 - 254; Atlas E; Culberson CH; Pytkowicz RM; Phosphate Association with Na⁺, Ca²⁺, and Mg²⁺ in Seawater

Reference No.: 7229(75ElW)

Mar. Chem., 1975, 3, 215 - 225; Elgquist B; Wedborg M; Stability of Ion Pairs from Gypsum Solubility Degree of Ion Pair Formation between the Major Constituents of Seawater

Reference No.: 7242(68Tru)

J. Geol. Educ., 1968, 16, 17 - 20; Truesdell AH; The Advantage of Using pE Rather than Eh in Redox Equilibrium Calculations

Reference No.: 7271(98SMM)

NIST Critical Stability Constants of Metal Complexes Database, 1998 Smith RM; Martell AE; Motekaitis RJ; Version 5.0; U.S. Dept. Commerce, Gaithersburg, MD, U.S.A.

Reference No.: 7273(84HiJ)

Dictionary of Electrochemistry, 2nd Edn., 1984 Hibbert DB; James AM; Macmillan Press, London, U.K.

Reference No.: 7275(98Atk)

Physical Chemistry, 6th Edn., 1998 Atkins PW; Oxford University Press, Oxford, U.K.

Reference No.: 7276(88CoW)

Advanced Inorganic Chemistry, 5th Edn., 1988 Cotton FA; Wilkinson G; John Wiley & Sons Inc., N.Y., U.S.A

Reference No.: 7372(78BDJ)

Vogel's Textbook of Quantitative Inorganic Analysis, 1978 Bassett J; Denney RC; Jeffery GH; Mendham J; including Elementary Instrumental Analysis; Longman, London, U.K.

Reference No.: 7373(96WBF)

Water Resources Res., 1996, 32, 3173 - 3187; Wunderly MD; Blowes DW; Frind EO; Ptacek CJ; Sulfide Mineral Oxidation and Subsequent Reactive Transport of Oxidation Products in Mine Tailings Impoundments: A Numerical Model

Reference No.: 7381(97Woo)

Physical Chemistry, 1997 Woodbury G; Brooks/Cole Publishing Co., Pacific Grove, U.S.A.

Reference No.: 7391(82MiS)

Am. J. Sci., 1982, 282, 1508 - 1540; Millero FJ; Schreiber DR; Use of the Ion Pairing Model to Estimate Activity Coefficients of the Ionic Components of Natural Waters

Reference No.: 7397(79FiF)

J. Solution Chem., 1979, 8, 309 - 328; Fisher FH; Fox AP; Divalent Sulfate Ion Pairs in Aqueous Solutions at Pressures up to 2000 atm

Reference No.: 7421(97Mar)

Ion Properties, 1997 Marcus Y; Marcel Dekker Inc., New York, U.S.A.

Reference No.: 7645(70Lar)

J. Phys. Chem., 1970, 74, 3392 - 3396; Larson JW; Thermodynamics of Divalent Metal Sulfate Dissociation and the Structure of the Solvated Metal Sulfate Ion Pair

Reference No.: 7694(84IPZ)

Russ. J. Inorg. Chem., 1984, 29, 860 - 862; Ivanov-Emin BN; Petrishcheva LP; Zaitsev BE; Izmailovich AS; Hydroxo-compounds of Copper(II)

Reference No.: 7703(03PLT)

Pure Appl. Chem., 2003, 75, 495 - 540; Portanova R; Lajunen LHJ; Tolazzi M; Piispanen J; Stability Constants for alpha-Hydroxycarboxylic Acid Complexes with Protons and Metal Ions and the Accompanying Enthalpy Changes - Part II: Aliphatic 2-Hydroxycarboxylic Acids

Reference No.: 7730(52CoM)

J. Chem. Soc., 1952,, 4363 - 4368; Colman-Porter CA; Monk CB; Dissociation Constants of the Alkaline-earth Salts of Some Monocarboxylic Acids

Reference No.: 7761(89Bra)

J. Phys. Chem. Ref. Data, 1989, 18, 1 - 21; Bratsch SG; Standard Electrode Potentials and Temperature Coefficients in Water at 298.15 K

Reference No.: 8226(58DuR)

J. Am. Chem. Soc., 1958, 80, 4812 - 4817; Durham EJ; Ryskiewich DP; The Acid Dissociation Constants of Diethylenetriaminepentaacetic Acid and the Stability Constants of Some of its Metal Chelates

Reference No.: 8309(99BSH)

J. Chem. Soc., Dalton Trans., 1999,, 3661 - 3671; Blindauer CA; Sjastad TI; Holy A; Sletten E; Sigel H; Aspects of the Co-ordination Chemistry of the Antiviral Nucleotide Analogue, 9-[2-(Phosphonomethoxy)ethyl]-2,6-diaminopurine (PMEDAP)

Reference No.: 8310(57HeB)

J. Am. Chem. Soc., 1957, 79, 2046 - 2048; Hershenson HM; Brooks RT; A Polarographic Study of the Formate Complexes of Cadmium, Copper, Lead, Thallium and Zinc

Reference No.: 8375(69GSM)

J. Indian Chem. Soc., 1969, 46, 784 - 786; Ghosh SC; Sarkar A; Mukherjee SK; Activity Measurement with Resin Membrane Electrode. Part II. Determination of Activity-Solubility Products of Sparingly Soluble Salts

Reference No.: 8385(85LDM)

Bull. Soc. Chim. Fr., 1985,, 638 - 643; Le Guyader M; Dorange G; Marchand A; Solubilité de la Calcite et Constantes de Stabilité d'Ions Complexes. II. Influence de la Mineralisation

Reference No.: 8399(66MaS)

J. Phys. Chem., 1966, 70, 4015 - 4027; Marshall WL; Slusher R; Thermodynamics of Calcium Sulfate Dihydrate in Aqueous Sodium Chloride Solutions, 0 - 110 C

Reference No.: 8402(69IEC)

J. Chem. Soc. (A), 1969,, 47 - 53; Izatt RM; Eatough DJ; Christensen JJ; Bartholomew CH; Calorimetrically Determined Log K, ΔH , and ΔS Values for the Interaction of Sulphate Ion with Several Bi- and Ter-valent Metal Ions

Reference No.: 8616(69YeM)

J. Phys. Chem., 1969, 73, 81 - 90; Yeatts LB; Marshall WL; Aqueous Solutions at High Temperatures. Apparent Invariance of Activity Coefficients of Calcium Sulfate at Constant Ionic Strength and Temperature in the System $\text{CaSO}_4\text{-Na}_2\text{SO}_4\text{-NaNO}_2\text{-H}_2\text{O}$ to the Critical Temperature of Water. Association Equilibria

Reference No.: 8628(67NaR)

Anal. Chem., 1967, 39, 1022 - 1023; Nakayama FS; Rasnick BA; Calcium Electrode Method for Measuring Dissociation and Solubility of Calcium Sulfate Dihydrate

Reference No.: 8630(73Ain)

J. Chem. Soc., Faraday Trans. 1, 1973, 69, 1028 - 1032; Ainsworth RG; Dissociation Constant of Calcium Sulphate from 25 to 50 C

Reference No.: 8646(68GFS)

Russ. J. Phys. Chem., 1968, 42, 1050 - 1054; Gordievskii AV; Filippov EL; Shterman VS; Krivoshein AS; Ion-exchange Membranes. III. Application of an Ion-exchange Membrane Electrode in the Study of Complex-forming Reactions

Reference No.: 8670(32MoD)

Trans. Faraday Soc., 1932, 28, 609 - 614; Money RW; Davies CW; The Extent of Dissociation of Salts in Water. Part IV. Bi-Bivalent Salts

Reference No.: 8671(70GaG)

Trans. Faraday Soc., 1970, 66, 1081 - 1086; Gardner AW; Glueckauf E; Thermodynamic Data of the Calcium Sulphate Solution Process between 0 and 200 C

Reference No.: 8675(72Pit)

J. Chem. Soc., Faraday Trans. 2, 1972, 68, 101 - 113; Pitzer KS; Thermodynamic Properties of Aqueous Solutions of Bivalent Sulphates

Reference No.: 8681(87DRS)

Thermochim. Acta, 1987, 115, 241 - 248; De Robertis A; Rigano C; Sammartano S; Zerbinati O; Ion Association of Cl^- with Na^+ , K^+ , Mg^{2+} and Ca^{2+} in Aqueous Solutions at $10 < T < 45$ C and $0 < I < 1$ mol L^{-1} . A Literature Data Analysis

Reference No.: 8692(77Fin)

Calcium Metabolism in Renal Failure and Nephrolithiasis, 1977, 337 - 382; Finlayson B; Calcium Stones: Some Physical and Clinical Aspects

Reference No.: 8695(00KlR)

Chemical Thermodynamics, 6th Edn., 2000 Klotz IM; Rosenberg RM; Basic Theory and Methods; John Wiley & Sons, N.Y., U.S.A.

Reference No.: 8710(91BLB)

Geochim. Cosmochim. Acta, 1991, 55, 2729 - 2735; Byrne RH; Lee JH; Bingler LS; Rare Earth Complexation by PO₄³⁻ Ions in Aqueous Solution

Reference No.: 8739(99KKG)

Geochim. Cosmochim. Acta, 1999, 63, 3105 - 3119; Konigsberger E; Konigsberger L-C; Gamsjager H; Low-temperature Thermodynamic Model for the System Na₂CO₃-MgCO₃-CaCO₃-H₂O

Reference No.: 8746(89CWM)

CODATA Key Values for Thermodynamics, 1989 Cox JD; Wagman DD; Medvedev VA; Values obtained from www.codata.org/codata/databases Apr. 2000 and <http://www.codata.org/resources/databases/key1.html> Sept. 2011; Hemisphere Publishing Corp., N.Y., U.S.A.

Reference No.: 8749(98MiP)

Aquat. Geochem., 1998, 4, 153 - 199; Millero FJ; Pierrot D; A Chemical Equilibrium Model for Natural Waters

Reference No.: 8775(99PeP)

Geochim. Cosmochim. Acta, 1999, 63, 1969 - 1980; Perkins RB; Palmer CD; Solubility of Ettringite (Ca₆[Al(OH)₆]₂(SO₄)₃·26H₂O) at 5-75C

Reference No.: 8798(99ArS)

Am. J. Sci., 1999, 299, 173 - 209; Arnorsson S; Stefansson A; Assessment of Feldspar Solubility Constants in Water in the Range 0 to 350C at Vapour Saturation Pressures

Reference No.: 8833(80HaW)

Geochim. Cosmochim. Acta, 1980, 44, 981 - 997; Harvie CE; Weare JH; The Prediction of Mineral Solubilities in Natural Waters: The Na-K-Mg-Ca-Cl-SO₄-H₂O System from Zero to High Concentration at 25C

Reference No.: 8875(81HKF)

Am. J. Sci., 1981, 281, 1249 - 1516; Helgeson HC; Kirkham DH; Flowers GC; Theoretical Prediction of the Thermodynamic Behavior of Aqueous Electrolytes at High Pressures and Temperatures. IV. Calculation of Activity Coefficients, Osmotic Coefficients and Apparent Molal and Standard and Relative Partial Molal Properties to 600 C and 5 Kb

Reference No.: 8888(93ShK)

Geochim. Cosmochim. Acta, 1993, 57, 4899 - 4922; Shock EL; Koretsky CM; Metal-organic Complexes in Geochemical Processes: Calculation of Standard Partial Molal Thermodynamic Properties of Aqueous Acetate Complexes at High Pressures and Temperatures

Reference No.: 8898(78JoP)

Am. J. Sci., 1978, 278, 1428 - 1447; Johnson KS; Pytkowicz RM; Ion Association of Cl⁻ with H⁺, Na⁺, K⁺, Ca²⁺, and Mg²⁺ in Aqueous Solutions at 25C

Reference No.: 8903(96SAP)

Water Res., 1996, 30, 1930 - 1933; Serkiz SM; Allison JD; Perdue EM; Allen HE; Brown DS; Correcting Errors in the Thermodynamic Database for the Equilibrium Speciation Model MINTEQA2

Reference No.: 8910(83SMM)

Am. J. Sci., 1983, 283, 218 - 229; Sass E; Morse JW; Millero FJ; Dependence of the Values of Calcite and Aragonite Thermodynamic Solubility Products on Ionic Models

Reference No.: 9027(76Ber)

Am. J. Sci., 1976, 276, 713 - 730; Berner RA; The Solubility of Calcite and Aragonite in Seawater at Atmospheric Pressure and 34.5% Salinity

Reference No.: 9029(97SSW)

Geochim. Cosmochim. Acta, 1997, 61, 907 - 950; Shock EL; Sassani DC; Willis M; Sverjensky DA; Inorganic Species in Geologic Fluids: Correlations among Standard Molal Thermodynamic Properties of Aqueous Ions and Hydroxide Complexes

Reference No.: 9058(89KBG)

Geochim. Cosmochim. Acta, 1989, 53, 2807 - 2810; Konigsberger E; Bugajski J; Gamsjager H; Solid-solute Phase Equilibria in Aqueous Solution: II. A Potentiometric Study of the Aragonite-Calcite Transition

Reference No.: 9059(27Buc)

Trans. Faraday Soc., 1927, 23, 668 - 671; Buchan JL; The Free Energy of Transition in the System Calcite-Aragonite

Reference No.: 9065(82PLS)

Geochim. Cosmochim. Acta, 1982, 46, 247 - 258; Plummer LN; Sundquist ET; Total Individual Ion Activity Coefficients of Calcium and Carbonate in Seawater at 25C and 35% Salinity, and the Implications to the Agreement between Apparent and Thermodynamic Constants of Calcite and Aragonite

Reference No.: 9073(84HMW)

Geochim. Cosmochim. Acta, 1984, 48, 723 - 751; Harvie CE; Moller N; Weare JH; The Prediction of Mineral Solubilities in Natural Waters: The Na-K-Mg-Ca-H-Cl-SO₄-OH-HCO₃-CO₃-CO₂-H₂O System to High Ionic Strengths at 25C

Reference No.: 9155(79RiH)

Geochim. Cosmochim. Acta, 1979, 43, 1313 - 1325; Richardson CK; Holland HD; The Solubility of Fluorite in Hydrothermal Solutions, an Experimental Study

Reference No.: 9156(86Haa)

Mar. Chem., 1986, 19, 299 - 304; Haas JW Jr; Complexation of Calcium and Copper with Carbohydrates

Reference No.: 9253(00KWK)

Monatsh. Chem., 2000, 131, 39 - 45; Konigsberger E; Wang Z; Konigsberger L-C; Solubility Of L-Cystine in NaCl and Artificial Urine Solutions

Reference No.: 9402(86Wan)

EIR-Bericht Nr. 589, 1986 Wanner H; Modelling Interaction of Deep Groundwaters with Bentonite and Radionuclide Speciation; Swiss Federal Institute for Reactor Research, Wurenlingen, Suisse

Reference No.: 9424(82ADR)

Ann. Chim. (Rome), 1982, 72, 1 - 24; Amico P; Daniele PG; Rigano C; Sammartano S; Stability of Calcium and Magnesium Citrate Complexes in Aqueous Solution

Reference No.: 9667(96BoF)

Ann. Chim. (Rome), 1996, 86, 133 - 142; Bottari E; Festa MR; The Behavior of Asparagine as a Ligand for Cations

Reference No.: 9683(82BoP)

Monatsh. Chem., 1982, 113, 1245 - 1252; Bottari E; Porto R; Complex Formation between Glycine and Magnesium(II), Calcium(II), and Iron(II) at 25C in 3.00 M Sodium Perchlorate

Reference No.: 9980(83DDD)

Ann. Chim. (Rome), 1983, 73, 619 - 633; Daniele PG; De Robertis A; De Stefano C; Rigano C; Sammartano S; Calcium Acetate, Succinate, Maleate and Phthalate Complexes in Aqueous Solution. Potentiometric Determination of Stability Constants and Their Dependence on Ionic Strength

Reference No.: 9983(82DRS)

Ann. Chim. (Rome), 1982, 72, 341 - 353; Daniele PG; Rigano C; Sammartano S; Formation and Stability of Calcium- and Magnesium-Phosphate Complexes in Aqueous Solution at 37C. A Potentiometric Investigation by Glass and Calcium Ion-Selective Electrodes in the Ionic Strength Range $0.03 < I < 0.5$

Reference No.: 10174(95OHS)

J. Phys. Chem. Ref. Data, 1995, 24, 1401 - 1560; Oelkers EH; Helgeson HC; Shock EL; Sverjensky DA; Johnson JW; Pokrovskii VA; Summary of the Apparent Standard Partial Molal Gibbs Free Energies of Formation of Aqueous Species, Minerals, and Gases at Pressures 1 to 5000 Bars and Temperatures 25 to 1000C

Reference No.: 11516(00PeP)

IUPAC Stability Constants Database, 2000 Pettit LD; Powell HKJ; Release 4; Academic Software, U.K.

Reference No.: 11762(77Kat)

Rikagaku Kenkyusho Hokoku, 1977, 53, 212 - 238; Katayama S; Conductimetric Study of the Ion Association in Aqueous Solutions

Reference No.: 11763(81YoY)

Bull. Chem. Soc. Jpn., 1981, 54, 2286 - 2289; Yokoyama H; Yamatera H; Ion Association of Some 2:2 Electrolytes in Water at 25C. III. A New Interpretation of Experimental Results and the Determination of Formation Constants of Inner-sphere Ion-pairs

Reference No.: 11928(41OwB)

Chem. Rev., 1941, 29, 461 - 474; Owen BB; Brinkley SR Jr; Calculation of the Effect of Pressure upon Ionic Equilibria in Pure Water and in Salt Solutions

Reference No.: 11989(58HaO)

The Physical Chemistry of Electrolytic Solutions, 3rd Edn., 1958 Harned HS; Owen BB; American Chemical Society Monograph Series No: 137; Reinhold Publishing Corp., N.Y.

Reference No.: 12002(59RoS)

Electrolyte Solutions, 2nd Rev. Edn., 1959 Robinson RA; Stokes RH; An Unabridged Re-publication of the Fifth Impression of the Second Revised Edition of the Work Originally Published in 1970 with New Preface Specially Prepared by Dr. Stokes; Dover Publications, N.Y., USA (previously Butterworth & Co., London)

Reference No.: 12189(89WiS)

Geochim. Cosmochim. Acta, 1989, 53, 313 - 318; Williams-Jones AE; Seward TM; The Stability of Calcium Chloride Ion Pairs in Aqueous Solutions at Temperatures between 100 and 360C

Reference No.: 12227(75SCH)

Collect. Czech. Chem. Commun., 1975, 40, 2020 - 2024; Sucha L; Cadek J; Hrabek K; Vesely J; The Stability of the Chloro Complexes of Magnesium and of the Alkaline Earth Metals at Elevated Temperatures

Reference No.: 12436(89RRH)

Thermochim. Acta, 1989, 139, 67 - 81; Robie RA; Russell-Robinson S; Hemingway BS; Heat Capacities and Entropies from 8 to 1000K of Langbeinite ($K_2Mg_2(SO_4)_3$), Anhydrite ($CaSO_4$) and of Gypsum ($CaSO_4 \cdot 2H_2O$) to 325K

Reference No.: 12547(98SBB)

J. Phys. Chem., 1998, B102, 4411 - 4417; Simonin J-P; Bernard O; Blum L; Real Ionic Solutions in the Mean Spherical Approximation. 3. Osmotic and Activity Coefficients for Associating Electrolytes in the Primitive Model

Reference No.: 12549(76LiB)

Proc. R. Soc. London Ser. A, 1976, 349, 355 - 368; Lilley TH; Briggs CC; Activity Coefficients of Calcium Sulfate in Water at 25C

Reference No.: 12584(00KKH)

Aquat. Geochem., 2000, 6, 147 - 199; Kulik DA; Kersten M; Heiser U; Neumann T; Application of Gibbs Energy Minimization to Model Early-Diagenetic Solid-Solution Aqueous-Solution Equilibria Involving Authigenic Rhodochrosites in Anoxic Baltic Sea Sediments

Reference No.: 12628(01OGC)

J. Solution Chem., 2001, 30, 31 - 53; Oscarson JL; Gillespie SE; Chen X; Schuck PC; Izatt RM; Enthalpies of Dilution of Aqueous Solutions of HCl, MgCl₂, CaCl₂, and BaCl₂ at 300, 325, and 350C

Reference No.: 12638(99TPG)

GAMSPATH Users Manual, 1999 Talman SJ; Perkins EH; Gunter WD; A Reaction Path - Mass Transfer Program

Reference No.: 12843(01Ste)

Chem. Geol., 2001, 172, 225 - 250; Stefansson A; Dissolution of Primary Minerals of Basalt in Natural Waters. I. Calculation of Mineral Solubilities from 0C to 350C

Reference No.: 12931(01SPG)

Chem. Geol., 2001, 171, 173 - 194; Seby F; Potin-Gautier M; Giffaut E; Borge G; Donard OFX; A Critical Review of Thermodynamic Data for Selenium Species at 25C

Reference No.: 12941(00FoG)

Talanta, 2000, 53, 617 - 626; Fovet Y; Gal J-Y; Formation Constants beta₂ of Calcium and Magnesium Fluorides at 25C

Reference No.: 12955(00CVI)

J. Chem. Thermodyn., 2000, 32, 1505 - 1512; Christov C; Velikova S; Ivanova Khr.R; Study of (m₁LiX + m₂CaX₂)(aq) where m_i Denotes Molality and X Denotes Cl, or Br at the Temperature 298.15 K

Reference No.: 13242(05AAD)

Pure Appl. Chem., 2005, 77, 1445 - 1495; Anderegg G; Arnaud-Neu F; Delgado R; Felcman J; Popov K; Critical Evaluation of Stability Constants of Metal Complexes of Complexones for Biomedical and Environmental Applications

Reference No.: 13297(03ADC)

Pure Appl. Chem., 2003, 75, 71 - 102; Arnaud-Neu F; Delgado R; Chaves S; Critical Evaluation of Stability Constants and Thermodynamic Functions of Metal Complexes of Crown-ethers

Reference No.: 13532(78Lan)

Geochim. Cosmochim. Acta, 1978, 42, 547 - 569; Langmuir D; Uranium Solution-Mineral Equilibria at Low Temperatures with Applications to Sedimentary Ore Deposits

Reference No.: 14923(05ONO)

OECD Chemical Thermodynamics Series, Volume 7, 2005 Olin A; Nolang B; Ohman L-O; Osadchii EG; Rosen E; Chemical Thermodynamics of Selenium

Reference No.: 16058(00KhA)

J. Chem. Eng. Data, 2000, 45, 1108 - 1111; Khalil MM; Attia AE; Potentiometric Studies on the Formation Equilibria of Binary and Ternary Complexes of Some Metal Ions with Dipicolinic Acid and Amino Acids

Reference No.: 16470(91SYP)

J. Chem. Eng. Data, 1991, 36, 52 - 54; Singh RP; Yeboah YD; Pambid ER; Debayle P; Stability Constant of the Calcium-Citrate(3-) Ion Pair Complex

Reference No.: 16641(73FiS)

J. Chem. Eng. Data, 1973, 18, 368 - 370; Finlayson B; Smith A; Spectrophotometry of Stability Constant of CaC2O4 Based on Competition Between Murexide and Oxalate for Ca+2

Reference No.: 16981(11OrB)

Russ. J. Inorg. Chem., 2011, 56, 975 - 980; Orlov YF; Belkina EI; Correlations between the Stability Constants of Metal Hydroxo Complexes and the Solubility Products of Crystalline Hydroxides. Series of the Polarizing Effect of Metal Cations

Reference No.: 17594(01KoK)

Pure Appl. Chem., 2001, 73, 785 - 797; Konigsberger E; Konigsberger L-C; Thermodynamic Modeling of Crystal Deposition in Humans

Reference No.: 17698(04AAS)

J. Chem. Eng. Data, 2004, 49, 62 - 72; Azab HA; Anwar ZM; Sokar M; Metal Ion Complexes Containing Nucleobases and Some Zwitterionic Buffers

Reference No.: 17779(99DGP)

Anal. Chim. Acta, 1999, 398, 103 - 110; De Stefano C; Gianguzza A; Piazzese D; Sammartano S; Speciation of Low Molecular Weight Carboxylic Ligands in Natural Fluids: Protonation Constants and Association with Major Components of Seawater of Oxydiacetic and Citric Acids

Reference No.: 17788(95DDF)

Anal. Chim. Acta, 1995, 300, 45 - 51; De Robertis A; Di Giacomo P; Foti C; Ion-Selective Electrode Measurements for the Determination of Formation Constants of Alkali and Alkaline Earth Metals with Low-Molecular-Weight Ligands

Reference No.: 17919(99WWW)

Chem. Speciation Bioavail., 1999, 11, 85 - 93; Whitburn JS; Wilkinson SD; Williams DR; Chemical Speciation of Ethylenediamine-N,N'-disuccinic Acid (EDDS) and its Metal Complexes in Solution

Reference No.: 18070(03MAZ)

Geochim. Cosmochim. Acta, 2003, 67, 1769 - 1785; Mercury L; Azaroual M; Zeyen H; Tardy Y; Thermodynamic Properties of Solutions in Metastable Systems under Negative or Positive Pressure

Reference No.: 18180(01RMC)

Am. J. Sci., 2001, 301, 103 - 111; Rock PA; Mandell GK; Casey WH; Walling EM; Gibbs Energy of Formation of Dolomite from Electrochemical Cell Measurements and Theoretical Calculations

Reference No.: 18273(57Dav)

Discuss. Faraday Soc., 1957, 24, 83 - 86; Davies CW; Incomplete Dissociation. Introductory Paper

Reference No.: 18421(72ISO)

Rev. Phys. Chem. Jpn., 1972, 42, 1 - 11; Inada E; Shimizu K; Osugi J; Electrical Conductivity of CaSO4 in Aqueous Solution under High Pressure

Reference No.: 19094(69GaG)

Proc. R. Soc. London Ser. A, 1969, 313, 131 - 147; Gardner AW; Glueckauf E; Ionic Association in Aqueous Solutions of Bivalent Sulphates

Reference No.: 20827(03GFF)

OECD Chemical Thermodynamics Series, Volume 5, 2003 Guillaumont R; Fanghanel T; Fuger J; Grenthe I; Neck V; Palmer DA; Rand MH; Update on the Chemical Thermodynamics of Uranium, Neptunium, Plutonium, Americium and Technetium; Elsevier Science

Reference No.: 20829(05BCG)

OECD Chemical Thermodynamics Series, Volume 8, 2005 Brown PL; Curti E; Grambow B; Ekberg C; Chemical Thermodynamics of Zirconium; Elsevier Science

Reference No.: 20830(05HAP)

OECD Chemical Thermodynamics Series, Volume 9, 2005 Hummel W; Anderegg G; Puigdomenech I; Rao L; Tochiyama O; Chemical Thermodynamics of Compounds and Complexes of U, Np, Pu, Am, Tc, Se, Ni and Zr with Selected Organic Ligands; Elsevier Science

Reference No.: 20878(06NJN)

Dalton Trans., 2006,, 4029 - 4038; Nomkoko TE; Jackson GE; Nakani BS; Hunter RJ; Solution Chemistry of 1,15-bis-(N,N-dimethyl)-5,11-dioxo-8- (N-benzyl)-1,4,8,12,15-pentaazapentadecane with Metal Ions of Biological Interest - Insights toward Active Metal Ion Containing Therapeutics and Diagnostic Agents

Reference No.: 20992(05SaC)

J. Chem. Eng. Data, 2005, 50, 1620 - 1623; Sari H; Covington AK; Comparative Measurements of Calcium Stability Constants of Some Dicarboxylic Acids by Titrimetry with pH Glass and Calcium Ion-Selective Electrodes

Reference No.: 21108(06SMM)

Mar. Chem., 2006, 99, 52 - 61; Sharma VK; Moulin A; Millero FJ; De Stefano C; Dissociation Constants of Protonated Cysteine Species in Seawater Media

Reference No.: 21342(51Mon)

Trans. Faraday Soc., 1951, 47, 1233 - 1240; Monk CB; Electrolytes in Solutions of Amino Acids. V. Solubilities of Calcium, Barium, and Lanthanum Iodates in Glycine, Alanine, and Glycylglycine

Reference No.: 21799(05DeV)

Pure Appl. Chem., 2005, 77, 619 - 629; De Visscher A; Vanderdeelen J; Consistency Issues of Aqueous Solubility Data and Solution Thermodynamics of Electrolytes

Reference No.: 21825(06LiS)

Geochim. Cosmochim. Acta, 2006, 70, 2530 - 2539; Lin Y-P; Singer PC; Inhibition of Calcite Precipitation by Orthophosphate: Speciation and Thermodynamic Considerations

Reference No.: 21870(77NoJ)

Geochim. Cosmochim. Acta, 1977, 41, 175 - 188; Nordstrom DK; Jenne EA; Fluorite Solubility Equilibria in Selected Geothermal Waters

Reference No.: 22077(70Laf)

Geochim. Cosmochim. Acta, 1970, 34, 935 - 940; Lafon GM; Calcium Complexing with Carbonate Ion in Aqueous Solutions at 25C and 1 Atmosphere

Reference No.: 22282(05CDC)

J. Chem. Thermodyn., 2005, 37, 1061 - 1070; Cruz FJAL; da Piedade MEM; Calado JCG; Standard Molar Enthalpies of Formation of Hydroxy-, Chlor-, and Bromapatite

Reference No.: 22388(09Ber)

Private Communication, 2009 Berthon G; Toulouse Blood Plasma Database

Reference No.: 22519(05Lid)

CRC Handbook of Chemistry and Physics, 86th Edn., 2005 Lide DR; A Ready-Reference Book of Chemical and Physical Data; Taylor & Francis, Boca Raton, USA

Reference No.: 22551(06Inz)

Encyclopedia of Electrochemistry, Vol. 7a, 2006, 17 - 75; Inzelt G; Standard, Formal and Other Characteristic Potentials of Selected Electrode Reactions

Reference No.: 22560(05PeP)

IUPAC Stability Constants Database, 2005 Pettit LD; Powell HKJ; Release 4.71; Academic Software, U.K.

Reference No.: 22612(93GML)

Anal. Chim. Acta, 1993, 273, 493 - 497; Glab S; Maj-Zurawska M; Lukomski P; Hulanicki A; Ion-selective Electrode Control Based on Coulometrically Determined Stability Constants of Biologically Important Calcium and Magnesium Complexes

Reference No.: 22656(01CDI)

Anal. Lett., 2001, 34, 1053 - 1062; Ciavatta L; De Tommaso G; Iuliano M; The Solubility of Calcium Citrate Hydrate in Sodium Perchlorate Solutions

Reference No.: 22958(10AML)

Appl. Geochem., 2010, 25, 242 - 260; Accornero M; Marini L; Lelli M; Prediction of the Thermodynamic Properties of Metal-chromate Aqueous Complexes to High Temperatures and Pressures and Implications for the Speciation of Hexavalent Chromium in Some Natural Waters

Reference No.: 22971(71HWH)

Chem. Rev., 1971, 71, 127 - 137; Hill JO; Worsley IG; Hepler LG; Thermochemistry and Oxidation Potentials of Vanadium, Niobium and Tantalum

Reference No.: 23091(05JMW)

J. Environ. Qual., 2005, 34, 248 - 254; Johnson CA; Moench H; Wersin P; Kugler P; Wenger C; Solubility of Antimony and Other Elements in Samples Taken from Shooting Ranges

Reference No.: 23099(04BoB)

Cem. Concr. Res., 2004, 34, 1057 - 1063; Bothe JV Jr; Brown PW; PhreeqC Modeling of Friedel's Salt Equilibria at 23+-1C

Reference No.: 23101(07MLG)

Cem. Concr. Res., 2007, 37, 1379 - 1410; Matschei T; Lothenbach B; Glasser FP; Thermodynamic Properties of Portland Cement Hydrates in the System CaO-Al₂O₃-SiO₂-CaSO₄-CaCO₃-H₂O

Reference No.: 23102(06ADC)

Environ. Sci. Technol., 2006, 40, 3551 - 3557; Astrup T; Dijkstra JJ; Comans RNJ; Van Der Sloot HA; Christensen TH; Geochemical Modeling of Leaching from MSWI Air-Pollution-Control Residues

Reference No.: 23134(10TPD)

J. Solution Chem., 2010, 39, 1 - 10; Torres J; Pintos V; Dominguez S; Kremer C; Kremer E; Selenite and Selenate Speciation in Natural Waters: Interaction with Divalent Metal Ions

Reference No.: 23185(08DuL)

Geochim. Cosmochim. Acta, 2008, 72, 5128 - 5145; Duan Z; Li D; Coupled Phase and Aqueous Species Equilibrium of the H₂O-CO₂-NaCl-CaCO₃ System from 0 to 250 C, 1 to 1000 bar with NaCl Concentrations up to Saturation of Halite

Reference No.: 23204(09GDB)

Appl. Geochem., 2009, 24, 454 - 462; Gustafsson JP; Dassman E; Backstrom M; Towards a Consistent Geochemical Model for Prediction of Uranium(VI) Removal from Groundwater by Ferrihydrite

Reference No.: 23205(09SDK)

Appl. Geochem., 2009, 24, 1287 - 1300; Shao H; Dmytrieva SV; Kolditz O; Kulik DA; Pfingsten W; Kosakowski G; Modeling Reactive Transport in Non-ideal Aqueous-solid Solution System

Reference No.: 23272(07QaF)

J. Solution Chem., 2007, 36, 81 - 95; Qafoku O; Felmy AR; Development of Accurate Chemical Equilibrium Models for Oxalate Species to High Ionic Strength in the System: Na-Ba-Ca-Mn-Sr-Cl-NO₃-PO₄-SO₄-H₂O at 25 C

Reference No.: 23288(08Hac)

J. Solution Chem., 2008, 37, 155 - 163; Hacht B; Complex Formation of Acetic Acid with Ca(II) and Mg(II) Under Physiological Conditions

Reference No.: 23315(08KKB)

Eur. J. Inorg. Chem., 2008,, 4719 - 4727; Kalman FK; Kiraly R; Brucher E; Stability Constants and Dissociation Rates of the EDTMP Complexes of Samarium(III) and Yttrium(III)

Reference No.: 24003(10Bal)

Collect. Czech. Chem. Commun., 2010, 75, 21 - 31; Balej J; Verification of Accuracy of Standard Thermodynamic Data of Inorganic Substances

Reference No.: 24235(79RHF)

U.S. Geol. Surv. Bull. 1452 (corrected edition), 1979 Robie RA; Hemingway BS; Fisher JR; Thermodynamic Properties of Minerals and Related Substances at 298.15K and 1 bar (10⁵ Pascals) Pressure and at Higher Temperatures; US Govt Printing Office, Washington

Reference No.: 24382(55Wan)

Suomen Kemi., 1955, B28, 146 - 152; Wanninen E; Diethylenetriaminepentaacetic Acid, a New Complex Forming Substance

Reference No.: 24712(51Nyd)

Acta Chem. Scand., 1951, 5, 669 - 670; Nydahl F; The Solubility of Calcium Oxalate Monohydrate in Ammonium Oxalate Solutions at 25 C

Reference No.: 24807(11Chr)

Calphad, 2011, 35, 42 - 53; Christov C; Isopiestic Investigation of the Osmotic Coefficients of Aqueous CaBr₂ and Study of Bromide Salt Solubility in the NaBr-CaBr₂-H₂O System at 50 C: Thermodynamic Model of Solution Behavior and Solid-Liquid Equilibria in the CaBr₂-H₂O, and NaBr-CaBr₂-H₂O Systems to High Concentration and Temperature

Reference No.: 24953(85PPS)

Report LBL-14996, 1985 Phillips SL; Phillips CA; Skeen J; Hydrolysis, Formation and Ionization Constants at 25C, and at High Temperature - High Ionic Strength; Lawrence Berkeley Laboratory, Univ. California, U.S.A.

Reference No.: 25435(12ASJ)

Chem. Geol., 2012, 304-305, 26 - 38; Aradottir ESP; Sonnenthal EL; Jonsson H; Development and Evaluation of a Thermodynamic Dataset for Phases of Interest in CO₂ Mineral Sequestration in Basaltic Rocks

Reference No.: 26078(65HoW)

J. Phys. Chem., 1965, 69, 6 - 8; Hopkins HP Jr; Wulff CA; The Solution Thermochemistry of Polyvalent Electrolytes. I. Calcium Hydroxide

Reference No.: 26086(18BBB)

Geochim. Cosmochim. Acta, 2018, 224, 262 - 275; Benezeth P; Berninger U-N; Bovet N; Schott J; Oelkers EH; Experimental Determination of the Solubility Product of Dolomite at 50-253 C

Reference No.: 26565(13SMM)

J. Chem. Eng. Data, 2013, 58, 187 - 188; Scharge T; Munoz AG; Moog HC; Addition to "Activity Coefficients of Fission Products in Highly Salinary Solutionsof Na+, K+, Mg2+, Ca2+, Cl-, and SO42- Cs+"

Reference No.: 26686(07ABF)

Ann. Chim. (Rome), 2007, 97, 1085 - 1096; Antonilli M; Bottari E; Festa MR; Gentile L; Am Investigation on Calcium(II) Oxalate as Solubility and Universal Standard

Reference No.: 26689(89GOM)

Clin. Chim. Acta, 1989, 182, 255 - 270; Geller DA; Ostrow JD; Moore EW; Celic L; Nancollas GH; Binding of Calcium by Organic Anions Determined by Perturbation of the Equilibrium Solubility of [14C] Calcium Oxalate

Reference No.: 26737(10NaH)

Urol. Res., 2010, 38, 277 - 280; Nancollas GH; Henneman ZJ; Calcium Oxalate: Calcium Phosphate Transformations

Reference No.: 26782(85LaM)

Geochim. Cosmochim. Acta, 1985, 49, 2423 - 2432; Langmuir D; Melchior DC; The Geochemistry of Ca, Sr, Ba and Ra Sulfates in some Deep Brines from the Palo Duro Basin, Texas

Reference No.: 26858(80BFS)

Invest. Urol., 1980, 18, 165 - 166; Burns JR; Finlayson B; Smith A; Stability of the Calcium Dioxalate Complex

Reference No.: 27292(13LBM)

OECD Chemical Thermodynamics Series, Volume 13a, 2013 Lemire RJ; Berner U; Musikas C; Palmer DA; Taylor P; Tochiyama O; Chemical Thermodynamics of Iron Part 1; OECD (NEA) Issy-les-Moulineaux, France

Reference No.: 27383(15BVG)

Appl. Geochem., 2015, 55, 95 - 107; Blanc P; Vieillard P; Gailhanou H; Gaboreau S; Marty N; Claret F; Made B; Giffaut E; ThermoChimie Database Developments in the Framework of Cement/Clay Interactions

Reference No.: 27392(15VRA)

Appl. Geochem., 2015, 55, 192 - 198; Vercouter T; Reiller PE; Ansoborlo E; Fevrier L; Gilbin R; Lomenech C; Philippini V; A Modelling Exercise on the Importance of Ternary Alkaline Earth Carbonate Species of Uranium(VI) in the Inorganic Speciation of Natural Waters

Reference No.: 27777(90CCK)

J. Cryst. Growth, 1990, 106, 349 - 354; Christoffersen MR; Christoffersen J; Kibalczyk W; Apparent Solubilities of Two Amorphous Calcium Phosphates and of Octacalcium Phosphate in the Temperature Range 30-42 C

Reference No.: 28080(82HAC)

J. Chem. Soc., Faraday Trans. 1, 1982, 78, 2455 - 2466; Hsieh A-K; Ang K-P; Chang M;

Conductance of Calcium Sulphate and Magnesium Sulphate in Aqueous Solution at High Pressure

Reference No.: 28172(15DCC)

J. Chem. Eng. Data, 2015, 60, 3792 - 3799; Djamali E; Chapman WG; Cox KR; Prediction of the Standard State Partial Molar Volume of Aqueous Electrolytes to High Temperatures and High Pressures

Reference No.: 28703(16PrM)

Fluid Phase Equilib., 2016, 425, 282 - 288; Prywer J; Mielniczek-Brzoska E; Chemical Equilibria of Complexes in Urine. A Contribution to the Physicochemistry of Infectious Urinary Stone Formation

Reference No.: 28760(86MDW)

Miner. Mag., 1986, 50, 33 - 39; Magalhaes MCF; de Jesus JP; Williams PA; Stability Constants and Formation of Cu(II) and Zn(II) Phosphate Minerals in the Oxidized Zone of Base Metal Orebodies

Reference No.: 28777(09CoD)

J. Solution Chem., 2009, 38, 1449 - 1462; Covington AK; Danish EY; Measurement of Magnesium Stability Constants of Biologically Relevant Ligands by Simultaneous Use of pH and Ion-Selective Electrodes

Reference No.: 28806(16GKK)

J. Phys. Chem. Solids, 2016, 98, 167 - 173; Gacsi A; Kutus B; Konya Z; Kukovecz A; Palinko I; Sipos P; Estimation of the Solubility Product of Hydrocalumite-Hydroxide, a Layered Double Hydroxide with the Formula of $[\text{Ca}_2\text{Al}(\text{OH})_6]\text{OH} \cdot n\text{H}_2\text{O}$

Reference No.: 28992(71NRK)

Handbook of Thermodynamic Data, 1971 Naumov GB; Ryzhenko BN; Khodakovskiy IL; Translated by G.J. Soleimani and edited by I. Barnes & V. Speltz (U.S. Geological Survey); U.S. National Technical Information Service, Springfield VA

Reference No.: 29025(14ThL)

Desalination, 2014, 346, 54 - 69; Thiel GP; Lienhard JH V; Treating Produced Water from Hydraulic Fracturing: Composition Effects on Scale Formation and Desalination System Selection

Reference No.: 29070(85VVM)

Eur. Urol., 1985, 11, 44 - 51; Verplaetse H; Verbeek RMH; Minnaert H; Oosterlinck W; Solubility of Inorganic Kidney Stone Components in the Presence of Acid-Base Sensitive Complexing Agents

Reference No.: 29124(16BCD)

Chemosphere, 2016, 150, 341 - 356; Bretti C; Cigala RM; De Stefano C; Lando G; Sammartano S; Understanding the Bioavailability and Sequestration of Different Metal Cations in the Presence of a Biodegradable Chelant S,S-EDDS in Biological Fluids and Natural Waters

Reference No.: 29125(17BCD)

Fluid Phase Equilib., 2017, 434, 63 - 73; Bretti C; Cigala RM; De Stefano C; Lando G; Sammartano S; Thermodynamic Solution Properties of a Biodegradable Chelant (MGDA) and its Interaction with the Major Constituents of Natural Fluids

Reference No.: 29203(16KGP)

RSC Adv., 2016, 6, 45231 - 45240; Kutus B; Gacsi A; Pallagi A; Palinko I; Peintler G; Sipos P; A Comprehensive Study on the Dominant Formation of the Dissolved $\text{Ca}(\text{OH})_2(\text{aq})$ in Strongly Alkaline Solutions Saturated by $\text{Ca}(\text{II})$

Reference No.: 29206(16GKC)

Dalton Trans., 2016, 45, 17296 - 17303; Gacsi A; Kutus B; Csendes Z; Farago T; Peintler G; Palinko I; Sipos P; Calcium L-Tartrate Complex Formation in Neutral and in Hyperalkaline Aqueous Solutions

Reference No.: 29284(17ToC)

J. Chem. Eng. Data, 2017, 62, 995 - 1010; Toner JD; Catling DC; A Low-Temperature Thermodynamic Model for the Na-K-Ca-Mg-Cl System Incorporating New Experimental Heat Capacities in KCl, MgCl₂, and CaCl₂ Solutions

Reference No.: 29298(17BFG)

J. Solution Chem., 2017, 46, 215 - 224; Bottari E; Festa MR; Gentile L; Cystine as Ligand of Calcium(II) and Magnesium(II) in Two Ionic Media and at Two Different Temperatures (25 and 37 C)

Reference No.: 29317(83JFO)

Am. Mineral., 1983, 68, 1134 - 1145; Johnson GK; Flotow HE; O'Hare PAG; Wise WS; Thermodynamic Studies of Zeolites: Natrolite, Mesolite and Scolecite

Reference No.: 29375(17WAK)

J. Solution Chem., 2017, 46, 521 - 588; Wang P; Anderko A; Kosinski JJ; Springer RD; Lencka MM; Modeling Speciation and Solubility in Aqueous Systems Containing U(IV, VI), Np(IV, V, VI), Pu(III, IV, V, VI), Am(III), and Cm(III)

Reference No.: 29419(16JeJ)

Environ. Earth Sci., 2016, 75, 1333-1 - 1333-14; Jeong HY; Jeon S-W; Geochemical Interactions of Mine Seepage Water with an Aquifer: Laboratory Tests and Reactive Transport Modeling

Reference No.: 29438(68RPN)

Clin. Sci., 1968, 34, 579 - 594; Robertson WG; Peacock M; Nordin BEC; Activity Products in Stone-forming and Non-stone-forming Urine

Reference No.: 29482(16ZZL)

Comput. Geosci., 2016, 90, 97 - 111; Zimmer K; Zhang Y; Lu P; Chen Y; Zhang G; Dalkilic M; Zhu C; SUPCRTBL: A Revised and Extended Thermodynamic Dataset and Software Package of SUPCRT92

Reference No.: 29484(11NaM)

Aquat. Geochem., 2011, 17, 209 - 219; Nair S; Merkel BJ; Impact of Alkaline Earth Metals on Aqueous Speciation of Uranium(VI) and Sorption on Quartz

Reference No.: 29520(17WoC)

Geochim. Cosmochim. Acta, 2017, 213, 635 - 676; Wolery TJ; Colon CFJ; Chemical Thermodynamic Data. 1. The Concept of Links to The Chemical Elements and the Historical Development of Key Thermodynamic Data

Reference No.: 29556(13Nor)

Procedia Earth Planet. Sci., 2013, 7, 624 - 627; Nordstrom DK; Improving Internal Consistency of Standard State Thermodynamic Data for Sulfate Ion, Portlandite, Gypsum, Barite, Celestine, and Associated Ions

Reference No.: 29559(09ZhL)

Geochim. Cosmochim. Acta, 2009, 73, 3171 - 3200; Zhu C; Lu P; Alkali Feldspar Dissolution and Secondary Mineral Precipitation in Batch Systems: 3. Saturation States of Product Minerals and Reaction Paths

Reference No.: 29583(15MTF)

Water Res., 2015, 85, 359 - 370; Mbamba CK; Tait S; Flores-Alsina X; Batstone DJ; A Systematic Study of Multiple Minerals Precipitation Modelling in Wastewater Treatment

Reference No.: 29612(02MNN)

Geochim. Cosmochim. Acta, 2002, 66, 1839 - 1850; Majzlan J; Navrotsky A; Neil JM; Energetics of Anhydrite, Barite, Celestine, and Anglesite: A High-temperature and Differential Scanning Calorimetry Study

Reference No.: 29666(12YLL)

J. Appl. Solution Chem. Model., 2012, 1, 46 - HBED; Yunta F; Lopez-Rayos S; Lucena JJ; Thermodynamic Database Update to Model Synthetic Chelating Agents in Soil Systems

Reference No.: 29755(14CCC)

Ind. Eng. Chem. Res., 2014, 53, 9544 - 9553; Cigala RM; Cordaro M; Crea F; De Stefano C; Fracassetti V; Marchesi M; Milea D; Sammartano S; Acid-Base Properties and Alkali and Alkaline Earth Metal Complex Formation in Aqueous Solution of Diethylenetriamine-N,N,N',N'',N''-pentakis(methylenephosphonic acid) Obtained by an Efficient Synthetic Procedure

Reference No.: 29777(87FMU)

J. Cryst. Growth, 1987, 80, 60 - 68; Furedi-Milhofer H; Markovic M; Uzelac M; Precipitation and Solubility of Calcium Phosphates and Oxalates in the System Ca(OH)₂-H₃PO₄-H₂C₂O₄-NaCl-H₂O

Reference No.: 29801(82DaM)

Ann. Chim. (Rome), 1982, 72, 25 - 38; Daniele PG; Marangella M; Ionic Equilibria in Urine: A Computer Model System Improved by Accurate Stability Constant Values

Reference No.: 29891(17LWZ)

J. Solution Chem., 2017, 46, 1941 - 1947; Li H; Wang S; Zeng D; Solubility and Ionic Interaction of the CaF₂-CaSO₄-H₂O System at 298.1 K

Reference No.: 29940(18CFG)

Chemosphere, 2018, 190, 72 - 79; Chille D; Foti C; Giuffre O; Thermodynamic Parameters for the Protonation and the Interaction of Arsenate with Mg²⁺, Ca²⁺ and Sr²⁺: Application to Natural Waters

Reference No.: 29947(18LZY)

Calphad, 2018, 60, 163 - 176; Li D; Zeng D; Yin X; Gao D; Phase Diagrams and Thermochemical Modeling of Salt Lake Brine Systems. III. Li₂SO₄+H₂O, Na₂SO₄+H₂O, K₂SO₄+H₂O, MgSO₄+H₂O, and CaSO₄+H₂O Systems

Reference No.: 29953(17ZZT)

Appl. Geochem., 2017, 82, 79 - 88; Zhang W; Zhou L; Tang H; Li H; Song W; Xie G; The Solubility of Fluorite in Na-K-Cl Solutions at Temperatures up to 260 C and Ionic Strengths up to 4 mol/kg H₂O

Reference No.: 29969(17TSF)

J. Solution Chem., 2017, 46, 2231 - 2247; Torres J; Santos P; Ferrari C; Kremer C; Kremer E; Solution Chemistry of Arsenic Anions in the Presence of Metal Cations

Reference No.: 30057(14StM)

Anal. Biochem., 2014, 459, 46 - 52; Stumpff F; McGuigan JAS; Measuring Ca²⁺ binding to short chain fatty acids and gluconate with a Ca²⁺ electrode: Role of the reference electrode

Reference No.: 30066(13JaG)

J. Chem. Thermodyn., 2013, 63, 7 - 10; Jacob KT; Gupta PC; Gibbs Energy of Formation of Ca₇V₄O₁₇

Reference No.: 30195(17Meh)

Appl. Geochem., 2017, 84, 133 - 153; Mehta S; Geochemical Evaluation of Uranium

Sequestration from Field-scale Infiltration and Injection of Polyphosphate Solutions in Contaminated Hanford Sediments

Reference No.: 30199(17KKV)

Appl. Geochem., 2017, 85, 35 - 48; Koukouzas N; Kypritidou Z; Vasilatos C; Tsoukalas N; Rochelle CA; Purser GH; Geochemical Modeling of Carbonation of Hydrated Oil Well Cement Exposed to CO₂-saturated Brine Solution

Reference No.: 30564(17KOV)

Dalton Trans., 2017, 46, 1065 - 1074; Kutus B; Ozsvar D; Varga N; Palinko I; Sipos P; ML and ML₂ Complex Formation between Ca(II) and D-Glucose Derivatives in Aqueous Solutions

Reference No.: 30627(17LVG)

Radiochim. Acta, 2017, 105, 171 - 185; Lee J-Y; Vespa M; Gaona X; Dardenne K; Rothe J; Rabung T; Altmaier M; Yun J-I; Formation, Stability and Structural Characterization of Ternary MgUO₂(CO₃)₃²⁻ and Mg₂UO₂(CO₃)₃(aq) Complexes

Reference No.: 30708(69Hep)

Can. J. Chem., 1969, 47, 3469 - 3470; Hepler LG; Thermodynamic Properties of Ruthenate and Molybdate ions

Reference No.: 30809(18DKN)

Monatsh. Chem., 2018, 149, 261 - 282; Dadze TP; Kashirtseva GA; Novikov MP; Plyasunov AV; Solubility of Calcium Molybdate in Aqueous Solutions at 573 K and Thermodynamics of Monomer Hydrolysis of Mo(VI) at Elevated Temperatures

Reference No.: 31120(18BCC)

Sci. Total Environ., 2018, 643, 704 - 714; Bretti C; Cardiano P; Cigala RM; De Stefano C; Irto A; Lando G; Sammartano S; Exploring Various Ligand Classes for the Efficient Sequestration of Stannous Cations in the Environment

Reference No.: 31154(58Wal)

Acta Chem. Scand., 1958, 12, 528 - 536; Walaas E; Stability Constants of Metal Complexes with Mononucleotides

Reference No.: 31218(95OGS)

Aust. J. Chem., 1995, 48, 207 - 215; Owens G; Guarillof P; Steel BJ; Kurucsev T; ¹⁴N Nuclear Magnetic Resonance Relaxation of the Nitrate Ion and Ion Pairing in Aqueous Solution

Reference No.: 31231(19MWW)

Appl. Geochem., 2019, 100, 213 - 222; Muhr-Ebert EL; Wagner F; Walther C; Speciation of Uranium: Compilation of a Thermodynamic Database and Its Experimental Evaluation Using Different Analytical Techniques

Reference No.: 31270(19DKB)

J. Mol. Liq., 2019, 1180, 491 - 498; Dudas C; Kutus B; Boszormenyi E; Peintler G; Attia AAA; Lupan A; Kele Z; Sipos P; Palinko I; Calcium Complexing Behaviour of Lactate in Neutral to Highly Alkaline Medium

Reference No.: 31291(84PSG)

U.S. Bur. Mines Bull. 677, 1984 Pankratz LB; Stuve JM; Gokcen NA; Thermodynamic Data for Mineral Technology; US Det. Interior, Bur. Mines, Washington, DC, USA

Reference No.: 31301(10KFD)

Japan Atomic Energy Agency Data/Code 2009-024, 2010 Kitamura A; Fujiwara K; Doi R; Yoshida Y; Mihara M; Terashima M; Yui M; JAEA Thermodynamic Database for Performance Assessment of Geological Disposal of High-level Radioactive and TRU Wastes; Geological Isolation Research Unit, JAEA, Japan

Reference No.: 31308(19LKM)

Cem. Concr. Res., 2019, 115, 472 - 506; Lothenbach B; Kulik DA; Matschei T; Balonis M; Baquerizo L; Dilnesa B; Miron GD; Myers RJ; Cemdata18: A Chemical Thermodynamic Database for Hydrated Portland Cements and Alkali-activated Materials

Reference No.: 31367(18RKA)

J. Solution Chem., 2018, 47, 855 - 891; Rai D; Kitamura A; Altmaier M; Rosso KM; Sasaki T; Kobayashi T; A Thermodynamic Model for ZrO₂(am) Solubility at 25 C in the Ca²⁺ - Na⁺ - H⁺ - Cl⁻ - OH⁻ - H₂O System: A Critical Review

Reference No.: 31676(08OSD)

Environ. Sci. Technol., 2008, 42, 4378 - 4383; Oorts K; Smolders E; Degryse F; Buekers J; Gasco G; Cornelis G; Mertens J; Solubility and Toxicity of Antimony Trioxide (Sb₂O₃) in Soil

Reference No.: 31677(11CVS)

Appl. Geochem., 2011, 26, 809 - 817; Cornelis G; Van Gerven T; Snellings R; Verbinnen B; Elsen J; Vandecasteele C; Stability of Pyrochlores in Alkaline Matrices: Solubility of Calcium Antimonate

Reference No.: 31694(86Lar)

Archiv. Oral Biol., 1986, 31, 757 - 761; Larsen MJ; An Investigation of the Theoretical Background for the Stability of the Calcium-Phosphate Salts and their Mutual Convesion in Aqueous Solutions

Reference No.: 31716(83SPZ)

J. Dent. Res., 1983, 62, 398 - 400; Shyu LJ; Perez L; Zawacki SJ; Heughebaert JC; Nancollas GH; The Solubility of Octacalcium Phosphate at 37C in the System Ca(OH)₂-H₃PO₄-KNO₃-H₂O

Reference No.: 31717(79ToN)

Invest. Urol., 1979, 16, 329 - 335; Tomazic BB; Nancollas GH; A Study of the Phase Transformation of Calcium Oxalate Trihydrate-Monohydrate

Reference No.: 31718(78MeE)

Calcif. Tiss. Res., 1978, 25, 59 - 68; Meyer JL; Eanes ED; A Thermodynamic Analysis of the Amorphous to Crystalline Calcium Phosphate Transformation

Reference No.: 31723(08WaN)

Chem. Rev., 2008, 108, 4628 - 4669; Wang L; Nancollas GH; Calcium Orthophosphates: Crystallization and Dissolution

Reference No.: 31724(07BLS)

Appl. Geochem., 2007, 22, 2016 - 2028; Bengtsson A; Lindegren M; Sjoberg S; Persson P; Dissolution, Adsorption and Phase Transformation in the Fluorapatite-Goethite System

Reference No.: 31741(20YZF)

Appl. Geochem., 2020, 120, 104659-1 - 9; Yan Q; Zhu Y; Feng G; Zhu Z; Zhang L; Liu J; He H; Characterization, Dissolution and Solubility of Lead Fluorapatite at 25-45 C

Reference No.: 31745(16ZZZ)

Chem. Geol., 2016, 423, 34 - 48; Zhu Y; Zhu Z; Zhao X; Liang Y; Dai L; Huang Y; Characterization, Dissolution and Solubility of Cadmium-Calcium Hydroxyapatite Solid Solutions at 25 C

Reference No.: 31748(19GoG)

J. Mol. Liq., 2019, 291, 111260-1 - 111260-10; Golovanova OA; Ghyngazov SA; Thermodynamic and Experimental Modeling of the Formation of the Mineral Phase of Calcification

Reference No.: 31749(18MaC)

Monatsh. Chem., 2018, 149, 253 - 260; Magalhaes MCF; Costa MOG; On the Solubility of Whitlockite, $\text{Ca}_9\text{Mg}(\text{HPO}_4)(\text{PO}_4)_6$, in Aqueous Solution at 298.15 K

Reference No.: 31761(20NVM)

Processes, 2020, 8, 1009-1 - 1009-21; Nikolenko MV; Vasylenko KV; Myrhorodska VD; Kostyniuk A; Likozar B; Synthesis of Calcium Orthophosphates by Chemical Precipitation in Aqueous Solutions: The Effect of the Acidity, Ca/P Molar Ratio, and Temperature on the Phase Composition and Solubility of Precipitates

Reference No.: 31793(18Kru)

J. Phys. Chem. Ref. Data, 2018, 47, 023101-1 - 023101-30; Krumgalz BS; Temperature Dependence of Mineral Solubility in Water. Part 3. Alkaline and Alkaline Earth Sulfates

Reference No.: 32047(21BMD)

Molecules, 2021, 26, 3149-1 - 3149-9; Berto S; Marangella M; De Stefano C; Milea D; Daniele PG; Critical Reappraisal of Methods for Measuring Urine Saturation with Calcium Salts

Reference No.: 32051(21ARE)

J. Cryst. Growth, 2021, 558, 125956-1 - 125956-7; Ahmed A; Rodgers AL; Elmagbari F; Jackson GE; In Support of Hydroxycitrate Being Clinically Investigated as a Potential Therapy of Calcium Nephrolithiasis: Theoretical Modelling and in vitro Investigation of Thermodynamic Effects

Reference No.: 32152(20AAG)

Chem. Geol., 2020, 550, 119699-1 - 119699-12; Aranovich LYa; Akinfiev NN; Golunova M; Quartz Solubility in Sodium Carbonate Solutions at High Pressure and Temperature

Reference No.: 32222(06DGC)

Technical Report TR-06-17, 2006 Duro L; Grive M; Cera E; Domenech C; Bruno J; Update of a Thermodynamic Database for Radionuclides to Assist Solubility Limits Calculation for Performance Assessment; Swedish Nucl. Fuel & Waste Management Co, Stockholm, Sweden

Reference No.: 32224(80BeT)

Lawrence Berkeley Laboratory Report LBL-11448, 1980 Benson LV; Teague LS; A Tabulation of Thermodynamic Data for Chemical Reactions Involving 8 Elements Common to Radioactive Waste Package Systems