

JESS Thermodynamic Database v8.9

Lithium

24-Jan-23

Reaction No. 1351							
CrO4-2 + Li+1 = Li+1_CrO4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0.01	0	Inf. Dilution	lgK:1.0819 (5SF)	5	EOD	22958
2	25	0	Inf. Dilution	lgK:1.0673 (5SF)	5	EOD	22958
3	60	0	Inf. Dilution	lgK:1.1581 (5SF)	5	EOD	22958
4	100	0	Inf. Dilution	lgK:1.3371 (5SF)	5	EOD	22958
5	150	0	Inf. Dilution	lgK:1.6332 (5SF)	5	EOD	22958
6	200	0	Inf. Dilution	lgK:2.0043 (5SF)	5	EOD	22958

Reaction No. 1514							
0.5<Cl2(g)> + Li(s) = Li+1_Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-99.25 (4SF)	3	CRV	10174
2	50	0	Inf. Dilution	dG:-99.60 (4SF)	2	CRV	10174
3	75	0	Inf. Dilution	dG:-99.99 (4SF)	2	CRV	10174
4	100	0	Inf. Dilution	dG:-100.41 (5SF)	1	CRV	10174
5	125	0	Inf. Dilution	dG:-100.86 (5SF)	1	CRV	10174
6	150	0	Inf. Dilution	dG:-101.34 (5SF)	1	CRV	10174
7	175	0	Inf. Dilution	dG:-101.85 (5SF)	0	CRV	10174
8	200	0	Inf. Dilution	dG:-102.39 (5SF)	0	CRV	10174
9	225	0	Inf. Dilution	dG:-102.96 (5SF)	0	CRV	10174
10	250	0	Inf. Dilution	dG:-103.55 (5SF)	0	CRV	10174
11	300	0	Inf. Dilution	dG:-104.84 (5SF)	0	CRV	10174

Reaction No. 1519							
4<C(s)> + 3<H2(g)> + Li(s) + 2<O2(g)> + e-1 = Li+1_Acetic-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-246.81 (5SF)	4	CRV	10174
2	50	0	Inf. Dilution	dG:-247.63 (5SF)	4	CRV	10174
3	75	0	Inf. Dilution	dG:-248.76 (5SF)	4	CRV	10174
4	100	0	Inf. Dilution	dG:-250.14 (5SF)	4	CRV	10174


5	125	0	Inf. Dilution	dG:-251.74 (5SF)	4	CRV	10174
6	150	0	Inf. Dilution	dG:-253.53 (5SF)	4	CRV	10174
7	175	0	Inf. Dilution	dG:-255.47 (5SF)	4	CRV	10174
8	200	0	Inf. Dilution	dG:-257.56 (5SF)	4	CRV	10174
9	225	0	Inf. Dilution	dG:-259.76 (5SF)	4	CRV	10174
10	250	0	Inf. Dilution	dG:-262.05 (5SF)	4	CRV	10174
11	300	0	Inf. Dilution	dG:-266.69 (5SF)	4	CRV	10174

Reaction No. 1557							
2<C(s)> + 1.5<H2(g)> + Li(s) + O2(g) = Li+1_Acetic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-158.61 (5SF)	4	CRV	10174
2	50	0	Inf. Dilution	dG:-159.18 (5SF)	4	CRV	10174
3	75	0	Inf. Dilution	dG:-159.89 (5SF)	4	CRV	10174
4	100	0	Inf. Dilution	dG:-160.73 (5SF)	4	CRV	10174
5	125	0	Inf. Dilution	dG:-161.67 (5SF)	4	CRV	10174
6	150	0	Inf. Dilution	dG:-162.70 (5SF)	4	CRV	10174
7	175	0	Inf. Dilution	dG:-163.83 (5SF)	4	CRV	10174
8	200	0	Inf. Dilution	dG:-165.04 (5SF)	4	CRV	10174
9	225	0	Inf. Dilution	dG:-166.32 (5SF)	4	CRV	10174
10	250	0	Inf. Dilution	dG:-167.67 (5SF)	4	CRV	10174
11	300	0	Inf. Dilution	dG:-170.57 (5SF)	4	CRV	10174

Reaction No. 3095							
NTA-3 + Li+1 = Li+1_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:3.28 (3SF)	6	MHY	999
2	20	0.1	KNO3	lgK:2.51 (3SF)	6	CMN	1118
3	20	0.1	Me4NNO3	lgK:2.51 (0.01SD)	6	MGL	999
4	25	0.1	Inert	lgK:2.56 (0.03MD)	5	MGL	2829
5	25	0.1	Unknown	lgK:2.45 (3SF)	6	CRV	552
6	25	0.1	Unknown	lgK:2.35 (3SF)	5	MSP	11516
Note (6): Harju L, Finn. Chem. Lett., 1985, 235							
7	25	0.5	Unknown	lgK:2.36 (3SF)	6	CRV	552
8	25	1	Unknown	lgK:2.44 (3SF)	6	CRV	552
9	25	0.1	Unknown	dH:2.0 (2SF)	6	CRV	552


10	25	0.25	Inert	dH:8. (2.MD) kJ	5	MCL	2829
----	----	------	-------	-----------------	---	-----	------

Reaction No. 4105




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:1.20 (3SF)	6	CRV	552

Reaction No. 4177




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.79 (3SF)	7	EIU	903
2	20	0.1	KCl	lgK:2.79 (3SF)	4	MHY	903
3	20	0.1	Me4NC1	lgK:2.97 (3SF)	5	MGL	903
4	20	0.1	Me4NOH	lgK:3.1 (0.1SD)	4	MPL	906
5	20	1	Me4NC1	lgK:2.66 (3SF)	5	MGL	903
6	25	0.1	Inert	lgK:2.90 (0.03MD)	5	MGL	2829
7	25	0.1	Unknown	lgK:2.79 (3SF)	4	ENS	773
8	25	0.32	CsCl	lgK:2.85 (3SF)	4	MGL	2016
9	25	0.5	Me4NC1	lgK:2.43 (3SF)	6	MSP	1976
10	20	0.1	Me4NC1	dH:0.2 (1SF)	4	MCL	903
11	20:40	0.1	KNO3	dH:0.1 (1SF)	5	MCL	3201
12	25	0.05	LiCl	dH:0.1 (1SF)	5	MCL	931
13	25	0.1	Me4N+ salt	dH:0.1 (1SF)	5	MCL	2558
14	25	0.25	Inert	dH:2. (1.MD) kJ	5	MCL	2829
15	25	1	Unknown	dH:0.2 (1SF)	4	MCL	903

Reaction No. 4199



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-8.0 (2SF)	1	EES	

Reaction No. 4258



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.1 (0.2SD)	5	CRV	13242
2	25	0.1	Unknown	lgK:3.1 (2SF)	4	ENS	773

Reaction No. 4838							
Li+1 + e-1 = Li(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:69.933 (5SF)	2	CRV	6488
2	25	0	Inf. Dilution	dG:292.9 (4SF) kJ	2	CRV	6494
3	25	0	Inf. Dilution	dG:293.31 (5SF) kJ	0	EFE	7275
4	25	0	Inf. Dilution	dG:293.3 (4SF) kJ	5	CRV	7421
5	25	0	Inf. Dilution	dG:292.9 (4SF) kJ	3	CRV	8746
6	25	0	Inf. Dilution	dG:69.946 (5SF)	2	CRV	8875
7	25	0	Inf. Dilution	dG:69.933 (5SF)	2	CRV	9029
8	25	0	Inf. Dilution	dG:292.920 (0.06SD) kJ	5	CRV	27292
9	25	0	Inf. Dilution	dG:293.31 (5SF) kJ	5	CRV	28172
10	25	0	Inf. Dilution	dG:293.3 (4SF) kJ	4	EOD	29025
11	25	0	Inf. Dilution	dG:292.92 (5SF) kJ	5	EOD	29520
12	25	0	Inf. Dilution	dG:293.80 (5SF) kJ	2	CRV	31315
13	25	0	Inf. Dilution	dG:293.3 (4SF) kJ	4	EFE	32152
14	23	0	Inf. Dilution	E:-3.02 (3SF)	0	ENS	7276
15	25	0	Inf. Dilution	E:-3.03 (0.01SD)	0	MIS	775
16	25	0	Inf. Dilution	E:-3.0401 (5SF)	3	CRV	6330
17	25	0	Inf. Dilution	E:-3.045 (4SF)	1	MEF	7273
18	25	0	Inf. Dilution	E:-3.045 (4SF)	1	CRV	7372
19	25	0	Inf. Dilution	E:-3.0401 (5SF)	0	ENS	7381
20	25	0	Inf. Dilution	E:-3.040 (4SF)	3	CRV	7761
21	25	0	Inf. Dilution	E:-3.0243 (5SF)	0	CRV	13213
Note (21): p. 256							
22	25	0	Inf. Dilution	E:-3.04 (0.005SD)	3	CRV	22551
23	25	0	Inf. Dilution	dH:66.55 (0.02SD)	7	CRV	5605
24	25	0	Inf. Dilution	dH:66.552 (5SF)	4	CRV	6488
25	25	0	Inf. Dilution	dH:278.5 (4SF) kJ	5	CRV	6494
26	25	0	Inf. Dilution	dH:278.49 (5SF) kJ	5	EFE	7275
27	25	0	Inf. Dilution	dH:278.5 (4SF) kJ	5	CRV	7761
28	25	0	Inf. Dilution	dH:278.47 (0.08MD) kJ	6	CRV	8746
29	25	0	Inf. Dilution	dH:66.552 (5SF)	4	CRV	8875
30	25	0	Inf. Dilution	dH:66.552 (5SF)	4	CRV	9029
31	25	0	Inf. Dilution	dH:278.470 (0.04SD) kJ	5	CRV	27292
32	25	0	Inf. Dilution	dH:278.49 (5SF) kJ	5	CRV	28172

33	25	0	Inf. Dilution	dH:278.5 (4SF) kJ	4	EOD	29025
34	25	0	Inf. Dilution	dH:278.47 (5SF) kJ	5	EOD	29520
35	25	0	Inf. Dilution	dH:278.50 (5SF) kJ	4	CRV	31315
36	25	0	Inf. Dilution	dH:278.5 (4SF) kJ	4	EFE	32152
37	25	0	GAMSPATH	dH:275.450 (6SF) kJ	0	CRV	12638
38	25	0	Inf. Dilution	Cp:-59.4 (3SF) J/K	4	EOD	29025

Reaction No. 4912							
IDA-2 + Li+1 = Li+1_IDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:0.96 (2SF)	6	ENS	773

Reaction No. 5014							
Cl-1 + Li+1 = Li+1_Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	100	0	P=500 Inf. Dilution	lgK:-1.29 (3SF)	0	EOD	6495
2	150	0	P=500 Inf. Dilution	lgK:-1.01 (3SF)	0	EOD	6495
3	200	0	P=500 Inf. Dilution	lgK:-0.68 (2SF)	0	EOD	6495
4	250	0	P=500 Inf. Dilution	lgK:-0.29 (2SF)	0	EOD	6495
5	300	0	P=500 Inf. Dilution	lgK:0.16 (2SF)	0	EOD	6495
6	100	0	P=1000 Inf. Dilution	lgK:-1.38 (3SF)	0	EOD	6495
7	150	0	P=1000 Inf. Dilution	lgK:-1.12 (3SF)	0	EOD	6495
8	200	0	P=1000 Inf. Dilution	lgK:-0.81 (2SF)	0	EOD	6495
9	250	0	P=1000 Inf. Dilution	lgK:-0.48 (2SF)	0	EOD	6495
10	300	0	P=1000 Inf. Dilution	lgK:-0.1 (1SF)	0	EOD	6495
11	100	0	P=2000 Inf. Dilution	lgK:-1.54 (3SF)	0	EOD	6495
12	150	0	P=2000 Inf. Dilution	lgK:-1.3 (2SF)	0	EOD	6495
13	200	0	P=2000 Inf. Dilution	lgK:-1.03 (3SF)	0	EOD	6495

14	250	0	P=2000 Inf. Dilution	lgK:-0.74 (2SF)	0	EOD	6495
15	300	0	P=2000 Inf. Dilution	lgK:-0.44 (2SF)	0	EOD	6495
16	100	0	P=3000 Inf. Dilution	lgK:-1.68 (3SF)	0	EOD	6495
17	150	0	P=3000 Inf. Dilution	lgK:-1.45 (3SF)	0	EOD	6495
18	200	0	P=3000 Inf. Dilution	lgK:-1.2 (2SF)	0	EOD	6495
19	250	0	P=3000 Inf. Dilution	lgK:-0.94 (2SF)	0	EOD	6495
20	300	0	P=3000 Inf. Dilution	lgK:-0.68 (2SF)	0	EOD	6495
21	100	0	P=4000 Inf. Dilution	lgK:-1.79 (3SF)	0	EOD	6495
22	150	0	P=4000 Inf. Dilution	lgK:-1.58 (3SF)	0	EOD	6495
23	200	0	P=4000 Inf. Dilution	lgK:-1.35 (3SF)	0	EOD	6495
24	250	0	P=4000 Inf. Dilution	lgK:-1.11 (3SF)	0	EOD	6495
25	300	0	P=4000 Inf. Dilution	lgK:-0.87 (2SF)	0	EOD	6495
26	100	0	P=5000 Inf. Dilution	lgK:-1.9 (2SF)	0	EOD	6495
27	150	0	P=5000 Inf. Dilution	lgK:-1.7 (2SF)	0	EOD	6495
28	200	0	P=5000 Inf. Dilution	lgK:-1.47 (3SF)	0	EOD	6495
29	250	0	P=5000 Inf. Dilution	lgK:-1.25 (3SF)	0	EOD	6495
30	300	0	P=5000 Inf. Dilution	lgK:-1.03 (3SF)	0	EOD	6495
31	0	0	Inf. Dilution	lgK:-1.55 (3SF)	0	EOD	6495
32	25	0	Inf. Dilution	lgK:-1.51 (3SF)	0	EOD	6495
33	25	0	Inf. Dilution	lgK:-2. (1SF)	2	EOD	9361
34	25			lgK:1.43 (3SF)	3	MCN	5398
35	50	0	Inf. Dilution	lgK:-1.42 (3SF)	0	EOD	6495
36	75	0	Inf. Dilution	lgK:-1.31 (3SF)	0	EOD	6495
37	100	0	Inf. Dilution	lgK:-1.18 (3SF)	0	EOD	6495
38	125	0	Inf. Dilution	lgK:-1.04 (3SF)	0	EOD	6495
39	150	0	Inf. Dilution	lgK:-0.88 (2SF)	0	EOD	6495

40	175	0	Inf. Dilution	lgK:-0.7 (1SF)	0	EOD	6495
41	200	0	Inf. Dilution	lgK:-0.51 (2SF)	0	EOD	6495
42	225	0	Inf. Dilution	lgK:-0.3 (1SF)	0	EOD	6495
43	250	0	Inf. Dilution	lgK:-0.05 (1SF)	0	EOD	6495
44	275	0	Inf. Dilution	lgK:0.23 (2SF)	0	EOD	6495
45	300	0	Inf. Dilution	lgK:0.56 (2SF)	0	EOD	6495
46	25		Acetic acid	lgK:7.13 (3SF)	0	MCN	140
47	25		Acetic acid	lgK:4.27 (3SF)	0	MCN	140
48	25		Acetic acid	lgK:3.98 (3SF)	0	MEF	140
49	25		Acetic acid	lgK:7.08 (3SF)	0	MEF	140
50	25		Acetone	lgK:3. (1SF)	4	EMU	931
51	25		Acetone	lgK:5.32 (3SF)	5	MCN	5398
52	25		Acetone	lgK:5.47 (3SF)	5	MCN	5398
53	25		Acetone	lgK:5.48 (3SF)	5	MCN	5398
54	25		Acetone	lgK:5.55 (3SF)	5	MKN	5398
55	25		Bu3PO4	lgK:5.3 (2SF)	5	MAG	5398
56	25		Butan-2-ol	lgK:2.3 (2SF)	4	EMU	931
57	0		DMF	lgK:0.74 (2SF)	4	MKN	931
58	18	0	DMSO Inf. Dilution	lgK:0.7 (1SF)	3	MFP	931
59	25		Dioxan:Water 70:30Wgt	lgK:2.54 (3SF)	4	MAG	140
60	25		Ethanol	lgK:1.75 (3SF)	4	MCN	140
61	25		Ethanol	lgK:1.43 (3SF)	4	EMU	931
62	25		Ethanol:Water 43.5:56.5Wgt	lgK:0.40 (2SF)	5	MCN	5398
63	25		Ethanol:Water 57.1:42.9Wgt	lgK:0.49 (2SF)	5	MCN	5398
64	25		Ethanol:Water 68.2:31.8Wgt	lgK:0.68 (2SF)	5	MCN	5398
65	25		Ethanol:Water 77.2:22.8Wgt	lgK:0.88 (2SF)	5	MCN	5398
66	25		Ethanol:Water 86.6:13.4Wgt	lgK:1.02 (3SF)	5	MCN	5398
67	25		Ethanol:Water 92.3:7.7Wgt	lgK:1.20 (3SF)	5	MCN	5398
68	25		HMPT	lgK:1.24 (3SF)	5	MCN	5398
69	25		HMPT	lgK:1.27 (3SF)	5	MCN	5398
70	25		Methanol	lgK:0.5 (1SF)	4	EMU	931

71	25		PrCarbonate	lgK:2.75 (3SF)	4	MCN	5398
72	25		PrCarbonate	lgK:1.70 (3SF)	4	MEF	5398
73	25		Propan-1-ol	lgK:2.32 (3SF)	5	MCN	5398
74	25		Propan-2-ol	lgK:2.2 (2SF)	4	EMU	931

Reaction No. 6662							
Acetic-1 + Li+1 = Li+1_Acetic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:0.47 (2SF)	3	CRV	8888
2	25	0	Inf. Dilution	lgK:0.259 (3SF)	4	MGL	381
3	25	0	Inf. Dilution	lgK:0.29 (2SF)	4	MGL	1045
4	25	0	Inf. Dilution	lgK:0.30 (2SF)	4	CRV	8888
5	25	0	Inf. Dilution	lgK:0.08 (1SF)	2	EMS	12547
6	25	0.16	Unknown	lgK:-0.13 (2SF)	5	MGL	14764
7	25	0.25	Unknown	lgK:0.13 (2SF)	5	MGL	1045
8	50	0	Inf. Dilution	lgK:0.25 (2SF)	4	CRV	8888
9	75	0	Inf. Dilution	lgK:0.28 (2SF)	3	CRV	8888
10	100	0	Inf. Dilution	lgK:0.35 (2SF)	3	CRV	8888
11	125	0	Inf. Dilution	lgK:0.45 (2SF)	2	CRV	8888
12	150	0	Inf. Dilution	lgK:0.59 (2SF)	2	CRV	8888
13	175	0	Inf. Dilution	lgK:0.75 (2SF)	1	CRV	8888
14	200	0	Inf. Dilution	lgK:0.93 (2SF)	1	CRV	8888
15	225	0	Inf. Dilution	lgK:1.14 (3SF)	0	CRV	8888
16	250	0	Inf. Dilution	lgK:1.38 (3SF)	0	CRV	8888
17	275	0	Inf. Dilution	lgK:1.65 (3SF)	0	CRV	8888
18	300	0	Inf. Dilution	lgK:1.98 (3SF)	0	CRV	8888
19	325	0	Inf. Dilution	lgK:2.41 (3SF)	0	CRV	8888
20	350	0	Inf. Dilution	lgK:2.92 (3SF)	0	CRV	8888

Reaction No. 7342							
Li+1 + H+1_OHEtDiPhos-4 = H+1_Li+1_OHEtDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NC1	lgK:1.36 (3SF)	5	MGL	2756
2	25	0.1	Unknown	lgK:1.4 (0.1SD)	6	CIU	7242
3	25	0.5	Me4NC1	lgK:1.1 (0.03SD)	4	MGL	4223
4	25	0.5	Unknown	lgK:1.1 (0.1SD)	6	CIU	7242

Reaction No. 7343							
2<Li+1> + OHETDiPhos-4 = Li+1(2)_OHETDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NC1	lgK:4.78 (3SF)	5	MGL	2756

Reaction No. 7398							
OHETDiPhos-4 + Li+1 = Li+1_OHETDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NC1	lgK:3.4 (0.06SD)	5	MGL	4223
2	25	0.5	Unknown	lgK:3.4 (0.1SD)	6	CIU	7242
3	25	0.5	Me4NC1	dH:-0.57 (2SF)	5	MCL	3083

Reaction No. 7464							
Lactic-1 + Li+1 = Li+1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.20 (2SF)	4	MHY	999

Reaction No. 9582							
Malonic-2 + Li+1 = Li+1_Malonic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:0.763 (3SF)	2	MCO	4861
2	25	0	Inf. Dilution	lgK:0.819 (3SF)	4	MCO	4861
3	25	0	Inf. Dilution	lgK:1.1 (2SF)	3	CRV	7271
4	30	0	Inf. Dilution	lgK:0.869 (3SF)	4	MCO	4861
5	35	0	Inf. Dilution	lgK:0.663 (3SF)	4	MCO	4861
6	37	0	Inf. Dilution	lgK:1.31 (3SF)	6	MGL	1045
7	37	0	HNO3	lgK:1.05 (3SF)	4	MGL	6797
8	37	0.15	HNO3	lgK:0.67 (0.02MD)	5	MGL	6797
9	37	0.15	Me4N+ salt	lgK:0.67 (2SF)	3	CRV	7271
10	37	0.2	HNO3	lgK:0.66 (2SF)	5	MGL	6797
11	37	0.25	Unknown	lgK:1. (0.04SD)	4	MGL	1045
12	37	0.4	HNO3	lgK:0.68 (2SF)	5	MGL	6797
13	37	0.6	HNO3	lgK:0.74 (2SF)	5	MGL	6797
14	37	0.8	HNO3	lgK:0.80 (2SF)	5	MGL	6797
15	37	1	HNO3	lgK:0.87 (2SF)	5	MGL	6797
16	25	0	Inf. Dilution	dH:-15.0 (0.5SD) kJ	4	MCO	4861
17	25	0	Inf. Dilution	dH:2. (1SF)	0	CRV	7271

Reaction No. 9583							
H+1 + Malonic-2 + Li+1 = H+1_Li+1_Malonic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.26(3SF)	2	EAE	
2	37	0	Inf. Dilution	lgK:6.16(3SF)	6	MGL	1045
3	37	0.25	Unknown	lgK:5.6(0.05SD)	5	MGL	1045

Reaction No. 9596							
Maleic-2 + Li+1 = Li+1_Maleic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:0.832(3SF)	4	MCO	4861
2	25	0	Inf. Dilution	lgK:0.944(3SF)	4	MCO	4861
3	30	0	Inf. Dilution	lgK:0.968(3SF)	4	MCO	4861
4	35	0	Inf. Dilution	lgK:1.029(4SF)	4	MCO	4861
5	37	0	Inf. Dilution	lgK:1.23(3SF)	6	MGL	1045
6	37	0	HNO3	lgK:1.08(3SF)	4	MGL	6797
7	37	0.15	HNO3	lgK:0.72(0.02MD)	5	MGL	6797
8	37	0.2	HNO3	lgK:0.72(2SF)	5	MGL	6797
9	37	0.25	Unknown	lgK:0.9(0.09SD)	5	MGL	1045
10	37	0.4	HNO3	lgK:0.77(2SF)	5	MGL	6797
11	37	0.6	HNO3	lgK:0.86(2SF)	5	MGL	6797
12	37	0.8	HNO3	lgK:0.96(2SF)	5	MGL	6797
13	37	1	HNO3	lgK:1.06(3SF)	5	MGL	6797
14	25	0	Inf. Dilution	dH:-16.(5.SD)kJ	4	MCO	4861

Reaction No. 9597							
H+1 + Maleic-2 + Li+1 = H+1_Li+1_Maleic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0	Inf. Dilution	lgK:6.32(3SF)	6	MGL	1045
2	37	0.25	Unknown	lgK:5.9(0.1SD)	5	MGL	1045

Reaction No. 9603							
Diglycol-2 + Li+1 = Li+1_Diglycol-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	12.5	0.25	Unknown	lgK:0.7(0.03SD)	5	MGL	1045
2	25	0	Inf. Dilution	lgK:1.10(3SF)	6	MGL	1045

3	25	0.25	Unknown	lgK:0.7(0.03SD)	5	MGL	1045
4	37	0.25	Unknown	lgK:0.7(0.04SD)	5	MGL	1045
5	48	0.25	Unknown	lgK:0.8(0.04SD)	5	MGL	1045
6	30	1	LiCl	lgR:-0.62(0.02SD)	6	MRM	999
7	25	0	Inf. Dilution	dH:4.(1SF)kJ	5	MCL	1045

Reaction No. 9604

H+1 + Diglycol-2 + Li+1 = H+1_Li+1_Diglycol-2

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	12.5	0.25	Unknown	lgK:3.8(0.06SD)	5	MGL	1045
2	25	0	Inf. Dilution	lgK:4.45(3SF)	6	MGL	1045
3	25	0.25	Unknown	lgK:3.9(0.06SD)	5	MGL	1045
4	37	0.25	Unknown	lgK:3.9(0.07SD)	5	MGL	1045
5	48	0.25	Unknown	lgK:4.1(0.08SD)	5	MGL	1045
6	25	0	Inf. Dilution	dH:10.(2SF)kJ	5	MCL	1045

Reaction No. 9611

Succinic-2 + Li+1 = Li+1_Succinic-2

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:0.80(0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:0.39(0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:0.30(0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:0.26(0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:0.22(0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:0.20(0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:0.18(0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:0.17(0.01SD)	4	EDH	5390
9	37	0	Inf. Dilution	lgK:1.09(3SF)	6	MGL	1045
10	37	0	HNO3	lgK:0.84(2SF)	4	MGL	6797
11	37	0.15	HNO3	lgK:0.42(0.03MD)	4	MGL	6797
12	37	0.2	HNO3	lgK:0.40(2SF)	5	MGL	6797
13	37	0.25	Unknown	lgK:0.70(2SF)	5	MGL	1045
14	37	0.4	HNO3	lgK:0.37(2SF)	5	MGL	6797
15	37	0.6	HNO3	lgK:0.37(2SF)	5	MGL	6797
16	37	0.8	HNO3	lgK:0.38(2SF)	5	MGL	6797
17	37	1	HNO3	lgK:0.39(2SF)	5	MGL	6797

Reaction No. 9612							
H+1 + Succinic-2 + Li+1 = H+1_Li+1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.04(3SF)	2	EAE	
2	37	0	Inf. Dilution	lgK:5.93(3SF)	6	MGL	1045
3	37	0.25	Unknown	lgK:5.38(3SF)	5	MGL	1045

Reaction No. 9623							
Phthalic-2 + Li+1 = Li+1_Phthalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:0.90(0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:0.52(0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:0.45(0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:0.41(0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:0.38(0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:0.36(0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:0.35(0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:0.34(0.01SD)	4	EDH	5390
9	37	0	Inf. Dilution	lgK:1.14(3SF)	6	MGL	1045
10	37	0	HNO3	lgK:1.00(3SF)	4	MGL	6797
11	37	0.15	HNO3	lgK:0.65(2SF)	5	MGL	6797
12	37	0.2	HNO3	lgK:0.65(2SF)	5	MGL	6797
13	37	0.25	Unknown	lgK:0.9(0.05SD)	5	MGL	1045
14	37	0.4	HNO3	lgK:0.71(2SF)	5	MGL	6797
15	37	0.6	HNO3	lgK:0.80(2SF)	5	MGL	6797
16	37	0.8	HNO3	lgK:0.90(2SF)	5	MGL	6797
17	37	1	HNO3	lgK:1.00(3SF)	5	MGL	6797

Reaction No. 9624							
H+1 + Phthalic-2 + Li+1 = H+1_Li+1_Phthalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0	Inf. Dilution	lgK:5.48(3SF)	6	MGL	1045
2	37	0.25	Unknown	lgK:5.0(0.09SD)	5	MGL	1045

Reaction No. 10621							
Malic-2 + Li+1 = Li+1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0.1	Unknown	lgK:0.38 (0.02SD)	4	ENS	999
2	25	0.28	Me4NBr	lgK:0.4 (0.05SD)	4	MGL	999


Reaction No. 12203							
Citric-3 + Li+1 = Li+1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.17	Unknown	lgK:0.83 (0.01SD)	4	ENS	999
2	25	0.5	KCl	lgK:1.10 (3SF)	6	MGL	2242
3	37	0.15	Unknown	lgK:0.88 (0.06MD)	4	MGL	1230
4	25	0.5	KCl	dH:-3.0 (2SF) kJ	4	MCL	2242

Reaction No. 14044							
Li+1 + H+1_EDTA-4 = H+1_Li+1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.32	CsCl	lgK:0.86 (2SF)	4	MGL	903

Reaction No. 14199							
5ATP-4 + Li+1 = Li+1_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Pr4N+ salt	lgK:2.57 (3SF)	4	MGL	5326
2	10	0.04	Pr4N+ salt	lgK:2.04 (3SF)	4	MGL	5326
3	10	0.16	Pr4N+ salt	lgK:1.83 (3SF)	4	MGL	5326
4	10	0.25	Pr4N+ salt	lgK:1.80 (3SF)	4	MGL	5326
5	10	0.49	Pr4N+ salt	lgK:1.82 (3SF)	4	MGL	5326
6	10	1	Pr4N+ salt	lgK:1.86 (3SF)	4	MGL	5326
7	25	0.05:0.12	LiCl	lgK:1.74 (3SF)	4	MGL	1437
8	25	0	Pr4N+ salt	lgK:2.53 (3SF)	4	MGL	5326
9	25	0.04	Pr4N+ salt	lgK:1.99 (3SF)	4	MGL	5326
10	25	0.1	Me4N+ salt	lgK:1.8 (0.08SD)	8	CIU	1437
11	25	0.16	Pr4N+ salt	lgK:1.79 (3SF)	4	MGL	5326
12	25	0.2	Et4NCl	lgK:1.53 (3SF)	4	MGL	258
13	25	0.2	Me4NCl	lgK:1.35 (3SF)	4	MGL	258
Note (13): This datum not in cited reference; source unknown							
14	25	0.2	Pr4NCl	lgK:1.57 (3SF)	4	MGL	258
15	25	0.25	Pr4N+ salt	lgK:1.78 (0.02SD)	5	MGL	3595
16	25	0.32	Unknown	lgK:1.7 (2SF)	4	MGL	999
17	25	0.49	Pr4N+ salt	lgK:1.83 (3SF)	4	MGL	5326


18	25	1	Pr4N+ salt	lgK:1.99 (3SF)	4	MGL	5326
19	25			lgK:1.7 (2SF)	3	ENS	3560
20	35	0	Pr4N+ salt	lgK:2.49 (3SF)	4	MGL	5326
21	35	0.04	Pr4N+ salt	lgK:1.95 (3SF)	4	MGL	5326
22	35	0.16	Pr4N+ salt	lgK:1.77 (3SF)	4	MGL	5326
23	35	0.25	Pr4N+ salt	lgK:1.76 (3SF)	4	MGL	5326
24	35	0.49	Pr4N+ salt	lgK:1.89 (3SF)	4	MGL	5326
25	35	1	Pr4N+ salt	lgK:2.09 (3SF)	4	MGL	5326
26	45	0	Pr4N+ salt	lgK:2.47 (3SF)	4	MGL	5326
27	45	0.04	Pr4N+ salt	lgK:1.93 (3SF)	4	MGL	5326
28	45	0.16	Pr4N+ salt	lgK:1.74 (3SF)	4	MGL	5326
29	45	0.25	Pr4N+ salt	lgK:1.75 (3SF)	4	MGL	5326
30	45	0.49	Pr4N+ salt	lgK:1.85 (3SF)	4	MGL	5326
31	45	1	Pr4N+ salt	lgK:2.2 (2SF)	4	MGL	5326
32	10:45	0.25	Pr4N+ salt	dH: -3. (2.SD) kJ	4	MTD	3595
33	25	0.1	Inert	dH: -4. (4.SD) kJ	5	CIU	1437

Reaction No. 14390




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:3.43 (3SF)	6	CRV	552
2	25	0.5	Unknown	lgK:4.01 (3SF)	5	MPM	3560

Reaction No. 14659




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.0 (2SF)	1	EDH	
2	25	0.5	Me4NOH	lgK:6.1 (0.1SD)	0	MPM	906
3	30	0.1	KNO3	lgK:4.13 (3SF)	4	MPL	2016

Reaction No. 14919




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1.5	KCl	lgK:1.17 (3SF)	6	MKN	999

Reaction No. 16084




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Inert	lgK:1.7(0.03SD)	4	MGL	1306

Reaction No. 16085




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Inert	lgK:6.9(0.03SD)	4	MGL	1306

Reaction No. 16086




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Inert	lgK:10.8(0.04SD)	4	MGL	1306

Reaction No. 16087




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Inert	lgK:13.0(0.06SD)	4	MGL	1306

Reaction No. 16088




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Inert	lgK:2.5(0.04SD)	4	MGL	1306

Reaction No. 16089



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Inert	lgK:6.9(0.1SD)	4	MGL	1306

Reaction No. 17205



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:1.3(0.05SD)	7	CIU	1437
2	25	0.2	Et4NC1	lgK:1.15(3SF)	4	MGL	258
3	25	0.2	Me4NC1	lgK:1.06(3SF)	4	MGL	258

Note (3): This datum not in cited reference; source unknown

4	25	0.2	Pr4NC1	lgK:1.15(3SF)	4	MGL	258
---	----	-----	--------	---------------	---	-----	-----

Reaction No. 17207

5AMP-2 + Li+1 = Li+1_5AMP-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:1.2(0.05SD)	7	CIU	1437
2	25	0.2	Et4NC1	lgK:0.61(2SF)	4	MGL	258
3	25	0.2	Me4NC1	lgK:0.50(2SF)	4	MGL	258
Note (3): This datum not in cited reference; source unknown							
4	25	0.2	Pr4NC1	lgK:0.61(2SF)	4	MGL	258

Reaction No. 17540							
5AQP-5 + Li+1 = Li+1_5AQP-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:2.2(0.05SD)	7	CIU	1437
2	25	0.2	Et4NC1	lgK:1.86(3SF)	4	MGL	258
3	25	0.2	Me4NC1	lgK:1.68(3SF)	4	MGL	258
Note (3): This datum not in cited reference; source unknown							
4	25	0.2	Pr4NC1	lgK:1.90(3SF)	4	MGL	258


Reaction No. 18388							
Gly-1 + Li+1 = Li+1_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NC1	lgK:-1.2(0.1SD)	3	MSP	1529

Reaction No. 20686							
Li+1_5ATP-4 + 5ATP-4 = Li+1_5ATP-4(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.32	Unknown	lgK:0.53(2SF)	6	MGL	999

Reaction No. 20687							
Li+1 + H+1_5ATP-4 = H+1_Li+1_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Pr4N+ salt	lgK:0.4(1SF)	4	MGL	1437
2	10	0.04	Pr4N+ salt	lgK:0.02(1SF)	4	MGL	1437
3	10	0.16	Pr4N+ salt	lgK:-0.14(2SF)	4	MGL	1437
4	10	0.25	Pr4N+ salt	lgK:-0.15(2SF)	4	MGL	1437
5	10	0.49	Pr4N+ salt	lgK:-0.1(1SF)	4	MGL	1437
6	10	1	Pr4N+ salt	lgK:-0.1(1SF)	4	MGL	1437
7	25	0	Pr4N+ salt	lgK:0.44(2SF)	4	MGL	1437


8	25	0.04	Pr4N+ salt	lgK:0.03(1SF)	4	MGL	1437
9	25	0.16	Pr4N+ salt	lgK:-0.10(2SF)	4	MGL	1437
10	25	0.25	Pr4N+ salt	lgK:-0.11(2SF)	4	MGL	1437
11	25	0.32	Unknown	lgK:0.8(1SF)	4	MGL	999
12	25	0.49	Pr4N+ salt	lgK:-0.05(1SF)	4	MGL	1437
13	25	1	Pr4N+ salt	lgK:0.09(1SF)	4	MGL	1437
14	35	0	Pr4N+ salt	lgK:0.45(2SF)	4	MGL	1437
15	35	0.04	Pr4N+ salt	lgK:0.05(1SF)	4	MGL	1437
16	35	0.16	Pr4N+ salt	lgK:-0.08(1SF)	4	MGL	1437
17	35	0.25	Pr4N+ salt	lgK:-0.08(1SF)	4	MGL	1437
18	35	0.49	Pr4N+ salt	lgK:-0.02(1SF)	4	MGL	1437
19	35	1	Pr4N+ salt	lgK:0.21(2SF)	4	MGL	1437
20	45	0	Pr4N+ salt	lgK:0.48(2SF)	4	MGL	1437
21	45	0.04	Pr4N+ salt	lgK:0.07(1SF)	4	MGL	1437
22	45	0.16	Pr4N+ salt	lgK:-0.06(1SF)	4	MGL	1437
23	45	0.25	Pr4N+ salt	lgK:-0.08(1SF)	4	MGL	1437
24	45	0.49	Pr4N+ salt	lgK:0.0(1SF)	4	MGL	1437
25	45	1	Pr4N+ salt	lgK:0.3(1SF)	4	MGL	1437
26	10:45	0.25	Pr4N+ salt	dH:0.96(2SF)	4	MTD	1437

Reaction No. 21365




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NC1	lgK:2.5(0.05SD)	4	MGL	4223
2	25	0.5	Me4NC1	dH:0.70(2SF)	5	MCL	3083

Reaction No. 21366



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NC1	lgK:0.8(0.03SD)	4	MGL	4223

Reaction No. 21846



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NC1	lgK:3.1(0.1SD)	5	MGL	4223
2	25	0.5	Me4NC1	dH:-0.36(2SF)	5	MCL	3083

Reaction No. 21847							
$\text{Li+1} + \text{H+1_Et11DiPhos-4} = \text{H+1_Li+1_Et11DiPhos-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NCl/m	lgK:1. (0.04SD)	5	MGL	

Reaction No. 24947							
$\text{H+1} + \text{Citric-3} + \text{Li+1} = \text{H+1_Li+1_Citric-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KCl	lgK:6.49 (3SF)	5	MGL	2242
2	25	0.5	KCl	dH:-3.6 (2SF) kJ	4	MCL	2242

Reaction No. 24948							
$2\text{<Li+1>} + \text{Citric-3} = \text{Li+1(2)_Citric-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KCl	lgK:1.66 (3SF)	6	MGL	2242
2	25	0.5	KCl	dH:-5.0 (2SF) kJ	4	MCL	2242

Reaction No. 25568							
$\text{N2COOPhenIDA-3} + \text{Li+1} = \text{Li+1_N2COOPhenIDA-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.18 (3SF)	6	MHY	999
2	20	0.1	Me4NNO3	lgK:2.05 (0.01SD)	6	MGL	999


Reaction No. 25811							
$[\text{12}]\text{N4:Acet*4-4} + \text{Li+1} = \text{Li+1_}[\text{12}]\text{N4:Acet*4-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:4.3 (0.03SD)	6	MGL	2016

Reaction No. 28452							
$\text{Li+1_NH3(2)} + \text{NH3} = \text{Li+1_NH3(3)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	2	NH4NO3	lgK:-1.3 (2SF)	4	MGL	140
2	25	0	Inf. Dilution	lgK:-1.3 (3SF)	2	EAE	

Reaction No. 28453							
$\text{Li+1_NH3} + \text{NH3} = \text{Li+1_NH3(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	23	2	NH4NO3	lgK:-0.8(1SF)	4	MGL	140
2	25	0	Inf. Dilution	lgK:-0.8(3SF)	2	EAE	

Reaction No. 28498




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NC1	lgK:5.25(3SF)	5	MPM	1976

Reaction No. 28499




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NC1	lgK:1.68(3SF)	5	MPM	1976

Reaction No. 28500




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NC1	lgK:2.60(3SF)	5	MPM	1976

Reaction No. 30042




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NNO3	lgK:-0.2(0.03SD)	6	MGL	2542
2	25	0.25	DMSO:Water 90:10Vol Me4NNO3	lgK:0.4(0.03SD)	6	MGL	2542

Reaction No. 30048



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NNO3	lgK:-0.5(0.05SD)	6	MGL	2542
2	25	0.25	DMSO:Water 90:10Vol Me4NNO3	lgK:0.5(0.03SD)	6	MGL	2542

Reaction No. 30054



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NNO3	lgK:-0.28(0.01SD)	6	MGL	2542

2	25	0.5	DMSO:Water 75:25Vol Me4NNO3	lgK:0.34 (0.02SD)	6	MGL	2542
3	25	0.25	DMSO:Water 90:10Vol Me4NNO3	lgK:0.61 (0.01SD)	6	MGL	2542
4	25	0.5	Dioxan:Water 50:50Vol Me4NNO3	lgK:0.15 (0.01SD)	6	MGL	2542
5	25	1	Dioxan:Water 50:50Vol Me4NNO3	lgK:0.12 (0.01SD)	6	MGL	2542
6	25	0.5	Methanol:Water 50:50Vol Me4NNO3	lgK:0.0800000 (0.09SD)	6	MGL	2542

Reaction No. 30810							
N2PyridMeAsp-2 + Li+1 = Li+1_N2PyridMeAsp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:1.71 (0.01SD)	5	MGL	999

Reaction No. 30926							
OHMePhos-2 + Li+1 = Li+1_OHMePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NCl	lgK:0.72 (2SF)	5	MGL	2756


Reaction No. 32637							
H+1 + EDTA-4 + Li+1 = H+1_Li+1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Inert	lgK:10.85 (0.05MD)	4	MGL	2829
2	25	0.25	Inert	dH:-2. (2.MD) kJ	4	MCL	2829

Reaction No. 32638							
EDTA-4 + 2<Li+1> = Li+1(2)_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Inert	lgK:3.05 (0.09MD)	4	MGL	2829
2	25	0.25	Inert	dH:3. (2.MD) kJ	4	MCL	2829

Reaction No. 32642							
H+1 + NTA-3 + Li+1 = H+1_Li+1_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0.1	Inert	lgK:9.6(0.2MD)	4	MGL	2829
2	25	0.25	Inert	dH:15.(8.MD)kJ	4	MCL	2829

Reaction No. 32924




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:3.00(0.01SD)	6	MPT	2733

Reaction No. 33639



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Ethanol LiClO4	lgK:2.1(0.2SD)	5	MGL	931
2	25	0.1	Methanol LiClO4	lgK:1.5(0.2SD)	5	MGL	931

Reaction No. 35798



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	KCl	lgK:5.5(2SF)	5	MGL	3283
2	25	0.05	Acetone Et4NClO4	lgK:11.80(0.03SD)	5	MAG	4399
3	25	0.05	Acetone Et4NClO4	dH:-63.0(0.4SD)kJ	5	MCL	4399
4	25	0.01	DMF Et4NClO4	lgK:6.99(3SF)	5	MGL	2931
5	25	0.01	DMSO Et4NClO4	lgK:5.84(3SF)	5	MGL	2931
6	25	0.05	Et3PO4 Et4NClO4	lgK:6.44(0.01SD)	5	MMR	2464
7	25		Ethanol:Water 95:5Vol	lgK:8.47(3SF)	5	MGL	2931
8	25	0.05	Me3PO4 Et4NClO4	lgK:7.0(0.05SD)	4	MIS	2529
9	25		MeCN	lgK:10.(2SF)	3	MGL	2931
10	25	0.01	Methanol KCl	lgK:6.0(2SF)	3	MGL	3283
11	25	0.05	Methanol Et4NClO4	lgK:8.04(3SF)	5	MAG	2956
12	25		Methanol	lgK:7.90(3SF)	5	MMC	3854
13	25		Methanol	dH:-33.9(3SF)kJ	4	MCL	3854


14	25	0.01	Methanol:Water 95:5Vol KCl	lgK:7.58 (3SF)	5	MGL	3283
15	25	0.1	Methanol:Water 95:5Vol Me4NCl	lgK:7.93 (3SF)	5	MGL	3712
16	25		NMePrAmide	lgK:6.43 (3SF)	5	MGL	2931
17	25	0.1	PrCarbonate Unknown	lgK:12.9 (0.1SD)	5	MIX	6922
18	25		PrCarbonate	lgK:12.86 (4SF)	5	MAG	4773
19	25		PrCarbonate	lgK:12.4 (0.1SD)	5	MPT	4822

Reaction No. 35806							
[2.2.1]crypt + Li+1 = Li+1_[2.2.1]crypt							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	KCl	lgK:2.50 (3SF)	5	MGL	3283
2	25	0.05	Acetone Et4NClO4	lgK:8.11 (0.02SD)	5	MAG	4399
3	25	0.05	Acetone Et4NClO4	dH:-38.8 (0.4SD) kJ	5	MCL	4399
4	25		DMSO	lgK:2.63 (3SF)	5	MAG	4773
5	25		Ethanol:Water 95:5Vol	lgK:5.38 (3SF)	5	MGL	2931
6	25		MeCN	lgK:10.33 (4SF)	5	MGL	2931
7	25	0.01	Methanol KCl	lgK:5.0 (2SF)	3	MGL	3283
8	25	0.05	Methanol Et4NClO4	lgK:5.38 (3SF)	5	MAG	2956
9	25		Methanol	lgK:4.69 (3SF)	5	MMC	3854
10	25		Methanol	dH:-10.3 (3SF) kJ	4	MCL	3854
11	25	0.01	Methanol:Water 95:5Vol KCl	lgK:4.18 (3SF)	5	MGL	3283
12	25	0.1	Methanol:Water 95:5Vol Me4NCl	lgK:4.46 (3SF)	5	MGL	3712
13	25		NMePrAmide	lgK:3.48 (3SF)	5	MGL	2931
14	25		PrCarbonate	lgK:9.67 (3SF)	5	MAG	4773
15	25		PrCarbonate	lgK:9.6 (0.1SD)	5	MPT	4822

Reaction No. 35814							
[2.2.2]crypt + Li+1 = Li+1_[2.2.2]crypt							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	KCl	lgK:2.0 (2SF)	3	MGL	3283
2	25	0.05	Acetone Et4NC1O4	lgK:4.62 (0.03SD)	5	MAG	4399
3	25	0.05	Acetone Et4NC1O4	dH:-23.9 (0.5SD) kJ	5	MCL	4399
4	25	0.01	DMSO Et4NC1O4	lgK:1.0 (2SF)	3	MGL	2931
5	25		Ethanol:Water 95:5Vol	lgK:2.3 (2SF)	3	MGL	2931
6	25		MeCN	lgK:6.97 (3SF)	5	MGL	2931
7	25		MeCN	dH:-7. (0.3SD)	5	MCL	4801
8	25	0.01	Methanol KCl	lgK:2.6 (2SF)	5	MGL	3283
9	25		Methanol	lgK:2.46 (3SF)	5	MMC	3854
10	25		Methanol	dH:-3.7 (2SF) kJ	4	MCL	3854
11	25	0.01	Methanol:Water 95:5Vol KCl	lgK:1.8 (2SF)	5	MGL	3283
12	25	0.1	Methanol:Water 95:5Vol Me4NC1	lgK:1. (1SF)	3	MGL	3712
13	25		NMePrAmide	lgK:2.97 (3SF)	5	MGL	2931
14	25		Nitromethane	lgK:11.5 (0.05SD)	5	MCN	4799
15	25		Nitromethane	dG:-15.68 (4SF)	5	EFE	4799
16	25		Nitromethane	dH:-14.1 (0.1SD)	5	MCL	4798
17	25		PrCarbonate	lgK:6.9 (0.1SD)	5	MPT	4822
18	25		PrCarbonate	dH:-8.7 (0.07SD)	5	MCL	4801

Reaction No. 35932



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:3.2 (2SF)	5	MPT	2725
2	-75			dH:3.3 (1.SD) kJ	3	MCL	13
3	-95			dH:-50. (20.SD) kJ	3	MCL	13
4	25	0.15	NaCl	dH:-2.1 (0.1SD) kJ	5	MCL	2725


Reaction No. 36051



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0.15	NaCl	lgK:4.8 (2SF)	5	MPT	2723
---	----	------	------	---------------	---	-----	------

Reaction No. 36246




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:5.61 (3SF)	6	CRV	552
2	20	0	Inf. Dilution	lgK:5.40 (3SF)	4	ENS	3560
3	20	0.1	Unknown	lgK:4.90 (0.02SD)	4	ENS	3560
4	25	0.1	Me4N+ salt	lgK:4.88 (3SF)	6	CRV	552
5	20	0.1	Me4N+ salt	dH:-1.8 (2SF)	6	CRV	552
6	20:40	0.1	KNO3	dH:-7.0 (2SF)	0	MCL	3201

Reaction No. 37208




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Dioxan:Water 75:25Wgt	lgK:5.95 (3SF)	5	MGL	2360

Reaction No. 37467




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Ethanol LiClO4	lgK:3.2 (0.2SD)	5	MGL	931
2	25	0.1	Methanol LiClO4	lgK:3.1 (0.2SD)	5	MGL	931

Reaction No. 37906



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:2. (1SF)	3	MPT	425
2	25		DMF	lgK:1.9 (0.05SD)	4	MPT	425
3	25		MeCN	lgK:5.8 (0.05SD)	4	MPT	425
4	25		Methanol	lgK:2.5 (0.05SD)	4	MPT	425
5	25		PrCarbonate	lgK:5.1 (0.1SD)	4	MPT	425
6	25		Pyridine	lgK:2.8 (0.05SD)	4	MPT	425

Reaction No. 38629



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	DMF Inf. Dilution	lgK:5.9(0.1SD)	5	MPT	4763
2	25	0	DMSO Inf. Dilution	lgK:3.7(0.1SD)	5	MPT	4763
3	25		Ethanol	lgK:5.35(3SF)	4	MPT	2938
4	25	0	MeCN Inf. Dilution	lgK:10.3(0.1SD)	3	MPT	4763
5	25	0	Methanol Inf. Dilution	lgK:3.6(0.1SD)	5	MPT	4763
6	25	0.16	Methanol Bu4NOH	lgK:3.3(0.1SD)	4	MCV	4777
7	25	0	PrCarbonate Inf. Dilution	lgK:11.5(0.1SD)	5	MPT	4763

Reaction No. 38641							
Lasalocid-1 + Li+1 = Li+1_Lasalocid-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	DMF Inf. Dilution	lgK:2.1(0.1SD)	5	MPT	4763
2	25	0	Ethanol Inf. Dilution	lgK:2.9(0.1SD)	5	MPT	4763
3	25	0	Methanol Inf. Dilution	lgK:2.2(0.1SD)	5	MPT	4763
4	25	1	Methanol Tris buffer	lgK:1.68(3SF)	4	MPH	5674
5	25		Methanol	lgK:1.9(2SF)	5	MGL	2600
6	25		Methanol	lgK:1.44(3SF)	4	MPT	2604
7	25		Methanol	dH:4.9(2SF) kJ	4	MCL	2600
8	25	0	PrCarbonate Inf. Dilution	lgK:4.9(0.1SD)	5	MPT	4763

Reaction No. 38688							
Phenanth + Li+1 = Li+1_Phenanth							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Acetone	lgK:3.11(0.01SD)	4	MFL	2469
2	25	0.05	Ethanol:Water 95:5Wgt Et4NC1O4	lgK:2.2(0.08SD)	4	MPS	2713
3	25		MeCN	lgK:3.0(0.03SD)	4	MFL	2469
4	25		Methanol	lgK:0.95(0.02SD)	4	MFL	2469

Reaction No. 38689							
Li+1_Phenanth + Phenanth = Li+1_Phenanth(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Acetone	lgK:2.00 (0.02SD)	4	MFL	2469
2	25		MeCN	lgK:1.9 (0.04SD)	4	MFL	2469

Reaction No. 38694							
Oxine-1 + Li+1 = Li+1_Oxine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Acetone	lgK:2.0 (0.08SD)	4	MFL	2469
2	25	0.05	Ethanol:Water 95:5Wgt Et4NC1O4	lgK:1.8 (0.07SD)	4	MPS	2713
3	25		MeCN	lgK:2.82 (0.02SD)	4	MFL	2469
4	25		Methanol	lgK:0.9 (0.03SD)	4	MFL	2469

Reaction No. 38695							
Li+1_Oxine-1 + Oxine-1 = Li+1_Oxine-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		MeCN	lgK:1.7 (0.05SD)	4	MFL	2469

Reaction No. 38701							
Bipy + Li+1 = Li+1_Bipy							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Acetone	lgK:1.8 (0.05SD)	4	MFL	2469
2	25	0.05	Ethanol:Water 95:5Wgt Et4NC1O4	lgK:1.6 (0.05SD)	4	MPS	2713
3	25		MeCN	lgK:1.87 (0.01SD)	4	MFL	2469
4	25		Methanol	lgK:0.4 (0.04SD)	4	MFL	2469

Reaction No. 38717							
[2.1.C5]crypt + Li+1 = Li+1_[2.1.C5]crypt							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Bu3PO4 Et4NC1O4	lgK:2.4 (0.1SD)	5	MMR	2464
2	25	0.05	Et3PO4 Et4NC1O4	lgK:2.0 (0.1SD)	5	MMR	2464
3	25	0.05	Et3PO4 Et4NC1O4	dH:34.75 (0.5SD) kJ	4	MDG	2464

4	25	0.05	Me3PO4 Et4NClO4	lgK:2.4 (0.1SD)	4	MIS	2529
---	----	------	--------------------	-----------------	---	-----	------

Reaction No. 38735							
[18]N2O4 + Li+1 = Li+1_[18]N2O4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Acetone Et4NClO4	lgK:1.52 (0.02SD)	5	MAG	4399
2	25	0.05	Acetone Et4NClO4	dH:0.0 (1SF) kJ	3	MCL	4399
3	25		MeCN	lgK:4.45 (3SF)	5	MAG	3910
4	25	0.1	Methanol:Water 95:5Vol Me4NCl	lgK:1.07 (3SF)	5	MGL	3712
5	25		Nitromethane	lgK:6.98 (3SF)	5	MAG	3910

Reaction No. 38741							
Li+1 + H+1(2)_Purpur-3 = H+1(2)_Li+1_Purpur-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Ethanol:Water 95:5Wgt Et4NClO4	lgK:2.4 (0.07SD)	5	MPS	2713

Reaction No. 38744							
Cat-2 + Li+1 = Li+1_Cat-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Ethanol:Water 95:5Wgt Et4NClO4	lgK:1.3 (0.05SD)	4	MPS	2713

Reaction No. 38748							
12BenzDiAm + Li+1 = Li+1_12BenzDiAm							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Ethanol:Water 95:5Wgt Et4NClO4	lgK:1.1 (0.03SD)	4	MPS	2713

Reaction No. 38752							
2AmPyridine + Li+1 = Li+1_2AmPyridine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Ethanol:Water 95:5Wgt Et4NClO4	lgK:0.8 (0.05SD)	4	MPS	2713

Reaction No. 39649							
[2.2.2]crypt:DiBenz + Li+1 = Li+1_[2.2.2]crypt:DiBenz							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	MeCN Et4NClO4	lgK:6.06(0.01SD)	5	MGL	4796
2	25	0.1	MeCN Et4NClO4	dG:-8.27(3SF)	5	EFE	4796
3	25		MeCN	dH:-7.9(0.05SD)	5	MCL	2185
4	25	0.1	Nitromethane Et4NClO4	lgK:10.5(0.05SD)	5	MGL	4796
5	25	0.1	Nitromethane Et4NClO4	dG:-14.32(4SF)	5	EFE	4796
6	25	0.1	PrCarbonate Et4NClO4	lgK:5.6(0.06SD)	5	MGL	4796
7	25	0.1	PrCarbonate Et4NClO4	dG:-7.64(3SF)	5	EFE	4796
8	25		PrCarbonate	dH:-8.8(0.05SD)	5	MCL	2185

Reaction No. 40449							
Pr22DiPhos-4 + Li+1 = Li+1_Pr22DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NCl	lgK:3.8(0.1SD)	5	MGL	931
2	25	0.5	Me4NCl	dH:-1.32(3SF)	5	MCL	3083

Reaction No. 40450							
Li+1 + H+1_Pr22DiPhos-4 = H+1_Li+1_Pr22DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NCl	lgK:1.4(0.04SD)	5	MGL	931

Reaction No. 40829							
[Hex]IDA-2 + Li+1 = Li+1_[Hex]IDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:1.74(0.02SD)	6	MGL	931

Reaction No. 40844							
[2OHHex]IDA-2 + Li+1 = Li+1_[2OHHex]IDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:2.19(0.01SD)	5	MGL	931

Reaction No. 40860							
NTetrHyPyran2MeIDA-2 + Li+1 = Li+1_NTetrHyPyran2MeIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:1.7 (0.1SD)	6	MGL	931


Reaction No. 41341							
[15]O5 + Li+1 = Li+1_[15]O5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:1.0 (2SF)	3	ENS	3560
2	25	0.05	Acetone Et4NC1O4	lgK:3.42 (0.04SD)	5	MPT	4399
3	25	0.1	Acetone Unknown	lgK:3.42 (0.04SD)	6	CIU	13297
4	25	0.05	Acetone Et4NC1O4	dH:-12.9 (0.5SD) kJ	5	MCL	4399
5	25	0.1	Acetone Unknown	dH:-12.9 (0.5SD) kJ	6	CIU	13297
6	25	0.1	MeCN Many Media	lgK:4.3 (0.2SD)	7	CIU	13297
7	25		MeCN	lgK:3.60 (3SF)	3	MCN	4820
8	25	0.1	Methanol Many Media	lgK:1.24 (0.05SD)	8	CIU	13297
9	25	0.1	Methanol:Water 70:30Wgt Unknown	lgK:1.02 (0.05SD)	6	CIU	13297
10	25	0.1	PrCarbonate Many Media	lgK:4.14 (0.09SD)	7	CIU	13297
11	25	0.1	PrCarbonate Many Media	dH:-21. (1. SD) kJ	8	CIU	13297

Reaction No. 41344							
[15]N2O3 + Li+1 = Li+1_[15]N2O3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Acetone Et4NC1O4	lgK:3.13 (0.02SD)	5	MAG	4399
2	25	0.05	Acetone Et4NC1O4	dH:-9.1 (0.3SD) kJ	5	MCL	4399

Reaction No. 41346							
[18]O6 + Li+1 = Li+1_[18]O6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0.05	Acetone Et4NC1O4	lgK:2.41(0.05SD)	5	MPT	4399
2	25	0.05	Acetone Et4NC1O4	dH:-19.8(0.4SD)kJ	5	MCL	4399
3	25	0.1	MeCN Many Media	lgK:2.32(0.05SD)	8	CIU	13297
4	25		MeCN	lgK:3.73(3SF)	3	MCN	4820
5	25	0.1	PrCarbonate Many Media	lgK:2.74(0.05SD)	8	CIU	13297
6	25	0.1	PrCarbonate Many Media	dH:-17.(1.SD)	6	CIU	13297

Reaction No. 42198




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:1.8(2SF)	5	MGL	2600
2	25		Methanol	dH:8.2(2SF)kJ	4	MCL	2600

Reaction No. 42392




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	lgK:1.0(2SF)	1	EES	

Reaction No. 43421



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	2	NH4NO3	lgK:-0.3(1SF)	4	MGL	140
2	25	0	Inf. Dilution	lgK:-0.3(4SF)	1	EOR	
3	25	0	Inf. Dilution	lgK:-0.3(3SF)	2	EAE	

Reaction No. 43917



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.13(3SF)	4	MDS	906
2	25			lgK:2.2(2SF)	3	MSC	906
3	30	0	Inf. Dilution	lgK:1.11(3SF)	4	MCN	1926
4	30		Propan-2-ol	lgK:2.72(3SF)	4	MCN	1926

Reaction No. 45247

Li+1 + H+1_CDTA-4 = H+1_Li+1_CDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Unknown	lgK:1.1(0.03SD)	4	MPM	906

Reaction No. 45619							
[18]O6:[Hex]*2 + Li+1 = Li+1_[18]O6:[Hex]*2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:0.6(0.3SD)	4	MIS	6509

Reaction No. 45777							
2<[12]O4> + Li+1 = Li+1_[12]O4(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:2.73(3SF)	5	MCN	2251
2	25		Methanol	dH:0.0(1SF)kJ	4	MCL	2251

Reaction No. 45876							
[2.2.2]crypt:56Benz + Li+1 = Li+1_[2.2.2]crypt:56Benz							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.02	Methanol Et4NC1O4	lgK:2.2(0.05SD)	5	MPT	4821

Reaction No. 45882							
Li+1_24DiNitrphenol-1 + TriEtOlAm = Li+1_TriEtOlAm_24DiNitrphenol-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		THF	lgK:4.699(4SF)	5	MCN	4832

Reaction No. 45928							
EtMalon-2 + Li+1 = Li+1_EtMalon-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:0.813(3SF)	4	MCO	4861
2	25	0	Inf. Dilution	lgK:0.857(3SF)	4	MCO	4861
3	30	0	Inf. Dilution	lgK:0.869(3SF)	4	MCO	4861
4	35	0	Inf. Dilution	lgK:0.913(3SF)	4	MCO	4861
5	25	0	Inf. Dilution	dH:-8.(4.SD)kJ	4	MCO	4861

Reaction No. 45930							
BuMalon-2 + Li+1 = Li+1_BuMalon-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	15	0	Inf. Dilution	lgK:0.778 (3SF)	4	MCO	4861
2	25	0	Inf. Dilution	lgK:0.839 (3SF)	4	MCO	4861
3	30	0	Inf. Dilution	lgK:0.869 (3SF)	4	MCO	4861
4	35	0	Inf. Dilution	lgK:0.919 (3SF)	4	MCO	4861
5	25	0	Inf. Dilution	dH:-12. (3.SD) kJ	4	MCO	4861


Reaction No. 45933							
DiEtMalon-2 + Li+1 = Li+1_DiEtMalon-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:0.934 (3SF)	4	MCO	4861
2	25	0	Inf. Dilution	lgK:0.929 (3SF)	4	MCO	4861
3	25	0	UCT_Sea	lgK:0.93 (0.01SD)	4	EDH	5390
4	25	0.1	UCT_Sea	lgK:0.55 (0.01SD)	4	EDH	5390
5	25	0.2	UCT_Sea	lgK:0.48 (0.01SD)	4	EDH	5390
6	25	0.3	UCT_Sea	lgK:0.44 (0.01SD)	4	EDH	5390
7	25	0.4	UCT_Sea	lgK:0.41 (0.01SD)	4	EDH	5390
8	25	0.5	UCT_Sea	lgK:0.39 (0.01SD)	4	EDH	5390
9	25	0.6	UCT_Sea	lgK:0.38 (0.01SD)	4	EDH	5390
10	25	0.7	UCT_Sea	lgK:0.37 (0.01SD)	4	EDH	5390
11	30	0	Inf. Dilution	lgK:0.996 (3SF)	4	MCO	4861
12	35	0	Inf. Dilution	lgK:1.041 (4SF)	4	MCO	4861
13	25	0	Inf. Dilution	dH:-10.7 (3SF) kJ	4	MCO	4861

Reaction No. 45937							
Di2PrMalon-2 + Li+1 = Li+1_Di2PrMalon-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:0.833 (3SF)	4	MCO	4861
2	25	0	Inf. Dilution	lgK:0.944 (3SF)	4	MCO	4861
3	30	0	Inf. Dilution	lgK:0.977 (3SF)	4	MCO	4861
4	35	0	Inf. Dilution	lgK:0.959 (3SF)	4	MCO	4861
5	25	0	Inf. Dilution	dH:-11. (4.SD) kJ	4	MCO	4861

Reaction No. 46367							
[2.2.2]crypt:DiLactam + Li+1 = Li+1_[2.2.2]crypt:DiLactam							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	33		MeCN	lgK:3.2 (0.07SD)	4	MMR	4782
2	33		MeCN	lgK:3.1 (0.1SD)	4	MMR	4782


3	33		Nitromethane	lgK:4.(1SF)	3	MMR	4782
4	33		Pyridine	lgK:2.6(0.1SD)	4	MMR	4782
5	33		THF	lgK:3.1(0.09SD)	4	MMR	4782

Reaction No. 52339




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:-0.11(0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:-0.40(0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:-0.43(0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:-0.45(0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:-0.46(0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:-0.47(0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:-0.47(0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:-0.38(0.01SD)	4	EDH	5390

Reaction No. 52340



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:0.09(0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:-0.11(0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:-0.14(0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:-0.15(0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:-0.20(0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:-0.18(0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:-0.18(0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:-0.18(0.01SD)	4	EDH	5390

Reaction No. 52761



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Acetone	lgK:2.16(3SF)	5	MCN	5398
2	0		DMF	lgK:-0.26(2SF)	4	MKN	931
3	25		Dioxan:Water 40:60Wgt	lgK:-0.82(2SF)	4	MCN	931
4	25		Dioxan:Water 60:40Wgt	lgK:0.40(2SF)	4	MCN	931


5	25		Dioxan:Water 70:30Wgt	lgK:1.38 (3SF)	4	MCN	931
6	25		Dioxan:Water 80:20Wgt	lgK:2.28 (3SF)	4	MCN	931
7	25		Dioxan:Water 87:13Wgt	lgK:2.82 (3SF)	4	MCN	931
8	25		Dioxan:Water 91:9Wgt	lgK:3.85 (3SF)	4	MCN	931
9	25		Dioxan:Water 95:5Wgt	lgK:4.50 (3SF)	4	MCN	931
10	25		HMPT	lgK:0.48 (2SF)	5	MCN	5398
11	25		HMPT	lgK:1.11 (3SF)	5	MCN	5398
12	25		HMPT	lgK:0.91 (2SF)	4	MCN	5756

Note (12): Using Fuoss-Hia equ; other fits also given

Reaction No. 52844							
Li+1 + Br-1 = Li+1_Br-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1. (1SF)	1	EES	
2	25			lgK:3.62 (3SF)	3	MCN	5398
3	30		Acetic acid	lgK:6.14 (3SF)	4	MCN	140
4	25		Acetone	lgK:2.80 (3SF)	4	MCN	931
5	25		Acetone	lgK:3.66 (3SF)	5	MCN	5398
6	25		Acetone	lgK:3.63 (3SF)	5	MKN	5398
7	25		Acetone	lgK:3.67 (3SF)	5	MKN	5398
8	30		Acetone	lgK:2.77 (3SF)	4	MCN	931
9	35		Acetone	lgK:2.85 (3SF)	4	MCN	931
10	40		Acetone	lgK:2.90 (3SF)	4	MCN	931
11	0		DMF	lgK:0.41 (2SF)	4	MKN	931
12	25		Dioxan:Water 50:50Wgt	lgK:1.11 (3SF)	5	MCN	5398
13	50		Dioxan:Water 50:50Wgt	lgK:1.63 (3SF)	5	MCN	5398
14	25		Dioxan:Water 70:30Wgt	lgK:1.78 (3SF)	5	MCN	5398
15	50		Dioxan:Water 70:30Wgt	lgK:3.34 (3SF)	5	MCN	5398
16	25		Dioxan:Water 77.5:22.5Wgt	lgK:3.08 (3SF)	5	MCN	5398
17	50		Dioxan:Water 77.5:22.5Wgt	lgK:4.76 (3SF)	5	MCN	5398


18	25		HMPT	lgK:0.76 (2SF)	4	MCN	5398
19	25		HMPT	lgK:1.13 (3SF)	4	MCN	5398
20	25		HMPT	lgK:0.98 (2SF)	4	MCN	5756
Note (20): Using Fuoss-Hia equ; other fits also given							
21	25		Methanol	lgK:1.19 (3SF)	4	MKN	931
22	25		Methanol:DMSO .01:.99Wgt	lgK:3.54 (3SF)	5	MCN	5398
23	25		Methanol:DMSO .3:.7Wgt	lgK:3.42 (3SF)	5	MCN	5398
24	25		Methanol:DMSO 1:99Wgt	lgK:3.19 (3SF)	5	MCN	5398
25	25		Methanol:DMSO 10:90Wgt	lgK:2.50 (3SF)	5	MCN	5398
26	25		Methanol:DMSO 2:88Wgt	lgK:3.03 (3SF)	5	MCN	5398
27	25		Methanol:DMSO 20:80Wgt	lgK:2.02 (3SF)	5	MCN	5398
28	25		Methanol:DMSO 5:95Wgt	lgK:2.78 (3SF)	5	MCN	5398
29	25		Methanol:DMSO 50:50Wgt	lgK:0.79 (2SF)	5	MCN	5398
30	25	0	PrCarbonate Inf. Dilution	lgK:1.28 (3SF)	5	MCN	5398
31	25		PrCarbonate	lgK:0.40 (2SF)	5	MEF	5398

Reaction No. 53037



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37.5		Acetic acid	lgK:-1.0 (2SF)	4	MVP	5398

Reaction No. 53412



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.1 (2SF)	4	MGL	140
2	25	1	Me4NCl	lgK:2.39 (3SF)	3	MGL	8315
3	40	0	Inf. Dilution	lgK:3.3 (2SF)	4	MGL	140
4	5	1	Me4NNO3	dH:0.32 (2SF)	4	MCL	5398
5	25	0	Inf. Dilution	dH:0.6 (1SF)	4	CRV	552
6	35	0	Inf. Dilution	dH:1.03 (3SF)	3	MCL	5398

Reaction No. 53414							
Li+1 + H+1_P2O7-4 = H+1_Li+1_P2O7-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NCl	lgK:1.03 (3SF)	5	MGL	140
2	35	0	Inf. Dilution	dH:0.29 (2SF)	4	MCL	5398
3	35	1	Me4NNO3	dH:-0.21 (2SF)	4	MCL	5398

Reaction No. 53617							
NO3-1 + Li+1 = Li+1_NO3-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18	0	Inf. Dilution	lgK:-0.7 (1SF)	3	MCN	140
2	23			lgK:-0.6 (1SF)	0	MRM	5398
3	25	0	Inf. Dilution	lgK:-1.14 (3SF)	2	EAE	
4	25			lgK:-1.63 (3SF)	0	EES	5398
5	30	0	Inf. Dilution	lgK:-1.45 (3SF)	4	MSP	140
6	30			lgK:0.43 (2SF)	0	EES	5398
7	25		Dioxan:Water 71.9:28.1Wgt	lgK:1.59 (3SF)	4	MCN	5398
8	25		Dioxan:Water 74.6:25.4Wgt	lgK:2.12 (3SF)	4	MCN	5398
9	25		Dioxan:Water 75.9:24.1Wgt	lgK:2.43 (3SF)	4	MCN	5398
10	25		Dioxan:Water 77.8:22.2Wgt	lgK:2.76 (3SF)	4	MCN	5398
11	25		Ethanol	lgK:1.28 (3SF)	4	MCN	140
12	25		HMPT	lgK:1.08 (3SF)	4	MCN	5756
Note (12): Using Fuoss-Hia equ; other fits also given							
13	25		MeCN	lgK:3.39 (3SF)	4	MCN	140
14	25		MeCN	lgK:3.35 (3SF)	4	MCN	5398
15	23	0.5	Propan-2-ol:Water 90:10Wgt Unknown	lgK:-0.54 (2SF)	5	MCE	931
16	25		Pyridine	lgK:0.91 (2SF)	4	MHY	931
17	25		THF	lgK:9.77 (3SF)	4	MCN	5398

Reaction No. 53808							
NO2-1 + Li+1 = Li+1_NO2-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.04 (1SF)	4	MCN	931

Reaction No. 53984							
Li+1 + H+1_P4O13-6 = H+1_Li+1_P4O13-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NC1	lgK:1.59 (3SF)	4	MGL	931

Reaction No. 54019							
SO4-2 + Li+1 = Li+1_SO4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18	0	Inf. Dilution	lgK:0.64 (2SF)	3	MCN	140
2	18	0	Inf. Dilution	lgK:0.640 (3SF)	3	MCN	11989
3	18	0.01:1	Unknown	lgK:0.6 (0.05SD)	0	MCN	5583
4	25	0	Inf. Dilution	lgK:0.6 (0.1SD)	3	CRV	552
5	25	0	Inf. Dilution	lgK:0.7 (1SF)	3	MAC	931
6	25	0	Inf. Dilution	lgK:0.64 (2SF)	4	ENS	6496
7	25	0	Inf. Dilution	lgK:0.77 (0.05SD)	4	CMN	7391
8	25	0	Inf. Dilution	lgK:0.38 (2SF)	2	EMS	12547
9	25	0	UCT_Sea	lgK:0.77 (0.01SD)	4	EDH	5390
10	25	0.1	UCT_Sea	lgK:0.34 (0.01SD)	4	EDH	5390
11	25	0.1	Unknown	lgK:0.8 (0.05SD)	5	MAC	5583
12	25	0.2	UCT_Sea	lgK:0.24 (0.01SD)	4	EDH	5390
13	25	0.3	UCT_Sea	lgK:0.18 (0.01SD)	4	EDH	5390
14	25	0.4	UCT_Sea	lgK:0.14 (0.01SD)	4	EDH	5390
15	25	0.5	UCT_Sea	lgK:0.11 (0.01SD)	4	EDH	5390
16	25	0.6	UCT_Sea	lgK:0.09 (0.01SD)	4	EDH	5390
17	25	0.7	UCT_Sea	lgK:0.07 (0.01SD)	4	EDH	5390
18	25	0.7	Unknown	lgK:0.26 (0.05SD)	3	EES	7391
19	25	4.8	Unknown	lgK:0.6 (0.05SD)	4	ENS	5490
20	37	0.15	Unknown	lgK:0.8 (0.1SD)	4	CRV	552
21	25			dH:0.0 (1SF)	0	MCL	140

Reaction No. 54276							
ClO3-1 + Li+1 = Li+1_ClO3-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.2 (2SF)	3	CRV	552
2	25		Dioxan:Water 64.5:35.5Wgt	lgK:1.42 (3SF)	4	MCN	931

3	25		Dioxan:Water 90:10Wgt	lgK:6.42 (3SF)	4	MCN	931
---	----	--	--------------------------	----------------	---	-----	-----

Reaction No. 54607							
Li+1 + B(OH)4-1 = Li+1_B(OH)4-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	P=57.6 Inf. Dilution	lgK:0.338 (0.197SD)	4	MCN	29937
2	25.1	0	P=195.2 Inf. Dilution	lgK:0.364 (0.131SD)	4	MCN	29937
3	175	0	P=201.1 Inf. Dilution	lgK:0.57 (0.17SD)	4	MCN	29937
4	250	0	P=203.1 Inf. Dilution	lgK:0.70 (0.23SD)	4	MCN	29937
5	275.1	0	P=203.1 Inf. Dilution	lgK:1.23 (0.08SD)	4	MCN	29937
6	5	0	Inf. Dilution	lgK:1.036 (4SF)	4	MPK	9162
7	15	0	Inf. Dilution	lgK:1.038 (4SF)	4	MPK	9162
8	25	0	Inf. Dilution	lgK:1.026 (4SF)	1	EOR	
9	25	0	Inf. Dilution	lgK:1.043 (4SF)	4	MPK	9162
10	25	0	UCT_Sea	lgK:0.55 (0.01SD)	0	EDH	5390
11	25	0.1	UCT_Sea	lgK:0.29 (0.01SD)	0	EDH	5390
12	25	0.2	UCT_Sea	lgK:0.21 (0.01SD)	0	EDH	5390
13	25	0.3	UCT_Sea	lgK:0.14 (0.01SD)	0	EDH	5390
14	25	0.4	UCT_Sea	lgK:0.09 (0.01SD)	3	EDH	5390
15	25	0.5	UCT_Sea	lgK:0.04 (0.01SD)	3	EDH	5390
16	25	0.6	UCT_Sea	lgK:-0.01 (0.01SD)	3	EDH	5390
17	25	0.7	NaCl	lgK:-0.05 (0.03SD)	5	MPS	769
18	25	0.7	UCT_Sea	lgK:-0.05 (0.01SD)	3	EDH	5390
19	35	0	Inf. Dilution	lgK:1.046 (4SF)	4	MPK	9162
20	45	0	Inf. Dilution	lgK:1.053 (4SF)	4	MPK	9162
21	5	0	Inf. Dilution	dH:0.26 (2SF) kJ	4	MTD	9162
22	15	0	Inf. Dilution	dH:0.49 (2SF) kJ	4	MTD	9162
23	25	0	Inf. Dilution	dH:0.73 (2SF) kJ	4	MTD	9162
24	35	0	Inf. Dilution	dH:0.97 (2SF) kJ	4	MTD	9162
25	45	0	Inf. Dilution	dH:1.22 (3SF) kJ	4	MTD	9162

Reaction No. 54632							
Ca(s) + 1.5<Cl2(g)> + 5<H2(g)> + Li(s) + 2.5<O2(g)> = Ca+2_Li+1_Cl-1(3)_H2O(5)_(s)							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2365.4 (5SF) kJ	3	EOD	12955
Note (1): From Wagman							

Reaction No. 54862							
$2\text{Li}^{+1} + \text{CrO}_4^{-2} = \text{Li}^{+1}(2)\text{CrO}_4^{-2}(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-4.9 (0.05SD)	4	ENS	766
2	25	0	Inf. Dilution	dH:10.8 (0.1SD)	4	ENS	766

Reaction No. 55095							
$2\text{Li}(\text{s}) + \text{Mo}(\text{s}) + 2\text{O}_2(\text{g}) = \text{Li}^{+1}(2)\text{MoO}_4^{-2}(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-336.9 (0.05SD)	4	ENS	802
2	25	0	Inf. Dilution	dH:-363.4 (0.1SD)	4	ENS	802

Reaction No. 55326							
$\text{Li}^{+1} + \text{H}^{+1}\text{V}_{10028-6} = \text{H}^{+1}\text{Li}^{+1}\text{V}_{10028-6}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Me4N+ salt	lgK:0.6 (0.05SD)	5	MGL	140
2	25	0	Inf. Dilution	lgK:1.63 (3SF)	2	EAE	

Reaction No. 55327							
$\text{Li}^{+1} + \text{Li}^{+1}\text{V}_{10028-6} = \text{Li}^{+1}(2)\text{V}_{10028-6}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Me4N+ salt	lgK:0.6 (0.05SD)	5	MGL	140
2	25	0	Inf. Dilution	lgK:1.63 (3SF)	2	EAE	

Reaction No. 55329							
$\text{Li}^{+1} + \text{OH}^{-1} = \text{Li}^{+1}\text{OH}^{-1}$							
Note: See comments on moh/m.oh for Na+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0	Inf. Dilution	lgK:0.26 (2SF)	3	MHY	5078
2	15	0	Inf. Dilution	lgK:0.19 (2SF)	3	MHY	5078
3	15	0	Inf. Dilution	lgK:-0.678 (3SF)	0	MCN	14257
4	25	0	Inf. Dilution	lgK:0.36 (2SF)	4	CRV	2556
5	25	0	Inf. Dilution	lgK:0.18 (0.05SD)	4	MHY	5078

Note (5): Table 6, p. 970							
6	25	0	Inf. Dilution	lgK:0.24 (2SF)	2	EMS	12547
7	25	0	Inf. Dilution	lgK:-0.013 (2SF)	4	MCN	14257
8	25	3	Unknown	lgK:-0.18 (2SF)	5	CRV	2556
9	35	0	Inf. Dilution	lgK:0.20 (2SF)	3	MHY	5078
10	45	0	Inf. Dilution	lgK:0.19 (2SF)	3	MHY	5078
11	45	0	Inf. Dilution	lgK:0.299 (3SF)	5	MCN	14257
12	10:40	0	Inf. Dilution	dH:0.0 (1SF)	4	CRV	2556

Reaction No. 55636							
Li+1 + V10028-6 = Li+1_V10028-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Me4N+ salt	lgK:1.6 (0.05SD)	5	MGL	140
2	25	0	Inf. Dilution	lgK:2.84 (3SF)	2	EAE	

Reaction No. 57225							
Li+1 + P308-5 = Li+1_P308-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NC1	lgK:4.26 (0.02MD)w	5	MPH	4607


Reaction No. 57226							
Li+1 + H+1 + P308-5 = H+1_Li+1_P308-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NC1	lgK:12.15 (0.04MD)w	5	MPH	4607

Reaction No. 57388							
PO4-3 + Li+1 = Li+1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	Unknown	lgK:0.7 (0.04SD)	6	ENS	3560
2	37	0.15	Me4N+ salt	lgK:0.95 (2SF)	5	CRV	2556

Reaction No. 57390							
P3O10-5 + Li+1 = Li+1_P3O10-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.9 (2SF)	4	MGL	140
2	25	1	Me4NC1	lgK:2.71 (3SF)	5	MGL	140
3	25	1	Me4NC1	lgK:2.87 (3SF)	5	MGL	140


4	40	0	Inf. Dilution	lgK:3.8 (2SF)	4	MGL	140
---	----	---	---------------	---------------	---	-----	-----

Reaction No. 57391



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Unknown	lgK:2.6 (0.06SD)	4	ENS	3560

Reaction No. 58166



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	P=136.1 Unknown/m	lgK:0.32 (2SF)	5	MSP	6571
2	25	1	P=408.3 Unknown/m	lgK:0.29 (2SF)	5	MSP	6571
3	25	1	P=680.5 Unknown/m	lgK:0.26 (2SF)	5	MSP	6571
4	25	1	P=952.6 Unknown/m	lgK:0.23 (2SF)	5	MSP	6571
5	25	1	P=1225 Unknown/m	lgK:0.19 (2SF)	5	MSP	6571
6	25	1	P=1497 Unknown/m	lgK:0.16 (2SF)	5	MSP	6571
7	25	1	P=1769 Unknown/m	lgK:0.12 (2SF)	5	MSP	6571
8	25	1	P=2041 Unknown/m	lgK:0.08 (1SF)	5	MSP	6571
9	15	1	NaClO4	lgK:-0.17 (0.08SD)	5	MIS	431
10	25	0	Inf. Dilution	lgK:0.23 (2SF)	5	MIS	431
11	25	0	Inf. Dilution	lgK:0.23 (2SF)	4	CRV	552
12	25	0	Inf. Dilution	lgK:0.41 (2SF)	4	MCN	16235
13	25	0	UCT_Sea	lgK:0.23 (0.01SD)	0	EDH	5390
14	25	0.02	NaClO4	lgK:0.13 (0.07SD)	5	MIS	431
15	25	0.05	NaClO4	lgK:0.05 (0.26SD)	5	MIS	431
16	25	0.1	NaClO4	lgK:0.03 (0.03SD)	5	MIS	431
17	25	0.1	UCT_Sea	lgK:0.03 (0.01SD)	0	EDH	5390
18	25	0.2	NaClO4	lgK:-0.2 (1SF)	5	MIS	431
19	25	0.2	UCT_Sea	lgK:-0.05 (0.01SD)	0	EDH	5390
20	25	0.3	UCT_Sea	lgK:0.11 (0.01SD)	0	EDH	5390
21	25	0.4	UCT_Sea	lgK:0.0 (0.01SD)	0	EDH	5390
22	25	0.5	NaClO4	lgK:-0.20 (2SF)	5	MIS	431

23	25	0.5	UCT_Sea	lgK:-0.18 (0.01SD)	0	EDH	5390
24	25	0.6	UCT_Sea	lgK:-0.17 (0.01SD)	0	EDH	5390
25	25	0.7	UCT_Sea	lgK:-0.15 (0.01SD)	0	EDH	5390
26	25	1	CsNO3	lgK:0.068 (2SF)	5	MIS	431
27	25	1	KNO3	lgK:-0.03 (1SF)	5	MIS	432
28	25	1	NaClO4	lgK:-0.12 (0.05SD)	5	MIS	431
29	25	1	NaClO4	lgK:-0.125 (3SF)	5	MIS	432
30	25	1	NaNO3	lgK:-0.24 (2SF)	3	MIS	432
31	25	1	RbNO3	lgK:0.009 (0.04SD)	5	MIS	431
32	25	1	Unknown	lgK:0.07 (1SF)	5	CRV	2556
33	25	1	Unknown/m	lgK:0.34 (2SF)	5	MSP	6571
34	35	1	NaClO4	lgK:-0.96 (0.05SD)	0	MIS	431
35	10:40	1	Unknown	dH:1. (1SF)	5	CRV	2556

Reaction No. 58304							
Li+1(3)_PO4-3_(s) = 3<Li+1> + PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-8.49 (3SF)	1	CRV	
Note (1): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
2	25	0	Inf. Dilution	lgK:-12.5 (3SF)	0	ENS	5648

Reaction No. 58410							
Li+1 + H+1_PO4-3 = H+1_Li+1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.2	Pr4NC1	lgK:0.32 (2SF)	0	MGL	140
2	25	0.1	Me4N+ salt	lgK:0.64 (2SF)	5	CRV	2556
3	25	0.2	Pr4NC1	lgK:0.72 (2SF)	4	MGL	140
4	37	0.15	Me4N+ salt	lgK:0.79 (2SF)	5	CRV	2556
5	0:30	0.1	Me4N+ salt	dH:6. (1SF)	6	CRV	552
6	25	0.2	Pr4NC1	dH:6. (1SF)	3	MTD	140

Reaction No. 58442							
Li+1 + H+1_P3O10-5 = H+1_Li+1_P3O10-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4N+ salt	lgK:1.7 (0.2SD)	6	CRV	552
2	25	1	Me4NC1	lgK:0.88 (2SF)	3	MGL	140
3	25	1	Me4NC1	lgK:1.55 (3SF)	4	MGL	140

Reaction No. 58746							
$2\text{Li} + \text{LiClO}_4 = \text{Li}_2\text{ClO}_4$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	16		Acetic acid	lgK:0.89 (2SF)	3	MFP	140

Reaction No. 58768							
$2\text{Li} + \text{LiBr} = \text{Li}_2\text{Br}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	16		Acetic acid	lgK:0.66 (2SF)	3	MFP	140

Reaction No. 58801							
$\text{BrO}_3^- + \text{Li} = \text{LiBrO}_3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.5 (1SF)	4	CRV	552
2	25	0.15	LiClO ₄	lgR:-0.77 (2SF)	4	MSL	140
3	25	0.2	LiClO ₄	lgR:-0.82 (2SF)	4	MSL	140

Reaction No. 58848							
$[\text{Li}]\text{N}_2\text{O}_3:\text{MeCOO}^*_{2-2} + \text{Li} = \text{Li}[\text{Li}]\text{N}_2\text{O}_3:\text{MeCOO}^*_{2-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me ₄ NNO ₃	lgK:2.14 (0.007SD)	5	MGL	1176

Reaction No. 58861							
$\text{Li} + \text{H}[\text{Li}]\text{N}_2\text{O}_3:\text{MeCOO}^*_{2-2} = \text{H}[\text{Li}]\text{Li}[\text{Li}]\text{N}_2\text{O}_3:\text{MeCOO}^*_{2-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me ₄ NNO ₃	lgK:1.15 (3SF)	5	MGL	1176

Reaction No. 59028							
$[\text{Li}]\text{N}_2\text{O}_4:[2.2]\text{Anthraquinone} + \text{Li} = \text{Li}[\text{Li}]\text{N}_2\text{O}_4:[2.2]\text{Anthraquinone}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	21	0.05	MeCN Unknown	lgK:5. (0.3SD)	5	MMR	5969

Reaction No. 59029							
$\text{Li}[\text{Li}]\text{N}_2\text{O}_4:[2.2]\text{Anthraquinone} + \text{Li} = \text{Li}_2[\text{Li}]\text{N}_2\text{O}_4:[2.2]\text{Anthraquinone}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	21	0.05	MeCN Unknown	lgK:2.2 (0.1SD)	5	MMR	5969

Reaction No. 59462							
Glycolic-1 + Li+1 = Li+1_Glycolic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:-0.11 (2SF)	3	ENS	3560

Reaction No. 59637							
2<5ATP-4> + Li+1 = Li+1_5ATP-4 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.25	Pr4N+ salt	lgK:1.35 (0.08SD)	5	MGL	3595
2	10:45	0.25	Pr4N+ salt	dH:11. (5.SD) kJ	4	MTD	3595

Reaction No. 59638							
H+1 + 5ATP-4 + Li+1 = H+1_Li+1_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.25	Pr4N+ salt	lgK:6.79 (0.05SD)	5	MGL	3595
2	10:45	0.25	Pr4N+ salt	dH:7. (4.SD) kJ	4	MTD	3595

Reaction No. 59649							
Li+1_5ATP-4 + Li+1 = Li+1 (2)_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:3.0 (2SF)	1	ESC	
2	10:45	0.25	Pr4N+ salt	dH:3.3 (2SF)	4	MTD	1437

Reaction No. 60167							
Li+1_EDTA-4 + Li+1 = Li+1 (2)_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.8 (1SF)	1	EOR	
2	25	0.32	CsCl	lgK:0.83 (2SF)	2	MGL	903

Reaction No. 60634							
Li+1 + H+1 (2)_PO4-3 = H+1 (2)_Li+1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.506 (3SF)	2	EAE	
2	37	0.5	Me4N+ salt	lgK:0.2 (1SF)	3	CRV	2556

Reaction No. 60663							
Li+1_F-1_(s) = Li+1 + F-1							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.42 (3SF)	1	CRV	
Note (1): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
2	25	0	Inf. Dilution	lgK:-2.77 (3SF)	4	CRV	2556
3	25	0	Inf. Dilution	dH:1.1 (2SF)	4	CRV	2556
4	25	0	Inf. Dilution	dH:1.070 (0.005SD)	5	MCL	31224

Reaction No. 65669							
$\text{Li}+1 + \text{B}(\text{OH})_3 = \text{Li}+1_B(\text{OH})_3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.34 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:0.34 (2SF)	4	CRV	552
3	25	0.7	Unknown	lgK:-0.05 (1SF)	6	CRV	552

Reaction No. 65875							
$\text{P4O}_{12}-4 + \text{Li}+1 = \text{Li}+1_P4O_{12}-4$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.27 (3SF)	4	CRV	552


Reaction No. 65891							
$\text{P6O}_{18}-6 + \text{Li}+1 = \text{Li}+1_P6O_{18}-6$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.11 (3SF)	4	CRV	552

Reaction No. 65933							
$\text{Li}+1(2)_SeO_4-2(s) = 2<\text{Li}+1> + SeO_4-2$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.05 (3SF)	4	CRV	552
2	25	0	Inf. Dilution	dG:-3.63 (3SF)	4	ENS	12931

Reaction No. 66932							
$3<\text{Li}(s)> + \text{Al}(s) + 3<\text{F}_2(g)> = \text{Al}+3_Li+1(3)_F-1(6)_(s)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:564.8 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:561.1 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:413.9 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:325.5 (4SF)	4	ENS	6422


5	327	0	Inf. Dilution	lgK:266.5 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-770.5 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-808.7 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-808.3 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-809.9 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-809.0 (4SF)	4	MTD	6422

Reaction No. 66933



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:279.4 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:277.6 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:203.5 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:159.0 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:129.2 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-381.2 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-406.9 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-406.7 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-408.8 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-408.6 (4SF)	4	MTD	6422

Reaction No. 66934



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:168.7 (4SF)	3	ENS	6422
2	27	0	Inf. Dilution	lgK:167.6 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:123.3 (4SF)	3	ENS	6422
4	227	0	Inf. Dilution	lgK:96.59 (4SF)	3	ENS	6422
5	327	0	Inf. Dilution	lgK:78.78 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-976.1 (4SF) kJ	3	CRV	6330
7	25	0	Inf. Dilution	dG:-230.2 (4SF)	3	EFE	6422
8	25	0	Inf. Dilution	dH:-1032.2 (5SF) kJ	3	CRV	6330
9	25	0	Inf. Dilution	dH:-243.6 (4SF)	3	MTD	6422
10	127	0	Inf. Dilution	dH:-243.7 (4SF)	3	MTD	6422
11	227	0	Inf. Dilution	dH:-244.4 (4SF)	3	MTD	6422
12	327	0	Inf. Dilution	dH:-244.4 (4SF)	0	MTD	6422


Reaction No. 66935							
$\text{Li(s)} + \text{Be(s)} + 1.5\text{F}_2(\text{g}) = \text{Be}_2\text{Li}_3\text{F}_3(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:276.2(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:274.4(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:202.5(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:159.3(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:130.6(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-376.7(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-394.8(4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-394.7(4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-395.1(4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-394.7(4SF)	4	MTD	6422

Reaction No. 66936							
$2\text{Li(s)} + \text{Be(s)} + 2\text{F}_2(\text{g}) = \text{Be}_2\text{Li}_4\text{F}_4(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:380.4(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:378.0(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:279.0(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:219.6(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:180.0(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-519.0(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-543.4(4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-543.2(4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-544.4(4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-543.9(4SF)	4	MTD	6422

Reaction No. 66937							
$0.5\text{Br}_2(\text{l}) + \text{Li(s)} = \text{LiBr(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:59.85(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:59.47(4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:43.80(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:34.22(4SF)	3	ENS	6422
5	327	0	Inf. Dilution	lgK:27.81(4SF)	0	ENS	6422


6	25	0	Inf. Dilution	dG:-342.0 (4SF) kJ	3	CRV	6330
7	25	0	Inf. Dilution	dG:-81.65 (4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dG:-342.0 (4SF) kJ	4	EOD	29025
9	25	0	Inf. Dilution	dH:-351.2 (4SF) kJ	3	CRV	6330
10	25	0	Inf. Dilution	dH:-83.9 (3SF)	4	MTD	6422
11	25	0	Inf. Dilution	dH:-351.2 (4SF) kJ	4	EOD	29025
12	127	0	Inf. Dilution	dH:-87.4 (3SF)	4	MTD	6422
13	227	0	Inf. Dilution	dH:-88.0 (3SF)	3	MTD	6422
14	327	0	Inf. Dilution	dH:-87.9 (3SF)	0	MTD	6422

Reaction No. 66938



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:198.3 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:197.0 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:144.1 (4SF)	3	ENS	6422
4	227	0	Inf. Dilution	lgK:112.3 (4SF)	2	ENS	6422
5	327	0	Inf. Dilution	lgK:90.99 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-1132.1 (5SF) kJ	5	CRV	6330
7	25	0	Inf. Dilution	dG:-270.6 (4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dG:-1132.1 (5SF) kJ	4	EOD	29025
9	25	0	Inf. Dilution	dG:-1133.0 (5SF) kJ	4	CRV	31315
10	25	0	Inf. Dilution	dH:-1215.9 (5SF) kJ	5	CRV	6330
11	25	0	Inf. Dilution	dH:-290.6 (4SF)	4	MTD	6422
12	25	0	Inf. Dilution	dH:-1215.9 (5SF) kJ	4	EOD	29025
13	25	0	Inf. Dilution	dH:-1216.0 (5SF) kJ	4	CRV	31315
14	127	0	Inf. Dilution	dH:-290.7 (4SF)	2	MTD	6422
15	227	0	Inf. Dilution	dH:-292.1 (4SF)	1	MTD	6422
16	327	0	Inf. Dilution	dH:-291.7 (4SF)	0	MTD	6422
17	25	0	Inf. Dilution	Cp:99.1 (3SF) J/K	4	EOD	29025


Reaction No. 66939



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:67.28 (4SF)	2	ENS	6422
2	27	0	Inf. Dilution	lgK:66.84 (4SF)	0	ENS	6422


3	127	0	Inf. Dilution	lgK:49.08 (4SF)	3	ENS	6422
4	227	0	Inf. Dilution	lgK:38.41 (4SF)	3	ENS	6422
5	327	0	Inf. Dilution	lgK:31.27 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-384.4 (4SF) kJ	3	CRV	6330
7	25	0	Inf. Dilution	dG:-91.78 (4SF)	2	EFE	6422
8	25	0	Inf. Dilution	dG:-384.37 (5SF) kJ	3	ENS	7381
9	25	0	Inf. Dilution	dG:-384.4 (4SF) kJ	4	EOD	29025
10	25	0	Inf. Dilution	dG:-384.37 (5SF) kJ	2	EOD	30015
11	25	0	Inf. Dilution	dH:-408.6 (4SF) kJ	3	CRV	6330
12	25	0	Inf. Dilution	dH:-97.6 (3SF)	3	MTD	6422
13	25	0	Inf. Dilution	dH:-408.61 (5SF) kJ	4	ENS	7381
14	25	0	Inf. Dilution	dH:-408.6 (4SF) kJ	4	EOD	29025
15	25	0	Inf. Dilution	dH:-408.61 (5SF) kJ	2	EOD	30015
16	127	0	Inf. Dilution	dH:-97.4 (3SF)	1	MTD	6422
17	227	0	Inf. Dilution	dH:-98.0 (3SF)	0	MTD	6422
18	327	0	Inf. Dilution	dH:-97.9 (3SF)	0	MTD	6422
19	25	0	Inf. Dilution	Cp:48.0 (3SF) J/K	3	EOD	29025

Reaction No. 66940




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:44.48 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:44.07 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:27.53 (4SF)	3	ENS	6422
4	227	0	Inf. Dilution	lgK:17.62 (4SF)	2	ENS	6422
5	236	0	Inf. Dilution	lgK:16.92 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-60.69 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-381.0 (4SF) kJ	3	CRV	6330
8	25	0	Inf. Dilution	dH:-91.0 (3SF)	4	MTD	6422
9	25	0	Inf. Dilution	dH:-91.11 (4SF)	5	MCL	21773
10	127	0	Inf. Dilution	dH:-90.6 (3SF)	3	MTD	6422
11	227	0	Inf. Dilution	dH:-90.7 (3SF)	2	MTD	6422
12	236	0	Inf. Dilution	dH:-90.6 (3SF)	0	MTD	6422

Reaction No. 66941




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:103.1 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:102.5 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:75.61 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:59.48 (4SF)	2	ENS	6422
5	327	0	Inf. Dilution	lgK:48.69 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-140.7 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dG:-587.71 (5SF) kJ	4	ENS	7381
8	25	0	Inf. Dilution	dG:-587.71 (5SF) kJ	2	EOD	30015
9	25	0	Inf. Dilution	dH:-147.5 (4SF)	4	MTD	6422
10	25	0	Inf. Dilution	dH:-615.97 (5SF) kJ	4	ENS	7381
11	25	0	Inf. Dilution	dH:-615.97 (5SF) kJ	2	EOD	30015
12	127	0	Inf. Dilution	dH:-147.4 (4SF)	1	MTD	6422
13	227	0	Inf. Dilution	dH:-148.0 (4SF)	0	MTD	6422
14	327	0	Inf. Dilution	dH:-148.0 (4SF)	0	MTD	6422

Reaction No. 66942



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.99 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:11.89 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:7.929 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:5.498 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:3.839 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-16.36 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dG:-68.35 (4SF) kJ	4	ENS	7381
8	25	0	Inf. Dilution	dH:-21.7 (3SF)	4	MTD	6422
9	25	0	Inf. Dilution	dH:-90.54 (4SF) kJ	4	ENS	7381
10	127	0	Inf. Dilution	dH:-21.9 (3SF)	4	MTD	6422
11	227	0	Inf. Dilution	dH:-21.7 (3SF)	4	MTD	6422
12	327	0	Inf. Dilution	dH:-22.8 (3SF)	4	MTD	6422

Reaction No. 66943



Note: Doubtful phase - unhydrated

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:47.24 (4SF)	2	ENS	6422
2	27	0	Inf. Dilution	lgK:46.95 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:35.16 (4SF)	1	ENS	6422
4	227	0	Inf. Dilution	lgK:27.64 (4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:22.37 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-64.45 (4SF)	2	EFE	6422
7	25	0	Inf. Dilution	dH:-64.5 (3SF)	2	MTD	6422
8	27	0	Inf. Dilution	dH:-64.6 (3SF)	0	MTD	6422
9	127	0	Inf. Dilution	dH:-66.6 (3SF)	1	MTD	6422
10	227	0	Inf. Dilution	dH:-72.4 (3SF)	0	MTD	6422
11	327	0	Inf. Dilution	dH:-72.2 (3SF)	0	MTD	6422

Reaction No. 66944							
3<Li(s)> + 0.5<N2(g)> = Li3N(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.54 (4SF)	3	ENS	6422
2	27	0	Inf. Dilution	lgK:22.36 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:15.17 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:10.74 (4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:7.671 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-30.75 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-39.3 (3SF)	3	MTD	6422
8	127	0	Inf. Dilution	dH:-39.6 (3SF)	2	MTD	6422
9	227	0	Inf. Dilution	dH:-42.0 (3SF)	0	MTD	6422
10	327	0	Inf. Dilution	dH:-42.1 (3SF)	0	MTD	6422

Reaction No. 66945							
2<Li(s)> + 0.5<O2(g)> = Li2O(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:98.48 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:98.31 (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:97.83 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:97.67 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:71.75 (4SF)	2	ENS	6422
6	127	0	Inf. Dilution	lgK:71.63 (4SF)	2	ENS	6494
7	227	0	Inf. Dilution	lgK:56.02 (4SF)	1	ENS	6422

8	227	0	Inf. Dilution	lgK:55.92 (4SF)	1	ENS	6494
9	327	0	Inf. Dilution	lgK:45.47 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:45.38 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-561.2 (4SF) kJ	5	EFE	6330
12	25	0	Inf. Dilution	dG:-134.3 (4SF)	4	EFE	6422
13	25	0	Inf. Dilution	dG:-134.1 (4SF)	4	EFE	6494
14	25	0	Inf. Dilution	dG:-561.18 (5SF) kJ	4	ENS	7381
15	25	0	Inf. Dilution	dG:-134.15 (5SF)	3	CRV	31291
16	25	0	Inf. Dilution	dH:-597.9 (4SF) kJ	5	CRV	6330
17	25	0	Inf. Dilution	dH:-143.1 (4SF)	4	MTD	6422
18	25	0	Inf. Dilution	dH:-142.9 (4SF)	4	MTD	6494
19	25	0	Inf. Dilution	dH:-597.94 (5SF) kJ	4	ENS	7381
20	25	0	Inf. Dilution	dH:-142.90 (5SF)	3	CRV	31291
21	127	0	Inf. Dilution	dH:-143.3 (4SF)	1	MTD	6422
22	127	0	Inf. Dilution	dH:-143.1 (4SF)	1	MTD	6494
23	227	0	Inf. Dilution	dH:-144.9 (4SF)	0	MTD	6422
24	227	0	Inf. Dilution	dH:-144.7 (4SF)	0	MTD	6494
25	327	0	Inf. Dilution	dH:-145.0 (4SF)	0	MTD	6422
26	327	0	Inf. Dilution	dH:-144.8 (4SF)	0	MTD	6494

Reaction No. 66946



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:100.0 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:99.35 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:71.80 (4SF)	2	ENS	6422
4	195	0	Inf. Dilution	lgK:59.76 (4SF)	2	ENS	6422
5	25	0	Inf. Dilution	dG:-136.5 (4SF)	4	EFE	6422
6	25	0	Inf. Dilution	dG:-136.97 (5SF)	3	CRV	31291
7	25	0	Inf. Dilution	dH:-634.3 (4SF) kJ	5	CRV	6330
8	25	0	Inf. Dilution	dH:-151.2 (4SF)	4	MTD	6422
9	25	0	Inf. Dilution	dH:-151.70 (5SF)	3	CRV	31291
10	127	0	Inf. Dilution	dH:-151.3 (4SF)	1	MTD	6422
11	195	0	Inf. Dilution	dH:-152.8 (4SF)	1	MTD	6422

Reaction No. 66947

Li(s) + Al(s) + O2(g) = LiAlO2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:197.3(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:196.0(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:144.3(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:113.2(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:92.43(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-269.2(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-284.1(4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-284.2(4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-285.0(4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-284.9(4SF)	4	MTD	6422

Reaction No. 66948							
Li(s) + Al(s) + Si(s) + 2<O2(g)> = LiAlSiO4(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:352.2(4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:352.0(4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:349.9(4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:349.7(4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:257.4(4SF)	3	ENS	6422
6	127	0	Inf. Dilution	lgK:257.3(4SF)	3	ENS	6494
7	227	0	Inf. Dilution	lgK:201.9(4SF)	2	ENS	6422
8	227	0	Inf. Dilution	lgK:201.8(4SF)	2	ENS	6494
9	327	0	Inf. Dilution	lgK:164.8(4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:164.8(4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-480.4(4SF)	4	EFE	6422
12	25	0	Inf. Dilution	dG:-480.2(4SF)	4	EFE	6494
13	25	0	Inf. Dilution	dH:-507.7(4SF)	4	MTD	6422
14	25	0	Inf. Dilution	dH:-507.5(4SF)	4	MTD	6494
15	127	0	Inf. Dilution	dH:-507.8(4SF)	3	MTD	6422
16	127	0	Inf. Dilution	dH:-507.6(4SF)	3	MTD	6494
17	227	0	Inf. Dilution	dH:-508.4(4SF)	2	MTD	6422
18	227	0	Inf. Dilution	dH:-508.2(4SF)	2	MTD	6494
19	327	0	Inf. Dilution	dH:-508.1(4SF)	0	MTD	6422
20	327	0	Inf. Dilution	dH:-508.0(4SF)	0	MTD	6494

Reaction No. 66949							
Li(s) + Al(s) + 2<Si(s)> + 3<O2(g)> = LiAlSi2O6(alpha,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:504.8(4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:504.6(4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:501.5(4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:501.3(4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:368.5(4SF)	3	ENS	6422
6	127	0	Inf. Dilution	lgK:368.4(4SF)	3	ENS	6494
7	227	0	Inf. Dilution	lgK:288.7(4SF)	2	ENS	6422
8	227	0	Inf. Dilution	lgK:288.6(4SF)	2	ENS	6494
9	327	0	Inf. Dilution	lgK:235.4(4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:235.3(4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-688.7(4SF)	4	EFE	6422
12	25	0	Inf. Dilution	dG:-688.4(4SF)	4	EFE	6494
13	25	0	Inf. Dilution	dH:-730.1(4SF)	3	MTD	6422
14	25	0	Inf. Dilution	dH:-729.8(4SF)	3	MTD	6494
15	127	0	Inf. Dilution	dH:-730.3(4SF)	1	MTD	6422
16	127	0	Inf. Dilution	dH:-730.0(4SF)	1	MTD	6494
17	227	0	Inf. Dilution	dH:-730.9(4SF)	0	MTD	6422
18	227	0	Inf. Dilution	dH:-730.7(4SF)	0	MTD	6494
19	327	0	Inf. Dilution	dH:-730.7(4SF)	0	MTD	6422
20	327	0	Inf. Dilution	dH:-730.5(4SF)	0	MTD	6494

Reaction No. 66950							
Li(s) + Al(s) + 2<Si(s)> + 3<O2(g)> = LiAlSi2O6(beta,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:501.2(4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:501.0(4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:498.0(4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:497.7(4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:366.2(4SF)	3	ENS	6422
6	127	0	Inf. Dilution	lgK:366.0(4SF)	3	ENS	6494
7	227	0	Inf. Dilution	lgK:287.1(4SF)	2	ENS	6422
8	227	0	Inf. Dilution	lgK:286.9(4SF)	2	ENS	6494

9	327	0	Inf. Dilution	lgK:234.4 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:234.2 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-683.8 (4SF)	4	EFE	6422
12	25	0	Inf. Dilution	dG:-683.4 (4SF)	4	EFE	6494
13	25	0	Inf. Dilution	dH:-723.4 (4SF)	3	MTD	6422
14	25	0	Inf. Dilution	dH:-723.1 (4SF)	3	MTD	6494
15	127	0	Inf. Dilution	dH:-723.5 (4SF)	1	MTD	6422
16	127	0	Inf. Dilution	dH:-723.2 (4SF)	1	MTD	6494
17	227	0	Inf. Dilution	dH:-724.0 (4SF)	0	MTD	6422
18	227	0	Inf. Dilution	dH:-723.8 (4SF)	0	MTD	6494
19	327	0	Inf. Dilution	dH:-723.6 (4SF)	0	MTD	6422
20	327	0	Inf. Dilution	dH:-732.4 (4SF)	0	MTD	6494

Reaction No. 66951							
$2\text{Li(s)} + 4\text{B(s)} + 3.5\text{O}_2\text{(g)} = \text{Li}_2\text{B}_4\text{O}_7\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:555.4 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:551.8 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:405.4 (4SF)	3	ENS	6422
4	227	0	Inf. Dilution	lgK:317.4 (4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:258.7 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-757.7 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-803.6 (4SF)	3	MTD	6422
8	127	0	Inf. Dilution	dH:-804.1 (4SF)	1	MTD	6422
9	227	0	Inf. Dilution	dH:-806.1 (4SF)	0	MTD	6422
10	327	0	Inf. Dilution	dH:-806.6 (4SF)	0	MTD	6422

Reaction No. 66952							
$2\text{Li(s)} + 6\text{B(s)} + 5\text{O}_2\text{(g)} = \text{Li}_2\text{B}_6\text{O}_{10}\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:767.8 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:762.8 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:560.0 (4SF)	3	ENS	6422
4	227	0	Inf. Dilution	lgK:438.3 (4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:357.1 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-1047. (4SF)	4	EFE	6422

7	25	0	Inf. Dilution	dH:-1114.(4SF)	3	MTD	6422
8	127	0	Inf. Dilution	dH:-1113.(4SF)	1	MTD	6422
9	227	0	Inf. Dilution	dH:-1114.(4SF)	0	MTD	6422
10	327	0	Inf. Dilution	dH:-1114.(4SF)	0	MTD	6422


Reaction No. 66953							
Li(s) + Fe(s) + O2(g) = LiFeO2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:121.7(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:120.9(4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:88.25(4SF)	3	ENS	6422
4	227	0	Inf. Dilution	lgK:68.64(4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:55.56(4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-166.03(5SF)	0	EFE	6422
7	25	0	Inf. Dilution	dH:-179.3(4SF)	3	MTD	6422
8	127	0	Inf. Dilution	dH:-179.2(4SF)	1	MTD	6422
9	227	0	Inf. Dilution	dH:-179.7(4SF)	0	MTD	6422
10	327	0	Inf. Dilution	dH:-179.4(4SF)	0	MTD	6422

Reaction No. 66954							
0.5<H2(g)> + Li(s) + 0.5<O2(g)> = Li+1_OH-1_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:76.90(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:76.38(4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:55.27(4SF)	3	ENS	6422
4	227	0	Inf. Dilution	lgK:42.57(4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:34.08(4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-104.9(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dG:-438.9(4SF) kJ	4	EOD	29025
8	25	0	Inf. Dilution	dH:-115.9(4SF)	3	MTD	6422
9	25	0	Inf. Dilution	dH:-484.9(4SF) kJ	4	EOD	29025
10	127	0	Inf. Dilution	dH:-115.9(4SF)	1	MTD	6422
11	227	0	Inf. Dilution	dH:-116.6(4SF)	0	MTD	6422
12	327	0	Inf. Dilution	dH:-116.5(4SF)	0	MTD	6422

Reaction No. 66955							
2<Li(s)> + 1.5<O2(g)> + Si(s) = Li2SiO3(s)							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:273.1 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:271.3 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:199.5 (4SF)	3	ENS	6422
4	227	0	Inf. Dilution	lgK:156.3 (4SF)	2	ENS	6422
5	327	0	Inf. Dilution	lgK:127.4 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-1557.2 (5SF) kJ	5	EFE	6330
7	25	0	Inf. Dilution	dG:-372.6 (4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dH:-1648.1 (5SF) kJ	3	CRV	6330
9	25	0	Inf. Dilution	dH:-394.2 (4SF)	3	MTD	6422
10	127	0	Inf. Dilution	dH:-394.5 (4SF)	1	MTD	6422
11	227	0	Inf. Dilution	dH:-396.0 (4SF)	0	MTD	6422
12	327	0	Inf. Dilution	dH:-396.0 (4SF)	0	MTD	6422

Reaction No. 66956



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:423.4 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:420.7 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:309.2 (4SF)	3	ENS	6422
4	227	0	Inf. Dilution	lgK:242.2 (4SF)	2	ENS	6422
5	327	0	Inf. Dilution	lgK:197.5 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-577.6 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-612.1 (4SF)	3	MTD	6422
8	127	0	Inf. Dilution	dH:-612.3 (4SF)	1	MTD	6422
9	227	0	Inf. Dilution	dH:-613.7 (4SF)	0	MTD	6422
10	327	0	Inf. Dilution	dH:-613.3 (4SF)	0	MTD	6422


Reaction No. 66957



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:386.1 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:383.5 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:282.1 (4SF)	3	ENS	6422
4	227	0	Inf. Dilution	lgK:220.9 (4SF)	2	ENS	6422
5	327	0	Inf. Dilution	lgK:180.0 (4SF)	0	ENS	6422


6	25	0	Inf. Dilution	dG:-526.7 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-556.9 (4SF)	3	MTD	6422
8	127	0	Inf. Dilution	dH:-557.7 (4SF)	1	MTD	6422
9	227	0	Inf. Dilution	dH:-561.5 (4SF)	0	MTD	6422
10	327	0	Inf. Dilution	dH:-562.3 (4SF)	0	MTD	6422

Reaction No. 66958




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:276.8 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:275.0 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:202.2 (4SF)	3	ENS	6422
4	227	0	Inf. Dilution	lgK:158.5 (4SF)	2	ENS	6422
5	327	0	Inf. Dilution	lgK:129.3 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-377.6 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-399.3 (4SF)	3	MTD	6422
8	127	0	Inf. Dilution	dH:-399.4 (4SF)	1	MTD	6422
9	227	0	Inf. Dilution	dH:-400.8 (4SF)	0	MTD	6422
10	327	0	Inf. Dilution	dH:-400.7 (4SF)	0	MTD	6422

Reaction No. 66959



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:292.0 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:290.1 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:213.5 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:167.5 (4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:136.7 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-398.4 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-420.7 (4SF)	2	MTD	6422
8	127	0	Inf. Dilution	dH:-420.6 (4SF)	1	MTD	6422
9	227	0	Inf. Dilution	dH:-422.0 (4SF)	0	MTD	6422
10	327	0	Inf. Dilution	dH:-421.9 (4SF)	0	MTD	6422


Reaction No. 66960



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:231.5 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:230.0 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:167.4 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:129.8 (4SF)	3	ENS	6422
5	327	0	Inf. Dilution	lgK:104.6 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-1321.7 (5SF) kJ	5	EFE	6330
7	25	0	Inf. Dilution	dG:-315.9 (4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dG:-1321.7 (5SF) kJ	4	EOD	29025
9	25	0	Inf. Dilution	dH:-1436.5 (5SF) kJ	5	CRV	6330
10	25	0	Inf. Dilution	dH:-343.3 (4SF)	4	MTD	6422
11	25	0	Inf. Dilution	dH:-1436.5 (5SF) kJ	4	EOD	29025
12	127	0	Inf. Dilution	dH:-344.0 (4SF)	4	MTD	6422
13	227	0	Inf. Dilution	dH:-345.8 (4SF)	3	MTD	6422
14	327	0	Inf. Dilution	dH:-345.8 (4SF)	0	MTD	6422
15	25	0	Inf. Dilution	Cp:117.6 (4SF) J/K	4	EOD	29025

Reaction No. 66961



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:71.91 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:71.46 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:53.20 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:42.15 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:34.59 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-98.10 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-100.2 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-100.3 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-103.5 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-104.0 (4SF)	4	MTD	6422

Reaction No. 66962



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:60.73 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:60.34 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:44.86 (4SF)	4	ENS	6422


4	227	0	Inf. Dilution	lgK:35.48 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:29.15 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-82.8 (3SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-85.0 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-85.1 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-89.8 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-87.1 (3SF)	4	MTD	6422

Reaction No. 67411							
Al(s) + Li(s) + 5<O2(g)> + 4<Si(s)> = LiAlSi4O10(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:807.7 (4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:802.5 (4SF)	0	ENS	6494
3	127	0	Inf. Dilution	lgK:589.7 (4SF)	3	ENS	6494
4	227	0	Inf. Dilution	lgK:462.1 (4SF)	2	ENS	6494
5	327	0	Inf. Dilution	lgK:376.9 (4SF)	0	ENS	6494
6	25	0	Inf. Dilution	dG:-1102. (4SF)	4	EFE	6494
7	25	0	Inf. Dilution	dH:-1168. (4SF)	4	MTD	6494
8	127	0	Inf. Dilution	dH:-1168. (4SF)	3	MTD	6494
9	227	0	Inf. Dilution	dH:-1169. (4SF)	2	MTD	6494
10	327	0	Inf. Dilution	dH:-1168. (4SF)	0	MTD	6494

Reaction No. 67438							
Li+1 + H2O = Li+1_OH-1 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-13.8 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-13.64 (4SF)	0	CRV	6478
3	25	0	Inf. Dilution	lgK:-13.64 (4SF)	0	ENS	6496
4	25	0	UCT_Sea	lgK:-13.64 (0.01SD)	0	EDH	5390
5	25	0.1	UCT_Sea	lgK:-13.65 (0.01SD)	0	EDH	5390
6	25	0.2	UCT_Sea	lgK:-13.66 (0.01SD)	0	EDH	5390
7	25	0.3	UCT_Sea	lgK:-13.68 (0.01SD)	0	EDH	5390
8	25	0.4	UCT_Sea	lgK:-13.69 (0.01SD)	0	EDH	5390
9	25	0.5	UCT_Sea	lgK:-13.70 (0.01SD)	0	EDH	5390
10	25	0.6	UCT_Sea	lgK:-13.71 (0.01SD)	0	EDH	5390
11	25	0.7	UCT_Sea	lgK:-13.72 (0.01SD)	0	EDH	5390


12	25	0	Inf. Dilution	dH:14.1 (3SF)	0	CRV	6478
13	25	0	Inf. Dilution	dH:13.4 (2.SD)	0	CRV	6478
14	25	0	Inf. Dilution	dH:0.0 (1SF)	0	ENS	6496

Reaction No. 67854




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.0 (1SF)	3	MPP	5757
2	25	0.1	MeCN Many Media	lgK:3.35 (0.12SD)	7	CIU	13297
3	25		MeCN	lgK:3.40 (3SF)	3	MCN	4820
4	25	0.1	MeCN Many Media	dH:-21.9 (0.8SD) kJ	6	CIU	13297
5	25	0.1	PrCarbonate Many Media	lgK:2.87 (0.06SD)	7	CIU	13297
6	25		PrCarbonate	lgK:2.9 (0.05SD)	3	MCV	2970
7	25	0.1	PrCarbonate Many Media	dH:-17. (1.SD) kJ	6	CIU	13297

Reaction No. 69808




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Propan-2-ol	lgK:2.46 (3SF)	3	MCN	1926

Reaction No. 69809



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Propan-2-ol	lgK:2.37 (3SF)	3	MCN	1926


Reaction No. 70286



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:126.6 (4SF) kJ	5	EFE	6330
2	25	0	Inf. Dilution	dG:126.66 (5SF) kJ	5	EFE	7275
3	25	0	Inf. Dilution	dG:126.6 (4SF) kJ	6	CRV	8746
4	25	0	Inf. Dilution	dG:126.600 (0.5SD) kJ	5	CRV	27292
5	25	0	Inf. Dilution	dH:159.3 (4SF) kJ	5	CRV	6330
6	25	0	Inf. Dilution	dH:159.37 (5SF) kJ	5	EFE	7275
7	25	0	Inf. Dilution	dH:159.3 (1.0MD) kJ	6	CRV	8746


8	25	0	Inf. Dilution	dH:159.300 (0.5SD) kJ	5	CRV	27292
---	----	---	---------------	-----------------------	---	-----	-------

Reaction No. 70351




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-1026. (4SF) kJ	5	ENS	7275

Reaction No. 70356




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-884. (3SF) kJ	0	ENS	7275

Reaction No. 70361




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-856. (3SF) kJ	0	ENS	7275

Reaction No. 70366




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-815. (3SF) kJ	5	ENS	7275

Reaction No. 71156




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:-2.920 (4SF)	5	CRV	7761
2	25	0	Inf. Dilution	dH:255.0 (4SF) kJ	5	CRV	7761

Reaction No. 71157



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:-2.331 (4SF)	5	CRV	7761
2	25	0	Inf. Dilution	dH:187.9 (4SF) kJ	5	CRV	7761


Reaction No. 71158



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-51.5 (3SF)	1	ELC	


2	25	0	Inf. Dilution	E:-3.060 (4SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:278. (3SF) kJ	2	CRV	7761

Reaction No. 71213




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-302.0 (4SF) kJ	5	EFE	6330
2	25	0	Inf. Dilution	dH:-372.4 (4SF) kJ	5	CRV	6330

Reaction No. 71214




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-381.1 (4SF) kJ	5	EFE	6330
2	25	0	Inf. Dilution	dH:-483.1 (4SF) kJ	5	CRV	6330

Reaction No. 71215




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:174.4 (4SF) kJ	5	CRV	6330
2	25	0	Inf. Dilution	dH:215.9 (4SF) kJ	5	CRV	6330

Reaction No. 71216




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-441.4 (4SF) kJ	5	CRV	6330

Reaction No. 71217



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-2095.8 (5SF) kJ	5	CRV	6330


Reaction No. 72501



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Et4NC1O4	lgK:2. (1SF)	3	MGL	5315
2	25	0.05	DMF Et4NC1O4	lgK:2.23 (0.05SD)	4	MMC	5315


3	25	0.05	DMF Et4NClO4	dH:36.4 (3SF) kJ	4	MCL	5315
4	25	0.05	MeCN Et4NClO4	lgK:9.13 (0.05SD)	4	MIS	5315
5	25	0.05	Methanol Et4NClO4	lgK:3.01 (0.05SD)	4	MMC	5315
6	25	0.05	Methanol Et4NClO4	dH:20.4 (3SF) kJ	4	MCL	5315
7	25	0.05	PrCarbonate Et4NClO4	lgK:7.0 (0.1SD)	4	MMC	5315
8	25	0.05	PrCarbonate Et4NClO4	dH:35.8 (3SF) kJ	4	MCL	5315
9	25	0.05	Pyridine Et4NClO4	lgK:5.08 (0.05SD)	4	MIS	5315

Reaction No. 72516



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.4 (4SF)	1	ELC	
2	14:17	10	NH4OH	dH:-0.5 (1SF)	0	MCL	5699

Reaction No. 72579



Note: Assumes lithium acetate is dissociated

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	HClO4	lgK:0.89 (0.05SD)	0	MPS	5765


Reaction No. 72580



Note: Assumes lithium acetate is dissociated

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	HClO4	lgK:-0.4 (0.1SD)	0	MPS	5765

Reaction No. 72584



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		HMPT	lgK:0.99 (2SF)	4	MCN	5756

Note (1): Using Fuoss-Hia equ; other fits also given

Reaction No. 72664

SCN-1 + Li+1 = Li+1_SCN-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaClO4	lgK:1.00 (3SF)	5	MCL	11516
Note (1): Ishiguro S et al., Inorg. Chem., 1988, 27, 1152							
2	5		DMF	lgK:0.94 (0.06SD)	4	MIR	5722
3	15		DMF	lgK:0.97 (0.06SD)	4	MIR	5722
4	25		DMF	lgK:0.93 (0.06SD)	4	MIR	5722
5	35		DMF	lgK:0.94 (0.06SD)	4	MIR	5722
6	43		DMF	lgK:0.79 (0.08SD)	4	MIR	5722
7	55		DMF	lgK:0.80 (0.09SD)	4	MIR	5722
8	65		DMF	lgK:0.70 (0.09SD)	4	MIR	5722
9	5:65		DMF	dH:7. (1SF) kJ	4	MTD	5722

Reaction No. 72882							
12PhenDTA-4 + Li+1 = Li+1_12PhenDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.01	Et4NClO4	lgK:1.99 (0.01SD)	5	MPS	5942
2	25	0.01	Et4NClO4	lgK:2.02 (0.05SD)	5	MPT	5942
3	25	0.01	Et4NClO4	dH:-10.4 (0.5SD) kJ	5	MCL	5942

Reaction No. 72883							
Li+1_12PhenDTA-4 + H+1 = H+1_Li+1_12PhenDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.01	Et4NClO4	lgK:5.63 (0.08SD)	5	MPS	5942

Reaction No. 72954							
Li+1(2)_SeO3-2_(s) = 2<Li+1> + SeO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-6.13 (3SF)	4	ENS	12931

Reaction No. 73365							
Oxalic-2 + Li+1 = Li+1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.2 (3SF)	2	EAE	
2	37	0	HNO3	lgK:1.17 (3SF)	3	MGL	6797
3	37	0.15	HNO3	lgK:0.79 (0.01MD)	3	MGL	6797
4	37	0.2	HNO3	lgK:0.78 (2SF)	3	MGL	6797

5	37	0.4	HNO3	lgK:0.80 (2SF)	3	MGL	6797
6	37	0.6	HNO3	lgK:0.85 (2SF)	3	MGL	6797
7	37	0.8	HNO3	lgK:0.91 (2SF)	3	MGL	6797
8	37	1	HNO3	lgK:0.97 (2SF)	3	MGL	6797


Reaction No. 73986							
Li+1(2)_CO3-2_(s) = 2<Li+1> + CO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-3.2 (2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-1.60 (3SF)	0	CRV	
Note (2): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
3	25	0	Inf. Dilution	lgK:-3.09 (3SF)	3	CRV	6330
Note (3): p. 8-58							
4	25	0	Inf. Dilution	lgK:-0.509 (3SF)	0	CRV	22551

Reaction No. 75534							
0.5<Cl2(g)> + H2(g) + Li(s) + 0.5<O2(g)> = Li+1_Cl-1_H2O_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-632.1 (4SF) kJ	3	EOD	12955
Note (1): From Wagman							
2	25	0	Inf. Dilution	dG:-631.80 (5SF) kJ	3	CRV	24003
3	25	0	Inf. Dilution	dG:-631.8 (4SF) kJ	2	EOD	29025
4	25	0	Inf. Dilution	dG:-631.80 (5SF) kJ	2	EOD	30015
5	25	0	Inf. Dilution	dH:-712.6 (4SF) kJ	2	EOD	29025
6	25	0	Inf. Dilution	dH:-712.58 (5SF) kJ	2	EOD	30015
7	25	0	Inf. Dilution	Cp:89.7 (3SF) J/K	2	EOD	29025

Reaction No. 75535							
0.5<Br2(l)> + 2<H2(g)> + Li(s) + O2(g) = Li+1_Br-1_H2O(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-842.8 (4SF) kJ	3	EOD	12955
Note (1): From Wagman							
2	25	0	Inf. Dilution	dG:-840.5 (4SF) kJ	5	CRV	24003
3	25	0	Inf. Dilution	dG:-840.6 (4SF) kJ	4	EOD	29025
4	25	0	Inf. Dilution	dG:-840.5 (4SF) kJ	1	MSL	30015
5	25	0	Inf. Dilution	dG:-841.54 (5SF) kJ	2	EOD	30015
6	25	0	Inf. Dilution	dG:-841.77 (5SF) kJ	2	EOD	30015


7	25	0	Inf. Dilution	dH:-962.7(4SF) kJ	4	EOD	29025
8	25	0	Inf. Dilution	dH:-962.7(4SF) kJ	2	EOD	30015

Reaction No. 75536




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1001.00(6SF) kJ	5	CRV	24003

Reaction No. 75537




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1103.5(5SF) kJ	5	CRV	24003

Reaction No. 75548




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1565.5(5SF) kJ	5	CRV	24003
2	25	0	Inf. Dilution	dG:-1563.3(5SF) kJ	4	EOD	29025
3	25	0	Inf. Dilution	dG:-1564.3(5SF) kJ	5	MSL	29947
4	25	0	Inf. Dilution	dH:-1738.4(5SF) kJ	2	EOD	29025
5	25	0	Inf. Dilution	dH:-1733.6(5SF) kJ	5	MSL	29947
6	25	0	Inf. Dilution	Cp:159.3(4SF) J/K	4	EOD	29025

Reaction No. 75570




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-125.0(4SF) kJ	5	CRV	6330
2	25	0	Inf. Dilution	dH:-190.8(4SF) kJ	5	CRV	6330

Reaction No. 75890




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.477(3SF)	2	EAE	
2	37	0.15	KCl	lgK:1.13(3SF)	5	MGL	1230

Reaction No. 75891



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.12(3SF)	2	EAE	
2	37	0.15	KCl	lgK:0.25(2SF)	5	MGL	1230


Reaction No. 76143



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaClO4	lgK:0.07(1SF)	5	MCL	11516

Note (1): Ishiguro S et al., Inorg. Chem., 1988, 27, 1152


Reaction No. 76220



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.32	CsCl	lgK:0.83(2SF)	5	MGL	11516

Note (1): Botts J et al., Biochemistry, 1965, 4, 1788


Reaction No. 76221



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.32	CsCl	lgK:3.68(3SF)	5	MGL	11516


Note (1): Botts J et al., Biochemistry, 1965, 4, 1788

Reaction No. 76227



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	NaClO4	lgK:1.67(3SF)	5	MGL	6146


Reaction No. 76522



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	LiCl	lgR:-2.75(0.05SD)	5	EOD	17594

Note (1): Hammarsten, C.R. Trav. Lab. Carlsb., 1932, 19, 1

Reaction No. 76563



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.8(2SF)	1	ELC	

2	25	0	Inf. Dilution	lgK:2.45 (3SF)	0	CRV	
Note (2): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
3	25	0	Inf. Dilution	dH:-11.716 (5SF)	5	MTD	12007

Reaction No. 76564							
Li+1_Cl-1_(s) = Li+1 + Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.0 (2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:2.35 (3SF)	0	CRV	
Note (2): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
3	25	0	Inf. Dilution	dH:-8.843 (4SF)	5	MTD	12007


Reaction No. 76565							
Li+1_OH-1_(s) = Li+1 + OH-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.96 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:1.46 (3SF)	0	CRV	
Note (2): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
3	25	0	Inf. Dilution	lgK:1.92 (3SF)	4	CRV	28992
4	50	0	Inf. Dilution	lgK:1.60 (3SF)	4	CRV	28992
5	100	0	Inf. Dilution	lgK:0.98 (2SF)	4	CRV	28992
6	150	0	Inf. Dilution	lgK:0.39 (2SF)	4	CRV	28992
7	200	0	Inf. Dilution	lgK:-0.16 (2SF)	4	CRV	28992
8	250	0	Inf. Dilution	lgK:-1.02 (3SF)	4	CRV	28992

Reaction No. 76566							
Li+1_I-1_(s) = Li+1 + I-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.2 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:2.18 (3SF)	0	CRV	
Note (2): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							

Reaction No. 76567							
Li+1_NO3-1_(s) = Li+1 + NO3-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.0 (2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:2.23 (3SF)	0	CRV	

Note (2): <http://www.saltlakemetals.com/SolubilityProducts.htm> (15/7/14)


Reaction No. 76568



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.8(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:1.65(3SF)	0	CRV	

Note (2): <http://www.saltlakemetals.com/SolubilityProducts.htm> (15/7/14)

Reaction No. 76569




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.73(3SF)	1	CRV	

Note (1): <http://www.saltlakemetals.com/SolubilityProducts.htm> (15/7/14)


2	25	0	Inf. Dilution	lgK:1.45(3SF)	3	CRV	28992
3	50	0	Inf. Dilution	lgK:1.06(3SF)	3	CRV	28992
4	100	0	Inf. Dilution	lgK:0.17(2SF)	3	CRV	28992
5	150	0	Inf. Dilution	lgK:-0.80(2SF)	2	CRV	28992
6	200	0	Inf. Dilution	lgK:-1.85(3SF)	2	CRV	28992
7	250	0	Inf. Dilution	lgK:-3.13(3SF)	2	CRV	28992

Reaction No. 76571




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.249(4SF)	1	ELC	
2	25	0	Inf. Dilution	dH:-6.31(0.13SD)	6	MCL	21773

Reaction No. 76583



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	lgK:5.172(4SF)	3	MSL	12955

Reaction No. 76584



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	lgK:5.038(4SF)	3	MSL	12955

Reaction No. 76588							
$\text{Ca}+2_{\text{Li}+1_{\text{Br}-1(3)}_{\text{H}_2\text{O}(5)}}(\text{s}) = \text{Ca}+2 + \text{Li}+1 + 3\langle\text{Br}-1\rangle + 5\langle\text{H}_2\text{O}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	lgK:15.035 (5SF)	3	MSL	12955

Reaction No. 76589							
$\text{Ca}+2_{\text{Li}+1_{\text{Cl}-1(3)}_{\text{H}_2\text{O}(5)}}(\text{s}) = \text{Ca}+2 + \text{Li}+1 + 3\langle\text{Cl}-1\rangle + 5\langle\text{H}_2\text{O}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	lgK:10.597 (5SF)	3	MSL	12955

Reaction No. 76769							
$2\langle\text{Li}(\text{s})\rangle + 2\langle\text{O}_2(\text{g})\rangle + \text{U}(\text{s}) = \text{Li}_2\text{UO}_4(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1853.20 (1.1SD) kJ	5	CRV	20827
2	25	0	Inf. Dilution	dH:-1968.20 (1.65SD) kJ	5	CRV	20827

Reaction No. 77482							
$2\langle\text{SCN}-1\rangle + \text{Li}+1 = \text{Li}+1_{\text{SCN}-1(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.4 (2SF)	1	ELC	

Reaction No. 78575							
$2\langle\text{NH}_3\rangle + \text{Li}+1 = \text{Li}+1_{\text{NH}_3(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.1 (4SF)	1	ELC	


Reaction No. 78595							
$\text{PO}_4-3 + \text{Li}+1 + \text{H}+1 = \text{H}+1_{\text{Li}+1_{\text{PO}_4-3}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.51 (4SF)	1	ELC	

Reaction No. 78653							
$\text{PO}_4-3 + \text{Li}+1 + 2\langle\text{H}+1\rangle = \text{H}+1(2)_{\text{Li}+1_{\text{PO}_4-3}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.03 (4SF)	1	ELC	

Reaction No. 78998							
$\text{Li}+1 + 3\langle\text{F}-1\rangle + \text{Be}+2 = \text{Be}+2_{\text{Li}+1_{\text{F}-1(3)}}(\text{s})$							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.4(4SF)	1	ELC	

Reaction No. 79000




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.03(4SF)	1	ELC	

Reaction No. 79030




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:30.0(3SF)	1	ELC	

Reaction No. 79032




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.99(4SF)	1	ELC	

Reaction No. 79139




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-4.868(4SF)	1	ELC	

Reaction No. 79140




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.8669(4SF)	1	ELC	

Reaction No. 79269



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.02852(4SF)	1	ELC	

Reaction No. 79410



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.071(4SF)	1	ELC	

Reaction No. 79415							
$\text{Li}+1 + 3\text{H}_2\text{O} + \text{ClO}_4-1 = \text{Li}+1_{\text{ClO}_4-1_{\text{H}_2\text{O}(3)}}(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: -2.006(4\text{SF})$	1	ELC	

Reaction No. 79478							
$\text{Li}+1 + \text{Formic}-1 = \text{Li}+1_{\text{Formic}-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: -8.(1\text{SF})$	1	EES	

Reaction No. 79548							
$0.5\text{Br}_2(1) + \text{H}_2(\text{g}) + \text{Li}(\text{s}) + 0.5\text{O}_2(\text{g}) = \text{Li}+1_{\text{Br}-1_{\text{H}_2\text{O}}}(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\text{dG}: -594.3(4\text{SF}) \text{ kJ}$	4	EOD	29025
2	25	0	Inf. Dilution	$\text{dH}: -662.6(4\text{SF}) \text{ kJ}$	4	EOD	29025

Reaction No. 79549							
$0.5\text{Cl}_2(\text{g}) + 2\text{H}_2(\text{g}) + \text{Li}(\text{s}) + \text{O}_2(\text{g}) = \text{Li}+1_{\text{Cl}-1_{\text{H}_2\text{O}(2)}}(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\text{dG}: -879.2(4\text{SF}) \text{ kJ}$	2	EOD	29025
2	25	0	Inf. Dilution	$\text{dG}: -874.75(5\text{SF}) \text{ kJ}$	2	MSL	30015
3	25	0	Inf. Dilution	$\text{dG}: -874.32(5\text{SF}) \text{ kJ}$	2	EOD	30015
4	25	0	Inf. Dilution	$\text{dH}: -1012.5(5\text{SF}) \text{ kJ}$	2	EOD	29025
5	25	0	Inf. Dilution	$\text{dH}: -1012.7(5\text{SF}) \text{ kJ}$	2	EOD	30015
6	25	0	Inf. Dilution	$\text{Cp}: 131.4(4\text{SF}) \text{ J/K}$	4	EOD	29025

Reaction No. 79550							
$1.5\text{H}_2(\text{g}) + \text{Li}(\text{s}) + \text{O}_2(\text{g}) = \text{Li}+1_{\text{OH}-1_{\text{H}_2\text{O}}}(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\text{dG}: -689.5(4\text{SF}) \text{ kJ}$	4	EOD	29025
2	25	0	Inf. Dilution	$\text{dH}: -789.8(4\text{SF}) \text{ kJ}$	4	EOD	29025

Reaction No. 80072							
$3\text{H}_2(\text{g}) + 0.5\text{I}_2(\text{s}) + \text{Li}(\text{s}) + 1.5\text{O}_2(\text{g}) = \text{Li}+1_{\text{I}-1_{\text{H}_2\text{O}(3)}}(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\text{dG}: -1032.1(5\text{SF}) \text{ kJ}$	2	EOD	30015
2	25	0	Inf. Dilution	$\text{dH}: -1192.2(5\text{SF}) \text{ kJ}$	2	EOD	30015

Reaction No. 80073							
$2\text{H}_2(\text{g}) + 0.5\text{I}_2(\text{s}) + \text{Li}(\text{s}) + \text{O}_2(\text{g}) = \text{Li+1_I-1_H}_2\text{O}(2)_(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-780.2(4SF)kJ	2	EOD	30015
2	25	0	Inf. Dilution	dH:-890.4(4SF)kJ	2	EOD	30015

Reaction No. 80074							
$\text{H}_2(\text{g}) + 0.5\text{I}_2(\text{s}) + \text{Li}(\text{s}) + 0.5\text{O}_2(\text{g}) = \text{Li+1_I-1_H}_2\text{O}_(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-531.3(4SF)kJ	1	MSL	30015
2	25	0	Inf. Dilution	dG:-519.15(5SF)kJ	2	EOD	30015
3	25	0	Inf. Dilution	dG:-515.34(5SF)kJ	2	EOD	30015
4	25	0	Inf. Dilution	dH:-590.32(5SF)kJ	2	EOD	30015

Reaction No. 80075							
$0.5\text{Br}_2(1) + 3\text{H}_2(\text{g}) + \text{Li}(\text{s}) + 1.5\text{O}_2(\text{g}) = \text{Li+1_Br-1_H}_2\text{O}(3)_(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1085.5(5SF)kJ	2	MSL	30015
2	25	0	Inf. Dilution	dG:-1084.4(5SF)kJ	2	EOD	30015
3	25	0	Inf. Dilution	dH:-1243.0(5SF)kJ	2	MSL	30015
4	25	0	Inf. Dilution	dH:-1252.1(5SF)kJ	2	EOD	30015

Reaction No. 80201							
$\text{Li}(\text{s}) + \text{Nb}(\text{s}) + 1.5\text{O}_2(\text{g}) = \text{LiNbO}_3(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1279.1(5SF)kJ	3	EOR	30153
Note (1): Original Russian reference given							
2	25	0	Inf. Dilution	dH:-1364.9(5SF)kJ	3	EOR	30153
Note (2): Original Russian reference given							

Reaction No. 80960							
$1.5\text{Br}_2(1) + \text{Ca}(\text{s}) + 5\text{H}_2(\text{g}) + \text{Li}(\text{s}) + 2.5\text{O}_2(\text{g}) = \text{Ca+2_Li+1_Br-1(3)_H}_2\text{O}(5)_(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2257.2(5SF)kJ	3	EOD	12955
Note (1): From Wagman							

Data Assessment

Weight	Assessment
9	highest accuracy
8	multi-determined; excellent dependability
7	trustworthy; outstanding single determination
6	better than average reliability
5	average single determination
4	some doubt
3	poorly known
2	guess to achieve consistency (or just as bad)
1	no information but consistent
0	problematic/inconsistent

Techniques

Abbrev	Method
CIU	Critical IUPAC publication (crit.)
CMN	Several experimental values (crit.)
CRV	Critical review
EAE	Automated extrapolation
EDH	Debye-Hueckel corrections
EES	Personal estimate
EFE	Free Energy relations
EIU	Critical IUPAC review (estim.)
ELC	Linear Combination of Reactions
EMS	Mean Spherical Approximation
EMU	Method unknown
ENS	Not specified
EOD	Calculated from data of others
EOR	Other Reaction Constants
ESC	Standard conditions anchor
MAC	Activity coefficient (not specified)
MAG	Silver electrode e.m.f.

MCE	Cation exchange
MCL	Calorimetry
MCN	Conductivity
MCO	Colorimetry (often for measuring pH)
MCV	Cyclic voltammetry
MDG	Combination of Thermodynamic Data
MDS	Distribution between two phases
MEF	Electromotoric force, not specified
MFL	Fluorescence
MFP	Freezing point
MGL	Glass electrode
MHY	Emf with hydrogen electrode
MIR	Infrared spectra
MIS	Ion selective electrode
MIX	Ion exchange
MKN	Rate of reaction
MMC	Metal competition
MMR	Nuclear magnetic resonance
MPH	pH method, not specified
MPK	Protonation constant shift
MPL	Polarography
MPM	Polarimetry
MPP	Partial pressure
MPS	Potentiometry and Spectrophotometry
MPT	Potentiometry
MRM	Raman spectra
MSC	Miscellaneous
MSL	Solubility
MSP	Spectroscopy
MTD	Temperature difference
MVP	Vapour phase osmometry

References

Reference No.: 13(92EJM)

J. Inclusion Phenom. Mol. Recognit. Chem., 1992, 12, 263 - 274; Eglin JL; Jackson EP; Moeggenborg KJ; Dye JL; Bencini A; Micheloni M; Li+(TMPAND)Na⁻ : The First Alkalide Prepared from an Azacage Complexant

Reference No.: 140(64SiM)

Stability Constants of Metal-ion Complexes SP17, 1964 Sillen LG; Martell AE; The Chemical Soc., London

Reference No.: 258(56SmA)

J. Phys. Chem., 1956, 60, 180 - 184; Smith RM; Alberty RA; The Apparent Stability Constants of Ionic Complexes of Various Adenosine Phosphates with Monovalent Cations

Reference No.: 381(64ArM)

J. Chem. Soc., 1964, 3117 - 3122; Archer DW; Monk CB; Ion-association Constants of Some Acetates by pH (Glass Electrode) Measurements

Reference No.: 425(94LuL)

Inorg. Chim. Acta, 1994, 219, 217 - 220; Lucas J; Lincoln SF; Solution Studies of Monovalent Metal Complex Ions of the Bibracchial Lariat Ether 7,16-Bis(2-methoxyethyl)-1,4,10,13-tetraoxa-7,16-diazacyclooctadecane

Reference No.: 431(84CTH)

Polyhedron, 1984, 3, 845 - 851; Chan CB; Tioh NH; Hefter GT; Fluoride Complexes of the Alkali Metal Ions

Reference No.: 432(84HCT)

Anal. Chem., 1984, 56, 749 - 752; Hefter GT; Chan CB; Tioh NH; Fluoride Standards in Determination of Equilibrium Constants of Metal Ion-Fluoride Complexes

Reference No.: 552(95SMM)

NIST Critical Stability Constants of Metal Complexes Database, 1995 Smith RM; Martell AE; Motekaitis RJ; Version 2.0; National Institute of Standards and Technology, Gaithersburg, USA

Reference No.: 766(87BrA)

Report EPA/600/3-87/012, 1987 Brown DS; Allison JD; MINTEQA1, An Equilibrium Metal Speciation Model: Users Manual; U.S. Environmental Protection Agency, Athens, Georgia 30613

Reference No.: 769(88RoV)

Talanta, 1988, 35, 271 - 275; Rogers HR; van den Berg CMG; Determination of Borate Ion-Pair Stability Constants by Potentiometry and Non-approximative Linearization of Titration Data

Reference No.: 773(85KoS)

Handbook of Chemical Equilibria in Analytical Chemistry, 1985 Kotrly S; Sucha L; Ellis Horwood Series in Anal. Chem.; Eds. Chalmers RA & Masson M; Ellis Horwood, Chichester

Reference No.: 775(71CCM)

Selected Constants, 1971 Charlot G; Collumeau A; Marchon MJC; Oxidation-Reduction Potentials of Inorganic Substances in Aqueous Solution; Butterworths, London

Reference No.: 802(90Wea)

CRC Handbook of Chemistry and Physics, 70th Edn., 1990 Weast RC; A Ready-Reference Book of Chemical and Physical Data; CRC Press, Cleveland, Ohio

Reference No.: 903(77And)

Critical Survey of Stability Constants of EDTA Complexes, 1977 Anderegg G; IUPAC Chemical Data Series. 14; Pergamon Press, Oxford

Reference No.: 906(79Per)

IUPAC Chemical Data Series No. 22, 1979 Perrin DD; Stability Constants of Metal-Ion Complexes, First Edition Part B, Organic Ligands; Pergamon, Oxford

Reference No.: 931(71SiM)

Stability Constants of Metal-ion Complexes SP25, 1971 Sillen LG; Martell AE; Supplement No 1 to Special Publication No 25; Chemical Society, London

Reference No.: 999(91MaM)

Estimation of Constants for JESS Database, 1991 May PM; May RF

Reference No.: 1045(85DDD)

J. Chem. Soc., Dalton Trans., 1985,, 2353 - 2361; Daniele PG; De Robertis A; De Stefano C; Sammartano S; Rigano C; On the Possibility of Determining the Thermodynamic Parameters for the Formation of Weak Complexes using a Simple Model for the Dependence on Ionic Strength of Activity Coefficients: Na⁺, K⁺, and Ca²⁺ Complexes of Low Molecular Weight Ligands in Aqueous Solution

Reference No.: 1118(82And)

Pure Appl. Chem., 1982, 54, 2693 - 2758; Anderegg G; Critical Survey of Stability Constants of NTA Complexes

Reference No.: 1176(87DDV)

Polyhedron, 1987, 6, 29 - 38; Delgado R; da Silva JJRF; Vaz MCTA; Metal Complexes of 1,4,10-Trioxa-7,13-Diazacyclopentadecane- N,N"-Diacetic Acid

Reference No.: 1230(81CDR)

Inorg. Chim. Acta, 1981, 56, L45 - L47; Cucinotta V; Daniele PG; Rigano C; Sammartano S; The Formation of Proton and Alkali-Metal Complexes with Ligands of Biological Interest in Aqueous Solution. Potentiometric and PMR Investigation of Li⁺, Na⁺, K⁺, Rb⁺, Cs⁺ and NH₄⁺ Complexes with Citrate

Reference No.: 1306(91DeD)

Talanta, 1991, 38, 439 - 444; De Robertis A; De Stefano C; Studies of Polyfunctional O-Ligands: Formation and Stability of Mg²⁺ and Ca²⁺ Complexes of 1,2,4,5-Benzenetetracarboxylic Acid in Aqueous Solution at 25 degrees

Reference No.: 1437(91SMC)

Pure Appl. Chem., 1991, 63, 1015 - 1080; Smith RM; Martell AE; Chen YT; Critical Evaluation of Stability Constants for Nucleotide Complexes with Protons and Metal Ions

Reference No.: 1529(87Har)

Talanta, 1987, 34, 817 - 820; Harju L; Determination of Stability Constants for Alkaline- Earth and Alkali Metal Ion Complexes of Glycine by Spectrophotometry

Reference No.: 1926(79PSJ)

J. Inorg. Nucl. Chem., 1979, 41, 1759 - 1763; Poonia NS; Sarad SK; Jayakumar A; Kumar GC; Coordination Chemistry of Alkali and Alkaline Earth Cations - 1. Lower Glycols as Ligands

Reference No.: 1976(73CaS)

J. Am. Chem. Soc., 1973, 95, 3569 - 3572; Carr JD; Swartzfager DG; Studies of the Alkali Metal Ion Complexes of 2,3-Diaminobutane-N,N,N',N'-tetracetic Acid

Reference No.: 2016(82DeF)

Talanta, 1982, 29, 815 - 822; Delgado R; Frausto da Silva JJR; Metal Complexes of Cyclic Tetra-azatetra-acetic Acids

Reference No.: 2185(88DaS)

J. Chem. Soc., Faraday Trans. 1, 1988, 84, 3539 - 3545; Danil de Namor AF; Salazar FF; Thermodynamic Parameters for the Complexation Process between Metal(I) Cations and Dibenzocryptand 222 in Dipolar, Aprotic Solvents

Reference No.: 2242(90DDD)

J. Chem. Res. (S), 1990,, 2316 - 2350; Daniele PG; De Robertis A; De Stefano C; Gianguzza A; Sammartano S; Studies on Polyfunctional O-Ligands. Formation Thermodynamics of Simple and Mixed Complexes with Citrate at Different Ionic Strengths in Aqueous Solution

Reference No.: 2251(87Bus)

J. Solution Chem., 1987, 16, 181 - 190; Buschmann H-J; Stability Constants and Thermodynamic Data for Complexes of 12-Crown-4 with Alkali Metal and Alkaline-Earth Cations in Methanol Solutions

Reference No.: 2360(83Van)

Polyhedron, 1983, 2, 285 - 289; van Uiter LG; Chelate Compound Stability Constant Calculations on Metal Diketonate Complexes

Reference No.: 2464(93LiR)

Inorg. Chim. Acta, 1993, 205, 23 - 30; Lincoln SF; Rodopoulos T; Equilibrium and Kinetic Study of the Complexation of Lithium(I), Sodium(I), Silver(I) and Thallium(I) by 4,7,13,16-Tetraoxa-1,10-diazabicyclo[8.5.5]eicosane (C211) and 4,7,13-trioxa-1,10-diazabicyclo[8.5.5]eicosane (C21C5) in Trialkyl Phosphate Solvents

Reference No.: 2469(92GhS)

J. Coord. Chem., 1992, 26, 337 - 344; Ghasemi J; Shamsipur M; Fluorimetric Study of Complexation of Alkali and Alkaline Earth Cations with 1,10-Phenanthroline, 2,2'-Bipyridine and 8-Hydroxy-Quinoline in Nonaqueous Solvents

Reference No.: 2529(91LiR)

Inorg. Chim. Acta, 1991, 190, 223 - 229; Lincoln SF; Rodopoulos T; Complexation of Lithium(I), Sodium(I), Silver(I) and Thallium(I) by 4,7,13,16-Tetraoxa-1,10-diazabicyclo[8.5.5]eicosane and 4,7,13-Trioxa-1,10-diazabicyclo[8.5.5]eicosane in Trimethyl Phosphate. A Potentiometric Titration and ⁷Li and ²³Na Nuclear Magnetic Resonance Study

Reference No.: 2542(82SSP)

Inorg. Chim. Acta, 1982, 66, 147 - 155; Sigel H; Scheller KH; Prus B; Metal Ion/Buffer Interactions. Stability of Alkali and Alkaline Earth Ion Complexes with Triethanolamine (Tea), 2-Amino-2(hydroxy- methyl)-1,3-Propanediol (Tris) and 2-[Bis(2-hydroxyethyl)amino]2 (hydroxymethyl)-1,3-propanediol (Bistris) in Aqueous and Mixed Solvents

Reference No.: 2556(93MSM)

NIST Critical Stability Constants of Metal Complexes Database, 1993 Martell AE; Smith RM; Motekaitis RJ; Version 1.0; National Institute of Standards and Technology, Gaithersburg, USA

Reference No.: 2558(54Cha)

J. Am. Chem. Soc., 1954, 76, 5854 - 5858; Charles RG; Heats and Entropies of Reaction of Metal Ions with Ethylenediaminetetraacetate

Reference No.: 2600(88PoJ)

J. Chem. Soc., Faraday Trans. 1, 1988, 84, 959 - 967; Pointud Y; Juillard J;

Interactions between Metal Cations and the Ionophore Lasalocid Part 2- Gibbs Functions, Enthalpies and Entropies for Complexation of Alkali-metal Cations by Lasalocid and Bromolasalocid

Reference No.: 2604(82BDJ)

Can. J. Chem., 1982, 60, 981 - 989; Bolte J; Demuyne C; Jeminet G; Juillard J; Tissier C; Etude Comparee de Trois Antibiotiques Ionophores: X.537 A (Lasalocid), A.23187 (Calcimycine) et X.14547 A. Complexation des Cations IA et IIA, Transport de Ca⁺⁺

Reference No.: 2713(93GhS)

J. Coord. Chem., 1993, 28, 231 - 236; Ghasemi J; Shamsipur M; Spectrophotometric Study of Complex Formation between some Alkali and Alkaline Earth Cations and Several Conventional (N,N), (N,O) and (O,O) Ligands in 95% Ethanol

Reference No.: 2723(90BBB)

Inorg. Chem., 1990, 29, 3282 - 3286; Bencini A; Bianchi A; Borselli A; Chimichi S; Ciampolini M; Dapporto P; Micheloni M; Nardi N; Paoli P; Valtancoli B; Selective Lithium Encapsulation in Aqueous Solution by the New Cage 4,10-Dimethyl-1,4,7,10,15-pentaazabicyclo[5.5.5]heptadecane (L). Synthesis, Characterization, and Structural Aspects. Crystal Structures of [LiL][ClO₄] and [CuL]Br₂.3H₂O

Reference No.: 2725(89BBB)

Inorg. Chem., 1989, 28, 4279 - 4284; Bencini A; Bianchi A; Borselli A; Ciampolini M; Garcia-Espana E; Dapporto P; Micheloni M; Paoli P; Ramirez JA; Valtancoli B; Synthesis and Characterization of the New Macrocyclic Cage 5,12,17-Trimethyl-1,5,9,12,17-pentaazabicyclo[7.5.5]nonadecane (L), which can selectively encapsulate Lithium Ion. Thermodynamic Studies on Protonation and Complex Formation. Crystal Structures of the Salt [HL][Cl].3H₂O and of the Lithium Complex [LiL][BPh₄]

Reference No.: 2733(92BBC)

J. Chem. Soc., Perkin Trans. 2, 1992,, 181 - 184; Bencini A; Bianchi A; Ciampolini M; Dapporto P; Micheloni M; Nardi N; Paoli P; Valtancoli B; Synthesis and Characterization of the Aza-cage 4-Benzyl-10,15-dimethyl-1,4,7,10,15-pentaazabicyclo[5.5.5] heptadecane (L). Its Proton Transfer Properties and Lithium Complex. The Crystal Structure of the Monoprotonated Salt [HL][BPh₄]

Reference No.: 2756(72WaF)

Anal. Chem., 1972, 44, 1640 - 1643; Wada H; Fernando Q; Interaction of Methanehydroxyphosphonic Acid and Ethane-1-hydroxy-1,1-diphosphonic Acid with Alkali and Alkaline Earth Metal Ions

Reference No.: 2829(85DRS)

Anal. Chem., 1985, 57, 2956 - 2960; Daniele PG; Rigano C; Sammartano S; Ionic Strength Dependence of Formation Constants. Alkali Metal Complexes of Ethylenediaminetetraacetate, Nitrilotriacetate, Diphosphate, and Tripolyphosphate in Aqueous Solution

Reference No.: 2931(81CGS)

J. Am. Chem. Soc., 1981, 103, 1384 - 1389; Cox BG; Garcia-Rosas J; Schneider H; Solvent Dependence of the Stability of Cryptate Complexes

Reference No.: 2938(84CVR)

J. Am. Chem. Soc., 1984, 106, 5965 - 5969; Cox BG; van Truong Ng.; Rzeszutarska J; Schneider H; Rates and Equilibria of Alkali Metal and Silver Ion Complex Formation with Monensin in Ethanol

Reference No.: 2956(78CSS)

J. Am. Chem. Soc., 1978, 100, 4746 - 4749; Cox BG; Schneider H; Stroka J; Kinetics of Alkali Metal Complex Formation with Cryptands in Methanol

Reference No.: 2970(80MDD)

J. Chem. Soc., Dalton Trans., 1980,, 865 - 868; Massaux J; Desreux JF; Duyckaerts G; Electrochemical Studies on Alkali-metal Complexes with the Small Macrocyclic 1,4,7,10-Tetraoxacyclododecane. Polarographic and Potentiometric Determination of the Stability Constants in Propylene Carbonate

Reference No.: 3083(68CaI)

J. Inorg. Nucl. Chem., 1968, 30, 2971 - 2976; Carroll RL; Irani RR; On the ΔH and ΔS of Metal Ion Interaction with Substituted Methylene Diphosphonates

Reference No.: 3201(77DCV)

J. Inorg. Nucl. Chem., 1977, 39, 613 - 619; da Silva JJRF; Candida M; Vaz TA; The Thermodynamics of Complex Formation between Uramildiacetic Acid and the Alkaline-Earth Metals

Reference No.: 3283(75LeS)

J. Am. Chem. Soc., 1975, 97, 6700 - 6707; Lehn J-M; Sauvage JP; [2]-Cryptates: Stability and Selectivity of Alkali and Alkaline-Earth Macrobicyclic Complexes

Reference No.: 3560(75Mid)

Chem. Soc. Rev., 1975, 4, 549 - 568; Midgley D; Alkali-metal Complexes in Aqueous Solution

Reference No.: 3595(86DDS)

J. Chem. Res. (S), 1986,, 164 - 165; De Robertis A; De Stefano C; Sammartano S; Cali R; Purrello R; Rigano C; Alkali-metal and Alkaline-earth-metal Ion Complexes with Adenosine 5'-triphosphate in Aqueous Solution. Thermodynamic Parameters and their Dependence on Temperature and Ionic Strength

Reference No.: 3712(81And)

Helv. Chim. Acta, 1981, 64, 1790 - 1795; Anderegg G; The Stability of Divalent 3d- and Trivalent 4f-Metal Complexes with Diazapolyoxa Macrocyclic Ligands

Reference No.: 3854(86Bus)

Inorg. Chim. Acta, 1986, 125, 31 - 35; Buschmann H-J; The Macrocyclic and Cryptate Effects. 5. Complexation of Alkali Ions by Monocyclic and Bicyclic Ligands in Methanol

Reference No.: 3910(89KaS)

Inorg. Chim. Acta, 1989, 155, 203 - 206; Kashanian S; Shamsipur M; Complex Formation of Alkaline Earth Cations with Benzo-15-Crown-5 and some 18-Crowns in methanol, Dimethylformamide and Dimethyl sulfoxide Solutions

Reference No.: 4223(67CaI)

Inorg. Chem., 1967, 6, 1994 - 1998; Carroll RL; Irani RR; On the Acidity of Substituted Methylendiphosphonates and Their Interaction with Alkali Metal Ions

Reference No.: 4399(94BCS)

J. Solution Chem., 1994, 23, 569 - 577; Buschmann H-J; Cleve E; Schollmeyer E; The Complexation of Alkaline Cations by Crown Ethers and Cryptands in Acetone

Reference No.: 4607(75Smi)

J. Inorg. Nucl. Chem., 1975, 37, 318 - 319; Smied R; Proton and Alkali Metal Complexes of Triphosphate(IV,III,IV) Anion (P308-5)

Reference No.: 4763(84CVR)

J. Chem. Soc., Faraday Trans. 1, 1984, 80, 3275 - 3284; Cox BG; van Truong Ng.; Rzeszutarska J; Schneider H; Stability Constants of Complexes of Monensin and Lasalocid with Alkali-metal and Alkaline-earth-metal Ions in Protic and Polar Aprotic Solvents

Reference No.: 4773(85ChK)

J. Solution Chem., 1985, 14, 1 - 12; Chantooni MK Jr; Kolthoff IM; Relation between Stability Constants of Metal Ion Cryptates in Two Solvents and the Transfer Activity Coefficients of the Metal Ions

Reference No.: 4777(78HoP)

J. Solution Chem., 1978, 7, 357 - 372; Hoogerheide JG; Popov AI; Study of Monensin Complexes with Monovalent Metal Ions in Anhydrous Methanol Solutions

Reference No.: 4782(77HoP)

J. Solution Chem., 1977, 6, 299 - 307; Hourdakis A; Popov AI; Lithium-7, Sodium-23, and Cesium-133 NMR and Far Infrared Study of Alkali Complexes with C222-Dilactam in Various Solvents

Reference No.: 4796(87DSG)

J. Chem. Soc., Faraday Trans. 1, 1987, 83, 2663 - 2670; Danil de Namor AF; Salazar FF; Greenwood P; Complexation and Transfer Free Energies of Metal-ion Dibenzo cryptates

Reference No.: 4798(86DGH)

J. Chem. Soc., Faraday Trans. 1, 1986, 82, 349 - 357; Danil de Namor AF; Ghousseini L; Hill T; Alkali-metal Cryptates in Nitromethane

Reference No.: 4799(85DGL)

J. Chem. Soc., Faraday Trans. 1, 1985, 81, 2495 - 2502; Danil de Namor AF; Ghousseini L; Lee WH; Stability Constants and Free Energies of Complexation of Metal-ion Cryptates in Nitromethane

Reference No.: 4801(85DaG)

J. Chem. Soc., Faraday Trans. 1, 1985, 81, 781 - 791; Danil de Namor AF; Ghousseini L; Enthalpies and Entropies of Complexation of Cryptand 222 and Metal Ions in Propylene Carbonate and Acetonitrile

Reference No.: 4820(80HoN)

J. Phys. Chem., 1980, 84, 309 - 314; Hopkins HP Jr; Norman AB; Conductance and Infrared Studies on Acetonitrile Solutions Containing Crown Ethers and Alkali Metal Salts

Reference No.: 4821(80CKS)

J. Phys. Chem., 1980, 84, 320 - 323; Cox BG; Knop D; Schneider H; Thermodynamics and Kinetics of Alkali Metal Ion Complexes with 5,6-Benzo-4,7,13,16,21,24-hexaoxa-1,10-diazabicyclo[8.8.8] hexacosane in Methanol

Reference No.: 4822(80CGS)

J. Phys. Chem., 1980, 84, 3178 - 3183; Cox BG; Garcia-Rosas J; Schneider H; Kinetics and Equilibria of Cryptate Formation in Propylene Carbonate

Reference No.: 4832(76FlG)

J. Phys. Chem., 1976, 80, 679 - 685; Flora HB; Gilkerson WR; Association of Triethanolamine and Related Ligands with Alkali Metal Ions and Ion Pairs in Tetrahydrofuran at 25 C

Reference No.: 4861(76KlO)

J. Chem. Soc., Faraday Trans. 1, 1976, 72, 513 - 525; Klaning UK; Osterby O; Hydration and Ion Pairing of Maleinates, Malonates, and Substituted Malonates in Aqueous Solution

Reference No.: 5078(54GiM)

Trans. Faraday Soc., 1954, 50, 965 - 972; Gimblett FGR; Monk CB; EMF Studies of Electrolytic Dissociation Part 7. Some Alkali and Alkaline Earth Metal Hydroxides in Water

Reference No.: 5315(94LuL)

J. Chem. Soc., Dalton Trans., 1994,, 423 - 427; Lucas JB; Lincoln SF; Monovalent Metal-ion Complexation by a Bibracchial Lariat Ether in Several Solvents

Reference No.: 5326(86DDS)

J. Chem. Res. (M), 1986,, 1301 - 1347; De Robertis A; De Stefano C; Sammartano S; Cali R; Purrello R; Rigano C; Alkali-metal and Alkali-earth-metal Ion Complexes with Adenosine 5'-Triphosphate in Aqueous Solution. Thermodynamic Parameters and their Dependence on Temperature and Ionic Strength

Reference No.: 5390(95Woo)

Thesis, Univ. Cape Town, 1995 Woolard C; A Computer Simulation of the Trace Metal Speciation in Seawater; Univ. Cape Town, South Africa

Reference No.: 5398(82Hog)

IUPAC Chemical Data Series No. 21, 1982 Hogfeldt E; Stability Constants of Metal-ion Complexes, 2nd Suppl., Part A, Inorganic Ligands; Pergamon, Oxford

Reference No.: 5490(90Par)

ACS Symp. Ser., 1990, 416, 30 - 43; Parkhurst DL; Ion-Association Models and Mean Activity Coefficients of Various Salts

Reference No.: 5583(75Rea)

J. Phys. Chem., 1975, 79, 422 - 425; Reardon EJ; Dissociation Constants of some Monovalent Sulfate Ion Pairs at 25C from Stoichiometric Activity Coefficients

Reference No.: 5605(78CDH)

J. Chem. Thermodyn., 1978, 10, 903 - 906; Cox JD; Drowart J; Heppler LG; Medvedev VA; Wagman DD; CODATA recommended Key Values for Thermodynamics, 1977. Report of the CODATA Task Group on Key Values for Thermodynamics, 1977

Reference No.: 5648(72MoO)

Ions in Aqueous Systems, 1972 Moller T; O'Connor R; An Introduction to Chemical Equilibrium and Solution Chemistry; McGraw-Hill Book Co., N.Y.

Reference No.: 5674(74DeF)

Biochemistry, 1974, 13, 5022 - 5032; Degani H; Friedman HL; Ion Binding by X-537A. Formulas, Formation Constants, and Spectra of Complexes

Reference No.: 5699(52Fyf)

J. Chem. Soc., 1952,, 2023 - 2027; Fyfe WS; Complex-ion Formation. Part II. The Entropies of Formation of Some Metal Ammines

Reference No.: 5722(94GGL)

J. Chem. Soc., Faraday Trans., 1994, 90, 315 - 320; Gans P; Gill JB; Longdon PJ; Spectrochemistry of Solutions. Part 26. Alkali-metal and Alkaline-earth-metal Thiocyanates in Dimethylformamide and Acetonitrile Solutions: Hot Bands, Stability Constants and Thermicity for the Formation of Inner- and Outer-sphere Ion Pairs

Reference No.: 5756(74HPP)

J. Solution Chem., 1974, 3, 563 - 583; Hanna EM; Pethybridge AD; Prue JE; Spiers DJ; Electrolyte Conductivity of Salts in Hexamethylphosphotriamide

Reference No.: 5757(79HRB)

J. Solution Chem., 1979, 8, 779 - 792; Hoiland H; Ringseth JA; Brun TS; Cation-Crown Ether Complex Formation in Water. II. Alkali and Alkaline Earth Cations and 12-Crown-4, 15-Crown-5, and 18-Crown-6

Reference No.: 5765(72SOT)

J. Inorg. Nucl. Chem., 1972, 34, 625 - 636; Sawada K; Ohtaki H; Tanaka M; Equilibria of Copper(II) Acetate with Perchloric Acid and Lithium Acetate in Acetic Acid

Reference No.: 5942(90NNT)

Inorg. Chem., 1990, 29, 147 - 149; Nakasuka N; Natsume Y; Tanaka M; Complexation of Lithium and Sodium Ions with o-Phenylenediaminetetraacetate in Aqueous Solutions

Reference No.: 5969(92CSA)

J. Am. Chem. Soc., 1992, 114, 444 - 451; Chen Z; Schall OF; Alcala M; Li YJ; Gokel GW; Echegoyen L; Unusual 1:2 Ligand:Metal Complex Formation between an Anthraquinone Cryptand and Li⁺

Reference No.: 6146(92CDL)

Ann. Chim. (Rome), 1992, 82, 13 - 21; Casale A; De Robertis A; Licastro F; Studies on Polyfunctional O-Ligands, Alkali Metal Complexes of 2,3-Dihydroxybenzoic Acid in Aqueous Solution

Reference No.: 6330(95LiF)

CRC Handbook of Chemistry and Physics, 76th Edn., 1995 Lide DR; Frederikse HPR; A Ready-Reference Book of Chemical and Physical Data; CRC Press, Cleveland, Ohio, U.S.A.

Reference No.: 6422(95BaP)

Thermochemical Data of Pure Substances, 3rd Edn., 1995 Barin I; Platzki G; Weinheim, Germany

Reference No.: 6478(81BaM)

Am. J. Sci., 1981, 281, 935 - 962; Baes CF Jr; Mesmer RE; The Thermodynamics of Cation Hydrolysis

Reference No.: 6488(88ShH)

Geochim. Cosmochim. Acta, 1988, 52, 2009 - 2036; Shock EL; Helgeson HC; Calculation of the Thermodynamic and Transport Properties of Aqueous Species at High Pressures and Temperatures: Correlation Algorithms for Ionic Species and Equation of State Predictions to 5 kb and 1000 C

Reference No.: 6494(95RoH)

U.S. Geol. Surv. Bull. 2131, 1995 Robie RA; Hemingway BS; Thermodynamic Properties of Minerals and Related Substances at 298.15 K and 1 Bar (10⁵ Pascals) Pressure and at Higher Temperatures; U.S. Government Printing Office, Washington, U.S.A

Reference No.: 6495(97SSH)

Geochim. Cosmochim. Acta, 1997, 61, 1359 - 1412; Sverjensky DA; Shock EL; Helgeson HC; Prediction of the Thermodynamic Properties of Aqueous Metal Complexes to 1000C and 5kb

Reference No.: 6496(96StM)

Aquatic Chemistry, 3rd Edn., 1996 Stumm W; Morgan JJ; Chemical Equilibria and Rates in Natural Waters; John Wiley & Sons, Inc., New York

Reference No.: 6509(71Fre)

J. Am. Chem. Soc., 1971, 93, 600 - 606; Frensdorff HK; Stability Constants of Cyclic Polyether Complexes with Univalent Cations

Reference No.: 6571(93MaA)

J. Solution Chem., 1993, 22, 859 - 872; Manohar S; Atkinson G; The Effect of High Pressure on the Ion Pair Equilibrium Constant of Alkali Metal Fluorides: A Spectrophotometric Study

Reference No.: 6797(83DRS)

Thermochim. Acta, 1983, 62, 101 - 112; Daniele PG; Rigano C; Sammartano S; The Formation of Proton and Alkali Metal Complexes with Ligands of Biological Interest in Aqueous Solution. Thermodynamics of Li+1, Na+1 and K+1-Dicarboxylate Complex Formation

Reference No.: 6922(81SAS)

Inorg. Nucl. Chem. Lett., 1981, 17, 253 - 256; Spiess B; Arnaud-Neu F; Schwing-Weill M-J; Complexation of Some Monovalent Cations by Diazapolyoxamacrocycles in PC and DMSO

Reference No.: 7242(68Tru)

J. Geol. Educ., 1968, 16, 17 - 20; Truesdell AH; The Advantage of Using pE Rather than Eh in Redox Equilibrium Calculations

Reference No.: 7271(98SMM)

NIST Critical Stability Constants of Metal Complexes Database, 1998 Smith RM; Martell AE; Motekaitis RJ; Version 5.0; U.S. Dept. Commerce, Gaithersburg, MD, U.S.A.

Reference No.: 7273(84HiJ)

Dictionary of Electrochemistry, 2nd Edn., 1984 Hibbert DB; James AM; Macmillan Press, London, U.K.

Reference No.: 7275(98Atk)

Physical Chemistry, 6th Edn., 1998 Atkins PW; Oxford University Press, Oxford, U.K.

Reference No.: 7276(88CoW)

Advanced Inorganic Chemistry, 5th Edn., 1988 Cotton FA; Wilkinson G; John Wiley & Sons Inc., N.Y., U.S.A

Reference No.: 7372(78BDJ)

Vogel's Textbook of Quantitative Inorganic Analysis, 1978 Bassett J; Denney RC; Jeffery GH; Mendham J; including Elementary Instrumental Analysis; Longman, London, U.K.

Reference No.: 7381(97Woo)

Physical Chemistry, 1997 Woodbury G; Brooks/Cole Publishing Co., Pacific Grove, U.S.A.

Reference No.: 7391(82MiS)

Am. J. Sci., 1982, 282, 1508 - 1540; Millero FJ; Schreiber DR; Use of the Ion Pairing Model to Estimate Activity Coefficients of the Ionic Components of Natural Waters

Reference No.: 7421(97Mar)

Ion Properties, 1997 Marcus Y; Marcel Dekker Inc., New York, U.S.A.

Reference No.: 7761(89Bra)

J. Phys. Chem. Ref. Data, 1989, 18, 1 - 21; Bratsch SG; Standard Electrode Potentials and Temperature Coefficients in Water at 298.15 K

Reference No.: 8315(57LaW)

J. Am. Chem. Soc., 1957, 79, 4262 - 4265; Lambert SM; Watters JI; The Complexes of Pyrophosphate Ion with Alkali Metal Ions

Reference No.: 8746(89CWM)

CODATA Key Values for Thermodynamics, 1989 Cox JD; Wagman DD; Medvedev VA; Values obtained from www.codata.org/codata/databases Apr. 2000 and <http://www.codata.org/resources/databases/key1.html> Sept. 2011; Hemisphere Publishing Corp., N.Y., U.S.A.

Reference No.: 8875(81HKF)

Am. J. Sci., 1981, 281, 1249 - 1516; Helgeson HC; Kirkham DH; Flowers GC; Theoretical Prediction of the Thermodynamic Behavior of Aqueous Electrolytes at High Pressures and

Temperatures. IV. Calculation of Activity Coefficients, Osmotic Coefficients and Apparent Molal and Standard and Relative Partial Molal Properties to 600 C and 5 Kb

Reference No.: 8888(93ShK)

Geochim. Cosmochim. Acta, 1993, 57, 4899 - 4922; Shock EL; Koretsky CM; Metal-organic Complexes in Geochemical Processes: Calculation of Standard Partial Molal Thermodynamic Properties of Aqueous Acetate Complexes at High Pressures and Temperatures

Reference No.: 9029(97SSW)

Geochim. Cosmochim. Acta, 1997, 61, 907 - 950; Shock EL; Sassani DC; Willis M; Sverjensky DA; Inorganic Species in Geologic Fluids: Correlations among Standard Molal Thermodynamic Properties of Aqueous Ions and Hydroxide Complexes

Reference No.: 9162(97YSW)

J. Chem. Thermodyn., 1997, 29, 1343 - 1351; Yang J-Z; Song P-S; Wang D-B; Thermodynamics of Aqueous Borates III. The Standard Association Constant of the Ion Pair $\text{Li}+\text{B}(\text{OH})_4^-$

Reference No.: 9361(84WCB)

Am. J. Sci., 1984, 284, 668 - 705; Wood SA; Crerar DA; Brantley SL; Borcsik M; Mean Molal Stoichiometric Activity Coefficients of Alkali Halides and Related Electrolytes in Hydrothermal Solutions

Reference No.: 10174(95OHS)

J. Phys. Chem. Ref. Data, 1995, 24, 1401 - 1560; Oelkers EH; Helgeson HC; Shock EL; Sverjensky DA; Johnson JW; Pokrovskii VA; Summary of the Apparent Standard Partial Molal Gibbs Free Energies of Formation of Aqueous Species, Minerals, and Gases at Pressures 1 to 5000 Bars and Temperatures 25 to 1000C

Reference No.: 11516(00PeP)

IUPAC Stability Constants Database, 2000 Pettit LD; Powell HKJ; Release 4; Academic Software, U.K.

Reference No.: 11989(58HaO)

The Physical Chemistry of Electrolytic Solutions, 3rd Edn., 1958 Harned HS; Owen BB; American Chemical Society Monograph Series No: 137; Reinhold Publishing Corp., N.Y.

Reference No.: 12007(78SiP)

J. Solution Chem., 1978, 7, 327 - 337; Silvester LF; Pitzer KS; Thermodynamics of Electrolytes. 10. Enthalpy and the Effect of Temperature on the Activity Coefficients

Reference No.: 12547(98SBB)

J. Phys. Chem., 1998, B102, 4411 - 4417; Simonin J-P; Bernard O; Blum L; Real Ionic Solutions in the Mean Spherical Approximation. 3. Osmotic and Activity Coefficients for Associating Electrolytes in the Primitive Model

Reference No.: 12638(99TPG)

GAMSPATH Users Manual, 1999 Talman SJ; Perkins EH; Gunter WD; A Reaction Path - Mass Transfer Program

Reference No.: 12931(01SPG)

Chem. Geol., 2001, 171, 173 - 194; Seby F; Potin-Gautier M; Giffaut E; Borge G; Donard OFX; A Critical Review of Thermodynamic Data for Selenium Species at 25C

Reference No.: 12955(00CVI)

J. Chem. Thermodyn., 2000, 32, 1505 - 1512; Christov C; Velikova S; Ivanova Khr.R; Study of $(m_1\text{LiX} + m_2\text{CaX}_2)(\text{aq})$ where m_i Denotes Molality and X Denotes Cl, or Br at the Temperature 298.15 K

Reference No.: 13213(61Mac)

The Principles of Electrochemistry, 1961 MacInnes DA; Dover Publications, New York

Reference No.: 13242(05AAD)

Pure Appl. Chem., 2005, 77, 1445 - 1495; Anderegg G; Arnaud-Neu F; Delgado R; Felcman J; Popov K; Critical Evaluation of Stability Constants of Metal Complexes of Complexones for Biomedical and Environmental Applications

Reference No.: 13297(03ADC)

Pure Appl. Chem., 2003, 75, 71 - 102; Arnaud-Neu F; Delgado R; Chaves S; Critical Evaluation of Stability Constants and Thermodynamic Functions of Metal Complexes of Crown-ethers

Reference No.: 14257(79CCF)

J. Solution Chem., 1979, 8, 897 - 908; Corti H; Crovetto R; Fernandez-Prini R; Aqueous Solutions of Lithium Hydroxide at Various Temperatures: Conductivity and Activity Coefficients

Reference No.: 14764(64StS)

Solubilities of Inorganic and Organic Compounds, Vol. 2, Part 2, 1964 Stephen H; Stephen T; Ternary and Multicomponent Systems, Part 2; Pergamon Press, The Macmillan Company, New York, 1964

Reference No.: 16235(77PeS)

J. Chem. Soc., Faraday Trans. 1, 1977, 73, 768 - 775; Pethybridge AD; Spiers DJ; Conductance of some Alkali Metal Halides in Dilute Aqueous Solution at 25C

Reference No.: 17594(01KoK)

Pure Appl. Chem., 2001, 73, 785 - 797; Konigsberger E; Konigsberger L-C; Thermodynamic Modeling of Crystal Deposition in Humans

Reference No.: 20827(03GFF)

OECD Chemical Thermodynamics Series, Volume 5, 2003 Guillaumont R; Fanghanel T; Fuger J; Grenthe I; Neck V; Palmer DA; Rand MH; Update on the Chemical Thermodynamics of Uranium, Neptunium, Plutonium, Americium and Technetium; Elsevier Science

Reference No.: 21773(60BiH)

J. Phys. Chem., 1960, 64, 686 - 687; Birky MM; Hepler LG; Thermochemistry of some Perchlorates and Aqueous Perchlorate Ion

Reference No.: 22551(06Inz)

Encyclopedia of Electrochemistry, Vol. 7a, 2006, 17 - 75; Inzelt G; Standard, Formal and Other Characteristic Potentials of Selected Electrode Reactions

Reference No.: 22958(10AML)

Appl. Geochem., 2010, 25, 242 - 260; Accornero M; Marini L; Lelli M; Prediction of the Thermodynamic Properties of Metal-chromate Aqueous Complexes to High Temperatures and Pressures and Implications for the Speciation of Hexavalent Chromium in Some Natural Waters

Reference No.: 24003(10Bal)

Collect. Czech. Chem. Commun., 2010, 75, 21 - 31; Balej J; Verification of Accuracy of Standard Thermodynamic Data of Inorganic Substances

Reference No.: 27292(13LBM)

OECD Chemical Thermodynamics Series, Volume 13a, 2013 Lemire RJ; Berner U; Musikas C; Palmer DA; Taylor P; Tochiyama O; Chemical Thermodynamics of Iron Part 1; OECD (NEA) Issy-les-Moulineaux, France

Reference No.: 28172(15DCC)

J. Chem. Eng. Data, 2015, 60, 3792 - 3799; Djamali E; Chapman WG; Cox KR; Prediction of the Standard State Partial Molar Volume of Aqueous Electrolytes to High Temperatures and High Pressures

Reference No.: 28992(71NRK)

Handbook of Thermodynamic Data, 1971 Naumov GB; Ryzhenko BN; Khodakovskiy IL; Translated by G.J. Soleimani and edited by I. Barnes & V. Speltz (U.S. Geological Survey); U.S. National Technical Information Service, Springfield VA

Reference No.: 29025(14ThL)

Desalination, 2014, 346, 54 - 69; Thiel GP; Lienhard JH V; Treating Produced Water from Hydraulic Fracturing: Composition Effects on Scale Formation and Desalination System Selection

Reference No.: 29520(17WoC)

Geochim. Cosmochim. Acta, 2017, 213, 635 - 676; Wolery TJ; Colon CFJ; Chemical Thermodynamic Data. 1. The Concept of Links to The Chemical Elements and the Historical Development of Key Thermodynamic Data

Reference No.: 29937(17FAZ)

Ind. Eng. Chem. Res., 2017, 56, 8121 - 8132; Ferguson JP; Arcis H; Zimmerman GH; Tremaine PR; Ion-Pair Formation Constants of Lithium Borate and Lithium Hydroxide under Pressurized Water Nuclear Reactor Coolant Conditions

Reference No.: 29947(18LZY)

Calphad, 2018, 60, 163 - 176; Li D; Zeng D; Yin X; Gao D; Phase Diagrams and Thermochemical Modeling of Salt Lake Brine Systems. III. $\text{Li}_2\text{SO}_4+\text{H}_2\text{O}$, $\text{Na}_2\text{SO}_4+\text{H}_2\text{O}$, $\text{K}_2\text{SO}_4+\text{H}_2\text{O}$, $\text{MgSO}_4+\text{H}_2\text{O}$, and $\text{CaSO}_4+\text{H}_2\text{O}$ Systems

Reference No.: 30015(16KAK)

Fluid Phase Equilib., 2016, 412, 177 - 198; Kim SH; Anantpinijwatna A; Kang JW; Gani R; Analysis and Modeling of Alkali Halide Aqueous Solutions

Reference No.: 30153(17LAZ)

Geol. Ore Deposits, 2017, 59, 305 - 318; Lukyanova EV; Akinfiev NN; Zotov AV; Rass IT; Kotova NP; Korzhinskaya VS; Niobium in Hydrothermal Systems Related to Alkali Granites: Thermodynamic Description of Hydroxo and Hydroxofluoride Complexes

Reference No.: 31224(64SHW)

J. Phys. Chem., 1964, 68, 1427 - 1429; Stephenson CC; Hopkins HP Jr; Wulff CA; The Standard Entropies of the Aqueous Lithium and Fluoride Ions and the Heat of Solution of Lithium Fluoride

Reference No.: 31291(84PSG)

U.S. Bur. Mines Bull. 677, 1984 Pankratz LB; Stuve JM; Gokcen NA; Thermodynamic Data for Mineral Technology; US Det. Interior, Bur. Mines, Washington, DC, USA

Reference No.: 31315(18WWZ)

J. Chem. Thermodyn., 2018, 123, 62 - 73; Wang J; Wu X; Zhang S; Development of a Thermodynamic Model for the $\text{Li}_2\text{CO}_3\text{-NaCl-Na}_2\text{SO}_4\text{-H}_2\text{O}$ System and its Application

Reference No.: 32152(20AAG)

Chem. Geol., 2020, 550, 119699-1 - 119699-12; Aranovich LYa; Akinfiev NN; Golunova M; Quartz Solubility in Sodium Carbonate Solutions at High Pressure and Temperature