

JESS Thermodynamic Database v8.9

Magnesium

24-Jan-23

Reaction No. 329							
Mg+2 + OH-1 = Mg+2_OH-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:2.19 (3SF)	0	EDT	5416
2	15	0	Inf. Dilution	lgK:2.53 (3SF)	0	EOD	29579
3	20	0	Inf. Dilution	lgK:2.56 (3SF)	0	EOD	29579
4	25	0	Inf. Dilution	lgK:2.35 (3SF)	1	ELC	
5	25	0	Inf. Dilution	lgK:2.6 (0.05SD)	0	CMN	22
6	25	0	Inf. Dilution	lgK:2.585 (4SF)	0	ENS	4852
7	25	0	Inf. Dilution	lgK:2.20 (3SF)	0	EDT	5416
8	25	0	Inf. Dilution	lgK:2.6 (2SF)	0	CRV	6405
9	25	0	Inf. Dilution	lgK:2.2 (0.2SD)	0	CMN	7391
10	25	0	Inf. Dilution	lgK:2.19 (3SF)	0	CRV	8749
11	25	0	Inf. Dilution	lgK:2.6 (2SF)	3	EOD	16981
12	25	0	Inf. Dilution	lgK:2.59 (3SF)	0	EOD	29579
13	25	0	SOLMNEQ	lgK:2.60 (3SF)	0	CMN	5416
14	25	0	SOLVEQ	lgK:2.19 (3SF)	0	CMN	5416
15	25	0	WATCH	lgK:2.20 (3SF)	0	CMN	5416
16	25	0	WATEQF	lgK:2.20 (3SF)	0	CMN	5416
17	25	0.2	NaCl	lgK:3.1 (0.04SD)	0	MGL	5217
18	25	0.7	Unknown	lgK:1.7 (0.05SD)	0	CMN	7391
19	25	0.7	Unknown	lgK:1.58 (3SF)	0	ENS	7391
20	25	3	NaCl	lgK:1.7 (2SF)	0	CRV	2556
21	25	3	NaClO4	lgK:2.2 (2SF)	0	CRV	2556
22	30	0	Inf. Dilution	lgK:2.62 (3SF)	0	EOD	29579
23	35	0	Inf. Dilution	lgK:2.24 (3SF)	0	CRV	8749
24	35	0	Inf. Dilution	lgK:2.65 (3SF)	0	EOD	29579
25	37	0	Inf. Dilution	lgK:3.16 (3SF)	0	CRV	28703
26	37	0.15	Unknown	lgK:1.9 (2SF)	0	CRV	2556
27	40	0	Inf. Dilution	lgK:2.31 (3SF)	0	EDT	5416
28	50	0	SOLMNEQ	lgK:2.70 (3SF)	0	CMN	5416

29	50	0	SOLVEQ	lgK:2.56 (3SF)	0	CMN	5416
30	50	0	WATCH	lgK:2.34 (3SF)	0	CMN	5416
31	50	0	WATEQF	lgK:2.33 (3SF)	0	CMN	5416
32	55	0	Inf. Dilution	lgK:2.38 (3SF)	0	EDT	5416
33	55	0	Inf. Dilution	lgK:2.32 (3SF)	0	CRV	8749
34	70	0	Inf. Dilution	lgK:2.47 (3SF)	0	EDT	5416
35	75	0	SOLMNEQ	lgK:2.90 (3SF)	0	CMN	5416
36	75	0	WATCH	lgK:2.47 (3SF)	0	CMN	5416
37	75	0	WATEQF	lgK:2.46 (3SF)	0	CMN	5416
38	90	0	Inf. Dilution	lgK:2.55 (3SF)	0	EDT	5416
39	100	0	SOLMNEQ	lgK:3.10 (3SF)	0	CMN	5416
40	100	0	SOLVEQ	lgK:2.90 (3SF)	0	CMN	5416
41	100	0	WATCH	lgK:2.59 (3SF)	0	CMN	5416
42	100	0	WATEQF	lgK:2.59 (3SF)	0	CMN	5416
43	100	3	Unknown	lgK:2.9 (2SF)	0	ELC	
44	125	0	SOLMNEQ	lgK:3.33 (3SF)	0	CMN	5416
45	125	0	WATCH	lgK:2.73 (3SF)	0	CMN	5416
46	125	0	WATEQF	lgK:2.71 (3SF)	0	CMN	5416
47	150	0	SOLMNEQ	lgK:3.60 (3SF)	0	CMN	5416
48	150	0	SOLVEQ	lgK:3.54 (3SF)	0	CMN	5416
49	150	0	WATCH	lgK:2.90 (3SF)	0	CMN	5416
50	150	0	WATEQF	lgK:2.84 (3SF)	0	CMN	5416
51	175	0	SOLMNEQ	lgK:3.85 (3SF)	0	CMN	5416
52	175	0	WATCH	lgK:3.10 (3SF)	0	CMN	5416
53	175	0	WATEQF	lgK:2.97 (3SF)	0	CMN	5416
54	200	0	SOLMNEQ	lgK:4.10 (3SF)	0	CMN	5416
55	200	0	SOLVEQ	lgK:4.07 (3SF)	0	CMN	5416
56	200	0	WATCH	lgK:3.34 (3SF)	0	CMN	5416
57	200	0	WATEQF	lgK:3.10 (3SF)	0	CMN	5416
58	225	0	SOLMNEQ	lgK:4.38 (3SF)	0	CMN	5416
59	225	0	WATCH	lgK:3.63 (3SF)	0	CMN	5416
60	225	0	WATEQF	lgK:3.22 (3SF)	0	CMN	5416
61	250	0	SOLMNEQ	lgK:4.65 (3SF)	0	CMN	5416
62	250	0	SOLVEQ	lgK:4.84 (3SF)	0	CMN	5416
63	250	0	WATCH	lgK:3.97 (3SF)	0	CMN	5416
64	250	0	WATEQF	lgK:3.35 (3SF)	0	CMN	5416

65	275	0	SOLMNEQ	lgK:4.90 (3SF)	0	CMN	5416
66	275	0	WATCH	lgK:4.37 (3SF)	0	CMN	5416
67	275	0	WATEQF	lgK:3.48 (3SF)	0	CMN	5416
68	300	0	SOLMNEQ	lgK:5.15 (3SF)	0	CMN	5416
69	300	0	SOLVEQ	lgK:5.96 (3SF)	0	CMN	5416
70	300	0	WATCH	lgK:4.82 (3SF)	0	CMN	5416
71	300	0	WATEQF	lgK:3.61 (3SF)	0	CMN	5416
72	325	0	SOLMNEQ	lgK:5.41 (3SF)	0	CMN	5416
73	325	0	WATCH	lgK:5.34 (3SF)	0	CMN	5416
74	325	0	WATEQF	lgK:3.73 (3SF)	0	CMN	5416
75	350	0	SOLMNEQ	lgK:5.70 (3SF)	0	CMN	5416
76	350	0	WATCH	lgK:5.91 (3SF)	0	CMN	5416
77	350	0	WATEQF	lgK:3.85 (3SF)	0	CMN	5416
78	10:90	0	Inf. Dilution	dH:3. (1SF)	1	CRV	552
79	25	0.1	KNO3	dH:2.8 (0.1SD)	1	ESR	3215

Reaction No. 331							
Mg+2 + 2<OH-1> = Mg+2_OH-1 (2)_ (s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:10.88 (4SF)	5	MSL	30743
2	10	0	Inf. Dilution	lgK:10.86 (4SF)	3	MSL	30743
3	20	0	Inf. Dilution	lgK:10.87 (4SF)	2	MSL	30743
4	25	0	Inf. Dilution	lgK:11.0 (3SF)	1	ELC	
5	25	0	Inf. Dilution	lgK:10.74 (4SF)	0	CRV	
Note (5): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
6	25	0	Inf. Dilution	lgK:11.2 (0.05SD)	0	MGL	4998
7	25	0	Inf. Dilution	lgK:11.25 (4SF)	0	CRV	6330
Note (7): p. 8-58							
8	25	0	Inf. Dilution	lgK:11.16 (4SF)	0	ENS	6405
9	25	0	Inf. Dilution	lgK:11.1 (3SF)	0	CRV	6405
10	25	0	Inf. Dilution	lgK:10.47 (4SF)	0	ENS	7694
11	25	0	Inf. Dilution	lgK:9.2 (2SF)	2	EOD	16981
12	25	0	Inf. Dilution	lgK:10.82 (4SF)	0	CRV	22551
13	25	0	Inf. Dilution	lgK:11.17 (4SF)	2	CRV	28992
14	25	0	Inf. Dilution	lgK:9.2 (2SF)	0	EOD	29070
15	25	0	Inf. Dilution	lgK:10.88 (4SF)	0	MSL	30743

16	25	1	NaNO3	lgK:9.38(0.10SD)w	0	MPH	4603
Note (16): EBP -> Mg+2 + 2<H2O> = Mg+2_OH-1(2)_(s) + 2<H+1>							
17	25	1	Unknown	lgK:10.25(4SF)	0	CMN	773
18	25	3	NaClO4	lgK:11.14(4SF)	0	CRV	552
19	25	3	NaClO4	lgK:11.9(0.05SD)	0	ENS	5520
Note (19): EBP -> Mg+2 + 2<H2O> = Mg+2_OH-1(2)_(s) + 2<H+1>							
20	30	0	Inf. Dilution	lgK:10.89(4SF)	3	MSL	30743
21	40	0	Inf. Dilution	lgK:10.92(4SF)	5	MSL	30743
22	50	0	Inf. Dilution	lgK:11.14(4SF)	4	CRV	28992
23	50	0	Inf. Dilution	lgK:10.98(4SF)	5	MSL	30743
24	60	0	Inf. Dilution	lgK:11.04(4SF)	5	MSL	30743
25	70	0	Inf. Dilution	lgK:11.11(4SF)	5	MSL	30743
26	80	0	Inf. Dilution	lgK:11.20(4SF)	5	MSL	30743
27	90	0	Inf. Dilution	lgK:11.29(4SF)	5	MSL	30743
28	100	0	Inf. Dilution	lgK:11.39(4SF)	4	CRV	28992
29	100	0	Inf. Dilution	lgK:11.38(4SF)	5	MSL	30743
30	120	0	Inf. Dilution	lgK:11.60(4SF)	5	MSL	30743
31	140	0	Inf. Dilution	lgK:11.85(4SF)	5	MSL	30743
32	150	0	Inf. Dilution	lgK:11.88(4SF)	4	CRV	28992
33	150	0	Inf. Dilution	lgK:11.98(4SF)	5	MSL	30743
34	160	0	Inf. Dilution	lgK:12.12(4SF)	5	MSL	30743
35	180	0	Inf. Dilution	lgK:12.40(4SF)	5	MSL	30743
36	200	0	Inf. Dilution	lgK:12.49(4SF)	4	CRV	28992
37	200	0	Inf. Dilution	lgK:12.69(4SF)	5	MSL	30743

Reaction No. 332							
4<Mg+2> + 4<H2O> = Mg+2(4)_OH-1(4) + 4<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-39.66(4SF)	4	CRV	32224
2	25	0	CHEMVAL1	lgK:-39.66(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:-39.66(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:-39.66(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:-40.30(0.01SD)	0	ENS	5156
6	25	0	UCT_Sea	lgK:-39.71(0.01SD)	3	EDH	5390
7	25	0.1	UCT_Sea	lgK:-39.26(0.01SD)	2	EDH	5390
8	25	0.2	UCT_Sea	lgK:-39.17(0.01SD)	2	EDH	5390


9	25	0.3	UCT_Sea	lgK:-39.12(0.01SD)	0	EDH	5390
10	25	0.4	UCT_Sea	lgK:-39.10(0.01SD)	0	EDH	5390
11	25	0.5	UCT_Sea	lgK:-39.09(0.01SD)	2	EDH	5390
12	25	0.6	UCT_Sea	lgK:-39.09(0.01SD)	4	EDH	5390
13	25	0.7	UCT_Sea	lgK:-39.09(0.01SD)	2	EDH	5390
14	25	1.6	MgCl2	lgK:-39.7(0.05SD)	0	ENS	4998
15	37	0.15	Blood Plasma	lgK:-40.0(0.05SD)	4	ENS	94

Reaction No. 333




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-14.6(3SF)	1	EOR	
2	25	3	Unknown	lgK:-12.3(0.2SD)	3	MEF	20
3	100	0	Inf. Dilution	lgK:-12.1(3SF)	1	EOR	

Reaction No. 334



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	2.4	Na2SO4	lgK:0.19(2SF)	5	MPL	5398
2	23	2	NH4NO3	lgK:0.2(0.05SD)	5	MGL	53
3	23	2	NH4NO3	lgK:0.23(2SF)	5	MGL	5646
4	25	0	Inf. Dilution	lgK:0.139(4SF)	1	EOR	
5	25	0	Inf. Dilution	lgK:0.10(2SF)	3	CRV	9402
6	25			lgK:-0.1(1SF)	0	MSL	140

Reaction No. 335



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	2.4	Na2SO4	lgK:-0.13(2SF)	5	MVM	11516
Note (1): Szymaszek A et al., Monatsh. Chem., 1973, 104, 74							
2	23	2	NH4NO3	lgK:-0.2(0.05SD)	5	MGL	53
3	23	2	NH4NO3	lgK:-0.15(2SF)	5	MGL	5646
4	25	0	Inf. Dilution	lgK:-0.175(3SF)	2	EAE	

Reaction No. 336



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	23	2	NH4NO3	lgK:-0.4 (0.05SD)	5	MGL	53
2	23	2	NH4NO3	lgK:-0.42 (2SF)	5	MGL	5646
3	25	0	Inf. Dilution	lgK:-0.41 (3SF)	2	EAE	

Reaction No. 337							
SO4-2 + Mg+2 = Mg+2_SO4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	P=250 Inf. Dilution	lgK:2.211 (4SF)	5	MCN	28080
2	25	0	P=250 Inf. Dilution	lgK:2.268 (4SF)	5	MCN	28080
3	35	0	P=250 Inf. Dilution	lgK:2.318 (4SF)	5	MCN	28080
4	15	0	P=500 Inf. Dilution	lgK:2.175 (4SF)	5	MCN	28080
5	25	0	P=500 Inf. Dilution	lgK:2.237 (4SF)	5	MCN	28080
6	35	0	P=500 Inf. Dilution	lgK:2.289 (4SF)	5	MCN	28080
7	15	0	P=750 Inf. Dilution	lgK:2.143 (4SF)	5	MCN	28080
8	25	0	P=750 Inf. Dilution	lgK:2.208 (4SF)	5	MCN	28080
9	35	0	P=750 Inf. Dilution	lgK:2.264 (4SF)	5	MCN	28080
10	15	0	P=1000 Inf. Dilution	lgK:2.114 (4SF)	5	MCN	28080
11	25	0	P=1000 Inf. Dilution	lgK:2.181 (4SF)	5	MCN	28080
12	35	0	P=1000 Inf. Dilution	lgK:2.237 (4SF)	5	MCN	28080
13	15	0	P=1250 Inf. Dilution	lgK:2.087 (4SF)	5	MCN	28080
14	25	0	P=1250 Inf. Dilution	lgK:2.156 (4SF)	5	MCN	28080
15	35	0	P=1250 Inf. Dilution	lgK:2.216 (4SF)	5	MCN	28080
16	15	0	P=1500 Inf. Dilution	lgK:2.063 (4SF)	5	MCN	28080
17	25	0	P=1500 Inf. Dilution	lgK:2.133 (4SF)	5	MCN	28080
18	35	0	P=1500 Inf. Dilution	lgK:2.195 (4SF)	5	MCN	28080
19	-3			lgK:0.36 (2SF)	0	MFP	140

20	-3			lgK:0.38 (2SF)	0	MFP	140
21	0	0	Inf. Dilution	lgK:2.185 (4SF)	3	MDG	140
22	0	0	Inf. Dilution	lgK:2.19 (3SF)	4	MFP	140
23	0	0	Inf. Dilution	lgK:2.13 (3SF)	4	MSL	931
24	0	0	Inf. Dilution	lgK:2.33 (3SF)	3	EMU	5398
25	0	0	Inf. Dilution	lgK:2.23 (3SF)	4	MCN	8389
26	0	0	Inf. Dilution	lgK:2.01 (3SF)	4	MCN	8390
27	0	0	Inf. Dilution	lgK:1.96 (3SF)	3	MHY	8394
28	0	0	Inf. Dilution	lgK:2.2 (2SF)	5	MFP	8636
29	0	0	Inf. Dilution	lgK:2.33 (3SF)	4	MDG	8675
30	0	0	Inf. Dilution	lgK:2.1 (2SF)	5	MEF	17019
31	0	0	Inf. Dilution	lgK:2.12 (3SF)	4	MPT	18276
32	0	0	Inf. Dilution/m	lgK:2.129 (4SF)	4	MSL	8397
33	0			lgK:0.38 (2SF)	0	MFP	140
34	0			lgK:1.06 (3SF)	0	MFP	140
35	0			lgK:1.56 (3SF)	0	MFP	140
36	1.7	0.66	Seawater/m	lgK:1.18 (0.5SD)	0	MIS	8631
37	1.7	0.66	Unknown	lgK:1.18 (3SF)	4	MIS	5398
38	2			lgK:0.95 (2SF)	0	EES	5398
39	5	0	Inf. Dilution	lgK:2.12 (3SF)	4	MIS	5574
40	5	0	Inf. Dilution	lgK:2.03 (3SF)	4	MCN	8390
41	5	0	Inf. Dilution	lgK:2.160 (4SF)	6	MCN	21442
42	5	0.1	Inert	lgK:1.42 (3SF)	0	MIS	5574
43	5	0.5	Inert	lgK:1.33 (0.05SD)	0	MIS	5574
44	5	1	Inert	lgK:1.36 (3SF)	0	MIS	5574
45	10	0	Inf. Dilution	lgK:2.06 (3SF)	4	MCN	8390
46	10	0	Inf. Dilution	lgK:2.167 (4SF)	6	MCN	21442
47	15	0	Inf. Dilution	lgK:2.20 (3SF)	4	MIS	5574
48	15	0	Inf. Dilution	lgK:2.08 (3SF)	4	MCN	8390
49	15	0	Inf. Dilution	lgK:2.29 (3SF)	4	MPT	18276
50	15	0	Inf. Dilution	lgK:2.172 (4SF)	6	MCN	21442
51	15	0	Inf. Dilution	lgK:2.254 (4SF)	5	MCN	28080
52	15	0	Inf. Dilution/m	lgK:2.16 (3SF)	4	MCN	7397
53	15	0.1	Inert	lgK:1.49 (3SF)	4	MIS	5574
54	15	0.5	Inert	lgK:1.42 (0.05SD)	0	MIS	5574
55	15	1	Inert	lgK:1.50 (3SF)	0	MIS	5574

56	18	0	Inf. Dilution	lgK:2.11(3SF)	4	MCN	140
57	18	0	Inf. Dilution	lgK:2.30(3SF)	4	MCN	140
58	18	0	Inf. Dilution	lgK:2.20(3SF)	4	MCN	8670
59	18	0	Inf. Dilution	lgK:2.21(3SF)	5	MCN	11516
Note (59): Davies C, Trans. Faraday Society, 1927, 23, 351							
60	18	0	Inf. Dilution	lgK:2.11(3SF)	3	MCN	11989
61	20	0	Inf. Dilution	lgK:2.20(3SF)	4	MSC	140
62	20	0	Inf. Dilution	lgK:2.11(3SF)	4	MCN	8390
63	20	0	Inf. Dilution	lgK:2.20(3SF)	4	MHY	8394
64	20	0	Inf. Dilution	lgK:2.32(3SF)	4	MPT	18276
65	20	0	Inf. Dilution	lgK:2.182(4SF)	6	MCN	21442
66	20	0	Inf. Dilution/m	lgK:2.29(3SF)	4	MHY	92
67	20	0	Inf. Dilution/m	lgK:2.22(3SF)	4	MCN	7397
68	20			lgK:0.40(2SF)	4	MGL	8647
69	25	0.51:0.54	Seawater	lgK:1.620(4SF)	0	EDT	5416
70	25	0	Inf. Dilution	lgK:2.20(3SF)	4	MCN	140
71	25	0	Inf. Dilution	lgK:2.21(3SF)	4	MCN	140
72	25	0	Inf. Dilution	lgK:2.27(3SF)	4	MCN	140
73	25	0	Inf. Dilution	lgK:2.25(3SF)	4	MDG	931
74	25	0	Inf. Dilution	lgK:2.40(3SF)	4	MSL	931
75	25	0	Inf. Dilution	lgK:2.22(3SF)	4	MSC	931
76	25	0	Inf. Dilution	lgK:2.21(0.015SD)	4	MCN	4990
77	25	0	Inf. Dilution	lgK:2.38(3SF)	3	EMU	5398
78	25	0	Inf. Dilution	lgK:2.23(3SF)	4	MCL	5398
79	25	0	Inf. Dilution	lgK:2.07(3SF)	4	MCN	5398
80	25	0	Inf. Dilution	lgK:2.24(3SF)	4	MCN	5398
81	25	0	Inf. Dilution	lgK:2.399(4SF)	3	EDT	5416
82	25	0	Inf. Dilution	lgK:2.23(0.02SD)	4	ENS	5574
83	25	0	Inf. Dilution	lgK:2.29(3SF)	4	MIS	5574
84	25	0	Inf. Dilution	lgK:2.36(0.1SD)	5	CMN	5575
85	25	0	Inf. Dilution	lgK:2.37(3SF)	4	ENS	6496
86	25	0	Inf. Dilution	lgK:2.21(0.02SD)	5	CMN	7391
87	25	0	Inf. Dilution	lgK:2.13(3SF)	4	MCN	8390
88	25	0	Inf. Dilution	lgK:2.25(3SF)	4	MHY	8394
89	25	0	Inf. Dilution	lgK:2.23(0.07SD)	4	MCL	8402
90	25	0	Inf. Dilution	lgK:2.22(3SF)	4	MSC	8618

91	25	0	Inf. Dilution	lgK:2.48 (3SF)	4	EMU	8672
92	25	0	Inf. Dilution	lgK:2.38 (3SF)	4	MDG	8675
93	25	0	Inf. Dilution	lgK:2.23 (3SF)	5	CRV	9402
94	25	0	Inf. Dilution	lgK:2.17 (3SF)	5	MCN	11516
Note (94): Inada E et al., Nippon Kagaku Kaishi, 1971, 92, 1096							
95	25	0	Inf. Dilution	lgK:2.20 (3SF)	3	MCN	11989
96	25	0	Inf. Dilution	lgK:2.155 (4SF)	4	EOD	12002
97	25	0	Inf. Dilution	lgK:1.83 (3SF)	2	EMS	12547
98	25	0	Inf. Dilution	lgK:2.12 (3SF)	4	MCN	12632
99	25	0	Inf. Dilution	lgK:2.16 (3SF)	3	CRV	18273
Note (99): Table 3, p. 85							
100	25	0	Inf. Dilution	lgK:2.37 (3SF)	4	MPT	18276
101	25	0	Inf. Dilution	lgK:2.196 (4SF)	6	MCN	21442
102	25	0	Inf. Dilution	lgK:2.21 (0.08SD)	5	EOD	22958
103	25	0	Inf. Dilution	lgK:1.966 (4SF)	0	MCN	23739
104	25	0	Inf. Dilution	lgK:2.302 (4SF)	5	MCN	28080
105	25	0	Inf. Dilution	lgK:2.38 (0.08SD)	5	MSL	30797
106	25	0	Inf. Dilution	lgK:2.23 (3SF)	4	CRV	32224
107	25	0	CHEMVAL1	lgK:2.23 (0.01SD)	0	ENS	5156
108	25	0	CHEMVAL2	lgK:2.23 (0.01SD)	0	ENS	5156
109	25	0	CHEMVAL3	lgK:2.23 (0.01SD)	0	ENS	5156
110	25	0	CHEMVAL4	lgK:2.23 (0.01SD)	5	ENS	5156
111	25	0	CsCl	lgK:2.38 (0.03SD)	4	EDH	9387
112	25	0	Inf. Dilution/m	lgK:2.36 (3SF)	4	MHY	92
113	25	0	Inf. Dilution/m	lgK:2.21 (3SF)	4	MCN	7397
114	25	0	Inf. Dilution/m	lgK:2.399 (4SF)	4	MSL	8397
115	25	0	SOLMNEQ	lgK:2.25 (3SF)	4	CMN	5416
116	25	0	SOLVEQ	lgK:2.40 (3SF)	4	CMN	5416
117	25	0	UCT_Sea	lgK:2.23 (0.01SD)	4	EDH	5390
118	25	0	Unknown	lgK:2.25 (3SF)	3	ENS	7373
119	25	0	WATCH	lgK:2.27 (3SF)	4	CMN	5416
120	25	0	WATEQF	lgK:2.24 (3SF)	4	CMN	5416
121	25	0.1	Inert	lgK:1.58 (3SF)	3	MIS	5574
122	25	0.1	UCT_Sea	lgK:1.46 (0.01SD)	4	EDH	5390
123	25	0.1	Unknown	lgK:1.46 (3SF)	6	CRV	552
124	25	0.1	Unknown	lgK:1.48 (3SF)	5	MIS	8391

125	25	0.2	UCT_Sea	lgK:1.29(0.01SD)	4	EDH	5390
126	25	0.25	CsCl	lgK:1.286(0.0031SD)	4	MIS	9387
127	25	0.3	UCT_Sea	lgK:1.19(0.01SD)	4	EDH	5390
128	25	0.4	UCT_Sea	lgK:1.11(0.01SD)	4	EDH	5390
129	25	0.5	CsCl	lgK:1.017(0.0025SD)	4	MIS	9387
130	25	0.5	Inert	lgK:1.52(0.05SD)	0	MIS	5574
131	25	0.5	UCT_Sea	lgK:1.07(0.01SD)	4	EDH	5390
132	25	0.5	Unknown	lgK:1.1(0.07SD)	6	CRV	552
133	25	0.5	Unknown	lgK:2.47(3SF)	0	MGL	25849
134	25	0.6	NaCl	lgK:1.01(3SF)	3	MPT	8898
135	25	0.6	UCT_Sea	lgK:1.04(0.01SD)	4	EDH	5390
136	25	0.67	Seawater/m	lgK:1.01(3SF)	0	MEF	8640
137	25	0.7	NaCl	lgK:0.79(2SF)	5	MGL	5101
138	25	0.7	NaCl	lgK:1.0(2SF)	3	EES	5398
139	25	0.7	NaCl	lgK:1.09(3SF)	0	MSL	7229
140	25	0.7	Seawater	lgK:0.80(0.05SD)w	0	MPH	5101
141	25	0.7	UCT_Sea	lgK:1.01(0.01SD)	4	EDH	5390
142	25	0.7	Unknown	lgK:1.01(0.02SD)	6	CMN	7391
143	25	0.7	Unknown	lgK:1.09(3SF)	4	ENS	7391
144	25	1	CsCl	lgK:0.750(0.001SD)	7	MIS	9387
145	25	1	Inert	lgK:1.65(3SF)	0	MIS	5574
146	25	1	Me4NC1	lgK:0.977(0.0022SD)	0	MIS	9387
147	25	1	Unknown	lgK:0.80(0.01SD)	6	CRV	552
148	25	2	CsCl	lgK:0.558(0.0022SD)	7	MIS	9387
149	25	4	CsCl	lgK:0.416(0.0017SD)	7	MIS	9387
150	25	6	CsCl	lgK:0.343(0.0033SD)	7	MIS	9387
151	30	0	Inf. Dilution	lgK:2.17(3SF)	4	MCN	8390
152	30	0	Inf. Dilution	lgK:2.35(3SF)	4	MHY	8394
153	30	0	Inf. Dilution	lgK:2.45(3SF)	4	MPT	18276
154	30	0	Inf. Dilution	lgK:2.219(4SF)	6	MCN	21442
155	30	0	Inf. Dilution/m	lgK:2.43(3SF)	4	MHY	92
156	35	0	Inf. Dilution	lgK:2.49(3SF)	4	MHY	92
157	35	0	Inf. Dilution	lgK:2.40(3SF)	4	MIS	5574
158	35	0	Inf. Dilution	lgK:2.18(3SF)	4	MCN	8390
159	35	0	Inf. Dilution	lgK:2.39(3SF)	4	MHY	8394
160	35	0	Inf. Dilution	lgK:2.53(3SF)	4	MPT	18276

161	35	0	Inf. Dilution	lgK:2.249(4SF)	6	MCN	21442
162	35	0	Inf. Dilution	lgK:2.347(4SF)	5	MCN	28080
163	35	0	Inf. Dilution/m	lgK:1.97(3SF)	3	MHG	698
164	35	0.1	Inert	lgK:1.68(3SF)	0	MIS	5574
165	35	0.5	Inert	lgK:1.62(0.05SD)	0	MIS	5574
166	35	1	Inert	lgK:1.81(3SF)	0	MIS	5574
167	37	0	Inf. Dilution	lgK:2.407(4SF)	2	CRV	28703
168	37	0.03	Me4NI	lgK:1.87(0.04MD)	5	MGL	29801
169	37	0.05	Me4NI	lgK:1.76(0.03MD)	5	MGL	29801
170	37	0.085	Unknown	lgK:1.39(3SF)	5	MPS	8626
171	37	0.1	Me4NI	lgK:1.59(0.04MD)	5	MGL	29801
172	37	0.1	Unknown	lgK:1.36(3SF)	5	MPS	8626
173	37	0.15	Blood Plasma	lgK:1.5(0.05SD)	4	ENS	94
174	37	0.15	Unknown	lgK:1.04(3SF)	3	MPS	8626
175	37	0.3	Me4NI	lgK:1.45(0.04MD)	0	MGL	29801
176	37	0.5	Me4NI	lgK:1.45(0.04MD)	0	MGL	29801
177	37			lgK:1.3(2SF)	0	MSP	5398
178	38	0	Inf. Dilution	lgK:2.43(3SF)	3	CRV	8692
179	40	0	Inf. Dilution	lgK:2.22(3SF)	4	MCN	8390
180	40	0	Inf. Dilution	lgK:2.45(3SF)	4	MHY	8394
181	40	0	Inf. Dilution	lgK:2.57(3SF)	4	EMU	8672
182	40	0	Inf. Dilution	lgK:2.59(3SF)	4	MPT	18276
183	45	0	Inf. Dilution	lgK:2.50(3SF)	4	MIS	5574
184	45	0	Inf. Dilution	lgK:2.24(3SF)	4	MCN	8390
185	45	0	Inf. Dilution	lgK:2.49(3SF)	4	MHY	8394
186	45	0.1	Inert	lgK:1.78(3SF)	0	MIS	5574
187	45	0.5	Inert	lgK:1.74(0.05SD)	0	MIS	5574
188	45	1	Inert	lgK:1.98(3SF)	0	MIS	5574
189	50	0	Inf. Dilution	lgK:2.63(3SF)	4	MSL	931
190	50	0	Inf. Dilution	lgK:2.170(4SF)	3	MCN	23739
191	50	0	Inf. Dilution/m	lgK:2.631(4SF)	4	MSL	8397
192	50	0	SOLMNEQ	lgK:2.60(3SF)	4	CMN	5416
193	50	0	SOLVEQ	lgK:2.62(3SF)	4	CMN	5416
194	50	0	WATCH	lgK:2.56(3SF)	4	CMN	5416
195	50	0	WATEQF	lgK:2.50(3SF)	4	CMN	5416
196	60	0	Inf. Dilution	lgK:2.7(2SF)	4	EMU	5398


197	60	0	Inf. Dilution	lgK:2.70 (3SF)	4	EMU	8672
198	75	0	Inf. Dilution	lgK:2.85 (3SF)	3	MSL	931
199	75	0	Inf. Dilution	lgK:2.414 (4SF)	4	MCN	23739
200	75	0	Inf. Dilution/m	lgK:2.846 (4SF)	4	MSL	8397
201	75	0	SOLMNEQ	lgK:2.90 (3SF)	4	CMN	5416
202	75	0	WATCH	lgK:2.82 (3SF)	4	CMN	5416
203	75	0	WATEQF	lgK:2.72 (3SF)	4	CMN	5416
204	80	0	Inf. Dilution	lgK:2.83 (3SF)	4	EMU	8672
205	90	0	Inf. Dilution	lgK:2.88 (3SF)	4	EMU	8672
206	100	0	Inf. Dilution	lgK:3.2 (2SF)	3	EMU	5398
207	100	0	Inf. Dilution	lgK:3.057 (4SF)	3	EDT	5416
208	100	0	Inf. Dilution	lgK:2.679 (4SF)	3	MCN	23739
209	100	0	Inf. Dilution/m	lgK:3.057 (4SF)	4	MSL	8397
210	100	0	SOLMNEQ	lgK:3.20 (3SF)	4	CMN	5416
211	100	0	SOLVEQ	lgK:3.06 (3SF)	4	CMN	5416
212	100	0	WATCH	lgK:3.06 (3SF)	4	CMN	5416
213	100	0	WATEQF	lgK:2.92 (3SF)	3	CMN	5416
214	125	0	Inf. Dilution	lgK:3.27 (3SF)	3	MSL	931
215	125	0	Inf. Dilution	lgK:2.953 (4SF)	6	MCN	23739
216	125	0	Inf. Dilution/m	lgK:3.274 (4SF)	4	MSL	8397
217	125	0	SOLMNEQ	lgK:3.55 (3SF)	3	CMN	5416
218	125	0	WATCH	lgK:3.28 (3SF)	3	CMN	5416
219	125	0	WATEQF	lgK:3.08 (3SF)	3	CMN	5416
220	150	0	Inf. Dilution	lgK:3.50 (3SF)	3	MSL	931
221	150	0	Inf. Dilution	lgK:3.9 (2SF)	0	EMU	5398
222	150	0	Inf. Dilution	lgK:3.225 (4SF)	6	MCN	23739
223	150	0	Inf. Dilution/m	lgK:3.501 (4SF)	4	MSL	8397
224	150	0	SOLMNEQ	lgK:3.90 (3SF)	0	CMN	5416
225	150	0	SOLVEQ	lgK:3.50 (3SF)	3	CMN	5416
226	150	0	WATCH	lgK:3.48 (3SF)	3	CMN	5416
227	150	0	WATEQF	lgK:3.23 (3SF)	0	CMN	5416
228	175	0	Inf. Dilution	lgK:3.74 (3SF)	3	MSL	931
229	175	0	Inf. Dilution	lgK:3.490 (4SF)	6	MCN	23739
230	175	0	Inf. Dilution/m	lgK:3.743 (4SF)	4	MSL	8397
231	175	0	SOLMNEQ	lgK:4.33 (3SF)	0	CMN	5416
232	175	0	WATCH	lgK:3.67 (3SF)	3	CMN	5416

233	175	0	WATEQF	lgK:3.37 (3SF)	0	CMN	5416
234	200	0	Inf. Dilution	lgK:4.00 (3SF)	3	MSL	931
235	200	0	Inf. Dilution	lgK:4.8 (2SF)	0	EMU	5398
236	200	0	Inf. Dilution	lgK:4.002 (4SF)	0	EDT	5416
237	200	0	Inf. Dilution	lgK:3.744 (4SF)	6	MCN	23739
238	200	0	Inf. Dilution/m	lgK:4.002 (4SF)	4	MSL	8397
239	200	0	SOLMNEQ	lgK:4.80 (3SF)	0	CMN	5416
240	200	0	SOLVEQ	lgK:4.00 (3SF)	3	CMN	5416
241	200	0	WATCH	lgK:3.84 (3SF)	3	CMN	5416
242	200	0	WATEQF	lgK:3.49 (3SF)	0	CMN	5416
243	225	0	Inf. Dilution	lgK:3.985 (4SF)	6	MCN	23739
244	225	0	SOLMNEQ	lgK:5.26 (3SF)	0	CMN	5416
245	225	0	WATCH	lgK:4.00 (3SF)	3	CMN	5416
246	225	0	WATEQF	lgK:3.59 (3SF)	0	CMN	5416
247	250	0	Inf. Dilution	lgK:4.58 (3SF)	3	MSL	931
248	250	0	Inf. Dilution	lgK:4.211 (4SF)	2	MCN	23739
249	250	0	Inf. Dilution/m	lgK:4.58 (3SF)	4	MSL	8397
250	250	0	SOLMNEQ	lgK:5.70 (3SF)	0	CMN	5416
251	250	0	SOLVEQ	lgK:4.58 (3SF)	0	CMN	5416
252	250	0	WATCH	lgK:4.14 (3SF)	0	CMN	5416
253	250	0	WATEQF	lgK:3.69 (3SF)	0	CMN	5416
254	275	0	Inf. Dilution	lgK:4.421 (4SF)	1	MCN	23739
255	275	0	SOLMNEQ	lgK:6.07 (3SF)	0	CMN	5416
256	275	0	WATCH	lgK:4.27 (3SF)	0	CMN	5416
257	275	0	WATEQF	lgK:3.78 (3SF)	0	CMN	5416
258	300	0	Inf. Dilution	lgK:4.791 (4SF)	0	MCN	23739
259	300	0	Inf. Dilution/m	lgK:5.23 (3SF)	4	MSL	8397
260	300	0	SOLMNEQ	lgK:6.40 (3SF)	0	CMN	5416
261	300	0	SOLVEQ	lgK:5.23 (3SF)	0	CMN	5416
262	300	0	WATCH	lgK:4.40 (3SF)	0	CMN	5416
263	300	0	WATEQF	lgK:3.86 (3SF)	0	CMN	5416
264	325	0	SOLMNEQ	lgK:6.71 (3SF)	0	CMN	5416
265	325	0	WATCH	lgK:4.51 (3SF)	0	CMN	5416
266	325	0	WATEQF	lgK:3.93 (3SF)	0	CMN	5416
267	350	0	Inf. Dilution/m	lgK:5.96 (3SF)	4	MSL	8397
268	350	0	SOLMNEQ	lgK:7.00 (3SF)	0	CMN	5416

269	350	0	WATCH	lgK:4.62 (3SF)	0	CMN	5416
270	350	0	WATEQF	lgK:4.00 (3SF)	0	CMN	5416
271	370	0	Inf. Dilution	lgK:6.27 (3SF)	3	MSL	931
272	23	0	Inf. Dilution	dG:-3.15 (0.05SD)	3	MCL	7645
273	0	0	Inf. Dilution/m	dH:4.08 (3SF)	0	MTD	8397
274	0:45	0	Inf. Dilution	dH:2.04 (3SF)	4	MCL	5398
275	0:45	0	Inf. Dilution	dH:2.04 (3SF)	4	MTD	8390
276	0:45	0	Inf. Dilution	dH:4.84 (3SF)	0	MTD	8394
277	1.7	0.66	Seawater/m	dH:-2.7 (0.5SD)	0	MTD	8631
278	23	0	Inf. Dilution	dH:1.27 (0.20SD)	3	MCL	7645
279	25	0	Inf. Dilution	dH:1.4 (0.1SD)	3	CMN	10
280	25	0	Inf. Dilution	dH:6.50 (0.17SD) kJ	4	MCL	90
281	25	0	Inf. Dilution	dH:5.7 (2SF)	0	MTD	92
282	25	0	Inf. Dilution	dH:4.87 (3SF)	0	MCL	931
283	25	0	Inf. Dilution	dH:0.51 (2SF)	0	MCL	5398
284	25	0	Inf. Dilution	dH:1.55 (3SF)	4	MCL	5398
285	25	0	Inf. Dilution	dH:1.35 (3SF)	4	MDG	5398
286	25	0	Inf. Dilution	dH:4.01 (3SF)	0	MTD	5416
287	25	0	Inf. Dilution	dH:4.55 (3SF)	0	ENS	6496
288	25	0	Inf. Dilution	dH:0.51 (0.03SD)	0	MCL	8402
289	25	0	Inf. Dilution	dH:1.40 (3SF)	3	CRV	9402
290	25	0	Inf. Dilution	dH:8.54 (3SF) kJ	4	MTD	11762
291	25	0	Inf. Dilution/m	dH:4.01 (3SF)	0	MTD	8397
292	25	0	Unknown	dH:1.4 (2SF)	3	ENS	7373
293	25	0.7	Unknown	dH:0.5 (1SF)	6	CRV	552
294	25	0.75	Seawater	dH:0.4 (0.3SD)	0	MCL	5086
295	25	0.75	Unknown	dH:2. (1SF) kJ	4	MCL	5086
296	25			dH:6.78 (0.08SD) kJ	5	MDG	11763
297	30	0	Inf. Dilution	dH:1.2 (0.1SD)	3	MCL	5087
298	50	0	Inf. Dilution/m	dH:4.22 (3SF)	4	MTD	8397
299	75	0	Inf. Dilution/m	dH:4.68 (3SF)	4	MTD	8397
300	100	0	Inf. Dilution	dH:5.41 (3SF)	3	MTD	5416
301	100	0	Inf. Dilution/m	dH:5.41 (3SF)	4	MTD	8397
302	125	0	Inf. Dilution/m	dH:6.41 (3SF)	4	MTD	8397
303	150	0	Inf. Dilution/m	dH:7.67 (3SF)	4	MTD	8397
304	175	0	Inf. Dilution/m	dH:9.20 (3SF)	4	MTD	8397

305	200	0	Inf. Dilution	dH:11.(2SF)	3	MTD	5416
306	200	0	Inf. Dilution/m	dH:11.0(3SF)	4	MTD	8397
307	250	0	Inf. Dilution/m	dH:15.4(3SF)	3	MTD	8397
308	300	0	Inf. Dilution/m	dH:20.8(3SF)	0	MTD	8397
309	350	0	Inf. Dilution/m	dH:27.3(3SF)	4	MTD	8397
310	25		Dioxan:Formamide 20:80Wgt	lgK:1.95(3SF)	5	MCN	931
311	25		Dioxan:Formamide 25:75Wgt	lgK:2.33(3SF)	5	MCN	931
312	25		Dioxan:Formamide 30:70Wgt	lgK:2.65(3SF)	5	MCN	931
313	25		Dioxan:Formamide 35:65Wgt	lgK:3.09(3SF)	5	MCN	931
314	25		Dioxan:Formamide 40:60Wgt	lgK:3.58(3SF)	5	MCN	931
315	25		Dioxan:Formamide 50:50Wgt	lgK:4.39(3SF)	5	MCN	931
316	25		Dioxan:Formamide 60:40Wgt	lgK:5.38(3SF)	5	MCN	931
317	25		Dioxan:Formamide 70:30Wgt	lgK:6.42(3SF)	5	MCN	931
318	25		Dioxan:Water 13:87Wgt	lgK:2.62(3SF)	4	MSC	140
319	25		Dioxan:Water 25:75Wgt	lgK:3.19(3SF)	4	MSC	140
320	25	0	Ethanol:Water 20:80Wgt Inf. Dilution	lgK:2.61(3SF)	4	MSP	140
321	25		Ethanol:Water 50:50Wgt	lgK:3.86(3SF)	4	MCN	140
322	25		Formamide	lgK:0.98(2SF)	5	MCN	931
323	25		Formamide:Acetone 50:50Wgt	lgK:4.50(3SF)	5	MCN	931
324	25	0	THF:Water 20:80Wgt Inf. Dilution	lgK:2.65(3SF)	4	MCN	5398
325	25	0	THF:Water 50:50Wgt Inf. Dilution	lgK:3.20(3SF)	4	MCN	5398

Reaction No. 338



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.3(1SF)	1	EES	

2	30	1	KCl	lgK:0.4 (0.05SD)	4	MIS	53
3	30		Dioxan:Water 75:25Wgt	lgK:1.8 (2SF)	4	MGL	140

Reaction No. 339							
Citric-3 + Mg+2 = Mg+2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:3.40 (3SF)	2	MGL	154
2	25	0	Inf. Dilution	lgK:3.96 (3SF)	0	MIX	999
3	25	0	Inf. Dilution	lgK:4.85 (3SF)	3	MGL	2804
4	25	0	Inf. Dilution	lgK:4.7 (2SF)	4	ENS	6405
5	25	0	Inf. Dilution	lgK:4.71 (3SF)	5	MGL	9424
6	25	0	Inf. Dilution	lgK:4.810 (0.015SD)	4	CRV	20830
7	25	0	Inf. Dilution	lgK:4.71 (3SF)	5	MGL	22560
8	25	0	Inf. Dilution	lgK:3.96 (3SF)	0	MIX	22560
9	25	0	Inf. Dilution	lgK:4.917 (4SF)	3	MEP	22560
10	25	0.09	Unknown	lgK:3.29 (3SF)	4	MPL	999
11	25	0.1	Cl-1 salt	lgK:3.63 (3SF)	2	MGL	2804
12	25	0.1	KNO3	lgK:3.4 (0.07SD)	5	MGL	3519
13	25	0.1	Me4NC1	lgK:1.92 (3SF)	0	MGL	152
14	25	0.1	Me4NC1	lgK:3.73 (3SF)	0	MGL	153
15	25	0.1	Me4NC1	lgK:3.55 (3SF)	3	MIX	20368
16	25	0.1	NH4Cl	lgK:3.16 (0.1SD)	0	MIX	198
17	25	0.1	NH4Cl	lgK:3.16 (3SF)	0	MIX	22560
18	25	0.1	NaCl	lgK:3.5 (0.06SD)	5	MGL	3925
19	25	0.15	NaCl	lgK:3.27 (3SF)	4	MCT	22612
20	25	0.15	Unknown	lgK:3.29 (3SF)	5	MVM	162
21	25	0.16	Unknown	lgK:3.2 (2SF)	4	MSC	999
22	25	0.16	Unknown	lgK:3.2 (2SF)	1	EEX	22560
23	25	0.5	NaClO4	lgK:2.71 (0.01MD)	2	MGL	4896
24	30	1	NaClO4	lgK:3.62 (3SF)	5	MGL	22560
25	32	0.1	Unknown	lgK:3.6 (2SF)	4	MGL	999
26	37	0	Inf. Dilution	lgK:4.67 (3SF)	2	CRV	28703
27	37	0.1	Inert	lgK:3.66 (3SF)	2	CRV	29801
28	37	0.1	KNO3	lgK:3.451 (4SF)	5	MGL	9424
29	37	0.15	Blood Plasma	lgK:3.3 (0.05SD)	4	ENS	94
30	37	0.15	NaCl	lgK:3.34 (3SF)	5	MGL	3520

31	37	0.15	NaCl	lgK:3.24 (3SF)	4	MCT	22612
32	37	0.15	NaCl	lgK:3.31 (0.08SD)	4	MGL	28777
33	37	0.15	NaCl	lgK:3.15 (0.13SD)	2	MIS	28777
34	37	0.15	NaClO ₄	lgK:3.33 (0.009SD)	5	MGL	2181
35	38	0	Inf. Dilution	lgK:4.84 (3SF)	3	CRV	8692
36	20:40	0.1	Unknown	dH:2. (1SF)	0	CRV	2556
37	25	0	Inf. Dilution	dH:-22.00 (4SF) kJ	0	MGL	9424

Reaction No. 340							
Mg+2 + H+1_Citric-3 = Mg+2_H+1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO ₄	lgK:1.84 (3SF)	3	MGL	154
2	20	0.1	Unknown	lgK:1.80 (3SF)	4	ENS	1539
3	25	0	Inf. Dilution	lgK:2.67 (3SF)	5	MGL	2804
4	25	0	Inf. Dilution	lgK:2.42 (3SF)	5	MGL	9424
5	25	0	Inf. Dilution	lgK:2.600 (0.04SD)	6	CRV	20830
6	25	0	Inf. Dilution	lgK:1.672 (4SF)	3	MEP	22560
7	25	0.09	Unknown	lgK:1.60 (3SF)	5	MPL	999
8	25	0.1	Cl-1 salt	lgK:1.78 (3SF)	5	MGL	2804
9	25	0.1	Me ₄ NC1	lgK:1.85 (3SF)	3	MGL	153
10	25	0.1	NaCl	lgK:1.62 (3SF)	5	MEP	3520
11	25	0.15	Unknown	lgK:1.60 (3SF)	4	MCV	22560
12	38	0	Inf. Dilution	lgK:2.50 (3SF)	3	CRV	8692
13	20:40	0.1	Unknown	dH:0.0 (1SF)	4	CRV	2556

Reaction No. 341							
Mg+2 + H+1(2)_Citric-3 = Mg+2_H+1(2)_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO ₄	lgK:0.8 (0.05SD)	4	MGL	154
2	20	0.1	Unknown	lgK:0.80 (2SF)	0	ENS	1539
3	25	0	Inf. Dilution	lgK:1.0 (2SF)	3	MGL	2804
4	25	0	Inf. Dilution	lgK:1.310 (0.08SD)	6	CRV	20830
5	25	0.1	Cl-1 salt	lgK:0.60 (2SF)	0	MGL	2804
6	38	0	Inf. Dilution	lgK:0.70 (2SF)	3	CRV	8692

Reaction No. 342							
EDTA-4 + Mg+2 = Mg+2_EDTA-4							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:9.12 (3SF)	0	MHY	140
2	20	0	Unknown	lgK:9.12 (3SF)	0	ENS	773
3	20	0.1	KCl	lgK:8.69 (3SF)	6	MHY	1947
4	20	0.1	KNO3	lgK:8.7 (0.04SD)	8	EIU	903
5	20	0.1	KNO3	lgK:8.61 (3SF)	4	MGL	903
6	20	0.1	KNO3	lgK:8.65 (3SF)	5	MGL	11516
Note (6): Anderegg G, IUPAC Chemical Data Series No. 14, 1978							
7	20	0.1	KNO3	lgK:11. (2SF)	0	MEP	11516
Note (7): Jokl V et al., Chem. Zvesti, 1965, 19, 249							
8	20	0.1	Unknown	lgK:8.79 (3SF)	4	ENS	773
9	25	0	Inf. Dilution	lgK:10.6 (3SF)	4	ENS	6405
10	25	0	Inf. Dilution	lgK:9.1 (2SF)	0	MCL	8497
11	25	0	Inf. Dilution	lgK:10.900 (0.05SD)	5	CRV	20830
12	25	0.1	KNO3	lgK:8.64 (3SF)	0	MGL	11516
Note (12): Bohigian T et al., US Comm. Con. no AT(30-1), 1960, 1823							
13	25	0.1	Me4N+ salt	lgK:9.13 (3SF)	6	CRV	552
14	25	0.1	NaClO4	lgK:8.9 (0.1SD)	3	MHG	146
15	25	0.1	Unknown	lgK:8.83 (3SF)	5	ENS	2016
16	25	0.5	KNO3	lgK:8.1 (0.04SD)	5	MGL	3832
17	25	0.5	Me4N+ salt	lgK:8.67 (3SF)	3	CRV	552
18	37	0.15	Blood Plasma	lgK:7.8 (0.05SD)	0	ENS	94
19	37	0.15	NaCl	lgK:7.75 (0.007SD)	0	MGL	1940
20	20	0.1	KNO3	dG:-11.7 (3SF)	5	MGL	2039
21	20	0.1	KNO3	dH:3.14 (3SF)	4	MCL	903
22	20	0.1	KNO3	dH:3.49 (3SF)	5	MCL	1963
23	20	0.1	KNO3	dH:3.15 (3SF)	5	MDG	2603
24	20:40	0.1	KNO3	dH:3. (0.4SD)	5	MCL	3201
25	25	0	Inf. Dilution	dH:19.800 (0.2SD) kJ	6	CRV	20830
26	25	0.05	Unknown	dH:3.1 (2SF)	0	MCL	999
27	25	0.1	KNO3	dH:3.1 (2SF)	5	MCL	139
28	25	0.1	Me4N+ salt	dH:3.1 (2SF)	5	MCL	2558
29	25	0.1	NaNO3	dH:3.49 (3SF)	5	MCL	1379
30	25	0.1	Unknown	dH:3.3 (2SF)	6	CRV	552
31	25	0.5	KNO3	dH:2.868 (4SF)	5	MTD	3832
32	20	0.1	KNO3	dS:51.7 (3SF)	5	EFE	2039

Reaction No. 345							
DTPA-5 + Mg+2 = Mg+2_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:9.30 (3SF)	2	ENS	773
2	25	0.1	KNO3	lgK:9.3 (0.1SD)	0	MGL	135
3	25	0.1	KNO3	lgK:9.3 (0.1SD)	0	CRV	13242
4	25	0.1	Unknown	lgK:9.34 (3SF)	2	ENS	773
5	37	0.15	Blood Plasma	lgK:8.6 (0.05SD)	3	ENS	94
6	37	0.15	NaCl	lgK:8.56 (0.02SD)	3	MGL	1940
7	37	0.15	NaCl	lgK:8.56 (0.05SD)	3	CRV	13242
8	20	0.1	KNO3	dH:3.0 (0.05SD)	3	MCL	187
9	25	0.1	KNO3	dH:3.6 (2SF)	3	MCL	139
10	25	0.1	NaNO3	dH:3.6 (2SF)	3	MCL	1379

Reaction No. 408							
2AmButan-1 + Mg+2 = Mg+2_2AmButan-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.08 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.6 (0.05SD)	3	ENS	94


Reaction No. 409							
2AmButan-1 + Mg+2 + H+1 = Mg+2_H+1_2AmButan-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.0 (0.05SD)	3	ENS	94

Reaction No. 410							
2<2AmButan-1> + Mg+2 = Mg+2_2AmButan-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.92 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.2 (0.05SD)	4	ENS	94

Reaction No. 411							
2<2AmButan-1> + Mg+2 + 2<H+1> = Mg+2_H+1 (2)_2AmButan-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0 (3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:19.5 (0.05SD)	3	ENS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 441




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Unknown	lgK:1.30 (3SF)	0	MGL	22560
2	25	0.1	KNO3	lgK:2.21 (3SF)	6	MGL	3511
3	25			lgK:1.30 (3SF)	0	MGL	6000
4	37	0.15	Blood Plasma	lgK:2.0 (0.05SD)	4	ENS	94

Reaction No. 442




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.3 (0.05SD)	3	ENS	94

Reaction No. 443




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.02 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.3 (0.05SD)	4	ENS	94

Reaction No. 444




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.0 (0.05SD)	4	ENS	94

Reaction No. 476




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaCl	lgK:1.33 (3SF)	5	MGL	9667
2	37	0.15	Blood Plasma	lgK:1.8 (0.05SD)	4	ENS	94
3	25	3	NaClO4	dH:-2. (0.8MD)	5	MCL	1602

Reaction No. 477




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.94 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.7 (0.05SD)	3	ENS	94

Reaction No. 478




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:4. (1SF)	3	MGL	3514
2	25	0	Inf. Dilution	lgK:4.01 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.3 (2SF)	4	ENS	94
4	25	3	NaClO4	dH:-3. (2.MD)	4	MCL	1602

Reaction No. 479



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.7 (0.05SD)	4	ENS	94


Reaction No. 513



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.08 (3SF)	4	MGL	6131
2	25	0	UCT_Sea	lgK:2.96 (0.01SD)	4	EDH	5390
3	25	0.1	KCl	lgK:2.43 (3SF)	4	MGL	6710
4	25	0.1	KCl	lgK:2.43 (3SF)	5	MGL	6710
5	25	0.1	KNO3	lgK:2.82 (3SF)	0	MGL	22560
6	25	0.1	NaNO3	lgK:4.35 (3SF)	0	MGL	16058
7	25	0.1	UCT_Sea	lgK:2.43 (0.01SD)	4	EDH	5390
8	25	0.1	Unknown	lgK:2.43 (3SF)	4	ENS	773
9	25	0.2	UCT_Sea	lgK:2.34 (0.01SD)	4	EDH	5390
10	25	0.3	UCT_Sea	lgK:2.29 (0.01SD)	4	EDH	5390
11	25	0.4	UCT_Sea	lgK:2.27 (0.01SD)	4	EDH	5390
12	25	0.5	UCT_Sea	lgK:2.26 (0.01SD)	4	EDH	5390
13	25	0.6	UCT_Sea	lgK:2.25 (0.01SD)	4	EDH	5390
14	25	0.7	UCT_Sea	lgK:2.25 (0.01SD)	4	EDH	5390
15	37	0.15	Blood Plasma	lgK:2.2 (0.05SD)	3	ENS	94
16	37	0.15	NaCl	lgK:2.56 (0.09SD)	3	MGL	28777


17	37	0.15	NaCl	lgK:2.27(0.25SD)	4	MIS	28777
18	37	0.15	NaClO4	lgK:2.0(0.03SD)	2	MGL	2181
19	37	0.15	Unknown	lgK:2.04(3SF)	4	CRV	552
20	25	0	Inf. Dilution	dH:9.(1SF)kJ	4	MCL	6131

Reaction No. 514




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.33(4SF)	3	MGL	6131
2	37	0.15	Blood Plasma	lgK:10.6(0.05SD)	3	ENS	94
3	37	0.15	NaCl	lgK:11.13(0.09SD)	0	MGL	28777
4	37	0.15	NaCl	lgK:11.06(0.19SD)	2	MIS	28777
5	37	0.15	NaClO4	lgK:10.5(0.03SD)	3	MGL	2181
6	25	0	Inf. Dilution	dH:-35.(2SF)kJ	3	MCL	6131

Reaction No. 515




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.9(2SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:2.9(0.05SD)	0	ENS	94
3	37	0.15	NaClO4	lgK:4.426(4SF)	6	MGL	2181

Reaction No. 516




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.1(0.05SD)	3	ENS	94

Reaction No. 545



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.66(3SF)	6	MGL	3511
2	37	0.15	Blood Plasma	lgK:1.6(0.05SD)	3	ENS	94


Reaction No. 546



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:10.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.8(0.05SD)	3	ENS	94

Reaction No. 547




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.86(3SF)	5	MGL	3511
2	37	0.15	Blood Plasma	lgK:1.9(0.05SD)	4	ENS	94

Reaction No. 548




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.8(0.05SD)	4	ENS	94

Reaction No. 586




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.025	Unknown	lgK:4.(1SF)	0	MGL	905
2	20	0.1	NaClO4	lgK:2.746(4SF)	6	MGL	3504
3	25	0	NaCl	lgK:4.16(3SF)	3	MGL	21108
4	37	0.15	Blood Plasma	lgK:2.6(0.05SD)	4	ENS	94

Reaction No. 587



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.2(3SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:11.5(0.05SD)	3	ENS	94

Reaction No. 588



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.025	HBr	lgK:4.(1SF)	3	MGL	6024
2	25	0	Inf. Dilution	lgK:4.46(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.4(0.05SD)	4	ENS	94

Reaction No. 589

2<Cys-2> + Mg+2 + 2<H+1> = Mg+2_H+1(2)_Cys-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.0(0.05SD)	4	ENS	94

Reaction No. 626							
Cis-2 + Mg+2 + H+1 = Mg+2_H+1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.7(0.05SD)	3	ENS	94

Reaction No. 627							
Cis-2 + Mg+2 + 2<H+1> = Mg+2_H+1(2)_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:17.7(0.05SD)	4	ENS	94

Reaction No. 628							
2<Cis-2> + Mg+2 + 2<H+1> = Mg+2_H+1(2)_Cis-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.0(0.05SD)	3	ENS	94

Reaction No. 629							
2<Cis-2> + Mg+2 + 4<H+1> = Mg+2_H+1(4)_Cis-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:35.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:34.5(0.05SD)	4	ENS	94

Reaction No. 667							
Glu-2 + Mg+2 = Mg+2_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.8(2SF)	4	ENS	2152
2	25	0	Inf. Dilution	lgK:2.75(3SF)	4	MGL	6131
3	25	0.1	KCl	lgK:1.9(2SF)	4	MGL	6710
4	25	0.1	NaNO3	lgK:3.20(3SF)	0	MGL	16058
5	25	1	NaCl	lgK:1.33(3SF)	6	MGL	957

6	37	0.15	Blood Plasma	lgK:1.8(0.05SD)	4	ENS	94
7	37	0.15	KNO3	lgK:2.79(3SF)	0	MGL	22560
8	37	0.15	NaCl	lgK:1.69(0.06SD)	3	MGL	28777
9	37	0.15	NaCl	lgK:1.86(0.28SD)	3	MIS	28777
10	37	0.15	NaClO4	lgK:2.20(0.02SD)	2	MGL	2181
11	25	0	Inf. Dilution	dH:10.(2SF)kJ	4	MCL	6131

Reaction No. 668							
H+1 + Glu-2 + Mg+2 = Mg+2_H+1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.70(4SF)	2	MGL	6131
2	37	0.15	Blood Plasma	lgK:10.6(0.05SD)	3	ENS	94
3	37	0.15	NaCl	lgK:10.56(0.19SD)	3	MGL	28777
4	37	0.15	NaCl	lgK:10.93(0.33SD)	3	MIS	28777
5	37	0.15	NaClO4	lgK:11.08(0.02SD)	2	MGL	2181
6	25	0	Inf. Dilution	dH:-32.(2SF)kJ	2	MCL	6131

Reaction No. 669							
2<Glu-2> + Mg+2 = Mg+2_Glu-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.46(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.5(0.05SD)	4	ENS	94


Reaction No. 670							
2<Glu-2> + Mg+2 + 2<H+1> = Mg+2_H+1(2)_Glu-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.3(0.05SD)	3	ENS	94

Reaction No. 704							
Gln-1 + Mg+2 = Mg+2_Gln-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.18(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.7(0.05SD)	3	ENS	94

Reaction No. 705							
Gln-1 + Mg+2 + H+1 = Mg+2_H+1_Gln-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.8(0.05SD)	3	ENS	94

Reaction No. 706




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.92(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.2(0.05SD)	4	ENS	94

Reaction No. 707




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.9(0.05SD)	4	ENS	94

Reaction No. 773




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:4.(1SF)	0	MGL	6024
2	25	0	Inf. Dilution	lgK:1.89(3SF)	0	MPH	6131
3	35	0.1	KNO3	lgK:2.80(3SF)	2	MGL	22560
4	37	0.15	Blood Plasma	lgK:2.2(0.05SD)	2	ENS	94
5	25	0	Inf. Dilution	dH:2.(1SF)kJ	3	MCL	6131

Reaction No. 774



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.10(4SF)	4	MPH	6131
2	37	0.15	Blood Plasma	lgK:10.1(0.05SD)	3	ENS	94
3	25	0	Inf. Dilution	dH:-39.(2SF)kJ	4	MCL	6131

Reaction No. 775



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.62(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.9(0.05SD)	4	ENS	94

Reaction No. 776							
$2\text{<His-1>} + \text{Mg}^{+2} + 2\text{<H+1>} = \text{Mg}^{+2}\text{_{H+1(2)}_His-1(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.3 (0.05SD)	3	ENS	94

Reaction No. 833							
$\text{Hyp-1} + \text{Mg}^{+2} = \text{Mg}^{+2}\text{_{Hyp-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.18 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.7 (0.05SD)	3	ENS	94

Reaction No. 834							
$\text{Hyp-1} + \text{Mg}^{+2} + \text{H+1} = \text{Mg}^{+2}\text{_{H+1_Hyp-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.2 (0.05SD)	3	ENS	94


Reaction No. 835							
$2\text{<Hyp-1>} + \text{Mg}^{+2} = \text{Mg}^{+2}\text{_{Hyp-1(2)}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.02 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.3 (0.05SD)	4	ENS	94

Reaction No. 836							
$2\text{<Hyp-1>} + \text{Mg}^{+2} + 2\text{<H+1>} = \text{Mg}^{+2}\text{_{H+1(2)}_Hyp-1(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.8 (0.05SD)	3	ENS	94

Reaction No. 865							
$\text{Mg}^{+2} + \text{Ile-1} = \text{Mg}^{+2}\text{_{Ile-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:1.8 (0.08SD)	6	MGL	2392
2	20	0.15	NaCl	lgK:1.85 (3SF)	5	MGL	22560
3	25	0	Inf. Dilution	lgK:2.28 (3SF)	2	EAE	


4	37	0.15	Blood Plasma	lgK:1.8(0.05SD)	4	ENS	94
---	----	------	--------------	-----------------	---	-----	----

Reaction No. 866




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.3(0.05SD)	3	ENS	94

Reaction No. 867




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.12(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.4(0.05SD)	4	ENS	94

Reaction No. 868




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.1(0.05SD)	3	ENS	94

Reaction No. 902




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:1.9(0.08SD)	6	MGL	2392
2	20	0.15	NaCl	lgK:1.89(3SF)	5	MGL	22560
3	25	0	Inf. Dilution	lgK:2.33(3SF)	2	EAE	
4	25	0.1	KNO3	lgK:3.69(3SF)	0	MGL	1089
5	37	0.15	Blood Plasma	lgK:1.8(0.05SD)	4	ENS	94

Reaction No. 903




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.4(0.05SD)	3	ENS	94

Reaction No. 904




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.02(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.3(0.05SD)	4	ENS	94

Reaction No. 905




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.1(0.05SD)	3	ENS	94

Reaction No. 948




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.95(3SF)	4	MPH	6131
2	37	0.15	Blood Plasma	lgK:1.1(0.05SD)	3	ENS	94
3	25	0	Inf. Dilution	dH:-4.(1SF)kJ	4	MCL	6131

Reaction No. 949




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.12(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.4(0.05SD)	3	ENS	94

Reaction No. 950



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.73(4SF)	4	MPH	6131
2	37	0.15	Blood Plasma	lgK:12.1(0.05SD)	4	ENS	94
3	25	0	Inf. Dilution	dH:-52.(2SF)kJ	4	MCL	6131

Reaction No. 951



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	4	MPH	6131
2	37	0.15	Blood Plasma	lgK:21.2(0.05SD)	0	ENS	94
3	25	0	Inf. Dilution	dH:-95.(2SF)kJ	4	MCL	6131

Reaction No. 952							
$2\text{<Lys-1>} + \text{Mg}+2 + 2\text{<H+1>} = \text{Mg}+2_{\text{H+1}(2)}_{\text{Lys-1}(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.7(0.05SD)	4	ENS	94

Reaction No. 953							
$2\text{<Lys-1>} + \text{Mg}+2 + 4\text{<H+1>} = \text{Mg}+2_{\text{H+1}(4)}_{\text{Lys-1}(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:39.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:40.0(0.05SD)	3	ENS	94

Reaction No. 988							
$\text{Met-1} + \text{Mg}+2 = \text{Mg}+2_{\text{Met-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.28(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.8(0.05SD)	4	ENS	94

Reaction No. 989							
$\text{Met-1} + \text{Mg}+2 + \text{H}+1 = \text{Mg}+2_{\text{H+1}}_{\text{Met-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.9(0.05SD)	3	ENS	94

Reaction No. 990							
$2\text{<Met-1>} + \text{Mg}+2 = \text{Mg}+2_{\text{Met-1}(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.12(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.4(0.05SD)	4	ENS	94

Reaction No. 991							
$2\text{<Met-1>} + \text{Mg}+2 + 2\text{<H+1>} = \text{Mg}+2_{\text{H+1}(2)}_{\text{Met-1}(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.1(0.05SD)	4	ENS	94

Reaction No. 1029							
-------------------	--	--	--	--	--	--	--

Orn-1 + Mg+2 + H+1 = Mg+2_H+1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.9(0.05SD)	4	ENS	94

Reaction No. 1030							
Orn-1 + Mg+2 + 2<H+1> = Mg+2_H+1(2)_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.7(0.05SD)	3	ENS	94

Reaction No. 1031							
2<Orn-1> + Mg+2 + 2<H+1> = Mg+2_H+1(2)_Orn-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.2(0.05SD)	4	ENS	94

Reaction No. 1032							
2<Orn-1> + Mg+2 + 4<H+1> = Mg+2_H+1(4)_Orn-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:38.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:38.8(0.05SD)	4	ENS	94

Reaction No. 1066							
Mg+2 + Phe-1 = Mg+2_Phe-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:1.63(3SF)	5	MGL	22560
2	25	0	Inf. Dilution	lgK:2.12(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:1.7(0.05SD)	3	ENS	94

Reaction No. 1067							
Phe-1 + Mg+2 + H+1 = Mg+2_H+1_Phe-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.8(0.05SD)	3	ENS	94

Reaction No. 1068							
-------------------	--	--	--	--	--	--	--

2<Phe-1> + Mg+2 = Mg+2_Phe-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.02(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.3(0.05SD)	4	ENS	94

Reaction No. 1069							
2<Phe-1> + Mg+2 + 2<H+1> = Mg+2_H+1(2)_Phe-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.0(0.05SD)	4	ENS	94

Reaction No. 1098							
Pro-1 + Mg+2 = Mg+2_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.38(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.9(0.05SD)	4	ENS	94

Reaction No. 1099							
Pro-1 + Mg+2 + H+1 = Mg+2_H+1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.6(0.05SD)	4	ENS	94

Reaction No. 1100							
2<Pro-1> + Mg+2 = Mg+2_Pro-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:4.(1SF)	3	MGL	3514
2	20	0.03	Unknown	lgK:4.(1SF)	3	MGL	999
3	25	0	Inf. Dilution	lgK:3.96(3SF)	2	EAE	
4	37	0.15	Blood Plasma	lgK:2.4(0.05SD)	4	ENS	94

Reaction No. 1101							
2<Pro-1> + Mg+2 + 2<H+1> = Mg+2_H+1(2)_Pro-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.2(0.05SD)	4	ENS	94

Reaction No. 1139							
Ser-1 + Mg+2 = Mg+2_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:1.47 (3SF)	4	MGL	905
2	25	0	Inf. Dilution	lgK:1.65 (3SF)	4	MPH	6131
3	25	0	UCT_Sea	lgK:1.37 (0.01SD)	3	EDH	5390
4	25	0.1	KNO3	lgK:3.37 (3SF)	0	MGL	1089
5	25	0.1	UCT_Sea	lgK:1.02 (0.01SD)	3	EDH	5390
6	25	0.2	UCT_Sea	lgK:0.97 (0.01SD)	3	EDH	5390
7	25	0.3	UCT_Sea	lgK:0.94 (0.01SD)	3	EDH	5390
8	25	0.4	UCT_Sea	lgK:0.92 (0.01SD)	4	EDH	5390
9	25	0.5	UCT_Sea	lgK:0.91 (0.01SD)	4	EDH	5390
10	25	0.6	UCT_Sea	lgK:0.91 (0.01SD)	4	EDH	5390
11	25	0.7	UCT_Sea	lgK:0.90 (0.01SD)	4	EDH	5390
12	25	3	NaCl	lgK:1.03 (3SF)	3	MGL	905
13	25	3	NaCl	lgK:1.0 (0.05SD)	3	MGL	1276
14	37	0.15	Blood Plasma	lgK:1.8 (0.05SD)	3	ENS	94
15	25	0	Inf. Dilution	dH:-15. (2SF) kJ	4	MCL	6131

Reaction No. 1140							
Ser-1 + Mg+2 + H+1 = Mg+2_H+1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.6 (2SF)	4	MPH	6131
2	37	0.15	Blood Plasma	lgK:9.8 (0.05SD)	3	ENS	94
3	25	0	Inf. Dilution	dH:-35. (2SF) kJ	4	MCL	6131

Reaction No. 1141							
2<Ser-1> + Mg+2 = Mg+2_Ser-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.12 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.4 (0.05SD)	4	ENS	94

Reaction No. 1142							
2<Ser-1> + Mg+2 + 2<H+1> = Mg+2_H+1 (2)_Ser-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.9 (0.05SD)	4	ENS	94

Reaction No. 1175							
Thr-1 + Mg+2 = Mg+2_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:1.45 (3SF)	4	MGL	905
2	25	0	Inf. Dilution	lgK:1.99 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:1.7 (0.05SD)	3	ENS	94

Reaction No. 1176							
Thr-1 + Mg+2 + H+1 = Mg+2_H+1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.8 (0.05SD)	3	ENS	94

Reaction No. 1177							
2<Thr-1> + Mg+2 = Mg+2_Thr-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.03 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.3 (0.05SD)	0	ENS	94
3	37	0.15	NaCl	lgK:3.31 (3SF)	5	MGL	11516
Note (3): Xiliang X et al., Acta Chimica Sinica, 1986, , 1005							


Reaction No. 1178							
2<Thr-1> + Mg+2 + 2<H+1> = Mg+2_H+1 (2)_Thr-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.7 (0.05SD)	4	ENS	94

Reaction No. 1209							
Trp-1 + Mg+2 = Mg+2_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.02 (3SF)	5	MGL	2261
2	37	0.15	Blood Plasma	lgK:1.8 (0.05SD)	4	ENS	94

Reaction No. 1210							
Trp-1 + Mg+2 + H+1 = Mg+2_H+1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:10.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.1(0.05SD)	3	ENS	94

Reaction No. 1211




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:4.(1SF)	3	MGL	3514
2	25	0	Inf. Dilution	lgK:3.88(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:2.3(0.05SD)	4	ENS	94

Reaction No. 1212




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.5(0.05SD)	3	ENS	94

Reaction No. 1256




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.06(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.1(0.05SD)	3	ENS	94

Reaction No. 1257




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.36(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:1.4(0.05SD)	3	ENS	94

Reaction No. 1258



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.7(0.05SD)	4	ENS	94


Reaction No. 1259



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:20.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.8(0.05SD)	3	ENS	94

Reaction No. 1260




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.1(0.05SD)	4	ENS	94

Reaction No. 1261




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:40.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:39.1(0.05SD)	4	ENS	94

Reaction No. 1308




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.2(0.05SD)	3	ENS	94

Reaction No. 1309




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.92(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.2(0.05SD)	4	ENS	94

Reaction No. 1310




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.0(3SF)	1	EES	
2	25	0	Inf. Dilution	lgK:10.46(4SF)	0	MPH	6131
3	37	0.15	Blood Plasma	lgK:10.4(0.05SD)	0	ENS	94
4	25	0	Inf. Dilution	dH:-34.(2SF)kJ	0	MCL	6131

Reaction No. 1311



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:2.0(0.08SD)	6	MGL	2392
2	25	0	Inf. Dilution	lgK:1.96(3SF)	6	MGL	2392
3	25	0	Inf. Dilution	lgK:1.75(3SF)	4	MPH	6131
4	25	0	UCT_Sea	lgK:1.96(0.01SD)	4	EDH	5390
5	25	0.1	UCT_Sea	lgK:1.62(0.01SD)	4	EDH	5390
6	25	0.2	UCT_Sea	lgK:1.56(0.01SD)	4	EDH	5390
7	25	0.3	UCT_Sea	lgK:1.52(0.01SD)	4	EDH	5390
8	25	0.4	UCT_Sea	lgK:1.51(0.01SD)	4	EDH	5390
9	25	0.5	UCT_Sea	lgK:1.50(0.01SD)	4	EDH	5390
10	25	0.6	UCT_Sea	lgK:1.50(0.01SD)	4	EDH	5390
11	25	0.7	UCT_Sea	lgK:1.50(0.01SD)	4	EDH	5390
12	37	0.15	Blood Plasma	lgK:1.7(0.05SD)	3	ENS	94
13	25	0	Inf. Dilution	dH:15.(2SF)kJ	4	MCL	6131

Reaction No. 1341



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:2.89(0.02SD)	4	EDT	5416
2	10	0	Inf. Dilution	lgK:2.868(4SF)	4	MPS	27114
3	10	0	Inf. Dilution	lgK:2.86(0.04SD)	6	MPT	27114
4	10	0	Inf. Dilution/m	lgK:2.86(0.04SD)	6	MGL	26086
5	15	0	Inf. Dilution	lgK:2.912(4SF)	4	MPS	27114
6	20	0	Inf. Dilution	lgK:2.954(4SF)	4	MPS	27114
7	20	0.1	Unknown	lgK:2.18(3SF)	5	MSP	140
8	25	0	Inf. Dilution	lgK:3.40(3SF)	0	MGL	140
9	25	0	Inf. Dilution	lgK:3.24(3SF)	2	MGL	337
10	25	0	Inf. Dilution	lgK:3.2(0.05SD)	3	MIS	337
11	25	0	Inf. Dilution	lgK:2.9(0.07SD)	4	CRV	552
12	25	0	Inf. Dilution	lgK:2.88(3SF)	4	MGL	5398
13	25	0	Inf. Dilution	lgK:2.9(0.03SD)	4	EDT	5416
14	25	0	Inf. Dilution	lgK:3.00(3SF)	5	MGL	6265
15	25	0	Inf. Dilution	lgK:2.88(3SF)	3	MGL	6350
16	25	0	Inf. Dilution	lgK:2.98(3SF)	4	ENS	6496
17	25	0	Inf. Dilution	lgK:2.9(0.1SD)	5	CMN	7391
18	25	0	Inf. Dilution	lgK:3.28(3SF)	2	ENS	7391


19	25	0	Inf. Dilution	lgK:3.32 (3SF)	2	MSL	8385
20	25	0	Inf. Dilution	lgK:3.00 (3SF)	4	CRV	8749
21	25	0	Inf. Dilution	lgK:2.984 (4SF)	6	MGL	9023
22	25	0	Inf. Dilution	lgK:2.98 (3SF)	6	MGL	9024
23	25	0	Inf. Dilution	lgK:2.88 (3SF)	3	CRV	9402
24	25	0	Inf. Dilution	lgK:2.996 (4SF)	4	MPS	27114
25	25	0	Inf. Dilution	lgK:3.01 (0.07SD)	6	MPT	27114
26	25	0	Inf. Dilution	lgK:2.98 (0.06SD)	5	MSP	29186
27	25	0	Inf. Dilution	lgK:2.98 (3SF)	3	EOD	30627
28	25	0	Inf. Dilution	lgK:2.98 (3SF)	4	CRV	32224
29	25	0	CHEMVAL1	lgK:2.92 (0.01SD)	0	ENS	5156
30	25	0	CHEMVAL2	lgK:0.40 (0.01SD)	0	ENS	5156
31	25	0	CHEMVAL3	lgK:2.92 (0.01SD)	0	ENS	5156
32	25	0	CHEMVAL4	lgK:2.92 (0.01SD)	5	ENS	5156
33	25	0	Inf. Dilution/m	lgK:3.01 (0.07SD)	6	MGL	26086
34	25	0	SOLMNEQ	lgK:3.40 (3SF)	0	CMN	5416
35	25	0	SOLVEQ	lgK:2.98 (3SF)	0	CMN	5416
36	25	0	UCT_Sea	lgK:2.92 (0.01SD)	4	EDH	5390
37	25	0	Unknown	lgK:2.981 (4SF)	3	ENS	7373
38	25	0	WATCH	lgK:2.98 (3SF)	4	CMN	5416
39	25	0	WATEQF	lgK:2.99 (3SF)	4	CMN	5416
40	25	0.1	UCT_Sea	lgK:2.19 (0.01SD)	4	EDH	5390
41	25	0.2	UCT_Sea	lgK:2.07 (0.01SD)	4	EDH	5390
42	25	0.3	UCT_Sea	lgK:2.03 (0.01SD)	2	EDH	5390
43	25	0.4	UCT_Sea	lgK:2.01 (0.01SD)	0	EDH	5390
44	25	0.5	UCT_Sea	lgK:2.02 (0.01SD)	0	EDH	5390
45	25	0.6	NaCl	lgK:2.05 (3SF)	0	MPT	8898
46	25	0.6	UCT_Sea	lgK:2.03 (0.01SD)	2	EDH	5390
47	25	0.7	NaCl	lgK:1.5 (2SF)	0	EES	5398
48	25	0.7	Seawater	lgK:1.51 (3SF)	0	ENS	405
49	25	0.7	Seawater	lgK:2.05 (3SF)	0	MEF	4996
50	25	0.7	UCT_Sea	lgK:2.05 (0.01SD)	0	EDH	5390
51	25	0.7	Unknown	lgK:2.1 (0.05SD)	0	MEF	4996
52	25	0.7	Unknown	lgK:2.05 (3SF)	0	MEF	5398
53	25	0.7	Unknown	lgK:2.05 (3SF)	0	EOD	5644
54	25	0.7	Unknown	lgK:1.94 (0.05SD)	2	CMN	7391

55	25	3	Inert	lgK:2.3 (2SF)	0	EOR	
56	25	3	NaClO4	lgK:1.79 (3SF)	3	MEF	338
57	25	3	NaClO4	lgK:1.73 (3SF)	0	CRV	552
58	25	3	NaClO4/m	lgK:1.79 (3SF)w	0	MPH	338
Note (58): Inconsistent with Gamsjager et al. [6211] Rxn. 69145 coz MPH perhaps							
59	30	0	Inf. Dilution	lgK:3.035 (4SF)	4	MPS	27114
60	35	0	Inf. Dilution	lgK:3.07 (3SF)	4	CRV	8749
61	35	0	Inf. Dilution	lgK:3.074 (4SF)	4	MPS	27114
62	37	0	Inf. Dilution	lgK:3.01 (3SF)	2	CRV	28703
63	37	0.15	Blood Plasma	lgK:2.9 (0.05SD)	0	ENS	94
64	40	0	Inf. Dilution	lgK:3.1 (0.02SD)	4	EDT	5416
65	40	0	Inf. Dilution	lgK:3.111 (4SF)	4	MPS	27114
66	40	0	Inf. Dilution	lgK:3.11 (0.06SD)	6	MPT	27114
67	40	0	Inf. Dilution/m	lgK:3.11 (0.06SD)	6	MSP	26086
68	45	0	Inf. Dilution	lgK:3.147 (4SF)	4	MPS	27114
69	50	0	Inf. Dilution	lgK:3.17 (3SF)	4	CRV	8749
70	50	0	Inf. Dilution	lgK:3.182 (4SF)	4	MPS	27114
71	50	0	SOLMNEQ	lgK:3.42 (3SF)	0	CMN	5416
72	50	0	SOLVEQ	lgK:3.12 (3SF)	0	CMN	5416
73	50	0	WATCH	lgK:3.12 (3SF)	4	CMN	5416
74	50	0	WATEQF	lgK:3.16 (3SF)	4	CMN	5416
75	55	0	Inf. Dilution	lgK:3.2 (0.03SD)	4	EDT	5416
76	55	0	Inf. Dilution	lgK:3.216 (4SF)	4	MPS	27114
77	60	0	Inf. Dilution	lgK:3.248 (4SF)	4	MPS	27114
78	60	0	Inf. Dilution	lgK:3.24 (0.05SD)	6	MPT	27114
79	60	0	Inf. Dilution/m	lgK:3.24 (3SF)	6	MGL	26086
80	65	0	Inf. Dilution	lgK:3.280 (4SF)	4	MPS	27114
81	70	0	Inf. Dilution	lgK:3.3 (0.04SD)	4	EDT	5416
82	70	0	Inf. Dilution	lgK:3.311 (4SF)	4	MPS	27114
83	75	0	SOLMNEQ	lgK:3.47 (3SF)	0	CMN	5416
84	75	0	WATCH	lgK:3.28 (3SF)	4	CMN	5416
85	75	0	WATEQF	lgK:3.32 (3SF)	4	CMN	5416
86	80	0	Inf. Dilution	lgK:3.37 (0.08SD)	6	MPH	27114
87	80	0	Inf. Dilution	lgK:3.370 (4SF)	4	MPS	27114
88	80	0	Inf. Dilution/m	lgK:3.37 (0.08SD)	6	MSP	26086
89	90	0	Inf. Dilution	lgK:3.4 (0.07SD)	4	EDT	5416

90	90	0	Inf. Dilution	lgK:3.425 (4SF)	4	MPS	27114
91	100	0	Inf. Dilution	lgK:3.48 (0.15SD)	6	MPH	27114
92	100	0	Inf. Dilution	lgK:3.478 (4SF)	4	MPS	27114
93	100	0	Inf. Dilution/m	lgK:3.48 (0.15SD)	6	MSP	26086
94	100	0	SOLMNEQ	lgK:3.55 (3SF)	4	CMN	5416
95	100	0	SOLVEQ	lgK:3.50 (3SF)	0	CMN	5416
96	100	0	WATCH	lgK:3.46 (3SF)	4	CMN	5416
97	100	0	WATEQF	lgK:3.49 (3SF)	4	CMN	5416
98	110	0	Inf. Dilution	lgK:3.527 (4SF)	4	MPS	27114
99	120	0	Inf. Dilution	lgK:3.574 (4SF)	4	MPS	27114
100	125	0	SOLMNEQ	lgK:3.65 (3SF)	4	CMN	5416
101	125	0	WATCH	lgK:3.67 (3SF)	4	CMN	5416
102	125	0	WATEQF	lgK:3.66 (3SF)	4	CMN	5416
103	130	0	Inf. Dilution	lgK:3.619 (4SF)	4	MPS	27114
104	140	0	Inf. Dilution	lgK:3.661 (4SF)	4	MPS	27114
105	150	0	Inf. Dilution	lgK:3.702 (4SF)	3	MPS	27114
106	150	0	SOLMNEQ	lgK:3.78 (3SF)	4	CMN	5416
107	150	0	SOLVEQ	lgK:3.97 (3SF)	0	CMN	5416
108	150	0	WATCH	lgK:3.90 (3SF)	4	CMN	5416
109	150	0	WATEQF	lgK:3.83 (3SF)	4	CMN	5416
110	175	0	SOLMNEQ	lgK:3.95 (3SF)	4	CMN	5416
111	175	0	WATCH	lgK:4.14 (3SF)	4	CMN	5416
112	175	0	WATEQF	lgK:3.99 (3SF)	4	CMN	5416
113	200	0	SOLMNEQ	lgK:4.16 (3SF)	3	CMN	5416
114	200	0	SOLVEQ	lgK:4.70 (3SF)	0	CMN	5416
115	200	0	WATCH	lgK:4.41 (3SF)	0	CMN	5416
116	200	0	WATEQF	lgK:4.16 (3SF)	3	CMN	5416
117	225	0	SOLMNEQ	lgK:4.43 (3SF)	3	CMN	5416
118	225	0	WATCH	lgK:4.69 (3SF)	0	CMN	5416
119	225	0	WATEQF	lgK:4.33 (3SF)	3	CMN	5416
120	250	0	SOLMNEQ	lgK:4.73 (3SF)	3	CMN	5416
121	250	0	SOLVEQ	lgK:5.70 (3SF)	0	CMN	5416
122	250	0	WATCH	lgK:5.00 (3SF)	0	CMN	5416
123	250	0	WATEQF	lgK:4.50 (3SF)	3	CMN	5416
124	275	0	SOLMNEQ	lgK:5.06 (3SF)	0	CMN	5416
125	275	0	WATCH	lgK:5.32 (3SF)	0	CMN	5416

126	275	0	WATEQF	lgK:4.66 (3SF)	0	CMN	5416
127	300	0	SOLMNEQ	lgK:5.40 (3SF)	0	CMN	5416
128	300	0	SOLVEQ	lgK:7.41 (3SF)	0	CMN	5416
129	300	0	WATCH	lgK:5.65 (3SF)	0	CMN	5416
130	300	0	WATEQF	lgK:4.83 (3SF)	0	CMN	5416
131	325	0	SOLMNEQ	lgK:5.75 (3SF)	0	CMN	5416
132	325	0	WATCH	lgK:6.01 (3SF)	0	CMN	5416
133	325	0	WATEQF	lgK:5.00 (3SF)	0	CMN	5416
134	350	0	SOLMNEQ	lgK:6.10 (3SF)	0	CMN	5416
135	350	0	WATCH	lgK:6.38 (3SF)	0	CMN	5416
136	350	0	WATEQF	lgK:5.17 (3SF)	0	CMN	5416
137	10:50	0	Inf. Dilution	dH:3. (1SF)	4	CRV	552
138	25	0	Inf. Dilution	dH:2.017 (4SF)	2	MTD	5416
139	25	0	Inf. Dilution	dH:2.713 (4SF)	4	ENS	6496
140	25	0	Inf. Dilution	dH:3.00 (3SF)	5	CRV	9402
141	25	0	Unknown	dH:2.535 (4SF)	3	ENS	7373


Reaction No. 1342



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.49 (4SF)	2	ENS	6405
2	25	0	Inf. Dilution	lgK:11.30 (4SF)	5	CRV	9402
3	25	0	Inf. Dilution	lgK:11.31 (4SF)	4	CRV	32224
4	25	0	CHEMVAL1	lgK:11.34 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL2	lgK:11.20 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL3	lgK:11.34 (0.01SD)	0	ENS	5156
7	25	0	CHEMVAL4	lgK:11.30 (0.01SD)	5	ENS	5156
8	25	0	UCT_Sea	lgK:11.41 (0.01SD)	0	EDH	5390
9	25	0	Unknown	lgK:11.397 (5SF)	3	ENS	7373
10	25	0.1	UCT_Sea	lgK:10.59 (0.01SD)	0	EDH	5390
11	25	0.2	UCT_Sea	lgK:10.37 (0.01SD)	0	EDH	5390
12	25	0.3	UCT_Sea	lgK:10.19 (0.01SD)	0	EDH	5390
13	25	0.4	UCT_Sea	lgK:10.06 (0.01SD)	0	EDH	5390
14	25	0.5	UCT_Sea	lgK:9.95 (0.01SD)	0	EDH	5390
15	25	0.6	UCT_Sea	lgK:9.84 (0.01SD)	0	EDH	5390
16	25	0.7	UCT_Sea	lgK:9.75 (0.01SD)	0	EDH	5390


17	25	0.7	Unknown	lgK:9.80 (3SF)	4	EOD	5644
18	25	3	Inert	lgK:10.1 (3SF)	1	EOR	
19	37	0.15	Blood Plasma	lgK:10.7 (0.05SD)	0	ENS	94
20	25	0	Unknown	dH:-2.775 (4SF)	3	ENS	7373

Reaction No. 1374



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-250.20 (5SF)	4	CRV	10174
2	25	0	Inf. Dilution	dG:-1047.00 (6SF) kJ	4	CRV	23205
3	25	0	Inf. Dilution	dG:-1047.00 (6SF) kJ	3	EOD	23205
4	25	0	Inf. Dilution	dG:-1048.3 (5SF) kJ	5	EFE	26086
5	50	0	Inf. Dilution	dG:-250.19 (5SF)	2	CRV	10174
6	75	0	Inf. Dilution	dG:-250.28 (5SF)	2	CRV	10174
7	100	0	Inf. Dilution	dG:-250.46 (5SF)	2	CRV	10174
8	125	0	Inf. Dilution	dG:-250.71 (5SF)	3	CRV	10174
9	150	0	Inf. Dilution	dG:-251.03 (5SF)	1	CRV	10174
10	175	0	Inf. Dilution	dG:-251.41 (5SF)	0	CRV	10174
11	200	0	Inf. Dilution	dG:-251.84 (5SF)	0	CRV	10174
12	225	0	Inf. Dilution	dG:-252.32 (5SF)	0	CRV	10174
13	250	0	Inf. Dilution	dG:-252.82 (5SF)	0	CRV	10174
14	300	0	Inf. Dilution	dG:-253.91 (5SF)	0	CRV	10174
15	25	0	Inf. Dilution	dH:-1156.2 (5SF) kJ	5	EFE	26086

Reaction No. 1375



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-139.70 (5SF)	3	CRV	10174
2	50	0	Inf. Dilution	dG:-139.23 (5SF)	2	CRV	10174
3	75	0	Inf. Dilution	dG:-138.83 (5SF)	2	CRV	10174
4	100	0	Inf. Dilution	dG:-138.49 (5SF)	1	CRV	10174
5	125	0	Inf. Dilution	dG:-138.20 (5SF)	1	CRV	10174
6	150	0	Inf. Dilution	dG:-137.95 (5SF)	1	CRV	10174
7	175	0	Inf. Dilution	dG:-137.73 (5SF)	0	CRV	10174
8	200	0	Inf. Dilution	dG:-137.54 (5SF)	0	CRV	10174
9	225	0	Inf. Dilution	dG:-137.38 (5SF)	0	CRV	10174


10	250	0	Inf. Dilution	dG:-137.22 (5SF)	0	CRV	10174
11	300	0	Inf. Dilution	dG:-136.92 (5SF)	0	CRV	10174

Reaction No. 1376




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-287.83 (5SF)	3	CRV	10174
2	50	0	Inf. Dilution	dG:-287.99 (5SF)	3	CRV	10174
3	75	0	Inf. Dilution	dG:-288.46 (5SF)	3	CRV	10174
4	100	0	Inf. Dilution	dG:-289.21 (5SF)	3	CRV	10174
5	125	0	Inf. Dilution	dG:-290.18 (5SF)	3	CRV	10174
6	150	0	Inf. Dilution	dG:-291.36 (5SF)	3	CRV	10174
7	175	0	Inf. Dilution	dG:-292.74 (5SF)	3	CRV	10174
8	200	0	Inf. Dilution	dG:-294.29 (5SF)	3	CRV	10174
9	225	0	Inf. Dilution	dG:-296.01 (5SF)	3	CRV	10174
10	250	0	Inf. Dilution	dG:-297.88 (5SF)	3	CRV	10174
11	300	0	Inf. Dilution	dG:-302.03 (5SF)	3	CRV	10174

Reaction No. 1377



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-198.52 (5SF)	4	CRV	10174
2	50	0	Inf. Dilution	dG:-198.28 (5SF)	4	CRV	10174
3	75	0	Inf. Dilution	dG:-198.18 (5SF)	4	CRV	10174
4	100	0	Inf. Dilution	dG:-198.20 (5SF)	4	CRV	10174
5	125	0	Inf. Dilution	dG:-198.32 (5SF)	4	CRV	10174
6	150	0	Inf. Dilution	dG:-198.53 (5SF)	4	CRV	10174
7	175	0	Inf. Dilution	dG:-198.82 (5SF)	4	CRV	10174
8	200	0	Inf. Dilution	dG:-199.17 (5SF)	4	CRV	10174
9	225	0	Inf. Dilution	dG:-199.59 (5SF)	4	CRV	10174
10	250	0	Inf. Dilution	dG:-200.05 (5SF)	4	CRV	10174
11	300	0	Inf. Dilution	dG:-201.07 (5SF)	4	CRV	10174


Reaction No. 1404



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:6.36 (3SF)	3	EOD	29579

2	20	0	Inf. Dilution	lgK:6.39 (3SF)	3	EOD	29579
3	23	0.01	Unknown	lgK:2.52 (3SF)	0	MIS	4547
4	25	0	Inf. Dilution	lgK:5.8 (0.1SD)	3	EES	7391
5	25	0	Inf. Dilution	lgK:5.63 (3SF)	4	CRV	8749
6	25	0	Inf. Dilution	lgK:6.43 (3SF)	3	EOD	29579
7	25	0	Inf. Dilution	lgK:6.59 (3SF)	2	CRV	32224
8	25	0	CHEMVAL2	lgK:6.47 (0.01SD)	0	ENS	5156
9	25	0	CHEMVAL3	lgK:6.47 (0.01SD)	0	ENS	5156
10	25	0	CHEMVAL4	lgK:4.83 (0.01SD)	0	ENS	5156
11	25	0	UCT_Sea	lgK:5.86 (0.01SD)	3	EDH	5390
12	25	0.1	UCT_Sea	lgK:4.60 (0.01SD)	4	EDH	5390
13	25	0.15	NaCl	lgK:1.9 (2SF)	0	MCT	22612
14	25	0.2	NaCl	lgK:3.13 (0.01SD)	0	MGL	5217
15	25	0.2	UCT_Sea	lgK:4.32 (0.01SD)	4	EDH	5390
16	25	0.3	UCT_Sea	lgK:4.16 (0.01SD)	4	EDH	5390
17	25	0.4	UCT_Sea	lgK:4.05 (0.01SD)	4	EDH	5390
18	25	0.5	UCT_Sea	lgK:3.98 (0.01SD)	4	EDH	5390
19	25	0.6	UCT_Sea	lgK:3.93 (0.01SD)	4	EDH	5390
20	25	0.68	Unknown	lgK:3.56 (3SF)	4	MGL	7177
21	25	0.7	UCT_Sea	lgK:3.90 (0.01SD)	4	EDH	5390
22	25	0.7	Unknown	lgK:3.56 (3SF)	3	ENS	7177
23	25	0.7	Unknown	lgK:3.84 (0.1SD)	5	CMN	7391
24	25	0.7	Unknown	lgK:4.2 (2SF)	3	ENS	7391
25	30	0	Inf. Dilution	lgK:6.47 (3SF)	2	EOD	29579
26	30	0.3	Unknown	lgK:1.2 (2SF)	0	MSP	4547
Note (26): Appears to be conditional on pH							
27	35	0	Inf. Dilution	lgK:6.52 (3SF)	0	EOD	29579
28	37	0	Inf. Dilution	lgK:5.88 (3SF)	2	CRV	28703
29	37	0.15	Blood Plasma	lgK:3.5 (0.05SD)	4	ENS	94
30	37	0.15	KNO3	lgK:3.4 (0.1SD)	5	MSP	255
31	37	0.15	NaCl	lgK:2.9 (2SF)	0	MCT	22612
32	38	0	Inf. Dilution	lgK:6.54 (3SF)	0	CRV	8692


Reaction No. 1405



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0	Inf. Dilution	lgK:15.26(4SF)	5	CRV	9402
2	25	0	Inf. Dilution	lgK:15.18(4SF)	4	CRV	32224
3	25	0	CHEMVAL2	lgK:15.26(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:15.26(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:15.10(0.01SD)	3	ENS	5156
6	25	0	UCT_Sea	lgK:15.16(0.01SD)	3	EDH	5390
7	25	0.1	UCT_Sea	lgK:13.73(0.01SD)	3	EDH	5390
8	25	0.2	UCT_Sea	lgK:13.39(0.01SD)	3	EDH	5390
9	25	0.3	UCT_Sea	lgK:13.19(0.01SD)	3	EDH	5390
10	25	0.4	UCT_Sea	lgK:13.04(0.01SD)	3	EDH	5390
11	25	0.5	UCT_Sea	lgK:12.91(0.01SD)	3	EDH	5390
12	25	0.6	UCT_Sea	lgK:12.84(0.01SD)	3	EDH	5390
13	25	0.7	UCT_Sea	lgK:12.79(0.01SD)	3	EDH	5390
14	25	3	Inert	lgK:13.5(3SF)	1	EOR	
15	37	0	Inf. Dilution	lgK:15.16(4SF)	2	CRV	28703
16	37	0.15	Blood Plasma	lgK:13.2(0.05SD)	2	ENS	94
17	100	0	Inf. Dilution	lgK:15.1(3SF)	5	MGL	5156
18	25	0	Inf. Dilution	dH:-0.50(2SF)	5	CRV	9402

Reaction No. 1406



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.03(4SF)	4	CRV	32224
2	25	0	CHEMVAL2	lgK:20.69(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:20.69(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:20.70(0.01SD)	0	ENS	5156
5	25	0	UCT_Sea	lgK:20.68(0.01SD)	0	EDH	5390
6	25	0.1	UCT_Sea	lgK:19.20(0.01SD)	0	EDH	5390
7	25	0.2	UCT_Sea	lgK:18.71(0.01SD)	0	EDH	5390
8	25	0.3	UCT_Sea	lgK:18.56(0.01SD)	0	EDH	5390
9	25	0.4	UCT_Sea	lgK:18.38(0.01SD)	0	EDH	5390
10	25	0.5	UCT_Sea	lgK:18.22(0.01SD)	0	EDH	5390
11	25	0.6	UCT_Sea	lgK:18.11(0.01SD)	0	EDH	5390
12	25	0.7	UCT_Sea	lgK:18.01(0.01SD)	0	EDH	5390
13	37	0	Inf. Dilution	lgK:20.53(4SF)	2	CRV	28703
14	37	0.15	Blood Plasma	lgK:18.7(0.05SD)	0	ENS	94

Reaction No. 1407							
$2\text{<PO4-3>} + \text{Mg+2} + 3\text{<H+1>} = \text{Mg+2_H+1(3)_PO4-3(2)}$							
Note: See comment on $\text{Mg+2_H+1(2)_PO4-3} + \text{H+1_PO4-3} = \text{Mg+2_H+1(3)_PO4-3(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:35.24(4SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:32.3(0.05SD)	0	ENS	94

Reaction No. 1408							
$2\text{<PO4-3>} + 2\text{<Mg+2>} + 2\text{<H+1>} = \text{Mg+2(2)_H+1(2)_PO4-3(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:31.0(3SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:27.6(0.05SD)	0	ENS	94


Reaction No. 1409							
$2\text{<PO4-3>} + \text{Mg+2} + 2\text{<H+1>} = \text{Mg+2_H+1(2)_PO4-3(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:27.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:25.3(0.05SD)	4	ENS	94

Reaction No. 1429							
$\text{SiH2O4-2} + \text{Mg+2} = \text{Mg+2_SiH2O4-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:5.32(0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:4.58(0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:4.43(0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:4.35(0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:4.30(0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:4.26(0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:4.23(0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:4.21(0.01SD)	4	EDH	5390
9	25	1	NaClO4	lgK:4.2(0.05SD)	5	MIS	455
10	37	0.15	Blood Plasma	lgK:4.2(0.05SD)	4	ENS	94

Reaction No. 1430							
$\text{SiH2O4-2} + \text{Mg+2} + \text{H+1} = \text{Mg+2_H+1_SiH2O4-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	UCT_Sea	lgK:14.20(0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:13.48(0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:13.35(0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:13.28(0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:13.24(0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:13.21(0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:13.19(0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:13.18(0.01SD)	4	EDH	5390
9	37	0.15	Blood Plasma	lgK:12.0(0.05SD)	4	ENS	94

Reaction No. 1431




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:30.82(0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:29.50(0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:29.26(0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:29.12(0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:29.03(0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:28.96(0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:28.93(0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:28.90(0.01SD)	4	EDH	5390
9	37	0.15	Blood Plasma	lgK:26.6(0.05SD)	4	ENS	94

Reaction No. 1482



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.3(3SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:10.5(0.05SD)	3	ENS	94


Reaction No. 1535



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.9(2SF)	1	ELC	
2	25	0.1	Me4NC1	lgK:3.85(3SF)	0	MGL	152
3	37	0.15	Blood Plasma	lgK:4.1(0.05SD)	0	ENS	94
4	37	0.15	NaCl	lgK:4.89(0.09SD)	4	MGL	28777
5	37	0.15	NaCl	lgK:4.58(0.09SD)	2	MIS	28777

6	37	0.15	NaClO4	lgK:5.1(0.04SD)	3	MGL	2181
---	----	------	--------	-----------------	---	-----	------

Reaction No. 1536




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.2(2SF)	3	ENS	2152
2	25	0.1	KNO3	lgK:7.7(0.2SD)	4	MGL	3519
3	25	0.1	NaCl	lgK:7.6(0.1SD)	4	MGL	3925
4	25	0.5	NaClO4	lgK:6.5(0.1MD)	0	MGL	4896
5	37	0	Inf. Dilution	lgK:13.07(4SF)	0	CRV	28703

Note (5): Obvious typo


6	37	0.1	Inert	lgK:7.63(3SF)	4	CRV	29801
7	37	0.1	KNO3	lgK:7.23(3SF)	2	MGL	9424
8	37	0.15	Blood Plasma	lgK:7.3(0.05SD)	2	ENS	94
9	37	0.15	NaCl	lgK:7.40(0.07SD)	4	MGL	28777
10	37	0.15	NaCl	lgK:7.69(0.05SD)	2	MIS	28777
11	37	0.15	NaClO4	lgK:7.5(0.02SD)	3	MGL	2181

Reaction No. 1537



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2(3SF)	3	MGL	22560
2	37	0	Inf. Dilution	lgK:12.43(4SF)	2	CRV	28703
3	37	0.15	Blood Plasma	lgK:10.0(0.05SD)	0	ENS	94
4	37	0.15	NaCl	lgK:10.83(0.19SD)	2	MGL	28777
5	37	0.15	NaCl	lgK:11.52(0.10SD)	0	MIS	28777
6	37	0.15	NaClO4	lgK:11.0(0.07SD)	3	MGL	2181


Reaction No. 1572



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:0.93(2SF)	5	MHY	4920
2	25	0	Inf. Dilution	lgK:1.37(3SF)	6	MHY	999
3	25	0.15	NaCl	lgK:0.61(2SF)	3	MCT	22612
4	25	0.5	NaClO4	lgK:0.9(0.08MD)	3	MGL	4896
5	25	1	NaClO4	lgK:0.75(2SF)	5	MIX	7703
6	25	1	Unknown	lgK:0.73(2SF)	6	MQH	999


7	37	0.15	Blood Plasma	lgK:0.8(1SF)	4	ENS	94
8	37	0.15	NaCl	lgK:0.64(2SF)	2	MCT	22612
9	37	0.15	NaCl	lgK:1.07(0.06SD)	4	MGL	28777
10	37	0.15	NaCl	lgK:1.04(0.03SD)	4	MIS	28777
11	37	0.15	NaClO4	lgK:1.23(0.004SD)	0	MGL	2181

Reaction No. 1573




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:1.27(3SF)	5	MIX	7703
2	25	1	Unknown	lgK:1.30(3SF)	6	MQH	999
3	37	0.15	Blood Plasma	lgK:1.8(0.05SD)	4	ENS	94

Reaction No. 1616



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:1.70(3SF)	5	MGL	154
2	20:25	4	KCl	lgK:1.55(3SF)	5	MHY	999
3	25	0	UCT_Sea	lgK:2.44(0.01SD)	4	EDH	5390
4	25	0.1	UCT_Sea	lgK:1.71(0.01SD)	4	EDH	5390
5	25	0.1	Unknown	lgK:1.70(3SF)	6	MGL	1217
6	25	0.2	UCT_Sea	lgK:1.56(0.01SD)	4	EDH	5390
7	25	0.3	UCT_Sea	lgK:1.51(0.01SD)	4	EDH	5390
8	25	0.4	UCT_Sea	lgK:1.47(0.01SD)	4	EDH	5390
9	25	0.5	UCT_Sea	lgK:1.45(0.01SD)	4	EDH	5390
10	25	0.6	UCT_Sea	lgK:1.43(0.01SD)	4	EDH	5390
11	25	0.7	UCT_Sea	lgK:1.42(0.01SD)	4	EDH	5390
12	25	1	NaNO3	lgK:1.42(3SF)	6	MGL	1506
13	37	0.15	Blood Plasma	lgK:1.5(0.05SD)	3	ENS	94
14	25	1	NaNO3	dH:0.97(0.01SD)	5	MCL	1506

Reaction No. 1617



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.96(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.0(0.05SD)	4	ENS	94

Reaction No. 1618							
Mg+2 + H+1 + Malic-2 = Mg+2_H+1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:6.34(0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:5.58(0.01SD)	4	EDH	5390
3	25	0.1	Unknown	lgK:5.61(3SF)	6	MGL	1217
4	25	0.2	UCT_Sea	lgK:5.46(0.01SD)	4	EDH	5390
5	25	0.3	UCT_Sea	lgK:5.38(0.01SD)	4	EDH	5390
6	25	0.4	UCT_Sea	lgK:5.32(0.01SD)	4	EDH	5390
7	25	0.5	UCT_Sea	lgK:5.29(0.01SD)	4	EDH	5390
8	25	0.6	UCT_Sea	lgK:5.26(0.01SD)	4	EDH	5390
9	25	0.7	UCT_Sea	lgK:5.25(0.01SD)	4	EDH	5390
10	37	0.15	Blood Plasma	lgK:5.6(0.05SD)	4	ENS	94

Reaction No. 1661							
Oxalic-2 + Mg+2 = Mg+2_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18	0	Inf. Dilution	lgK:3.43(3SF)	3	MCN	8670
2	20	0.1	KClO4	lgK:2.39(0.05SD)	0	MDS	931
3	20	0.1	NaNO3	lgK:2.76(3SF)w	3	MPH	140
4	20	0.1	Unknown	lgK:2.76(3SF)	5	ENS	773
5	23	0.2	KCl	lgK:2.61(3SF)	3	MSC	931
6	25	0	Inf. Dilution	lgK:4.38(3SF)	0	MSL	7927
7	25	0	Inf. Dilution	lgK:3.432(4SF)	3	EOD	12002
8	25	0	Inf. Dilution	lgK:3.43(3SF)	4	CRV	18273
Note (8): Table 3, p. 85							
9	25	0	Inf. Dilution	lgK:3.560(0.02SD)	5	CRV	20830
10	25	0.15	NaCl	lgK:2.18(3SF)	2	MCT	22612
11	25	0.2	KCl	lgK:2.55(3SF)	3	MHY	140
12	25	0.8	NaClO4	lgK:1.62(3SF)	2	MSL	11516
Note (12): Fedorova V et al., Zhur. Neorg. Khim., 1977, 22, 1215							
13	35	0.1	KNO3	lgK:4.65(3SF)	0	MGL	1187
14	37	0.03:0.5	Et4N+ salt	lgK:2.75(3SF)	0	MGL	2261
15	37	0	Inf. Dilution	lgK:3.41(3SF)	3	MCN	140
16	37	0	Inf. Dilution	lgK:3.62(3SF)	2	CRV	28703
17	37	0.03	Me4NI	lgK:3.02(0.03MD)	5	MGL	29801

18	37	0.05	Me4NI	lgK:2.92 (0.03MD)	5	MGL	29801
19	37	0.1	Me4NI	lgK:2.75 (0.04MD)	5	MGL	29801
20	37	0.15	Blood Plasma	lgK:2.4 (0.05SD)	2	ENS	94
21	37	0.15	NaCl	lgK:2.39 (3SF)	2	MCT	22612
22	37	0.3	Me4NI	lgK:2.54 (0.04MD)	3	MGL	29801
23	37	0.5	Me4NI	lgK:2.52 (0.04MD)	3	MGL	29801
24	37	0.62	Unknown	lgK:2.28 (3SF)	0	MSL	140
25	38	0	Inf. Dilution	lgK:3.60 (3SF)	4	MSL	6472
26	38	0	Inf. Dilution	lgK:3.60 (3SF)	3	CRV	8692

Reaction No. 1662							
2<Oxalic-2> + Mg+2 = Mg+2_Oxalic-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.38 (3SF)	3	MSL	140
2	25	0	Inf. Dilution	lgK:5.17 (0.04SD)	5	CRV	20830
3	25	0.03	Unknown	lgK:4.54 (3SF)	5	MAG	931
4	25	0.09	Unknown	lgK:4.24 (3SF)	5	MEF	931
5	25	0.1	Unknown	lgK:4.24 (3SF)	5	ENS	773
6	37	0	Inf. Dilution	lgK:4.38 (3SF)	2	CRV	28703
7	37	0.15	Blood Plasma	lgK:3.8 (0.05SD)	4	ENS	94

Reaction No. 1663							
Oxalic-2 + Mg+2 + H+1 = Mg+2_H+1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.76 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.8 (0.05SD)	4	ENS	94

Reaction No. 1692							
Pyruvic-1 + Mg+2 = Mg+2_Pyruvic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.28 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:0.8 (0.05SD)	4	ENS	94

Reaction No. 1710							
Salicylic-2 + Mg+2 = Mg+2_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Me4NC1	lgK:1.59 (3SF)	0	MCL	11516

Note (1): Mironov V et al., Zhur. Neorg. Khim., 1997, 42, 787							
2	25	0	UCT_Sea	lgK:5.50(0.01SD)	4	EDH	5390
3	25	0.1	UCT_Sea	lgK:4.97(0.01SD)	4	EDH	5390
4	25	0.2	UCT_Sea	lgK:4.89(0.01SD)	4	EDH	5390
5	25	0.3	UCT_Sea	lgK:4.84(0.01SD)	4	EDH	5390
6	25	0.4	UCT_Sea	lgK:4.82(0.01SD)	4	EDH	5390
7	25	0.5	UCT_Sea	lgK:4.81(0.01SD)	4	EDH	5390
8	25	0.6	UCT_Sea	lgK:4.80(0.01SD)	4	EDH	5390
9	25	0.7	UCT_Sea	lgK:4.80(0.01SD)	4	EDH	5390
10	37	0.15	Blood Plasma	lgK:5.1(0.05SD)	4	ENS	94
11	37	0.15	NaClO4	lgK:5.16(0.01SD)	3	MGL	107
12	23	0	Dioxan:Water 50:50Vol Inf. Dilution	lgK:3.69(3SF)	5	ENS	4455
13	25		Methanol	lgK:4.2(2SF)	5	MPT	2599
14	25		Methanol	dH:-27.4(3SF)kJ	5	MCL	4795


Reaction No. 1711							
2<Salicylic-2> + Mg+2 = Mg+2_Salicylic-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:9.5(0.05SD)	3	ENS	94
3	25		Methanol	lgK:6.6(2SF)	5	MPT	2599
4	25		Methanol	dH:-38.7(3SF)kJ	5	MCL	4795

Reaction No. 1712							
Salicylic-2 + Mg+2 + H+1 = Mg+2_H+1_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.6(3SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:13.9(0.05SD)	3	ENS	94

Reaction No. 1741							
Succinic-2 + Mg+2 = Mg+2_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.035	KCl	lgK:1.79(3SF)	4	MSP	5748
2	25	0	Inf. Dilution	lgK:2.05(3SF)	4	CRV	18273
Note (2): Table 3, p. 85							
3	25	0	UCT_Sea	lgK:2.05(0.01SD)	4	EDH	5390


4	25	0.1	UCT_Sea	lgK:1.28(0.01SD)	4	EDH	5390
5	25	0.2	KCl	lgK:1.20(3SF)	6	MHY	999
6	25	0.2	UCT_Sea	lgK:1.11(0.01SD)	4	EDH	5390
7	25	0.3	UCT_Sea	lgK:1.01(0.01SD)	4	EDH	5390
8	25	0.4	UCT_Sea	lgK:0.94(0.01SD)	4	EDH	5390
9	25	0.5	UCT_Sea	lgK:0.89(0.01SD)	4	EDH	5390
10	25	0.6	UCT_Sea	lgK:0.85(0.01SD)	4	EDH	5390
11	25	0.7	UCT_Sea	lgK:0.81(0.01SD)	4	EDH	5390
12	37	0.15	Blood Plasma	lgK:1.2(0.05SD)	3	ENS	94

Reaction No. 1742




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.06(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.1(0.05SD)	4	ENS	94

Reaction No. 1743



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:6.56(0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:5.82(0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:5.69(0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:5.62(0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:5.58(0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:5.56(0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:5.55(0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:5.55(0.01SD)	4	EDH	5390
9	37	0.15	Blood Plasma	lgK:5.8(0.05SD)	4	ENS	94

Reaction No. 1780



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:1.36(3SF)	6	MGL	1217
2	25	0.2	KCl	lgK:1.36(3SF)	6	MHY	999
3	25	0.5	NaClO4	lgK:1.1(0.08MD)	6	MGL	4896
4	37	0.15	Blood Plasma	lgK:1.5(0.05SD)	3	ENS	94
5	37	0.2	NaClO4	lgK:1.91(3SF)	6	MGL	999

Reaction No. 1781							
$2<\text{Tartaric-2}> + \text{Mg+2} = \text{Mg+2_Tartaric-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:2.0(0.05SD)	4	ENS	94

Reaction No. 1782							
$\text{Mg+2} + \text{H+1} + \text{Tartaric-2} = \text{Mg+2_H+1_Tartaric-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:4.87(3SF)	6	MGL	1217
2	37	0.15	Blood Plasma	lgK:5.0(0.05SD)	4	ENS	94

Reaction No. 1811							
$\text{Pen-2} + \text{Mg+2} = \text{Mg+2_Pen-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:2.713(4SF)	5	MGL	3504
2	37	0.15	Blood Plasma	lgK:2.6(0.05SD)	4	ENS	94

Reaction No. 1812							
$2<\text{Pen-2}> + \text{Mg+2} = \text{Mg+2_Pen-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:3.5(0.05SD)	4	ENS	94

Reaction No. 1838							
$\text{OxPen-2} + \text{Mg+2} + \text{H+1} = \text{Mg+2_H+1_OxPen-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:10.3(0.05SD)	3	ENS	94

Reaction No. 1839							
$2<\text{OxPen-2}> + \text{Mg+2} + 2<\text{H+1}> = \text{Mg+2_H+1(2)_OxPen-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:19.8(0.05SD)	3	ENS	94

Reaction No. 1874							
$\text{GSH-3} + \text{Mg+2} = \text{Mg+2_GSH-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.1(2SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:4.0(0.05SD)	4	ENS	94

Reaction No. 1875							
$2\text{<GSH-3>} + \text{Mg}^{+2} = \text{Mg}^{+2}\text{GSH-3(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.3(2SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:4.2(0.05SD)	4	ENS	94

Reaction No. 2013							
$\text{Desfer-2} + \text{Mg}^{+2} = \text{Mg}^{+2}\text{Desfer-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:4.30(3SF)	5	MGL	3572
2	25	0	Inf. Dilution	lgK:5.2(2SF)	4	ENS	6405
3	37	0.15	Blood Plasma	lgK:4.2(0.05SD)	4	ENS	94

Reaction No. 2039							
$\text{DTPA-5} + \text{Mg}^{+2} + \text{H}^{+1} = \text{Mg}^{+2}\text{H}^{+1}\text{DTPA-5}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.5(0.05SD)	4	ENS	94
3	37	0.15	NaCl	lgK:15.52(0.01SD)	5	MGL	1940

Reaction No. 2040							
$\text{DTPA-5} + \text{Mg}^{+2} + 2\text{<H}^{+1}\text{>} = \text{Mg}^{+2}\text{H}^{+1(2)}\text{DTPA-5}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.2(0.05SD)	3	ENS	94
3	37	0.15	NaCl	lgK:20.2(0.03SD)	5	MGL	1940

Reaction No. 2041							
$\text{DTPA-5} + \text{Mg}^{+2} + 3\text{<H}^{+1}\text{>} = \text{Mg}^{+2}\text{H}^{+1(3)}\text{DTPA-5}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:27.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.9(0.05SD)	4	ENS	94
3	37	0.15	NaCl	lgK:23.9(0.03SD)	5	MGL	1940

Reaction No. 2062							
$\text{CDTA-4} + \text{Mg}^{+2} = \text{Mg}^{+2}\text{CDTA-4}$							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0.5	0.1	KNO3	lgK:10.45 (4SF)	0	MGL	999
2	20	0.1	KCl	lgK:10.32 (4SF)	6	MHY	1947
3	20	0.1	KNO3	lgK:10.32 (4SF)	6	MPT	197
4	20	0.1	KNO3	lgK:10.97 (4SF)	0	MGL	1963
5	20	0.1	Unknown	lgK:11.00 (4SF)	0	ENS	1539
6	25	0	Inf. Dilution	lgK:12.8 (3SF)	2	ENS	6405
7	25	0.1	Unknown	lgK:11.07 (4SF)	0	ENS	2016
8	25.3	0.1	KNO3	lgK:10.41 (4SF)	6	MGL	999
9	37	0.15	Blood Plasma	lgK:9.8 (0.05SD)	0	ENS	94
10	42.4	0.1	KNO3	lgK:10.31 (4SF)	3	MGL	999
11	20	0.1	KNO3	dH:3.80 (3SF)	4	MCL	1963
12	20	1	KCl	dH:1.89 (3SF)	5	MCL	2018
13	25	0.1	KNO3	dH:1.6 (2SF)	4	MCL	139
14	25	0.1	Methanol:Water 99:1Wgt NaClO4	lgK:10.2 (3SF)	4	MGL	906

Reaction No. 2094							
EDDA-2 + Mg+2 = Mg+2_EDDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.53 (3SF)	0	MGL	1941
2	25	0.1	KNO3	lgK:3.95 (3SF)	5	MGL	2028
3	25	0.1	NaClO4	lgK:4.3 (2SF)	3	MCL	1685
4	30	0.1	KCl	lgK:3.9 (2SF)	2	MGL	6500
5	37	0.15	Blood Plasma	lgK:3.9 (0.05SD)	2	ENS	94
6	37	0.15	NaCl	lgK:3.90 (3SF)	5	MDG	1779
7	25	0.1	NaClO4	dH:12.3 (3SF) kJ	5	MCL	1685

Reaction No. 2120							
EGTA-4 + Mg+2 = Mg+2_EGTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.21 (3SF)	6	MHY	1957
2	20	0.1	KCl	lgK:5.30 (3SF)	5	MGL	3584
3	20	0.1	KNO3	lgK:5.2 (2SF)	4	MGL	1956
4	25	0.1	KNO3	lgK:5.2 (2SF)	4	MGL	999
5	25	0.1	Unknown	lgK:5.4 (2SF)	4	MGL	999

6	37	0.15	Blood Plasma	lgK:5.0(0.05SD)	4	ENS	94
7	20	0.1	KNO3	dH:5.18(3SF)	5	MCL	1956
8	25	0.1	KCl	dH:5.5(0.1SD)	5	MCL	999
9	25	0.1	KNO3	dH:4.4(2SF)	5	MCL	139
10	20	0.1	KNO3	dS:41.5(3SF)	5	EFE	1956
11	25	0.1	Methanol:Water 99:1Wgt NaClO4	lgK:6.3(2SF)	5	MGL	906

Reaction No. 2121							
EGTA-4 + Mg+2 + H+1 = Mg+2_H+1_EGTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.0(3SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:12.6(0.05SD)	2	ENS	94

Reaction No. 2143							
EHPG-4 + Mg+2 = Mg+2_EHPG-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:8.00(3SF)	6	MGL	1941
2	37	0.15	Blood Plasma	lgK:7.7(0.05SD)	4	ENS	94
3	25	0.1	KNO3	dH:2.51(3SF)	5	MCL	1941


Reaction No. 2144							
EHPG-4 + Mg+2 + H+1 = Mg+2_H+1_EHPG-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:16.5(0.05SD)	4	ENS	94

Reaction No. 2145							
EHPG-4 + Mg+2 + 2<H+1> = Mg+2_H+1(2)_EHPG-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:24.0(0.05SD)	4	ENS	94

Reaction No. 2168							
EEDTA-4 + Mg+2 = Mg+2_EEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:8.32(3SF)	6	MGL	1957
2	20	0.1	KNO3	lgK:8.32(3SF)	6	MGL	1956
3	37	0.15	Blood Plasma	lgK:8.3(0.05SD)	4	ENS	94


4	20	0.1	KNO3	dH:3.51 (3SF)	5	MCL	1956
5	25	0.1	KNO3	dH:3.6 (2SF)	5	MCL	139

Reaction No. 2169




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:13.0 (0.05SD)	4	ENS	94

Reaction No. 2201



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:6.31 (3SF)	4	MHY	140
2	0.5	0.1	KNO3	lgK:5.33 (3SF)	2	MGL	1118
3	10	0	Inf. Dilution	lgK:6.39 (3SF)	4	MHY	140
4	20	0	Inf. Dilution	lgK:6.50 (3SF)	4	MHY	140
5	20	0	Inf. Dilution	lgK:7.0 (2SF)	2	MHY	1118
6	20	0.1	KCl	lgK:5.43 (3SF)	6	CMN	1118
7	20	0.1	KCl	lgK:5.46 (0.02SD)	3	MGL	2595
8	20	0.1	KCl	lgK:5.41 (3SF)	6	MGL	3486
9	23	0.1	NH4Cl	lgK:6.4 (2SF)	0	MCG	906
10	25	0	Inf. Dilution	lgK:6.500 (4SF)	3	CRV	552
11	25	0.1	Unknown	lgK:5.5 (0.03SD)	6	CRV	552
12	25.3	0.1	KNO3	lgK:5.36 (3SF)	3	MGL	1118
13	30	0	Inf. Dilution	lgK:6.61 (3SF)	4	MHY	140
14	37	0.15	Blood Plasma	lgK:5.1 (0.05SD)	0	ENS	94
15	42.4	0.1	KNO3	lgK:5.37 (3SF)	2	MGL	1118
16	20	0.1	KNO3	dH:4.2 (2SF)	6	CMN	1118
17	20	0.1	KNO3	dH:4.07 (3SF)	4	MCL	1118
18	20	0.1	KNO3	dH:4.44 (3SF)	4	MCL	1118
19	20:40	0.1	KNO3	dH:3.0 (2SF)	2	MCL	3201
20	25	0.1	KNO3	dH:4.4 (2SF)	5	MTD	6627
21	25	0.1	Unknown	dH:4.3 (2SF)	6	CRV	552
22	30	0	Inf. Dilution	dH:4.8 (2SF)	4	MHY	140


Reaction No. 2202



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	20	0.1	KCl	lgK:10.2 (3SF)	5	MGL	19653
2	25	0	Inf. Dilution	lgK:9.5 (2SF)	1	ELC	
3	37	0.15	Blood Plasma	lgK:7.0 (0.05SD)	4	ENS	94

Reaction No. 2203



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-6.5 (2SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:-6.5 (0.05SD)	4	ENS	94

Reaction No. 2221



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:1.50 (3SF)	4	CRV	8888
2	23	0.2	KCl	lgK:0.51 (2SF)	0	MHY	4920

Note (2): Low wgt for internal consistency

3	25	0	Inf. Dilution	lgK:1.25 (3SF)	5	MGL	380
4	25	0	Inf. Dilution	lgK:0.82 (2SF)	5	MSL	380
5	25	0	Inf. Dilution	lgK:1.28 (3SF)	3	MGL	381
6	25	0	Inf. Dilution	lgK:1.27 (3SF)	4	ENS	1541
7	25	0	Inf. Dilution	lgK:1.70 (3SF)	5	MSC	4482
8	25	0	Inf. Dilution	lgK:1.28 (3SF)	4	CRV	8888
9	25	0.03	NaCl	lgK:0.81 (2SF)	5	MIS	11516

Note (9): Emara M et al., Electrochim. Acta, 1981, 26, 1705

10	25	0.1	Unknown	lgK:0.1 (1SF)	0	MPT	6426
----	----	-----	---------	---------------	---	-----	------

Note (10): Low wgt for internal consistency

11	25	0.15	NaCl	lgK:0.46 (2SF)	3	MCT	22612
12	25	0.16	Unknown	lgK:0.55 (2SF)	5	MGL	14764
13	25	0.8	NaClO4	lgK:0.26 (2SF)	5	MSL	11516

Note (13): Fedorova V et al., Zhur. Neorg. Khim., 1977, 22, 1215

14	25	4.5	Unknown	lgK:-0.72 (2SF)	3	MRM	6426
15	25	8.5	Unknown	lgK:-0.55 (2SF)	3	MRM	6426
16	30	0.4	NaNO3	lgK:0.5 (0.03SD)	4	MGL	382
17	35	0	Inf. Dilution	lgK:1.21 (0.01SD)	4	MGL	999
18	37	0.15	Blood Plasma	lgK:1.2 (0.05SD)	0	ENS	94
19	37	0.15	NaCl	lgK:0.58 (2SF)	4	MCT	22612

20	37	0.15	NaCl	lgK:0.87(0.05SD)	0	MGL	23288
Note (20): Model selection appears suspect c.f. Zbar curves							
21	50	0	Inf. Dilution	lgK:1.22(3SF)	4	CRV	8888
22	50	4.5	Unknown	lgK:-0.66(2SF)	3	MRM	6426
23	50	8.5	Unknown	lgK:-0.39(2SF)	3	MRM	6426
24	75	0	Inf. Dilution	lgK:1.26(3SF)	4	CRV	8888
25	80	0	Inf. Dilution	lgK:0.0(1SF)	0	MSL	6426
Note (25): Low wgt for internal consistency							
26	100	0	Inf. Dilution	lgK:1.35(3SF)	4	CRV	8888
27	100	4.5	Unknown	lgK:-0.35(2SF)	3	MRM	6426
28	100	8.5	Unknown	lgK:-0.24(2SF)	3	MRM	6426
29	125	0	Inf. Dilution	lgK:1.49(3SF)	4	CRV	8888
30	150	0	Inf. Dilution	lgK:1.67(3SF)	4	CRV	8888
31	150	4.5	Unknown	lgK:-0.20(2SF)	3	MRM	6426
32	150	8.5	Unknown	lgK:-0.31(2SF)	3	MRM	6426
33	175	0	Inf. Dilution	lgK:1.87(3SF)	4	CRV	8888
34	200	0	Inf. Dilution	lgK:2.10(3SF)	4	CRV	8888
35	225	0	Inf. Dilution	lgK:2.36(3SF)	4	CRV	8888
36	250	0	Inf. Dilution	lgK:2.65(3SF)	4	CRV	8888
37	275	0	Inf. Dilution	lgK:2.99(3SF)	4	CRV	8888
38	300	0	Inf. Dilution	lgK:3.37(3SF)	3	CRV	8888
39	325	0	Inf. Dilution	lgK:3.83(3SF)	4	CRV	8888
40	350	0	Inf. Dilution	lgK:4.33(3SF)	4	CRV	8888
41	25:35	0	Inf. Dilution	dH:-1.5(0.1SD)	4	MGL	380
42	25	0.1	Dioxan:Water 50:50Vol KCl	lgK:2.4(2SF)	4	MPS	1511
43	25		Methanol	lgK:4.4(2SF)	5	MGL	4795

Reaction No. 2222							
2<Acetic-1> + Mg+2 = Mg+2_Acetic-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.2(2SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:1.8(0.05SD)	4	ENS	94
3	37	0.15	NaCl	lgK:2.95(0.04SD)	0	MGL	23288
Note (3): Model selection appears suspect c.f. Zbar curves							
4	25		Methanol	lgK:6.6(2SF)	5	MGL	4795

Reaction No. 2230							
2AmBenz-1 + Mg+2 = Mg+2_2AmBenz-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.72 (2SF)	6	MGL	999
2	37	0.15	Blood Plasma	lgK:0.7 (0.05SD)	4	ENS	94

Reaction No. 2238							
AcSal-1 + Mg+2 = Mg+2_AcSal-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:2.3 (0.05SD)	4	ENS	94
2	37	0.15	NaClO4	lgK:2.3 (0.04SD)	6	MGL	107

Reaction No. 2239							
2<AcSal-1> + Mg+2 = Mg+2_AcSal-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:4.0 (0.05SD)	4	ENS	94

Reaction No. 2447							
Mg+2 + NH3 + H+1 + PO4-3 + 6<H2O> = Mg+2_H+1_NH3_PO4-3_H2O(6)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.4 (0.1SD)	5	MSL	256


Reaction No. 2450							
Mg+2 + H+1_PO4-3 = Mg+2_H+1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.2	Pr4NC1	lgK:1.505 (4SF)	3	MGL	257
2	10	0	Inf. Dilution	lgK:2.612 (4SF)	3	MHY	4852
3	15	0	Inf. Dilution	lgK:3.01 (3SF)	3	EOD	29579
4	15	0.1	KNO3	lgK:1.78 (3SF)	5	MGL	259
5	20	0	Inf. Dilution	lgK:2.674 (4SF)	4	MHY	4852
6	20	0	Inf. Dilution	lgK:3.04 (3SF)	3	EOD	29579
7	25	0	Inf. Dilution	lgK:2.50 (3SF)	3	MGL	140
8	25	0	Inf. Dilution	lgK:2.85 (3SF)	6	MSL	436
9	25	0	Inf. Dilution	lgK:2.9 (0.05SD)	5	CMN	665
10	25	0	Inf. Dilution	lgK:2.70 (3SF)	4	MGL	1937
11	25	0	Inf. Dilution	lgK:2.74 (3SF)	3	ENS	5398

12	25	0	Inf. Dilution	lgK:5.8 (2SF)	0	EOD	5606
13	25	0	Inf. Dilution	lgK:2.84 (0.06SD)	3	EES	7391
14	25	0	Inf. Dilution	lgK:2.70 (3SF)	4	CRV	8749
15	25	0	Inf. Dilution	lgK:2.85 (0.2MD)	5	MGL	9902
16	25	0	Inf. Dilution	lgK:3.09 (3SF)	3	EOD	29579
17	25	0	NaCl/m	lgK:2.70 (3SF)	7	MGL	5384
18	25	0.1	NaNO3	lgK:1.83 (0.03MD)	5	MGL	6412
19	25	0.2	NaCl	lgK:1.9 (0.08SD)	2	MGL	5217
20	25	0.2	Pr4NC1	lgK:1.88 (3SF)	2	MGL	257
21	25	0.68	Unknown	lgK:1.47 (3SF)	4	MGL	7177
22	25	0.7	Na+1 salt	lgK:1.60 (3SF)	3	CRV	552
23	25	0.7	Unknown	lgK:1.60 (3SF)	4	MGL	5322
24	25	0.7	Unknown	lgK:1.47 (3SF)	4	ENS	7177
25	25	0.7	Unknown	lgK:1.51 (0.07SD)	5	CMN	7391
26	25	3	NaClO4	lgK:1.42 (0.03SD)	5	MHY	242
27	30	0	Inf. Dilution	lgK:2.745 (4SF)	4	MHY	4852
28	30	0	Inf. Dilution	lgK:3.13 (3SF)	3	EOD	29579
29	30	0.3	Unknown	lgK:1.20 (3SF)	0	MGL	4547

Note (29): Appears to be conditional on pH

30	35	0	Inf. Dilution	lgK:3.18 (3SF)	3	EOD	29579
31	37	0.1	Me4N+ salt	lgK:2.16 (3SF)	4	MGL	9983
32	37	0.15	Inert	lgK:2.08 (3SF)	0	CRV	29801
33	37	0.15	KNO3	lgK:1.8 (0.1SD)	5	MPS	255
34	37	0.15	Unknown	lgK:2.08 (3SF)	4	CRV	552
35	38	0	Inf. Dilution	lgK:2.87 (3SF)	3	MCN	140
36	38	0	Inf. Dilution	lgK:2.87 (3SF)	3	CRV	8692
37	38	0.16	NaCl	lgK:1.62 (3SF)	2	MSL	140
38	40	0	Inf. Dilution	lgK:2.826 (4SF)	4	MHY	4852
39	50	0	Inf. Dilution	lgK:2.916 (4SF)	4	MHY	4852
40	25	0	Inf. Dilution	dH:12.2 (3SF) kJ	4	MCL	1937

Reaction No. 2451



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:1.31 (3SF)	3	EOD	29579
2	20	0	Inf. Dilution	lgK:1.34 (3SF)	3	EOD	29579

3	20			lgK:0.42 (2SF)	0	MGL	8647
4	25	0	Inf. Dilution	lgK:1.2 (2SF)	1	EOR	
5	25	0	Inf. Dilution	lgK:1.28 (3SF)	5	MSL	436
6	25	0	Inf. Dilution	lgK:1.13 (0.02SD)	3	EES	7391
7	25	0	Inf. Dilution	lgK:1.13 (3SF)	3	CRV	8749
8	25	0	Inf. Dilution	lgK:0.61 (0.2MD)	0	MGL	9902
Note (8): Difficult to explain this; failure to extrapolate to I=0 perhaps?							
9	25	0	Inf. Dilution	lgK:1.38 (3SF)	3	EOD	29579
10	25	0.2	NaCl	lgK:1.5 (0.05SD)	0	MGL	5217
11	25	0.68	Unknown	lgK:0.37 (2SF)	4	MGL	7177
12	25	0.7	Unknown	lgK:0.37 (0.02SD)	3	CMN	7391
13	25	0.7	Unknown	lgK:0.37 (2SF)	3	EOD	7391
14	25	3	Inert	lgK:-0.9 (1SF)	0	EOR	
15	25	3	NaClO4	lgK:0.16 (2SF)	4	CRV	552
16	25	3	NaClO4	lgK:0.16 (0.05MD)	5	MGL	9902
17	30	0	Inf. Dilution	lgK:1.42 (3SF)	3	EOD	29579
18	35	0	Inf. Dilution	lgK:1.47 (3SF)	3	EOD	29579
19	37	0	Inf. Dilution	lgK:1.65 (0.02SD)	3	CRV	552
20	37	0.1	Me4N+ salt	lgK:1.22 (3SF)	4	MGL	9983
21	37	0.15	KNO3	lgK:0.6 (0.3SD)	0	MSP	255
22	37	0.15	Unknown	lgK:1.19 (3SF)	3	CRV	552
23	38	0	Inf. Dilution	lgK:1.5 (2SF)	3	CRV	8692
24	100	0	Inf. Dilution	lgK:0.7 (1SF)	0	EOR	

Reaction No. 2452							
3<Mg+2> + 2<PO4-3> + 8<H2O> = Mg+2 (3)_PO4-3 (2)_H2O (8)_ (s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.28 (4SF)	3	CRV	552
2	25	0	Inf. Dilution	lgK:25.2 (0.1SD)	3	ENS	5606
3	25	0	Inf. Dilution	lgK:25.2 (3SF)	3	CRV	6405
4	25	0	CHEMVAL2	lgK:-25.20 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:-25.20 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:-25.20 (0.01SD)	0	ENS	5156
7	25	0	CHEMVAL4	lgK:25.20 (0.01SD)	3	ENS	5156
8	25	3	Inert	lgK:25.0 (3SF)	1	EOR	
9	100	0	Inf. Dilution	lgK:24.2 (3SF)	1	EOR	

Reaction No. 2453							
$\text{Mg}+2 + \text{H}+1_ \text{PO4}-3 + 3\text{<H2O>} = \text{Mg}+2_ \text{H}+1_ \text{PO4}-3_ \text{H2O}(3)_ (\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 5.777(0.015\text{SD})$	7	MSL	436
2	25	0	Inf. Dilution	$\lg K: 5.8(0.05\text{SD})$	5	CMN	665
3	25	0	Inf. Dilution	$\lg K: 5.8(2\text{SF})$	5	CRV	6405
4	25	3	Unknown	$\lg K: 4.5(2\text{SF})$	6	CRV	552


Reaction No. 2469							
$2\text{<P2O7-4>} + \text{Mg}+2 = \text{Mg}+2_ \text{P2O7-4}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 7.2(2\text{SF})$	1	EOR	
2	25	1	Me4N+ salt	$\lg K: 7.8(0.05\text{SD})$	7	CSM	8
3	25	1	Me4NCl	$\lg K: 7.75(3\text{SF})$	5	MGL	274
4	100	0	Inf. Dilution	$\lg K: 5.5(2\text{SF})$	1	EOR	

Reaction No. 2470							
$\text{P2O7-4} + \text{Mg}+2 = \text{Mg}+2_ \text{P2O7-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	$\lg K: 5.4(0.05\text{SD})\text{w}$	5	MPH	259
2	19	0.02	KNO3	$\lg K: 5.70(3\text{SF})$	4	MCO	140
3	25	0	Inf. Dilution	$\lg K: 7.2(0.05\text{SD})$	4	MGL	267
4	25	0.1	NaNO3	$\lg K: 4.7(2\text{SF})$	5	MGL	931
5	25	0.1	Unknown	$\lg K: 5.45(3\text{SF})$	6	CRV	552
6	25	1	Me4NBr	$\lg K: 5.42(0.05\text{SD})$	5	MGL	264
7	25	1	Me4NCl	$\lg K: 5.41(3\text{SF})$	5	MGL	274
8	30	0.1	NH4+ salt	$\lg K: 5.69(0.05\text{SD})$	6	MIS	5262
9	40	0	Inf. Dilution	$\lg K: 7.1(2\text{SF})$	4	MGL	267
10	19:25	0.02	KNO3	$\text{dH}: 2.9(0.1\text{SD})$	5	MCL	5429
11	25	0	Inf. Dilution	$\text{dH}: 3.(1\text{SF})$	4	CRV	552
12	25			$\text{dH}: 2.90(3\text{SF})$	0	MCL	140

Reaction No. 2471							
$\text{OH-1} + \text{P2O7-4} + \text{Mg}+2 = \text{Mg}+2_ \text{OH-1_ P2O7-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 9.3(0.05\text{SD})$	5	MGL	267


2	25	3	Inert	lgK:11.0(3SF)	1	EOR	
3	100	0	Inf. Dilution	lgK:7.0(2SF)	1	EOR	

Reaction No. 2472



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NC1	lgK:1.33(0.05SD)w	5	MPH	398

Reaction No. 2487



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	2	0.1	KNO3	lgK:6.39(3SF)	0	MGL	281

Note (1): Low wgt for internal consistency

2	15	0.1	KNO3	lgK:5.75(3SF)	6	MGL	259
3	20	0.1	KCl	lgK:5.80(3SF)	4	MGL	140
4	20	0.1	Me4NNO3	lgK:7.05(0.01SD)	0	MGL	284

Note (4): Would usually be taken as reliable but cf. NIST value

5	23	0.1	NH4Cl	lgK:5.8(2SF)	0	MGL	140
---	----	-----	-------	--------------	---	-----	-----

Note (5): Consistency prob.; might just be temp.; could be same datum as above!

6	25	0	Inf. Dilution	lgK:8.6(0.05SD)	0	MGL	267
7	25	0.1	K+1 salt	lgK:5.86(3SF)	6	CRV	552
8	25	0.1	KCl	lgK:5.65(0.03SD)	5	MGL	277
9	25	0.1	KNO3	lgK:4.93(3SF)	0	MGL	281
10	25	0.1	Me4N+ salt	lgK:6.47(3SF)	3	CRV	552
11	25	0.1	NaCl	lgK:5.8(0.06SD)	5	MGL	3925
12	25	0.1	NaNO3	lgK:5.7(0.05SD)	5	MGL	283
13	25	1	Me4NBr	lgK:5.81(3SF)	4	MGL	264
14	25	1	Me4NC1	lgK:5.83(0.05SD)	5	MGL	274
15	30	0.1	NH4+ salt	lgK:5.97(0.05SD)	6	MIS	5262
16	35	0.1	KNO3	lgK:6.56(3SF)	0	MGL	281
17	40	0	Inf. Dilution	lgK:8.3(2SF)	0	MGL	267
18	45	0.1	KNO3	lgK:5.47(3SF)	2	MGL	281
19	65	1	Me4NBr	lgK:5.76(3SF)	4	MGL	140
20	65	1	Me4NBr	lgK:5.76(3SF)	4	MDG	264
21	20	0.1	Me4NNO3	dH:4.34(0.01SD)	7	MCL	284
22	25	0.1	KNO3	dH:-2.11(3SF)	0	MTD	281

Reaction No. 2488							
Mg+2 + H+1_P3O10-5 = Mg+2_H+1_P3O10-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	2	0.1	KNO3	lgK:3.60 (3SF)	0	MGL	281
2	15	0.1	KNO3	lgK:4.00 (3SF)	6	MGL	259
3	20	0.1	KCl	lgK:3.7 (2SF)	3	MGL	140
4	20	0.1	Me4NNO3	lgK:4.45 (0.01SD)	0	MGL	284
5	23	0.1	NH4Cl	lgK:3.6 (2SF)	0	MGL	140
6	25	0.1	K+1 salt	lgK:4.05 (3SF)	6	CRV	552
7	25	0.1	KCl	lgK:3.27 (0.02SD)	0	MGL	277
8	25	0.1	KNO3	lgK:3.33 (0.05SD)	0	MGL	281
Note (8): Suspect other species							
9	25	0.1	Na+1 salt	lgK:3.85 (3SF)	6	CRV	552
10	25	1	Me4NBr	lgK:3.36 (3SF)	4	MGL	264
11	25	1	Me4NCl	lgK:3.34 (0.05SD)	4	MGL	274
12	35	0.1	KNO3	lgK:4.06 (3SF)	3	MGL	281
13	45	0.1	KNO3	lgK:3.49 (3SF)	0	MGL	5398
14	65	1	Me4NBr	lgK:3.40 (3SF)	4	MGL	264
15	0:50	0	Inf. Dilution	dH:2. (1SF)	4	CRV	552
16	25	0.1	KNO3	dH:1.4 (0.2SD)	3	MGL	281


Reaction No. 2489							
Mg+2_P3O10-5 + H+1 = Mg+2_H+1_P3O10-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Me4NNO3	lgK:6.22 (3SF)	0	MGL	931
2	25	0	Inf. Dilution	lgK:7.4 (2SF)	1	ELC	
3	25	0.1	KCl	lgK:5.68 (0.04SD)	0	MGL	277
4	25	0.1	NaNO3	lgK:5.8 (0.05SD)	0	MGL	283

Reaction No. 2490							
OH-1 + Mg+2_P3O10-5 = Mg+2_OH-1_P3O10-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.2 (2SF)	1	ELC	

Reaction No. 2491							
OH-1 + P3O10-5 + Mg+2 = Mg+2_OH-1_P3O10-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0	Inf. Dilution	lgK:11.0 (0.05SD)	5	MGL	267
2	40	0	Inf. Dilution	lgK:10.4 (3SF)	4	MGL	267

Reaction No. 2505



Note: Sillen identified the strong potential interaction between Mg+2 and F-1 in seawater as described within his original seawater equilibrium model [61Sil_9000, p. 565]. This still remains a realistic possibility [G. Hefter, personal communication, 6/8/2015] despite the facts that Mg+2 and SO4-2 interaction is also strong and SO4-2 occurs at more than 2 orders of magnitude higher total concentration than F-1. However, such an outcome would have to be due significantly to other specific ion effects given that at I=0.7 in NaClO4 lgK(F-1) = 1.3 whereas lgK(SO4-2) = 0.8, only half an order of magnitude difference.

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	150	0	P=500 Inf. Dilution	lgK:2.08 (3SF)	5	EOD	6495
2	200	0	P=500 Inf. Dilution	lgK:2.55 (3SF)	3	EOD	6495
3	250	0	P=500 Inf. Dilution	lgK:3.09 (3SF)	4	EOD	6495
4	300	0	P=500 Inf. Dilution	lgK:3.72 (3SF)	3	EOD	6495
5	100	0	P=1000 Inf. Dilution	lgK:1.63 (3SF)	5	EOD	6495
6	150	0	P=1000 Inf. Dilution	lgK:2.01 (3SF)	5	EOD	6495
7	200	0	P=1000 Inf. Dilution	lgK:2.45 (3SF)	5	EOD	6495
8	250	0	P=1000 Inf. Dilution	lgK:2.93 (3SF)	4	EOD	6495
9	300	0	P=1000 Inf. Dilution	lgK:3.46 (3SF)	3	EOD	6495
10	100	0	P=2000 Inf. Dilution	lgK:1.57 (3SF)	5	EOD	6495
11	150	0	P=2000 Inf. Dilution	lgK:1.91 (3SF)	5	EOD	6495
12	200	0	P=2000 Inf. Dilution	lgK:2.3 (2SF)	5	EOD	6495
13	250	0	P=2000 Inf. Dilution	lgK:2.72 (3SF)	4	EOD	6495
14	300	0	P=2000 Inf. Dilution	lgK:3.16 (3SF)	3	EOD	6495
15	100	0	P=3000 Inf. Dilution	lgK:1.52 (3SF)	5	EOD	6495
16	150	0	P=3000 Inf. Dilution	lgK:1.84 (3SF)	5	EOD	6495

17	200	0	P=3000 Inf. Dilution	lgK:2.2 (2SF)	5	EOD	6495
18	250	0	P=3000 Inf. Dilution	lgK:2.57 (3SF)	4	EOD	6495
19	300	0	P=3000 Inf. Dilution	lgK:2.96 (3SF)	3	EOD	6495
20	100	0	P=4000 Inf. Dilution	lgK:1.49 (3SF)	5	EOD	6495
21	150	0	P=4000 Inf. Dilution	lgK:1.79 (3SF)	5	EOD	6495
22	200	0	P=4000 Inf. Dilution	lgK:2.12 (3SF)	5	EOD	6495
23	250	0	P=4000 Inf. Dilution	lgK:2.47 (3SF)	4	EOD	6495
24	300	0	P=4000 Inf. Dilution	lgK:2.82 (3SF)	3	EOD	6495
25	100	0	P=5000 Inf. Dilution	lgK:1.47 (3SF)	5	EOD	6495
26	150	0	P=5000 Inf. Dilution	lgK:1.75 (3SF)	5	EOD	6495
27	200	0	P=5000 Inf. Dilution	lgK:2.06 (3SF)	5	EOD	6495
28	250	0	P=5000 Inf. Dilution	lgK:2.38 (3SF)	4	EOD	6495
29	300	0	P=5000 Inf. Dilution	lgK:2.71 (3SF)	3	EOD	6495
30	0	0	Inf. Dilution	lgK:1.39 (3SF)	4	EOD	6495
31	2	1	NaClO4	lgK:1.15 (3SF)	5	MIS	310
32	2	1	NaClO4	lgK:1.23 (3SF)	5	MIS	312
33	15	0.5	NaClO4	lgK:1.20 (3SF)	4	MRX	140
34	15	0.5	NaClO4	lgK:1.30 (3SF)	5	MEF	307
35	15	1	NaNO3	lgK:1.27 (3SF)	5	MIS	5398
36	16	0.5	NaClO4	lgK:1.26 (3SF)	5	MIS	5398
37	24	1	NaClO4	lgK:1.38 (3SF)	5	MGL	312
38	25	0	Inf. Dilution	lgK:2.05 (3SF)	4	CRV	552
39	25	0	Inf. Dilution	lgK:1.8 (0.05SD)	5	MRX	5433
40	25	0	Inf. Dilution	lgK:1.35 (3SF)	3	EOD	6495
41	25	0	Inf. Dilution	lgK:1.82 (3SF)	4	ENS	6496
42	25	0	Inf. Dilution	lgK:1.90 (0.05SD)	3	EES	7391
43	25	0	Inf. Dilution	lgK:1.82 (3SF)	4	CRV	8749
44	25	0	Inf. Dilution	lgK:1.80 (3SF)	5	CRV	9402

45	25	0	Inf. Dilution	lgK:1.82 (3SF)	4	CRV	32224
46	25	0	CHEMVAL1	lgK:1.80 (0.01SD)	0	ENS	5156
47	25	0	CHEMVAL2	lgK:1.80 (0.01SD)	0	ENS	5156
48	25	0	CHEMVAL3	lgK:1.80 (0.01SD)	0	ENS	5156
49	25	0	CHEMVAL4	lgK:1.86 (0.01SD)	5	ENS	5156
50	25	0	UCT_Sea	lgK:1.82 (0.01SD)	4	EDH	5390
51	25	0.1	NaCl	lgK:1.46 (3SF)	5	MIS	5398
52	25	0.1	UCT_Sea	lgK:1.46 (0.01SD)	4	EDH	5390
53	25	0.2	NaCl	lgK:1.41 (3SF)	5	MIS	5398
54	25	0.2	UCT_Sea	lgK:1.40 (0.01SD)	4	EDH	5390
55	25	0.3	UCT_Sea	lgK:1.36 (0.01SD)	4	EDH	5390
56	25	0.4	NaCl	lgK:1.34 (3SF)	5	MIS	5398
57	25	0.4	UCT_Sea	lgK:1.34 (0.01SD)	4	EDH	5390
58	25	0.5	NaClO4	lgK:1.30 (3SF)	5	MRX	307
59	25	0.5	NaClO4	lgK:1.32 (3SF)	5	MIS	309
60	25	0.5	NaClO4	lgK:1.3 (0.05SD)	5	MIS	309
61	25	0.5	UCT_Sea	lgK:1.33 (0.01SD)	4	EDH	5390
62	25	0.6	NaCl	lgK:1.29 (3SF)	5	MIS	5398
63	25	0.6	UCT_Sea	lgK:1.32 (0.01SD)	4	EDH	5390
64	25	0.7:1	NaCl	lgK:1.27 (3SF)	5	MIS	5398
65	25	0.7	Seawater	lgK:1.36 (0.05SD) w	0	MPH	5101
66	25	0.7	UCT_Sea	lgK:1.32 (0.01SD)	4	EDH	5390
67	25	0.7	Unknown	lgK:1.3 (2SF)	4	EOD	5644
68	25	0.7	Unknown	lgK:1.29 (0.02SD)	5	CMN	7391
69	25	0.7	Unknown	lgK:1.30 (3SF)	4	ENS	7391
70	25	0.7	Unknown	lgK:1.29 (3SF)	4	ENS	7391
71	25	1	Many Media	lgK:1.3 (0.05SD)	5	CMN	437
72	25	1	NaCl	lgK:1.19 (3SF)	4	MIS	
Note (72): K Bourke, Honours Program, Murdoch University, 2002							
73	25	1	NaCl	lgK:1.27 (3SF)	0	MIS	437
74	25	1	NaClO4	lgK:1.32 (3SF)	5	MIS	310
75	25	1	NaClO4	lgK:1.38 (3SF)	5	MIS	312
76	25	1	NaNO3	lgK:1.30 (3SF)	5	MIS	437
77	25	1	NaNO3	lgK:1.32 (3SF)	5	MIS	5398
78	25	1	NaNO3	lgK:1.31 (0.03SD)	6	MIS	6344
79	25	3	NaCl	lgK:1.29 (3SF)	4	MIS	

Note (79): K Bourke, Honours Program, Murdoch University, 2002							
80	25	5	NaCl	lgK:1.51 (3SF)	4	MIS	
Note (80): K Bourke, Honours Program, Murdoch University, 2002							
81	35	0	Inf. Dilution	lgK:1.88 (3SF)	4	CRV	8749
82	35	1	NaClO4	lgK:1.40 (3SF)	5	MIS	312
83	35	1	NaNO3	lgK:1.35 (3SF)	5	MIS	5398
84	39	1	NaClO4	lgK:1.40 (3SF)	5	MIS	310
85	50	0	Inf. Dilution	lgK:1.43 (3SF)	2	EOD	6495
86	55	0	Inf. Dilution	lgK:1.95 (3SF)	4	CRV	8749
87	75	0	Inf. Dilution	lgK:1.57 (3SF)	2	EOD	6495
88	100	0	Inf. Dilution	lgK:1.74 (3SF)	2	EOD	6495
89	100	0	Inf. Dilution	lgK:1.68 (3SF)	2	EOD	6495
90	125	0	Inf. Dilution	lgK:1.94 (3SF)	2	EOD	6495
91	150	0	Inf. Dilution	lgK:2.17 (3SF)	2	EOD	6495
92	175	0	Inf. Dilution	lgK:2.42 (3SF)	2	EOD	6495
93	200	0	Inf. Dilution	lgK:2.69 (3SF)	2	EOD	6495
94	225	0	Inf. Dilution	lgK:2.99 (3SF)	2	EOD	6495
95	250	0	Inf. Dilution	lgK:3.32 (3SF)	2	EOD	6495
96	275	0	Inf. Dilution	lgK:3.7 (2SF)	0	EOD	6495
97	300	0	Inf. Dilution	lgK:4.13 (3SF)	0	EOD	6495
98	25	0	Inf. Dilution	dH:3.2 (2SF)	4	ENS	6496
99	25	0	Inf. Dilution	dH:3.20 (3SF)	5	CRV	9402
100	25	0.5	NaClO4	dH:4. (1SF)	0	MDS	140
101	25	0.5	NaClO4	dH:3.991 (4SF)	3	MTD	307
102	25	1	NaClO4	dH:3.203 (4SF)	3	MCL	310
103	25	1	NaClO4	dH:2.701 (4SF)	3	MTD	310
104	25	1	NaNO3	dH:2. (1.SD)	5	EVK	437
105	25	1	NaNO3	dH:1.506 (4SF)	3	MTD	6344
Note (105): Changed from Lit.Ref.533. (In error). But Ref. not sighted.							

Reaction No. 2512							
Cl-1 + Mg+2 = Mg+2_Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	100	0	P=500 Inf. Dilution	lgK:0.12 (2SF)	5	EOD	6495
2	150	0	P=500 Inf. Dilution	lgK:0.46 (2SF)	5	EOD	6495


3	200	0	P=500 Inf. Dilution	lgK:0.87 (2SF)	5	EOD	6495
4	250	0	P=500 Inf. Dilution	lgK:1.34 (3SF)	4	EOD	6495
5	300	0	P=500 Inf. Dilution	lgK:1.9 (2SF)	3	EOD	6495
6	100	0	P=1000 Inf. Dilution	lgK:0.08 (1SF)	5	EOD	6495
7	150	0	P=1000 Inf. Dilution	lgK:0.4 (1SF)	5	EOD	6495
8	200	0	P=1000 Inf. Dilution	lgK:0.77 (2SF)	5	EOD	6495
9	250	0	P=1000 Inf. Dilution	lgK:1.19 (3SF)	4	EOD	6495
10	300	0	P=1000 Inf. Dilution	lgK:1.66 (3SF)	3	EOD	6495
11	100	0	P=2000 Inf. Dilution	lgK:0.03 (1SF)	5	EOD	6495
12	150	0	P=2000 Inf. Dilution	lgK:0.32 (2SF)	5	EOD	6495
13	200	0	P=2000 Inf. Dilution	lgK:0.65 (2SF)	5	EOD	6495
14	250	0	P=2000 Inf. Dilution	lgK:1.01 (3SF)	4	EOD	6495
15	300	0	P=2000 Inf. Dilution	lgK:1.39 (3SF)	3	EOD	6495
16	100	0	P=3000 Inf. Dilution	lgK:0.02 (1SF)	5	EOD	6495
17	150	0	P=3000 Inf. Dilution	lgK:0.27 (2SF)	5	EOD	6495
18	200	0	P=3000 Inf. Dilution	lgK:0.57 (2SF)	5	EOD	6495
19	250	0	P=3000 Inf. Dilution	lgK:0.89 (2SF)	4	EOD	6495
20	300	0	P=3000 Inf. Dilution	lgK:1.22 (3SF)	3	EOD	6495
21	100	0	P=4000 Inf. Dilution	lgK:0.02 (1SF)	5	EOD	6495
22	150	0	P=4000 Inf. Dilution	lgK:0.25 (2SF)	5	EOD	6495
23	200	0	P=4000 Inf. Dilution	lgK:0.52 (2SF)	5	EOD	6495
24	250	0	P=4000 Inf. Dilution	lgK:0.81 (2SF)	4	EOD	6495
25	300	0	P=4000 Inf. Dilution	lgK:1.11 (3SF)	3	EOD	6495

26	100	0	P=5000 Inf. Dilution	lgK:0.03(1SF)	5	EOD	6495
27	150	0	P=5000 Inf. Dilution	lgK:0.24(2SF)	5	EOD	6495
28	200	0	P=5000 Inf. Dilution	lgK:0.49(2SF)	5	EOD	6495
29	250	0	P=5000 Inf. Dilution	lgK:0.76(2SF)	4	EOD	6495
30	300	0	P=5000 Inf. Dilution	lgK:1.03(3SF)	3	EOD	6495
31	0	0	Inf. Dilution	lgK:0.91(2SF)	0	MFP	140
32	0	0	Inf. Dilution	lgK:-0.1(1SF)	0	EOD	6495
33	0			lgK:0.08(1SF)	0	MFP	140
34	0			lgK:0.62(2SF)	0	MFP	140
35	5	0.5	Inert	lgK:0.01(0.2SD)	0	MIS	8681
36	10	0.1	Inert	lgK:0.13(2SF)	0	EOD	5574
37	10	0.5	Inert	lgK:0.02(1SF)	0	EOD	5574
38	10	1	Inert	lgK:0.09(1SF)	0	EOD	5574
39	15	0.5	Inert	lgK:0.03(0.2SD)	0	MIS	8681
40	15	1	NaNO3	lgK:-0.1(0.05SD)	0	MIS	5019
41	15	1	NaNO3/m	lgK:0.88(2SF)	0	MIS	12227
42	15	1	NaNO3/m	lgK:0.74(2SF)	0	MAG	12227
43	25	0	Inf. Dilution	lgK:0.6(1SF)	0	CRV	552
44	25	0	Inf. Dilution	lgK:0.283(3SF)	0	EDT	5416
45	25	0	Inf. Dilution	lgK:-0.14(2SF)	3	EOD	6495
46	25	0	CHEMVAL1	lgK:-0.10(0.01SD)	0	ENS	5156
47	25	0	CHEMVAL2	lgK:-0.10(0.01SD)	0	ENS	5156
48	25	0	CHEMVAL3	lgK:-0.10(0.01SD)	0	ENS	5156
49	25	0	CHEMVAL4	lgK:-0.46(0.01SD)	0	ENS	5156
50	25	0.1	Inert	lgK:0.18(2SF)	0	EOD	5574
51	25	0.1	Unknown	lgK:0.2(1SF)	0	CRV	552
52	25	0.38	Unknown	lgK:0.651(3SF)	0	EDT	5416
53	25	0.5	Inert	lgK:0.07(1SF)	0	EOD	5574
54	25	0.5	Inert	lgK:0.07(0.2SD)	0	MIS	8681
55	25	0.5	Unknown	lgK:0.1(1SF)	0	CRV	552
56	25	0.7	Seawater	lgK:-0.46(0.05SD)w	0	MPH	5101
57	25	0.7	Unknown	lgK:0.011(2SF)	0	EDT	5416
58	25	1	HClO4	lgK:0.7(0.2SD)	0	MPS	5373

59	25	1	Inert	lgK:0.13 (2SF)	0	EOD	5574
60	25	1	NaClO4	lgK:0.77 (2SF)	0	MPS	2261
61	25	1	NaNO3	lgK:-0.1 (0.05SD)	0	MIS	5019
62	25	1	NaNO3/m	lgK:0.83 (2SF)	0	MIS	12227
63	25	1	NaNO3/m	lgK:0.77 (2SF)	0	MAG	12227
64	25	3	NaClO4	lgK:-0.98 (0.19SD)	0	MVP	399
65	35	0.5	Inert	lgK:0.09 (0.2SD)	0	MIS	8681
66	35	1	NaNO3/m	lgK:0.88 (2SF)	0	MIS	12227
67	35	1	NaNO3/m	lgK:0.86 (2SF)	0	MAG	12227
68	45	0.1	Inert	lgK:0.24 (2SF)	0	EOD	5574
69	45	0.5	Inert	lgK:0.12 (2SF)	0	EOD	5574
70	45	0.5	Inert	lgK:0.1 (0.2SD)	0	MIS	8681
71	45	1	Inert	lgK:0.18 (2SF)	0	EOD	5574
72	45	1	NaNO3	lgK:-0.08 (0.05SD)	0	MIS	5019
73	45	1	NaNO3/m	lgK:1.0 (2SF)	0	MIS	12227
74	45	1	NaNO3/m	lgK:1.0 (2SF)	0	MAG	12227
75	50	0	Inf. Dilution	lgK:-0.08 (1SF)	0	EOD	6495
76	60	1	NaNO3/m	lgK:1.1 (2SF)	0	MIS	12227
77	60	1	NaNO3/m	lgK:1.2 (2SF)	0	MAG	12227
78	65	1	NaNO3	lgK:-0.02 (0.05SD)	0	MIS	5019
79	75	0	Inf. Dilution	lgK:0.03 (1SF)	0	EOD	6495
80	85	1	NaNO3	lgK:0.1 (0.05SD)	0	MIS	5019
81	100	0	Inf. Dilution	lgK:0.17 (2SF)	0	EOD	6495
82	125	0	Inf. Dilution	lgK:0.34 (2SF)	2	EOD	6495
83	150	0	Inf. Dilution	lgK:0.54 (2SF)	2	EOD	6495
84	175	0	Inf. Dilution	lgK:0.75 (2SF)	2	EOD	6495
85	200	0	Inf. Dilution	lgK:0.99 (2SF)	2	EOD	6495
86	225	0	Inf. Dilution	lgK:1.26 (3SF)	0	EOD	6495
87	250	0	Inf. Dilution	lgK:1.55 (3SF)	0	EOD	6495
88	250	0	Inf. Dilution/m	lgK:1.86 (3SF)	0	EOD	12628
89	275	0	Inf. Dilution	lgK:1.89 (3SF)	0	EOD	6495
90	275	0	Inf. Dilution/m	lgK:2.22 (3SF)	0	EOD	12628
91	300	0	Inf. Dilution	lgK:2.28 (3SF)	0	EOD	6495
92	300	0	Inf. Dilution/m	lgK:2.05 (3SF)	0	MCL	12628
93	25	0.6	NaCl	lgR:0.28 (2SF)	3	MPT	8898
94	25	0.7	NaCl	lgR:-0.3 (1SF)	3	MSL	7229


95	10:50	1	Unknown	dH:1.(1SF)	0	CRV	2556
96	25	1	NaNO3/m	dH:-1.296(4SF)	0	MTD	12227
97	275	0	Inf. Dilution/m	dH:89.6(3SF)kJ	0	EOD	12628
98	300	0	Inf. Dilution/m	dH:102.(3SF)kJ	0	MCL	12628
99	25	1	NaNO3/m	dS:-4.9(4.2SD)	0	EFE	12227
100	-20		Ethanol	lgK:3.40(3SF)	3	MCN	140
101	-40		Ethanol	lgK:3.22(3SF)	3	MCN	140
102	0		Ethanol	lgK:3.67(3SF)	3	MCN	140
103	20		Ethanol	lgK:3.79(3SF)	4	MCN	140
104	25		Ethanol:Acetone 50:50Wgt	lgK:2.58(3SF)	5	MDG	5398

Reaction No. 2515



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-4.00(0.05SD)	5	MSL	317
2	25	0	Inf. Dilution	lgK:-4.390(4SF)	5	MSL	14335

Reaction No. 2516




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-4.445(0.05SD)	3	MSL	317
2	25	0	Inf. Dilution	lgK:-4.515(4SF)	3	MSL	14335
3	25	0	Inf. Dilution	lgK:-4.455(4SF)	3	EOD	24835

Note (3): Taken from Altmaier et al., THEREDA database, 2011

4	25	0	Inf. Dilution	lgK:-4.42(3SF)	4	CRV	32224
5	25	0	CHEMVAL1	lgK:-4.42(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL2	lgK:-4.42(0.01SD)	0	ENS	5156
7	25	0	CHEMVAL3	lgK:-4.42(0.01SD)	0	ENS	5156
8	25	0	CHEMVAL4	lgK:-4.45(0.01SD)	3	ENS	5156
9	25	0	Inf. Dilution	dH:15.67(4SF)kJ	1	EOD	29284

Reaction No. 2521



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:1.05(0.02SD)	4	EDT	5416
2	10	0	Inf. Dilution	lgK:1.112(4SF)	4	MPS	27114

3	10	0	Inf. Dilution	lgK:1.14 (0.08SD)	4	MPT	27114
4	10	0	Inf. Dilution/m	lgK:1.14 (0.08SD)	4	MGL	26086
5	15	0	Inf. Dilution	lgK:1.106 (4SF)	4	MPS	27114
6	20	0	Inf. Dilution	lgK:1.103 (4SF)	4	MPS	27114
7	22	0	Inf. Dilution	lgK:0.86 (2SF)	0	MGL	931
8	22			lgK:0.77 (2SF)	0	MGL	140
9	25	0	Inf. Dilution	lgK:1.16 (3SF)	4	MGL	140
10	25	0	Inf. Dilution	lgK:1.23 (3SF)	3	MGL	337
11	25	0	Inf. Dilution	lgK:1.23 (3SF)	2	MIS	337
12	25	0	Inf. Dilution	lgK:1. (0.05SD)	5	MGL	339
13	25	0	Inf. Dilution	lgK:1.0 (0.06SD)	4	CRV	552
14	25	0	Inf. Dilution	lgK:1.07 (0.01SD)	4	EDT	5416
15	25	0	Inf. Dilution	lgK:1.07 (3SF)	4	ENS	6496
16	25	0	Inf. Dilution	lgK:0.95 (0.19SD)	3	CMN	7391
17	25	0	Inf. Dilution	lgK:1.21 (3SF)	3	ENS	7391
18	25	0	Inf. Dilution	lgK:1.23 (3SF)	2	MSL	8385
19	25	0	Inf. Dilution	lgK:2.984 (4SF)	0	MGL	9023
20	25	0	Inf. Dilution	lgK:1.104 (4SF)	4	MPS	27114
21	25	0	Inf. Dilution	lgK:1.09 (0.07SD)	6	MPT	27114
22	25	0	Inf. Dilution	lgK:1.12 (0.11SD)	5	MSP	29186
23	25	0	Inf. Dilution	lgK:1.07 (3SF)	3	EOD	30627
24	25	0	Inf. Dilution/m	lgK:1.09 (0.07SD)	6	MGL	26086
25	25	0	SOLMNEQ	lgK:0.90 (2SF)	0	CMN	5416
26	25	0	SOLVEQ	lgK:0.90 (2SF)	3	CMN	5416
27	25	0	WATCH	lgK:1.07 (3SF)	4	CMN	5416
28	25	0	WATEQF	lgK:1.05 (3SF)	4	CMN	5416
29	25	0.6	NaCl	lgK:0.21 (2SF)	0	MPT	8898
30	25	0.7	NaCl	lgK:0.02 (1SF)	0	EES	
31	25	0.7	Seawater	lgK:0.02 (1SF)	0	ENS	405
32	25	0.7	Seawater	lgK:0.21 (2SF)	0	MEF	4996
33	25	0.7	Unknown	lgK:0.2 (0.05SD)	3	MEF	4996
34	25	0.7	Unknown	lgK:0.21 (2SF)	3	MEF	5398
35	25	0.7	Unknown	lgK:0.28 (0.08SD)	6	CMN	7391
36	25	3	NaClO4	lgK:0.15 (2SF)	6	MEF	338
37	25	3	NaClO4	lgK:1.49 (3SF)	0	MSL	5398
38	25	3	NaClO4/m	lgK:0.146 (0.026SD)	4	MEF	338

39	25			lgK:3.7 (2SF)	0	MHY	140
40	30	0	Inf. Dilution	lgK:1.107 (4SF)	4	MPS	27114
41	35	0	Inf. Dilution	lgK:1.112 (4SF)	4	MPS	27114
42	40	0	Inf. Dilution	lgK:1.11 (0.006SD)	4	EDT	5416
43	40	0	Inf. Dilution	lgK:1.121 (4SF)	4	MPS	27114
44	40	0	Inf. Dilution	lgK:1.09 (0.05SD)	6	MPT	27114
45	40	0	Inf. Dilution/m	lgK:1.09 (0.05SD)	6	MGL	26086
46	45	0	Inf. Dilution	lgK:1.131 (4SF)	4	MPS	27114
47	50	0	Inf. Dilution	lgK:1.144 (4SF)	4	MPS	27114
48	50	0	SOLMNEQ	lgK:1.52 (3SF)	0	CMN	5416
49	50	0	SOLVEQ	lgK:1.52 (3SF)	0	CMN	5416
50	50	0	WATCH	lgK:1.15 (3SF)	4	CMN	5416
51	50	0	WATEQF	lgK:1.13 (3SF)	4	CMN	5416
52	55	0	Inf. Dilution	lgK:1.16 (0.01SD)	4	EDT	5416
53	55	0	Inf. Dilution	lgK:1.160 (4SF)	4	MPS	27114
54	60	0	Inf. Dilution	lgK:1.177 (4SF)	4	MPS	27114
55	60	0	Inf. Dilution	lgK:1.15 (0.06SD)	6	MPT	27114
56	60	0	Inf. Dilution/m	lgK:1.15 (0.06SD)	6	MGL	26086
57	65	0	Inf. Dilution	lgK:1.196 (4SF)	4	MPS	27114
58	70	0	Inf. Dilution	lgK:1.23 (0.02SD)	4	EDT	5416
59	70	0	Inf. Dilution	lgK:1.217 (4SF)	4	MPS	27114
60	75	0	SOLMNEQ	lgK:2.14 (3SF)	0	CMN	5416
61	75	0	WATCH	lgK:1.23 (3SF)	4	CMN	5416
62	75	0	WATEQF	lgK:1.24 (3SF)	4	CMN	5416
63	80	0	Inf. Dilution	lgK:1.31 (0.08SD)	6	MPH	27114
64	80	0	Inf. Dilution	lgK:1.265 (4SF)	4	MPS	27114
65	80	0	Inf. Dilution/m	lgK:1.31 (0.08SD)	6	MSP	26086
66	90	0	Inf. Dilution	lgK:1.34 (0.007SD)	4	EDT	5416
67	90	0	Inf. Dilution	lgK:1.319 (4SF)	4	MPS	27114
68	100	0	Inf. Dilution	lgK:1.40 (0.15SD)	6	MPH	27114
69	100	0	Inf. Dilution	lgK:1.380 (4SF)	4	MPS	27114
70	100	0	Inf. Dilution/m	lgK:1.40 (0.15SD)	6	MSP	26086
71	100	0	SOLMNEQ	lgK:2.76 (3SF)	0	CMN	5416
72	100	0	SOLVEQ	lgK:2.76 (3SF)	0	CMN	5416
73	100	0	WATCH	lgK:1.33 (3SF)	4	CMN	5416
74	100	0	WATEQF	lgK:1.38 (3SF)	4	CMN	5416

75	110	0	Inf. Dilution	lgK:1.446 (4SF)	4	MPS	27114
76	120	0	Inf. Dilution	lgK:1.518 (4SF)	4	MPS	27114
77	125	0	Inf. Dilution	lgK:1.55 (0.15SD)	6	MPH	27114
78	125	0	Inf. Dilution/m	lgK:1.55 (0.15SD)	5	MSP	26086
79	125	0	SOLMNEQ	lgK:3.41 (3SF)	0	CMN	5416
80	125	0	WATCH	lgK:1.43 (3SF)	4	CMN	5416
81	125	0	WATEQF	lgK:1.54 (3SF)	4	CMN	5416
82	130	0	Inf. Dilution	lgK:1.594 (4SF)	4	MPS	27114
83	140	0	Inf. Dilution	lgK:1.675 (4SF)	4	MPS	27114
84	150	0	Inf. Dilution	lgK:1.75 (0.2SD)	4	MPH	27114
85	150	0	Inf. Dilution	lgK:1.760 (4SF)	2	MPS	27114
86	150	0	Inf. Dilution/m	lgK:1.75 (0.2SD)	3	MSP	26086
87	150	0	SOLMNEQ	lgK:4.06 (3SF)	0	CMN	5416
88	150	0	SOLVEQ	lgK:4.06 (3SF)	0	CMN	5416
89	150	0	WATCH	lgK:1.54 (3SF)	2	CMN	5416
90	150	0	WATEQF	lgK:1.74 (3SF)	4	CMN	5416
91	175	0	SOLMNEQ	lgK:4.74 (3SF)	0	CMN	5416
92	175	0	WATCH	lgK:1.65 (3SF)	2	CMN	5416
93	175	0	WATEQF	lgK:1.96 (3SF)	0	CMN	5416
94	200	0	SOLMNEQ	lgK:5.50 (3SF)	0	CMN	5416
95	200	0	SOLVEQ	lgK:5.50 (3SF)	0	CMN	5416
96	200	0	WATCH	lgK:1.78 (3SF)	3	CMN	5416
97	200	0	WATEQF	lgK:2.21 (3SF)	2	CMN	5416
98	225	0	SOLMNEQ	lgK:6.40 (3SF)	0	CMN	5416
99	225	0	WATCH	lgK:1.91 (3SF)	2	CMN	5416
100	225	0	WATEQF	lgK:2.49 (3SF)	0	CMN	5416
101	250	0	SOLMNEQ	lgK:7.40 (3SF)	0	CMN	5416
102	250	0	SOLVEQ	lgK:7.40 (3SF)	0	CMN	5416
103	250	0	WATCH	lgK:2.05 (3SF)	0	CMN	5416
104	250	0	WATEQF	lgK:2.80 (3SF)	0	CMN	5416
105	275	0	SOLMNEQ	lgK:8.42 (3SF)	0	CMN	5416
106	275	0	WATCH	lgK:2.19 (3SF)	0	CMN	5416
107	275	0	WATEQF	lgK:3.14 (3SF)	0	CMN	5416
108	300	0	SOLMNEQ	lgK:9.60 (3SF)	0	CMN	5416
109	300	0	SOLVEQ	lgK:9.60 (3SF)	0	CMN	5416
110	300	0	WATCH	lgK:2.35 (3SF)	0	CMN	5416

111	300	0	WATEQF	lgK:3.51(3SF)	0	CMN	5416
112	325	0	SOLMNEQ	lgK:11.03(4SF)	0	CMN	5416
113	325	0	WATCH	lgK:2.51(3SF)	0	CMN	5416
114	325	0	WATEQF	lgK:4.33(3SF)	0	CMN	5416
115	350	0	SOLMNEQ	lgK:12.80(4SF)	0	CMN	5416
116	350	0	WATCH	lgK:2.67(3SF)	0	CMN	5416
117	350	0	WATEQF	lgK:4.33(3SF)	0	CMN	5416
118	10:90	0	Inf. Dilution	dH:1.(1SF)	0	CRV	552
119	25	0	Inf. Dilution	dH:1.192(4SF)	4	MTD	5416
120	25	0	Inf. Dilution	dH:0.79(2SF)	4	ENS	6496

Reaction No. 2523							
Mg+2 + 2<H2O> = Mg+2_OH-1(2)_(s) + 2<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-16.33(4SF)	0	EPZ	6219
2	25	0	Inf. Dilution	lgK:-16.84(0.03SD)	3	CRV	6478
3	25	0	Inf. Dilution	lgK:-16.84(4SF)	3	ENS	6496
4	25	0	Inf. Dilution	lgK:-16.85(4SF)	3	CRV	9402
5	25	0	Inf. Dilution	lgK:-17.1(0.1SD)	6	MSL	23192
6	25	0	Inf. Dilution	lgK:-16.84(4SF)	4	EOD	29487
7	25	0	Inf. Dilution	lgK:-16.84(4SF)	3	EOD	30627
8	25	0	Inf. Dilution	lgK:-17.05(0.20SD)	3	EOD	30797
9	25	0	Inf. Dilution	lgK:-16.43(4SF)	2	CRV	32224
10	25	0	CHEMVAL1	lgK:-16.85(4SF)	0	ENS	5156
11	25	0	CHEMVAL2	lgK:-16.85(4SF)	0	ENS	5156
12	25	0	CHEMVAL3	lgK:-16.85(4SF)	0	ENS	5156
13	25	0	CHEMVAL4	lgK:-16.70(4SF)	0	ENS	5156
14	25	0	Inf. Dilution/m	lgK:-17.1(0.1SD)	5	MSL	17838
15	25	1	NaNO3	lgK:-18.24(4SF)	0	EBP	4603
Note (15): Mg+2 + 2<OH-1> = Mg+2_OH-1(2)_(s)							
16	25	3	NaClO4	lgK:-16.3(3SF)	3	EBP	5520
Note (16): Mg+2 + 2<OH-1> = Mg+2_OH-1(2)_(s)							
17	25	3.5	NaClO4/m	lgK:-16.51(4SF)	0	MSL	6219
18	60	0.1	NaCl/m	lgK:-15.29(4SF)	6	MIS	6256
19	60	1	NaCl/m	lgK:-15.52(4SF)	1	MIS	6256
20	90	0	Inf. Dilution	lgK:-13.28(4SF)	2	EOD	29487

21	100	0.1	NaCl/m	lgK:-13.47 (4SF)	6	MIS	6256
22	100	1	NaCl/m	lgK:-13.64 (4SF)	2	MIS	6256
23	150	0.1	NaCl/m	lgK:-11.62 (4SF)	6	MIS	6256
24	150	1	NaCl/m	lgK:-11.88 (4SF)	2	MIS	6256
25	200	0.1	NaCl/m	lgK:-10.21 (4SF)	6	MIS	6256
26	200	1	NaCl/m	lgK:-10.44 (4SF)	3	MIS	6256
27	25	0	Inf. Dilution	dH:27.26 (0.3SD)	4	CRV	6478
28	25	0	Inf. Dilution	dH:27.1 (3SF)	4	ENS	6496
29	25	0	Inf. Dilution	dH:26.00 (4SF)	4	CRV	9402
30	25	0	Inf. Dilution	dH:113.39 (5SF) kJ	4	EOD	29487

Reaction No. 2524							
CO3-2 + Mg+2 + 3<H2O> = Mg+2_CO3-2_H2O(3)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.7 (0.05SD)	3	MSL	341
2	25	0	Inf. Dilution	lgK:5.62 (3SF)	0	CRV	6330
Note (2): p. 8-58							
3	25	0	Inf. Dilution	lgK:4.54 (3SF)	3	ENS	6405
4	25	0	Inf. Dilution	lgK:4.67 (3SF)	3	CRV	6405
5	25	0	Inf. Dilution	lgK:4.67 (3SF)	3	EOD	30627
6	25	0	Inf. Dilution	lgK:5.23 (3SF)	2	CRV	32224
7	25	0	CHEMVAL1	lgK:4.67 (0.01SD)	0	ENS	5156
8	25	0	CHEMVAL2	lgK:4.67 (0.01SD)	0	ENS	5156
9	25	0	CHEMVAL3	lgK:4.67 (0.01SD)	0	ENS	5156
10	25	0	CHEMVAL4	lgK:5.19 (0.01SD)	2	ENS	5156
11	25	3	Unknown	lgK:4.5 (2SF)	1	EOR	

Reaction No. 2525							
Mg+2 + CO3-2 = Mg+2_CO3-2_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	P=400 Inf. Dilution	lgK:7.921 (4SF)	3	CRV	11928
Note (1): with lgK0=8.265 & Kp/K=2.21							
2	25	0	P=1000 Inf. Dilution	lgK:7.470 (4SF)	3	CRV	11928
Note (2): with lgK0=8.265 & Kp/K=6.24							
3	0	0	Inf. Dilution/m	lgK:7.92 (3SF)	4	EFE	8739

Note (3): Calculated by EK 28/10/04 from data in the ref.							
4	5	0	Inf. Dilution/m	lgK:7.99(3SF)	4	EFE	8739
5	10	0	Inf. Dilution/m	lgK:8.05(3SF)	4	EFE	8739
6	15	0	Inf. Dilution/m	lgK:8.13(3SF)	4	EFE	8739
7	20	0	Inf. Dilution/m	lgK:8.20(3SF)	4	EFE	8739
8	25	0	Inf. Dilution	lgK:7.(0.9SD)	0	MSL	341
9	25	0	Inf. Dilution	lgK:7.46(3SF)	0	CMN	773
10	25	0	Inf. Dilution	lgK:4.4(2SF)	0	ENS	5648
11	25	0	Inf. Dilution	lgK:5.17(3SF)	0	CRV	6330
Note (11): p. 8-58							
12	25	0	Inf. Dilution	lgK:7.45(3SF)	0	ENS	6405
13	25	0	Inf. Dilution	lgK:7.46(3SF)	0	CRV	6405
14	25	0	Inf. Dilution	lgK:4.59(3SF)	0	ENS	7694
15	25	0	Inf. Dilution	lgK:8.04(3SF)	1	CRV	9402
16	25	0	Inf. Dilution	lgK:5.1(2SF)	0	EOD	12584
17	25	0	Inf. Dilution	lgK:7.80(0.3SD)	5	MSL	26071
18	25	0	Inf. Dilution	lgK:5.10(3SF)	0	CRV	28992
19	25	0	Inf. Dilution	lgK:7.46(3SF)	2	EOD	30627
20	25	0	Inf. Dilution	lgK:7.91(3SF)	4	CRV	32224
21	25	0	CHEMVAL1	lgK:7.46(0.01SD)	0	ENS	5156
22	25	0	CHEMVAL2	lgK:7.46(0.01SD)	0	ENS	5156
23	25	0	CHEMVAL3	lgK:7.46(0.01SD)	0	ENS	5156
24	25	0	CHEMVAL4	lgK:8.20(0.01SD)	2	ENS	5156
25	25	0	Inf. Dilution/m	lgK:8.28(3SF)	4	EFE	8739
Note (25): Calculated by EK 28/10/04 from data in the ref.							
26	30	0	Inf. Dilution/m	lgK:8.37(3SF)	4	EFE	8739
27	35	0	Inf. Dilution/m	lgK:8.45(3SF)	4	EFE	8739
28	40	0	Inf. Dilution/m	lgK:8.54(3SF)	4	EFE	8739
29	45	0	Inf. Dilution/m	lgK:8.63(3SF)	4	EFE	8739
30	50	0	Inf. Dilution	lgK:5.74(3SF)	0	CRV	28992
31	50	0	Inf. Dilution/m	lgK:8.73(3SF)	3	EFE	8739
32	100	0	Inf. Dilution	lgK:7.01(3SF)	0	CRV	28992
33	150	0	Inf. Dilution	lgK:8.28(3SF)	0	CRV	28992
34	200	0	Inf. Dilution	lgK:9.53(3SF)	0	CRV	28992
35	25	0	Inf. Dilution	dH:6.20(3SF)	4	CRV	9402

Reaction No. 2526							
$\text{Ca}+2 + \text{Mg}+2 + 2\langle\text{CO}_3-2\rangle = \text{Ca}+2_ \text{Mg}+2_ \text{CO}_3-2(2)_ (s)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.1(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:17.00(4SF)	0	CRV	9402
3	25	0	Inf. Dilution	lgK:15.44(4SF)	0	CRV	28992
4	25	0	Inf. Dilution	lgK:18.06(4SF)	0	CRV	32224
5	50	0	Inf. Dilution	lgK:16.19(4SF)	0	CRV	28992
6	100	0	Inf. Dilution	lgK:17.88(4SF)	0	CRV	28992
7	150	0	Inf. Dilution	lgK:19.91(4SF)	0	CRV	28992
8	200	0	Inf. Dilution	lgK:22.10(4SF)	0	CRV	28992
9	25	0	Inf. Dilution	dH:8.36(3SF)	2	CRV	9402
10	25	0	Inf. Dilution	Cp:200.00(5SF)	3	CRV	9402

Reaction No. 2527							
$\text{Ca}+2_ \text{CO}_3-2_ (\text{Calc.},s) + \text{Mg}+2_ \text{CO}_3-2_ (s) = \text{Ca}+2_ \text{Mg}+2_ \text{CO}_3-2(2)_ (s)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.3(1SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:1.7(2SF)	0	CRV	6405

Reaction No. 2528							
$\text{Mg}+2 + \text{Ca}+2 + 2\langle\text{CO}_2(g)\rangle + 2\langle\text{H}_2\text{O}\rangle = \text{Ca}+2_ \text{Mg}+2_ \text{CO}_3-2(2)_ (s) + 4\langle\text{H}+1\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-19.0(3SF)	1	ELC	


Reaction No. 2529							
$\text{Mg}+2 + \text{Ca}+2 + 4\langle\text{H}+1_ \text{CO}_3-2\rangle = \text{Ca}+2_ \text{Mg}+2_ \text{CO}_3-2(2)_ (s) + 2\langle\text{CO}_2(g)\rangle + 2\langle\text{H}_2\text{O}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2(3SF)	1	ELC	

Reaction No. 2530							
$2\langle\text{Ca}+2_ \text{CO}_3-2_ (\text{Calc.},s)\rangle + \text{Mg}+2 = \text{Ca}+2_ \text{Mg}+2_ \text{CO}_3-2(2)_ (s) + \text{Ca}+2$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.2(1SF)	1	ELC	

Reaction No. 2531							
$\text{Ca}+2_ \text{Mg}+2_ \text{CO}_3-2(2)_ (s) + \text{Mg}+2 = 2\langle\text{Mg}+2_ \text{CO}_3-2_ (s)\rangle + \text{Ca}+2$							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.5(1SF)	1	ELC	

Reaction No. 2547




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.17(0.05SD)	4	MCN	386
2	25	0.1	Me4N+ salt	lgK:3.4(0.04SD)	6	CRV	552

Reaction No. 2552




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:6.5(0.05SD)	5	MCG	394
2	25	1	Me4NCl	lgK:6.0(0.05SD)	5	MGL	388
3	30	0.1	NH4+ salt	lgK:6.33(0.05SD)	6	MIS	5262
4	60			lgK:1.75(3SF)	0	MKN	931

Reaction No. 2553




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NCl	lgK:3.7(0.05SD)	5	MGL	388

Reaction No. 2554




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.4(2SF)	1	ELC	
2	25	1	Me4NCl	lgK:2.2(0.05SD)	2	MGL	388

Reaction No. 2560



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-7.6(2SF)	1	ELC	


Reaction No. 2562



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:29.5(0.1SD)	0	ENS	5437


Note (1): Not regarded any longer as the correct stoichiometry for Hydromagnesite

Reaction No. 2930




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:11.07(4SF)	4	MSL	30858
2	25	0	Inf. Dilution	lgK:10.6(0.05SD)	2	MSL	256
3	25	0	Inf. Dilution	lgK:11.00(4SF)	5	MSL	30858
4	25	0	Inf. Dilution	lgK:10.872(5SF)	5	MSL	31766
5	35	0	Inf. Dilution	lgK:10.90(4SF)	4	MSL	30858

Reaction No. 3151



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.78(3SF)	0	MGL	11516
Note (1): Kroll H, AE. C. Contract(30-1), 1959, 2096							
2	20	0.1	Unknown	lgK:7.0(2SF)	4	ENS	773
3	25	0.1	KNO3	lgK:7.0(2SF)	6	MEF	999
4	25	1	Unknown	lgK:7.0(2SF)	6	CRV	552
5	30	0.1	NaClO4	lgK:6.41(3SF)	0	MGL	2261
6	25	0.1	KNO3	dH:3.4(2SF)	5	MCL	139

Reaction No. 3426



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	16	0.1	KNO3	lgK:4.35(3SF)	6	MSP	999
2	17:20	1	NH4Cl	lgK:4.08(3SF)	6	MDS	999
3	20	0	Inf. Dilution	lgK:4.74(3SF)	6	MGL	999
4	20	0.01	Unknown	lgK:4.5(2SF)	4	MGL	999
5	20	0.1	Unknown	lgK:4.31(3SF)	6	ENS	773
6	20	1	Unknown	lgK:3.91(3SF)	6	ENS	773
7	25	0	Unknown	lgK:4.74(3SF)	6	ENS	773
8	25	0.1	Unknown	lgK:4.48(3SF)	6	MKN	999
9	25		Acetone	lgK:2.3(0.06SD)	4	MFL	2469
10	25	0.1	Dioxan:Water 60:40Vol NaClO4	lgK:5.79(3SF)	5	MGL	3082

11	25	0.05	Ethanol:Water 95:5Wgt Et4NC1O4	lgK:2.3(0.04SD)	4	MPS	2713
12	25		MeCN	lgK:4.0(0.08SD)	4	MFL	2469
13	25		Methanol	lgK:2.01(0.02SD)	4	MFL	2469

Reaction No. 3458							
Sulfox-2 + Mg+2 = Mg+2_Sulfox-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:4.8(2SF)	4	MGL	999
2	25	0	Inf. Dilution	lgK:4.79(3SF)	6	MGL	999
3	25	0	Unknown	lgK:4.79(3SF)	6	ENS	773
4	25	0.1	KNO3	lgK:4.06(3SF)	6	MGL	999
5	25	0.1	Unknown	lgK:4.02(3SF)	6	ENS	773
6	25	0.1	Dioxan:Water 60:40Wgt NaClO4	lgK:5.70(3SF)	4	MGL	906

Reaction No. 3459							
2<Sulfox-2> + Mg+2 = Mg+2_Sulfox-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Unknown	lgK:8.2(2SF)	4	ENS	773
2	25	0.1	Unknown	lgK:7.63(3SF)	6	ENS	773

Reaction No. 3558							
Mg+2 + Phenanth = Mg+2_Phenanth							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:1.43(0.03MD)	4	MGL	7090
2	10	0.25	Inert	lgK:1.61(3SF)	6	MGL	1520
3	10	0.5	KCl	lgK:1.53(0.03MD)	5	MGL	7090
4	20	0.1	KNO3	lgK:1.2(2SF)	4	MGL	999
5	20	0.1	NaNO3	lgK:1.25(3SF)	6	MGL	1988
6	20	0.25	Inert	lgK:1.2(2SF)	4	MGL	1520
7	25	0	Inf. Dilution	lgK:1.42(0.03MD)	4	MGL	7090
8	25	0.1	NaClO4	lgK:1.46(0.02SD)	6	MGL	2961
9	25	0.25	Inert	lgK:1.55(3SF)	6	MGL	1520
10	25	0.5	KCl	lgK:1.53(0.03MD)	5	MGL	7090
11	40	0	Inf. Dilution	lgK:1.42(0.03MD)	4	MGL	7090


12	40	0.25	Inert	lgK:1.49 (3SF)	6	MGL	1520
13	40	0.5	KCl	lgK:1.53 (0.03MD)	5	MGL	7090
14	25	0.25	Inert	dH:-1.7 (2SF)	5	MCL	1520
15	25		Acetone	lgK:4.2 (0.05SD)	4	MFL	2469
16	25	0.05	Ethanol:Water 95:5Wgt Et4NC1O4	lgK:2.9 (0.06SD)	4	MPS	2713
17	25		MeCN	lgK:5.1 (0.04SD)	4	MFL	2469
18	25		Methanol	lgK:2.14 (0.01SD)	4	MFL	2469

Reaction No. 3817							
Malonic-2 + Mg+2 = Mg+2_Malonic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:2.818 (4SF)	5	MCO	4861
2	20	0.1	NaClO4	lgK:1.95 (3SF)	4	MGL	154
3	23	0.035	KCl	lgK:2.86 (3SF)	0	MSP	5748
4	25	0	Inf. Dilution	lgK:2.9 (2SF)	4	ENS	2152
5	25	0	Inf. Dilution	lgK:2.862 (4SF)	5	MCO	4861
6	25	0	Inf. Dilution	lgK:2.8 (2SF)	4	MCN	8670
7	25	0	Inf. Dilution	lgK:2.854 (4SF)	4	EOD	12002
8	25	0	Inf. Dilution	lgK:2.83 (3SF)	4	CRV	18273
Note (8): Table 3, p. 85							
9	25	0	Inf. Dilution	lgK:2.84 (3SF)	5	MHY	21336
10	25	0.04	Unknown	lgK:2.85 (3SF)	4	MEF	999
11	25	0.1	KNO3	lgK:2.045 (4SF)	5	MIX	16285
12	25	0.1	NaClO4	lgK:2.11 (3SF)	4	MGL	476
13	25	0.2	KCl	lgK:1.91 (3SF)	5	MHY	999
14	25	1	NaCl	lgK:1.73 (3SF)	6	MGL	957
15	30	0	Inf. Dilution	lgK:2.903 (4SF)	5	MCO	4861
16	35	0	Inf. Dilution	lgK:2.98 (3SF)	5	MCO	4861
17	25	0	Inf. Dilution	dH:14. (2.SD) kJ	4	MCO	4861
18	25	0	Inf. Dilution	dH:3. (1SF)	3	CRV	7271

Reaction No. 3818							
Mg+2 + H+1_Malonic-2 = Mg+2_H+1_Malonic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:0.83 (2SF)	5	MGL	154


2	25	0	Inf. Dilution	lgK:0.4 (1SF)	2	ENS	4852
3	25	0.1	NaClO4	lgK:0.96 (2SF)	6	MGL	476
4	25	0.1	Unknown	lgK:0.90 (2SF)	3	CRV	7271

Reaction No. 4107




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:4.18 (3SF)	4	ENS	773
2	20	0	Inf. Dilution	lgK:4.41 (3SF)	3	MHY	2699
3	20	0.1	KCl	lgK:3.44 (3SF)	6	MGL	3486
4	20	0.1	KCl	lgK:3.4 (0.1SD)	2	CRV	13242
5	20	0.1	KNO3	lgK:3.44 (3SF)	6	MGL	2040
6	25	0	Inf. Dilution	lgK:4.18 (3SF)	3	CRV	552
7	25	0.1	KCl	lgK:3.48 (3SF)	4	MGL	999
8	25	0.1	NaClO4	lgK:3.5 (2SF)	3	MPL	999
9	25	0.1	NaClO4	lgK:3.5 (0.1SD)	3	CRV	13242
10	25	0.1	Unknown	lgK:3.48 (3SF)	5	ENS	7168
11	20	0.1	KNO3	dG:-4.62 (3SF)	6	MGL	2040
12	20	0.1	KNO3	dH:-3.12 (3SF)	0	MCL	2040
13	25	0.1	KCl	dH:2.9 (0.1SD)	0	MCL	3215
14	20	0.1	KNO3	dS:26.4 (3SF)	6	EFE	2040

Reaction No. 4108



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:5.80 (3SF)	3	ENS	773
2	25	0.1	NaClO4	lgK:5.83 (0.05SD)	5	CRV	13242
3	25	0.1	Unknown	lgK:5.83 (3SF)	5	CRV	552
4	25	0.1	Unknown	dH:2.1 (2SF)	5	CRV	552

Reaction No. 4139



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:2.20 (3SF)	6	MGL	999
2	25	0	Inf. Dilution	lgK:2.58 (3SF)	4	MGL	999
3	25	0	Inf. Dilution	lgK:2.6 (2SF)	4	ENS	6405
4	25	0.1	NaNO3	lgK:2.5 (2SF)	4	MGL	999

Reaction No. 4140							
2<Picolinic-1> + Mg+2 = Mg+2_Picolinic-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.95(3SF)	4	MGL	999
2	25	0	Inf. Dilution	lgK:4.0(2SF)	4	ENS	6405

Reaction No. 4181							
Mg+2_EDTA-4 + H+1 = Mg+2_H+1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.9(2SF)	4	MGL	1957
2	20	0.1	Unknown	lgK:3.85(3SF)	4	ENS	773
3	25	0	Inf. Dilution	lgK:4.500(0.1SD)	6	CRV	20830
4	25	0.1	Me4N+ salt	lgK:4.0(2SF)	4	CRV	552

Reaction No. 4259							
Mg+2_DTPA-5 + H+1 = Mg+2_H+1_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:7.09(3SF)	6	ENS	773
2	25	0.1	KNO3	lgK:6.9(2SF)	5	CRV	13242
3	25	0.1	Unknown	lgK:6.85(3SF)	6	ENS	773
4	37	0.15	NaCl	lgK:6.96(0.05SD)	5	CRV	13242

Reaction No. 4312							
Mg+2_EGTA-4 + H+1 = Mg+2_H+1_EGTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:7.7(2SF)	4	MGL	1957
2	20	0.1	Unknown	lgK:7.62(3SF)	6	ENS	773
3	25	0	Inf. Dilution	lgK:7.9(2SF)	1	ESC	

Reaction No. 4351							
TTHA-6 + Mg+2 = Mg+2_TTHA-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:8.10(3SF)	0	MGL	906
2	25	0.1	KNO3	lgK:8.43(3SF)	5	MEF	999
3	25	0.1	KNO3	lgK:8.5(0.1SD)	5	CRV	13242
4	30	0.1	KCl	lgK:8.47(3SF)	5	MGL	999

Reaction No. 4352							
Mg+2_TTHA-6 + H+1 = Mg+2_H+1_TTHA-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:9.30(3SF)	6	MGL	999
2	25	0.1	KNO3	lgK:9.3(0.1SD)	5	CRV	13242
3	25	0.1	Unknown	lgK:9.31(3SF)	6	ENS	773
4	30	0.1	Unknown	lgK:9.25(3SF)	6	ENS	773

Reaction No. 4353							
Mg+2_H+1_TTHA-6 + H+1 = Mg+2_H+1(2)_TTHA-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.65(3SF)	6	MGL	999
2	25	0.1	KNO3	lgK:4.7(0.1SD)	5	CRV	13242

Reaction No. 4354							
Mg+2_TTHA-6 + Mg+2 = Mg+2(2)_TTHA-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.5(2SF)	2	MGL	999
2	25	0.1	KNO3	lgK:5.9(0.1SD)	4	CRV	13242
3	30	0.1	KCl	lgK:5.94(3SF)	3	MGL	999

Reaction No. 4355							
Mg+2(2)_TTHA-6 + Mg+2 = Mg+2(3)_TTHA-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.10(3SF)	6	MGL	999
2	25	0.1	Unknown	lgK:5.3(2SF)	0	ENS	773

Reaction No. 4529							
Acac-1 + Mg+2 = Mg+2_Acac-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:3.75(3SF)	6	MGL	999
2	20	0	Inf. Dilution	lgK:3.67(3SF)	6	MGL	999
3	20	0.1	Unknown	lgK:3.67(3SF)	6	ENS	1539
4	25	0	UCT_Sea	lgK:3.65(0.01SD)	4	EDH	5390
5	25	0	Unknown	lgK:3.65(3SF)	6	ENS	773
6	25	0.1	UCT_Sea	lgK:3.35(0.01SD)	4	EDH	5390
7	25	0.2	UCT_Sea	lgK:3.25(0.01SD)	4	EDH	5390

8	25	0.3	UCT_Sea	lgK:3.22(0.01SD)	4	EDH	5390
9	25	0.4	UCT_Sea	lgK:3.21(0.01SD)	4	EDH	5390
10	25	0.5	UCT_Sea	lgK:3.20(0.01SD)	4	EDH	5390
11	25	0.6	UCT_Sea	lgK:3.19(0.01SD)	4	EDH	5390
12	25	0.7	UCT_Sea	lgK:3.19(0.01SD)	4	EDH	5390
13	30	0	Inf. Dilution	lgK:3.63(3SF)	6	MGL	999
14	40	0	Inf. Dilution	lgK:3.65(3SF)	6	MGL	999
15	10:40	0	Inf. Dilution	dH:-1.8(2SF)	5	MGL	999

Reaction No. 4530							
2<Acac-1> + Mg+2 = Mg+2_Acac-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:6.38(3SF)	6	ENS	1539
2	25	0	Inf. Dilution	lgK:6.2(2SF)	5	MGL	2360
3	25	0	UCT_Sea	lgK:6.30(0.01SD)	4	EDH	5390
4	25	0	Unknown	lgK:6.25(3SF)	6	ENS	773
5	25	0.1	UCT_Sea	lgK:5.80(0.01SD)	4	EDH	5390
6	25	0.2	UCT_Sea	lgK:5.68(0.01SD)	4	EDH	5390
7	25	0.3	UCT_Sea	lgK:5.61(0.01SD)	4	EDH	5390
8	25	0.4	UCT_Sea	lgK:5.58(0.01SD)	4	EDH	5390
9	25	0.5	UCT_Sea	lgK:5.56(0.01SD)	4	EDH	5390
10	25	0.6	UCT_Sea	lgK:5.55(0.01SD)	4	EDH	5390
11	25	0.7	UCT_Sea	lgK:5.55(0.01SD)	4	EDH	5390


Reaction No. 4594							
Kojic-1 + Mg+2 = Mg+2_Kojic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20:23	0.1	KCl	lgK:3.0(2SF)	4	MHY	999
2	25	0.1	KNO3	lgK:2.92(3SF)	6	MGL	999

Reaction No. 4595							
2<Kojic-1> + Mg+2 = Mg+2_Kojic-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:5.11(3SF)	6	ENS	773

Reaction No. 4634							
Tiron-4 + Mg+2 = Mg+2_Tiron-4							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:6.86(3SF)	6	MGL	999

Reaction No. 4635



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.98(3SF)	6	MGL	999

Reaction No. 4820



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-79.69(4SF)	4	CRV	32224
2	25	3	Inert	lgK:-80.7(3SF)	1	EOR	
3	25	0	Inf. Dilution	dG:108.7(0.1SD)	3	ENS	802
4	25	0	Inf. Dilution	dG:108.51(5SF)	2	CRV	6488
5	25	0	Inf. Dilution	dG:455.4(4SF)kJ	2	CRV	6494
6	25	0	Inf. Dilution	dG:454.8(4SF)kJ	3	EFE	7275
7	25	0	Inf. Dilution	dG:454.8(4SF)kJ	5	CRV	7421
8	25	0	Inf. Dilution	dG:455.3(4SF)kJ	2	CRV	8739
9	25	0	Inf. Dilution	dG:455.4(4SF)kJ	2	CRV	8746
10	25	0	Inf. Dilution	dG:108.700(6SF)	4	CRV	8875
11	25	0	Inf. Dilution	dG:108.510(6SF)	2	CRV	9029
12	25	0	Inf. Dilution	dG:108.50(5SF)	0	CRV	10174
13	25	0	Inf. Dilution	dG:453.990(6SF)kJ	1	EOD	12843
14	25	0	Inf. Dilution	dG:455.38(1.335SD)kJ	2	CRV	14923
15	25	0	Inf. Dilution	dG:453.990(6SF)kJ	2	CRV	23205
16	25	0	Inf. Dilution	dG:453.990(6SF)kJ	2	EOD	23205
17	25	0	Inf. Dilution	dG:454.80(5SF)kJ	5	CRV	28172
18	25	0	Inf. Dilution	dG:454.8(4SF)kJ	4	EOD	29025
19	25	0	Inf. Dilution	dG:108.70(5SF)	2	EOD	29489
20	25	0	Inf. Dilution	dG:455.38(5SF)kJ	5	EOD	29520
21	25	0	Inf. Dilution	dG:455.4(0.6SD)kJ	3	EOD	30052
22	25	0	Inf. Dilution	dG:454.8(4SF)kJ	4	EFE	32152
23	25	0	Inf. Dilution/m	dG:454.81(5SF)kJ	5	EPZ	8833
24	50	0	Inf. Dilution	dG:107.68(5SF)	0	CRV	10174
25	75	0	Inf. Dilution	dG:106.84(5SF)	0	CRV	10174

26	100	0	Inf. Dilution	dG:106.01 (5SF)	0	CRV	10174
27	125	0	Inf. Dilution	dG:105.17 (5SF)	0	CRV	10174
28	150	0	Inf. Dilution	dG:104.32 (5SF)	3	CRV	10174
29	175	0	Inf. Dilution	dG:103.45 (5SF)	0	CRV	10174
30	200	0	Inf. Dilution	dG:102.56 (5SF)	0	CRV	10174
31	225	0	Inf. Dilution	dG:101.64 (5SF)	0	CRV	10174
32	250	0	Inf. Dilution	dG:100.68 (5SF)	0	CRV	10174
33	300	0	Inf. Dilution	dG:98.59 (4SF)	0	CRV	10174
34	23	0	Inf. Dilution	E:-2.37 (3SF)	0	ENS	7276
35	25	0	Inf. Dilution	E:-2.372 (4SF)	0	CRV	6330
36	25	0	Inf. Dilution	E:-2.375 (4SF)	0	MEF	7273
37	25	0	Inf. Dilution	E:-2.37 (3SF)	0	CRV	7372
38	25	0	Inf. Dilution	E:-2.372 (4SF)	0	ENS	7381
39	25	0	Inf. Dilution	E:-2.360 (4SF)	2	CRV	7761
40	25	0	Inf. Dilution	E:-2.356 (4SF)	4	CRV	22551
41	25	0	Inf. Dilution	dH:111.6 (0.1SD)	5	ENS	802
42	25	0	Inf. Dilution	dH:111.37 (5SF)	3	CRV	6488
43	25	0	Inf. Dilution	dH:467.0 (4SF) kJ	5	CRV	6494
44	25	0	Inf. Dilution	dH:466.85 (5SF) kJ	5	EFE	7275
45	25	0	Inf. Dilution	dH:466.9 (4SF) kJ	5	CRV	7761
46	25	0	Inf. Dilution	dH:467.0 (4SF) kJ	5	CRV	8739
47	25	0	Inf. Dilution	dH:467.0 (0.6MD) kJ	6	CRV	8746
48	25	0	Inf. Dilution	dH:111.560 (6SF)	4	CRV	8875
49	25	0	Inf. Dilution	dH:111.370 (6SF)	3	CRV	9029
50	25	0	Inf. Dilution	dH:465.960 (6SF) kJ	3	EOD	12843
51	25	0	Inf. Dilution	dH:467.00 (0.600SD) kJ	6	CRV	14923
52	25	0	Inf. Dilution	dH:467.00 (5SF) kJ	4	CRV	26555
53	25	0	Inf. Dilution	dH:466.85 (5SF) kJ	5	CRV	28172
54	25	0	Inf. Dilution	dH:466.9 (4SF) kJ	4	EOD	29025
55	25	0	Inf. Dilution	dH:111.58 (5SF)	2	EOD	29489
56	25	0	Inf. Dilution	dH:467.0 (4SF) kJ	5	EOD	29520
57	25	0	Inf. Dilution	dH:466.9 (4SF) kJ	4	EFE	32152
58	25	0	GAMSPATH	dH:466.780 (6SF) kJ	3	CRV	12638
59	25	0	Inf. Dilution	Cp:22.3 (3SF) J/K	4	EOD	29025

Reaction No. 4914

IDA-2 + Mg+2 = Mg+2_IDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:3.66(3SF)	4	MHY	2699
2	20	0.1	KCl	lgK:2.94(3SF)	5	MHY	999
3	20	0.1	KNO3	lgK:2.94(3SF)	6	MGL	1956
4	20	0.1	KNO3	lgK:2.94(0.05SD)	5	CRV	13242
5	20	0.1	NaNO3	lgK:2.94(3SF)	6	MGL	1506
6	23	0.1	NH4Cl	lgK:3.2(2SF)	0	MCG	906
7	25	0	Inf. Dilution	lgK:3.8(0.1SD)	4	CRV	552
8	25	0	Inf. Dilution	lgK:4.25(3SF)	3	MGL	6131
9	25	0.1	Unknown	lgK:2.98(3SF)	2	ENS	773
10	20	0.1	KNO3	dH:2.94(3SF)	5	MCL	1956
11	20	0.1	NaNO3	dH:2.94(3SF)	5	MCL	1506
12	25	0	Inf. Dilution	dH:10.(2SF)kJ	3	MCL	6131
13	25	0.1	Unknown	dH:3.3(2SF)	3	CRV	552


Reaction No. 5177							
Cat-2 + Mg+2 = Mg+2_Cat-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	NaClO4	lgK:5.24(3SF)	4	MGL	999
2	30	0.1	Unknown	lgK:5.7(2SF)	3	ENS	773
3	35	0.1	KNO3	lgK:4.12(3SF)	0	MGL	3565
Note (3): Low wgt for internal consistency							
4	25	0.05	Ethanol:Water 95:5Wgt Et4NClO4	lgK:2.0(0.05SD)	4	MPS	2713

Reaction No. 5403							
2<H+1> + 2<Gly-1> + Mg+2 = Mg+2_H+1(2)_Gly-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.0(3SF)	2	ESC	
2	37	0.15	Blood Plasma	lgK:20.3(0.05SD)	0	ENS	94
3	37	0.15	NaCl	lgK:20.28(0.26SD)	0	MGL	28777
4	37	0.15	NaCl	lgK:21.15(0.15SD)	3	MIS	28777
5	37	0.15	NaClO4	lgK:21.6(0.1SD)	2	MGL	2181

Reaction No. 5404							
2<Gly-1> + Mg+2 = Mg+2_Gly-1(2)							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:4. (1SF)	3	MGL	3514
2	25	0.01	Unknown	lgK:6.46 (3SF)	0	MGL	22560
3	25	3	NaClO4	lgK:2.26 (3SF)	6	CRV	552
4	37	0.15	Blood Plasma	lgK:2.7 (0.05SD)	4	ENS	94

Reaction No. 5437



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0.5	Many Media	lgK:10.60 (0.07SD)	6	CMN	6128
2	10	0.1	NaClO4	lgK:10.33 (0.05SD)	5	CRV	6128
3	10	0.25	NaClO4	lgK:10.36 (0.05SD)	5	CRV	6128
4	10	0.5	NaClO4	lgK:10.45 (0.05SD)	5	CRV	6128
5	10	0.75	NaClO4	lgK:10.55 (0.05SD)	5	CRV	6128
6	15	0.5	Many Media	lgK:10.31 (0.04SD)	6	CMN	6128
7	25	0	Inf. Dilution	lgK:10.2 (3SF)	4	MPH	6131
8	25	0.1	NaClO4	lgK:9.98 (0.07SD)	5	CRV	6128
9	25	0.25	NaClO4	lgK:9.99 (0.07SD)	5	CRV	6128
10	25	0.5	Many Media	lgK:10.05 (0.04SD)	6	CMN	6128
11	25	0.5	NaClO4	lgK:10.05 (0.07SD)	5	CRV	6128
12	25	0.5	Unknown	lgK:10.05 (0.05SD)	5	MPT	6128
13	25	0.75	NaClO4	lgK:10.12 (0.07SD)	5	CRV	6128
14	35	0.5	Many Media	lgK:9.83 (0.05SD)	6	CMN	6128
15	37	0.15	Blood Plasma	lgK:10.6 (0.05SD)	0	ENS	94
16	37	0.15	NaCl	lgK:10.11 (0.05SD)	3	MGL	28777
17	37	0.15	NaCl	lgK:10.27 (0.31SD)	3	MIS	28777
18	37	0.15	NaClO4	lgK:10.9 (0.04SD)	0	MGL	2181
19	40	0.1	NaClO4	lgK:9.70 (0.1SD)	5	CRV	6128
20	40	0.25	NaClO4	lgK:9.70 (0.1SD)	5	CRV	6128
21	40	0.5	NaClO4	lgK:9.73 (0.1SD)	5	CRV	6128
22	40	0.75	NaClO4	lgK:9.77 (0.1SD)	5	CRV	6128
23	45	0.5	Many Media	lgK:9.64 (0.07SD)	6	CMN	6128
24	25	0	Inf. Dilution	dH:-36. (2SF) kJ	4	MCL	6131


Reaction No. 5467



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.09	KCl	lgK:2.12 (3SF)	0	MGL	22560
2	5	0.5	Many Media	lgK:1.43 (0.05SD)	6	CMN	6128
3	10	0.1	NaClO4	lgK:1.44 (0.03SD)	0	CRV	6128
4	10	0.25	NaClO4	lgK:1.42 (0.03SD)	3	CRV	6128
5	10	0.5	NaClO4	lgK:1.49 (0.03SD)	5	CRV	6128
6	10	0.75	NaClO4	lgK:1.57 (0.03SD)	3	CRV	6128
7	15	0.5	Many Media	lgK:1.55 (0.03SD)	6	CMN	6128
8	20	0.15	NaCl	lgK:2.33 (3SF)	0	MGL	22560
9	20	0.7	Unknown	lgK:1.3 (2SF)	6	CRV	552
10	25	0	Inf. Dilution	lgK:2.08 (3SF)	4	CRV	552
11	25	0	Inf. Dilution	lgK:2.7 (2SF)	4	ENS	2152
12	25	0	Inf. Dilution	lgK:2.0 (2SF)	4	MPH	6131
13	25	0	Inf. Dilution	lgK:3.44 (3SF)	0	MGL	21342
14	25	0.01	Unknown	lgK:3.45 (3SF)	0	MGL	22560
15	25	0.1	KNO3	lgK:3.09 (3SF)	0	MGL	17698
16	25	0.1	NaClO4	lgK:1.66 (0.04SD)	3	CRV	6128
17	25	0.1	NaNO3	lgK:3.30 (3SF)	0	MPT	1069
18	25	0.1	NaNO3	lgK:3.45 (3SF)	0	MGL	7362
19	25	0.1	Unknown	lgK:2.22 (3SF)	4	ENS	773
20	25	0.25	NaClO4	lgK:1.63 (0.04SD)	3	CRV	6128
21	25	0.5	KCl	lgK:1.34 (0.05SD)	2	MGL	183
22	25	0.5	Many Media	lgK:1.68 (0.03SD)	6	CMN	6128
23	25	0.5	NaClO4	lgK:1.68 (0.04SD)	5	CRV	6128
24	25	0.5	Unknown	lgK:1.34 (3SF)	3	ENS	2350
25	25	0.5	Unknown	lgK:1.68 (0.03SD)	5	MPT	6128
26	25	0.75	NaClO4	lgK:1.75 (0.04SD)	3	CRV	6128
27	25	1	Me4NC1	lgK:1.17 (0.02SD)	0	MSP	1529
28	25	3	NaClO4	lgK:1.53 (3SF)	6	CRV	552
29	25	3	NaClO4	lgK:1.53 (3SF)	4	MEF	9683
30	30	0.09	KCl	lgK:2.23 (3SF)	2	MGL	999
31	30	0.09	KCl	lgK:2.23 (3SF)	2	MGL	22560
32	35	0.1	KNO3	lgK:3.40 (3SF)	0	MGL	1187
33	35	0.1	KNO3	lgK:3.4 (0.06SD)	0	MGL	2371
34	35	0.1	KNO3	lgK:3.40 (3SF)	0	MGL	3565
35	35	0.1	Unknown	lgK:1.4 (2SF)	0	CRV	552


36	35	0.5	Many Media	lgK:1.81(0.03SD)	6	CMN	6128
37	37	0.15	Blood Plasma	lgK:2.1(0.05SD)	2	ENS	94
38	37	0.15	NaCl	lgK:1.54(0.01SD)	2	MGL	28777
39	37	0.15	NaCl	lgK:1.83(0.15SD)	4	MIS	28777
40	37	0.15	NaClO4	lgK:1.98(0.02SD)	6	MGL	2181
41	40	0.1	NaClO4	lgK:1.88(0.05SD)	2	CRV	6128
42	40	0.25	NaClO4	lgK:1.84(0.05SD)	5	CRV	6128
43	40	0.5	NaClO4	lgK:1.88(0.05SD)	5	CRV	6128
44	40	0.75	NaClO4	lgK:1.93(0.05SD)	2	CRV	6128
45	45	0.5	Many Media	lgK:1.95(0.05SD)	6	CMN	6128
46	25	0	Inf. Dilution	dH:22.(2SF)kJ	4	MCL	6131
47	25	0.1	Unknown	dH:1.(1SF)	0	CRV	552

Reaction No. 5930




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.8(0.05SD)	3	ENS	94

Reaction No. 6319




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.92(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.2(0.05SD)	4	ENS	94

Reaction No. 6328



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.2(0.05SD)	3	ENS	94

Reaction No. 6476



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaCl	lgK:1.42(3SF)	6	MGL	957

Reaction No. 6477

Mg+2 + H+1_COOGlu-3 = Mg+2_H+1_COOGlu-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaCl	lgK:0.92 (2SF)	6	MGL	957

Reaction No. 6482							
5ATP-4 + Mg+2 = Mg+2_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:3.97 (0.02SD)	5	MGL	3482
2	1	0.15	NaCl	lgK:3.06 (3SF)	0	MIX	1437
3	3	0.2	Me4NBr	lgK:4.34 (3SF)	0	MGL	1437
4	5	0.07	Pr4NBr	lgK:4.46 (3SF)	0	MIX	1437
5	5	0.1	Pr4NBr	lgK:4.45 (3SF)	0	MIX	1437
6	5	0.17	Pr4NBr	lgK:4.38 (3SF)	0	MIX	1437
7	12	0.1	KNO3	lgK:4.10 (0.02SD)	5	MGL	3482
8	15	0.1	KNO3	lgK:4.05 (3SF)	6	MGL	259
9	17	0.2	Me4NBr	lgK:4.53 (3SF)	0	MGL	1437
10	20	0.001	HCl	lgK:4.68 (3SF)	0	MKN	999
11	20	0.003	Tris buffer	lgK:4.68 (3SF)	0	MKN	1437
12	20	0.05	NEtMorph buffer	lgK:4.76 (3SF)	4	MSP	1437
13	20	0.1	KCl	lgK:4.00 (3SF)	4	MGL	280
14	20	0.1	KCl	lgK:3.84 (3SF)	0	MGL	999
15	20	0.12	NaCl	lgK:3.65 (3SF)	0	MKN	1437
16	22	0.25	KNO3	lgK:4.73 (3SF)	0	MGL	1437
17	23	0	Na+1 salt	lgK:4.76 (3SF)	0	MIX	1437
18	23	0.03	Tris buffer	lgK:4.87 (3SF)	4	MSC	1437
19	23	0.1	NaCl	lgK:4.04 (3SF)	3	MIX	1437
20	23	0.1	NaCl	lgK:4.04 (3SF)	3	MIX	31154
21	23	0.1	Unknown	lgK:3.61 (3SF)	0	MIX	999
22	23	0.1	Unknown	lgK:4.28 (3SF)	3	ENS	1437
23	23	0.12	Na+1 salt	lgK:3.61 (3SF)	0	MIX	1437
24	23	0.12	NaCl	lgK:3.82 (3SF)	0	MIX	1437
25	23	0.12	NaCl	lgK:3.94 (3SF)	4	MIX	1437
26	23	0.12	NaCl	lgK:3.95 (3SF)	4	MIX	1437
27	23	0.15	NaCl	lgK:3.34 (3SF)	0	MIX	1437
28	23	0.2	Na+1 salt	lgK:3.59 (3SF)	0	MIX	1437
29	23	0.25	NaCl	lgK:3.82 (3SF)	4	MIX	1437

30	25	0	Bu3EtNBr	lgK:5.70 (3SF)	4	MSP	1437
31	25	0	Inert	lgK:5.8 (0.07SD)	8	CIU	1437
32	25	0	Na+1 salt	lgK:6.06 (3SF)	3	MIS	1437
33	25	0	Na+1 salt	lgK:5.87 (3SF)	4	MIS	1437
34	25	0	Pr4NBr	lgK:5.83 (3SF)	4	MIX	1437
35	25	0.0006	Unknown	lgK:5.74 (3SF)	3	MSP	1437
36	25	0.001	Unknown	lgK:5.26 (3SF)	3	MIS	1437
37	25	0.002	Unknown	lgK:5.22 (3SF)	3	MSP	1437
38	25	0.004	Unknown	lgK:4.63 (3SF)	3	MSP	1437
39	25	0.005	Unknown	lgK:5.21 (3SF)	3	MIS	1437
40	25	0.007	Unknown	lgK:4.30 (3SF)	0	MSP	1437
41	25	0.009	Unknown	lgK:4.90 (3SF)	3	MIS	1437
42	25	0.02	MgCl2	lgK:4. (0.3SD)	0	MSP	999
43	25	0.03	Unknown	lgK:4.78 (3SF)	3	MSP	1437
44	25	0.04	Tris buffer	lgK:4.72 (3SF)	4	MSP	1437
45	25	0.04	Unknown	lgK:4.49 (3SF)	3	MSP	1437
46	25	0.05	Tris buffer	lgK:4.51 (3SF)	4	MSP	1437
47	25	0.07	Pr4NBr	lgK:4.60 (3SF)	0	MIX	1437
48	25	0.095	Me4NCl	lgK:4.87 (3SF)	0	MKN	1437
49	25	0.1	Et4NBr	lgK:4.56 (3SF)	0	MGL	1437
50	25	0.1	Et4NBr	lgK:4.4 (0.04SD)	0	MGL	1437
51	25	0.1	Et4NBr	lgK:4.35 (3SF)	3	MIX	1437
52	25	0.1	KCl	lgK:4.17 (3SF)	6	MIX	999
53	25	0.1	KCl	lgK:4.04 (3SF)	4	MGL	1437
54	25	0.1	KNO3	lgK:3.99 (3SF)	0	MGL	1437
55	25	0.1	KNO3	lgK:4.22 (0.02SD)	5	MGL	3482
56	25	0.1	Me4N+ salt	lgK:4.6 (0.07SD)	0	CIU	1437
57	25	0.1	Me4NCl	lgK:4.85 (3SF)	0	MSP	1437
58	25	0.1	NaCl	lgK:4.36 (3SF)	3	MSP	1437
59	25	0.1	NaClO4	lgK:4.4 (0.04SD)	0	MGL	1297
60	25	0.1	NaClO4	lgK:4.29 (0.01SD)	4	MGL	1369
61	25	0.1	NaClO4	lgK:4.03 (3SF)	0	MGL	1483
62	25	0.1	NaClO4	lgK:4.24 (0.02SD)	6	MGL	2961
63	25	0.1	Pr4NBr	lgK:4.56 (3SF)	0	MDG	1437
64	25	0.1	Pr4NBr	lgK:4.63 (3SF)	0	MIX	1437
65	25	0.11	Bu3EtNBr	lgK:4.58 (3SF)	3	MSP	2060

66	25	0.11	KCl	lgK:4.25 (3SF)	4	MSP	2060
67	25	0.12	NaCl	lgK:4.01 (3SF)	4	MGL	1437
68	25	0.15	KCl	lgK:3.99 (3SF)	4	MSP	1437
69	25	0.17	Pr4NBr	lgK:4.54 (3SF)	0	MIX	1437
70	25	0.2	Me4N+ salt	lgK:3.45 (3SF)	4	MGL	257
71	25	0.2	Me4NBr	lgK:4.30 (3SF)	0	ENS	2060
72	25	0.2	Pr4NCl	lgK:3.473 (4SF)	0	MGL	257
73	25	0.22	Bu3EtNBr	lgK:4.35 (3SF)	3	MSP	2060
74	25	0.22	KCl	lgK:4.35 (3SF)	0	MSP	2060
75	25	0.25	Pr4N+ salt	lgK:4.54 (0.06SD)	0	EOD	3595
76	25	0.5	Inert	lgK:4.5 (0.07SD)	0	CIU	1437
77	25	0.5	NaNO3	lgK:4.5 (0.05SD)	0	MGL	956
78	25	1	KNO3	lgK:3.22 (3SF)	0	MGL	1437
79	26	0.2	Me4NBr	lgK:4.62 (3SF)	0	MGL	1437
80	30	0	Et4NBr	lgK:6.11 (3SF)	3	MSP	1437
81	30	0.02	NEtMorph buffer	lgK:4.89 (3SF)	4	MSP	1437
82	30	0.04	Unknown	lgK:4.89 (3SF)	3	MSP	1437
83	30	0.05	Tris buffer	lgK:4.24 (3SF)	4	MIX	1437
84	30	0.05	Tris buffer	lgK:4.30 (3SF)	4	MSP	1437
85	30	0.1	Et4NBr	lgK:4.88 (3SF)	0	MGL	1437
86	30	0.1	Et4NBr	lgK:4.94 (3SF)	0	MIX	1437
87	30	0.1	KNO3	lgK:4.7 (2SF)	0	MMR	1437
88	30	0.1	Unknown	lgK:4.30 (3SF)	6	MSP	999
89	30	0.2	Me4NBr	lgK:4.66 (3SF)	0	MGL	1437
90	30	0.2	Me4NCl	lgK:4.69 (3SF)	0	MCL	1437
91	30	0.3	Me4NCl	lgK:4.6 (2SF)	0	MSP	1437
92	35	0.1	KNO3	lgK:4.50 (3SF)	3	MGL	1437
93	37	0.058	Unknown	lgK:4.53 (3SF)	6	MPS	8626
94	37	0.06	Tris buffer	lgK:4.79 (3SF)	4	MSP	1437
95	37	0.085	Unknown	lgK:4.33 (3SF)	5	MPS	8626
96	37	0.1	Tris buffer	lgK:4.46 (3SF)	4	MSP	1437
97	37	0.1	Unknown	lgK:4.28 (3SF)	5	MPS	8626
98	37	0.11	Bu3EtNBr	lgK:4.74 (3SF)	3	EIE	2060
99	37	0.15	KCl	lgK:4.08 (3SF)	4	MIS	1437
100	37	0.15	KCl	lgK:4.42 (3SF)	0	MEP	1437
101	37	0.15	Na+1 salt	lgK:4.3 (0.07SD)	0	CIU	1437

102	37	0.15	Tris buffer	lgK:4.11 (3SF)	4	MSP	1437
103	37	0.15	Unknown	lgK:3.94 (3SF)	5	MPS	8626
104	37	0.2	Me4NCl	lgK:4.73 (3SF)	0	MGL	1437
105	37	0.24	Tris buffer	lgK:3.67 (3SF)	4	MSP	1437
106	37	0.24	Unknown	lgK:3.51 (3SF)	3	MPS	8626
107	39	0.2	Me4NBr	lgK:4.75 (3SF)	0	MGL	1437
108	40	0.1	KNO3	lgK:4.28 (0.02SD)	5	MGL	3482
109	43	0.15	NaCl	lgK:3.50 (3SF)	0	MIX	1437
110	45	0.07	Pr4NBr	lgK:4.78 (3SF)	3	MIX	1437
111	45	0.1	Pr4NBr	lgK:4.81 (3SF)	0	MIX	1437
112	45	0.17	Pr4NBr	lgK:4.70 (3SF)	0	MIX	1437
113	50	0	Me4NOH/m	lgK:6.17 (0.01SD)	4	MCL	7086
114	64	0.11	Bu3EtNBr	lgK:4.991 (4SF)	4	MSP	2060
115	65	0.07	Pr4NBr	lgK:4.96 (3SF)	4	MIX	1437
116	65	0.1	Pr4NBr	lgK:4.92 (3SF)	0	MIX	1437
117	65	0.17	Pr4NBr	lgK:4.85 (3SF)	0	MIX	1437
118	75	0	Me4NOH/m	lgK:6.61 (0.01SD)	4	MCL	7086
119	100	0	Me4NOH/m	lgK:7.12 (0.01SD)	4	MCL	7086
120	125	0	Me4NOH/m	lgK:7.67 (0.01SD)	4	MCL	7086
121	30	0.2	Me4NBr	dG:-6.48 (3SF)	0	EFE	1971
122	0:25	0.1	KNO3	dH:3.9 (2SF)	4	MTD	1437
123	0:40	0.1	KNO3	dH:2.6 (0.1SD)	0	MCL	3482
124	1:43	0.1	NaCl	dH:4.1 (2SF)	4	MTD	1437
125	3:39	0.2	Me4NBr	dH:4.5 (2SF)	4	MTD	1437
126	10:30	0.12	NaCl	dH:4.59 (3SF)	4	MTD	1437
127	10:37	0	Pr4NBr	dH:5.1 (2SF)	4	MTD	1437
128	10:37	0.1	Pr4NBr	dH:3.3 (2SF)	4	MTD	1437
129	10:45	0.25	Pr4N+ salt	dH:15. (3.SD) kJ	4	EOD	3595
130	25	0.1	Inert	dH:18.8 (0.8SD) kJ	5	CIU	1437
131	25	0.1	NaClO4	dH:18.08 (0.10SD) kJ	6	MCL	1483
132	25:64	0.11	Bu3EtNBr	dH:4.2 (2SF)	0	MTD	2060
133	30	0.2	Me4NBr	dH:4.46 (3SF)	5	MCL	1971
134	30	0.2	Me4NCl	dH:4.47 (3SF)	4	MCL	1437
135	37:39	0.2	Me4NCl	dH:4.37 (3SF)	4	MCL	1437
136	37:64	0.11	Bu3EtNBr	dH:5. (1SF)	3	MTD	2060
137	50	0	Me4NOH	dH:31.6 (0.8SD) kJ	4	MCL	7086

138	75	0	Me4NOH	dH:44.3(0.8SD) kJ	4	MCL	7086
139	100	0	Me4NOH	dH:56.9(0.8SD) kJ	4	MCL	7086
140	125	0	Me4NOH	dH:69.6(0.8SD) kJ	4	MCL	7086
141	50	0	Me4NOH	Cp:507.(16.SD) J/K	4	MCL	7086
142	75	0	Me4NOH	Cp:507.(16.SD) J/K	4	MCL	7086
143	100	0	Me4NOH	Cp:507.(16.SD) J/K	4	MCL	7086
144	125	0	Me4NOH	Cp:507.(16.SD) J/K	4	MCL	7086

Reaction No. 6483							
H+1 + 5ATP-4 + Mg+2 = Mg+2_H+1_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:8.6(0.05SD)	5	MGL	1297
2	25	0.1	NaClO4	lgK:8.63(3SF)	6	MGL	1483
3	25	0.25	Pr4N+ salt	lgK:8.96(0.09SD)	0	MGL	3595
4	25	0.5	NaNO3	lgK:9.1(0.1SD)	0	MGL	956
5	10:45	0.25	Pr4N+ salt	dG:-51.1(5.SD) kJ	0	EFE	3595
6	25	0.1	NaClO4	dH:-14.65(0.20SD) kJ	6	MCL	1483

Reaction No. 6484							
2<H+1> + 5ATP-4 + Mg+2 = Mg+2_H+1(2)_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.5(3SF)	1	ELC	
2	25	0.5	NaNO3	lgK:12.7(0.1SD)	0	MGL	956

Reaction No. 6485							
2<5ATP-4> + Mg+2 = Mg+2_5ATP-4(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.3(2SF)	1	ELC	
2	25	0.25	Pr4N+ salt	lgK:6.0(0.2SD)	0	MGL	3595
3	25	0.5	NaNO3	lgK:5.5(0.09SD)	0	MGL	956
4	10:45	0.25	Pr4N+ salt	dG:-34.(2.SD) kJ	0	EFE	3595

Reaction No. 6490							
Mg+2 + Ca+2 + 5ATP-4 = Ca+2_Mg+2_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaNO3	lgK:5.5(0.2SD)	4	MGL	956

Reaction No. 6524							
Val-1 + Mg+2 = Mg+2_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:1.6(0.08SD)	6	MGL	2392
2	25	0	Inf. Dilution	lgK:2.1(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:1.7(0.05SD)	3	ENS	94


Reaction No. 6841							
ClAcet-1 + Mg+2 = Mg+2_ClAcet-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.4	NaNO3	lgK:0.2(0.05SD)	4	MGL	382

Reaction No. 7252							
Propanoic-1 + Mg+2 = Mg+2_Propanoic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:0.54(2SF)	5	MHY	4920
2	25	0	Inf. Dilution	lgK:2.36(3SF)	5	MSC	4482
3	25	0	UCT_Sea	lgK:0.94(0.01SD)	4	EDH	5390
4	25	0.03	NaCl	lgK:1.01(3SF)	5	MIS	11516
Note (4): Emara M et al., Electrochim. Acta, 1981, 26, 1705							
5	25	0.1	UCT_Sea	lgK:0.60(0.01SD)	4	EDH	5390
6	25	0.2	UCT_Sea	lgK:0.54(0.01SD)	4	EDH	5390
7	25	0.3	UCT_Sea	lgK:0.51(0.01SD)	4	EDH	5390
8	25	0.4	UCT_Sea	lgK:0.50(0.01SD)	4	EDH	5390
9	25	0.5	UCT_Sea	lgK:0.49(0.01SD)	4	EDH	5390
10	25	0.6	UCT_Sea	lgK:0.48(0.01SD)	4	EDH	5390
11	25	0.7	UCT_Sea	lgK:0.48(0.01SD)	4	EDH	5390
12	25	0.8	NaClO4	lgK:0.12(2SF)	5	MSL	11516
Note (12): Fedorova V et al., Zhur. Neorg. Khim., 1977, 22, 1215							

Reaction No. 7344							
OHEtDiPhos-4 + Mg+2 = Mg+2_OHEtDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:6.55(3SF)	5	MGL	931
2	25	0.1	KNO3	lgK:4.49(3SF)	0	MGL	1599
3	25	0.1	Me4NCl	lgK:7.28(3SF)	4	MGL	2756
4	25	0.1	Unknown	lgK:7.3(0.2SD)	6	CIU	7242


5	25	0.5	Many Media	lgK:6.4 (0.1SD)	6	CIU	7242
6	25	0.5	Me4NC1	lgK:6.39 (0.16SD)	4	MGL	3083
7	25	1	Unknown	lgK:7.2 (0.1SD)	6	CIU	7242

Reaction No. 7345




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.31 (3SF)	3	MGL	1599
2	25	0.1	Me4NC1	lgK:3.70 (3SF)	5	MGL	2756
3	25	0.1	Unknown	lgK:3.7 (0.1SD)	6	CIU	7242
4	25	0.5	Me4NC1	lgK:3.32 (0.06SD)	5	MGL	3083
5	25	0.5	Unknown	lgK:3.3 (0.1SD)	6	CIU	7242
6	25	1	Unknown	lgK:3.1 (0.1SD)	6	CIU	7242

Reaction No. 7346




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:10.50 (4SF)	6	MGL	999
2	25	0.1	Me4NC1	lgK:10.75 (4SF)	5	MGL	2756

Reaction No. 7747




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:0.9 (0.06SD)	4	MPS	1103

Reaction No. 8162



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:3.0 (0.03SD)	4	MGL	1275
2	25	0.1	KNO3	lgK:3.1 (0.03SD)	4	MGL	1275
3	35	0.1	KNO3	lgK:2.7 (0.03SD)	4	MGL	1031
4	45	0.1	KNO3	lgK:3.4 (0.03SD)	4	MGL	1275
5	25	0.1	KNO3	dH:5. (0.5SD)	5	MCL	1275


Reaction No. 8347



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	37	0.15	NaCl	lgK:25.20 (0.01SD)	4	MGL	978
---	----	------	------	--------------------	---	-----	-----

Reaction No. 8348




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:17.2 (0.07SD)	4	MGL	978

Reaction No. 8349




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:12.37 (0.02SD)	6	MGL	978

Reaction No. 8350




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:5.14 (0.006SD)	6	MGL	978

Reaction No. 8450




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:4.7 (0.08SD)	5	MGL	2482

Reaction No. 10032




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:4.744 (0.002SD)	6	MGL	1144

Reaction No. 10033



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:7.6 (0.03SD)	4	MGL	1144

Reaction No. 10042



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:5.5 (0.02SD)	6	MGL	1144

Reaction No. 10043

2<DeOxDeMeTetracycline-2> + Mg+2 = Mg+2_DeOxDeMeTetracycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:9.3(0.09SD)	3	MGL	1144

Reaction No. 10044							
H+1 + DeOxDeMeTetracycline-2 + Mg+2 = Mg+2_H+1_DeOxDeMeTetracycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:13.07(0.02SD)	4	MGL	1144

Reaction No. 10045							
H+1 + 2<DeOxDeMeTetracycline-2> + Mg+2 = Mg+2_H+1_DeOxDeMeTetracycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:19.3(0.02SD)	4	MGL	1144

Reaction No. 10046							
2<H+1> + 2<DeOxDeMeTetracycline-2> + Mg+2 = Mg+2_H+1(2)_DeOxDeMeTetracycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:26.6(0.03SD)	6	MGL	1144

Reaction No. 10371							
PO4Ser-3 + Mg+2 = Mg+2_PO4Ser-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Pr4NI	lgK:3.3(0.1SD)	0	MGL	931
2	25	0.1	Unknown	lgK:2.44(3SF)	6	CRV	552
3	25	0.15	KCl	lgK:2.4(2SF)	4	MGL	931
4	25	0.2	KNO3	lgK:2.00(0.02SD)	4	MGL	1370
5	37	0.15	Et4NBr	lgK:2.9(0.04SD)	2	MGL	906
6	37	0.15	KNO3	lgK:2.55(0.02SD)	3	MGL	906

Reaction No. 10372							
Mg+2 + H+1_PO4Ser-3 = Mg+2_H+1_PO4Ser-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Pr4NI	lgK:2.5(0.1SD)	0	MGL	931
2	25	0.15	KCl	lgK:1.60(3SF)	6	MGL	931
3	25	0.2	KNO3	lgK:1.3(0.06SD)	3	MGL	1370
4	37	0.15	Et4NBr	lgK:1.8(0.08SD)	2	MGL	906
5	37	0.15	KNO3	lgK:1.8(0.08SD)	3	MGL	906

Reaction No. 10373							
$\text{Mg}+2 + \text{H}+1(2)\text{PO4Ser-3} = \text{Mg}+2\text{H}+1(2)\text{PO4Ser-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Et4NBr	$\lg K: 2.0(0.1\text{SD})$	0	MGL	906
2	37	0.15	KNO3	$\lg K: 1.4(0.1\text{SD})$	0	MGL	906
3	37	0.15	Unknown	$\lg K: 5.21(3\text{SF})$	6	CRV	552

Reaction No. 10374							
$\text{Mg}+2\text{H}+1(2)\text{PO4Ser-3} + \text{H}+1\text{PO4Ser-3} = \text{Mg}+2\text{H}+1(3)\text{PO4Ser-3}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Et4NBr	$\lg K: 1.(0.3\text{SD})$	0	MGL	999
2	37	0.15	KNO3	$\lg K: 2.(0.3\text{SD})$	3	MGL	999

Reaction No. 10375							
$2<\text{Mg}+2\text{H}+1\text{PO4Ser-3}> = \text{Mg}+2(2)\text{H}+1(2)\text{PO4Ser-3}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Et4NBr	$\lg K: 1.(0.3\text{SD})$	0	MGL	999
2	37	0.15	KNO3	$\lg K: 2.(0.3\text{SD})$	3	MGL	999

Reaction No. 10479							
$\text{Mg}+2 + \text{OxAcet-2} = \text{Mg}+2\text{OxAcet-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	$\lg K: 2.0(0.09\text{SD})$	0	MGL	999
2	25	0.1	KCl	$\lg K: 1.02(3\text{SF})$	4	MSP	1511
3	25	0.5	KCl	$\lg K: 0.81(2\text{SF})$	4	MKN	1503
4	25	0.1	Dioxan:Water 50:50Vol KCl	$\lg K: 2.67(3\text{SF})$	4	MSP	1511
5	25	0.1	Dioxan:Water 50:50Vol KCl	$\lg K: 2.83(3\text{SF})$	4	MPS	1511

Reaction No. 10480							
$\text{Mg}+2 + \text{H}+1(-1)\text{OxAcet-2} = \text{Mg}+2\text{H}+1(-1)\text{OxAcet-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	$\lg K: 6.27(3\text{SF})$	6	MGL	999

Reaction No. 10481							
--------------------	--	--	--	--	--	--	--

Mg+2 + 2<H+1(-1)_OxAcet-2> = Mg+2_H+1(-2)_OxAcet-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:11.09(4SF)	6	MGL	999

Reaction No. 10495							
Mg+2 + H+1_Succinic-2 = Mg+2_H+1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:0.52(2SF)	6	MHY	999

Reaction No. 10512							
MeMalon-2 + Mg+2 = Mg+2_MeMalon-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:1.73(3SF)	6	MGL	476

Reaction No. 10576							
Diglycol-2 + Mg+2 = Mg+2_Diglycol-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:1.61(3SF)	0	MGL	1257
2	25	0.1	KNO3	lgK:2.06(3SF)	2	MGL	2308
3	25	0.1	KNO3	lgK:2.15(0.01SD)	2	MGL	3519
4	30	0.1	KCl	lgK:1.7(2SF)	2	MGL	4250

Reaction No. 10613							
Mg+2 + H+1_Malic-2 = Mg+2_H+1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:0.90(2SF)	5	MGL	154
2	20	0.1	NaClO4	lgK:1.70(3SF)	0	MGL	22560
3	20:25	4	KCl	lgK:0.77(2SF)	5	MHY	999
4	25	0.2	KCl	lgK:0.77(2SF)	3	MEF	22560

Reaction No. 10649							
Mg+2 + H+1_Tartaric-2 = Mg+2_H+1_Tartaric-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:0.92(2SF)	6	MHY	999

Reaction No. 10686							
Butanoic-1 + Mg+2 = Mg+2_Butanoic-1							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.37(3SF)	1	MSC	4482
2	25	0.03	NaCl	lgK:1.01(3SF)	5	MIS	11516
Note (2): Emara M et al., Electrochim. Acta, 1981, 26, 1705							
3	25	0.2	KCl	lgK:0.53(2SF)	5	MHY	4920
4	25	0.8	NaClO4	lgK:-0.02(1SF)	3	MSL	11516
Note (4): Fedorova V et al., Zhur. Neorg. Khim., 1977, 22, 1215							


Reaction No. 10790							
3OHButan-1 + Mg+2 = Mg+2_3OHButan-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:1.00(0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:0.66(0.01SD)	4	EDH	5390
3	25	0.2	KCl	lgK:0.60(2SF)	5	MHY	4920
4	25	0.2	UCT_Sea	lgK:0.60(0.01SD)	4	EDH	5390
5	25	0.3	UCT_Sea	lgK:0.57(0.01SD)	4	EDH	5390
6	25	0.4	UCT_Sea	lgK:0.56(0.01SD)	4	EDH	5390
7	25	0.5	UCT_Sea	lgK:0.56(0.01SD)	4	EDH	5390
8	25	0.6	UCT_Sea	lgK:0.55(0.01SD)	4	EDH	5390
9	25	0.7	UCT_Sea	lgK:0.54(0.01SD)	4	EDH	5390

Reaction No. 10859							
2OH2MePropan-1 + Mg+2 = Mg+2_2OH2MePropan-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:1.27(0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:0.93(0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:0.87(0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:0.84(0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:0.83(0.01SD)	4	EDH	5390
6	25	0.5	NaClO4	lgK:0.98(0.05MD)	6	MGL	4896
7	25	0.5	UCT_Sea	lgK:0.82(0.01SD)	4	EDH	5390
8	25	0.6	UCT_Sea	lgK:0.81(0.01SD)	4	EDH	5390
9	25	0.7	UCT_Sea	lgK:0.81(0.01SD)	4	EDH	5390
10	25	1	NaClO4	lgK:0.81(0.02SD)	4	MQH	999

Reaction No. 10860							
2<2OH2MePropan-1> + Mg+2 = Mg+2_2OH2MePropan-1(2)							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:2.22 (0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:1.67 (0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:1.58 (0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:1.53 (0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:1.50 (0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:1.48 (0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:1.47 (0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:1.47 (0.01SD)	4	EDH	5390
9	25	1	NaClO4	lgK:1.47 (0.04SD)	3	MQH	999

Reaction No. 11032




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.4	NaNO3	lgK:0.3 (0.03SD)	6	MGL	382

Reaction No. 11065




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:9.95 (3SF)	6	MPT	1978
2	25	0.1	KCl	lgK:10.08 (4SF)	6	MGL	2015
3	30	0.1	KCl	lgK:10.29 (4SF)	6	MGL	2019
4	20	1	KCl	dH:1.00 (3SF)	5	MCL	2018

Reaction No. 11291



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.69 (3SF)	4	CRV	552
2	25	0	Inf. Dilution	dH:0.0 (1SF)	4	MHY	999


Reaction No. 11424



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:2.75 (3SF)	6	MGL	999
2	20	0	Inf. Dilution	lgK:2.71 (3SF)	6	MGL	999
3	25	0	Inf. Dilution	lgK:2.6 (2SF)	1	ESC	
4	30	0	Inf. Dilution	lgK:2.54 (3SF)	6	MGL	999


5	40	0	Inf. Dilution	lgK:2.44 (3SF)	6	MGL	999
6	10:40	0	Inf. Dilution	dH:-4.3 (2SF)	5	MGL	999

Reaction No. 11461




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:1.55 (3SF)	6	MGL	476

Reaction No. 11478




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:2.526 (4SF)	5	MCO	4861
2	25	0	Inf. Dilution	lgK:2.625 (4SF)	5	MCO	4861
3	25	0.1	NaClO4	lgK:1.62 (3SF)	6	MGL	476
4	30	0	Inf. Dilution	lgK:2.675 (4SF)	5	MCO	4861
5	35	0	Inf. Dilution	lgK:2.705 (4SF)	5	MCO	4861
6	25	0	Inf. Dilution	dH:13. (2.SD) kJ	4	MCO	4861

Reaction No. 11502




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.08 (3SF)	5	MGL	2551
2	25	0.2	KCl	lgK:1.08 (3SF)	6	MHY	999

Reaction No. 11503




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:0.52 (2SF)	6	MHY	999

Reaction No. 11680




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.35 (3SF)	6	MGL	999
2	25	0.1	KCl	dH:-0.67 (0.3SD)	5	MTD	3215

Reaction No. 11745




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.54 (3SF)	6	MGL	3511
2	25	1	KNO3	lgK:1.71 (3SF)	6	MGL	3511

Reaction No. 11921




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.19 (3SF)	6	MGL	999

Reaction No. 12112




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:2.06 (3SF)	5	MGL	154
2	25	0.15	Unknown	lgK:2.00 (3SF)	5	MGL	162

Reaction No. 12113




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:1.20 (3SF)	5	MGL	154
2	25	0.15	Unknown	lgK:0.91 (2SF)	5	MGL	162

Reaction No. 12114




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:0.77 (2SF)	5	MGL	154

Reaction No. 12152



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:1.7 (0.02SD)	4	MGL	1231

Reaction No. 12299



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:0.70 (2SF)	5	MHY	4920
2	25	0.1	Unknown	lgK:0.8 (1SF)	4	CRV	31120
3	25	0.1	Unknown	dH:4.0 (2SF) kJ	4	CRV	31120

Reaction No. 12630							
Mg+2_Citrul-1 + Citrul-1 = Mg+2_Citrul-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:0.2 (1SF)	4	MGL	3511

Reaction No. 12789							
HIMDA-2 + Mg+2 = Mg+2_HIMDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.44 (3SF)	6	MGL	3486
2	23	0.1	NH4Cl	lgK:4.8 (2SF)	0	MCG	906
Note (2): Low wgt for internal consistency							
3	25	0.1	NaClO4	lgK:3.5 (2SF)	6	MPL	999
4	30	0.1	KCl	lgK:3.54 (3SF)	6	MGL	999
5	25	0.1	Unknown	dH:2.8 (2SF)	6	CRV	552

Reaction No. 12866							
DHEGly-1 + Mg+2 = Mg+2_DHEGly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KCl	lgK:1.15 (3SF)	6	MGL	999

Reaction No. 12905							
DGEN + Mg+2 = Mg+2_DGEN							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KCl	lgK:0.54 (2SF)	6	MGL	999

Reaction No. 12910							
Benzoic-1 + Mg+2 = Mg+2_Benzoic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.09 (3SF)	4	MGL	4503
2	25	0	UCT_Sea	lgK:0.54 (0.01SD)	4	EDH	5390
3	25	0.03	NaCl	lgK:0.981 (3SF)	4	MGL	4503
4	25	0.045	NaCl	lgK:0.904 (3SF)	4	MGL	4503
5	25	0.1	UCT_Sea	lgK:0.20 (0.01SD)	4	EDH	5390
6	25	0.2	UCT_Sea	lgK:0.14 (0.01SD)	4	EDH	5390
7	25	0.3	NaCl	lgK:0.418 (3SF)	4	MGL	4503
8	25	0.3	UCT_Sea	lgK:0.11 (0.01SD)	4	EDH	5390
9	25	0.4	UCT_Sea	lgK:0.10 (0.01SD)	4	EDH	5390

10	25	0.45	NaCl	lgK:0.322 (3SF)	4	MGL	4503
11	25	0.5	UCT_Sea	lgK:0.09 (0.01SD)	4	EDH	5390
12	25	0.6	UCT_Sea	lgK:0.08 (0.01SD)	4	EDH	5390
13	25	0.7	UCT_Sea	lgK:0.08 (0.01SD)	4	EDH	5390
14	30	0.4	KNO3	lgK:0.1 (1SF)	4	MGL	382
15	35	0	Inf. Dilution	lgK:1.15 (3SF)	4	MGL	4503
16	35	0.03	NaCl	lgK:1.057 (4SF)	4	MGL	4503
17	35	0.045	NaCl	lgK:0.973 (3SF)	4	MGL	4503
18	35	0.3	NaCl	lgK:0.481 (3SF)	4	MGL	4503
19	35	0.45	NaCl	lgK:0.352 (3SF)	4	MGL	4503
20	45	0	Inf. Dilution	lgK:1.20 (3SF)	4	MGL	4503
21	45	0.03	NaCl	lgK:1.093 (4SF)	4	MGL	4503
22	45	0.045	NaCl	lgK:1.037 (4SF)	4	MGL	4503
23	45	0.3	NaCl	lgK:0.526 (3SF)	4	MGL	4503
24	45	0.45	NaCl	lgK:0.380 (3SF)	4	MGL	4503
25	25:45	0	Inf. Dilution	dH:-1.04 (3SF)	4	MTD	4503
26	25		Methanol	lgK:4.7 (2SF)	5	MGL	4795

Reaction No. 12916

SalAld-1 + Mg+2 = Mg+2_SalAld-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KCl	lgK:1.72 (3SF)	6	MGL	183

Reaction No. 12947

Tropolone-1 + Mg+2 = Mg+2_Tropolone-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:3.82 (3SF)	6	MCO	999
2	30		Water:Dioxan 50:50Wgt	lgK:5.5 (2SF)	5	MGL	140

Reaction No. 13027

34DHB-3 + Mg+2 = Mg+2_34DHB-3

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.1 (2SF)	0	ESC	931
2	30	0.1	KNO3	lgK:5.67 (3SF)	2	MGL	140
3	30	0.1	NaClO4	lgK:6.30 (3SF)	2	MGL	931

Reaction No. 13036							
Mg+2_34DHB-3 + 34DHB-3 = Mg+2_34DHB-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:4.17 (3SF)	5	MGL	140

Reaction No. 13186							
35DiNitrSal-2 + Mg+2 = Mg+2_35DiNitrSal-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.30 (3SF)	5	MGL	906
2	30	0.1	KNO3	lgK:2.43 (3SF)	5	MGL	906
3	35	0.1	KNO3	lgK:2.65 (3SF)	5	MGL	906

Reaction No. 13213							
23PyridineDiCOO-2 + Mg+2 = Mg+2_23PyridineDiCOO-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.3 (2SF)	4	MGL	999

Reaction No. 13229							
24PyridineDiCOO-2 + Mg+2 = Mg+2_24PyridineDiCOO-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.4 (2SF)	4	MGL	999

Reaction No. 13282							
26PyridineDiCOO-2 + Mg+2 = Mg+2_26PyridineDiCOO-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:2.30 (3SF)	6	MGL	999
2	20	0.1	Unknown	lgK:2.30 (3SF)	6	ENS	773
3	25	0.1	KNO3	lgK:2.7 (2SF)	4	MGL	999
4	25	0.1	NaCl	lgK:1.9 (0.03SD)	4	MGL	3925
5	25	0.1	Unknown	lgK:2.32 (3SF)	6	MGL	999
6	30	0.1	KCl	lgK:2.4 (2SF)	4	MGL	4250

Reaction No. 13315							
Mg+2_26PyridineDiCOO-2 + 26PyridineDiCOO-2 = Mg+2_26PyridineDiCOO-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:0.7 (1SF)	4	MIX	999

Reaction No. 13576							
EDDM-4 + Mg+2 = Mg+2_EDDM-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:4.86(3SF)	6	CRV	552
2	25	0.1	KNO3	lgK:4.93(3SF)	5	MPL	906
3	25	0.1	KNO3	lgK:4.5(0.07SD)	4	MGL	999

Reaction No. 13577							
Mg+2 + H+1_EDDM-4 = Mg+2_H+1_EDDM-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:2.0(2SF)	6	CRV	552
2	25	0.1	KNO3	lgK:1.80(3SF)	3	MPL	906
3	25	0.1	KNO3	lgK:2.3(0.06SD)	3	MGL	999

Reaction No. 13578							
Mg+2 + Mg+2_EDDM-4 = Mg+2(2)_EDDM-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.49(3SF)	6	MGL	999

Reaction No. 13722							
2<Oxine-1> + Mg+2 = Mg+2_Oxine-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	17:20	1	NH4Cl	lgK:8.18(3SF)	6	MDS	999

Reaction No. 13806							
Mg+2_Sulfox-2 + Sulfox-2 = Mg+2_Sulfox-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:3.7(2SF)	4	MGL	999
2	25	0	Inf. Dilution	lgK:3.4(2SF)	4	MGL	999
3	25	0.1	KNO3	lgK:3.57(3SF)	6	MGL	999
4	25	0.1	Dioxan:Water 60:40Wgt NaClO4	lgK:4.79(3SF)	4	MGL	906

Reaction No. 13855							
Bipy + Mg+2 = Mg+2_Bipy							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0.2	Unknown	lgK:0.38(2SF)	5	MGL	6125

2	5	0.5	Unknown	lgK:0.32 (2SF)	5	MGL	6125
3	5	0.75	Unknown	lgK:0.28 (2SF)	5	MGL	6125
4	10	0.25	Inert	lgK:0.38 (2SF)	6	MGL	1520
5	15	0.2	Unknown	lgK:0.43 (2SF)	5	MGL	6125
6	15	0.5	Unknown	lgK:0.41 (2SF)	5	MGL	6125
7	15	0.75	Unknown	lgK:0.40 (2SF)	5	MGL	6125
8	25	0.2	Unknown	lgK:0.47 (2SF)	5	MGL	6125
9	25	0.25	Inert	lgK:0.32 (2SF)	4	MGL	1520
10	25	0.5	Unknown	lgK:0.5 (1SF)	4	MSP	999
11	25	0.5	Unknown	lgK:0.50 (2SF)	5	MGL	6125
12	25	0.75	Unknown	lgK:0.53 (2SF)	5	MGL	6125
13	35	0.2	Unknown	lgK:0.52 (2SF)	5	MGL	6125
14	35	0.5	Unknown	lgK:0.59 (2SF)	5	MGL	6125
15	35	0.75	Unknown	lgK:0.65 (2SF)	5	MGL	6125
16	40	0.25	Inert	lgK:0.26 (2SF)	0	MGL	1520
17	45	0.2	Unknown	lgK:0.57 (2SF)	5	MGL	6125
18	45	0.5	Unknown	lgK:0.68 (2SF)	5	MGL	6125
19	45	0.75	Unknown	lgK:0.78 (2SF)	5	MGL	6125
20	5	0.2	Unknown	dH:7. (1SF) kJ	3	MTD	6125
21	5	0.5	Unknown	dH:13. (2SF) kJ	5	MTD	6125
22	5	0.75	Unknown	dH:18. (2SF) kJ	3	MTD	6125
23	15	0.2	Unknown	dH:7. (1SF) kJ	3	MTD	6125
24	15	0.5	Unknown	dH:14. (2SF) kJ	5	MTD	6125
25	15	0.75	Unknown	dH:20. (2SF) kJ	2	MTD	6125
26	25	0.2	Unknown	dH:8. (1SF) kJ	4	MTD	6125
27	25	0.25	Inert	dH:-1.5 (2SF)	0	MCL	1520
28	25	0.5	Unknown	dH:15. (2SF) kJ	5	MTD	6125
29	25	0.75	Unknown	dH:21. (2SF) kJ	2	MTD	6125
30	35	0.2	Unknown	dH:9. (1SF) kJ	3	MTD	6125
31	35	0.5	Unknown	dH:16. (2SF) kJ	5	MTD	6125
32	35	0.75	Unknown	dH:23. (2SF) kJ	0	MTD	6125
33	45	0.2	Unknown	dH:9. (1SF) kJ	5	MTD	6125
34	45	0.5	Unknown	dH:17. (2SF) kJ	5	MTD	6125
35	45	0.75	Unknown	dH:24. (2SF) kJ	0	MTD	6125
36	25		Acetone	lgK:2.0 (0.05SD)	4	MFL	2469

37	25	0.05	Ethanol:Water 95:5Wgt Et4NC1O4	lgK:2.20 (0.01SD)	4	MPS	2713
38	25		MeCN	lgK:2.8 (0.09SD)	4	MFL	2469
39	25		Methanol	lgK:1.9 (0.03SD)	4	MFL	2469

Reaction No. 13934							
2QuinCOO-1 + Mg+2 = Mg+2_2QuinCOO-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.37 (3SF)	6	MGL	999

Reaction No. 13935							
2<2QuinCOO-1> + Mg+2 = Mg+2_2QuinCOO-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.55 (3SF)	6	MGL	999

Reaction No. 13969							
8QuinCOO-1 + Mg+2 = Mg+2_8QuinCOO-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.24 (3SF)	6	MGL	999


Reaction No. 13970							
Mg+2_8QuinCOO-1 + 8QuinCOO-1 = Mg+2_8QuinCOO-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.73 (3SF)	6	MGL	999

Reaction No. 14045							
Mg+2 + H+1_EDTA-4 = Mg+2_H+1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.3 (2SF)	4	MGL	1957
2	20	0.1	KNO3	lgK:2.28 (3SF)	6	MGL	1956
3	25	0	Inf. Dilution	lgK:3.52 (3SF)	2	EAE	

Reaction No. 14103							
EDDS-4 + Mg+2 = Mg+2_EDDS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:6.09 (3SF)	4	MGL	2006
2	20	0.1	KNO3	lgK:5.6 (2SF)	0	MEP	2006


3	25	0	Inf. Dilution	lgK:7.77 (3SF)	4	CRV	29666
4	25	0.1	KNO3	lgK:5.8 (0.05SD)	0	MGL	999
5	25	0.1	Unknown	lgK:6.01 (3SF)	4	CRV	552
6	25	0.1	Unknown	lgK:6.39 (3SF)	3	CRV	31120
7	25	0.3	Unknown	lgK:5.55 (0.125SD)	2	EOD	29124
8	25	0.5	KNO3	lgK:5.6 (0.03SD)	2	MGL	3832
9	15	0.5	KNO3	dH:21.32 (4SF) kJ	2	MTD	3832
10	25	0.1	Unknown	dH:7.0 (2SF) kJ	2	CRV	31120
11	25	0.5	KNO3	dH:23.78 (4SF) kJ	2	MTD	3832
12	35	0.5	KNO3	dH:28.02 (4SF) kJ	2	MTD	3832

Reaction No. 14104




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:1.78 (3SF)	3	MGL	999
2	25	0.1	KNO3	lgK:2.6 (0.05SD)	0	MGL	999
3	25	0.3	Unknown	lgK:1.64 (0.15SD)	2	EOD	29124
4	25	0.5	KNO3	lgK:1.5 (0.04SD)	3	MGL	3832

Reaction No. 14105



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.1 (0.06SD)	4	MGL	999


Reaction No. 14200



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:1.95 (0.02SD)	5	MGL	3482
2	12	0.1	KNO3	lgK:2.16 (0.02SD)	5	MGL	3482
3	15	0.1	KNO3	lgK:2.18 (3SF)	6	MGL	259
4	20	0.1	KCl	lgK:2.0 (2SF)	3	MGL	280
5	20	0.1	KCl	lgK:2.09 (3SF)	5	MGL	999
6	25	0.02	Unknown	lgK:1.7 (0.2SD)	0	MRM	906
7	25	0.1	KCl	lgK:2.16 (3SF)	5	MGL	999
8	25	0.1	KNO3	lgK:1.89 (3SF)	2	MGL	1437
9	25	0.1	KNO3	lgK:2.24 (0.02SD)	5	MGL	3482
10	25	0.1	Me4N+ salt	lgK:2.3 (0.1SD)	8	CIU	1437


11	25	0.1	NaClO ₄	lgK:2.42 (0.025SD)	2	MGL	1369
12	25	0.1	NaClO ₄	lgK:1.94 (3SF)	2	MGL	1437
13	25	0.1	NaClO ₄	lgK:2.12 (3SF)	4	MGL	1437
14	25	0.2	Me ₄ N ⁺ salt	lgK:1.15 (3SF)	2	MGL	257
15	25	0.2	Pr ₄ NCl	lgK:1.491 (4SF)	0	MGL	257
16	25	0.25	Pr ₄ N ⁺ salt	lgK:2.0 (2SF)	4	EUN	1437
17	25	0.5	Inert	lgK:2.1 (0.1SD)	2	CIU	1437
18	25	0.5	Na ⁺ salt	lgK:2.1 (2SF)	0	MGL	1437
19	30	0.1	Et ₄ NBr	lgK:2.7 (2SF)	0	MGL	999
20	30	0.1	Et ₄ NBr	lgK:2.7 (2SF)	0	MGL	1437
21	30	0.1	KNO ₃	lgK:2.8 (2SF)	0	MMR	1437
22	35	0.1	KNO ₃	lgK:2.77 (3SF)	0	MGL	1437
23	37	0.15	Na ⁺ salt	lgK:2.4 (0.07SD)	0	CIU	1437
24	40	0.1	KNO ₃	lgK:2.29 (0.02SD)	5	MGL	3482
25	10:37	0	Pr ₄ NBr	dH:2.2 (2SF)	3	MTD	1437
26	10:37	0.1	Pr ₄ NBr	dH:1.9 (2SF)	4	MTD	1437
27	12:40	0.1	KNO ₃	dH:2.4 (2SF)	4	MTD	1437
28	25	0.1	Inert	dH:9.6 (0.8SD) kJ	5	CIU	1437
29	25	0.1	KNO ₃	dH:3.4 (0.1SD)	0	MCL	3482
30	25:40	0.1	NaClO ₄	dH:2.3 (2SF)	4	MCL	1437

Reaction No. 14201



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.58 (3SF)	2	MGL	999
2	25	0	Inf. Dilution	lgK:2.6 (2SF)	1	EDH	
3	25	0.5	Na ⁺ salt	lgK:1.7 (2SF)	2	MGL	1437
4	30	0.1	Et ₄ NBr	lgK:1.3 (2SF)	0	MGL	1437


Reaction No. 14362



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:6.02 (3SF)	6	MGL	1957
2	20	0.1	KNO ₃	lgK:6.21 (3SF)	6	MGL	1956
3	25	0.1	Unknown	lgK:6.33 (3SF)	6	CRV	552
4	20	0.1	KNO ₃	dH:9.09 (3SF)	5	MCL	1956


5	25	0.1	NaNO ₃	dH:9.09 (3SF)	5	MCL	1379
---	----	-----	-------------------	---------------	---	-----	------

Reaction No. 14363




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.91 (3SF)	6	MGL	1957
2	20	0.1	KNO ₃	lgK:3.05 (3SF)	6	MGL	1956

Reaction No. 14446




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.25 (3SF)	6	MPL	999
2	20	0.1	KNO ₃	lgK:4.5 (2SF)	0	MSC	999
3	30	0.1	KCl	lgK:5.3 (2SF)	5	MGL	2019

Reaction No. 14450




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.63 (3SF)	6	MGL	999

Reaction No. 14504




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:11.33 (4SF)	6	MGL	1947
2	20	0.1	KCl	lgK:11.44 (4SF)	6	MGL	2000
3	25	0.1	KCl	lgK:11.41 (0.02SD)	6	MGL	128

Reaction No. 14551



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:8.84 (3SF)	6	MGL	999
2	20	0.1	KCl	lgK:8.85 (3SF)	6	MGL	2000

Reaction No. 14552



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.07 (3SF)	6	MGL	999

Reaction No. 14583							
EDDG-4 + Mg+2 = Mg+2_EDDG-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:3.90 (3SF)	2	CRV	552
2	25	0.1	KNO3	lgK:3.0 (0.05SD)	2	MGL	999

Reaction No. 14584							
Mg+2 + H+1_EDDG-4 = Mg+2_H+1_EDDG-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:1.4 (2SF)	6	CRV	552
2	25	0.1	KNO3	lgK:1.3 (0.04SD)	3	MGL	999

Reaction No. 14585							
Mg+2_EDDG-4 + Mg+2 = Mg+2 (2)_EDDG-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.7 (0.06SD)	4	MGL	999


Reaction No. 14613							
Pyrid2Azo4DiMeAniline + Mg+2 = Mg+2_Pyrid2Azo4DiMeAniline							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaNO3	lgK:0.0 (1SF)	4	MSP	5703

Reaction No. 14767							
CrO4-2 + Mg+2 = Mg+2_CrO4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0.01	0	Inf. Dilution	lgK:2.6571 (5SF)	4	EOD	22958
2	25	0	Inf. Dilution	lgK:2.4717 (5SF)	4	EOD	22958
3	60	0	Inf. Dilution	lgK:2.3558 (5SF)	4	EOD	22958
4	100	0	Inf. Dilution	lgK:2.3416 (5SF)	4	EOD	22958
5	150	0	Inf. Dilution	lgK:2.4680 (5SF)	4	EOD	22958
6	200	0	Inf. Dilution	lgK:2.7635 (5SF)	4	EOD	22958

Reaction No. 14874							
HexMDTA-4 + Mg+2 = Mg+2_HexMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.8 (2SF)	2	MGL	1956
2	25	0	Inf. Dilution	lgK:6.0 (2SF)	1	EDH	


3	25	0.1	KNO3	lgK:4.2(0.07SD)	3	MGL	999
---	----	-----	------	-----------------	---	-----	-----

Reaction No. 14875




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.66(3SF)	6	MGL	1956
2	25	0.1	KNO3	lgK:3.4(0.06SD)	4	MGL	999

Reaction No. 14876




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.3(0.08SD)	4	MGL	999

Reaction No. 14921




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.4(2SF)	4	MHY	1957
2	20	0.1	KCl	lgK:3.47(3SF)	5	MGL	3584
3	20	0.1	KNO3	lgK:3.4(2SF)	4	MGL	1956
4	25	0	Inf. Dilution	lgK:3.5(2SF)	1	ESC	

Reaction No. 14970




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:13.9(3SF)	4	MGL	999

Reaction No. 14987



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.81(3SF)	2	MGL	999
2	30	0.1	KCl	lgK:1.9(2SF)	1	MGL	999

Reaction No. 14988



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:7.55(3SF)	6	MGL	999
2	30	0.1	KCl	lgK:7.39(3SF)	6	MGL	999

Reaction No. 15034							
$H+1 + MECAMS-9 + Mg+2 = Mg+2_H+1_MECAMS-9$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:22.3(0.2SD)	3	MGL	1348

Reaction No. 15035							
$2<H+1> + MECAMS-9 + Mg+2 = Mg+2_H+1(2)_MECAMS-9$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:27.9(0.1SD)	4	MGL	1348

Reaction No. 15052							
$4<H+1> + 343LICAMS-12 + Mg+2 = Mg+2_H+1(4)_343LICAMS-12$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:50.(0.3SD)	3	MGL	1348

Reaction No. 15053							
$3<H+1> + 343LICAMS-12 + Mg+2 = Mg+2_H+1(3)_343LICAMS-12$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:43.(0.4SD)	3	MGL	1348


Reaction No. 15054							
$2<H+1> + 343LICAMS-12 + Mg+2 = Mg+2_H+1(2)_343LICAMS-12$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:34.(0.3SD)	3	MGL	1348

Reaction No. 15055							
$343LICAMS-12 + 2<Mg+2> = Mg+2(2)_343LICAMS-12$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:19.9(0.2SD)	3	MGL	1348

Reaction No. 15249							
$NTMP-6 + Mg+2 = Mg+2_NTMP-6$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:7.52(0.02SD)	6	MGL	1338
2	25	1	KNO3	lgK:6.5(0.1SD)	4	MGL	931
3	25	1	Unknown	lgK:6.49(3SF)	6	ENS	773
4	25	0	Inf. Dilution	dH:9.5(2SF)	5	MCL	2261


5	25	0.1	KNO3	dH:6.17 (3SF)	5	MCL	2876
---	----	-----	------	---------------	---	-----	------

Reaction No. 15250




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:9.42 (0.02SD)	6	MGL	1338
2	25	1	Unknown	lgK:9.1 (2SF)	4	ENS	773
3	25	0.1	KNO3	dH:-11.6 (3SF)	5	MCL	2876

Reaction No. 15251




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:6.1 (0.04SD)	4	MGL	1338
2	25	1	Unknown	lgK:6.2 (2SF)	4	ENS	773
3	25	0.1	KNO3	dH:2.10 (3SF)	5	MCL	2876

Reaction No. 15252



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.8 (0.1SD)	4	MGL	1338
2	25	1	Unknown	lgK:4.6 (2SF)	4	ENS	773

Reaction No. 15496



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Unknown	lgK:10.70 (4SF)	0	ENS	1354
2	25	0.1	Me4NCl	lgK:9.69 (3SF)	6	MSP	1207
3	25	0.1	NaNO3	lgK:9.69 (3SF)	6	ENS	1823
4	25	0.1	NaNO3	lgK:8.9 (0.1SD)	0	MGL	2031
5	25	0.1	NaNO3	lgK:9.69 (0.03SD)	5	CRV	13242
6	25	0.1	Unknown	lgK:8.93 (3SF)	0	ENS	1354
7	35	0.1	NaNO3	lgK:9.66 (0.03SD)	5	CRV	13242
8	35	0.1	Unknown	lgK:9.7 (0.03SD)	3	MGL	1379
9	45	0.1	Unknown	lgK:9.64 (0.02SD)	3	MGL	1379
10	55	0.1	Unknown	lgK:9.73 (0.02SD)	3	MGL	1379
11	20:60	0.1	Unknown	dH:0.0 (1SF)	6	CRV	552
12	25	0.1	NaNO3	dH:0.4 (0.9SD)	6	MCL	1379

Reaction No. 15541							
Tetracycline-2 + 2<Mg+2> = Mg+2(2)_Tetracycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:7.740 (4SF)	6	MGL	1337

Reaction No. 15542							
H+1 + Tetracycline-2 + Mg+2 = Mg+2_H+1_Tetracycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:12.657 (5SF)	6	MGL	1337

Reaction No. 15543							
2<Tetracycline-2> + Mg+2 = Mg+2_Tetracycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:8.698 (4SF)	6	MGL	1337

Reaction No. 15544							
H+1 + 2<Tetracycline-2> + Mg+2 = Mg+2_H+1_Tetracycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:17.597 (5SF)	6	MGL	1337

Reaction No. 15545							
2<H+1> + 2<Tetracycline-2> + Mg+2 = Mg+2_H+1(2)_Tetracycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:25.275 (5SF)	6	MGL	1337

Reaction No. 15554							
OxTetracycline-2 + Mg+2 = Mg+2_OxTetracycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:3.8 (2SF)	5	MGL	3682
2	37	0.15	NaCl	lgK:4.874 (4SF)	6	MGL	1337

Reaction No. 15555							
OxTetracycline-2 + 2<Mg+2> = Mg+2(2)_OxTetracycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:8.346 (4SF)	6	MGL	1337

Reaction No. 15556							
--------------------	--	--	--	--	--	--	--

2<OxTetracycline-2> + Mg+2 = Mg+2_OxTetracycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:9.560(4SF)	6	MGL	1337

Reaction No. 15557							
H+1 + 2<OxTetracycline-2> + Mg+2 = Mg+2_H+1_OxTetracycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:17.423(5SF)	6	MGL	1337

Reaction No. 15558							
2<H+1> + 2<OxTetracycline-2> + Mg+2 = Mg+2_H+1(2)_OxTetracycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:24.095(5SF)	6	MGL	1337

Reaction No. 15559							
H+1 + OxTetracycline-2 + 2<Mg+2> = Mg+2(2)_H+1_OxTetracycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:14.970(5SF)	6	MGL	1337

Reaction No. 15567							
Doxycycline-2 + 2<Mg+2> = Mg+2(2)_Doxycycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:8.546(4SF)	6	MGL	1337

Reaction No. 15568							
H+1 + Doxycycline-2 + Mg+2 = Mg+2_H+1_Doxycycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:12.988(5SF)	6	MGL	1337

Reaction No. 15569							
H+1 + 2<Doxycycline-2> + Mg+2 = Mg+2_H+1_Doxycycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:17.420(5SF)	6	MGL	1337

Reaction No. 15570							
2<H+1> + 2<Doxycycline-2> + Mg+2 = Mg+2_H+1(2)_Doxycycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:25.559(5SF)	6	MGL	1337

Reaction No. 15576							
$H+1 + ClTetracycline-2 + Mg+2 = Mg+2_H+1_ClTetracycline-2$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:11.515 (5SF)	6	MGL	1337

Reaction No. 15577							
$2<H+1> + 2<ClTetracycline-2> + Mg+2 = Mg+2_H+1(2)_ClTetracycline-2(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:23.995 (5SF)	6	MGL	1337

Reaction No. 15624							
$Mg+2_Diglycol-2 + H+1 = Mg+2_H+1_Diglycol-2$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.0 (2SF)	4	MGL	1257

Reaction No. 15637							
$COOMeTartronic-3 + Mg+2 = Mg+2_COOMeTartronic-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.77 (3SF)	6	MGL	1257

Reaction No. 15638							
$Mg+2_COOMeTartronic-3 + H+1 = Mg+2_H+1_COOMeTartronic-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.07 (3SF)	6	MGL	1257

Reaction No. 15661							
$DiTartronic-4 + Mg+2 = Mg+2_DiTartronic-4$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.43 (3SF)	6	MGL	1257

Reaction No. 15662							
$Mg+2_DiTartronic-4 + H+1 = Mg+2_H+1_DiTartronic-4$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.33 (3SF)	6	MGL	1257

Reaction No. 15906							
$Mg+2 + Maleic-2 = Mg+2_Maleic-2$							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:2.228(4SF)	5	MCO	4861
2	25	0	Inf. Dilution	lgK:2.303(4SF)	5	MCO	4861
3	25	0.1	Unknown	lgK:1.4(2SF)	4	ESL	1217
4	30	0	Inf. Dilution	lgK:2.332(4SF)	5	MCO	4861
5	35	0	Inf. Dilution	lgK:2.373(4SF)	5	MCO	4861
6	25	0	Inf. Dilution	dH:14.4(1.5SD)kJ	4	MCO	4861

Reaction No. 15915							
Mg+2 + Fumaric-2 = Mg+2_Fumaric-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:0.5(1SF)	4	ESL	1217

Reaction No. 15991							
Mg+2 + TMS-4 = Mg+2_TMS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.94(3SF)	6	MGL	1217

Reaction No. 15992							
Mg+2_TMS-4 + H+1 = Mg+2_H+1_TMS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.21(3SF)	6	MGL	1217

Reaction No. 16017							
Mg+2 + TDS-6 = Mg+2_TDS-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.40(3SF)	6	MGL	1217

Reaction No. 16018							
Mg+2_TDS-6 + H+1 = Mg+2_H+1_TDS-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.41(3SF)	6	MGL	1217

Reaction No. 16019							
Mg+2_TDS-6 + Mg+2 = Mg+2(2)_TDS-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:1.59(3SF)	6	MGL	1217

Reaction No. 16090							
1245BenzTetrCOO-4 + Mg+2 = Mg+2_1245BenzTetrCOO-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.7(0.2SD)	5	MGL	1716
2	25	0	Inert	lgK:3.94(3SF)	6	MGL	1306
3	25	0.1	Inert	lgK:2.63(0.05MD)	6	MGL	1306
4	25	0.25	Inert	lgK:2.60(3SF)	6	MGL	1306
5	25	0.5	Inert	lgK:2.91(3SF)	6	MGL	1306
6	25	0.75	Inert	lgK:3.31(3SF)	6	MGL	1306

Reaction No. 16091							
H+1 + 1245BenzTetrCOO-4 + Mg+2 = Mg+2_H+1_1245BenzTetrCOO-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inert	lgK:9.08(3SF)	6	MGL	1306
2	25	0.1	Inert	lgK:7.41(0.04MD)	6	MGL	1306
3	25	0.25	Inert	lgK:7.32(3SF)	6	MGL	1306
4	25	0.5	Inert	lgK:7.64(3SF)	6	MGL	1306
5	25	0.75	Inert	lgK:8.06(3SF)	6	MGL	1306

Reaction No. 16092							
2<H+1> + 1245BenzTetrCOO-4 + Mg+2 = Mg+2_H+1(2)_1245BenzTetrCOO-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inert	lgK:12.73(4SF)	6	MGL	1306
2	25	0.1	Inert	lgK:10.92(0.06MD)	4	MGL	1306
3	25	0.25	Inert	lgK:10.84(4SF)	6	MGL	1306
4	25	0.5	Inert	lgK:11.23(4SF)	6	MGL	1306
5	25	0.75	Inert	lgK:11.73(4SF)	6	MGL	1306

Reaction No. 16093							
3<H+1> + 1245BenzTetrCOO-4 + Mg+2 = Mg+2_H+1(3)_1245BenzTetrCOO-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inert	lgK:14.9(3SF)	4	MGL	1306
2	25	0.1	Inert	lgK:13.1(0.1MD)	4	MGL	1306
3	25	0.25	Inert	lgK:13.0(3SF)	4	MGL	1306
4	25	0.5	Inert	lgK:13.3(3SF)	4	MGL	1306
5	25	0.75	Inert	lgK:13.8(3SF)	4	MGL	1306

Reaction No. 16094							
1245BenzTetrCOO-4 + 2<Mg+2> = Mg+2(2)_1245BenzTetrCOO-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inert	lgK:5.81(3SF)	6	MGL	1306
2	25	0.1	Inert	lgK:3.7(0.07MD)	4	MGL	1306
3	25	0.25	Inert	lgK:3.48(3SF)	6	MGL	1306
4	25	0.5	Inert	lgK:3.65(3SF)	6	MGL	1306
5	25	0.75	Inert	lgK:3.94(3SF)	6	MGL	1306

Reaction No. 16110							
ICRF198-2 + Mg+2 = Mg+2_ICRF198-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.2(2SF)	1	ESC	
2	37	0.15	NaCl	lgK:5.08(0.008SD)	4	MGL	97

Reaction No. 16111							
H+1 + ICRF198-2 + Mg+2 = Mg+2_H+1_ICRF198-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.1(2SF)	1	ESC	
2	37	0.15	NaCl	lgK:8.9(0.05SD)	4	MGL	97

Reaction No. 16112							
2<ICRF198-2> + Mg+2 = Mg+2_ICRF198-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.1(2SF)	1	ESC	
2	37	0.15	NaCl	lgK:6.9(0.05SD)	4	MGL	97

Reaction No. 16132							
ICRF226-2 + Mg+2 = Mg+2_ICRF226-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.1(2SF)	1	ESC	
2	37	0.15	NaCl	lgK:4.88(0.007SD)	6	MGL	97

Reaction No. 16189							
EDTMP-8 + Mg+2 = Mg+2_EDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:8.43(3SF)	0	MGL	1237

2	25	0.1	KNO3	lgK:4.78 (3SF)	0	MGL	1595
3	25	0.1	KNO3	lgK:5.69 (3SF)	3	MMX	2780
4	25	0.1	KNO3	lgK:8.4 (0.03SD)	0	MGL	2876
5	37	0.15	NaCl	lgK:5.49 (0.01SD)	4	MGL	4910
6	25	0.1	KNO3	dH:16.5 (0.7SD) kJ	4	MCL	2876

Reaction No. 16190							
Mg+2_EDTMP-8 + H+1 = Mg+2_H+1_EDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:9.95 (3SF)	3	MGL	1237
2	25	0.1	KNO3	lgK:10.60 (4SF)	0	MMX	2780
3	25	0.1	KNO3	lgK:10.07 (0.01SD)	3	MGL	2876
4	37	0.15	NaCl	lgK:9.21 (0.01SD)	2	MGL	4910
5	25	0.1	KNO3	dH:-25.7 (0.3SD) kJ	2	MCL	2876


Reaction No. 16191							
Mg+2_H+1_EDTMP-8 + H+1 = Mg+2_H+1(2)_EDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:8.79 (3SF)	5	MGL	1237
2	25	0.1	KNO3	lgK:9.10 (3SF)	3	MMX	2780
3	25	0.1	KNO3	lgK:8.73 (0.02SD)	5	MGL	2876
4	37	0.15	NaCl	lgK:8.63 (0.01SD)	5	MGL	4910
5	25	0.1	KNO3	dH:-20.7 (0.3SD) kJ	5	MCL	2876

Reaction No. 16192							
Mg+2_H+1(2)_EDTMP-8 + H+1 = Mg+2_H+1(3)_EDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:6.96 (3SF)	5	MGL	1237
2	25	0.1	KNO3	lgK:8.23 (3SF)	0	MMX	2780
3	25	0.1	KNO3	lgK:6.86 (0.02SD)	5	MGL	2876
4	37	0.15	NaCl	lgK:7.06 (0.02SD)	5	MGL	4910
5	25	0.1	KNO3	dH:0.3 (0.4SD) kJ	5	MCL	2876

Reaction No. 16193							
Mg+2_H+1(3)_EDTMP-8 + H+1 = Mg+2_H+1(4)_EDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.97 (3SF)	5	MGL	1237


2	25	0.1	KNO3	lgK:7.07(3SF)	0	MMX	2780
3	25	0.1	KNO3	lgK:5.3(0.06SD)	5	MGL	2876
4	25	0.1	KNO3	dH:0.6(0.5SD) kJ	4	MCL	2876

Reaction No. 16328




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.2	KNO3	lgK:1.63(0.02SD)	4	MGL	1258

Reaction No. 16497




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:18.3(0.03SD)	5	MGL	1297

Reaction No. 16527




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NBr	lgK:1.(1SF)	3	MGL	4245

Reaction No. 16529




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NBr	lgK:0.5(1SF)	3	MGL	4245

Reaction No. 16532




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.2(2SF)	1	ESC	
2	70	0.2	Me4NCl	lgK:3.9(2SF)	4	MGL	1437

Reaction No. 16686



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NCl	lgK:7.1(2SF)	4	MSP	1207


Reaction No. 16887



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	20	0.1	KNO3	lgK:9.40 (0.02SD)	5	MGL	2010
2	25	0.1	KCl	lgK:9.14 (0.02SD)	4	MGL	999

Reaction No. 16902




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.66 (0.01SD)	6	MGL	1274

Reaction No. 16916




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:10.3 (0.03SD)	3	MGL	1274
2	25	0.1	Unknown	lgK:10.40 (4SF)	6	CRV	552

Reaction No. 16972



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:2.9 (0.03SD)	4	MGL	1275
2	25	0.1	KNO3	lgK:3.0 (0.03SD)	4	MGL	1275
3	35	0.1	KNO3	lgK:3.1 (0.03SD)	4	MGL	1275
4	45	0.1	KNO3	lgK:3.2 (0.03SD)	4	MGL	1275

Reaction No. 17040



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:1.77 (3SF)	4	MKN	1437
2	25	0	Bu3EtNBr	lgK:2.5 (2SF)	4	MSP	2060
3	25	0	Na+1 salt	lgK:2.61 (3SF)	4	MIS	1437
4	25	0.04	Tris buffer	lgK:1.52 (3SF)	4	MSP	1437
5	25	0.1	Me4N+ salt	lgK:1.7 (2SF)	8	MCL	1437
6	25	0.11	Bu3EtNBr	lgK:1.8 (2SF)	4	MSP	2060
7	25	0.16	Unknown	lgK:1.52 (3SF)	4	MMR	1437
8	25	0.25	Pr4N+ salt	lgK:1.5 (2SF)	4	MSP	1437
9	30	0.3	Me4NC1	lgK:1.6 (2SF)	4	MSP	1437
10	37	0.2	Me4NC1	lgK:1.69 (3SF)	4	MCL	1437

Reaction No. 17047

5GTP-4 + Mg+2 = Mg+2_5GTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.1	NaCl	lgK:4.02 (3SF)	4	MIX	1437
2	25	0.1	KNO3	lgK:5.0 (0.06SD)	0	MGL	1972
3	25	0.1	Me4N+ salt	lgK:4.5 (0.07SD)	6	CIU	1437
4	25	0.1	NaClO4	lgK:4.13 (0.05MD)	5	MGL	2648
5	30	0.2	Me4NBr	lgK:3.9 (0.05SD)	4	MCL	1971
6	30	0.2	Me4NCl	lgK:3.9 (0.05SD)	4	MCL	1437
7	35	0.1	KNO3	lgK:5.2 (0.06SD)	0	MGL	1972
8	45	0.1	KNO3	lgK:5.0 (0.06SD)	0	MGL	1972
9	30	0.2	Me4NBr	dG:-5.42 (3SF)	5	EFE	1971
10	25	0.1	Inert	dH:18.0 (0.8SD) kJ	5	CIU	1437
11	25:45	0.1	KNO3	dH:0.90 (0.01SD)	2	MTD	1972
12	30	0.2	Me4NBr	dH:4.3 (2SF)	4	MCL	1971
13	30	0.2	Me4NBr	dH:4.29 (3SF)	5	MCL	1971

Reaction No. 17048							
Mg+2 + H+1_5GTP-4 = Mg+2_H+1_5GTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:2.3 (0.05SD)	7	CIU	1437
2	25	0.1	Me4N+ salt	lgK:2.23 (3SF)	5	MCL	1437

Reaction No. 17055							
5ITP-4 + Mg+2 = Mg+2_5ITP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.1	NaCl	lgK:4.04 (3SF)	4	MIX	1437
2	25	0	Inf. Dilution	lgK:5.8 (2SF)	1	EDH	
3	25	0.03	Unknown	lgK:5.00 (3SF)	4	MSP	1437
4	25	0.05	Tris buffer	lgK:4.78 (3SF)	4	MSP	1437
5	25	0.1	KNO3	lgK:3.8 (0.06SD)	0	MGL	1972
6	25	0.1	Me4N+ salt	lgK:4.4 (0.07SD)	7	CIU	1437
7	25	0.1	NaClO4	lgK:4.08 (0.02MD)	5	MGL	2648
8	30	0.2	Me4NBr	lgK:3.9 (0.06SD)	5	MCL	1971
9	30	0.2	Me4NCl	lgK:3.9 (0.06SD)	5	MCL	1437
10	35	0.1	KNO3	lgK:4.1 (0.06SD)	4	MGL	1972
11	45	0.1	KNO3	lgK:3.8 (0.06SD)	0	MGL	1972

12	30	0.2	Me4NBr	dG:-5.42 (3SF)	5	EFE	1971
13	25	0.1	Inert	dH:18.8 (0.8SD) kJ	5	CIU	1437
14	25:45	0.1	KNO3	dH:2. (0.8SD)	0	MTD	1972
15	30	0.2	Me4NBr	dH:4.48 (3SF)	4	MCL	1971

Reaction No. 17056							
Mg+2 + H+1_5ITP-4 = Mg+2_H+1_5ITP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:2.3 (0.1SD)	7	CIU	1437
2	30	0.2	Me4NBr	lgK:2.26 (3SF)	4	MCL	1437

Reaction No. 17063							
5CTP-4 + Mg+2 = Mg+2_5CTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:4.03 (3SF)	6	MGL	259
2	23	0.1	NaCl	lgK:4.01 (3SF)	4	MIX	1437
3	25	0.1	KNO3	lgK:4.19 (3SF)	4	MGL	1437
4	25	0.1	Me4N+ salt	lgK:4.4 (0.07SD)	8	CIU	1437
5	25	0.1	NaClO4	lgK:4.08 (0.06MD)	4	MGL	2648
6	25	0.1	NaNO3	lgK:4.20 (0.025SD)	4	MGL	1369
7	35	0.1	KNO3	lgK:4.2 (0.06SD)	3	MGL	3186
8	45	0.1	KNO3	lgK:4.30 (3SF)	4	MGL	1437
9	25:45	0.1	KNO3	dH:2.4 (2SF)	4	MTD	1437

Reaction No. 17064							
Mg+2 + H+1_5CTP-4 = Mg+2_H+1_5CTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:2.18 (3SF)	0	MGL	259
Note (1): Low wgt for internal consistency							
2	25	0.1	KNO3	lgK:3.85 (3SF)	0	MGL	1437
Note (2): Low wgt for internal consistency							
3	25	0.1	Me4N+ salt	lgK:2.2 (0.1SD)	0	CIU	1437
4	25	0.1	NaNO3	lgK:2.27 (0.18SD)	0	MGL	1369
Note (4): Low wgt for internal consistency							
5	35	0.1	KNO3	lgK:3.9 (0.06SD)	3	MGL	3186
6	45	0.1	KNO3	lgK:3.98 (3SF)	4	MGL	1437
7	25:45	0.1	KNO3	dH:2.8 (2SF)	4	MTD	1437

Reaction No. 17065							
Mg+2_5CTP-4 + Mg+2 = Mg+2(2)_5CTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:1.8(0.1SD)	7	CIU	1437

Reaction No. 17081							
5UTP-4 + Mg+2 = Mg+2_5UTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.1	NaCl	lgK:4.02(3SF)	4	MIX	1437
2	25	0.1	Me4N+ salt	lgK:4.4(0.07SD)	3	CIU	1437
3	25	0.1	NaClO4	lgK:4.27(0.01SD)	2	MGL	1369
4	25	0.1	NaClO4	lgK:4.18(3SF)	0	MGL	1437
5	25	0.1	NaClO4	lgK:4.00(3SF)	4	MGL	1437
6	25	0.1	NaClO4	lgK:4.00(0.01MD)	5	MGL	2648
7	25	0.1	NaNO3	lgK:4.23(3SF)	0	MGL	1437
8	30	0.2	Me4NBr	lgK:4.2(0.1SD)	0	MCL	1971
9	35	0.1	KNO3	lgK:5.5(0.06SD)	0	MGL	3159
10	30	0.2	Me4NBr	dG:-5.73(3SF)	0	EFE	1971
11	25	0.1	Inert	dH:18.4(0.8SD)kJ	5	CIU	1437
12	25:45	0.1	KNO3	dH:4.1(2SF)	4	MTD	1437
13	30	0.2	Me4NBr	dH:4.40(3SF)	4	MCL	1971

Reaction No. 17082							
Mg+2 + H+1_5UTP-4 = Mg+2_H+1_5UTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:2.6(0.1SD)	8	CIU	1437
2	25	0.1	NaClO4	lgK:2.72(0.045SD)	4	MGL	1369

Reaction No. 17095							
5TTP-4 + Mg+2 = Mg+2_5TTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:4.5(0.07SD)	7	CIU	1437
2	25	0.1	NaClO4	lgK:4.2(0.04SD)	4	MGL	1369
3	25	0.1	NaClO4	lgK:4.18(0.01MD)	5	MGL	2648

Reaction No. 17102							
--------------------	--	--	--	--	--	--	--

5ADP-3 + Mg+2 = Mg+2_5ADP-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:2.94 (0.02SD)	4	MGL	3481
2	5	0.04	Pr4NBr	lgK:3.48 (3SF)	4	MIX	1437
3	5	0.11	Pr4NBr	lgK:3.24 (3SF)	4	MIX	1437
4	5	0.18	Pr4NBr	lgK:3.14 (3SF)	0	MIX	1437
5	12	0.1	KNO3	lgK:3.05 (0.02SD)	5	MGL	3481
6	15	0.1	KNO3	lgK:3.21 (3SF)	5	MGL	259
7	20	0.05	NEtMorph buffer	lgK:3.71 (3SF)	4	MSP	1437
8	20	0.1	KCl	lgK:3.11 (3SF)	4	MGL	280
9	22	0.25	KNO3	lgK:2.53 (3SF)	0	MGL	1437
10	23	0.1	Na+1 salt	lgK:3.04 (3SF)	2	MIX	1437
11	23	0.1	NaCl	lgK:3.15 (3SF)	3	MIX	1437
12	23	0.1	NaCl	lgK:3.15 (3SF)	5	MIX	31154
13	23	0.1	Unknown	lgK:3.04 (3SF)	6	MIX	999
14	23	0.14	Tris buffer	lgK:3.30 (3SF)	3	MSP	1437
15	23	0.14	Tris buffer	lgK:3.35 (3SF)	3	MSP	1437
16	25	0	Bu3EtNBr	lgK:4.14 (3SF)	4	MSP	1437
17	25	0	Bu3EtNBr	lgK:4.10 (3SF)	4	MSP	2060
18	25	0	Na+1 salt	lgK:4.65 (3SF)	4	MIS	1437
19	25	0	Pr4NBr	lgK:4.27 (3SF)	2	MIX	1437
20	25	0.0006	Unknown	lgK:4.61 (3SF)	4	MSP	1437
21	25	0.001	Unknown	lgK:4.00 (3SF)	4	MIS	1437
22	25	0.002	Unknown	lgK:4.19 (3SF)	4	MSP	1437
23	25	0.004	Unknown	lgK:3.90 (3SF)	4	MIS	1437
24	25	0.004	Unknown	lgK:3.72 (3SF)	4	MSP	1437
25	25	0.007	Unknown	lgK:3.34 (3SF)	2	MSP	1437
26	25	0.009	Unknown	lgK:3.60 (3SF)	4	MIS	1437
27	25	0.03	Unknown	lgK:3.78 (3SF)	4	MSP	1437
28	25	0.04	Pr4NBr	lgK:3.65 (3SF)	4	MIX	1437
29	25	0.05	Me4NCl	lgK:3.34 (3SF)	2	MGL	999
30	25	0.05	Tris buffer	lgK:3.54 (3SF)	4	MSP	1437
31	25	0.095	Me4NCl	lgK:3.63 (3SF)	2	MKN	1437
32	25	0.1	KCl	lgK:3.23 (3SF)	4	MGL	1437
33	25	0.1	KNO3	lgK:3.17 (0.01SD)	5	MGL	3481
34	25	0.1	Me4N+ salt	lgK:3.4 (0.1SD)	8	CIU	1437

35	25	0.1	Me4NC1	lgK:3.90 (3SF)	0	MSP	1437
36	25	0.1	NaCl	lgK:3.90 (3SF)	0	MSP	1437
37	25	0.1	NaClO4	lgK:3.28 (3SF)	6	MGL	1483
38	25	0.1	Pr4NBr	lgK:3.50 (3SF)	4	MIX	1437
39	25	0.11	Bu3EtNBr	lgK:3.342 (4SF)	5	MSP	2060
40	25	0.11	Pr4NBr	lgK:3.44 (3SF)	4	MIX	1437
41	25	0.18	Pr4NBr	lgK:3.33 (3SF)	2	MIX	1437
42	25	0.2	Me4N+ salt	lgK:3.09 (3SF)	4	MGL	257
43	25	0.2	Pr4NC1	lgK:3.00 (3SF)	5	MGL	257
44	25	0.22	Bu3EtNBr	lgK:3.23 (3SF)	5	MSP	2060
45	25	0.22	Et4NBr	lgK:3.23 (3SF)	2	MSP	999
46	30	0	NEtMorph buffer	lgK:4.39 (3SF)	4	MSP	1437
47	30	0.01	Tris buffer	lgK:3.28 (3SF)	0	MIX	1437
48	30	0.01	Tris buffer	lgK:3.10 (3SF)	2	MIX	1437
49	30	0.02	NEtMorph buffer	lgK:3.61 (3SF)	4	MSP	1437
50	30	0.05	Tris buffer	lgK:3.08 (3SF)	4	MIX	1437
51	30	0.1	KNO3	lgK:4.1 (2SF)	0	MMR	1437
52	30	0.2	Me4NC1	lgK:3.69 (3SF)	0	MCL	1437
53	35	0.11	Bu3EtNBr	lgK:3.477 (4SF)	5	MSP	2060
54	37	0.11	Bu3EtNBr	lgK:3.52 (3SF)	4	EOD	2060
55	37	0.15	KCl	lgK:3.37 (3SF)	4	MEP	1437
56	37	0.15	Na+1 salt	lgK:3.2 (0.07SD)	8	CIU	1437
57	40	0.1	KNO3	lgK:3.30 (0.02SD)	5	MGL	3481
58	45	0.04	Pr4NBr	lgK:3.83 (3SF)	4	MIX	1437
59	45	0.11	Pr4NBr	lgK:3.60 (3SF)	4	MIX	1437
60	45	0.18	Pr4NBr	lgK:3.46 (3SF)	2	MIX	1437
61	64	0.11	Bu3EtNBr	lgK:3.839 (4SF)	5	MSP	2060
62	65	0.04	Pr4NBr	lgK:4.00 (3SF)	4	MIX	1437
63	65	0.11	Pr4NBr	lgK:3.76 (3SF)	4	MIX	1437
64	65	0.18	Pr4NBr	lgK:3.64 (3SF)	2	MIX	1437
65	75	0	Me4NOH/m	lgK:4.89 (0.01SD)	4	MCL	7086
66	100	0	Me4NOH/m	lgK:5.29 (0.01SD)	4	MCL	7086
67	30	0.2	Me4NBr	dG:-5.08 (3SF)	0	EFE	1971
68	0:40	0.1	KNO3	dH:3.6 (0.2SD)	0	MCL	3481
69	10:37	0	Pr4NBr	dH:4.3 (2SF)	4	MTD	1437
70	10:37	0.1	Pr4NBr	dH:3.6 (2SF)	4	MTD	1437


71	25	0.1	Inert	dH:13.4(0.8SD) kJ	5	CIU	1437
72	25	0.1	NaClO4	dH:17.53(0.10SD) kJ	6	MCL	1483
73	30	0.2	Me4NBr	dH:3.2(2SF)	4	MCL	1437
74	30	0.2	Me4NBr	dH:3.18(3SF)	5	MCL	1971
75	37:64	0.11	Bu3EtNBr	dH:6.(1SF)	3	MTD	2060
76	75	0	Me4NOH	dH:34.9(0.8SD) kJ	2	MCL	7086
77	100	0	Me4NOH	dH:44.5(0.8SD) kJ	0	MCL	7086
78	75	0	Me4NOH	Cp:386.(16.SD) J/K	4	MCL	7086
79	100	0	Me4NOH	Cp:386.(16.SD) J/K	4	MCL	7086

Reaction No. 17103							
Mg+2 + H+1_5ADP-3 = Mg+2_H+1_5ADP-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:1.39(0.02SD)	4	MGL	3481
2	12	0.1	KNO3	lgK:1.51(0.02SD)	5	MGL	3481
3	15	0.1	KNO3	lgK:1.55(3SF)	5	MGL	259
4	20	0.1	KCl	lgK:1.5(2SF)	4	MGL	280
5	25	0.1	KCl	lgK:1.58(3SF)	4	MGL	1437
6	25	0.1	KNO3	lgK:1.64(0.02SD)	5	MGL	3481
7	25	0.1	Me4N+ salt	lgK:1.6(0.03SD)	8	CIU	1437
8	25	0.1	NaClO4	lgK:1.90(3SF)	2	MGL	1437
9	25	0.1	Pr4NBr	lgK:2.0(2SF)	2	MIX	1437
10	25	0.2	Me4N+ salt	lgK:1.08(3SF)	4	MGL	257
11	25	0.2	Pr4NCl	lgK:1.447(4SF)	5	MGL	257
12	30	0.01	Tris buffer	lgK:2.03(3SF)	3	MGL	1437
13	30	0.1	KNO3	lgK:2.9(2SF)	0	MMR	1437
14	37	0.15	Na+1 salt	lgK:1.6(0.07SD)	8	CIU	1437
15	40	0.1	KNO3	lgK:1.78(0.02SD)	5	MGL	3480
16	10:37	0	Pr4NBr	dH:0.91(2SF)	2	MTD	1437
17	10:37	0.1	Pr4NBr	dH:1.0(2SF)	4	MTD	1437
18	25	0.1	Inert	dH:7.5(1.SD) kJ	5	CIU	1437
19	25	0.1	KNO3	dH:3.9(0.2SD)	0	MCL	3481
20	25	0.1	NaClO4	dH:1.8(2SF)	4	MCL	1437

Reaction No. 17104							
Mg+2_5ADP-3 + Mg+2 = Mg+2(2)_5ADP-3							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:1.0 (2SF)	4	MKN	1437
2	25	0	Na+1 salt	lgK:1.7 (2SF)	4	MIS	1437
3	25	0.1	Me4N+ salt	lgK:1.0 (0.1SD)	7	CIU	1437
4	75	0	Me4NOH/m	lgK:2.10 (0.01SD)	4	MCL	7086
5	100	0	Me4NOH/m	lgK:2.29 (0.01SD)	4	MCL	7086
6	75	0	Me4NOH	dH:18.3 (0.8SD) kJ	4	MCL	7086
7	100	0	Me4NOH	dH:20.7 (0.8SD) kJ	4	MCL	7086
8	75	0	Me4NOH	Cp:97. (16.SD) J/K	4	MCL	7086
9	100	0	Me4NOH	Cp:97. (16.SD) J/K	4	MCL	7086

Reaction No. 17123




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:3.22 (3SF)	6	MGL	259
2	20	0.05	Me4NCl	lgK:1.5 (2SF)	0	MSP	931
3	25	0.1	Me4N+ salt	lgK:3.4 (0.1SD)	7	CIU	1437

Reaction No. 17124




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:1.60 (3SF)	6	MGL	259
2	25	0.1	Me4N+ salt	lgK:1.6 (0.1SD)	7	CIU	1437

Reaction No. 17125



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:1.0 (2SF)	4	MKN	1437
2	25	0.1	Me4N+ salt	lgK:1.0 (0.1SD)	7	CIU	1437

Reaction No. 17126




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.1	NaCl	lgK:3.17 (3SF)	4	MIX	1437
2	25	0.1	Me4N+ salt	lgK:3.4 (0.1SD)	7	CIU	1437
3	30	0.2	Me4NBr	lgK:3.4 (0.06SD)	4	MCL	1971
4	30	0.2	Me4NBr	dG:-4.76 (3SF)	5	EFE	1971

5	25	0.1	Inert	dH:13.4 (0.8SD) kJ	5	CIU	1437
6	30	0.2	Me4NBr	dH:3.22 (3SF)	4	MCL	1971

Reaction No. 17127							
5AMP-2 + Mg+2 = Mg+2_5AMP-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:1.75 (0.02SD)	4	MGL	3481
2	12	0.1	KNO3	lgK:1.85 (0.02SD)	5	MGL	3481
3	15	0.1	KNO3	lgK:1.80 (3SF)	5	MPT	259
4	20	0.1	KCl	lgK:1.69 (3SF)	4	MGL	280
5	23	0	NaCl	lgK:2.73 (3SF)	4	MIX	1437
6	23	0.1	Na+1 salt	lgK:2.0 (2SF)	4	MIX	1437
7	23	0.1	NaCl	lgK:1.95 (3SF)	4	MIX	1437
8	23	0.1	Unknown	lgK:2.0 (2SF)	4	MIX	999
9	25	0	Inf. Dilution	lgK:2.81 (3SF)	4	MGL	1937
10	25	0	KNO3	lgK:2.75 (3SF)	4	MGL	1437
11	25	0	Na+1 salt	lgK:2.57 (3SF)	4	MIS	1437
12	25	0	Pr4NCl	lgK:2.62 (3SF)	4	MGL	257
13	25	0.1	KCl	lgK:2.14 (3SF)	4	MGL	1437
14	25	0.1	KNO3	lgK:1.97 (0.02SD)	5	MGL	3481
15	25	0.1	Me4N+ salt	lgK:2.0 (0.1SD)	8	CIU	1437
16	25	0.1	NaClO4	lgK:2.10 (3SF)	6	MGL	1483
17	25	0.1	NaClO4	lgK:1.63 (3SF)	5	MGL	6055
18	25	0.1	NaNO3	lgK:1.57 (0.04MD)	6	MGL	2134
19	25	0.1	NaNO3	lgK:1.60 (0.02MD)	5	MGL	2906
20	25	0.2	Me4NCl	lgK:1.53 (3SF)	4	MGL	257
21	25	0.2	Me4NCl	lgK:1.69 (3SF)	6	MGL	999
22	25	0.2	NaCl	lgK:1.83 (3SF)	4	MGL	1437
23	25	0.2	Pr4NCl	lgK:1.690 (4SF)	5	MGL	257
24	30	0.01	Tris buffer	lgK:2.20 (3SF)	4	MIX	1437
25	30	0.2	Me4NCl	lgK:1.81 (3SF)	4	MCL	1437
26	37	0.15	Na+1 salt	lgK:1.9 (0.1SD)	8	CIU	1437
27	40	0.1	KNO3	lgK:2.09 (0.02SD)	4	MGL	3481
28	30	0.2	Me4NBr	dG:-2.48 (3SF)	5	EFE	1971
29	0:40	0.1	KNO3	dH:3.4 (2SF)	4	MCL	234
30	0:40	0.1	KNO3	dH:3.4 (0.2SD)	0	MCL	3481


31	25	0	Inf. Dilution	dH:11.4 (3SF) kJ	4	MCL	1937
32	25	0.1	Inert	dH:7.5 (0.8SD) kJ	5	CIU	1437
33	25	0.1	NaClO4	dH:5.71 (0.10SD) kJ	6	MCL	1483
34	30	0.2	Me4NBr	dH:1.8 (2SF)	4	MCL	1437
35	30	0.2	Me4NBr	dH:1.77 (3SF)	5	MCL	1971

Reaction No. 17137




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:1.68 (0.02SD)	4	MGL	3481
2	12	0.1	KNO3	lgK:1.78 (0.02SD)	5	MGL	3481
3	25	0.1	KCl	lgK:1.73 (3SF)	4	MGL	1437
4	25	0.1	KNO3	lgK:1.89 (0.01SD)	5	MGL	3480
5	25	0.1	KNO3	lgK:1.89 (0.02SD)	5	MGL	3481
6	25	0.1	Me4N+ salt	lgK:1.9 (0.1SD)	7	CIU	1437
7	25	0.1	NaNO3	lgK:1.49 (0.03MD)	6	MGL	6104
8	40	0.1	KNO3	lgK:2.01 (0.02SD)	4	MGL	3481
9	0:40	0.1	KNO3	dH:3.5 (0.1SD)	0	MCL	3481
10	25	0.1	Inert	dH:7.9 (2.SD) kJ	5	CIU	1437

Reaction No. 17148



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:1.71 (0.02SD)	4	MGL	3481
2	12	0.1	KNO3	lgK:1.82 (0.02SD)	5	MGL	3481
3	15	0.1	KNO3	lgK:1.75 (3SF)	6	MGL	3
4	25	0.1	KNO3	lgK:1.93 (0.02SD)	5	MGL	3481
5	25	0.1	Me4N+ salt	lgK:2.0 (0.1SD)	8	CIU	1437
6	25	0.1	NaNO3	lgK:1.53 (0.04MD)	6	MGL	6104
7	40	0.1	KNO3	lgK:2.05 (0.02SD)	4	MGL	3481
8	0:40	0.1	KNO3	dH:3.5 (0.1SD)	0	MCL	3481
9	25	0.1	Inert	dH:7.9 (2.SD) kJ	5	CIU	1437


Reaction No. 17158



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:2.0 (0.1SD)	8	CIU	1437


2	25	0.1	NaNO3	lgK:1.70 (0.02MD)	6	MGL	4460
3	25	0.2	NaCl	lgK:1.81 (3SF)	4	MGL	1437
4	30	0.2	Me4N+ salt	lgK:1.76 (0.02SD)	4	MCL	197
5	30	0.2	Me4NBr	dG:-2.43 (3SF)	5	EFE	1971
6	25	0.1	Inert	dH:7.1 (0.8SD) kJ	5	CIU	1437
7	30	0.2	Me4NBr	dH:1.72 (3SF)	4	MCL	1971

Reaction No. 17169




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:1.75 (3SF)	6	MGL	259
2	25	0.1	KNO3	lgK:1.75 (3SF)	5	MPT	1760
3	25	0.1	Me4N+ salt	lgK:1.9 (0.1SD)	8	CIU	1437
4	25	0.1	NaNO3	lgK:1.54 (0.05MD)	6	MGL	1345
5	25	0.1	NaNO3	lgK:1.51 (3SF)	5	MPT	1760
6	25	0.2	NaCl	lgK:1.81 (3SF)	4	MGL	1437

Reaction No. 17185



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.1	NaCl	lgK:2.25 (3SF)	0	MDS	1760
2	25	0.1	Me4N+ salt	lgK:1.9 (0.1SD)	6	CIU	1437
3	25	0.1	NaNO3	lgK:1.6 (0.2MD)	3	MGL	1345
4	25	0.1	NaNO3	lgK:1.48 (0.02MD)	3	MGL	6097
5	30	0.2	Me4NBr	lgK:1.70 (0.02SD)	3	MCL	1971
6	30	0.2	Me4NBr	dG:-2.34 (3SF)	3	EFE	1971
7	25	0.1	Inert	dH:7.5 (0.8SD) kJ	5	CIU	1437
8	30	0.2	Me4NBr	dH:1.82 (3SF)	4	MCL	1971

Reaction No. 17195



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:2.0 (0.1SD)	8	CIU	1437
2	25	0.1	NaNO3	lgK:1.6 (0.2MD)	3	MGL	1345
3	25	0.2	NaCl	lgK:1.76 (3SF)	4	MGL	1437

Reaction No. 17211

5GDP-3 + Mg+2 = Mg+2_5GDP-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.2	Me4NBr	lgK:3.4 (0.1SD)	6	MCL	1971
2	30	0.2	Me4NBr	dG:-4.72 (3SF)	5	EFE	1971
3	25	0.1	Inert	dH:14.2 (0.8SD) kJ	5	CIU	1437
4	30	0.2	Me4NBr	dH:3.41 (3SF)	4	MCL	1971

Reaction No. 17381							
Mg+2_MIDA-2(2) + EDTA-4 = Mg+2_EDTA-4 + 2<MIDA-2>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.8 (2SF)	1	EES	
2	25	0	Unknown	dG:-3.65 (3SF)	0	MCL	1394
3	25	0	Unknown	dH:1.31 (3SF)	2	MCL	1394

Reaction No. 17408							
PO4EtAm-2 + Mg+2 = Mg+2_PO4EtAm-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Pr4NI	lgK:2.2 (0.1SD)	3	MGL	999
2	25	0.15	KCl	lgK:1.70 (3SF)	6	MGL	999
3	25	0.2	KNO3	lgK:1.6 (0.08SD)	3	MGL	1370

Reaction No. 17409							
Mg+2 + H+1_PO4EtAm-2 = Mg+2_H+1_PO4EtAm-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Pr4NI	lgK:1.5 (0.1SD)	3	MGL	999
2	25	0.15	KCl	lgK:1.23 (3SF)	6	MGL	999
3	25	0.2	KNO3	lgK:1.2 (0.1SD)	3	MGL	1370

Reaction No. 17444							
Mg+2 + H+1_PO4MeSer-3 = Mg+2_H+1_PO4MeSer-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:1.6 (0.05SD)	3	MGL	1370

Reaction No. 17445							
Mg+2 + PO4MeSer-3 = Mg+2_PO4MeSer-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:2.4 (0.03SD)	4	MGL	1370

Reaction No. 17462							
Mg+2 + H+1_PO4Thr-3 = Mg+2_H+1_PO4Thr-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:1.6(0.07SD)	3	MGL	1370

Reaction No. 17463							
Mg+2 + PO4Thr-3 = Mg+2_PO4Thr-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:2.3(0.03SD)	4	MGL	1370

Reaction No. 17472							
Inositol126TriPhos-6 + Mg+2 = Mg+2_Inositol126TriPhos-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Bu4NBr	lgK:5.61(0.01SD)	6	MGL	963
2	37	0.2	KCl	lgK:3.91(0.02SD)	4	MGL	963

Reaction No. 17473							
H+1 + Inositol126TriPhos-6 + 2<Mg+2> = Mg+2(2)_H+1_Inositol126TriPhos-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.2(3SF)	1	ESC	
2	37	0.2	KCl	lgK:13.7(0.04SD)	4	MGL	963

Reaction No. 17474							
H+1 + Inositol126TriPhos-6 + Mg+2 = Mg+2_H+1_Inositol126TriPhos-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Bu4NBr	lgK:13.50(0.01SD)	6	MGL	963

Reaction No. 17475							
2<H+1> + Inositol126TriPhos-6 + Mg+2 = Mg+2_H+1(2)_Inositol126TriPhos-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Bu4NBr	lgK:19.4(0.05SD)	3	MGL	963

Reaction No. 17476							
Inositol126TriPhos-6 + 3<Mg+2> = Mg+2(3)_Inositol126TriPhos-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Bu4NBr	lgK:11.3(0.03SD)	4	MGL	963

Reaction No. 17758							
4NitrPhenOPO3-2 + Mg+2 = Mg+2_4NitrPhenOPO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.29 (0.03MD)	6	MGL	1345

Reaction No. 17765							
PhenOPO3-2 + Mg+2 = Mg+2_PhenOPO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.53 (0.02MD)	6	MGL	1345

Reaction No. 17772							
nBuOPO3-2 + Mg+2 = Mg+2_nBuOPO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.69 (0.02MD)	6	MGL	1345

Reaction No. 17782							
RibosePO3-2 + Mg+2 = Mg+2_RibosePO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:1.7 (2SF)	4	MGL	259
2	25	0.1	NaNO3	lgK:1.58 (0.02MD)	6	MGL	1345


Reaction No. 17792							
MeOPO3-2 + Mg+2 = Mg+2_MeOPO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:1.57 (3SF)	6	MGL	1345
2	65	0.1	Unknown	lgK:2.09 (3SF)	5	MSP	931

Reaction No. 18104							
Mg+2 + H+1_DTPA-5 = Mg+2_H+1_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:5.84 (3SF)	6	ENS	1539
2	25	0	Inf. Dilution	lgK:7.49 (3SF)	2	EAE	

Reaction No. 18248							
2<26PyridineDiCOO-2> + Mg+2 = Mg+2_26PyridineDiCOO-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:3.00 (3SF)	6	ENS	1539


2	25	0.1	Unknown	lgK:3.0 (2SF)	4	ENS	773
---	----	-----	---------	---------------	---	-----	-----

Reaction No. 18344




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.25 (3SF)	6	MGL	1456
2	25	0.1	KNO3	lgK:3.31 (0.003SD)	5	MGL	6861
3	25	0.1	Many Media	lgK:3.3 (0.1SD)	7	CIU	7242
4	25	0.1	Unknown	lgK:3.3 (0.03SD)	6	CRV	552

Reaction No. 18345




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.8 (2SF)	4	MGL	1456

Reaction No. 18419




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.8 (2SF)	1	EDH	
2	25	0.1	KNO3	lgK:1.9 (2SF)	2	MGL	2308
3	25	0.1	Unknown	lgK:2.78 (3SF)	2	MGL	999

Reaction No. 18622



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	Unknown	lgK:4.6 (0.2SD)	4	MGL	1379
2	25	0.1	NaNO3	lgK:4.6 (0.2SD)	5	CRV	13242
3	35	0.1	Unknown	lgK:4. (0.3SD)	3	MGL	1379
4	45	0.1	Unknown	lgK:4.4 (0.2SD)	4	MGL	1379
5	55	0.1	Unknown	lgK:4.1 (0.2SD)	4	MGL	1379
6	20:60	0.1	Unknown	dH:-8. (1SF)	6	CRV	552
7	25	0.1	Unknown	dH:-7.7 (2SF)	5	MCL	1379

Reaction No. 18714



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:4.3 (0.06SD)	4	MGL	1467

Reaction No. 18715							
[12]N3O:Acet*3-3 + Mg+2 = Mg+2_[12]N3O:Acet*3-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:10.25(0.006SD)	6	MGL	1467
2	25	0.1	Me4NNO3	dH:2.4(2SF)	6	MCL	1467

Reaction No. 18736							
Mg+2 + H+1_[12]N4:Acet*4-4 = Mg+2_H+1_[12]N4:Acet*4-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:3.92(0.005SD)	6	MGL	2016

Reaction No. 18737							
[12]N4:Acet*4-4 + Mg+2 = Mg+2_[12]N4:Acet*4-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:11.03(4SF)	5	MGL	2016
2	25	0.1	KCl	lgK:11.15(0.01SD)	6	MGL	2527
3	25	0.1	Me4NNO3	lgK:11.92(0.005SD)	0	MGL	2016
4	25	0.1	Me4NNO3	lgK:11.85(0.09SD)	0	CRV	13242
5	25	0.1	Me4NNO3	dH:1.89(3SF)	5	MCL	6927


Reaction No. 18862							
TriMDDA-2 + Mg+2 = Mg+2_TriMDDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:3.4(2SF)	4	MGL	1685
2	25	0.1	NaClO4	dH:10.5(3SF) kJ	5	MCL	1685

Reaction No. 18866							
EDD2P-2 + Mg+2 = Mg+2_EDD2P-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.8(0.1SD)	5	MGL	999
2	20	0.1	KNO3	lgK:2.82(0.01SD)	6	MPT	2004
3	25	0.1	NaClO4	lgK:3.2(2SF)	4	MGL	1685
4	25	0.1	NaClO4	dH:23.3(3SF) kJ	5	MCL	1685

Reaction No. 18868							
DiMeEDDA-2 + Mg+2 = Mg+2_DiMeEDDA-2							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.72 (3SF)	4	CRV	552
2	25	0.1	KNO3	lgK:5.36 (0.04SD)	6	MGL	2281
3	25	0.1	NaClO4	lgK:5.2 (2SF)	4	MGL	1685
4	25	0	Inf. Dilution	dH:1. (1SF)	4	CRV	552
5	25	0.1	NaClO4	dH:8.5 (2SF) kJ	5	MCL	1685


Reaction No. 19815



Note: Values seem somewhat inconsistent given that they imply $\text{GugC} > 1.1$; prefer to assume default ionic strength correction is OK (and, in effect, average the various lgKs)


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.43 (0.01SD)	3	MGL	931
2	25	0.03	NaCl	lgK:0.75 (2SF)	5	MIS	11516
Note (2): Emara M et al., Electrochim. Acta, 1981, 26, 1705							
3	25	0.8	NaClO4	lgK:0.28 (2SF)	5	MSL	11516
Note (3): Fedorova V et al., Zhur. Neorg. Khim., 1977, 22, 1215							
4	30	0.4	NaNO3	lgK:0.3 (0.03SD)	5	MGL	382
5	35	0	Inf. Dilution	lgK:1.39 (0.01SD)	3	MGL	931
6	25	0	Inf. Dilution/m	dH:-1.77 (3SF)	4	EOD	6366

Reaction No. 20049




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.06 (3SF)	4	MGL	140
2	25	0.15	Unknown	lgK:1.34 (3SF)	5	MGL	140

Reaction No. 20170




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.28 (3SF)	5	MHY	6833
2	25	0.1	Unknown	lgK:5.3 (0.2SD)	6	CRV	552
3	30	0.1	KCl	lgK:5.2 (2SF)	5	MGL	999
4	25	0.1	Unknown	dH:3.4 (2SF)	6	CRV	552

Reaction No. 20299




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.09 (3SF)	6	MGL	1747

Reaction No. 20300




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.05 (3SF)	6	MGL	1747

Reaction No. 20301




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.44 (3SF)	6	MGL	1747

Reaction No. 20302




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.30 (3SF)	6	MGL	1747

Reaction No. 20344




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.44 (3SF)	6	MGL	1747

Reaction No. 20345




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.18 (3SF)	6	MGL	1747

Reaction No. 20346



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.11 (3SF)	6	MGL	1747

Reaction No. 20347



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.77 (3SF)	6	MGL	1747

Reaction No. 20944							
Mg+2 + H+1_Adenine-1 = Mg+2_H+1_Adenine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:2.71 (3SF)	5	MPT	1760

Reaction No. 20982							
Cytidine + Mg+2 = Mg+2_Cytidine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaNO3	lgK:0.12 (0.04MD)	5	MGL	6115
2	35	0.1	KNO3	lgK:2.42 (3SF)	3	MGL	1187

Reaction No. 20993							
Cytosine + Mg+2 = Mg+2_Cytosine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.1 (2SF)	1	EDH	
2	30	0.1	KNO3	lgK:2.2 (2SF)	4	MGL	6864
3	35	0.1	KNO3	lgK:1.76 (3SF)	0	MPT	1183
4	45	0.1	KNO3	lgK:2.4 (0.1SD)	4	MGL	3853

Reaction No. 21001							
Mg+2 + H+1(-1)_Cytosine = Mg+2_H+1(-1)_Cytosine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:2.71 (0.01SD)	5	MPT	1760
2	45	0.1	KNO3	lgK:2.7 (0.1SD)	5	MGL	3853

Reaction No. 21314							
[9]N3:MePhosOEt*3-3 + Mg+2 = Mg+2_[9]N3:MePhosOEt*3-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:6.2 (2SF)	4	MPT	1823

Reaction No. 21322							
[9]N3:MePhos*3-6 + Mg+2 = Mg+2_[9]N3:MePhos*3-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:11.0 (3SF)	4	MGL	1823

Reaction No. 21360							
MeDiPhos-4 + Mg+2 = Mg+2_MeDiPhos-4							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.3(2SF)	0	MGL	931
2	25	0.1	KCl	lgK:6.38(3SF)	4	MGL	999
3	25	0.1	Unknown	lgK:5.51(3SF)	3	MGL	931
4	25	0.5	Me4NCl	lgK:5.78(0.10SD)	0	MGL	3083
5	25	1	Me4NBr	lgK:4.82(0.03SD)	3	MGL	4245
6	50	1	Me4NBr	lgK:5.07(3SF)	4	MGL	4245

Reaction No. 21361							
Mg+2 + H+1_MeDiPhos-4 = Mg+2_H+1_MeDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.02(3SF)	5	MGL	931
2	25	0.1	Unknown	lgK:2.76(3SF)	4	MGL	931
3	25	0.5	Me4NCl	lgK:2.92(0.05SD)	4	MGL	3083
4	25	1	Me4NBr	lgK:3.0(0.05SD)	4	MGL	4245
5	50	1	Me4NBr	lgK:3.33(3SF)	5	MGL	4245

Reaction No. 21362							
Mg+2_MeDiPhos-4 + Mg+2 = Mg+2(2)_MeDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:2.60(3SF)	6	MGL	999

Reaction No. 21382							
Glyceric-1 + Mg+2 = Mg+2_Glyceric-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:0.86(2SF)	5	MHY	4920

Reaction No. 21500							
SulfCat-3 + Mg+2 = Mg+2_SulfCat-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:6.27(3SF)	6	MGL	999

Reaction No. 21501							
Mg+2_SulfCat-3 + SulfCat-3 = Mg+2_SulfCat-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:4.14(3SF)	6	MGL	999

Reaction No. 21589							
DTPMP-9 + Mg+2 = Mg+2_DTPMP-9							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.40 (4SF)	2	EDH	29755
2	25	0.1	KCl	lgK:6.40 (3SF)	0	MGL	999
3	25	0.127	NaCl	lgK:9.44 (0.23SD)	4	MGL	29755
4	25	0.319	NaCl	lgK:8.81 (0.19SD)	4	MGL	29755
5	25	0.958	NaCl	lgK:8.80 (0.32SD)	4	MGL	29755

Reaction No. 21590							
Mg+2 + H+1_DTPMP-9 = Mg+2_H+1_DTPMP-9							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.04 (4SF)	2	EDH	29755
2	25	0.1	KCl	lgK:5.40 (3SF)	0	MGL	999
3	25	0.127	NaCl	lgK:7.99 (0.15SD)	4	MGL	29755
4	25	0.319	NaCl	lgK:7.50 (0.12SD)	4	MGL	29755
5	25	0.958	NaCl	lgK:7.45 (0.24SD)	4	MGL	29755

Reaction No. 21591							
Mg+2 + H+1(2)_DTPMP-9 = Mg+2_H+1(2)_DTPMP-9							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.96 (3SF)	2	EDH	29755
2	25	0.1	KCl	lgK:4.70 (3SF)	0	MGL	999
3	25	0.127	NaCl	lgK:5.91 (0.14SD)	4	MGL	29755
4	25	0.319	NaCl	lgK:5.29 (0.13SD)	4	MGL	29755
5	25	0.958	NaCl	lgK:5.15 (0.021SD)	4	MGL	29755

Reaction No. 21592							
Mg+2 + H+1(3)_DTPMP-9 = Mg+2_H+1(3)_DTPMP-9							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.17 (3SF)	2	EDH	29755
2	25	0.1	KCl	lgK:3.94 (3SF)	0	MGL	999
3	25	0.127	NaCl	lgK:4.71 (0.13SD)	4	MGL	29755
4	25	0.319	NaCl	lgK:4.19 (0.12SD)	4	MGL	29755
5	25	0.958	NaCl	lgK:3.90 (0.19SD)	4	MGL	29755

Reaction No. 21593							
--------------------	--	--	--	--	--	--	--

Mg+2 + H+1(4)_DTPMP-9 = Mg+2_H+1(4)_DTPMP-9							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.67(3SF)	2	EDH	29755
2	25	0.1	KCl	lgK:3.13(3SF)	0	MGL	999
3	25	0.127	NaCl	lgK:3.75(0.13SD)	4	MGL	29755
4	25	0.319	NaCl	lgK:3.29(0.11SD)	4	MGL	29755
5	25	0.958	NaCl	lgK:2.91(0.15SD)	4	MGL	29755

Reaction No. 21594							
Mg+2 + H+1(5)_DTPMP-9 = Mg+2_H+1(5)_DTPMP-9							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.47(3SF)	2	EDH	29755
2	25	0.1	KCl	lgK:2.36(3SF)	0	MGL	999
3	25	0.127	NaCl	lgK:2.71(0.22SD)	4	MGL	29755
4	25	0.319	NaCl	lgK:2.47(0.18SD)	4	MGL	29755
5	25	0.958	NaCl	lgK:2.35(0.17SD)	4	MGL	29755

Reaction No. 21628							
ClMePhos-2 + Mg+2 = Mg+2_ClMePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.62(3SF)w	5	MPH	906


Reaction No. 21645							
AmMePhos-2 + Mg+2 = Mg+2_AmMePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.04(3SF)	6	MGL	999
2	25	0.1	KNO3	lgK:2.03(0.03MD)	6	MGL	2408
3	25	0.1	Many Media	lgK:1.99(0.05SD)	7	CIU	7242
4	25	0.1	NaNO3	lgK:1.94(0.06MD)w	5	MPH	4478

Reaction No. 21816							
Mg+2 + SalAld-1 + Gly-1 = Mg+2_Gly-1_SalAld-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KCl	lgK:4.77(3SF)	6	MGL	183

Reaction No. 21852							
Et11DiPhos-4 + Mg+2 = Mg+2_Et11DiPhos-4							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NC1	lgK:6.26(0.12SD)	4	MGL	3083

Reaction No. 21853




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NC1	lgK:2.99(0.07SD)	4	MGL	3083

Reaction No. 21876




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:2.17(3SF)	5	MGL	154

Reaction No. 21877




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:1.23(3SF)	5	MGL	154

Reaction No. 21997




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NBr	lgK:2.85(3SF)	4	MGL	4245

Reaction No. 21998




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NBr	lgK:2.67(3SF)	4	MGL	4245

Reaction No. 22102



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NC1	lgK:1.3(2SF)	4	MGL	1572
2	25		DMF	lgK:2.4(0.06SD)	4	MPS	3910
3	25		DMSO	lgK:2.1(0.07SD)	4	MPS	3910
4	25		Methanol	lgK:3.4(0.06SD)	4	MPS	3910

Reaction No. 22104



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	KCl	lgK:2.0 (2SF)	3	MGL	3283
2	25	0.1	Me4NCl	lgK:1.7 (2SF)	4	MGL	1572
3	25	0.01	Water:Methanol 5:95Vol KCl	lgK:2.0 (2SF)	3	MGL	3283

Reaction No. 22294							
DHAP-2 + Mg+2 = Mg+2_DHAP-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.6 (0.03SD)	4	MGL	1744

Reaction No. 22306							
1GlycerolOPO3-2 + Mg+2 = Mg+2_1GlycerolOPO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.6 (0.03SD)	4	MGL	1744

Reaction No. 22322							
Mg+2_[9]N3:MePhos*3-6 + H+1 = Mg+2_H+1_[9]N3:MePhos*3-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:5.4 (2SF)	4	ENS	1823

Reaction No. 22331							
HPEDDA-4 + Mg+2 = Mg+2_HPEDDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:14. (0.4SD)	4	MGL	1783


Reaction No. 23267							
EBDP-4 + Mg+2 = Mg+2_EBDP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:6.4 (0.03SD)	4	MGL	1902

Reaction No. 23553							
Mg+2_5ADP-3 + Oxine-1 = Mg+2_Oxine-1_5ADP-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.3	Unknown	lgK:3.72 (3SF)	6	MKN	999

Reaction No. 23554							
Mg+2_5ATP-4 + Oxine-1 = Mg+2_Oxine-1_5ATP-4							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.3	Unknown	lgK:3.70 (3SF)	6	MKN	999

Reaction No. 23578




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.1 (0.04SD)	4	MGL	999

Reaction No. 23619




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.80 (3SF)	6	MGL	999
2	28	0.1	KNO3	lgK:3.25 (3SF)	6	MGL	999

Reaction No. 23620




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.1 (2SF)	1	ELC	
2	28	0.1	KNO3	lgK:3.95 (3SF)	0	MGL	999

Reaction No. 23621



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.20 (3SF)	6	MGL	999

Reaction No. 23671



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:2.2 (0.05SD)	5	MGL	2194
2	20	0.01	Unknown	lgK:3.0 (2SF)	4	MGL	999
3	25	0.1	KNO3	lgK:2.3 (0.05SD)	5	MGL	2194
4	35	0.1	KNO3	lgK:2.4 (0.05SD)	5	MGL	2194
5	45	0.1	KNO3	lgK:2.5 (0.05SD)	5	MGL	2194
6	15:45	0.1	KNO3	dH:17. (1.SD) kJ	5	MCL	2194
7	21		DMSO	lgK:1.63 (3SF)	4	MMR	906

Reaction No. 23828

5AQP-5 + Mg+2 = Mg+2_5AQP-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.22 (3SF)	4	MGL	1437

Reaction No. 23829							
Mg+2 + H+1_5AQP-5 = Mg+2_H+1_5AQP-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.7 (2SF)	4	MGL	1437

Reaction No. 23830							
Mg+2_5AQP-5 + H+1 = Mg+2_H+1_5AQP-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.3 (2SF)	4	MGL	999

Reaction No. 23986							
TetMDTA-4 + Mg+2 = Mg+2_TetMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:6.22 (3SF)	6	MGL	1956
2	20	0.1	KNO3	lgK:6.23 (3SF) w	6	MPH	2043
3	25	0.1	Unknown	lgK:6.33 (3SF)	6	CRV	552
4	20	0.1	KNO3	dH:8.5 (2SF)	5	MCL	1956


Reaction No. 23987							
Mg+2 + H+1_TetMDTA-4 = Mg+2_H+1_TetMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.44 (3SF)	6	MGL	1957
2	20	0.1	KNO3	lgK:3.50 (3SF)	6	MGL	1956

Reaction No. 24025							
Mg+2 + H+1_EEDTA-4 = Mg+2_H+1_EEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.75 (3SF)	6	MGL	1957
2	20	0.1	KNO3	lgK:3.8 (2SF)	4	MGL	1956

Reaction No. 24079							
TEDTA-4 + Mg+2 = Mg+2_TEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	20	0.1	KCl	lgK:4.61 (3SF)	6	MGL	999
2	20	0.1	KNO3	lgK:4.61 (3SF)	6	MGL	1956
3	20	0.1	KNO3	dH:4.13 (3SF)	5	MCL	1956

Reaction No. 24080




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.20 (3SF)	6	MGL	999
2	20	0.1	KNO3	lgK:3.2 (2SF)	4	MGL	1956

Reaction No. 24150




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KCl	lgK:7.1 (2SF)	4	MGL	999

Reaction No. 24151




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KCl	lgK:2.6 (2SF)	4	MGL	999

Reaction No. 24181




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KCl	lgK:1.8 (2SF)	4	MGL	999

Reaction No. 24268



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.8 (2SF)	4	MGL	1956

Reaction No. 24269



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.66 (3SF)	6	MGL	1956
2	25	3	NaClO4	lgK:1.41 (3SF)	4	MEF	6147
3	25	3	NaClO4	lgK:1.33 (3SF)	4	MGL	9919

Reaction No. 24303

HBED-4 + Mg+2 = Mg+2_HBED-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:10.51(4SF)	6	MGL	1941

Reaction No. 24304							
Mg+2 + H+1_HBED-4 = Mg+2_H+1_HBED-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:6.20(3SF)	6	MGL	1941

Reaction No. 24305							
Mg+2 + H+1(2)_HBED-4 = Mg+2_H+1(2)_HBED-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.21(3SF)	6	MGL	1941
2	25	0.1	KNO3	dH:2.32(3SF)	5	MCL	1941

Reaction No. 24330							
PentMDTA-4 + Mg+2 = Mg+2_PentMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.2(2SF)	4	MGL	1956

Reaction No. 24331							
Mg+2 + H+1_PentMDTA-4 = Mg+2_H+1_PentMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.6(2SF)	4	MGL	1957
2	20	0.1	KNO3	lgK:3.6(2SF)	4	MGL	1956

Reaction No. 24373							
2<IDA-2> + Mg+2 = Mg+2_IDA-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.3(2SF)	3	MGL	1956
2	25	0.1	Unknown	lgK:4.85(3SF)	6	CRV	552

Reaction No. 24405							
Chelidam-3 + Mg+2 = Mg+2_Chelidam-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:3.7(2SF)	4	MGL	1982

Reaction No. 24406							
--------------------	--	--	--	--	--	--	--

Mg+2_Chelidam-3 + H+1 = Mg+2_H+1_Chelidam-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:8.09(3SF)	6	MGL	1982

Reaction No. 24609							
Nalidixic-1 + Mg+2 = Mg+2_Nalidixic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:3.05(0.02SD)	4	MPT	2099

Reaction No. 24610							
2<Nalidixic-1> + Mg+2 = Mg+2_Nalidixic-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:6.0(0.03SD)	4	MPT	2099

Reaction No. 24611							
Nalidixic-1 + Mg+2 = H+1 + Mg+2_H+1(-1)_Nalidixic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:-4.6(0.03SD)	4	MPT	2099

Reaction No. 24770							
AcoxAcet-1 + Mg+2 = Mg+2_AcoxAcet-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.4	NaNO3	lgK:0.3(0.04SD)	6	MGL	382


Reaction No. 24840							
Glycolic-1 + Mg+2 = Mg+2_Glycolic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.2	KCl	lgK:0.92(2SF)	5	MHY	4920
2	25	0	Inf. Dilution	lgK:1.3(2SF)	4	ENS	2152
3	25	0.5	NaClO4	lgK:1.03(0.02MD)	6	MGL	4896

Reaction No. 24847							
H+1 + Malonic-2 + Mg+2 = Mg+2_H+1_Malonic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.1(2SF)	4	ENS	2152

Reaction No. 24856							
Mg+2 + Ca+2 + Tetracycline-2 = Ca+2_Mg+2_Tetracycline-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:8.5 (0.05SD)	4	MGL	2160

Reaction No. 24857




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:8.31 (0.02SD)	6	MGL	2160

Reaction No. 24858




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:16.6 (0.03SD)	4	MGL	2160

Reaction No. 24861




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:5.89 (3SF)	6	MGL	2160

Reaction No. 24862




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:13.09 (4SF)	6	MGL	2160

Reaction No. 24863




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:15.82 (4SF)	6	MGL	2160

Reaction No. 24911



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:23.59 (0.02SD)	6	MGL	2170

Reaction No. 24912



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:15.4 (0.1SD)	4	MGL	2170

Reaction No. 24913							
H+1 + Demeclocycline-2 + Mg+2 = Mg+2_H+1_Demeclocycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:11.85(0.01SD)	4	MGL	2170

Reaction No. 24914							
Demeclocycline-2 + 2<Mg+2> = Mg+2(2)_Demeclocycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:7.6(0.04SD)	4	MGL	2170

Reaction No. 24915							
2<H+1> + 2<Minocycline-2> + Mg+2 = Mg+2_H+1(2)_Minocycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:26.73(0.02SD)	4	MGL	2155

Reaction No. 24916							
H+1 + 2<Minocycline-2> + Mg+2 = Mg+2_H+1_Minocycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:17.9(0.07SD)	4	MGL	2155

Reaction No. 24917							
2<H+1> + Minocycline-2 + Mg+2 = Mg+2_H+1(2)_Minocycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:18.4(0.04SD)	4	MGL	2155

Reaction No. 24918							
3<H+1> + 2<Minocycline-2> + Mg+2 = Mg+2_H+1(3)_Minocycline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:32.3(0.03SD)	4	MGL	2155

Reaction No. 24926							
2<H+1> + Glu-2 + Mg+2 = Mg+2_H+1(2)_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.16(4SF)	2	MGL	6131
2	37	0.15	NaCl	lgK:14.53(0.11SD)	2	MGL	28777
3	37	0.15	NaCl	lgK:15.00(0.10SD)	3	MIS	28777
4	37	0.15	NaClO4	lgK:14.9(0.02SD)	3	MGL	2181

5	25	0	Inf. Dilution	dH:-39.(2SF)kJ	3	MCL	6131
---	----	---	---------------	----------------	---	-----	------

Reaction No. 24927							
2<Glu-2> + Mg+2 = H+1 + Mg+2_H+1(-1)_Glu-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-6.0(2SF)	1	EAE	
2	37	0.15	NaCl	lgK:-7.13(0.15SD)	1	MGL	28777
3	37	0.15	NaClO4	lgK:-6.1(0.02SD)	1	MGL	2181

Reaction No. 24928							
2<H+1> + Asp-2 + Mg+2 = Mg+2_H+1(2)_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.02(4SF)	1	MGL	6131
2	37	0.15	NaCl	lgK:14.45(0.15SD)	3	MGL	28777
3	37	0.15	NaCl	lgK:14.56(0.03SD)	3	MIS	28777
4	37	0.15	NaClO4	lgK:14.1(0.04SD)	2	MGL	2181
5	25	0	Inf. Dilution	dH:-40.(2SF)kJ	3	MCL	6131


Reaction No. 24929							
Asp-2 + Mg+2 = H+1 + Mg+2_H+1(-1)_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-8.2(2SF)	2	ESC	
2	37	0.15	NaCl	lgK:-8.36(0.13SD)	3	MGL	28777
3	37	0.15	NaCl	lgK:-8.81(0.12SD)	3	MIS	28777
4	37	0.15	NaClO4	lgK:-8.7(0.02SD)	3	MGL	2181

Reaction No. 24930							
Asp-2 + 2<Mg+2> = Mg+2(2)_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.36(3SF)	2	EAE	
2	37	0.15	NaCl	lgK:4.40(0.31SD)	4	MGL	28777
3	37	0.15	NaClO4	lgK:4.4(0.05SD)	4	MGL	2181

Reaction No. 24931							
Gly-1 + Mg+2 + H2O = H+1 + Mg+2_Gly-1_OH-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-8.22(3SF)	2	EAE	


2	37	0.15	NaClO4	lgK:-8.7(0.04SD)	6	MGL	2181
---	----	------	--------	------------------	---	-----	------

Reaction No. 24933




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1(3SF)	2	EAE	
2	37	0.15	NaClO4	lgK:10.4(0.07SD)	6	MGL	2181

Reaction No. 24934




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-12.0(3SF)	1	ESC	
2	37	0.15	NaCl	lgK:-12.86(0.14SD)	3	MGL	28777
3	37	0.15	NaClO4	lgK:-12.6(0.03SD)	4	MGL	2181

Reaction No. 24935




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-18.2(3SF)	2	EAE	
2	37	0.15	NaCl	lgK:-18.64(0.17SD)	3	MGL	28777
3	37	0.15	NaClO4	lgK:-18.47(0.02SD)	4	MGL	2181

Reaction No. 25132




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:2.91(0.006SD)	6	MGL	2182

Reaction No. 25146



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:5.87(0.01SD)	6	MGL	2182

Reaction No. 25199



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.3(0.1SD)	6	MGL	2281

Reaction No. 25277

2<Guanosine-1> + Mg+2 = Mg+2_Guanosine-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:3.62(3SF)	5	MGL	2194
2	25	0.1	KNO3	lgK:3.71(3SF)	5	MGL	2194
3	35	0.1	KNO3	lgK:3.80(3SF)	5	MGL	2194
4	45	0.1	KNO3	lgK:3.87(3SF)	5	MGL	2194
5	15:45	0.1	KNO3	dH:14.7(1.SD)kJ	5	MCL	2194

Reaction No. 25285							
Guanosine-1 + Mg+2 + Bipy = Mg+2_Bipy_Guanosine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:5.9(0.07SD)	6	MGL	2194
2	25	0.1	KNO3	lgK:6.0(0.07SD)	6	MGL	2194
3	35	0.1	KNO3	lgK:6.0(0.07SD)	6	MGL	2194
4	45	0.1	KNO3	lgK:6.1(0.07SD)	6	MGL	2194
5	15:45	0.1	KNO3	dH:13.(1.SD)kJ	5	MCL	2194


Reaction No. 25292							
Guanosine-1 + Mg+2 + Phenanth = Mg+2_Phenanth_Guanosine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:5.5(0.07SD)	6	MGL	2194
2	25	0.1	KNO3	lgK:5.6(0.07SD)	6	MGL	2194
3	35	0.1	KNO3	lgK:5.7(0.07SD)	6	MGL	2194
4	45	0.1	KNO3	lgK:5.7(0.07SD)	6	MGL	2194
5	25	0.1	KNO3	dH:13.(1.SD)kJ	5	MTD	2194

Reaction No. 25299							
Guanosine-1 + Mg+2 + SulfSal-3 = Mg+2_Guanosine-1_SulfSal-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:2.2(0.07SD)	6	MGL	2194
2	25	0.1	KNO3	lgK:2.2(0.07SD)	6	MGL	2194
3	35	0.1	KNO3	lgK:2.3(0.07SD)	6	MGL	2194
4	45	0.1	KNO3	lgK:2.4(0.07SD)	6	MGL	2194
5	25	0.1	KNO3	dH:14.(1.SD)kJ	5	MTD	2194

Reaction No. 25327							
Mg+2_H+1(-1)_Arg-1 + H+1 = Mg+2_Arg-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:11.22 (4SF)	5	ENS	2350

Reaction No. 25554




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.90 (0.01SD)	5	MGL	999
2	20	0.1	NaNO3	lgK:3.98 (0.05MD)	5	MPT	6937
3	20	0.1	NaNO3	dH:3.8 (0.1MD)	5	MCL	6937

Reaction No. 25576




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.91 (3SF)	5	MHY	6833

Reaction No. 25625




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.36 (3SF)	6	MGL	1979

Reaction No. 25638




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.36 (3SF)	6	MGL	1979

Reaction No. 25651



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.24 (3SF)	6	MGL	1979

Reaction No. 25662



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.84 (0.02SD)	3	MGL	2591
2	20	0.1	KNO3	lgK:5.83 (3SF)	3	MGL	1979
3	25	0.05	NaCl	lgK:6.45 (0.19SD)	1	MGL	29125
4	25	0.15	NaCl	lgK:5.61 (0.17SD)	3	MGL	29125

5	25	0.5	NaCl	lgK:5.54 (0.14SD)	3	MGL	29125
6	25	1	NaCl	lgK:5.36 (0.24SD)	3	MGL	29125
7	25	0.151	Unknown	dH:15.1 (0.2SD) kJ	3	MCL	29125
8	25	0.503	Unknown	dH:11.9 (0.2SD) kJ	3	MCL	29125
9	25	0.992	Unknown	dH:10.4 (0.2SD) kJ	3	MCL	29125

Reaction No. 25774							
DiClMeDiPhos-4 + Mg+2 = Mg+2_DiClMeDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NC1	lgK:6.20 (0.01SD)	6	MGL	2209
2	25	0.1	Me4NC1	dG:-8.45 (0.02SD)	6	MGL	2209
3	25	0.1	Me4NC1	dH:3. (0.5SD)	6	MCL	2209
4	25	0.1	Me4NC1	dS:38.7 (0.2SD)	6	EFE	2209

Reaction No. 25775							
Mg+2 + H+1_DiClMeDiPhos-4 = Mg+2_H+1_DiClMeDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NC1	lgK:3.15 (0.01SD)	6	MGL	2209
2	25	0.1	Me4NC1	dG:-4.29 (0.02SD)	6	MGL	2209
3	25	0.1	Me4NC1	dH:2. (0.3SD)	5	MCL	2209
4	25	0.1	Me4NC1	dS:21.7 (0.1SD)	5	EFE	2209

Reaction No. 25776							
2<Mg+2> + DiClMeDiPhos-4 = Mg+2(2)_DiClMeDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NC1	lgK:8.74 (3SF)	3	MGL	2209

Reaction No. 25797							
N23DiOHPrIDA-2 + Mg+2 = Mg+2_N23DiOHPrIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.0 (0.06SD)	6	MGL	1996

Reaction No. 25955							
Mg+2 + H+1_NPhosMeIDA-4 = Mg+2_H+1_NPhosMeIDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.96 (3SF)	6	MHY	140
2	20	0.1	KNO3	lgK:2.1 (2SF)	6	MEP	2009

Reaction No. 25971							
[13]N4:Acet*4-4 + Mg+2 = Mg+2_[13]N4:Acet*4-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:6.36(3SF)	0	MGL	2016
2	25	0.1	K+1 salt	lgK:8.(0.3SD)	6	CRV	552
3	25	0.1	KCl	lgK:8.18(0.01SD)	6	MGL	2527
4	25	0.1	KNO3	lgK:7.62(0.004SD)	0	MGL	2016

Reaction No. 25972							
Mg+2 + H+1_[13]N4:Acet*4-4 = Mg+2_H+1_[13]N4:Acet*4-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.0(2SF)	1	ELC	
2	25	0.1	KNO3	lgK:2.78(0.005SD)	0	MGL	2016

Reaction No. 25995							
[14]N4:Acet*4-4 + Mg+2 = Mg+2_[14]N4:Acet*4-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.02(3SF)	0	MGL	2016
2	25	0.1	K+1 salt	lgK:2.80(0.01SD)	1	CRV	552
3	25	0.1	KCl	lgK:3.01(0.01SD)	0	MGL	2527
4	25	0.1	KNO3	lgK:1.967(0.001SD)	2	MGL	2016


Reaction No. 25996							
Mg+2 + H+1_[14]N4:Acet*4-4 = Mg+2_H+1_[14]N4:Acet*4-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.74(0.005SD)	6	MGL	2016

Reaction No. 26206							
H+1 + 5ADP-3 + Mg+2 = Mg+2_H+1_5ADP-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:8.31(3SF)	6	MGL	1483
2	25	0.1	NaClO4	dH:-10.01(0.20SD)kJ	6	MCL	1483

Reaction No. 26212							
Uracil-1 + Mg+2 = Mg+2_Uracil-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	45	0.1	KNO3	lgK:2.6(0.1SD)	5	MGL	2326
---	----	-----	------	----------------	---	-----	------

Reaction No. 26219




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.96(3SF)	5	MPT	1760
2	45	0.1	KNO3	lgK:2.8(0.1SD)	5	MGL	2326

Reaction No. 26358




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:7.93(3SF)w	6	MPH	2043

Reaction No. 26453




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.39(3SF)	3	MGL	1599

Reaction No. 27037




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:7.39(3SF)	5	MGL	999

Reaction No. 27038



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.46(3SF)	5	MGL	999

Reaction No. 27064



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.6(0.1SD)	4	MGL	6845
2	25	0	Inf. Dilution	lgK:7.43(3SF)	4	MPS	7000

Reaction No. 27065



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.0(0.1SD)	4	MGL	6845

Reaction No. 27169							
Mg+2 + H+1_Cytosine = Mg+2_H+1_Cytosine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:2.0(0.1SD)	5	MGL	1892

Reaction No. 27170							
Mg+2_H+1_Cytosine + H+1_Cytosine = Mg+2_H+1(2)_Cytosine(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:3.5(0.08SD)	5	MGL	1892

Reaction No. 27180							
Mg+2_H+1_Cytosine + H+1_SulfSal-3 = Mg+2_H+1(2)_Cytosine_SulfSal-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.4(2SF)	1	ESC	
2	45	0.1	KNO3	lgK:2.4(0.2SD)	5	MGL	1892

Reaction No. 27185							
Mg+2_Cytosine + H+1_Bipy = Mg+2_H+1_Bipy_Cytosine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:6.(0.2SD)	5	MGL	1892

Reaction No. 27292							
Mg+2_CPDTA-4 + H+1 = Mg+2_H+1_CPDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:5.36(3SF)	6	CRV	552

Reaction No. 27294							
Mg+2 + H+1_CPDTA-4 = Mg+2_H+1_CPDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.32(3SF)	4	MGL	140

Reaction No. 27329							
4AmPyrid26DiCOO-2 + Mg+2 = Mg+2_4AmPyrid26DiCOO-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:2.91(3SF)	6	MGL	2041
2	22	0.1	NaClO4	lgK:2.88(3SF)	5	MGL	999

Reaction No. 27458							
PhosAcet-3 + Mg+2 = Mg+2_PhosAcet-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.58(0.09SD)	4	MPT	6298
2	25	0.05	Unknown	lgK:4.50(0.02SD)	5	MCT	6298
3	37	0.15	KNO3	lgK:3.90(3SF)	6	MGL	2141
4	25	0	Inf. Dilution	dH:3.0(0.7SD)	5	MCL	6298

Reaction No. 27459							
Mg+2_PhosAcet-3 + PhosAcet-3 = Mg+2_PhosAcet-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:1.3(0.1SD)	6	MGL	2141

Reaction No. 27460							
Mg+2 + H+1_PhosAcet-3 = Mg+2_H+1_PhosAcet-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.(0.3SD)	4	ENS	3882
2	25	0.05	Unknown	lgK:2.56(0.05SD)	5	MCT	6298
3	37	0.15	KNO3	lgK:1.84(0.05SD)	6	MGL	2141


Reaction No. 27523							
Suberic-2 + Mg+2 = Mg+2_Suberic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.10(3SF)	3	MGL	1716

Reaction No. 27525							
Phthalic-2 + Mg+2 = Mg+2_Phthalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.5(0.2SD)	5	MGL	1716
2	25	0.1	NaCl	lgK:2.53(3SF)	5	MGL	11516
Note (2): Skorik N et al., Zhur. Neorg. Khim., 1989, 34, 2276							
3	25	0.493	Unknown	lgK:2.51(3SF)	5	MGL	11516
Note (3): Parthasarathy S et al., Electrochim. Acta, 1975, 20, 611							

Reaction No. 27526							
TPhth-2 + Mg+2 = Mg+2_TPhth-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:2. (0.6SD)	5	MGL	1716
---	----	---	---------------	----------------	---	-----	------

Reaction No. 27552




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.2 (0.06SD)	6	MGL	3147
2	25	0.1	NaNO3	lgK:0.6 (1SF)	0	MGL	6105
3	35	0.1	KNO3	lgK:2.2 (0.06SD)	4	MGL	2371
4	45	0.1	KNO3	lgK:2.4 (0.06SD)	6	MGL	1884
5	25	0.1	KNO3	dG:-3.0 (0.06SD)	6	MGL	1884
6	25	0.1	KNO3	dH:4. (1.SD)	6	MCL	1884
7	25	0.1	KNO3	dS:20. (3.SD)	6	EFE	1884

Reaction No. 27595




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:11.35 (4SF)	5	MGL	906
2	25	0.1	KNO3	lgK:11.38 (0.02MD)	6	ENS	2408
3	25	0.1	Unknown	lgK:11.4 (0.1SD)	6	CIU	7242

Reaction No. 27611




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:12.5 (0.07MD)	6	MGL	2408

Reaction No. 27612



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.1 (0.07MD)	6	MGL	2408
2	25	0.2	KNO3	lgK:2.24 (0.01SD)	5	MGL	6868

Reaction No. 27635



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:12.57 (0.05MD)	6	MGL	2408

Reaction No. 27636

3AmPrPhos-2 + Mg+2 = Mg+2_3AmPrPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.0(0.08MD)	6	MGL	2408

Reaction No. 27642							
H+1 + 1AmEtPhos-2 + Mg+2 = Mg+2_H+1_1AmEtPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:11.54(0.06MD)	6	MGL	2408

Reaction No. 27643							
1AmEtPhos-2 + Mg+2 = Mg+2_1AmEtPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.0(0.08MD)	6	MGL	2408
2	25	0.2	KNO3	lgK:1.84(0.02SD)	5	MGL	6868

Reaction No. 27647							
H+1 + 1Am2MePrPhos-2 + Mg+2 = Mg+2_H+1_1Am2MePrPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:11.73(0.06MD)	6	MGL	2408

Reaction No. 27648							
1Am2MePrPhos-2 + Mg+2 = Mg+2_1Am2MePrPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	24	0.1	KNO3	lgK:3.68(3SF)	0	MGL	2261
2	25	0.1	KNO3	lgK:2.15(0.05MD)	6	MGL	2408


Reaction No. 27652							
H+1 + 1AmPentPhos-2 + Mg+2 = Mg+2_H+1_1AmPentPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:11.6(0.07MD)	6	MGL	2408

Reaction No. 27653							
1AmPentPhos-2 + Mg+2 = Mg+2_1AmPentPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.03(0.05MD)	6	MGL	2408

Reaction No. 27657							
H+1 + 2Am2PrPhos-2 + Mg+2 = Mg+2_H+1_2Am2PrPhos-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:11.6(0.07MD)	6	MGL	2408

Reaction No. 27658




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.01(0.06MD)	6	MGL	2408

Reaction No. 27726




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:11.44(4SF)	3	MGL	1187

Reaction No. 27729




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7(3SF)	1	ESC	
2	35	0.1	KNO3	lgK:11.48(4SF)	3	MGL	1187

Reaction No. 27732




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:11.78(4SF)	3	MGL	1187

Reaction No. 27743




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.1(2SF)	1	ESC	
2	35	0.1	KNO3	lgK:8.81(3SF)	3	MGL	1187

Reaction No. 27745




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.1(2SF)	1	ELC	
2	35	0.1	KNO3	lgK:3.35(3SF)	0	MGL	1187

Reaction No. 27749




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.1 (2SF)	1	ESC	
2	35	0.1	KNO3	lgK:8.90 (3SF)	0	MGL	1187

Reaction No. 27750




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.7 (2SF)	1	ESC	
2	35	0.1	KNO3	lgK:2.58 (3SF)	5	MGL	1187

Reaction No. 27758




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:2.44 (3SF)	0	MGL	1187

Reaction No. 27762




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:8.48 (3SF)	5	MGL	1187

Reaction No. 27763




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:2.96 (3SF)	5	MGL	1187

Reaction No. 27887




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:8.29 (3SF)	5	MPT	1183

Reaction No. 27893



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:3.30 (3SF)	5	MPT	1183


Reaction No. 27901



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:8.4 (2SF)	1	ESC	
2	35	0.1	KNO3	lgK:8.07 (3SF)	5	MPT	1183

Reaction No. 27904




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:6.91 (3SF)	5	MPT	1183

Reaction No. 27907



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:3.06 (3SF)	5	MPT	1183

Reaction No. 28225




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:6.51 (3SF)	0	CRV	552
2	25	0.1	KCl	lgK:8.1 (0.03SD)	6	MGL	2527

Reaction No. 28451




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	2	NH4NO3	lgK:-0.95 (2SF)	4	MGL	5646
2	25	0	Inf. Dilution	lgK:-0.95 (3SF)	2	EAE	

Reaction No. 28492




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KCl	lgK:6.9 (2SF)	6	MGL	6500

Reaction No. 28644



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:7.49 (3SF)	5	CRV	2556

Reaction No. 28645



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0.1	K+1 salt	lgK:10.15 (4SF)	5	CRV	2556
---	----	-----	----------	-----------------	---	-----	------

Reaction No. 28646							
Mg+2_H+1_2HMDTMP-8 + H+1 = Mg+2_H+1(2)_2HMDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:9.47 (3SF)	5	CRV	2556

Reaction No. 28647							
Mg+2_H+1(2)_2HMDTMP-8 + H+1 = Mg+2_H+1(3)_2HMDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:8.03 (3SF)	5	CRV	2556

Reaction No. 28648							
Mg+2_H+1(3)_2HMDTMP-8 + H+1 = Mg+2_H+1(4)_2HMDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:6.46 (3SF)	5	CRV	2556

Reaction No. 28649							
Mg+2_H+1(4)_2HMDTMP-8 + H+1 = Mg+2_H+1(5)_2HMDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:4.4 (2SF)	4	CRV	2556

Reaction No. 28671							
Mg+2_DTPMP-9 + H+1 = Mg+2_H+1_DTPMP-9							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:11.04 (4SF)	5	CRV	2556

Reaction No. 28701							
EDTPI-4 + Mg+2 = Mg+2_EDTPI-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.94 (3SF)	5	MGL	5653

Reaction No. 28853							
4MePhen1Bu13Dione-1 + Mg+2 = Mg+2_4MePhen1Bu13Dione-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20		Dioxan:Water 3:1Vol	lgK:9.50 (3SF)	5	MGL	2261

Reaction No. 28854							
2<4MePhen1Bu13Dione-1> + Mg+2 = Mg+2_4MePhen1Bu13Dione-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20		Dioxan:Water 3:1Vol	lgK:15.91(4SF)	5	MGL	2261

Reaction No. 28902							
2BenzNTA-3 + Mg+2 = Mg+2_2BenzNTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:5.44(3SF)	6	CRV	2556

Reaction No. 28969							
Mg+2 + H+1_MetNNDiAcet-3 = Mg+2_H+1_MetNNDiAcet-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Na+1 salt	lgK:1.48(3SF)	6	CRV	2556

Reaction No. 28999							
2AmPr13DioicN2Bu14Dioic-4 + Mg+2 = Mg+2_2AmPr13DioicN2Bu14Dioic-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.03(3SF)	5	MGL	2261

Reaction No. 29093							
Mg+2 + Xanthosine-1 + H+1_TMEDA = Mg+2_H+1_TMEDA_Xanthosine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:5.3(0.06SD)	5	MGL	1905

Reaction No. 29107							
Mg+2_TriMDTA-4 + H+1 = Mg+2_H+1_TriMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:7.5(2SF)	5	ENS	2373
2	25	0.1	Unknown	lgK:7.3(2SF)	6	CRV	552

Reaction No. 29117							
Mg+2_PentMDTA-4 + H+1 = Mg+2_H+1_PentMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:9.0(2SF)	5	ENS	2373

Reaction No. 29126							
--------------------	--	--	--	--	--	--	--

Di (2MeAc)EDDA-4 + Mg+2 = Mg+2_Di (2MeAc)EDDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:8.58 (0.01SD)	0	MPT	2004
Note (1): Low wgt for internal consistency							
2	30	0.1	KCl	lgK:9.41 (3SF)	3	MGL	2019

Reaction No. 29130							
Di (2EtAc)EDDA-4 + Mg+2 = Mg+2_Di (2EtAc)EDDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:7.83 (3SF)	5	ENS	2373

Reaction No. 29134							
Di (2PrAc)EDDA-4 + Mg+2 = Mg+2_Di (2PrAc)EDDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:7.96 (3SF)	5	ENS	2373

Reaction No. 29138							
Di (2IPrAc)EDDA-4 + Mg+2 = Mg+2_Di (2IPrAc)EDDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:5.20 (3SF)	5	ENS	2373


Reaction No. 29229							
Norval-1 + Mg+2 = Mg+2_Norval-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:1.56 (3SF)	6	MGL	2392

Reaction No. 29236							
Norleu-1 + Mg+2 = Mg+2_Norleu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:1.9 (0.08SD)	6	MGL	2392

Reaction No. 29319							
CPDTA-4 + Mg+2 = Mg+2_CPDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:9.07 (3SF)	4	MGL	140
2	20	0.1	Unknown	lgK:9.05 (3SF)	4	MGL	931
3	20	1	Unknown	lgK:9.29 (3SF)	6	CRV	552


4	25	0.1	Unknown	lgK:9.30 (3SF)	6	CRV	552
5	20	1	KCl	dH:4.37 (3SF)	5	MCL	2018

Reaction No. 29634




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0.1	KNO3	lgK:5.6 (0.08SD)	2	MGL	3867
2	25	0.1	KNO3	lgK:5.0 (0.1SD)	2	MGL	3867
3	35	0.1	KNO3	lgK:5.07 (3SF)	2	MGL	2371
4	45	0.1	KNO3	lgK:5.47 (3SF)	2	MGL	1905
5	25	0.1	KNO3	dH:1.9 (0.1SD)	2	MCL	3867

Reaction No. 29641



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:2.5 (2SF)	4	MGL	2371

Reaction No. 29659




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.9 (2SF)	1	ESC	
2	45	0.1	KNO3	lgK:1.9 (0.09SD)	5	MGL	1905

Reaction No. 29666



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:7. (0.4SD)	5	MGL	1905

Reaction No. 30044



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:0.7 (1SF)	3	MGL	6086
2	25	1	KNO3	lgK:1.0 (2SF)	0	MGL	6086
3	25	1	Me4NNO3	lgK:0.30 (0.01SD)	6	MGL	2542
4	25	0.25	DMSO:Water 90:10Vol Me4NNO3	lgK:0.500000 (0.2SD)	6	MGL	2542

Reaction No. 30050							
TriEtOlAm + Mg+2 = Mg+2_TriEtOlAm							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NNO3	lgK:0.24(0.02SD)	6	MGL	2542
2	25	0.25	DMSO:Water 90:10Vol Me4NNO3	lgK:0.5(0.03SD)	6	MGL	2542

Reaction No. 30056							
BisTris + Mg+2 = Mg+2_BisTris							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:0.34(0.05SD)	5	MGL	6089
2	25	1	Me4NNO3	lgK:0.3(0.05SD)	6	MGL	2542
3	25	0.5	DMSO:Water 75:25Vol Me4NNO3	lgK:0.44(0.01SD)	6	MGL	2542
4	25	0.25	DMSO:Water 90:10Vol Me4NNO3	lgK:0.9(0.04SD)	6	MGL	2542
5	25	0.5	Dioxan:Water 50:50Vol Me4NNO3	lgK:0.51(0.02SD)	6	MGL	2542
6	25	0.5	Methanol:Water 50:50Vol Me4NNO3	lgK:0.43(0.01SD)	6	MGL	2542

Reaction No. 30152							
Mg+2 + H+1_HPEDDA-4 = Mg+2_H+1_HPEDDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:10.(0.3SD)	4	MGL	1783

Reaction No. 30153							
Mg+2 + H+1(2)_HPEDDA-4 = Mg+2_H+1(2)_HPEDDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:6.0(0.2SD)	4	MGL	1783

Reaction No. 30228							
[14]N4:2OHEt*4 + Mg+2 = Mg+2_[14]N4:2OHEt*4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:1.86(3SF)	5	ENS	233

Reaction No. 30679							
EtEDTA-4 + Mg+2 = Mg+2_EtEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:10.15 (4SF)	6	MGL	2011

Reaction No. 30703							
11DiMeEDTA-4 + Mg+2 = Mg+2_11DiMeEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:9.65 (3SF)	6	MPT	1978

Reaction No. 30728							
HexEDTA-4 + Mg+2 = Mg+2_HexEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:10.2 (0.03SD)	6	MPL	1981

Reaction No. 30789							
Mg+2_mBDTA-4 + H+1 = Mg+2_H+1_mBDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:4.47 (3SF)	6	CRV	552

Reaction No. 30927							
OHMePhos-2 + Mg+2 = Mg+2_OHMePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NC1	lgK:1.92 (3SF)	5	MGL	2756


Reaction No. 31059							
Mg+2 + H+1(2)_Tartaric-2 + Ascorbic-2 = Mg+2_H+1(2)_Ascorbic-2_Tartaric-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:3.77 (3SF)	3	MGL	2261

Reaction No. 31146							
Mg+2 + H+1_NTMP-6 = Mg+2_H+1_NTMP-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:3.2 (0.09SD)	4	MGL	931
2	25	0	Inf. Dilution	dH:7.23 (3SF)	5	MCL	2261

Reaction No. 31428							
NEtIm(MePhos)*2-4 + Mg+2 = Mg+2_NEtIm(MePhos)*2-4							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	K+1 salt	lgK:4.42 (3SF)	5	CRV	2556

Reaction No. 31429




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	K+1 salt	lgK:10.33 (4SF)	5	CRV	2556

Reaction No. 31430




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	K+1 salt	lgK:5.5 (2SF)	5	CRV	2556

Reaction No. 31483




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:3.35 (3SF)	5	MGL	2261

Reaction No. 31484




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:2.22 (3SF)	5	MGL	2261

Reaction No. 32014




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:6.57 (3SF)	5	MGL	2261

Reaction No. 32015



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:6.32 (3SF)	5	MGL	2261

Reaction No. 32057



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:7.40 (3SF)	5	MGL	2261

Reaction No. 32058							
$\text{Mg}+2 + \text{H}+1_ \text{ADOPPH}-5 = \text{Mg}+2_ \text{H}+1_ \text{ADOPPH}-5$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:6.85 (3SF)	5	MGL	2261

Reaction No. 32059							
$\text{Mg}+2 + \text{H}+1(2)_ \text{ADOPPH}-5 = \text{Mg}+2_ \text{H}+1(2)_ \text{ADOPPH}-5$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:4.54 (3SF)	5	MGL	2261

Reaction No. 32060							
$\text{Mg}+2 + \text{H}+1(3)_ \text{ADOPPH}-5 = \text{Mg}+2_ \text{H}+1(3)_ \text{ADOPPH}-5$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:3.17 (3SF)	5	MGL	2261

Reaction No. 32061							
$\text{Mg}+2 + \text{H}+1(4)_ \text{ADOPPH}-5 = \text{Mg}+2_ \text{H}+1(4)_ \text{ADOPPH}-5$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:2.67 (3SF)	5	MGL	2261

Reaction No. 32255							
$2\text{Am}3\text{PhosPr}-3 + \text{Mg}+2 = \text{Mg}+2_ 2\text{Am}3\text{PhosPr}-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:2.59 (3SF)	5	MGL	6868


Reaction No. 32256							
$\text{Mg}+2 + \text{H}+1_ 2\text{Am}3\text{PhosPr}-3 = \text{Mg}+2_ \text{H}+1_ 2\text{Am}3\text{PhosPr}-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:1.00 (3SF)	5	MGL	6868

Reaction No. 32400							
$\text{N}25\text{DiCOOPhenIDA}-4 + \text{Mg}+2 = \text{Mg}+2_ \text{N}25\text{DiCOOPhenIDA}-4$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.14 (3SF)	5	CRV	2556
2	25	0.1	KNO3	dH:8.3 (2SF)	5	CRV	2556

Reaction No. 32490							
$\text{Mg}+2 + \text{H}+1_ \text{EDTMP}-8 = \text{Mg}+2_ \text{H}+1_ \text{EDTMP}-8$							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.03 (3SF)	0	MGL	1595

Reaction No. 32491




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.45 (3SF)	0	MGL	1595

Reaction No. 32492




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.06 (3SF)	0	MGL	1595

Reaction No. 32780




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.38 (3SF)	6	MEF	1997

Reaction No. 32896




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:2.53 (3SF)	5	MGL	6135
2	25	0.16	NaCl	lgK:2.53 (3SF)	5	MGL	2717

Reaction No. 32949




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:10.30 (4SF)	6	MPT	2011

Reaction No. 32954



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:10.16 (4SF)	6	MPT	2011

Reaction No. 33017



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.64 (0.02SD)	6	MGL	2595

Reaction No. 33022							
4ClPhen2NTA-3 + Mg+2 = Mg+2_4ClPhen2NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.45 (0.02SD)	6	MGL	2595

Reaction No. 33027							
24MePhenNTA-3 + Mg+2 = Mg+2_24MePhenNTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.74 (0.02SD)	6	MGL	2595

Reaction No. 33032							
24MeoxPhenNTA-3 + Mg+2 = Mg+2_24MeoxPhenNTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.75 (0.01SD)	6	MGL	2595

Reaction No. 33187							
Phenanth + Mg+2 + 5ATP-4 = Mg+2_Phenanth_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:6.1 (0.1SD)	6	MGL	2961

Reaction No. 33188							
Mg+2_5ATP-4 + Phenanth = Mg+2_Phenanth_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.02 (0.02SD)	6	MGL	2961

Reaction No. 33354							
SalNH2-1 + Mg+2 = Mg+2_SalNH2-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	Dioxan:Water 75:25Wgt NaClO4	lgK:2.79 (3SF)	5	MGL	931

Reaction No. 34156							
Tetracycline-2 + Mg+2 = Mg+2_Tetracycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:8.40 (3SF)	0	MPT	1069
2	25	0.1	Unknown	lgK:5.42 (3SF)	5	ENS	233

Reaction No. 34211							
2COCH3Naphthol-1 + Mg+2 = Mg+2_2COCH3Naphthol-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:7.15 (3SF)	5	MGL	140

Reaction No. 34212							
Mg+2_2COCH3Naphthol-1 + 2COCH3Naphthol-1 = Mg+2_2COCH3Naphthol-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:5.55 (3SF)	5	MGL	140

Reaction No. 34243							
4ClSalAld-1 + Mg+2 = Mg+2_4ClSalAld-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.3	Dioxan:Water 50:50Wgt NaClO4	lgK:3. (1SF) w	4	MPH	931

Reaction No. 34250							
6ClSalAld-1 + Mg+2 = Mg+2_6ClSalAld-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.3	Dioxan:Water 50:50Wgt NaClO4	lgK:2. (1SF) w	4	MPH	931

Reaction No. 34347							
EriochromeBT-3 + Mg+2 = Mg+2_EriochromeBT-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18:20	0.08	Unknown	lgK:7.0 (2SF)	5	MSP	140

Reaction No. 34557							
Mg+2 + H+1(2)_EriochromeBT-3 = Mg+2_EriochromeBT-3 + 2<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		MeCN	lgK:3.97 (3SF)	4	MSP	906

Reaction No. 34558							
Mg+2 + H+1_EriochromeBT-3 = Mg+2_EriochromeBT-3 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		MeCN	lgK:5.02 (3SF)	4	MSP	906

Reaction No. 34689							
Cysam-1 + Mg+2 = Mg+2_Cysam-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:2.64 (0.01SD)	4	EDH	5390
2	25	0.1	KNO3	lgK:2.30 (3SF)	5	MGL	931
3	25	0.1	UCT_Sea	lgK:2.30 (0.01SD)	4	EDH	5390
4	25	0.2	UCT_Sea	lgK:2.24 (0.01SD)	4	EDH	5390
5	25	0.3	UCT_Sea	lgK:2.21 (0.01SD)	4	EDH	5390
6	25	0.4	UCT_Sea	lgK:2.20 (0.01SD)	4	EDH	5390
7	25	0.5	UCT_Sea	lgK:2.19 (0.01SD)	4	EDH	5390
8	25	0.6	UCT_Sea	lgK:2.18 (0.01SD)	4	EDH	5390
9	25	0.7	UCT_Sea	lgK:2.18 (0.01SD)	4	EDH	5390

Reaction No. 35539							
Nitroacetic-1 + Mg+2 = Mg+2_Nitroacetic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18	0.2	Ba (NO3) 2	lgK:-0.19 (2SF)	3	MKN	140

Reaction No. 35802							
[2.1.1]crypt + Mg+2 = Mg+2_[2.1.1]crypt							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	KCl	lgK:2. (0.3SD)	5	MGL	3283
2	25	0.01	Methanol:Water 95:5Vol KCl	lgK:4.0 (2SF)	5	MGL	3283

Reaction No. 35810							
[2.2.1]crypt + Mg+2 = Mg+2_[2.2.1]crypt							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	KCl	lgK:2.0 (2SF)	3	MGL	3283
2	25	0.01	Methanol:Water 95:5Vol KCl	lgK:2.0 (2SF)	3	MGL	3283

Reaction No. 35860							
2<H+1> + 13FDDS-4 + Mg+2 = Mg+2_H+1(2)_13FDDS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:10.5 (0.02SD)	5	MGL	3802

Reaction No. 35861							
$H+1 + 13FDDS-4 + Mg+2 = Mg+2_H+1_13FDDS-4$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:6.44 (0.01SD)	5	MGL	3802

Reaction No. 35862							
$13FDDS-4 + Mg+2 = Mg+2_13FDDS-4$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:1.3 (0.03SD)	5	MGL	3802

Reaction No. 36074							
$[12]N4 + Mg+2 = Mg+2_ [12]N4$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:2. (0.6SD)	5	MGL	3913

Reaction No. 36075							
$Mg+2_5ADP-3 + H+1 = Mg+2_H+1_5ADP-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:5.03 (3SF)	5	MGL	3905
2	25	0.1	NaClO4	dH:-7.52 (3SF) kJ	5	MCL	3905

Reaction No. 36076							
$Mg+2_5ATP-4 + H+1 = Mg+2_H+1_5ATP-4$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:4.6 (0.05SD)	5	MGL	3905
2	25	0.1	NaNO3	lgK:4.60 (0.025SD)	5	MGL	6100
3	70	0.2	Me4NCl	lgK:5.36 (3SF)	0	MGL	1437
4	25	0.1	NaClO4	dH:-3.43 (3SF) kJ	5	MCL	3905

Reaction No. 36242							
$UramilIDA-3 + Mg+2 = Mg+2_UramilIDA-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:8.13 (0.01SD)	5	MGL	3201
2	20	0.1	Unknown	lgK:8.19 (3SF)	6	CRV	552
3	25	0.1	KNO3	lgK:8.09 (0.01SD)	5	MGL	3201
4	25	0.1	Me4N+ salt	lgK:8.35 (3SF)	6	CRV	552

5	25	0.1	Unknown	lgK:8.1(0.05SD)	6	CRV	552
6	30	0.1	KNO3	lgK:8.06(0.01SD)	5	MGL	3201
7	35	0.1	KNO3	lgK:8.02(0.01SD)	5	MGL	3201
8	40	0.1	KNO3	lgK:7.98(0.01SD)	5	MGL	3201
9	20	0.1	Me4N+ salt	dH:0.6(1SF)	6	CRV	552
10	20:40	0.1	KNO3	dH:-3.2(0.2SD)	0	MCL	3201
11	25	0.1	KNO3	dH:0.91(2SF)	5	MTD	6627

Reaction No. 36526							
H+1 + P3O10-5 + Mg+2 = Mg+2_H+1_P3O10-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.5(3SF)	4	ENS	6405

Reaction No. 36847							
2<Mg+2> + Cu+2 + Citric-3 = 2<H+1> + Cu+2_Mg+2(2)_H+1(-2)_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:-1.10(3SF)	5	MGL	3870

Reaction No. 36861							
2SHPyrimidine-1 + Mg+2 = Mg+2_2SHPyrimidine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:2.76(0.02SD)	5	MGL	3853

Reaction No. 36867							
6SHPurine-1 + Mg+2 = Mg+2_6SHPurine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:6.0(0.2SD)	5	MGL	3853

Reaction No. 37093							
Etbis(ImMePhos)-4 + Mg+2 = Mg+2_Etbis(ImMePhos)-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.(1SF)	3	MGL	931

Reaction No. 37128							
Mg+2_Tropolone-1 + Tropolone-1 = Mg+2_Tropolone-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 50:50Wgt	lgK:4.4(2SF)	4	MGL	140

Reaction No. 37139							
3BrTropolone-1 + Mg+2 = Mg+2_3BrTropolone-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 50:50Wgt	lgK:4.9 (2SF)	4	MGL	140

Reaction No. 37140							
Mg+2_3BrTropolone-1 + 3BrTropolone-1 = Mg+2_3BrTropolone-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 50:50Wgt	lgK:3.9 (2SF)	4	MGL	140

Reaction No. 37209							
DiBenzoylmethane-1 + Mg+2 = Mg+2_DiBenzoylmethane-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:8.54 (3SF)	5	MGL	140

Reaction No. 37210							
Mg+2_DiBenzoylmethane-1 + DiBenzoylmethane-1 = Mg+2_DiBenzoylmethane-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:7.67 (3SF)	5	MGL	140


Reaction No. 37227							
oOHDiBenzoylmethane-1 + Mg+2 = Mg+2_oOHDiBenzoylmethane-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:8.14 (3SF)	5	MGL	140

Reaction No. 37228							
Mg+2_oOHDiBenzoylmethane-1 + oOHDiBenzoylmethane-1 = Mg+2_oOHDiBenzoylmethane-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:7.00 (3SF)	5	MGL	140

Reaction No. 37289							
Mg+2 + H+1_Salicylaldoxime-2 = Mg+2_H+1_Salicylaldoxime-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:0.64 (2SF)	4	MGL	140
---	----	---	---------------	----------------	---	-----	-----

Reaction No. 37290




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.10 (3SF)	4	MGL	140

Reaction No. 37326



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:2.00 (3SF)	5	MGL	140

Reaction No. 37383




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:7.69 (3SF)	5	MGL	140
2	30		Dioxan:Water 75:25Wgt	lgK:7.84 (3SF)	5	MGL	140

Reaction No. 37384



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:6.20 (3SF)	5	MGL	140
2	30		Dioxan:Water 75:25Wgt	lgK:6.40 (3SF)	5	MGL	140

Reaction No. 37402



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:7.18 (3SF)	5	MGL	140

Reaction No. 37403



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:6.05 (3SF)	5	MGL	140

Reaction No. 37478							
OPhosSerLys-3 + Mg+2 = Mg+2_OPhosSerLys-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:1.63 (3SF)	5	MGL	931

Reaction No. 37487							
12PhenDioxDiacet-2 + Mg+2 = Mg+2_12PhenDioxDiacet-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:1.5 (2SF)	3	MGL	931

Reaction No. 37561							
CNMeIDA-2 + Mg+2 = Mg+2_CNMeIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.86 (3SF)	6	MGL	3486

Reaction No. 37593							
Piperazine26DiCOO-2 + Mg+2 = Mg+2_Piperazine26DiCOO-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	0.1	KCl	lgK:3.2 (2SF)	5	MGL	140

Reaction No. 37602							
Piperazine23DiCOO-2 + Mg+2 = Mg+2_Piperazine23DiCOO-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	0.1	KCl	lgK:7.3 (2SF)	5	MGL	140

Reaction No. 37619							
SulfSal-3 + Mg+2 = Mg+2_SulfSal-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.02 (3SF)	3	MGL	3617
2	25	0.1	NaNO3	lgK:4.70 (3SF)	4	MGL	3617
3	45	0.1	KNO3	lgK:3.85 (3SF)	4	MGL	5987

Reaction No. 37622							
Mg+2 + H+1_SulfSal-3 = Mg+2_H+1_SulfSal-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.61 (3SF)	5	MGL	3617
2	25	1	NaNO3	lgK:0.73 (2SF)	5	MGL	3617

Reaction No. 37729							
CarbMeIDA-2 + Mg+2 = Mg+2_CarbMeIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.47 (3SF)	6	MGL	3486
2	25	0.1	KNO3	lgK:2.51 (0.02SD)	5	MGL	6631
3	25	0.1	Unknown	lgK:2.54 (3SF)	6	CRV	552
4	10:40	0.1	Unknown	dH:5. (1SF)	6	CRV	552

Reaction No. 37899							
Colchiceine-1 + Mg+2 = Mg+2_Colchiceine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	NaClO4	lgK:5.93 (3SF)	5	MGL	620
2	20	0.025	NaClO4	lgK:5.72 (3SF)	5	MGL	620
3	20	0.05	NaClO4	lgK:5.64 (3SF)	5	MGL	620
4	20	0.1	NaClO4	lgK:5.22 (3SF)	5	MGL	620

Reaction No. 37900							
2<Colchiceine-1> + Mg+2 = Mg+2_Colchiceine-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	NaClO4	lgK:10.65 (4SF)	2	MGL	620
2	20	0.025	NaClO4	lgK:10.48 (4SF)	3	MGL	620
3	20	0.05	NaClO4	lgK:9.66 (3SF)	2	MGL	620
4	20	0.1	NaClO4	lgK:9.37 (3SF)	0	MGL	620
5	25	0	Inf. Dilution	lgK:10.5 (3SF)	1	EDH	

Reaction No. 38320							
N33DiMeBuIDA-2 + Mg+2 = Mg+2_N33DiMeBuIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.60 (3SF)	6	MGL	3486

Reaction No. 38342							
NPhenIDA-2 + Mg+2 = Mg+2_NPhenIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.15 (3SF)	6	MGL	3486
2	25	0.1	KNO3	lgK:1.1 (0.2MD)	5	MGL	2551
3	25	0.1	KNO3	dH:1.4 (0.1MD)	5	MCL	2551

Reaction No. 38354							
N2MeoxEtIDA-2 + Mg+2 = Mg+2_N2MeoxEtIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.31 (3SF)	6	MGL	3486

Reaction No. 38388							
N2SHEtIDA-2 + Mg+2 = Mg+2_N2SHEtIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.32 (3SF)	6	MGL	3486

Reaction No. 38389							
Mg+2 + H+1_N2SHEtIDA-2 = Mg+2_H+1_N2SHEtIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.50 (3SF)	6	MGL	3486

Reaction No. 38415							
N2MeSEtIDA-2 + Mg+2 = Mg+2_N2MeSEtIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.02 (3SF)	6	MGL	3486

Reaction No. 38443							
UEDDA-2 + Mg+2 = Mg+2_UEDDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.53 (3SF)	6	MGL	3486


Reaction No. 38485							
2BisCarboxMeAmEtTriMeAm-1 + Mg+2 = Mg+2_2BisCarboxMeAmEtTriMeAm-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.42 (3SF)	6	MGL	3486

Reaction No. 38505							
N2EttoxFormAmEtIDA-2 + Mg+2 = Mg+2_N2EttoxFormAmEtIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.68 (3SF)	6	MGL	3486

Reaction No. 38646							
Lasalocid-1 + Mg+2 = Mg+2_Lasalocid-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	DMF Inf. Dilution	lgK:3.2(0.2SD)	5	MPT	4763
2	25	0	Ethanol Inf. Dilution	lgK:6.2(0.2SD)	5	MPT	4763
3	25	0	Methanol Inf. Dilution	lgK:3.9(0.2SD)	5	MPT	4763
4	25	1	Methanol Tris buffer	lgK:3.83(3SF)	4	MPH	5674
5	25		Methanol	lgK:4.20(3SF)	5	MPT	2599
6	25		Methanol	lgK:4.12(3SF)	4	MPT	2604
7	25		Methanol	dH:-27.5(3SF) kJ	5	MCL	4795
8	25	0	PrCarbonate Inf. Dilution	lgK:7.7(0.2SD)	5	MPT	4763

Reaction No. 38647




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:6.7(2SF)	5	MPT	2599
2	25		Methanol	lgK:6.07(3SF)	4	MPT	2604
3	25		Methanol	dH:-33.0(3SF) kJ	5	MCL	4795

Reaction No. 38652




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Vol KCl	lgK:2.6(2SF)	4	MPS	1511

Reaction No. 38653



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Vol KCl	lgK:2.5(2SF)	4	MPS	1511

Reaction No. 38685



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Acetone	lgK:2.40(0.02SD)	4	MFL	2469
2	25		MeCN	lgK:3.5(0.07SD)	4	MFL	2469

Reaction No. 38692							
Mg+2_Oxine-1 + Oxine-1 = Mg+2_Oxine-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Acetone	lgK:1.80(0.01SD)	4	MFL	2469
2	25	0.1	Dioxan:Water 60:40Vol NaClO4	lgK:5.23(3SF)	5	MGL	3082
3	25		MeCN	lgK:2.3(0.09SD)	4	MFL	2469

Reaction No. 38698							
Mg+2_Bipy + Bipy = Mg+2_Bipy(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Acetone	lgK:1.0(0.06SD)	4	MFL	2469
2	25		MeCN	lgK:2.2(0.07SD)	4	MFL	2469

Reaction No. 38719							
Mg+2_OxAcet-2 = Mg+2_H+1(-1)_OxAcet-2 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-8.5(2SF)	1	EDH	
2	25	0.1	KCl	lgK:-7.6(2SF)	1	MSP	1511
3	25	0.5	KCl	lgK:-8.6(2SF)	2	MKN	1503
4	25	0.1	Dioxan:Water 50:50Vol KCl	lgK:-8.93(3SF)	4	MSP	1511


Reaction No. 38722							
Mg+2_Acetic-1 + OxAcet-2 = Mg+2_Acetic-1_OxAcet-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Vol KCl	lgK:2.9(2SF)	3	MSP	1511

Reaction No. 38723							
Mg+2_Acetic-1_OxAcet-2 + Acetic-1 = Mg+2_Acetic-1(2)_OxAcet-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Vol KCl	lgK:2.8(2SF)	3	MSP	1511

Reaction No. 38724							
2<Mg+2> + OxAcet-2 + Acetic-1 = Mg+2(2)_H+1(-1)_Acetic-1_OxAcet-2 + H+1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Vol KCl	lgK:2.92 (3SF)	4	MSP	1511

Reaction No. 38725




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		DMF	lgK:2.0 (2SF)	3	MPS	3910
2	25		DMSO	lgK:2.0 (2SF)	3	MPS	3910
3	25		Methanol	lgK:2.7 (0.07SD)	4	MPS	3910

Reaction No. 38728




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		DMF	lgK:2.5 (0.05SD)	4	MPS	3910
2	25		DMSO	lgK:2.2 (0.06SD)	4	MPS	3910
3	25		Methanol	lgK:3.6 (0.06SD)	4	MPS	3910
4	25	0.1	Methanol:Water 90:10Wgt Unknown	lgK:2.70 (0.04SD)	6	CIU	13297
5	25	0.1	Methanol:Water 90:10Wgt Unknown	dH:-4.67 (0.1SD) kJ	6	CIU	13297
6	25	0.1	PrCarbonate Unknown	lgK:2.94 (0.05SD)	6	CIU	13297
7	25	0.1	PrCarbonate Unknown	dH:-30. (1.SD)	6	CIU	13297

Reaction No. 38732



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		DMF	lgK:2.0 (2SF)	3	MPS	3910
2	25		DMSO	lgK:2.0 (2SF)	3	MPS	3910
3	25		Methanol	lgK:2.3 (0.07SD)	4	MPS	3910

Reaction No. 38746



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0.05	Ethanol:Water 95:5Wgt Et4NC1O4	lgK:1.7(0.07SD)	4	MPS	2713
---	----	------	--------------------------------------	-----------------	---	-----	------

Reaction No. 38750							
2AmPyridine + Mg+2 = Mg+2_2AmPyridine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Ethanol:Water 95:5Wgt Et4NC1O4	lgK:1.12(0.01SD)	4	MPS	2713

Reaction No. 38796							
H+1 + Diglycol-2 + Mg+2 = Mg+2_H+1_Diglycol-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.7(2SF)	1	ELC	
2	25	0.1	KNO3	lgK:5.88(0.02SD)	0	MGL	3519

Reaction No. 38800							
2<Norleu-1> + Mg+2 = Mg+2_Norleu-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:4.(1SF)	3	MGL	3514

Reaction No. 39181							
HydrazineNNDiAcet-2 + Mg+2 = Mg+2_HydrazineNNDiAcet-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KCl	lgK:1.9(2SF)	4	MGL	4250

Reaction No. 39352							
[2.1.C5]crypt + Mg+2 = Mg+2_[2.1.C5]crypt							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Et4NC1O4	lgK:2.3(0.1SD)	5	MGL	2516
2	25	0.1	Methanol:Water 95:5Vol Et4NC1O4	lgK:3.2(0.05SD)	5	MGL	2516

Reaction No. 39517							
2<DiBenzoylmethane-1> + Mg+2 = Mg+2_DiBenzoylmethane-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Dioxan:Water 75:25Vol	lgK:16.7(3SF)	5	MGL	2360

Reaction No. 39626							
NNDiMeAmMePhos-2 + Mg+2 = Mg+2_NNDiMeAmMePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.0 (2SF)	5	MGL	2131

Reaction No. 39682							
3OH4Pyridinone-1 + Mg+2 = Mg+2_3OH4Pyridinone-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:4.33 (3SF)	6	MGL	2017

Reaction No. 39683							
Mg+2_3OH4Pyridinone-1 + 3OH4Pyridinone-1 = Mg+2_3OH4Pyridinone-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:3.15 (3SF)	6	MGL	2017

Reaction No. 39686							
Mimosine-2 + Mg+2 = Mg+2_Mimosine-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:4.38 (3SF)	6	MGL	2017

Reaction No. 39687							
H+1 + Mimosine-2 + Mg+2 = Mg+2_H+1_Mimosine-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:11.46 (4SF)	6	MGL	2017


Reaction No. 39688							
2<Mimosine-2> + Mg+2 = Mg+2_Mimosine-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:7.31 (3SF)	6	MGL	2017

Reaction No. 39689							
H+1 + 2<Mimosine-2> + Mg+2 = Mg+2_H+1_Mimosine-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:15.0 (0.07SD)	6	MGL	2017

Reaction No. 39690							
2<H+1> + 2<Mimosine-2> + Mg+2 = Mg+2_H+1(2)_Mimosine-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	37	0.15	KNO3	lgK:21.9(0.1SD)	6	MGL	2017
---	----	------	------	-----------------	---	-----	------

Reaction No. 39691




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:5.6(0.2SD)	6	MGL	2017

Reaction No. 39704




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:4.50(3SF)	6	MGL	2017

Reaction No. 39705




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:12.47(4SF)	6	MGL	2017

Reaction No. 39706




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:7.56(3SF)	4	MGL	2017

Reaction No. 39707




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:16.2(0.04SD)	6	MGL	2017

Reaction No. 39708



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:23.8(0.2SD)	6	MGL	2017

Reaction No. 39709



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:6.3(0.2SD)	6	MGL	2017

Reaction No. 39710

2<IMimosine-2> + 2<Mg+2> = Mg+2(2)_IMimosine-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	KNO3	lgK:10.(0.4SD)	6	MGL	2017

Reaction No. 39727							
Tau-1 + Mg+2 = Mg+2_Tau-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:0.4(1SF)	3	MCO	1867
2	37	0.1	NaClO4	lgK:0.3(1SF)	3	MCO	1867

Reaction No. 39729							
MES-1 + Mg+2 = Mg+2_MES-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:0.6(1SF)	4	MCO	1867
2	37	0.1	NaClO4	lgK:0.5(1SF)	4	MCO	1867

Reaction No. 39886							
[14]N2O3:MeCOO*2-2 + Mg+2 = Mg+2_[14]N2O3:MeCOO*2-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:6.7(2SF)	0	CRV	552
2	25	0.1	Me4NCl	lgK:7.4(0.09SD)	5	MGL	1491
3	25	0.1	Me4NNO3	lgK:7.53(0.004SD)	5	MGL	1176
4	25	0.1	Me4NNO3	dH:3.8(2SF)	5	MCL	1007

Reaction No. 39918							
[12]N4:MePhos*4-8 + Mg+2 = Mg+2_[12]N4:MePhos*4-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:9.4(0.05SD)	5	MGL	1318
2	25	1	KNO3	lgK:7.3(2SF)	5	ENS	1318

Reaction No. 39936							
H+1 + [12]N4:MePhos*4-8 + Mg+2 = Mg+2_H+1_[12]N4:MePhos*4-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:20.6(0.08SD)	5	MGL	1318
2	25	1	KNO3	lgK:18.12(4SF)	5	ENS	1318

Reaction No. 39937							
--------------------	--	--	--	--	--	--	--

2<H+1> + [12]N4:MePhos*4-8 + Mg+2 = Mg+2_H+1(2)_ [12]N4:MePhos*4-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:30.60 (0.02SD)	5	MGL	1318
2	25	1	KNO3	lgK:26.84 (4SF)	5	ENS	1318

Reaction No. 39938							
3<H+1> + [12]N4:MePhos*4-8 + Mg+2 = Mg+2_H+1(3)_ [12]N4:MePhos*4-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:39.53 (0.02SD)	5	MGL	1318
2	25	1	KNO3	lgK:35.2 (3SF)	5	ENS	1318

Reaction No. 39939							
4<H+1> + [12]N4:MePhos*4-8 + Mg+2 = Mg+2_H+1(4)_ [12]N4:MePhos*4-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:46.1 (0.03SD)	5	MGL	1318
2	25	1	KNO3	lgK:41.59 (4SF)	5	ENS	1318

Reaction No. 39940							
[12]N4:MePhos*4-8 + 2<Mg+2> = Mg+2(2)_ [12]N4:MePhos*4-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:15.75 (0.02SD)	5	MGL	1318

Reaction No. 39941							
H+1 + [12]N4:MePhos*4-8 + 2<Mg+2> = Mg+2(2)_H+1_ [12]N4:MePhos*4-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:24.78 (0.02SD)	5	MGL	1318

Reaction No. 40071							
Mg+2 + H+1(2)_NTMP-6 = Mg+2_H+1(2)_NTMP-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:3. (0.3SD)	4	MGL	931

Reaction No. 40072							
Mg+2 + H+1(3)_NTMP-6 = Mg+2_H+1(3)_NTMP-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:1.90 (0.02SD)	4	MGL	931

Reaction No. 40138							
--------------------	--	--	--	--	--	--	--

Cu+2 + Mg+2 + 2<Citric-3> = Cu+2_Mg+2_H+1(-2)_Citric-3(2) + 2<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:-1.1(2SF)	5	MSP	3870

Reaction No. 40165							
Mg+2 + H+1_Salicylic-2 = Mg+2_Salicylic-2 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:-8.48(0.03SD)	6	MSP	2260

Reaction No. 40205							
[Bu]11DiCOO-2 + Mg+2 = Mg+2_[Bu]11DiCOO-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.11(3SF)	5	MGL	931

Reaction No. 40206							
Mg+2 + H+1_[Bu]11DiCOO-2 = Mg+2_H+1_[Bu]11DiCOO-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:0.95(2SF)	5	MGL	931

Reaction No. 40417							
2PhosGlyceric-3 + Mg+2 = Mg+2_2PhosGlyceric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1:0.4	Pr4NI	lgK:2.45(3SF)	5	MGL	931


Reaction No. 40429							
Pr12DiPhos-4 + Mg+2 = Mg+2_Pr12DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.04(3SF)	5	MGL	931

Reaction No. 40430							
Mg+2 + H+1_Pr12DiPhos-4 = Mg+2_H+1_Pr12DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.08(3SF)	5	MGL	931

Reaction No. 40439							
Pr13DiPhos-4 + Mg+2 = Mg+2_Pr13DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.84(3SF)	5	MGL	931


2	25	0.1	Unknown	lgK:2.8 (2SF)	5	MGL	931
---	----	-----	---------	---------------	---	-----	-----

Reaction No. 40440




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.08 (3SF)	5	MGL	931

Reaction No. 40463




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:8.3 (0.2SD)	5	MGL	2596

Reaction No. 40464




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:3.6 (0.03SD)	5	MGL	2596

Reaction No. 40465




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:2. (0.3SD)	5	MGL	2596

Reaction No. 40466




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:1.05 (0.02SD)	5	MGL	2596

Reaction No. 40565



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:1.86 (3SF)	5	MGL	931

Reaction No. 40566



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:1.64 (3SF)	5	MGL	931

Reaction No. 40567

Mg+2 + Mg+2_GlyOPhosSer-3 = Mg+2(2)_GlyOPhosSer-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:1.4(2SF)	5	MGL	931

Reaction No. 40573							
OPhosSerGly-3 + Mg+2 = Mg+2_OPhosSerGly-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:1.94(3SF)	5	MGL	931

Reaction No. 40574							
Mg+2 + H+1_OPhosSerGly-3 = Mg+2_H+1_OPhosSerGly-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:1.40(3SF)	5	MGL	931

Reaction No. 40575							
Mg+2 + Mg+2_OPhosSerGly-3 = Mg+2(2)_OPhosSerGly-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:1.25(3SF)	5	MGL	931

Reaction No. 40607							
N2OxPrIDA-2 + Mg+2 = Mg+2_N2OxPrIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.72(3SF)	6	MGL	931

Reaction No. 40631							
4ClPyrid26DiCOO-2 + Mg+2 = Mg+2_4ClPyrid26DiCOO-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	0.1	NaClO4	lgK:2.38(3SF)	5	MGL	931

Reaction No. 40709							
26DiCOOPiperNAcet-3 + Mg+2 = Mg+2_26DiCOOPiperNAcet-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.06(0.01SD)	6	MGL	931

Reaction No. 40753							
N1COO[Hept]IDA-3 + Mg+2 = Mg+2_N1COO[Hept]IDA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:6.2(0.03SD)	6	MGL	2591

Reaction No. 40774							
Fruct16DiPhos-4 + Mg+2 = Mg+2_Fruct16DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.08	Unknown	lgK:2.7 (2SF)	5	MGL	931

Reaction No. 40775							
Mg+2 + H+1_Fruct16DiPhos-4 = Mg+2_H+1_Fruct16DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.08	Unknown	lgK:2.12 (3SF)	5	MGL	931

Reaction No. 40830							
[Hex]IDA-2 + Mg+2 = Mg+2_[Hex]IDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.46 (0.02SD)	6	MGL	931

Reaction No. 40861							
NTetrHyPyran2MeIDA-2 + Mg+2 = Mg+2_NTetrHyPyran2MeIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.70 (0.01SD)	6	MGL	931

Reaction No. 40968							
N1COO[Hex]IDA-3 + Mg+2 = Mg+2_N1COO[Hex]IDA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5. (0.3SD)	6	MGL	2591


Reaction No. 41092							
N2NitrBenzIDA-2 + Mg+2 = Mg+2_N2NitrBenzIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.65 (3SF)	6	MGL	931

Reaction No. 41147							
N1COO[Pent]IDA-3 + Mg+2 = Mg+2_N1COO[Pent]IDA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:6.75 (0.02SD)	6	MGL	2591

Reaction No. 41181							
2<Acetic-1> + Mg+2 + OxAcet-2 = Mg+2_Acetic-1(2)_OxAcet-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Vol KCl	lgK:8.32 (3SF)	5	MPS	1511

Reaction No. 41185




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:2.2 (2SF)	3	MGL	6759
2	25			lgK:0.0 (1SF)	3	MPS	3819
3	25		DMF	lgK:3.6 (0.07SD)	5	MPS	3819
4	25		DMSO	lgK:3.2 (0.07SD)	5	MPS	3819
5	25	0.05	Ethanol:Water 95:5Wgt Et4NClO4	lgK:4.7 (0.08SD)	5	MPS	2713
6	25		Methanol	lgK:3.8 (0.1SD)	5	MPS	3819

Reaction No. 41210




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:3.10 (3SF)	6	ENS	233

Reaction No. 41243




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2. (1SF)	3	ENS	1007

Reaction No. 41509




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KCl	lgK:1.7 (0.07SD)	6	MGL	2086

Reaction No. 41609




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:4.20 (3SF)	3	MPT	1069

Reaction No. 41610




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.5 (3SF)	1	ELC	
2	25	0.1	NaNO ₃	lgK:12.60 (4SF)	0	MPT	1069

Reaction No. 41627




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:-6.97 (0.04SD)	5	MSP	2260

Reaction No. 41628




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:-14.7 (3SF)	5	MSP	2260

Reaction No. 41634




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0	Dioxan:Water 50:50Vol Inf. Dilution	lgK:3.11 (3SF)	5	ENS	4455

Reaction No. 41745




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.5 (2SF)	5	MHY	931

Reaction No. 41814




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.8 (2SF)	4	MGL	140
2	30	0.1	KCl	lgK:1.6 (2SF)	0	MGL	140

Reaction No. 41847




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KNO ₃	lgK:1.32 (3SF)	4	MGL	140

Reaction No. 41855




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KCl	lgK:3.6(2SF)	6	MGL	140

Reaction No. 41952




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:7.31(3SF)	5	MHY	140

Reaction No. 41953




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.92(3SF)	5	MHY	140

Reaction No. 41964




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.38(3SF)	5	MHG	140

Reaction No. 41971




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.3(2SF)	5	MHG	140

Reaction No. 42181




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:3.89(3SF)	5	MPT	2599

Reaction No. 42182



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:6.3(2SF)	5	MPT	2599

Reaction No. 42192



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:4.5(2SF)	5	MPT	2599

Reaction No. 42193							
2<oAnisic-1> + Mg+2 = Mg+2_oAnisic-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:7.0(2SF)	5	MPT	2599

Reaction No. 42269							
5IMP-2 + Mg+2 = Mg+2_5IMP-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.81(3SF)	3	MGL	1937
2	25	0.1	NaNO3	lgK:1.67(0.02MD)	6	MGL	4460
3	25	0	Inf. Dilution	dH:11.4(3SF)kJ	3	MCL	1937

Reaction No. 42391							
Mg+2_NH3(5) + NH3 = Mg+2_NH3(6)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	2	NH4NO3	lgK:-1.3(2SF)	4	MGL	5646
2	25	0	Inf. Dilution	lgK:-1.3(3SF)	2	EAE	

Reaction No. 42424							
NACPen-2 + Mg+2 = Mg+2_NACPen-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:2.684(4SF)	5	MGL	3504


Reaction No. 42798							
Urea + Mg+2 = Mg+2_Urea							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20:23	4	NaClO4	lgK:-0.31(2SF)	4	MSP	906

Reaction No. 42799							
2<Urea> + Mg+2 = Mg+2_Urea(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20:23	4	NaClO4	lgK:-0.92(2SF)	4	MSP	906

Reaction No. 42847							
Co+3_Oxalic-2(3) + Mg+2 = Co+3_Mg+2_Oxalic-2(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.89(3SF)	4	MPL	906


2	25	0.1	NH4NO3	lgK:1.75 (3SF)	4	MPL	906
---	----	-----	--------	----------------	---	-----	-----

Reaction No. 43172




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NC1	lgK:6.83 (0.12SD)	5	MGL	3083

Reaction No. 43173




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Me4NC1	lgK:3.33 (0.05SD)	5	MGL	3083

Reaction No. 43205




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:5.1 (2SF)	0	MGL	6864
2	45	0.1	KNO3	lgK:3.9 (2SF)	5	MGL	906

Reaction No. 43473




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:2.63 (3SF)	5	MGL	906

Reaction No. 43508




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.2	NaClO4	lgK:2.08 (3SF)	4	MGL	906

Reaction No. 43517



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:6.7 (2SF)	0	MGL	6864
2	45	0.1	KNO3	lgK:3.05 (0.01SD)	4	MGL	906


Reaction No. 43524



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	45	0.1	KNO3	lgK:2.5 (2SF)	4	MGL	906
---	----	-----	------	---------------	---	-----	-----

Reaction No. 43560




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:8.65 (0.05MD)	6	MGL	4460

Reaction No. 43570




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:9.0 (0.2MD)	6	MGL	4460

Reaction No. 43605




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:5.9 (0.2SD)	4	MGL	906

Reaction No. 43677




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.2	NaClO4	lgK:2.59 (3SF)	5	MGL	906

Reaction No. 43683




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.2	NaClO4	lgK:2.44 (3SF)	4	MGL	906

Reaction No. 43687



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.2	NaClO4	lgK:2.80 (3SF)	4	MGL	906

Reaction No. 43760



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NCl	lgK:1.76 (3SF)	4	MGL	906

Reaction No. 43761

2<Isocitric-3> + Mg+2 = Mg+2_Isocitric-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NC1	lgK:2.72 (3SF)	4	MGL	906

Reaction No. 43810							
NPhosMeIDA-4 + Mg+2 = Mg+2_NPhosMeIDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:6.28 (3SF)	6	MHY	140
2	30	0.1	KCl	lgK:6.0 (2SF)	6	MGL	140


Reaction No. 44293							
5ClSalAld-1 + Mg+2 = Mg+2_5ClSalAld-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.3	Dioxan:Water 50:50Wgt NaClO4	lgK:3.39 (3SF)	5	MGL	3133
2	25	0.3	Dioxan:Water 50:50Wgt NaClO4	lgK:3.30 (3SF)	5	MGL	3133
3	35	0.3	Dioxan:Water 50:50Wgt NaClO4	lgK:3.16 (3SF)	5	MGL	3133
4	50	0.3	Dioxan:Water 50:50Wgt NaClO4	lgK:3.07 (3SF)	5	MGL	3133

Reaction No. 44294							
Mg+2_5ClSalAld-1 + 5ClSalAld-1 = Mg+2_5ClSalAld-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.3	Dioxan:Water 50:50Wgt NaClO4	lgK:2.87 (3SF)	5	MGL	3133
2	25	0.3	Dioxan:Water 50:50Wgt NaClO4	lgK:2.82 (3SF)	5	MGL	3133
3	35	0.3	Dioxan:Water 50:50Wgt NaClO4	lgK:2.74 (3SF)	5	MGL	3133
4	50	0.3	Dioxan:Water 50:50Wgt NaClO4	lgK:2.58 (3SF)	5	MGL	3133

Reaction No. 44463							
2OHAcPhenone-1 + Mg+2 = Mg+2_2OHAcPhenone-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	Dioxan:Water 75:25Wgt NaClO4	lgK:7.22 (3SF)	4	MGL	906

Reaction No. 44479




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:1. (1SF)	3	MGL	2482

Reaction No. 44633




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:5.08 (3SF)	4	MKN	906

Reaction No. 44634




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:3.05 (3SF)	4	MKN	906

Reaction No. 44635




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.3	Unknown	lgK:3.72 (3SF)	4	MKN	906

Reaction No. 44801




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	17:20	1	HCl	lgK:1.98 (3SF)	4	MDS	906
2	17:20	1	NH4Cl	lgK:1.98 (3SF)	4	MDS	906

Reaction No. 44802




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	17:20	1	HCl	lgK:5.03 (3SF)	4	MDS	906
2	17:20	1	NH4Cl	lgK:5.03 (3SF)	4	MDS	906

Reaction No. 44998




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.29 (3SF)	6	MGL	906

Reaction No. 44999




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:8.73 (3SF)	6	MGL	906

Reaction No. 45000




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:7.54 (3SF)	6	MGL	906

Reaction No. 45026




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:1.77 (3SF)	0	ENS	906
2	25	0	Inf. Dilution	lgK:8.5 (2SF)	1	EES	

Reaction No. 45170




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:6.3 (0.03SD)	6	MGL	2591

Reaction No. 45178




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.17 (0.02SD)	6	MGL	2591

Reaction No. 45406



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KCl	lgK:3.3 (2SF)	5	MGL	140


Reaction No. 45460



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0.1	Acetone:Water 75:25Wgt KNO3	lgK:7.3(0.06SD)	4	MGL	906
---	----	-----	-----------------------------------	-----------------	---	-----	-----

Reaction No. 45484




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Acetone:Water 75:25Wgt KNO3	lgK:7.3(0.08SD)	4	MGL	906

Reaction No. 45511




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.2(0.04SD)	5	MGL	2008

Reaction No. 45539




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:7.96(0.02SD)	5	MGL	2008

Reaction No. 45580




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.58(3SF)	4	MGL	906

Reaction No. 45581




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.53(3SF)	4	MGL	906

Reaction No. 45658



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.14(2SF)	1	ELC	


Reaction No. 45711



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	23			lgK:4.09(3SF)	3	MSP	906
2	25	0	Inf. Dilution	lgK:5.0(2SF)	1	ESC	

Reaction No. 45836




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	DMF Inf. Dilution	lgK:6.9(0.2SD)	5	MPT	4763
2	25	0	DMSO Inf. Dilution	lgK:5.4(0.2SD)	5	MPT	4763
3	25	0	Ethanol Inf. Dilution	lgK:9.1(0.2SD)	5	MPT	4763
4	25	0	Methanol Inf. Dilution	lgK:5.2(0.2SD)	5	MPT	4763
5	25	0	PrCarbonate Inf. Dilution	lgK:12.7(0.2SD)	5	MPT	4763

Reaction No. 45850




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:2.34(0.02SD)	5	MGL	4910

Reaction No. 45920



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:2.437(4SF)	5	MCO	4861
2	25	0	Inf. Dilution	lgK:2.508(4SF)	5	MCO	4861
3	30	0	Inf. Dilution	lgK:2.561(4SF)	5	MCO	4861
4	35	0	Inf. Dilution	lgK:2.608(4SF)	5	MCO	4861
5	25	0	Inf. Dilution	dH:14.6(1.5SD)kJ	4	MCO	4861

Reaction No. 45923



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:2.562(4SF)	5	MCO	4861
2	25	0	Inf. Dilution	lgK:2.625(4SF)	5	MCO	4861
3	25	0	UCT_Sea	lgK:2.63(0.01SD)	4	EDH	5390
4	25	0.1	UCT_Sea	lgK:1.89(0.01SD)	4	EDH	5390
5	25	0.2	UCT_Sea	lgK:1.75(0.01SD)	4	EDH	5390

6	25	0.3	UCT_Sea	lgK:1.67(0.01SD)	4	EDH	5390
7	25	0.4	UCT_Sea	lgK:1.61(0.01SD)	4	EDH	5390
8	25	0.5	UCT_Sea	lgK:1.57(0.01SD)	4	EDH	5390
9	25	0.6	UCT_Sea	lgK:1.55(0.01SD)	4	EDH	5390
10	25	0.7	UCT_Sea	lgK:1.52(0.01SD)	4	EDH	5390
11	30	0	Inf. Dilution	lgK:2.675(4SF)	5	MCO	4861
12	35	0	Inf. Dilution	lgK:2.705(4SF)	5	MCO	4861
13	25	0	Inf. Dilution	dH:12.(3.SD)kJ	4	MCO	4861

Reaction No. 46066							
Bul4DiPhos-4 + Mg+2 = Mg+2_Bul4DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.77(3SF)	5	MGL	931
2	25	0.1	Unknown	lgK:2.7(2SF)	3	MGL	4245

Reaction No. 46067							
Mg+2 + H+1_Bul4DiPhos-4 = Mg+2_H+1_Bul4DiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.05(3SF)	5	MGL	931

Reaction No. 46160							
Mg+2_Cytosine + Cytosine = Mg+2_Cytosine(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:3.5(0.08SD)	4	MGL	3853


Reaction No. 46169							
45DiAm6OHPyrimidine-1 + Mg+2 = Mg+2_45DiAm6OHPyrimidine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:3.1(0.03SD)	4	MGL	3853

Reaction No. 46172							
24DiAm6OHPyrimidine-1 + Mg+2 = Mg+2_24DiAm6OHPyrimidine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:2.7(0.1SD)	4	MGL	3853

Reaction No. 46253							
Mg+2 + H+1_AmMePhos-2 = Mg+2_H+1_AmMePhos-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.22(0.05MD)w	5	MPH	4478

Reaction No. 46271




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:4.1(0.07MD)w	5	MPH	4478

Reaction No. 46272




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.6(0.1MD)w	5	MPH	4478

Reaction No. 46324




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:3.0(0.06SD)	5	MGL	5977
2	27			lgK:1.079(4SF)	0	MMR	4935

Reaction No. 46378




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:7.1(2SF)	5	MGL	4795

Reaction No. 46393




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.9(2SF)	1	ESC	
2	35	0.1	KNO3	lgK:2.79(3SF)	4	MGL	3565

Reaction No. 46403



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:7.27(3SF)	4	MGL	3565


Reaction No. 46410



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:8.6(2SF)	1	ESC	
2	35	0.1	KNO3	lgK:8.30(3SF)	4	MGL	3565

Reaction No. 46476




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.6(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:1.60(0.01SD)	3	ETS	94

Reaction No. 46477




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.3(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:10.00(0.01SD)	3	ETS	94

Reaction No. 46478




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.3(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:2.20(0.01SD)	3	ETS	94

Reaction No. 46479




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.50(0.01SD)	3	ETS	94

Reaction No. 47059



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.65(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.45(0.01SD)	3	ETS	94


Reaction No. 47060



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.5(2SF)	1	EAE	


2	37	0.15	Blood Plasma	lgK:3.45 (0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 47061




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.50 (0.01SD)	3	ETS	94

Reaction No. 47062




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.7 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:4.7 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.50 (0.01SD)	3	ETS	94

Reaction No. 47063




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.76 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:4.76 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.80 (0.01SD)	3	ETS	94

Reaction No. 47064




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.30 (0.01SD)	3	ETS	94

Reaction No. 47065



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.56 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.60 (0.01SD)	3	ETS	94


Reaction No. 47066



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:4.65(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.45(0.01SD)	3	ETS	94

Reaction No. 47067




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.70(0.01SD)	3	ETS	94

Reaction No. 47068




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.80(0.01SD)	3	ETS	94

Reaction No. 47069




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.50(0.01SD)	3	ETS	94

Reaction No. 47070




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.75(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.55(0.01SD)	3	ETS	94

Reaction No. 47071



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.50(0.01SD)	3	ETS	94


Reaction No. 47072



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.75(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:3.55 (0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 47073




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.50 (0.01SD)	3	ETS	94

Reaction No. 47074




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.75 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.55 (0.01SD)	3	ETS	94

Reaction No. 47075




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.50 (0.01SD)	3	ETS	94

Reaction No. 47076




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.50 (0.01SD)	3	ETS	94

Reaction No. 47077



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.65 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.45 (0.01SD)	3	ETS	94

Reaction No. 47078



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.02 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.30 (0.01SD)	3	ETS	94

Reaction No. 47079							
Mg+2 + bAla-1 + Lactic-1 = Mg+2_bAla-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.4 (2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:2.30 (0.01SD)	3	ETS	94

Reaction No. 47080							
Mg+2 + Arg-1 + Lactic-1 = Mg+2_Arg-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.07 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.35 (0.01SD)	3	ETS	94

Reaction No. 47081							
Mg+2 + Asn-1 + Lactic-1 = Mg+2_Asn-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.07 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.35 (0.01SD)	3	ETS	94

Reaction No. 47082							
Mg+2 + Asp-2 + Lactic-1 = Mg+2_Lactic-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.61 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.65 (0.01SD)	3	ETS	94

Reaction No. 47083							
Mg+2 + Citrul-1 + Lactic-1 = Mg+2_Citrul-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.87 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.15 (0.01SD)	3	ETS	94

Reaction No. 47084							
Mg+2 + Glu-2 + Lactic-1 = Mg+2_Lactic-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.41 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.45 (0.01SD)	3	ETS	94

Reaction No. 47085							
--------------------	--	--	--	--	--	--	--

Mg+2 + Gln-1 + Lactic-1 = Mg+2_Gln-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.02(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.30(0.01SD)	3	ETS	94

Reaction No. 47086							
Mg+2 + Gly-1 + Lactic-1 = Mg+2_Gly-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.27(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.55(0.01SD)	3	ETS	94

Reaction No. 47087							
Mg+2 + His-1 + Lactic-1 = Mg+2_His-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.37(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.65(0.01SD)	3	ETS	94

Reaction No. 47088							
Mg+2 + Hyp-1 + Lactic-1 = Mg+2_Hyp-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.07(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.35(0.01SD)	3	ETS	94


Reaction No. 47089							
Mg+2 + Ile-1 + Lactic-1 = Mg+2_Ile-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.12(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.40(0.01SD)	3	ETS	94

Reaction No. 47090							
Mg+2 + Leu-1 + Lactic-1 = Mg+2_Lactic-1_Leu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.07(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.35(0.01SD)	3	ETS	94

Reaction No. 47091							
Mg+2 + Met-1 + Lactic-1 = Mg+2_Lactic-1_Met-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.12(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.40(0.01SD)	3	ETS	94

Reaction No. 47092




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.07(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.35(0.01SD)	3	ETS	94

Reaction No. 47093




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.12(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.40(0.01SD)	3	ETS	94

Reaction No. 47094




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.07(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.35(0.01SD)	3	ETS	94

Reaction No. 47095




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.07(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.35(0.01SD)	3	ETS	94

Reaction No. 47096



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.02(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.30(0.01SD)	3	ETS	94


Reaction No. 47097



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:4.45(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.25(0.01SD)	3	ETS	94

Reaction No. 47098




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.41(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.45(0.01SD)	3	ETS	94

Reaction No. 47099




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.36(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.40(0.01SD)	3	ETS	94

Reaction No. 47100




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.61(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.65(0.01SD)	3	ETS	94

Reaction No. 47101




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.71(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.75(0.01SD)	3	ETS	94

Reaction No. 47102



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.46(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.50(0.01SD)	3	ETS	94


Reaction No. 47103



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.41(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:2.45(0.01SD)	3	ETS	94
---	----	------	--------------	------------------	---	-----	----

Reaction No. 47104




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.35(0.01SD)	3	ETS	94

Reaction No. 47105




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.16(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.20(0.01SD)	3	ETS	94

Reaction No. 47106




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.26(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.30(0.01SD)	3	ETS	94

Reaction No. 47107




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.35(0.01SD)	3	ETS	94

Reaction No. 47108



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.31(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:4.31(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.35(0.01SD)	3	ETS	94


Reaction No. 47109



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.11(4SF)	1	EOR	


2	25	0	Inf. Dilution	lgK:4.11(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.15(0.01SD)	3	ETS	94

Reaction No. 47110




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.41(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:4.41(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.45(0.01SD)	3	ETS	94

Reaction No. 47111




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.26(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:4.26(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.30(0.01SD)	3	ETS	94

Reaction No. 47112




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.51(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.55(0.01SD)	3	ETS	94

Reaction No. 47113



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.61(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:4.61(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.65(0.01SD)	3	ETS	94

Reaction No. 47114



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.36(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:4.36(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.40(0.01SD)	3	ETS	94

Reaction No. 47115							
Oxalic-2 + Leu-1 + Mg+2 = Mg+2_Leu-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.31(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:4.31(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.35(0.01SD)	3	ETS	94

Reaction No. 47116							
Oxalic-2 + Met-1 + Mg+2 = Mg+2_Met-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.36(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:4.36(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.40(0.01SD)	3	ETS	94

Reaction No. 47117							
Mg+2 + Phe-1 + Oxalic-2 = Mg+2_Phe-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.35(0.01SD)	3	ETS	94

Reaction No. 47118							
Mg+2 + Ser-1 + Oxalic-2 = Mg+2_Ser-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.36(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.40(0.01SD)	3	ETS	94

Reaction No. 47119							
Mg+2 + Thr-1 + Oxalic-2 = Mg+2_Thr-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.35(0.01SD)	3	ETS	94

Reaction No. 47120							
Mg+2 + Val-1 + Oxalic-2 = Mg+2_Val-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.26(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.30(0.01SD)	3	ETS	94

Reaction No. 47121							
Mg+2 + Citric-3 + Oxalic-2 = Mg+2_Oxalic-2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.21(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.25(0.01SD)	3	ETS	94

Reaction No. 47122							
Oxalic-2 + Lactic-1 + Mg+2 = Mg+2_Lactic-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.06(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:4.06(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.10(0.01SD)	3	ETS	94

Reaction No. 47123							
Oxalic-2 + Malic-2 + Mg+2 = Mg+2_Malic-2_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.16(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:4.16(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.20(0.01SD)	3	ETS	94


Reaction No. 47124							
Mg+2 + Citric-3 + Salicylic-2 = Mg+2_Salicylic-2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.08(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:7.12(0.01SD)	3	ETS	94

Reaction No. 47125							
Mg+2 + Lactic-1 + Salicylic-2 = Mg+2_Lactic-1_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.93(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.97(0.01SD)	3	ETS	94

Reaction No. 47126							
Mg+2 + Arg-1 + Succinic-2 = Mg+2_Arg-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.46(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:2.50 (0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 47127




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.41 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.45 (0.01SD)	3	ETS	94

Reaction No. 47128




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.66 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.70 (0.01SD)	3	ETS	94

Reaction No. 47129




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.76 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.80 (0.01SD)	3	ETS	94

Reaction No. 47130




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.51 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.55 (0.01SD)	3	ETS	94

Reaction No. 47131



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.46 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.50 (0.01SD)	3	ETS	94

Reaction No. 47132



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.36 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.40 (0.01SD)	3	ETS	94

Reaction No. 47133							
Mg+2 + Lactic-1 + Succinic-2 = Mg+2_Lactic-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.21(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.25(0.01SD)	3	ETS	94

Reaction No. 47134							
Mg+2 + Malic-2 + Succinic-2 = Mg+2_Malic-2_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.35(0.01SD)	3	ETS	94

Reaction No. 47135							
Mg+2 + Oxalic-2 + Succinic-2 = Mg+2_Oxalic-2_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.21(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.25(0.01SD)	3	ETS	94

Reaction No. 47136							
H+1 + Mg+2 + Arg-1 + Ala-1 = Mg+2_H+1_Al-1_Arg-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.55(0.01SD)	3	ETS	94

Reaction No. 47137							
H+1 + Mg+2 + Asn-1 + Ala-1 = Mg+2_H+1_Al-1_Asn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.55(0.01SD)	3	ETS	94

Reaction No. 47138							
H+1 + Mg+2 + Asp-2 + Ala-1 = Mg+2_H+1_Al-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.95(0.01SD)	3	ETS	94

Reaction No. 47139							
--------------------	--	--	--	--	--	--	--

H+1 + Mg+2 + Citrul-1 + Ala-1 = Mg+2_H+1_Ala-1_Citrul-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.35(0.01SD)	3	ETS	94

Reaction No. 47140							
H+1 + Mg+2 + Gln-1 + Ala-1 = Mg+2_H+1_Ala-1_Gln-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.50(0.01SD)	3	ETS	94

Reaction No. 47141							
H+1 + Mg+2 + His-1 + Ala-1 = Mg+2_H+1_Ala-1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.85(0.01SD)	3	ETS	94

Reaction No. 47142							
H+1 + Mg+2 + Met-1 + Ala-1 = Mg+2_H+1_Ala-1_Met-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.60(0.01SD)	3	ETS	94


Reaction No. 47143							
H+1 + Mg+2 + Phe-1 + Ala-1 = Mg+2_H+1_Ala-1_Phe-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.55(0.01SD)	3	ETS	94

Reaction No. 47144							
H+1 + Mg+2 + Ser-1 + Ala-1 = Mg+2_H+1_Ala-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.60(0.01SD)	3	ETS	94

Reaction No. 47145							
H+1 + Mg+2 + Thr-1 + Ala-1 = Mg+2_H+1_Ala-1_Thr-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.55(0.01SD)	3	ETS	94

Reaction No. 47146




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.65(0.01SD)	3	ETS	94

Reaction No. 47147




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.45(0.01SD)	3	ETS	94

Reaction No. 47148




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.30(0.01SD)	3	ETS	94

Reaction No. 47149




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.40(0.01SD)	3	ETS	94

Reaction No. 47150



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.30(0.01SD)	3	ETS	94


Reaction No. 47151



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:12.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.45(0.01SD)	3	ETS	94

Reaction No. 47152




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.6(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:11.25(0.01SD)	3	ETS	94

Reaction No. 47153




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:12.10(0.01SD)	3	ETS	94

Reaction No. 47154




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.3(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:10.95(0.01SD)	3	ETS	94

Reaction No. 47155




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.4(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:11.05(0.01SD)	3	ETS	94

Reaction No. 47156



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.3(3SF)	1	EAE	
2	25	0	Inf. Dilution	lgK:12.4(3SF)	1	ESC	
3	37	0.15	Blood Plasma	lgK:11.95(0.01SD)	3	ETS	94


Reaction No. 47157



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:11.4 (3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:11.10 (0.01SD)	3	ETS	94

Reaction No. 47158




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.7 (3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:20.15 (0.01SD)	3	ETS	94

Reaction No. 47159




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.13 (0.01SD)	3	ETS	94

Reaction No. 47160




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.70 (0.01SD)	3	ETS	94

Reaction No. 47161




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.35 (0.01SD)	3	ETS	94

Reaction No. 47162



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.55 (0.01SD)	3	ETS	94

Reaction No. 47163



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8 (3SF)	2	EAE	

2	37	0.15	Blood Plasma	lgK:11.05 (0.01SD)	3	ETS	94
---	----	------	--------------	--------------------	---	-----	----

Reaction No. 47164							
H+1 + Mg+2 + Val-1 + Arg-1 = Mg+2_H+1_Arg-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.45 (0.01SD)	3	ETS	94

Reaction No. 47165							
H+1 + Mg+2 + Citric-3 + Arg-1 = Mg+2_H+1_Arg-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.85 (0.01SD)	3	ETS	94

Reaction No. 47166							
H+1 + Mg+2 + Lactic-1 + Arg-1 = Mg+2_H+1_Arg-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.70 (0.01SD)	3	ETS	94

Reaction No. 47167							
H+1 + Mg+2 + Malic-2 + Arg-1 = Mg+2_H+1_Arg-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.80 (0.01SD)	3	ETS	94

Reaction No. 47168							
H+1 + Mg+2 + Oxalic-2 + Arg-1 = Mg+2_H+1_Arg-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.9 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.70 (0.01SD)	3	ETS	94

Reaction No. 47169							
H+1 + Mg+2 + Succinic-2 + Arg-1 = Mg+2_H+1_Arg-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.85 (0.01SD)	3	ETS	94

Reaction No. 47170							
$2\text{<H+1>} + \text{Mg+2} + \text{Ala-1} + \text{Arg-1} = \text{Mg+2_H+1(2)_Ala-1_Arg-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.90(0.01SD)	3	ETS	94

Reaction No. 47171							
$2\text{<H+1>} + \text{Mg+2} + \text{bAla-1} + \text{Arg-1} = \text{Mg+2_H+1(2)_Arg-1_bAla-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.55(0.01SD)	3	ETS	94

Reaction No. 47172							
$\text{H+1} + \text{Mg+2} + \text{Gln-1} + \text{Asn-1} = \text{Mg+2_H+1_Asn-1_Gln-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.00(0.01SD)	3	ETS	94

Reaction No. 47173							
$\text{Gly-1} + \text{Asn-1} + \text{Mg+2} + \text{H+1} = \text{Mg+2_H+1_Asn-1_Gly-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.3(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:12.3(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:11.60(0.01SD)	3	ETS	94

Reaction No. 47174							
$\text{H+1} + \text{Mg+2} + \text{His-1} + \text{Asn-1} = \text{Mg+2_H+1_Asn-1_His-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.33(0.01SD)	3	ETS	94

Reaction No. 47175							
$\text{H+1} + \text{Mg+2} + \text{Pro-1} + \text{Asn-1} = \text{Mg+2_H+1_Asn-1_Pro-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.55(0.01SD)	3	ETS	94

Reaction No. 47176							
H+1 + Mg+2 + Ser-1 + Asn-1 = Mg+2_H+1_Asn-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.13(0.01SD)	3	ETS	94

Reaction No. 47177							
H+1 + Mg+2 + Thr-1 + Asn-1 = Mg+2_H+1_Asn-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.03(0.01SD)	3	ETS	94

Reaction No. 47178							
H+1 + Mg+2 + Val-1 + Asn-1 = Mg+2_H+1_Asn-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.35(0.01SD)	3	ETS	94

Reaction No. 47179							
Citric-3 + Asn-1 + Mg+2 + H+1 = Mg+2_H+1_Asn-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.4(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:13.4(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:11.70(0.01SD)	3	ETS	94

Reaction No. 47180							
H+1 + Mg+2 + Lactic-1 + Asn-1 = Mg+2_H+1_Asn-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.55(0.01SD)	3	ETS	94

Reaction No. 47181							
H+1 + Mg+2 + Malic-2 + Asn-1 = Mg+2_H+1_Asn-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.65(0.01SD)	3	ETS	94

Reaction No. 47182							
Oxalic-2 + Asn-1 + Mg+2 + H+1 = Mg+2_H+1_Asn-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.7(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:12.7(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:11.55(0.01SD)	3	ETS	94

Reaction No. 47183							
H+1 + Mg+2 + Succinic-2 + Asn-1 = Mg+2_H+1_Asn-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.70(0.01SD)	3	ETS	94

Reaction No. 47184							
2<H+1> + Mg+2 + Ala-1 + Asn-1 = Mg+2_H+1(2)_Ala-1_Asn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.75(0.01SD)	3	ETS	94

Reaction No. 47185							
2<H+1> + Mg+2 + bAla-1 + Asn-1 = Mg+2_H+1(2)_Asn-1_bAla-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.40(0.01SD)	3	ETS	94

Reaction No. 47186							
2<H+1> + Mg+2 + Arg-1 + Asn-1 = Mg+2_H+1(2)_Arg-1_Asn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.15(0.01SD)	3	ETS	94

Reaction No. 47187							
H+1 + Mg+2 + Gln-1 + Asp-2 = Mg+2_H+1_Gln-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.55(0.01SD)	3	ETS	94

Reaction No. 47188							
Gly-1 + Asp-2 + Mg+2 + H+1 = Mg+2_H+1_Gly-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.2(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:13.2(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:12.00(0.01SD)	3	ETS	94

Reaction No. 47189							
H+1 + Mg+2 + His-1 + Asp-2 = Mg+2_H+1_His-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.90(0.01SD)	3	ETS	94

Reaction No. 47190							
H+1 + Mg+2 + Pro-1 + Asp-2 = Mg+2_H+1_Pro-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.85(0.01SD)	3	ETS	94

Reaction No. 47191							
H+1 + Mg+2 + Ser-1 + Asp-2 = Mg+2_H+1_Ser-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.65(0.01SD)	3	ETS	94

Reaction No. 47192							
H+1 + Mg+2 + Thr-1 + Asp-2 = Mg+2_H+1_Thr-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.60(0.01SD)	3	ETS	94

Reaction No. 47193							
H+1 + Mg+2 + Val-1 + Asp-2 = Mg+2_H+1_Val-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.75(0.01SD)	3	ETS	94

Reaction No. 47194							
Citric-3 + Asp-2 + Mg+2 + H+1 = Mg+2_H+1_Asp-2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.1(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:14.1(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:12.40(0.01SD)	3	ETS	94

Reaction No. 47195							
H+1 + Mg+2 + Lactic-1 + Asp-2 = Mg+2_H+1_Lactic-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.25(0.01SD)	3	ETS	94

Reaction No. 47196							
H+1 + Mg+2 + Malic-2 + Asp-2 = Mg+2_H+1_Asp-2_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.35(0.01SD)	3	ETS	94

Reaction No. 47197							
Oxalic-2 + Asp-2 + Mg+2 + H+1 = Mg+2_H+1_Asp-2_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.7(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:13.7(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:12.25(0.01SD)	3	ETS	94

Reaction No. 47198							
H+1 + Mg+2 + Succinic-2 + Asp-2 = Mg+2_H+1_Asp-2_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.40(0.01SD)	3	ETS	94

Reaction No. 47199							
2<H+1> + Mg+2 + Ala-1 + Asp-2 = Mg+2_H+1(2)_Ala-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.45(0.01SD)	3	ETS	94

Reaction No. 47200							
2<H+1> + Mg+2 + bAla-1 + Asp-2 = Mg+2_H+1(2)_bAla-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:20.10(0.01SD)	3	ETS	94

Reaction No. 47201							
2<H+1> + Mg+2 + Arg-1 + Asp-2 = Mg+2_H+1(2)_Arg-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.85(0.01SD)	3	ETS	94

Reaction No. 47202							
2<H+1> + Mg+2 + Asn-1 + Asp-2 = Mg+2_H+1(2)_Asn-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.70(0.01SD)	3	ETS	94

Reaction No. 47203							
H+1 + Mg+2 + Gln-1 + Citrul-1 = Mg+2_H+1_Citrul-1_Gln-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.90(0.01SD)	3	ETS	94

Reaction No. 47204							
Gly-1 + Citrul-1 + Mg+2 + H+1 = Mg+2_H+1_Citrul-1_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:12.2(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:11.50(0.01SD)	3	ETS	94

Reaction No. 47205							
H+1 + Mg+2 + Pro-1 + Citrul-1 = Mg+2_H+1_Citrul-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.35(0.01SD)	3	ETS	94

Reaction No. 47206							
H+1 + Mg+2 + Thr-1 + Citrul-1 = Mg+2_H+1_Citrul-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.95(0.01SD)	3	ETS	94

Reaction No. 47207							
H+1 + Mg+2 + Val-1 + Citrul-1 = Mg+2_H+1_Citrul-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.25(0.01SD)	3	ETS	94

Reaction No. 47208							
H+1 + Mg+2 + Citric-3 + Citrul-1 = Mg+2_H+1_Citrul-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.75(0.01SD)	3	ETS	94

Reaction No. 47209							
H+1 + Mg+2 + Lactic-1 + Citrul-1 = Mg+2_H+1_Citrul-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.60(0.01SD)	3	ETS	94

Reaction No. 47210							
H+1 + Mg+2 + Malic-2 + Citrul-1 = Mg+2_H+1_Citrul-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.70(0.01SD)	3	ETS	94

Reaction No. 47211							
Oxalic-2 + Citrul-1 + Mg+2 + H+1 = Mg+2_H+1_Citrul-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.8(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:12.8(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:11.60(0.01SD)	3	ETS	94

Reaction No. 47212							
H+1 + Mg+2 + Succinic-2 + Citrul-1 = Mg+2_H+1_Citrul-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.75(0.01SD)	3	ETS	94

Reaction No. 47213							
2<H+1> + Mg+2 + Ala-1 + Citrul-1 = Mg+2_H+1(2)_Ala-1_Citrul-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80(0.01SD)	3	ETS	94

Reaction No. 47214							
2<H+1> + Mg+2 + Arg-1 + Citrul-1 = Mg+2_H+1(2)_Arg-1_Citrul-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.20(0.01SD)	3	ETS	94

Reaction No. 47215							
2<H+1> + Mg+2 + Asn-1 + Citrul-1 = Mg+2_H+1(2)_Asn-1_Citrul-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.05(0.01SD)	3	ETS	94

Reaction No. 47216							
2<H+1> + Mg+2 + Asp-2 + Citrul-1 = Mg+2_H+1(2)_Citrul-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.75(0.01SD)	3	ETS	94

Reaction No. 47217							
H+1 + Mg+2 + Citric-3 + Cys-2 = Mg+2_H+1_Cys-2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.35(0.01SD)	3	ETS	94

Reaction No. 47218							
--------------------	--	--	--	--	--	--	--

H+1 + Mg+2 + Lactic-1 + Cys-2 = Mg+2_H+1_Lactic-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.20 (0.01SD)	3	ETS	94

Reaction No. 47219							
Oxalic-2 + Cys-2 + Mg+2 + H+1 = Mg+2_H+1_Cys-2_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.6 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:14.6 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:13.20 (0.01SD)	3	ETS	94

Reaction No. 47220							
H+1 + Mg+2 + Succinic-2 + Cys-2 = Mg+2_H+1_Cys-2_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.35 (0.01SD)	3	ETS	94

Reaction No. 47221							
2<H+1> + Mg+2 + Ala-1 + Cys-2 = Mg+2_H+1(2)_Ala-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.40 (0.01SD)	3	ETS	94

Reaction No. 47222							
2<H+1> + Mg+2 + Arg-1 + Cys-2 = Mg+2_H+1(2)_Arg-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.80 (0.01SD)	3	ETS	94

Reaction No. 47223							
H+1 + Mg+2 + Gln-1 + Cis-2 = Mg+2_H+1_Gln-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.40 (0.01SD)	3	ETS	94

Reaction No. 47224							
--------------------	--	--	--	--	--	--	--

H+1 + Mg+2 + Thr-1 + Cis-2 = Mg+2_H+1_Thr-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.45(0.01SD)	3	ETS	94

Reaction No. 47225							
Citric-3 + Cis-2 + Mg+2 + H+1 = Mg+2_H+1_Cis-2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.0(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:14.0(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:12.35(0.01SD)	3	ETS	94

Reaction No. 47226							
H+1 + Mg+2 + Lactic-1 + Cis-2 = Mg+2_H+1_Lactic-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.20(0.01SD)	3	ETS	94

Reaction No. 47227							
H+1 + Mg+2 + Malic-2 + Cis-2 = Mg+2_H+1_Cis-2_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.30(0.01SD)	3	ETS	94

Reaction No. 47228							
Oxalic-2 + Cis-2 + Mg+2 + H+1 = Mg+2_H+1_Cis-2_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.6(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:13.6(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:12.20(0.01SD)	3	ETS	94

Reaction No. 47229							
H+1 + Mg+2 + Succinic-2 + Cis-2 = Mg+2_H+1_Cis-2_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.35(0.01SD)	3	ETS	94

Reaction No. 47230							
2<H+1> + Mg+2 + Ala-1 + Cis-2 = Mg+2_H+1(2)_Ala-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.40(0.01SD)	3	ETS	94

Reaction No. 47231							
2<H+1> + Mg+2 + bAla-1 + Cis-2 = Mg+2_H+1(2)_bAla-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:20.05(0.01SD)	3	ETS	94

Reaction No. 47232							
2<H+1> + Mg+2 + Arg-1 + Cis-2 = Mg+2_H+1(2)_Arg-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80(0.01SD)	3	ETS	94

Reaction No. 47233							
2<H+1> + Mg+2 + Asn-1 + Cis-2 = Mg+2_H+1(2)_Asn-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.65(0.01SD)	3	ETS	94

Reaction No. 47234							
2<H+1> + Mg+2 + Asp-2 + Cis-2 = Mg+2_H+1(2)_Asp-2_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.35(0.01SD)	3	ETS	94

Reaction No. 47235							
2<H+1> + Mg+2 + Citrul-1 + Cis-2 = Mg+2_H+1(2)_Citrul-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.70(0.01SD)	3	ETS	94

Reaction No. 47236							
--------------------	--	--	--	--	--	--	--

H+1 + Mg+2 + Gln-1 + Glu-2 = Mg+2_H+1_Gln-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.55(0.01SD)	3	ETS	94

Reaction No. 47237							
H+1 + Mg+2 + Thr-1 + Glu-2 = Mg+2_H+1_Thr-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.60(0.01SD)	3	ETS	94

Reaction No. 47238							
H+1 + Mg+2 + Citric-3 + Glu-2 = Mg+2_H+1_Glu-2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.50(0.01SD)	3	ETS	94

Reaction No. 47239							
H+1 + Mg+2 + Lactic-1 + Glu-2 = Mg+2_H+1_Lactic-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.35(0.01SD)	3	ETS	94

Reaction No. 47240							
H+1 + Mg+2 + Malic-2 + Glu-2 = Mg+2_H+1_Glu-2_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.45(0.01SD)	3	ETS	94

Reaction No. 47241							
Oxalic-2 + Glu-2 + Mg+2 + H+1 = Mg+2_H+1_Glu-2_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.8(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:13.8(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:12.35(0.01SD)	3	ETS	94

Reaction No. 47242							
--------------------	--	--	--	--	--	--	--

H+1 + Mg+2 + Succinic-2 + Glu-2 = Mg+2_H+1_Glu-2_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.50(0.01SD)	3	ETS	94

Reaction No. 47243							
2<H+1> + Mg+2 + Ala-1 + Glu-2 = Mg+2_H+1(2)_Ala-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.55(0.01SD)	3	ETS	94

Reaction No. 47244							
2<H+1> + Mg+2 + bAla-1 + Glu-2 = Mg+2_H+1(2)_bAla-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.7(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:20.20(0.01SD)	3	ETS	94

Reaction No. 47245							
2<H+1> + Mg+2 + Arg-1 + Glu-2 = Mg+2_H+1(2)_Arg-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.95(0.01SD)	3	ETS	94


Reaction No. 47246							
2<H+1> + Mg+2 + Asn-1 + Glu-2 = Mg+2_H+1(2)_Asn-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80(0.01SD)	3	ETS	94

Reaction No. 47247							
2<H+1> + Mg+2 + Asp-2 + Glu-2 = Mg+2_H+1(2)_Asp-2_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.50(0.01SD)	3	ETS	94

Reaction No. 47248							
2<H+1> + Mg+2 + Citrul-1 + Glu-2 = Mg+2_H+1(2)_Citrul-1_Glu-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.85(0.01SD)	3	ETS	94

Reaction No. 47249




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.45(0.01SD)	3	ETS	94

Reaction No. 47250




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:12.4(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:11.65(0.01SD)	3	ETS	94

Reaction No. 47251




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.30(0.01SD)	3	ETS	94

Reaction No. 47252




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.40(0.01SD)	3	ETS	94

Reaction No. 47253




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.45(0.01SD)	3	ETS	94

Reaction No. 47254




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.45 (0.01SD)	3	ETS	94

Reaction No. 47255




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.18 (0.01SD)	3	ETS	94

Reaction No. 47256




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.13 (0.01SD)	3	ETS	94

Reaction No. 47257




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.50 (0.01SD)	3	ETS	94

Reaction No. 47258




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.13 (0.01SD)	3	ETS	94

Reaction No. 47259



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.00 (0.01SD)	3	ETS	94


Reaction No. 47260



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:12.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.25 (0.01SD)	3	ETS	94

Reaction No. 47261




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.40 (0.01SD)	3	ETS	94

Reaction No. 47262




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.80 (0.01SD)	3	ETS	94

Reaction No. 47263




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.65 (0.01SD)	3	ETS	94

Reaction No. 47264




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.75 (0.01SD)	3	ETS	94

Reaction No. 47265



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.8 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:12.8 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:11.65 (0.01SD)	3	ETS	94


Reaction No. 47266



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.80(0.01SD)	3	ETS	94

Reaction No. 47267




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.85(0.01SD)	3	ETS	94

Reaction No. 47268




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.50(0.01SD)	3	ETS	94

Reaction No. 47269




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.25(0.01SD)	3	ETS	94

Reaction No. 47270




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.10(0.01SD)	3	ETS	94

Reaction No. 47271



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80(0.01SD)	3	ETS	94


Reaction No. 47272



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:19.15(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 47273




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.75(0.01SD)	3	ETS	94

Reaction No. 47274




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.75(0.01SD)	3	ETS	94

Reaction No. 47275




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.90(0.01SD)	3	ETS	94

Reaction No. 47276




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.90(0.01SD)	3	ETS	94

Reaction No. 47277



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.75(0.01SD)	3	ETS	94

Reaction No. 47278



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.70(0.01SD)	3	ETS	94

Reaction No. 47279							
H+1 + Mg+2 + Ser-1 + Gly-1 = Mg+2_H+1_Gly-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.65 (0.01SD)	3	ETS	94

Reaction No. 47280							
H+1 + Mg+2 + Thr-1 + Gly-1 = Mg+2_H+1_Gly-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.60 (0.01SD)	3	ETS	94

Reaction No. 47281							
H+1 + Mg+2 + Trp-1 + Gly-1 = Mg+2_H+1_Gly-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.70 (0.01SD)	3	ETS	94

Reaction No. 47282							
H+1 + Mg+2 + Citric-3 + Gly-1 = Mg+2_H+1_Gly-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.50 (0.01SD)	3	ETS	94

Reaction No. 47283							
H+1 + Mg+2 + Lactic-1 + Gly-1 = Mg+2_H+1_Gly-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.35 (0.01SD)	3	ETS	94

Reaction No. 47284							
H+1 + Mg+2 + Malic-2 + Gly-1 = Mg+2_H+1_Gly-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.45 (0.01SD)	3	ETS	94

Reaction No. 47285							
--------------------	--	--	--	--	--	--	--

H+1 + Mg+2 + Oxalic-2 + Gly-1 = Mg+2_H+1_Gly-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.35(0.01SD)	3	ETS	94

Reaction No. 47286							
H+1 + Mg+2 + Succinic-2 + Gly-1 = Mg+2_H+1_Gly-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.50(0.01SD)	3	ETS	94

Reaction No. 47287							
2<H+1> + Mg+2 + Ala-1 + Gly-1 = Mg+2_H+1(2)_Ala-1_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.55(0.01SD)	3	ETS	94

Reaction No. 47288							
2<H+1> + Mg+2 + bAla-1 + Gly-1 = Mg+2_H+1(2)_bAla-1_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.7(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:20.20(0.01SD)	3	ETS	94

Reaction No. 47289							
2<H+1> + Mg+2 + Arg-1 + Gly-1 = Mg+2_H+1(2)_Arg-1_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.95(0.01SD)	3	ETS	94

Reaction No. 47290							
Gly-1 + Asn-1 + Mg+2 + 2<H+1> = Mg+2_H+1(2)_Asn-1_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:19.80(0.01SD)	3	ETS	94

Reaction No. 47291							
--------------------	--	--	--	--	--	--	--

Gly-1 + Asp-2 + Mg+2 + 2<H+1> = Mg+2_H+1(2)_Gly-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.7(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:21.7(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:20.50(0.01SD)	3	ETS	94

Reaction No. 47292							
Gly-1 + Citrul-1 + Mg+2 + 2<H+1> = Mg+2_H+1(2)_Citrul-1_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:19.85(0.01SD)	3	ETS	94

Reaction No. 47293							
Gly-1 + Cys-2 + Mg+2 + 2<H+1> = Mg+2_H+1(2)_Gly-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.6(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:22.6(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:21.45(0.01SD)	3	ETS	94


Reaction No. 47294							
Gly-1 + Cis-2 + Mg+2 + 2<H+1> = Mg+2_H+1(2)_Gly-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.6(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:21.6(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:20.45(0.01SD)	3	ETS	94

Reaction No. 47295							
Gly-1 + Glu-2 + Mg+2 + 2<H+1> = Mg+2_H+1(2)_Gly-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.8(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:21.8(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:20.60(0.01SD)	3	ETS	94

Reaction No. 47296							
Gly-1 + Gln-1 + Mg+2 + 2<H+1> = Mg+2_H+1(2)_Gln-1_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:20.4 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:20.4 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:19.90 (0.01SD)	3	ETS	94

Reaction No. 47297




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.80 (0.01SD)	3	ETS	94

Reaction No. 47298




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.85 (0.01SD)	3	ETS	94

Reaction No. 47299




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.38 (0.01SD)	3	ETS	94

Reaction No. 47300




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.33 (0.01SD)	3	ETS	94

Reaction No. 47301



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.65 (0.01SD)	3	ETS	94


Reaction No. 47302



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:13.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.00 (0.01SD)	3	ETS	94

Reaction No. 47303




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.85 (0.01SD)	3	ETS	94

Reaction No. 47304




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.95 (0.01SD)	3	ETS	94

Reaction No. 47305




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.0 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:13.0 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:11.85 (0.01SD)	3	ETS	94

Reaction No. 47306




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.00 (0.01SD)	3	ETS	94

Reaction No. 47307



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.05 (0.01SD)	3	ETS	94


Reaction No. 47308



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:20.2 (3SF)	1	EAE	
2	25	0	Inf. Dilution	lgK:20.1 (3SF)	1	ESC	
3	37	0.15	Blood Plasma	lgK:19.70 (0.01SD)	3	ETS	94

Reaction No. 47309




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.45 (0.01SD)	3	ETS	94

Reaction No. 47310




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.30 (0.01SD)	3	ETS	94

Reaction No. 47311




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.00 (0.01SD)	3	ETS	94

Reaction No. 47312




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.35 (0.01SD)	3	ETS	94

Reaction No. 47313



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.95 (0.01SD)	3	ETS	94


Reaction No. 47314



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:21.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.95(0.01SD)	3	ETS	94

Reaction No. 47315




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.10(0.01SD)	3	ETS	94

Reaction No. 47316




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.40(0.01SD)	3	ETS	94

Reaction No. 47317




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.10(0.01SD)	3	ETS	94

Reaction No. 47318




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.25(0.01SD)	3	ETS	94

Reaction No. 47319



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.10(0.01SD)	3	ETS	94


Reaction No. 47320



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:11.20 (0.01SD)	3	ETS	94
---	----	------	--------------	--------------------	---	-----	----

Reaction No. 47321




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.3 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:13.3 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:12.10 (0.01SD)	3	ETS	94

Reaction No. 47322




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.25 (0.01SD)	3	ETS	94

Reaction No. 47323




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.30 (0.01SD)	3	ETS	94

Reaction No. 47324




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.70 (0.01SD)	3	ETS	94

Reaction No. 47325



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.55 (0.01SD)	3	ETS	94


Reaction No. 47326



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1 (3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:19.60 (0.01SD)	3	ETS	94
---	----	------	--------------	--------------------	---	-----	----

Reaction No. 47327




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.20 (0.01SD)	3	ETS	94

Reaction No. 47328




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.35 (0.01SD)	3	ETS	94

Reaction No. 47329




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.65 (0.01SD)	3	ETS	94

Reaction No. 47330




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.35 (0.01SD)	3	ETS	94

Reaction No. 47331



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.85 (0.01SD)	3	ETS	94

Reaction No. 47332



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.50 (0.01SD)	3	ETS	94

Reaction No. 47333							
H+1 + Mg+2 + Citric-3 + Ile-1 = Mg+2_H+1_Ile-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.40(0.01SD)	3	ETS	94

Reaction No. 47334							
H+1 + Mg+2 + Lactic-1 + Ile-1 = Mg+2_H+1_Ile-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.25(0.01SD)	3	ETS	94

Reaction No. 47335							
H+1 + Mg+2 + Malic-2 + Ile-1 = Mg+2_H+1_Ile-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.35(0.01SD)	3	ETS	94

Reaction No. 47336							
Oxalic-2 + Ile-1 + Mg+2 + H+1 = Mg+2_H+1_Ile-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.4(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:13.4(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:12.25(0.01SD)	3	ETS	94

Reaction No. 47337							
H+1 + Mg+2 + Succinic-2 + Ile-1 = Mg+2_H+1_Ile-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.40(0.01SD)	3	ETS	94

Reaction No. 47338							
2<H+1> + Mg+2 + Ala-1 + Ile-1 = Mg+2_H+1(2)_Ala-1_Ile-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.45(0.01SD)	3	ETS	94

Reaction No. 47339							
$2\text{<H+1>} + \text{Mg}+2 + \text{bAla}-1 + \text{Ile}-1 = \text{Mg}+2_{\text{H}+1(2)}_{\text{bAla}-1_{\text{Ile}-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:20.10(0.01SD)	3	ETS	94

Reaction No. 47340							
$2\text{<H+1>} + \text{Mg}+2 + \text{Arg}-1 + \text{Ile}-1 = \text{Mg}+2_{\text{H}+1(2)}_{\text{Arg}-1_{\text{Ile}-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.85(0.01SD)	3	ETS	94

Reaction No. 47341							
$2\text{<H+1>} + \text{Mg}+2 + \text{Asn}-1 + \text{Ile}-1 = \text{Mg}+2_{\text{H}+1(2)}_{\text{Asn}-1_{\text{Ile}-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.70(0.01SD)	3	ETS	94

Reaction No. 47342							
$2\text{<H+1>} + \text{Mg}+2 + \text{Asp}-2 + \text{Ile}-1 = \text{Mg}+2_{\text{H}+1(2)}_{\text{Ile}-1_{\text{Asp}-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.40(0.01SD)	3	ETS	94

Reaction No. 47343							
$2\text{<H+1>} + \text{Mg}+2 + \text{Citru1}-1 + \text{Ile}-1 = \text{Mg}+2_{\text{H}+1(2)}_{\text{Citru1}-1_{\text{Ile}-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.75(0.01SD)	3	ETS	94

Reaction No. 47344							
$2\text{<H+1>} + \text{Mg}+2 + \text{Cis}-2 + \text{Ile}-1 = \text{Mg}+2_{\text{H}+1(2)}_{\text{Ile}-1_{\text{Cis}-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.35(0.01SD)	3	ETS	94

Reaction No. 47345							
--------------------	--	--	--	--	--	--	--

2<H+1> + Mg+2 + Glu-2 + Ile-1 = Mg+2_H+1(2)_Ile-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.50(0.01SD)	3	ETS	94

Reaction No. 47346							
2<H+1> + Mg+2 + Gln-1 + Ile-1 = Mg+2_H+1(2)_Gln-1_Ile-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80(0.01SD)	3	ETS	94

Reaction No. 47347							
2<H+1> + Mg+2 + Gly-1 + Ile-1 = Mg+2_H+1(2)_Gly-1_Ile-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.50(0.01SD)	3	ETS	94

Reaction No. 47348							
2<H+1> + Mg+2 + His-1 + Ile-1 = Mg+2_H+1(2)_His-1_Ile-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.00(0.01SD)	3	ETS	94


Reaction No. 47349							
2<H+1> + Mg+2 + Hyp-1 + Ile-1 = Mg+2_H+1(2)_Hyp-1_Ile-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.25(0.01SD)	3	ETS	94

Reaction No. 47350							
H+1 + Mg+2 + Thr-1 + Leu-1 = Mg+2_H+1_Leu-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.50(0.01SD)	3	ETS	94

Reaction No. 47351							
H+1 + Mg+2 + Citric-3 + Leu-1 = Mg+2_H+1_Leu-1_Citric-3							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.40(0.01SD)	3	ETS	94

Reaction No. 47352




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.25(0.01SD)	3	ETS	94

Reaction No. 47353




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.35(0.01SD)	3	ETS	94

Reaction No. 47354




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.4(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:13.4(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:12.25(0.01SD)	3	ETS	94

Reaction No. 47355




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.40(0.01SD)	3	ETS	94

Reaction No. 47356




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.45(0.01SD)	3	ETS	94

Reaction No. 47357




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:20.10(0.01SD)	3	ETS	94

Reaction No. 47358




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.85(0.01SD)	3	ETS	94

Reaction No. 47359




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.70(0.01SD)	3	ETS	94

Reaction No. 47360




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.40(0.01SD)	3	ETS	94

Reaction No. 47361




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.75(0.01SD)	3	ETS	94

Reaction No. 47362



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.35(0.01SD)	3	ETS	94


Reaction No. 47363



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:21.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.35 (0.01SD)	3	ETS	94

Reaction No. 47364




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.50 (0.01SD)	3	ETS	94

Reaction No. 47365




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80 (0.01SD)	3	ETS	94

Reaction No. 47366




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.50 (0.01SD)	3	ETS	94

Reaction No. 47367




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.00 (0.01SD)	3	ETS	94

Reaction No. 47368



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.25 (0.01SD)	3	ETS	94


Reaction No. 47369



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.9 (3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:20.40(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 47370




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.70(0.01SD)	3	ETS	94

Reaction No. 47371




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.55(0.01SD)	3	ETS	94

Reaction No. 47372




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.7(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:14.7(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:13.55(0.01SD)	3	ETS	94

Reaction No. 47373




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.70(0.01SD)	3	ETS	94

Reaction No. 47374



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.10(0.01SD)	3	ETS	94


Reaction No. 47375



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.3(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:12.60 (0.01SD)	3	ETS	94
---	----	------	--------------	--------------------	---	-----	----

Reaction No. 47376




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.10 (0.01SD)	3	ETS	94

Reaction No. 47377




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.50 (0.01SD)	3	ETS	94

Reaction No. 47378




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.90 (0.01SD)	3	ETS	94

Reaction No. 47379




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.75 (0.01SD)	3	ETS	94

Reaction No. 47380



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.85 (0.01SD)	3	ETS	94


Reaction No. 47381



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.9 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:12.9 (3SF)	2	EAE	


3	37	0.15	Blood Plasma	lgK:11.75 (0.01SD)	3	ETS	94
---	----	------	--------------	--------------------	---	-----	----

Reaction No. 47382




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.90 (0.01SD)	3	ETS	94

Reaction No. 47383




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.95 (0.01SD)	3	ETS	94

Reaction No. 47384




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.35 (0.01SD)	3	ETS	94

Reaction No. 47385




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.20 (0.01SD)	3	ETS	94

Reaction No. 47386



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.90 (0.01SD)	3	ETS	94

Reaction No. 47387



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.25 (0.01SD)	3	ETS	94

Reaction No. 47388							
2<H+1> + Mg+2 + Cis-2 + Met-1 = Mg+2_H+1(2)_Met-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.85(0.01SD)	3	ETS	94

Reaction No. 47389							
2<H+1> + Mg+2 + Glu-2 + Met-1 = Mg+2_H+1(2)_Met-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.00(0.01SD)	3	ETS	94

Reaction No. 47390							
2<H+1> + Mg+2 + Gln-1 + Met-1 = Mg+2_H+1(2)_Gln-1_Met-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.30(0.01SD)	3	ETS	94

Reaction No. 47391							
2<H+1> + Mg+2 + Gly-1 + Met-1 = Mg+2_H+1(2)_Gly-1_Met-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.00(0.01SD)	3	ETS	94

Reaction No. 47392							
2<H+1> + Mg+2 + His-1 + Met-1 = Mg+2_H+1(2)_His-1_Met-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.50(0.01SD)	3	ETS	94

Reaction No. 47393							
2<H+1> + Mg+2 + Hyp-1 + Met-1 = Mg+2_H+1(2)_Hyp-1_Met-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.75(0.01SD)	3	ETS	94

Reaction No. 47394							
--------------------	--	--	--	--	--	--	--

2<H+1> + Mg+2 + Ile-1 + Met-1 = Mg+2_H+1(2)_Ile-1_Met-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.90 (0.01SD)	3	ETS	94

Reaction No. 47395							
2<H+1> + Mg+2 + Leu-1 + Met-1 = Mg+2_H+1(2)_Leu-1_Met-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.90 (0.01SD)	3	ETS	94

Reaction No. 47396							
H+1 + Mg+2 + Citric-3 + Orn-1 = Mg+2_H+1_Orn-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.45 (0.01SD)	3	ETS	94

Reaction No. 47397							
H+1 + Mg+2 + Lactic-1 + Orn-1 = Mg+2_H+1_Lactic-1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.30 (0.01SD)	3	ETS	94

Reaction No. 47398							
Oxalic-2 + Orn-1 + Mg+2 + H+1 = Mg+2_H+1_Orn-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.5 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:14.5 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:13.30 (0.01SD)	3	ETS	94

Reaction No. 47399							
2<H+1> + Mg+2 + Ala-1 + Orn-1 = Mg+2_H+1(2)_Ala-1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.50 (0.01SD)	3	ETS	94

Reaction No. 47400							
--------------------	--	--	--	--	--	--	--

2<H+1> + Mg+2 + Gln-1 + Orn-1 = Mg+2_H+1(2)_Gln-1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.85(0.01SD)	3	ETS	94

Reaction No. 47401							
2<H+1> + Mg+2 + Gly-1 + Orn-1 = Mg+2_H+1(2)_Gly-1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.55(0.01SD)	3	ETS	94

Reaction No. 47402							
H+1 + Mg+2 + Pro-1 + Phe-1 = Mg+2_H+1_Phe-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.55(0.01SD)	3	ETS	94

Reaction No. 47403							
H+1 + Mg+2 + Thr-1 + Phe-1 = Mg+2_H+1_Phe-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.05(0.01SD)	3	ETS	94


Reaction No. 47404							
H+1 + Mg+2 + Val-1 + Phe-1 = Mg+2_H+1_Phe-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.45(0.01SD)	3	ETS	94

Reaction No. 47405							
H+1 + Mg+2 + Citric-3 + Phe-1 = Mg+2_H+1_Phe-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.85(0.01SD)	3	ETS	94

Reaction No. 47406							
H+1 + Mg+2 + Lactic-1 + Phe-1 = Mg+2_H+1_Lactic-1_Phe-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.70 (0.01SD)	3	ETS	94

Reaction No. 47407




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.80 (0.01SD)	3	ETS	94

Reaction No. 47408




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.9 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.70 (0.01SD)	3	ETS	94

Reaction No. 47409




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.85 (0.01SD)	3	ETS	94

Reaction No. 47410




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.90 (0.01SD)	3	ETS	94

Reaction No. 47411



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1 (3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.55 (0.01SD)	3	ETS	94


Reaction No. 47412



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.30(0.01SD)	3	ETS	94

Reaction No. 47413




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.15(0.01SD)	3	ETS	94

Reaction No. 47414




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.85(0.01SD)	3	ETS	94

Reaction No. 47415




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.20(0.01SD)	3	ETS	94

Reaction No. 47416




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80(0.01SD)	3	ETS	94

Reaction No. 47417



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.95(0.01SD)	3	ETS	94


Reaction No. 47418



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:19.25(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 47419




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.95(0.01SD)	3	ETS	94

Reaction No. 47420




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.45(0.01SD)	3	ETS	94

Reaction No. 47421




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.70(0.01SD)	3	ETS	94

Reaction No. 47422




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.85(0.01SD)	3	ETS	94

Reaction No. 47423



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.85(0.01SD)	3	ETS	94

Reaction No. 47424



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.35(0.01SD)	3	ETS	94

Reaction No. 47425							
H+1 + Mg+2 + Ser-1 + Pro-1 = Mg+2_H+1_Pro-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.60(0.01SD)	3	ETS	94

Reaction No. 47426							
H+1 + Mg+2 + Thr-1 + Pro-1 = Mg+2_H+1_Pro-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.55(0.01SD)	3	ETS	94

Reaction No. 47427							
H+1 + Mg+2 + Citric-3 + Pro-1 = Mg+2_H+1_Pro-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.45(0.01SD)	3	ETS	94

Reaction No. 47428							
H+1 + Mg+2 + Lactic-1 + Pro-1 = Mg+2_H+1_Lactic-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.30(0.01SD)	3	ETS	94

Reaction No. 47429							
H+1 + Mg+2 + Malic-2 + Pro-1 = Mg+2_H+1_Pro-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.40(0.01SD)	3	ETS	94

Reaction No. 47430							
H+1 + Mg+2 + Oxalic-2 + Pro-1 = Mg+2_H+1_Pro-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.30(0.01SD)	3	ETS	94

Reaction No. 47431							
--------------------	--	--	--	--	--	--	--

H+1 + Mg+2 + Succinic-2 + Pro-1 = Mg+2_H+1_Pro-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.45(0.01SD)	3	ETS	94

Reaction No. 47432							
2<H+1> + Mg+2 + Ala-1 + Pro-1 = Mg+2_H+1(2)_Ala-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.50(0.01SD)	3	ETS	94

Reaction No. 47433							
2<H+1> + Mg+2 + bAla-1 + Pro-1 = Mg+2_H+1(2)_bAla-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.7(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:21.15(0.01SD)	3	ETS	94

Reaction No. 47434							
2<H+1> + Mg+2 + Arg-1 + Pro-1 = Mg+2_H+1(2)_Arg-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.90(0.01SD)	3	ETS	94


Reaction No. 47435							
2<H+1> + Mg+2 + Asn-1 + Pro-1 = Mg+2_H+1(2)_Asn-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.75(0.01SD)	3	ETS	94

Reaction No. 47436							
2<H+1> + Mg+2 + Asp-2 + Pro-1 = Mg+2_H+1(2)_Pro-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.45(0.01SD)	3	ETS	94

Reaction No. 47437							
2<H+1> + Mg+2 + Citrul-1 + Pro-1 = Mg+2_H+1(2)_Citrul-1_Pro-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.80(0.01SD)	3	ETS	94

Reaction No. 47438




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.40(0.01SD)	3	ETS	94

Reaction No. 47439




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.40(0.01SD)	3	ETS	94

Reaction No. 47440




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.55(0.01SD)	3	ETS	94

Reaction No. 47441




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.85(0.01SD)	3	ETS	94

Reaction No. 47442



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.55(0.01SD)	3	ETS	94


Reaction No. 47443



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:21.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.05 (0.01SD)	3	ETS	94

Reaction No. 47444




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.30 (0.01SD)	3	ETS	94

Reaction No. 47445




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.9 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.45 (0.01SD)	3	ETS	94

Reaction No. 47446




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.9 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.45 (0.01SD)	3	ETS	94

Reaction No. 47447




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.95 (0.01SD)	3	ETS	94

Reaction No. 47448



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.50 (0.01SD)	3	ETS	94


Reaction No. 47449



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.4 (3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:20.90(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 47450




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.13(0.01SD)	3	ETS	94

Reaction No. 47451




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.40(0.01SD)	3	ETS	94

Reaction No. 47452




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.80(0.01SD)	3	ETS	94

Reaction No. 47453




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.65(0.01SD)	3	ETS	94

Reaction No. 47454



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.75(0.01SD)	3	ETS	94

Reaction No. 47455



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.65(0.01SD)	3	ETS	94

Reaction No. 47456							
H+1 + Mg+2 + Succinic-2 + Ser-1 = Mg+2_H+1_Ser-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.80(0.01SD)	3	ETS	94

Reaction No. 47457							
2<H+1> + Mg+2 + Ala-1 + Ser-1 = Mg+2_H+1(2)_Ala-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.85(0.01SD)	3	ETS	94

Reaction No. 47458							
2<H+1> + Mg+2 + bAla-1 + Ser-1 = Mg+2_H+1(2)_bAla-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.50(0.01SD)	3	ETS	94

Reaction No. 47459							
2<H+1> + Mg+2 + Arg-1 + Ser-1 = Mg+2_H+1(2)_Arg-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.25(0.01SD)	3	ETS	94

Reaction No. 47460							
2<H+1> + Mg+2 + Asn-1 + Ser-1 = Mg+2_H+1(2)_Asn-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.10(0.01SD)	3	ETS	94

Reaction No. 47461							
2<H+1> + Mg+2 + Asp-2 + Ser-1 = Mg+2_H+1(2)_Ser-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80(0.01SD)	3	ETS	94

Reaction No. 47462							
--------------------	--	--	--	--	--	--	--

2<H+1> + Mg+2 + Citrul-1 + Ser-1 = Mg+2_H+1(2)_Citrul-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.15(0.01SD)	3	ETS	94

Reaction No. 47463							
2<H+1> + Mg+2 + Cys-2 + Ser-1 = Mg+2_H+1(2)_Ser-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.75(0.01SD)	3	ETS	94

Reaction No. 47464							
2<H+1> + Mg+2 + Cis-2 + Ser-1 = Mg+2_H+1(2)_Ser-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.75(0.01SD)	3	ETS	94

Reaction No. 47465							
2<H+1> + Mg+2 + Glu-2 + Ser-1 = Mg+2_H+1(2)_Ser-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.90(0.01SD)	3	ETS	94


Reaction No. 47466							
2<H+1> + Mg+2 + Gln-1 + Ser-1 = Mg+2_H+1(2)_Gln-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.20(0.01SD)	3	ETS	94

Reaction No. 47467							
2<H+1> + Mg+2 + Gly-1 + Ser-1 = Mg+2_H+1(2)_Gly-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.90(0.01SD)	3	ETS	94

Reaction No. 47468							
2<H+1> + Mg+2 + His-1 + Ser-1 = Mg+2_H+1(2)_His-1_Ser-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.40(0.01SD)	3	ETS	94

Reaction No. 47469




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.65(0.01SD)	3	ETS	94

Reaction No. 47470




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80(0.01SD)	3	ETS	94

Reaction No. 47471




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80(0.01SD)	3	ETS	94

Reaction No. 47472




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.30(0.01SD)	3	ETS	94

Reaction No. 47473



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.25(0.01SD)	3	ETS	94


Reaction No. 47474



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:21.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.85 (0.01SD)	3	ETS	94

Reaction No. 47475




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.30 (0.01SD)	3	ETS	94

Reaction No. 47476




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.35 (0.01SD)	3	ETS	94

Reaction No. 47477




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.70 (0.01SD)	3	ETS	94

Reaction No. 47478




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.55 (0.01SD)	3	ETS	94

Reaction No. 47479



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.65 (0.01SD)	3	ETS	94


Reaction No. 47480



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.7 (3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:11.55(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 47481




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.70(0.01SD)	3	ETS	94

Reaction No. 47482




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.75(0.01SD)	3	ETS	94

Reaction No. 47483




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.40(0.01SD)	3	ETS	94

Reaction No. 47484




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.15(0.01SD)	3	ETS	94

Reaction No. 47485



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.00(0.01SD)	3	ETS	94

Reaction No. 47486



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.70(0.01SD)	3	ETS	94

Reaction No. 47487							
$2\text{<H+1>} + \text{Mg+2} + \text{Citrul-1} + \text{Thr-1} = \text{Mg+2_H+1(2)_Citrul-1_Thr-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.05(0.01SD)	3	ETS	94

Reaction No. 47488							
$2\text{<H+1>} + \text{Mg+2} + \text{Cys-2} + \text{Thr-1} = \text{Mg+2_H+1(2)_Thr-1_Cys-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.65(0.01SD)	3	ETS	94

Reaction No. 47489							
$2\text{<H+1>} + \text{Mg+2} + \text{Cis-2} + \text{Thr-1} = \text{Mg+2_H+1(2)_Thr-1_Cis-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.65(0.01SD)	3	ETS	94

Reaction No. 47490							
$2\text{<H+1>} + \text{Mg+2} + \text{Glu-2} + \text{Thr-1} = \text{Mg+2_H+1(2)_Thr-1_Glu-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80(0.01SD)	3	ETS	94

Reaction No. 47491							
$2\text{<H+1>} + \text{Mg+2} + \text{Gln-1} + \text{Thr-1} = \text{Mg+2_H+1(2)_Gln-1_Thr-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.10(0.01SD)	3	ETS	94

Reaction No. 47492							
$2\text{<H+1>} + \text{Mg+2} + \text{Gly-1} + \text{Thr-1} = \text{Mg+2_H+1(2)_Gly-1_Thr-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.80(0.01SD)	3	ETS	94

Reaction No. 47493							
--------------------	--	--	--	--	--	--	--

2<H+1> + Mg+2 + His-1 + Thr-1 = Mg+2_H+1(2)_His-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.30(0.01SD)	3	ETS	94

Reaction No. 47494							
2<H+1> + Mg+2 + Hyp-1 + Thr-1 = Mg+2_H+1(2)_Hyp-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.55(0.01SD)	3	ETS	94

Reaction No. 47495							
2<H+1> + Mg+2 + Ile-1 + Thr-1 = Mg+2_H+1(2)_Ile-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.70(0.01SD)	3	ETS	94

Reaction No. 47496							
2<H+1> + Mg+2 + Leu-1 + Thr-1 = Mg+2_H+1(2)_Leu-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.70(0.01SD)	3	ETS	94


Reaction No. 47497							
2<H+1> + Mg+2 + Met-1 + Thr-1 = Mg+2_H+1(2)_Met-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.20(0.01SD)	3	ETS	94

Reaction No. 47498							
2<H+1> + Mg+2 + Phe-1 + Thr-1 = Mg+2_H+1(2)_Phe-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.15(0.01SD)	3	ETS	94

Reaction No. 47499							
2<H+1> + Mg+2 + Pro-1 + Thr-1 = Mg+2_H+1(2)_Pro-1_Thr-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.75 (0.01SD)	3	ETS	94

Reaction No. 47500




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.10 (0.01SD)	3	ETS	94

Reaction No. 47501




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.10 (0.01SD)	3	ETS	94

Reaction No. 47502




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.95 (0.01SD)	3	ETS	94

Reaction No. 47503




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.05 (0.01SD)	3	ETS	94

Reaction No. 47504



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.95 (0.01SD)	3	ETS	94


Reaction No. 47505



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:12.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.10(0.01SD)	3	ETS	94

Reaction No. 47506




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.15(0.01SD)	3	ETS	94

Reaction No. 47507




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.55(0.01SD)	3	ETS	94

Reaction No. 47508




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.40(0.01SD)	3	ETS	94

Reaction No. 47509




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.45(0.01SD)	3	ETS	94

Reaction No. 47510



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.05(0.01SD)	3	ETS	94


Reaction No. 47511



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.4(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:20.20(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 47512




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.50(0.01SD)	3	ETS	94

Reaction No. 47513




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.20(0.01SD)	3	ETS	94

Reaction No. 47514




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.70(0.01SD)	3	ETS	94

Reaction No. 47515




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.10(0.01SD)	3	ETS	94

Reaction No. 47516



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.10(0.01SD)	3	ETS	94

Reaction No. 47517



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.60(0.01SD)	3	ETS	94

Reaction No. 47518							
2<H+1> + Mg+2 + Phe-1 + Trp-1 = Mg+2_H+1(2)_Phe-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.55(0.01SD)	3	ETS	94

Reaction No. 47519							
2<H+1> + Mg+2 + Pro-1 + Trp-1 = Mg+2_H+1(2)_Pro-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.15(0.01SD)	3	ETS	94

Reaction No. 47520							
2<H+1> + Mg+2 + Ser-1 + Trp-1 = Mg+2_H+1(2)_Ser-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.50(0.01SD)	3	ETS	94

Reaction No. 47521							
2<H+1> + Mg+2 + Thr-1 + Trp-1 = Mg+2_H+1(2)_Thr-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.40(0.01SD)	3	ETS	94

Reaction No. 47522							
H+1 + Mg+2 + Citric-3 + Tyr-2 = Mg+2_H+1_Tyr-2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.40(0.01SD)	3	ETS	94

Reaction No. 47523							
H+1 + Mg+2 + Lactic-1 + Tyr-2 = Mg+2_H+1_Lactic-1_Tyr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.25(0.01SD)	3	ETS	94

Reaction No. 47524							
--------------------	--	--	--	--	--	--	--

H+1 + Mg+2 + Oxalic-2 + Tyr-2 = Mg+2_H+1_Oxalic-2_Tyr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.25(0.01SD)	3	ETS	94

Reaction No. 47525							
2<H+1> + Mg+2 + Gln-1 + Tyr-2 = Mg+2_H+1(2)_Gln-1_Tyr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.80(0.01SD)	3	ETS	94

Reaction No. 47526							
H+1 + Mg+2 + Citric-3 + Val-1 = Mg+2_H+1_Val-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.25(0.01SD)	3	ETS	94

Reaction No. 47527							
H+1 + Mg+2 + Lactic-1 + Val-1 = Mg+2_H+1_Lactic-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.10(0.01SD)	3	ETS	94


Reaction No. 47528							
H+1 + Mg+2 + Malic-2 + Val-1 = Mg+2_H+1_Val-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.20(0.01SD)	3	ETS	94

Reaction No. 47529							
H+1 + Mg+2 + Oxalic-2 + Val-1 = Mg+2_H+1_Val-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.10(0.01SD)	3	ETS	94

Reaction No. 47530							
H+1 + Mg+2 + Succinic-2 + Val-1 = Mg+2_H+1_Val-1_Succinic-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.25 (0.01SD)	3	ETS	94

Reaction No. 47531




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.30 (0.01SD)	3	ETS	94

Reaction No. 47532




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.5 (3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:19.95 (0.01SD)	3	ETS	94

Reaction No. 47533




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.70 (0.01SD)	3	ETS	94

Reaction No. 47534




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.55 (0.01SD)	3	ETS	94

Reaction No. 47535



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.25 (0.01SD)	3	ETS	94


Reaction No. 47536



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:20.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.60(0.01SD)	3	ETS	94

Reaction No. 47537




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.20(0.01SD)	3	ETS	94

Reaction No. 47538




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.20(0.01SD)	3	ETS	94

Reaction No. 47539




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.35(0.01SD)	3	ETS	94

Reaction No. 47540




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.65(0.01SD)	3	ETS	94

Reaction No. 47541



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.35(0.01SD)	3	ETS	94


Reaction No. 47542



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.3(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:19.85(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 47543




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.10(0.01SD)	3	ETS	94

Reaction No. 47544




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.25(0.01SD)	3	ETS	94

Reaction No. 47545




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:20.25(0.01SD)	3	ETS	94

Reaction No. 47546




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.75(0.01SD)	3	ETS	94

Reaction No. 47547



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.70(0.01SD)	3	ETS	94

Reaction No. 47548



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.30(0.01SD)	3	ETS	94

Reaction No. 47549							
$2\text{<H+1>} + \text{Mg}+2 + \text{Ser}-1 + \text{Val}-1 = \text{Mg}+2_ \text{H}+1(2)_ \text{Ser}-1_ \text{Val}-1$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.65(0.01SD)	3	ETS	94

Reaction No. 47550							
$2\text{<H+1>} + \text{Mg}+2 + \text{Thr}-1 + \text{Val}-1 = \text{Mg}+2_ \text{H}+1(2)_ \text{Thr}-1_ \text{Val}-1$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.55(0.01SD)	3	ETS	94

Reaction No. 47551							
$2\text{<H+1>} + \text{Mg}+2 + \text{Trp}-1 + \text{Val}-1 = \text{Mg}+2_ \text{H}+1(2)_ \text{Trp}-1_ \text{Val}-1$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.95(0.01SD)	3	ETS	94

Reaction No. 47552							
$\text{H}+1 + \text{Mg}+2 + \text{Ala}-1 + \text{PO4}-3 = \text{Mg}+2_ \text{H}+1_ \text{Ala}-1_ \text{PO4}-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.05(0.01SD)	3	ETS	94

Reaction No. 47553							
$\text{H}+1 + \text{Mg}+2 + \text{bAla}-1 + \text{PO4}-3 = \text{Mg}+2_ \text{H}+1_ \text{bAla}-1_ \text{PO4}-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.5(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:14.05(0.01SD)	3	ETS	94

Reaction No. 47554							
$\text{H}+1 + \text{Mg}+2 + \text{Arg}-1 + \text{PO4}-3 = \text{Mg}+2_ \text{H}+1_ \text{Arg}-1_ \text{PO4}-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.10(0.01SD)	3	ETS	94

Reaction No. 47555							
--------------------	--	--	--	--	--	--	--

H+1 + Mg+2 + Asn-1 + PO4-3 = Mg+2_H+1_Asn-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.10(0.01SD)	3	ETS	94

Reaction No. 47556							
H+1 + Mg+2 + Asp-2 + PO4-3 = Mg+2_H+1_Asp-2_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.40(0.01SD)	3	ETS	94

Reaction No. 47557							
H+1 + Mg+2 + Citrul-1 + PO4-3 = Mg+2_H+1_Citrul-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.90(0.01SD)	3	ETS	94

Reaction No. 47558							
H+1 + Mg+2 + Glu-2 + PO4-3 = Mg+2_H+1_Glu-2_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.20(0.01SD)	3	ETS	94


Reaction No. 47559							
H+1 + Mg+2 + Gln-1 + PO4-3 = Mg+2_H+1_Gln-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.05(0.01SD)	3	ETS	94

Reaction No. 47560							
H+1 + Mg+2 + Gly-1 + PO4-3 = Mg+2_H+1_Gly-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.30(0.01SD)	3	ETS	94

Reaction No. 47561							
H+1 + Mg+2 + His-1 + PO4-3 = Mg+2_H+1_His-1_PO4-3							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.40(0.01SD)	3	ETS	94

Reaction No. 47562




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.10(0.01SD)	3	ETS	94

Reaction No. 47563




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.15(0.01SD)	3	ETS	94

Reaction No. 47564




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.10(0.01SD)	3	ETS	94

Reaction No. 47565




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.15(0.01SD)	3	ETS	94

Reaction No. 47566



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.10(0.01SD)	3	ETS	94


Reaction No. 47567



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:15.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.15 (0.01SD)	3	ETS	94

Reaction No. 47568




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.10 (0.01SD)	3	ETS	94

Reaction No. 47569




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.10 (0.01SD)	3	ETS	94

Reaction No. 47570




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.05 (0.01SD)	3	ETS	94

Reaction No. 47571




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.00 (0.01SD)	3	ETS	94

Reaction No. 47572



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.85 (0.01SD)	3	ETS	94


Reaction No. 47573



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.6 (3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:13.95 (0.01SD)	3	ETS	94
---	----	------	--------------	--------------------	---	-----	----

Reaction No. 47574




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.85 (0.01SD)	3	ETS	94

Reaction No. 47575




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:17.72 (0.01SD)	3	ETS	94

Reaction No. 47576




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.00 (0.01SD)	3	ETS	94

Reaction No. 47577




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.05 (0.01SD)	3	ETS	94

Reaction No. 47578



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.3 (3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:22.70 (0.01SD)	3	ETS	94

Reaction No. 47579



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.45 (0.01SD)	3	ETS	94

Reaction No. 47580							
2<H+1> + Mg+2 + Asn-1 + PO4-3 = Mg+2_H+1(2)_Asn-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.30(0.01SD)	3	ETS	94

Reaction No. 47581							
2<H+1> + Mg+2 + Asp-2 + PO4-3 = Mg+2_H+1(2)_Asp-2_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.00(0.01SD)	3	ETS	94

Reaction No. 47582							
2<H+1> + Mg+2 + Citrul-1 + PO4-3 = Mg+2_H+1(2)_Citrul-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.35(0.01SD)	3	ETS	94

Reaction No. 47583							
2<H+1> + Mg+2 + Cys-2 + PO4-3 = Mg+2_H+1(2)_Cys-2_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:26.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.95(0.01SD)	3	ETS	94

Reaction No. 47584							
2<H+1> + Mg+2 + Cis-2 + PO4-3 = Mg+2_H+1(2)_Cis-2_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.95(0.01SD)	3	ETS	94

Reaction No. 47585							
2<H+1> + Mg+2 + Glu-2 + PO4-3 = Mg+2_H+1(2)_Glu-2_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.10(0.01SD)	3	ETS	94

Reaction No. 47586							
--------------------	--	--	--	--	--	--	--

2<H+1> + Mg+2 + Gln-1 + PO4-3 = Mg+2_H+1(2)_Gln-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.40(0.01SD)	3	ETS	94

Reaction No. 47587							
2<H+1> + Mg+2 + Gly-1 + PO4-3 = Mg+2_H+1(2)_Gly-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.10(0.01SD)	3	ETS	94

Reaction No. 47588							
2<H+1> + Mg+2 + His-1 + PO4-3 = Mg+2_H+1(2)_His-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.60(0.01SD)	3	ETS	94

Reaction No. 47589							
2<H+1> + Mg+2 + Hyp-1 + PO4-3 = Mg+2_H+1(2)_Hyp-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.85(0.01SD)	3	ETS	94


Reaction No. 47590							
2<H+1> + Mg+2 + Ile-1 + PO4-3 = Mg+2_H+1(2)_Ile-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.00(0.01SD)	3	ETS	94

Reaction No. 47591							
2<H+1> + Mg+2 + Leu-1 + PO4-3 = Mg+2_H+1(2)_Leu-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.00(0.01SD)	3	ETS	94

Reaction No. 47592							
2<H+1> + Mg+2 + Lys-1 + PO4-3 = Mg+2_H+1(2)_Lys-1_PO4-3							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:26.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:24.30 (0.01SD)	3	ETS	94

Reaction No. 47593




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.50 (0.01SD)	3	ETS	94

Reaction No. 47594




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:26.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:24.05 (0.01SD)	3	ETS	94

Reaction No. 47595




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.45 (0.01SD)	3	ETS	94

Reaction No. 47596




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:26.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:24.05 (0.01SD)	3	ETS	94

Reaction No. 47597



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.40 (0.01SD)	3	ETS	94


Reaction No. 47598



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:24.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.30 (0.01SD)	3	ETS	94

Reaction No. 47599




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.70 (0.01SD)	3	ETS	94

Reaction No. 47600




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:26.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:24.00 (0.01SD)	3	ETS	94

Reaction No. 47601




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.85 (0.01SD)	3	ETS	94

Reaction No. 47602




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.66 (0.01SD)	3	ETS	94

Reaction No. 47603



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.51 (0.01SD)	3	ETS	94

Reaction No. 47604



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.0 (3SF)	2	EAE	

2	37	0.15	Blood Plasma	lgK:14.61(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 47605							
H+1 + Mg+2 + Oxalic-2 + SiH2O4-2 = Mg+2_H+1_Oxalic-2_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.51(0.01SD)	3	ETS	94

Reaction No. 47606							
H+1 + Mg+2 + Succinic-2 + SiH2O4-2 = Mg+2_H+1_SiH2O4-2_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.66(0.01SD)	3	ETS	94

Reaction No. 47607							
2<H+1> + Mg+2 + Ala-1 + SiH2O4-2 = Mg+2_H+1(2)_Ala-1_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.71(0.01SD)	3	ETS	94

Reaction No. 47608							
2<H+1> + Mg+2 + bAla-1 + SiH2O4-2 = Mg+2_H+1(2)_bAla-1_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.0(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:23.36(0.01SD)	3	ETS	94

Reaction No. 47609							
2<H+1> + Mg+2 + Arg-1 + SiH2O4-2 = Mg+2_H+1(2)_Arg-1_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.11(0.01SD)	3	ETS	94

Reaction No. 47610							
2<H+1> + Mg+2 + Asn-1 + SiH2O4-2 = Mg+2_H+1(2)_Asn-1_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.96(0.01SD)	3	ETS	94

Reaction No. 47611							
$2\text{<H+1>} + \text{Mg}+2 + \text{Asp}-2 + \text{SiH}_2\text{O}_4-2 = \text{Mg}+2_{\text{H}+1(2)}_{\text{Asp}-2}_{\text{SiH}_2\text{O}_4-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.66(0.01SD)	3	ETS	94

Reaction No. 47612							
$2\text{<H+1>} + \text{Mg}+2 + \text{Citrul}-1 + \text{SiH}_2\text{O}_4-2 = \text{Mg}+2_{\text{H}+1(2)}_{\text{Citrul}-1}_{\text{SiH}_2\text{O}_4-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.01(0.01SD)	3	ETS	94

Reaction No. 47613							
$2\text{<H+1>} + \text{Mg}+2 + \text{Cis}-2 + \text{SiH}_2\text{O}_4-2 = \text{Mg}+2_{\text{H}+1(2)}_{\text{Cis}-2}_{\text{SiH}_2\text{O}_4-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.61(0.01SD)	3	ETS	94

Reaction No. 47614							
$2\text{<H+1>} + \text{Mg}+2 + \text{Glu}-2 + \text{SiH}_2\text{O}_4-2 = \text{Mg}+2_{\text{H}+1(2)}_{\text{Glu}-2}_{\text{SiH}_2\text{O}_4-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.76(0.01SD)	3	ETS	94

Reaction No. 47615							
$2\text{<H+1>} + \text{Mg}+2 + \text{Gln}-1 + \text{SiH}_2\text{O}_4-2 = \text{Mg}+2_{\text{H}+1(2)}_{\text{Gln}-1}_{\text{SiH}_2\text{O}_4-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.06(0.01SD)	3	ETS	94

Reaction No. 47616							
$2\text{<H+1>} + \text{Mg}+2 + \text{Gly}-1 + \text{SiH}_2\text{O}_4-2 = \text{Mg}+2_{\text{H}+1(2)}_{\text{Gly}-1}_{\text{SiH}_2\text{O}_4-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.76(0.01SD)	3	ETS	94

Reaction No. 47617							
--------------------	--	--	--	--	--	--	--

2<H+1> + Mg+2 + His-1 + SiH2O4-2 = Mg+2_H+1(2)_His-1_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.26(0.01SD)	3	ETS	94

Reaction No. 47618							
2<H+1> + Mg+2 + Hyp-1 + SiH2O4-2 = Mg+2_H+1(2)_Hyp-1_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.51(0.01SD)	3	ETS	94

Reaction No. 47619							
2<H+1> + Mg+2 + Ile-1 + SiH2O4-2 = Mg+2_H+1(2)_Ile-1_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.66(0.01SD)	3	ETS	94

Reaction No. 47620							
2<H+1> + Mg+2 + Leu-1 + SiH2O4-2 = Mg+2_H+1(2)_Leu-1_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.66(0.01SD)	3	ETS	94


Reaction No. 47621							
2<H+1> + Mg+2 + Met-1 + SiH2O4-2 = Mg+2_H+1(2)_Met-1_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.16(0.01SD)	3	ETS	94

Reaction No. 47622							
2<H+1> + Mg+2 + Phe-1 + SiH2O4-2 = Mg+2_H+1(2)_Phe-1_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.11(0.01SD)	3	ETS	94

Reaction No. 47623							
2<H+1> + Mg+2 + Pro-1 + SiH2O4-2 = Mg+2_H+1(2)_Pro-1_SiH2O4-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:24.71(0.01SD)	3	ETS	94

Reaction No. 47624




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.06(0.01SD)	3	ETS	94

Reaction No. 47625




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:22.96(0.01SD)	3	ETS	94

Reaction No. 47626




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.36(0.01SD)	3	ETS	94

Reaction No. 47627




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.51(0.01SD)	3	ETS	94

Reaction No. 48787



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:283.4(4SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-386.710(6SF)	0	CRV	406

Reaction No. 52341



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0	UCT_Sea	lgK:1.26 (0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:0.92 (0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:0.86 (0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:0.83 (0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:0.81 (0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:0.80 (0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:0.80 (0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:0.80 (0.01SD)	4	EDH	5390

Reaction No. 52342							
Mg+2 + 12PrDiAm = Mg+2_12PrDiAm							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:0.09 (0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:0.15 (0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:0.18 (0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:0.20 (0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:0.22 (0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:0.24 (0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:0.26 (0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:0.27 (0.01SD)	4	EDH	5390


Reaction No. 52431							
LDopa-3 + Mg+2 = Mg+2_LDopa-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.71 (3SF)	3	MGL	2482

Reaction No. 52471							
[18]N2O4:2OHEt*2 + Mg+2 = Mg+2_[18]N2O4:2OHEt*2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	LiClO4	lgK:2. (1SF)	3	MGL	4631

Reaction No. 53364							
Mg+2 + H+1_PO4-3 + H+1 = Mg+2_H+1(2)_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.3 (2SF)	1	EOR	
2	25	3	NaClO4	lgK:6.44 (0.05SD)	5	MHY	242
3	25	3	NaClO4	lgK:6.44 (3SF)	5	MGL	5398


4	37	0.15	Inert	lgK:8.03 (3SF)	4	CRV	29801
---	----	------	-------	----------------	---	-----	-------

Reaction No. 53448




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NBr	lgK:2.13 (3SF)	4	MGL	264
2	45	0.1	KNO3	lgK:1.10 (3SF)	5	MGL	5398
3	65	1	Me4NBr	lgK:2.12 (3SF)	4	MDG	264

Reaction No. 53449



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:1.9 (2SF)	5	MGL	5398


Reaction No. 53509



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.3 (1SF)	1	EES	
2	25	3	Inert	lgK:1.0 (2SF)	1	EES	
3	25	3	NaClO4/m	lgK:0.47 (0.13SD)	0	MEF	338


Note (3): Sign problem?

Reaction No. 53525



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	2.4	Na2SO4	lgK:0.06 (1SF)	4	MPL	5398
2	22	2	NH4NO3	lgK:0.08 (1SF)	6	CRV	552
3	25	0	Inf. Dilution	lgK:0.1711 (4SF)	1	EOR	
4	25	0	Inf. Dilution	lgK:0.2 (1SF)	4	CRV	2556
5	25	0	Inf. Dilution	lgK:0.0 (1SF)	3	CRV	9402
6	25	0	Inf. Dilution	dH:-1.2 (2SF)	4	CRV	2556


Reaction No. 53526



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	2.4	Na2SO4	lgK:-0.19 (2SF)	4	MPL	5398
2	22	2	NH4NO3	lgK:-0.3 (1SF)	6	CRV	552


3	25	0	Inf. Dilution	lgK:-0.3 (4SF)	1	EOR	
4	25	0	Inf. Dilution	lgK:-0.30 (2SF)	3	CRV	9402

Reaction No. 53527




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	2.4	Na2SO4	lgK:-1.0 (2SF)	4	MPL	5398
2	25	0	Inf. Dilution	lgK:-1.354 (4SF)	1	EOR	
3	25	0	Inf. Dilution	lgK:-1.00 (3SF)	3	CRV	9402

Reaction No. 53528




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	2.4	Na2SO4	lgK:-1.7 (2SF)	3	MPL	5398
2	25	0	Inf. Dilution	lgK:-1.69 (4SF)	1	EOR	
3	25	0	Inf. Dilution	lgK:-1.69 (3SF)	2	EAE	

Reaction No. 53619




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1. (1SF)	1	EAC	
2	25		Ethanol:Acetone 50:50Wgt	lgK:2.595 (4SF)	4	MDG	5398
3	23	0.5	Propan-2-ol:Water 90:10Wgt Unknown	lgK:0.20 (2SF)	5	MCE	931

Reaction No. 53828



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.1686 (4SF)	1	ELC	
2	23	0.5	Propan-2-ol:Water 90:10Wgt Unknown	lgK:-0.07 (1SF)	5	MCE	931


Reaction No. 53913



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.6 (2SF)	1	EES	


2	25	0.1	NaNO3	lgK:6.0 (2SF)	0	MGL	931
3	25	3	Inert	lgK:5.4 (2SF)	1	EES	
4	100	0	Inf. Dilution	lgK:9.1 (2SF)	1	EES	

Reaction No. 54435




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22			lgK:-8.50 (3SF)	0	MGL	140

Reaction No. 54513




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-14.1 (0.05SD)	3	ENS	557

Reaction No. 54515



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:3.2 (0.05SD) w	3	MPH	259
2	25	1	Me4NBr	lgK:3.05 (3SF)	3	MGL	264
3	25	1	Me4NCl	lgK:3.06 (0.05SD)	3	MGL	274
4	25	1	Me4NCl	lgK:4.40 (3SF)	0	MPH	398
5	65	1	Me4NBr	lgK:4.13 (3SF)	3	MGL	264

Reaction No. 54518



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.6 (2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:7.4 (2SF)	0	CRV	

Note (2): <http://www.saltlakemetals.com/SolubilityProducts.htm> (15/7/14)

3	25	0	Inf. Dilution	lgK:8.18 (3SF)	2	CMN	773
4	25	0	Inf. Dilution	lgK:7.9 (2SF)	0	ENS	5648
5	25	0	Inf. Dilution	lgK:10.13 (4SF)	0	CRV	6330

Note (5): p. 8-58

6	25	0	Inf. Dilution	lgK:8.18 (3SF)	2	CRV	9402
7	25	0	Inf. Dilution	lgK:8.19 (3SF)	2	CRV	22551
8	25	0	Inf. Dilution	lgK:9.79 (3SF)	3	CRV	28992
9	25	0	Inf. Dilution	lgK:9.49 (3SF)	4	CRV	32224

10	25	0	CHEMVAL1	lgK:8.18(0.01SD)	0	ENS	5156
11	25	0	CHEMVAL2	lgK:8.18(0.01SD)	0	ENS	5156
12	25	0	CHEMVAL3	lgK:8.18(0.01SD)	0	ENS	5156
13	25	0	CHEMVAL4	lgK:9.26(0.01SD)	0	ENS	5156
14	27	0	Inf. Dilution	lgK:8.2(0.05SD)	1	MCN	5435
15	50	0	Inf. Dilution	lgK:9.89(3SF)	2	CRV	28992
16	100	0	Inf. Dilution	lgK:10.27(4SF)	2	CRV	28992
17	150	0	Inf. Dilution	lgK:10.77(4SF)	2	CRV	28992
18	200	0	Inf. Dilution	lgK:11.48(4SF)	2	CRV	28992
19	0:40	0	Inf. Dilution	dH:2.(1SF)	0	CRV	2556
Note (19): Low wgt for internal consistency							
20	25	0	Inf. Dilution	dH:2.00(3SF)	4	CRV	9402

Reaction No. 54522							
Mg(s) + Mo(s) + 2<O2(g)> = Mg+2_MoO4-2_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:227.1(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:225.5(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:164.6(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:128.0(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:103.7(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-309.7(0.05SD)	4	ENS	802
7	25	0	Inf. Dilution	dG:-309.8(4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dH:-334.8(0.1SD)	4	ENS	802
9	25	0	Inf. Dilution	dH:-334.9(4SF)	4	MTD	6422
10	127	0	Inf. Dilution	dH:-334.6(4SF)	4	MTD	6422
11	227	0	Inf. Dilution	dH:-334.2(4SF)	4	MTD	6422
12	327	0	Inf. Dilution	dH:-333.7(4SF)	4	MTD	6422

Reaction No. 54525							
Ca+2_Mg+2_CO3-2(2)_(disord.,s) = Ca+2 + Mg+2 + 2<CO3-2>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-16.5(0.05SD)	3	ENS	5484
2	25	0	Inf. Dilution	lgK:-16.54(4SF)	3	ENS	6496
3	25	0	Inf. Dilution	dH:-11.1(0.1SD)	3	ENS	5484
4	25	0	Inf. Dilution	dH:-11.09(4SF)	3	ENS	6496


Reaction No. 54528							
Mg+2 + B(OH)4-1 = Mg+2_B(OH)4-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.618(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:1.34(3SF)	4	CRV	406
3	25	0	Inf. Dilution	lgK:1.52(3SF)	4	CRV	406
4	25	0	Inf. Dilution	lgK:1.63(3SF)	4	CRV	406
5	25	0	Inf. Dilution	lgK:1.57(0.02SD)	3	EES	7391
6	25	0	Inf. Dilution	lgK:1.3993(5SF)	3	EOD	30797
7	25	0	UCT_Sea	lgK:1.63(0.01SD)	4	EDH	5390
8	25	0.1	UCT_Sea	lgK:1.28(0.01SD)	4	EDH	5390
9	25	0.16	Cl-1 salt	lgK:1.6(0.05SD)w	0	MPH	373
10	25	0.2	UCT_Sea	lgK:1.22(0.01SD)	4	EDH	5390
11	25	0.3	UCT_Sea	lgK:1.19(0.01SD)	4	EDH	5390
12	25	0.4	UCT_Sea	lgK:1.16(0.01SD)	4	EDH	5390
13	25	0.5	UCT_Sea	lgK:1.15(0.01SD)	4	EDH	5390
14	25	0.6	UCT_Sea	lgK:1.14(0.01SD)	4	EDH	5390
15	25	0.7	NaCl	lgK:1.1(0.03SD)	3	MPS	769
16	25	0.7	Seawater	lgK:0.73(2SF)	0	ENS	405
17	25	0.7	UCT_Sea	lgK:1.13(0.01SD)	4	EDH	5390
18	25	0.7	Unknown	lgK:1.4(0.1SD)	0	CMN	406
19	25	0.7	Unknown	lgK:0.93(0.03SD)	5	CMN	7391
20	25	0.7	Unknown	lgK:0.73(2SF)	2	ENS	7391
21	25	0.7	Unknown	lgK:0.90(2SF)	3	ENS	7391
22	10:50	0.16	Cl-1 salt	dH:-0.5(1.SD)	5	MPH	373

Reaction No. 54551							
Mg+2 + H+1_SiH2O4-2 = Mg+2_H+1_SiH2O4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.0(2SF)	1	EOR	
2	25	1	NaClO4	lgK:0.6(0.05SD)	3	MIS	455

Reaction No. 54552							
Mg+2 + 2<H+1_SiH2O4-2> = Mg+2_H+1(2)_SiH2O4-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.3(2SF)	1	EOR	


2	25	1	NaClO4	lgK:3.8(0.05SD)	3	MIS	455
---	----	---	--------	-----------------	---	-----	-----

Reaction No. 54553



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-16.0(0.05SD)	4	ENS	557
2	25	3	Inert	lgK:-13.8(3SF)	1	EES	
3	100	0	Inf. Dilution	lgK:-14.6(3SF)	1	EES	

Reaction No. 54558




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-21.7(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-21.2(0.1SD)	0	ENS	440
3	25	0	Inf. Dilution	lgK:-21.20(4SF)	0	CRV	6405

Note (3): p. 246

4	25	0	Inf. Dilution	lgK:-21.07(4SF)	0	CRV	32224
5	25	0	CHEMVAL1	lgK:-23.70(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL2	lgK:-23.70(0.01SD)	0	ENS	5156
7	25	0	CHEMVAL3	lgK:-23.70(0.01SD)	0	ENS	5156
8	25	0	CHEMVAL4	lgK:-19.90(0.01SD)	0	ENS	5156

Reaction No. 54559




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:66.1(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:62.4(0.1SD)	0	ENS	440
3	25	0	Inf. Dilution	lgK:62.44(4SF)	0	CRV	6405

Note (3): p. 246

4	25	0	Inf. Dilution	lgK:61.85(4SF)	0	CRV	32224
5	25	0	CHEMVAL1	lgK:67.61(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL2	lgK:67.61(0.01SD)	0	ENS	5156
7	25	0	CHEMVAL3	lgK:67.61(0.01SD)	0	ENS	5156

Reaction No. 54561



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0	Inf. Dilution	lgK:-40.(0.3SD)	3	MSL	441
2	51	0	Inf. Dilution	lgK:-39.(0.3SD)	3	MSL	441
3	70	0	Inf. Dilution	lgK:-38.(0.3SD)	3	MSL	441


Reaction No. 54720							
Mg+2(3)_AsO4-3(2)_(s) = 3<Mg+2> + 2<AsO4-3>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:-19.7(0.05SD)	5	ENS	5468
2	25	0	Inf. Dilution	lgK:-19.7(3SF)	5	EES	
Note (2): For a LC boost (only)							
3	25	0	Inf. Dilution	lgK:-19.7(4SF)	1	EOR	
4	25	0	Inf. Dilution	lgK:-19.68(4SF)	3	CRV	
Note (4): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							

Reaction No. 54772							
Mg+2 + SO4-2 + 7<H2O> = Mg+2_SO4-2_H2O(7)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:2.06(3SF)	4	CRV	31793
2	10	0	Inf. Dilution	lgK:1.97(3SF)	4	CRV	31793
3	20	0	Inf. Dilution	lgK:1.886(4SF)	4	CRV	31793
4	25	0	Inf. Dilution	lgK:2.1(0.05SD)	1	ENS	5458
5	25	0	Inf. Dilution	lgK:1.881(4SF)	3	EOD	24835
Note (5): Taken from Altmaier et al., THEREDA database, 2011							
6	25	0	Inf. Dilution	lgK:1.842(4SF)	4	CRV	31793
7	25	0	Inf. Dilution	lgK:2.07(3SF)	4	CRV	32224
8	25	0	CHEMVAL1	lgK:2.07(0.01SD)	0	ENS	5156
9	25	0	CHEMVAL2	lgK:2.07(0.01SD)	0	ENS	5156
10	25	0	CHEMVAL3	lgK:2.07(0.01SD)	0	ENS	5156
11	25	0	CHEMVAL4	lgK:2.07(0.01SD)	1	ENS	5156
12	30	0	Inf. Dilution	lgK:1.790(4SF)	4	CRV	31793
13	40	0	Inf. Dilution	lgK:1.662(4SF)	4	CRV	31793
14	50	0	Inf. Dilution	lgK:1.485(4SF)	3	CRV	31793

Reaction No. 54773							
Mg+2 + SO4-2 + 6<H2O> = Mg+2_SO4-2_H2O(6)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.7(0.05SD)	2	ENS	5458


2	25	0	Inf. Dilution	lgK:1.73(3SF)	2	CRV	32224
3	25	0	CHEMVAL1	lgK:1.73(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:1.73(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:1.73(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:1.70(0.01SD)	2	ENS	5156
7	30	0	Inf. Dilution	lgK:1.567(4SF)	4	CRV	31793
8	40	0	Inf. Dilution	lgK:1.526(4SF)	4	CRV	31793
9	50	0	Inf. Dilution	lgK:1.457(4SF)	4	CRV	31793
10	60	0	Inf. Dilution	lgK:1.359(4SF)	4	CRV	31793
11	70	0	Inf. Dilution	lgK:1.225(4SF)	4	CRV	31793
12	80	0	Inf. Dilution	lgK:1.056(4SF)	4	CRV	31793
13	90	0	Inf. Dilution	lgK:0.852(3SF)	3	CRV	31793

Reaction No. 54774



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.67(2SF)	0	CRV	
Note (1): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
2	25	0	Inf. Dilution	lgK:-5.0(0.05SD)	4	ENS	5458
3	25	0	Inf. Dilution	lgK:-5.04(3SF)	4	CRV	32224
4	25	0	CHEMVAL1	lgK:-5.04(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL2	lgK:-5.04(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL3	lgK:-5.04(0.01SD)	0	ENS	5156
7	25	0	CHEMVAL4	lgK:-5.03(0.01SD)	5	ENS	5156

Reaction No. 54778



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.36(3SF)	1	MTD	
2	25	0	Inf. Dilution	lgK:-1.4(0.05SD)	1	ENS	5458
3	25	0	Inf. Dilution	lgK:-1.36(3SF)	4	CRV	32224
4	25	0	CHEMVAL1	lgK:-1.36(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL2	lgK:-1.36(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL3	lgK:-1.36(0.01SD)	0	ENS	5156
7	25	0	CHEMVAL4	lgK:-1.36(0.01SD)	1	ENS	5156
8	70	0	Inf. Dilution	lgK:0.5478(4SF)	4	CRV	31793

9	80	0	Inf. Dilution	lgK:0.6529(4SF)	4	CRV	31793
10	90	0	Inf. Dilution	lgK:0.8480(4SF)	4	CRV	31793
11	100	0	Inf. Dilution	lgK:1.1349(5SF)	3	CRV	31793

Reaction No. 54845



Note: Havel and Hogfeldt [74HaH_242]: "improvement in fit could equally well be due to the change in activity coefficients on replacement of Na+ with Mg2+ in such media of high ionic strength"

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.9(2SF)	1	EES	
2	25	3	Inert	lgK:3.0(2SF)	1	EES	
3	37	0.15	KNO3	lgK:3.0(0.5SD)	3	MPS	255


Reaction No. 54846



Note: Indication of a dimer but too uncertain to be confirmed [74HaH-242]


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.0(2SF)	1	EES	
2	25	3	Inert	lgK:1.3(2SF)	1	EES	
3	37	0.15	KNO3	lgK:1.4(0.4SD)	3	MPS	255
4	100	0	Inf. Dilution	lgK:1.3(2SF)	1	EES	

Reaction No. 54860



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-5.4(0.05SD)	4	ENS	766
2	25	0	Inf. Dilution	dH:21.3(0.1SD)	4	ENS	766

Reaction No. 54917



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.0(3SF)	0	CRV	
Note (1): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
2	25	0	Inf. Dilution	lgK:23.7(3SF)	1	ERG	
Note (2): Was lgK=24.6 prev iter							
3	25	0	Inf. Dilution	lgK:23.9(0.05SD)	2	ENS	5458

4	25	0	Inf. Dilution	lgK:25.2 (3SF)	0	ENS	6405
5	25	0	Inf. Dilution	lgK:28.40 (4SF)	0	CRV	9402
6	25	0	Inf. Dilution	lgK:23.90 (4SF)	4	CRV	32224


Reaction No. 54935							
$\text{Mg}^{+2} + 2\text{Cr}^{+3}\text{OH-1(2)} - 4\text{H}^{+1} = \text{MgO.Cr}_2\text{O}_3(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-10.0 (3SF)	1	ERG	
Note (1): Was lgK=-10.4 prev iter							
2	25	0	Inf. Dilution	lgK:-12.1 (0.05SD)	0	ENS	766
3	25	0	Inf. Dilution	dH:39.9 (0.1SD)	1	ENS	766

Reaction No. 54978							
$2\text{Mg}^{+2} + 2\text{OH-1} = \text{Mg}^{+2(2)}\text{OH-1(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	(H,Na)NO3	lgK:-21.2 (0.05SD)	6	CMN	4496

Reaction No. 55024							
$\text{Ca}^{+2}\text{Mg}^{+2}\text{CO}_3\text{-2(2)}_{(\text{ord.,s})} = \text{Ca}^{+2} + \text{Mg}^{+2} + 2\text{CO}_3\text{-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-16.6 (3SF)	1	EES	
2	25	0	Inf. Dilution	lgK:-17.10 (0.02SD)	3	ENS	5484
3	25	0	Inf. Dilution	lgK:-17.09 (4SF)	3	ENS	6496
4	25	0	CHEMVAL1	lgK:-16.98 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL2	lgK:-16.98 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL3	lgK:-16.98 (0.01SD)	0	ENS	5156
7	25	0	CHEMVAL4	lgK:-17.10 (0.01SD)	3	ENS	5156
8	25	3	Inert	lgK:-14.0 (3SF)	1	EES	
9	50	0.1056	NaCl/m	lgK:-15.96 (4SF)	4	CRV	26086
10	50.6	0.1056	NaCl/m	lgK:-15.86 (4SF)	4	CRV	26086
11	50.6	0.1067	NaCl/m	lgK:-15.70 (4SF)	3	CRV	26086
12	74.7	0.1045	NaCl/m	lgK:-16.73 (4SF)	4	CRV	26086
13	75.9	0.1051	NaCl/m	lgK:-16.79 (4SF)	4	CRV	26086
14	99.2	0.1038	NaCl/m	lgK:-17.73 (4SF)	3	CRV	26086
15	99.8	0.1041	NaCl/m	lgK:-17.60 (4SF)	4	CRV	26086
16	100.5	0.1048	NaCl/m	lgK:-17.23 (4SF)	3	CRV	26086
17	124.2	0.1038	NaCl/m	lgK:-18.33 (4SF)	4	CRV	26086


18	124.7	0.1029	NaCl/m	lgK:-18.28 (4SF)	4	CRV	26086
19	125	0.1029	NaCl/m	lgK:-18.76 (4SF)	2	CRV	26086
20	125.2	0.1034	NaCl/m	lgK:-18.41 (4SF)	4	CRV	26086
21	139.4	0.1043	NaCl/m	lgK:-21.45 (4SF)	0	CRV	26086
22	148.6	0.103	NaCl/m	lgK:-19.19 (4SF)	4	CRV	26086
23	152.1	0.1029	NaCl/m	lgK:-19.06 (4SF)	4	CRV	26086
24	152.2	0.1031	NaCl/m	lgK:-19.61 (4SF)	2	CRV	26086
25	174.4	0.1028	NaCl/m	lgK:-19.92 (4SF)	4	CRV	26086
26	174.6	0.1025	NaCl/m	lgK:-19.68 (4SF)	2	CRV	26086
27	175.1	0.1027	NaCl/m	lgK:-20.27 (4SF)	4	CRV	26086
28	175.5	0.1019	NaCl/m	lgK:-19.77 (4SF)	2	CRV	26086
29	176.5	0.1022	NaCl/m	lgK:-19.86 (4SF)	3	CRV	26086
30	180.7	0.1043	NaCl/m	lgK:-23.15 (4SF)	0	CRV	26086
31	199.4	0.1048	NaCl/m	lgK:-21.02 (4SF)	4	CRV	26086
32	221.2	0.1045	NaCl/m	lgK:-25.22 (4SF)	0	CRV	26086
33	227.2	0.1032	NaCl/m	lgK:-21.99 (4SF)	4	CRV	26086
34	228.2	0.1077	NaCl/m	lgK:-22.43 (4SF)	2	CRV	26086
35	247.5	0.1052	NaCl/m	lgK:-23.62 (4SF)	0	CRV	26086
36	252.5	0.1038	NaCl/m	lgK:-26.44 (4SF)	0	CRV	26086
37	25	0	Inf. Dilution	dH:-9.4 (0.1SD)	3	ENS	5484
38	25	0	Inf. Dilution	dH:-9.436 (4SF)	3	ENS	6496

Reaction No. 55085



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-184. (0.5SD)	4	ENS	802
2	25	0	Inf. Dilution	dH:-221.5 (0.05SD)	4	ENS	802

Reaction No. 55086



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:103.7 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:103.7 (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:103.0 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:103.0 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:75.13 (4SF)	3	ENS	6422


6	127	0	Inf. Dilution	lgK:75.09 (4SF)	3	ENS	6494
7	227	0	Inf. Dilution	lgK:58.43 (4SF)	2	ENS	6422
8	227	0	Inf. Dilution	lgK:58.40 (4SF)	2	ENS	6494
9	327	0	Inf. Dilution	lgK:47.32 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:47.29 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-141.5 (0.05SD)	4	ENS	802
12	25	0	Inf. Dilution	dG:-591.8 (4SF) kJ	5	CRV	6330
13	25	0	Inf. Dilution	dG:-141.5 (4SF)	4	EFE	6422
14	25	0	Inf. Dilution	dG:-141.4 (4SF)	4	EFE	6494
15	25	0	Inf. Dilution	dG:-591.79 (5SF) kJ	5	EFE	7275
16	25	0	Inf. Dilution	dG:-591.8 (4SF) kJ	4	EOD	29025
17	25	0	Inf. Dilution	dH:-153.3 (0.05SD)	4	ENS	802
18	25	0	Inf. Dilution	dH:-641.3 (4SF) kJ	5	CRV	6330
19	25	0	Inf. Dilution	dH:-153.3 (4SF)	4	MTD	6422
20	25	0	Inf. Dilution	dH:-153.3 (4SF)	4	MTD	6494
21	25	0	Inf. Dilution	dH:-641.32 (5SF) kJ	5	EFE	7275
22	25	0	Inf. Dilution	dH:-641.3 (4SF) kJ	4	EOD	29025
23	127	0	Inf. Dilution	dH:-153.0 (4SF)	3	MTD	6422
24	127	0	Inf. Dilution	dH:-152.9 (4SF)	3	MTD	6494
25	227	0	Inf. Dilution	dH:-152.7 (4SF)	2	MTD	6422
26	227	0	Inf. Dilution	dH:-152.6 (4SF)	2	MTD	6494
27	327	0	Inf. Dilution	dH:-152.3 (4SF)	0	MTD	6422
28	327	0	Inf. Dilution	dH:-152.2 (4SF)	0	MTD	6494
29	25	0	Inf. Dilution	Cp:71.4 (3SF) J/K	4	EOD	29025

Reaction No. 55087



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-206.0 (0.05SD)	4	ENS	802
2	25	0	Inf. Dilution	dG:-862.4 (4SF) kJ	4	EOD	29025
3	25	0	Inf. Dilution	dH:-231.0 (0.05SD)	4	ENS	802
4	25	0	Inf. Dilution	dH:-967.1 (4SF) kJ	4	EOD	29025
5	25	0	Inf. Dilution	Cp:115.3 (4SF) J/K	4	EOD	29025

Reaction No. 55088



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-267.2(0.05SD)	0	ENS	802
2	25	0	Inf. Dilution	dG:-1118.5(5SF)kJ	0	EOD	29025
3	25	0	Inf. Dilution	dG:-1150.7(5SF)kJ	2	MAC	30014
4	25	0	Inf. Dilution	dH:-305.9(0.05SD)	0	ENS	802
5	25	0	Inf. Dilution	dH:-1280.3(5SF)kJ	0	EOD	29025
6	25	0	Inf. Dilution	dH:-1367.5(5SF)kJ	2	MAC	30014
7	25	0	Inf. Dilution	Cp:159.2(4SF)J/K	2	EOD	29025

Reaction No. 55089							
$\text{Cl}_2(\text{g}) + 4\text{H}_2(\text{g}) + \text{Mg}(\text{s}) + 2\text{O}_2(\text{g}) = \text{Mg}_2\text{Cl}_2\text{H}_2\text{O}_4(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-388.0(0.05SD)	0	ENS	802
2	25	0	Inf. Dilution	dG:-1633.8(5SF)kJ	1	EOD	29025
3	25	0	Inf. Dilution	dG:-1636.3(5SF)kJ	3	MAC	30014
4	25	0	Inf. Dilution	dH:-453.9(0.05SD)	0	ENS	802
5	25	0	Inf. Dilution	dH:-1899.5(5SF)kJ	1	EOD	29025
6	25	0	Inf. Dilution	dH:-1930.7(5SF)kJ	3	MAC	30014
7	25	0	Inf. Dilution	Cp:241.4(4SF)J/K	2	EOD	29025

Reaction No. 55090							
$\text{Cl}_2(\text{g}) + 6\text{H}_2(\text{g}) + \text{Mg}(\text{s}) + 3\text{O}_2(\text{g}) = \text{Mg}_2\text{Cl}_2\text{H}_2\text{O}_6(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-505.5(0.05SD)	2	ENS	802
2	25	0	Inf. Dilution	dG:-2114.60(6SF)kJ	2	CRV	24003
3	25	0	Inf. Dilution	dG:-2114.8(5SF)kJ	2	EOD	29025
4	25	0	Inf. Dilution	dG:-2119.0(5SF)kJ	3	MAC	30014
5	25	0	Inf. Dilution/m	dG:-2114.80(6SF)kJ	3	EPZ	8833
6	25	0	Inf. Dilution	dH:-597.3(0.05SD)	2	ENS	802
7	25	0	Inf. Dilution	dH:-2499.6(5SF)kJ	2	EOD	29025
8	25	0	Inf. Dilution	dH:-2504.1(5SF)kJ	3	MAC	30014
9	25	0	Inf. Dilution	Cp:315.1(4SF)J/K	3	EOD	29025

Reaction No. 55091							
$\text{Mg}(\text{s}) + 2\text{O}_2(\text{g}) + \text{S}(\text{s}) = \text{Mg}_2\text{SO}_4\text{S}_2(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:205.1(4SF)	4	ENS	6422

2	25	0	Inf. Dilution	lgK:205.1 (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:203.7 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:203.7 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:147.7 (4SF)	3	ENS	6422
6	127	0	Inf. Dilution	lgK:147.7 (4SF)	3	ENS	6494
7	227	0	Inf. Dilution	lgK:114.1 (4SF)	2	ENS	6422
8	227	0	Inf. Dilution	lgK:114.1 (4SF)	2	ENS	6494
9	327	0	Inf. Dilution	lgK:91.65 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:91.64 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-280. (0.5SD)	2	ENS	802
12	25	0	Inf. Dilution	dG:-1170.6 (5SF) kJ	5	CRV	6330
13	25	0	Inf. Dilution	dG:-279.8 (4SF)	4	EFE	6422
14	25	0	Inf. Dilution	dG:-279.8 (4SF)	4	EFE	6494
15	25	0	Inf. Dilution	dG:-1170.6 (5SF) kJ	4	ENS	7381
16	25	0	Inf. Dilution	dG:-1170.6 (5SF) kJ	4	EOD	29025
17	25	0	Inf. Dilution	dH:-307. (0.5SD)	4	ENS	802
18	25	0	Inf. Dilution	dH:-1284.9 (5SF) kJ	5	CRV	6330
19	25	0	Inf. Dilution	dH:-307.1 (4SF)	4	MTD	6422
20	25	0	Inf. Dilution	dH:-307.1 (4SF)	4	MTD	6494
21	25	0	Inf. Dilution	dH:-1284.9 (5SF) kJ	4	ENS	7381
22	25	0	Inf. Dilution	dH:-1284.9 (5SF) kJ	4	EOD	29025
23	127	0	Inf. Dilution	dH:-307.8 (4SF)	2	MTD	6422
24	127	0	Inf. Dilution	dH:-307.7 (4SF)	2	MTD	6494
25	227	0	Inf. Dilution	dH:-308.0 (4SF)	2	MTD	6422
26	227	0	Inf. Dilution	dH:-308.0 (4SF)	2	MTD	6494
27	327	0	Inf. Dilution	dH:-308.1 (4SF)	0	MTD	6422
28	327	0	Inf. Dilution	dH:-308.1 (4SF)	0	MTD	6494
29	25	0	Inf. Dilution	Cp:96.5 (3SF) J/K	4	EOD	29025

Reaction No. 55092

$$\text{Mg(s)} + \text{N}_2(\text{g}) + 3\text{O}_2(\text{g}) = \text{Mg}_2\text{NO}_3\text{-1(2)}$$

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-162. (0.5SD)	4	ENS	802
2	25	0	Inf. Dilution	dH:-210.7 (0.05SD)	4	ENS	802

Reaction No. 55093

Mg(s) + N2(g) + 3<O2(g)> = Mg+2_NO3-1(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:103.2(4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:103.2(4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:102.4(4SF)	4	ENS	6422
4	27	0	Inf. Dilution	lgK:102.4(4SF)	4	ENS	6494
5	127	0	Inf. Dilution	lgK:67.97(4SF)	4	ENS	6422
6	127	0	Inf. Dilution	lgK:67.97(4SF)	4	ENS	6494
7	227	0	Inf. Dilution	lgK:47.38(4SF)	4	ENS	6422
8	227	0	Inf. Dilution	lgK:47.38(4SF)	4	ENS	6494
9	327	0	Inf. Dilution	lgK:33.74(4SF)	4	ENS	6422
10	327	0	Inf. Dilution	lgK:33.74(4SF)	4	ENS	6494
11	25	0	Inf. Dilution	dG:-141.(0.5SD)	4	ENS	802
12	25	0	Inf. Dilution	dG:-589.4(4SF)kJ	5	CRV	6330
13	25	0	Inf. Dilution	dG:-140.8(4SF)	4	EFE	6422
14	25	0	Inf. Dilution	dG:-140.8(4SF)	4	EFE	6494
15	25	0	Inf. Dilution	dH:-189.0(0.05SD)	4	ENS	802
16	25	0	Inf. Dilution	dH:-790.7(4SF)kJ	5	CRV	6330
17	25	0	Inf. Dilution	dH:-188.9(4SF)	4	MTD	6422
18	25	0	Inf. Dilution	dH:-189.0(4SF)	4	MTD	6494
19	27	0	Inf. Dilution	dH:-188.9(4SF)	4	MTD	6494
20	127	0	Inf. Dilution	dH:-188.7(4SF)	4	MTD	6422
21	127	0	Inf. Dilution	dH:-188.7(4SF)	4	MTD	6494
22	227	0	Inf. Dilution	dH:-187.9(4SF)	4	MTD	6422
23	227	0	Inf. Dilution	dH:-187.9(4SF)	4	MTD	6494
24	327	0	Inf. Dilution	dH:-186.5(4SF)	4	MTD	6422
25	327	0	Inf. Dilution	dH:-186.5(4SF)	4	MTD	6494

Reaction No. 55094							
Mg(s) + N2(g) + 6<O2(g)> + 6<H2(g)> = Mg+2_NO3-1(2)_H2O(6)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:365.3(4SF)	1	EES	
2	25	0	Inf. Dilution	dG:-497.(0.5SD)	2	ENS	802
3	25	0	Inf. Dilution	dG:-2084.0(5SF)kJ	3	MAC	30014
4	25	0	Inf. Dilution	dH:-624.6(0.05SD)	2	ENS	802
5	25	0	Inf. Dilution	dH:-2602.4(5SF)kJ	3	MAC	30014

Reaction No. 55096							
C(s) + 5<H2(g)> + Mg(s) + 4<O2(g)> = Mg+2_CO3-2_H2O(5)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:384.6(4SF)	1	EOR	
2	25	0	Inf. Dilution	dG:-526.(0.5SD)	1	ENS	802
3	25	0	Inf. Dilution	dG:-2198.(4SF)kJ	4	CRV	8739
4	25	0	Inf. Dilution	dG:-2199.5(5SF)kJ	3	EOD	29025
5	25	0	Inf. Dilution	dH:-2574.30(6SF)kJ	4	CRV	8739
6	25	0	Inf. Dilution	dH:-2605.3(5SF)kJ	1	EOD	29025
7	25	0	Inf. Dilution	Cp:284.1(4SF)J/K	4	EOD	29025

Reaction No. 55097							
Mg(s) + 1.5<O2(g)> + Si(s) = MgO.SiO2(Clinoen.,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:256.1(4SF)	2	ENS	6422
2	25	0	Inf. Dilution	lgK:255.4(4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:254.5(4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:253.8(4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:187.0(4SF)	2	ENS	6422
6	127	0	Inf. Dilution	lgK:186.5(4SF)	2	ENS	6494
7	227	0	Inf. Dilution	lgK:146.6(4SF)	1	ENS	6422
8	227	0	Inf. Dilution	lgK:146.2(4SF)	1	ENS	6494
9	327	0	Inf. Dilution	lgK:119.6(4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:119.3(4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-349.5(0.05SD)	0	ENS	802
12	25	0	Inf. Dilution	dG:-349.4(4SF)	2	EFE	6422
13	25	0	Inf. Dilution	dG:-348.61(5SF)	4	EFE	6482
14	25	0	Inf. Dilution	dG:-348.5(4SF)	4	EFE	6494
15	25	0	Inf. Dilution	dG:-1458.1(5SF)kJ	3	EOD	12843
16	25	0	Inf. Dilution	dH:-370.2(0.05SD)	4	ENS	802
17	25	0	Inf. Dilution	dH:-370.2(4SF)	4	MTD	6422
18	25	0	Inf. Dilution	dH:-369.49(5SF)	4	EFE	6482
19	25	0	Inf. Dilution	dH:-369.3(4SF)	4	MTD	6494
20	25	0	Inf. Dilution	dH:-1545.0(5SF)kJ	3	EOD	12843
21	127	0	Inf. Dilution	dH:-370.3(4SF)	1	MTD	6422

22	127	0	Inf. Dilution	dH:-369.3 (4SF)	1	MTD	6494
23	227	0	Inf. Dilution	dH:-370.2 (4SF)	0	MTD	6422
24	227	0	Inf. Dilution	dH:-369.3 (4SF)	0	MTD	6494
25	327	0	Inf. Dilution	dH:-370.1 (4SF)	0	MTD	6422
26	327	0	Inf. Dilution	dH:-369.2 (4SF)	0	MTD	6494

Reaction No. 55098							
2<Mg+2> + H+1(2)_SiH2O4-2 = 2MgO.SiO2(s) + 4<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-28.8 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-28.9 (0.05SD)	0	ENS	557
3	25	0	Inf. Dilution	lgK:-28.44 (4SF)	0	CRV	6405
Note (3): p. 245							
4	25	0	Inf. Dilution	lgK:-28.14 (4SF)	4	CRV	32224
5	25	0	CHEMVAL1	lgK:-29.98 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL2	lgK:-29.98 (0.01SD)	0	ENS	5156
7	25	0	CHEMVAL3	lgK:-29.98 (0.01SD)	0	ENS	5156
8	25	0	CHEMVAL4	lgK:-29.10 (0.01SD)	0	ENS	5156

Reaction No. 55102							
5<Mg+2> + OH-1 + 3<PO4-3> = Mg+2(5)_OH-1_PO4-3(3)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:47.4 (0.1SD)	4	ENS	5043


Reaction No. 55103							
5<Mg+2> + F-1 + 3<PO4-3> = Mg+2(5)_F-1_PO4-3(3)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:42.9 (0.1SD)	4	ENS	5043

Reaction No. 55104							
2<Mg+2> + F-1 + PO4-3 = Mg+2(2)_F-1_PO4-3_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.2 (0.1SD)	4	ENS	5043

Reaction No. 55300							
Mg+2 + SO3-2 = Mg+2_SO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:2.36(0.02SD)	4	MGL	5071
---	----	---	---------------	------------------	---	-----	------

Reaction No. 55374




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-21.7(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-7.8(0.05SD)	0	ENS	557

Reaction No. 55407




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO ₄	lgK:-1.45(1.SD)	4	MVP	399
2	25	3	NaClO ₄	lgK:-1.5(0.1SD)	4	ENS	5398
3	20	0	Ethanol Inf. Dilution	lgK:3.38(3SF)	4	MCN	140

Reaction No. 55499




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Cl-1 salt	lgK:2.59(0.03SD)	4	MIS	5378
2	20	0	Cl-1 salt	lgK:2.60(0.02SD)	4	MIS	5378
3	25	0	Inf. Dilution	lgK:2.8(0.03SD)	4	MCN	222
4	25	0	Cl-1 salt	lgK:2.63(0.02SD)	4	MIS	5378
5	25	0.1	NO ₃ -1 salt	lgK:1.44(0.01SD)	6	MCL	5304
6	25	3	Li+1 salt	lgK:0.04(1SF)	0	CRV	552
7	30	0	Cl-1 salt	lgK:2.65(0.03SD)	4	MIS	5378
8	35	0	Cl-1 salt	lgK:2.66(0.03SD)	4	MIS	5378
9	25	0.1	NO ₃ -1 salt	dH:0.79(0.1SD)	6	MCL	5304
10	25	3	LiCl	dH:-3.4(0.1SD)	5	MIS	5306

Reaction No. 55529




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	(H,Na)NO ₃	lgK:-39.1(0.05SD)	6	CMN	4496

Reaction No. 55590




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.6(0.1SD)	4	ENS	5522

Reaction No. 55591




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.0(0.1SD)	4	ENS	5522

Reaction No. 55726




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-673.1(0.1SD)	4	ENS	3006

Reaction No. 55727




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-461.5(0.1SD)	4	ENS	3006

Reaction No. 55728



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-240.9(0.1SD)	4	ENS	3006


Reaction No. 55751



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:378.9(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:379.0(4SF)	0	ENS	6422
3	27	0	Inf. Dilution	lgK:376.5(4SF)	0	ENS	6422
4	127	0	Inf. Dilution	lgK:275.3(4SF)	1	ENS	6422
5	227	0	Inf. Dilution	lgK:214.6(4SF)	1	ENS	6422
6	327	0	Inf. Dilution	lgK:174.1(4SF)	0	ENS	6422
7	25	0	Inf. Dilution	dG:-517.1(4SF)	0	EFE	6422
8	25	0	Inf. Dilution	dG:-2147.8(5SF) kJ	0	MEF	18180
9	25	0	Inf. Dilution	dG:-2148.9(5SF) kJ	0	EMD	18180
10	25	0	Inf. Dilution	dG:-2160.9(2.SD) kJ	6	EFE	26086
11	25	0	Inf. Dilution	dH:-556.0(4SF)	0	MTD	6422

12	25	0	Inf. Dilution	dH:-555.86(5SF)	0	ENS	6437
13	25	0	Inf. Dilution	dH:-2323.1(2.SD)kJ	6	EFE	26086
14	127	0	Inf. Dilution	dH:-555.8(4SF)	0	MTD	6422
15	227	0	Inf. Dilution	dH:-555.6(4SF)	0	MTD	6422
16	327	0	Inf. Dilution	dH:-555.3(4SF)	0	MTD	6422
17	25	0	Inf. Dilution	Cp:37.65(0.01SD)	2	ENS	802

Reaction No. 55753



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.4(3SF)	1	EOR	
2	25	3	NaClO4	lgK:18.2(0.05SD)	3	MSL	5398

Reaction No. 55813




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	NaCl/m	lgK:-12.81(0.06MD)	6	MHY	7321
2	0	0.1	NaCl/m	lgK:-13.02(0.06MD)	6	MHY	7321
3	0	0.3	NaCl/m	lgK:-13.09(0.06MD)	6	MHY	7321
4	0	1	NaCl/m	lgK:-13.10(0.07MD)	2	MHY	7321
5	0	5	NaCl/m	lgK:-13.75(0.13MD)	4	MHY	7321
6	5	0	Inert	lgK:-12.3(0.1SD)	0	MIS	5574
7	15	0	Inert	lgK:-11.8(0.1SD)	0	MIS	5574
8	25	0	Inf. Dilution	lgK:-11.68(4SF)	4	MPT	6428
9	25	0	Inf. Dilution	lgK:-11.44(4SF)	4	CRV	6478
10	25	0	Inf. Dilution	lgK:-11.44(4SF)	4	ENS	6496
11	25	0	Inf. Dilution	lgK:-11.42(4SF)	3	CRV	9402
12	25	0	Inf. Dilution	lgK:-11.44(4SF)	3	EOD	30627
13	25	0	Inf. Dilution	lgK:-11.8090(6SF)	3	EOD	30797
14	25	0	Inf. Dilution	lgK:-11.42(4SF)	4	CRV	32224
15	25	0	CHEMVAL1	lgK:-11.42(0.01SD)	0	ENS	5156
16	25	0	CHEMVAL2	lgK:-11.42(0.01SD)	0	ENS	5156
17	25	0	CHEMVAL3	lgK:-11.20(0.01SD)	0	ENS	5156
18	25	0	CHEMVAL4	lgK:-12.00(0.01SD)	0	ENS	5156
19	25	0	Inert	lgK:-11.4(0.1SD)	0	MIS	5574
20	25	0	NaCl/m	lgK:-11.68(0.05MD)	6	MHY	7321

21	25	0	UCT_Sea	lgK:-11.79(0.01SD)	3	EDH	5390
22	25	0.1	NaCl/m	lgK:-11.91(0.05MD)	6	MHY	7321
23	25	0.1	UCT_Sea	lgK:-11.99(0.01SD)	3	EDH	5390
24	25	0.2	UCT_Sea	lgK:-12.05(0.01SD)	3	EDH	5390
25	25	0.3	NaCl/m	lgK:-11.98(0.04MD)	6	MHY	7321
26	25	0.3	UCT_Sea	lgK:-12.10(0.01SD)	3	EDH	5390
27	25	0.4	UCT_Sea	lgK:-12.13(0.01SD)	3	EDH	5390
28	25	0.5	UCT_Sea	lgK:-12.16(0.01SD)	3	EDH	5390
29	25	0.6	UCT_Sea	lgK:-12.23(0.01SD)	3	EDH	5390
30	25	0.7	UCT_Sea	lgK:-12.23(0.01SD)	3	EDH	5390
31	25	0.7	Unknown	lgK:-11.70(4SF)	2	EOD	5644
32	25	1	NaCl/m	lgK:-11.99(0.06MD)	2	MHY	7321
33	25	5	NaCl/m	lgK:-12.51(0.10MD)	6	MHY	7321
34	35	0	Inert	lgK:-11.1(0.1SD)	2	MIS	5574
35	37	0.15	Blood Plasma	lgK:-11.5(0.05SD)	4	ENS	94
36	45	0	Inert	lgK:-10.6(0.1SD)	0	MIS	5574
37	50	0	NaCl/m	lgK:-10.73(0.05MD)	6	MHY	7321
38	50	0.1	NaCl/m	lgK:-10.97(0.05MD)	6	MHY	7321
39	50	0.3	NaCl/m	lgK:-11.05(0.04MD)	6	MHY	7321
40	50	1	NaCl/m	lgK:-11.06(0.05MD)	3	MHY	7321
41	50	5	NaCl/m	lgK:-11.47(0.08MD)	6	MHY	7321
42	75	0	NaCl/m	lgK:-9.92(0.05MD)	6	MHY	7321
43	75	0.1	NaCl/m	lgK:-10.17(0.05MD)	6	MHY	7321
44	75	0.3	NaCl/m	lgK:-10.26(0.05MD)	6	MHY	7321
45	75	1	NaCl/m	lgK:-10.28(0.05MD)	3	MHY	7321
46	75	5	NaCl/m	lgK:-10.61(0.08MD)	6	MHY	7321
47	100	0	NaCl/m	lgK:-9.22(0.06MD)	6	MHY	7321
48	100	0.1	NaCl/m	lgK:-9.49(0.05MD)	6	MHY	7321
49	100	0.3	NaCl/m	lgK:-9.58(0.04MD)	6	MHY	7321
50	100	1	NaCl/m	lgK:-9.62(0.05MD)	4	MHY	7321
51	100	5	NaCl/m	lgK:-9.87(0.08MD)	6	MHY	7321
52	150	0	NaCl/m	lgK:-8.06(0.07MD)	6	MHY	7321
53	150	0.1	NaCl/m	lgK:-8.37(0.07MD)	6	MHY	7321
54	150	0.3	NaCl/m	lgK:-8.49(0.06MD)	6	MHY	7321
55	150	1	NaCl/m	lgK:-8.56(0.06MD)	6	MHY	7321
56	150	5	NaCl/m	lgK:-8.72(0.10MD)	6	MHY	7321

57	200	0	NaCl/m	lgK:-7.14 (0.08MD)	6	MHY	7321
58	200	0.1	NaCl/m	lgK:-7.52 (0.08MD)	6	MHY	7321
59	200	0.3	NaCl/m	lgK:-7.67 (0.07MD)	6	MHY	7321
60	200	1	NaCl/m	lgK:-7.78 (0.06MD)	6	MHY	7321
61	200	5	NaCl/m	lgK:-7.90 (0.12MD)	6	MHY	7321
62	250	0	NaCl/m	lgK:-6.40 (0.09SD)	4	MHY	7321
63	250	0.1	NaCl/m	lgK:-6.87 (0.09MD)	6	MHY	7321
64	250	0.3	NaCl/m	lgK:-7.07 (0.08MD)	6	MHY	7321
65	250	1	NaCl/m	lgK:-7.24 (0.07MD)	6	MHY	7321
66	250	5	NaCl/m	lgK:-7.36 (0.14MD)	6	MHY	7321
67	0:25	5	NaCl/m	dH:79.5 (2.4MD) kJ	2	MTD	7321
68	0:50	1	NaCl/m	dH:70.4 (1.2MD) kJ	5	MTD	7321
69	0:100	0	NaCl/m	dH:70.1 (1.2MD) kJ	5	MTD	7321
70	0:100	0.1	NaCl/m	dH:70.1 (1.2MD) kJ	5	MTD	7321
71	0:100	0.3	NaCl/m	dH:70.1 (1.2MD) kJ	5	MTD	7321
72	25	0	Inf. Dilution	dH:16.75 (4SF)	4	MTD	6428
73	25	0	Inf. Dilution	dH:14.9 (3SF)	0	CRV	6478
74	50	5	NaCl/m	dH:79.6 (2.4MD) kJ	2	MTD	7321
75	75	5	NaCl/m	dH:79.7 (2.4MD) kJ	2	MTD	7321
76	75:100	1	NaCl/m	dH:70.5 (1.2MD) kJ	5	MTD	7321
77	100	5	NaCl/m	dH:79.8 (2.4MD) kJ	2	MTD	7321
78	150	0	NaCl/m	dH:70.2 (1.2MD) kJ	4	MTD	7321
79	150	0.1	NaCl/m	dH:70.2 (1.2MD) kJ	4	MTD	7321
80	150	0.3	NaCl/m	dH:70.3 (1.2MD) kJ	4	MTD	7321
81	150	1	NaCl/m	dH:70.6 (1.2MD) kJ	4	MTD	7321
82	150	5	NaCl/m	dH:80.1 (2.4MD) kJ	2	MTD	7321
83	200	0	NaCl/m	dH:70.8 (1.2MD) kJ	4	MTD	7321
84	200	0.1	NaCl/m	dH:70.7 (1.2MD) kJ	4	MTD	7321
85	200	0.3	NaCl/m	dH:70.7 (1.2MD) kJ	4	MTD	7321
86	200	1	NaCl/m	dH:71.0 (1.2MD) kJ	3	MTD	7321
87	200	5	NaCl/m	dH:80.4 (2.4MD) kJ	2	MTD	7321
88	250	0	NaCl/m	dH:72.7 (1.2MD) kJ	2	MTD	7321
89	250	0.1	NaCl/m	dH:72.4 (1.2MD) kJ	4	MTD	7321
90	250	0.3	NaCl/m	dH:72.2 (1.2MD) kJ	3	MTD	7321
91	250	1	NaCl/m	dH:72.2 (1.2MD) kJ	2	MTD	7321
92	250	5	NaCl/m	dH:81.0 (2.4MD) kJ	4	MTD	7321


93	0	5	NaCl/m	Cp:3. (1SF)	4	MTD	7321
94	25	0	Inf. Dilution	Cp:0.0 (1SF)	4	MTD	6428
95	25	5	NaCl/m	Cp:3. (1SF)	4	MTD	7321
96	50	5	NaCl/m	Cp:3. (1SF)	4	MTD	7321
97	75	0.3	NaCl/m	Cp:1. (1SF)	4	MTD	7321
98	75	1	NaCl/m	Cp:1. (1SF)	4	MTD	7321
99	75	5	NaCl/m	Cp:3. (1SF)	4	MTD	7321
100	100	0.1	NaCl/m	Cp:1. (1SF)	4	MTD	7321
101	100	0.3	NaCl/m	Cp:1. (1SF)	4	MTD	7321
102	100	1	NaCl/m	Cp:1. (1SF)	4	MTD	7321
103	100	5	NaCl/m	Cp:4. (1SF)	4	MTD	7321
104	150	0.1	NaCl/m	Cp:5. (1SF)	4	MTD	7321
105	150	0.3	NaCl/m	Cp:5. (1SF)	4	MTD	7321
106	150	1	NaCl/m	Cp:4. (1SF)	4	MTD	7321
107	150	5	NaCl/m	Cp:6. (1SF)	4	MTD	7321
108	200	0.1	NaCl/m	Cp:17. (2SF)	4	MTD	7321
109	200	0.3	NaCl/m	Cp:16. (2SF)	4	MTD	7321
110	200	1	NaCl/m	Cp:13. (2SF)	4	MTD	7321
111	200	5	NaCl/m	Cp:10. (2SF)	4	MTD	7321
112	250	0.1	NaCl/m	Cp:61. (2SF)	4	MTD	7321
113	250	0.3	NaCl/m	Cp:54. (2SF)	4	MTD	7321
114	250	1	NaCl/m	Cp:41. (2SF)	4	MTD	7321
115	250	5	NaCl/m	Cp:12. (2SF)	4	MTD	7321

Reaction No. 55814



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-17.7 (3SF)	1	ELC	
2	25	0	CHEMVAL1	lgK:-18.79 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:-18.79 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:-18.79 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:-16.20 (0.01SD)	0	ENS	5156

Reaction No. 55815



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0	Inf. Dilution	lgK:-8.9 (2SF)	1	ELC	
2	25	0	CHEMVAL1	lgK:-8.83 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:-8.83 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:-8.83 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:-8.59 (0.01SD)	0	ENS	5156

Reaction No. 55816							
$\text{Mg}+2 + 2\text{<H+1(2)<SiH2O4-2>} = \text{Mg}+2_{\text{H+1(2)<SiH2O4-2(2)<} + 2\text{<H+1>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-15.4 (3SF)	1	ELC	
2	25	0	CHEMVAL1	lgK:-15.12 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:-15.12 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:-15.12 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:-15.30 (0.01SD)	0	ENS	5156

Reaction No. 56081							
$\text{Mg}+2 + 3\text{<NO3-1>} + 27\text{<H+1>} + 24\text{<e-1>} = \text{Mg}+2_{\text{NH3(3)<} + 9\text{<H2O>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:329.8 (4SF)	1	ELC	
2	25	0	CHEMVAL4	lgK:329.00 (0.01SD)	0	ENS	5156

Reaction No. 56082							
$\text{Mg}+2 + \text{NO3-1} + 9\text{<H+1>} + 8\text{<e-1>} = \text{Mg}+2_{\text{NH3}} + 3\text{<H2O>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:110.(3SF)	1	ELC	
2	25	0	CHEMVAL4	lgK:110.00 (0.01SD)	0	ENS	5156

Reaction No. 56084							
$\text{Mg}+2 + 2\text{<NO3-1>} + 18\text{<H+1>} + 16\text{<e-1>} = \text{Mg}+2_{\text{NH3(2)<} + 6\text{<H2O>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:220.2 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:219.3 (4SF)	0	MGL	5156
3	25	0	CHEMVAL4	lgK:220.00 (0.01SD)	0	ENS	5156

Reaction No. 56096							
$\text{Mg}+2(2)_{\text{UO2+2(6)<OH-1(10)<SO4-2(3)<H2O(8)<(s)} + 10\text{<H+1>} = 3\text{<SO4-2>} + 18\text{<H2O>} + 2\text{<Mg+2>} + 6\text{<UO2+2>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	CHEMVAL1	lgK:-6.17 (0.01SD)	0	ENS	5156
2	25	0	CHEMVAL2	lgK:-6.17 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:-6.17 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:-6.00 (0.01SD)	4	ENS	5156

Reaction No. 56152



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:31.4 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:29.85 (4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:30.27 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:30.27 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:30.27 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:30.30 (0.01SD)	0	ENS	5156

Reaction No. 56153




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:47.4 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:45.39 (4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:48.74 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:48.74 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:48.74 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:45.80 (0.01SD)	0	ENS	5156

Reaction No. 56154



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:69.0 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:68.55 (4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:71.54 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:71.54 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:71.54 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:68.70 (0.01SD)	0	ENS	5156


Reaction No. 56172



Note: All log Ks in source [25435] should be ln Ks?

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:23.742 (5SF)	0	CRV	25435
2	25	0	Inf. Dilution	lgK:21.3 (3SF)	1	ELC	
3	25	0	Inf. Dilution	lgK:21.335 (5SF)	0	CRV	25435
4	25	0	Inf. Dilution	lgK:21.48 (4SF)	4	CRV	32224
5	25	0	CHEMVAL1	lgK:21.65 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL2	lgK:21.65 (0.01SD)	0	ENS	5156
7	25	0	CHEMVAL3	lgK:21.65 (0.01SD)	0	ENS	5156
8	25	0	CHEMVAL4	lgK:21.50 (0.01SD)	0	ENS	5156
9	60	0	Inf. Dilution	lgK:18.580 (5SF)	0	CRV	25435
10	100	0	Inf. Dilution	lgK:16.6 (3SF)	1	ELC	
11	100	0	Inf. Dilution	lgK:16.082 (5SF)	0	CRV	25435
12	150	0	Inf. Dilution	lgK:13.638 (5SF)	0	CRV	25435
13	200	0	Inf. Dilution	lgK:11.702 (5SF)	0	CRV	25435
14	250	0	Inf. Dilution	lgK:10.101 (5SF)	0	CRV	25435
15	300	0	Inf. Dilution	lgK:8.716 (4SF)	0	CRV	25435

Reaction No. 56173



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:36.9 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:38.42 (4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:37.02 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:37.02 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:37.02 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:36.30 (0.01SD)	0	ENS	5156

Reaction No. 56174



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.3 (3SF)	1	EES	
2	25	0	CHEMVAL1	lgK:21.20 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:21.20 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:21.20 (0.01SD)	0	ENS	5156

5	25	0	CHEMVAL4	lgK:16.70 (0.01SD)	0	ENS	5156
6	25	1	Unknown	lgK:17.4 (3SF)	1	EES	

Reaction No. 56175							
Mg+2_CO3-2_H2O(5)_(s) = Mg+2 + CO3-2 + 5<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-5.42 (3SF)	3	CRV	6330
Note (1): p. 8-58							
2	25	0	Inf. Dilution	lgK:-5.45 (3SF)	4	CRV	32224
3	25	0	CHEMVAL1	lgK:-4.54 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:-4.54 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:-4.54 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:-5.42 (0.01SD)	4	ENS	5156


Reaction No. 56176							
Mg+2(2)_OH-1(2)_CO3-2_H2O(3)_(s) + 2<H+1> = 2<Mg+2> + CO3-2 + 5<H2O >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.62 (3SF)	4	CRV	32224
2	25	0	CHEMVAL1	lgK:9.62 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:9.62 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:9.62 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:9.61 (0.01SD)	4	ENS	5156

Reaction No. 56177							
Ca+2_Mg+2(3)_CO3-2(4)_(s) = Ca+2 + 3<Mg+2> + 4<CO3-2>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:-30.01 (0.01SD)	0	ENS	5156
2	25	0	CHEMVAL2	lgK:-30.01 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:-30.01 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:-30.50 (0.01SD)	4	ENS	5156

Reaction No. 56178							
Mg+2_Cl-1(2)_(s) = Mg+2 + 2<Cl-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.00 (4SF)	4	CRV	32224
2	25	0	CHEMVAL1	lgK:21.98 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:21.98 (0.01SD)	0	ENS	5156


4	25	0	CHEMVAL3	lgK:21.98(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:22.00(0.01SD)	4	ENS	5156

Reaction No. 56179




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.24(4SF)	4	CRV	32224
2	25	0	CHEMVAL1	lgK:16.24(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:16.24(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:16.24(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:16.20(0.01SD)	4	ENS	5156

Reaction No. 56180




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.2(2SF)	1	ELC	
Note (1): Corresponds to dG0 from Schlaikjer et al. [17STK_30014]							
2	25	0	Inf. Dilution	lgK:12.88(4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:12.88(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:12.88(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:12.88(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:12.90(0.01SD)	0	ENS	5156

Reaction No. 56181



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.2(2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:7.43(3SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:7.43(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:7.43(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:7.43(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:7.44(0.01SD)	0	ENS	5156


Reaction No. 56182



Note: Solid is v. odd; extremely supersat'd; seemingly no supporting evidence; concluded that no such reaction occurs in solution PMM (6/6/13)


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:-2.20 (0.01SD)	0	ENS	5156
2	25	0	CHEMVAL2	lgK:-2.20 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:-2.20 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:-2.20 (0.01SD)	0	ENS	5156

Reaction No. 56183




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-9.85 (3SF)	2	CRV	32224
2	25	0	CHEMVAL1	lgK:-9.85 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:-9.85 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:-9.85 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:-9.77 (0.01SD)	2	ENS	5156

Reaction No. 56184




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:11.64 (4SF)	0	ENS	6405
3	25	0	CHEMVAL1	lgK:12.65 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:12.65 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:12.65 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:11.40 (0.01SD)	0	ENS	5156

Reaction No. 56185




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:72.8 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:67.75 (4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:80.39 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:80.39 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:80.39 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:80.40 (0.01SD)	0	ENS	5156

Reaction No. 56186




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:32.2(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:32.9(0.05SD)	0	ENS	557
3	25	0	Inf. Dilution	lgK:32.20(4SF)	0	ENS	6496
4	25	0	Inf. Dilution	lgK:31.52(4SF)	0	CRV	32224
5	25	0	CHEMVAL1	lgK:34.50(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL2	lgK:34.50(0.01SD)	0	ENS	5156
7	25	0	CHEMVAL3	lgK:34.50(0.01SD)	0	ENS	5156
8	25	0	CHEMVAL4	lgK:34.50(0.01SD)	0	ENS	5156
9	25	0	Inf. Dilution	dH:-46.8(3SF)	2	ENS	6496

Reaction No. 56187



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:36.24(0.01SD)	0	ENS	5156
2	25	0	CHEMVAL2	lgK:36.24(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:36.24(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:36.20(0.01SD)	4	ENS	5156

Reaction No. 56189



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-18.13(4SF)	1	ELC	
2	25	0	CHEMVAL2	lgK:-5.82(0.01SD)	0	ENS	5156
Note (2): lgK refers to reaction involving H+_PO4-3, not H+ + PO4-3							
3	25	0	CHEMVAL3	lgK:-5.82(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:-5.82(0.01SD)	0	ENS	5156

Reaction No. 56190



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:-9.22(0.01SD)	4	ENS	5156
2	25	0	CHEMVAL2	lgK:-9.22(0.01SD)	4	ENS	5156
3	25	0	CHEMVAL3	lgK:-9.22(0.01SD)	4	ENS	5156
4	25	0	CHEMVAL4	lgK:-9.22(0.01SD)	4	ENS	5156

Reaction No. 56191

Mg ₃ Si ₄ O ₁₀ (OH) ₂ ·3H ₂ O(s) + H ₂ O + 6<H+1> = 3<Mg+2> + 4<H+1(2)_SiH ₂ O ₄ -2 >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:29.86(0.01SD)	0	ENS	5156
2	25	0	CHEMVAL2	lgK:29.86(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:29.86(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:29.90(0.01SD)	4	ENS	5156

Reaction No. 56192							
Mg ₃ Si ₄ O ₁₀ (OH) ₂ (s) + 6<H+1> + 4<H ₂ O> = 3<Mg+2> + 4<H+1(2)_SiH ₂ O ₄ -2 >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.6(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:21.53(4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:24.45(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:24.45(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:24.45(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:19.60(0.01SD)	0	ENS	5156

Reaction No. 56193							
2MgO·2Al ₂ O ₃ ·5SiO ₂ (s) + 16<H+1> + 2<H ₂ O> = 2<Mg+2> + 4<Al+3> + 5<H+1(2)_SiH ₂ O ₄ -2 >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:50.6(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:45.5(0.05SD)	0	ENS	557
3	25	0	Inf. Dilution	lgK:53.88(4SF)	0	CRV	32224
4	25	0	CHEMVAL1	lgK:53.77(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL2	lgK:53.77(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL3	lgK:53.77(0.01SD)	0	ENS	5156
7	25	0	CHEMVAL4	lgK:49.40(0.01SD)	0	ENS	5156

Reaction No. 56248							
Mg+2_UO ₂ +2(2)_PO ₄ -3(2)_(s) = 2<UO ₂ +2> + Mg+2 + 2<PO ₄ -3>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-46.320(5SF)	3	CRV	31231
2	25	0	CHEMVAL2	lgK:-43.93(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:-43.93(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:-42.20(0.01SD)	0	ENS	5156

Reaction No. 56252							
--------------------	--	--	--	--	--	--	--

MgUO4(s) + 4<H+1> = Mg+2 + UO2+2 + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.4 (3SF)	1	ELC	
2	25	0	CHEMVAL1	lgK:23.20 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:23.20 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:23.20 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:23.30 (0.01SD)	2	ENS	5156

Reaction No. 56256							
Mg+2(2)_UO2+2_CO3-2(3)_(s) = UO2+2 + 2<Mg+2> + 3<CO3-2>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:-36.79 (0.01SD)	0	ENS	5156
2	25	0	CHEMVAL2	lgK:-36.79 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:-36.79 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:-36.80 (0.01SD)	4	ENS	5156

Reaction No. 56257							
Ca+2_Mg+2_UO2+2_CO3-2(3)_(s) = UO2+2 + Ca+2 + Mg+2 + 3<CO3-2>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:-37.86 (0.01SD)	0	ENS	5156
2	25	0	CHEMVAL2	lgK:-37.86 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:-37.86 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:-37.90 (0.01SD)	4	ENS	5156

Reaction No. 56314							
Mg+2_Br-1(2)_(s) = Mg+2 + 2<Br-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:27.87 (4SF)	4	CRV	32224
2	25	0	CHEMVAL4	lgK:27.80 (0.01SD)	4	ENS	5156

Reaction No. 56315							
Mg+2_Br-1(2)_H2O(6)_(s) = Mg+2 + 2<Br-1> + 6<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.307 (4SF)	5	MSL	14335
2	25	0	Inf. Dilution	lgK:5.19 (3SF)	4	CRV	32224
3	25	0	CHEMVAL4	lgK:5.22 (0.01SD)	4	ENS	5156
4	75	0	Inf. Dilution	lgK:5.242 (4SF)	3	MSL	27463

Reaction No. 56316							
$\text{Mg}^{+2}_{\text{I-1}(2)}(\text{s}) = \text{Mg}^{+2} + 2\text{I-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:34.8(3SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:2.78(3SF)	0	CRV	
Note (2): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
3	25	0	Inf. Dilution	lgK:35.13(4SF)	4	CRV	32224
4	25	0	CHEMVAL4	lgK:35.00(0.01SD)	1	ENS	5156

Reaction No. 56317							
$\text{Mg}^{+2}_{\text{NO3-1}(2)}(\text{s}) = \text{Mg}^{+2} + 2\text{NO3-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.38(3SF)	0	CRV	
Note (1): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
2	25	0	Inf. Dilution	lgK:14.3(3SF)	1	ERG	
3	25	0	Inf. Dilution	lgK:15.53(4SF)	4	CRV	32224
4	25	0	CHEMVAL4	lgK:15.50(0.01SD)	1	ENS	5156


Reaction No. 56318							
$\text{Mg}^{+2}_{\text{NO3-1}(2)}\text{H}_2\text{O}(6)(\text{s}) = \text{Mg}^{+2} + 2\text{NO3-1} + 6\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.49(3SF)	2	CRV	32224
2	25	0	CHEMVAL4	lgK:2.58(0.01SD)	2	ENS	5156

Reaction No. 56331							
$\text{Mg}_5\text{Al}_2\text{Si}_3\text{O}_{10}(\text{OH})_8(\text{s}) + 16\text{H}^{+1} = 5\text{Mg}^{+2} + 2\text{Al}^{+3} + 3\text{H}^{+1}(2)\text{SiH}_2\text{O}_4^{-2} + 6\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:61.6(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:71.92(4SF)	0	CRV	32224
3	25	0	CHEMVAL1	lgK:57.02(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:57.02(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:57.02(0.01SD)	0	ENS	5156

Reaction No. 56333							
$\text{Mg}^{+2} + 4\text{NO3-1} + 36\text{H}^{+1} + 32\text{e-1} = \text{Mg}^{+2}_{\text{NH3}(4)} + 12\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:439.0(4SF)	1	ELC	
2	25	0	CHEMVAL4	lgK:438.00(0.01SD)	0	ENS	5156

Reaction No. 56344




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-549.0(0.05SD)	5	ENS	557

Reaction No. 56345




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:955.3(4SF)	1	ERG	
2	25	0	Inf. Dilution	dG:-1305.0(0.05SD)	1	ENS	557

Reaction No. 56346



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2096.0(0.1SD)	0	ENS	557

Reaction No. 56347



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:11.64(4SF)	0	CRV	6405
3	25	0	Inf. Dilution	lgK:11.46(4SF)	4	CRV	32224
4	25	0	CHEMVAL1	lgK:13.04(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL2	lgK:13.04(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL3	lgK:13.04(0.01SD)	0	ENS	5156
7	25	0	CHEMVAL4	lgK:12.60(0.01SD)	0	ENS	5156


Reaction No. 56348



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:707.4(4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:706.4(4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:702.7(4SF)	4	ENS	6422
4	27	0	Inf. Dilution	lgK:701.7(4SF)	4	ENS	6494

5	127	0	Inf. Dilution	lgK:512.7 (4SF)	4	ENS	6422
6	127	0	Inf. Dilution	lgK:511.9 (4SF)	4	ENS	6494
7	227	0	Inf. Dilution	lgK:398.6 (4SF)	4	ENS	6422
8	227	0	Inf. Dilution	lgK:398.0 (4SF)	4	ENS	6494
9	327	0	Inf. Dilution	lgK:322.7 (4SF)	4	ENS	6422
10	327	0	Inf. Dilution	lgK:322.2 (4SF)	4	ENS	6494
11	25	0	Inf. Dilution	dG:-965.1 (0.05SD)	4	ENS	802
12	25	0	Inf. Dilution	dG:-965.1 (0.05SD)	5	ENS	802
13	25	0	Inf. Dilution	dG:-965.1 (4SF)	4	EFE	6422
14	25	0	Inf. Dilution	dG:-964.48 (5SF)	4	EFE	6482
15	25	0	Inf. Dilution	dG:-963.8 (4SF)	4	EFE	6494
16	25	0	GAMSPATH	dG:-4037. (4SF) kJ	3	CRV	12638
17	25	0	Inf. Dilution	dH:-1043.4 (0.1SD)	4	ENS	802
18	25	0	Inf. Dilution	dH:-1043.4 (0.1SD)	5	ENS	802
19	25	0	Inf. Dilution	dH:-1043. (4SF)	4	MTD	6422
20	25	0	Inf. Dilution	dH:-1042.8 (5SF)	4	ENS	6437
21	25	0	Inf. Dilution	dH:-1042.9 (5SF)	4	EFE	6482
22	25	0	Inf. Dilution	dH:-1042. (4SF)	4	MTD	6494
23	25	0	GAMSPATH	dH:-4364.40 (6SF) kJ	3	CRV	12638
24	127	0	Inf. Dilution	dH:-1044. (4SF)	4	MTD	6422
25	127	0	Inf. Dilution	dH:-1042. (4SF)	4	MTD	6494
26	227	0	Inf. Dilution	dH:-1043. (4SF)	4	MTD	6422
27	227	0	Inf. Dilution	dH:-1042. (4SF)	4	MTD	6494
28	327	0	Inf. Dilution	dH:-1042. (4SF)	4	MTD	6422
29	327	0	Inf. Dilution	dH:-1041. (4SF)	4	MTD	6494


Reaction No. 56371



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:59.82 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:59.44 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:44.38 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:35.27 (4SF)	0	ENS	6422
5	327	0	Inf. Dilution	lgK:29.16 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-81.7 (0.05SD)	4	ENS	802
7	25	0	Inf. Dilution	dG:-81.7 (0.05SD)	5	ENS	802

8	25	0	Inf. Dilution	dG: -341.8 (4SF) kJ	5	CRV	6330
9	25	0	Inf. Dilution	dG: -81.60 (4SF)	4	EFE	6422
10	25	0	Inf. Dilution	dH: -82.7 (0.1SD)	4	ENS	802
11	25	0	Inf. Dilution	dH: -82.7 (0.1SD)	5	ENS	802
12	25	0	Inf. Dilution	dH: -346.0 (4SF) kJ	5	CRV	6330
13	25	0	Inf. Dilution	dH: -82.6 (3SF)	4	MTD	6422
14	127	0	Inf. Dilution	dH: -83.2 (3SF)	1	MTD	6422
15	227	0	Inf. Dilution	dH: -83.6 (3SF)	0	MTD	6422
16	327	0	Inf. Dilution	dH: -83.9 (3SF)	0	MTD	6422

Reaction No. 56372



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK: 622.2 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK: 622.3 (4SF)	0	ERG	

Note (2): Was lgK=621.3 prev iter

3	25	0	Inf. Dilution	lgK: 620.0 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK: 615.9 (4SF)	0	ENS	6422
5	127	0	Inf. Dilution	lgK: 451.2 (4SF)	0	ENS	6422
6	227	0	Inf. Dilution	lgK: 352.4 (4SF)	0	ENS	6422
7	327	0	Inf. Dilution	lgK: 286.5 (4SF)	0	ENS	6422
8	25	0	Inf. Dilution	dG: -845.8 (0.05SD)	0	ENS	802
9	25	0	Inf. Dilution	dG: -845.8 (4SF)	0	EFE	6422
10	25	0	Inf. Dilution	dH: -903.6 (0.1SD)	0	ENS	802
11	25	0	Inf. Dilution	dH: -903.6 (4SF)	0	MTD	6422
12	127	0	Inf. Dilution	dH: -904.4 (4SF)	0	MTD	6422
13	227	0	Inf. Dilution	dH: -904.5 (4SF)	0	MTD	6422
14	327	0	Inf. Dilution	dH: -904.3 (4SF)	0	MTD	6422

Reaction No. 56373



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK: 971.0 (4SF)	0	ENS	6422
2	25	0	Inf. Dilution	lgK: 967.1 (4SF)	3	ENS	6494
3	27	0	Inf. Dilution	lgK: 964.6 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK: 960.7 (4SF)	0	ENS	6494

5	127	0	Inf. Dilution	lgK:706.8 (4SF)	0	ENS	6422
6	127	0	Inf. Dilution	lgK:703.8 (4SF)	2	ENS	6494
7	227	0	Inf. Dilution	lgK:552.1 (4SF)	0	ENS	6422
8	227	0	Inf. Dilution	lgK:549.8 (4SF)	1	ENS	6494
9	327	0	Inf. Dilution	lgK:449.0 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:447.1 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-1324.8 (0.05SD)	0	ENS	802
12	25	0	Inf. Dilution	dG:-1325. (4SF)	0	EFE	6422
13	25	0	Inf. Dilution	dG:-1318.8 (5SF)	0	EFE	6482
14	25	0	Inf. Dilution	dG:-1319. (4SF)	4	EFE	6494
15	25	0	GAMSPATH	dG:-5524. (4SF) kJ	0	CRV	12638
16	25	0	Inf. Dilution	dH:-1415.5 (0.1SD)	0	ENS	802
17	25	0	Inf. Dilution	dH:-1415. (4SF)	0	MTD	6422
18	25	0	Inf. Dilution	dH:-1410.3 (5SF)	4	ENS	6437
19	25	0	Inf. Dilution	dH:-1409.5 (5SF)	3	EFE	6482
20	25	0	Inf. Dilution	dH:-1410. (4SF)	4	MTD	6494
21	25	0	GAMSPATH	dH:-5903.3 (5SF) kJ	0	CRV	12638
22	127	0	Inf. Dilution	dH:-1416. (4SF)	0	MTD	6422
23	127	0	Inf. Dilution	dH:-1410. (4SF)	1	MTD	6494
24	227	0	Inf. Dilution	dH:-1416. (4SF)	0	MTD	6422
25	227	0	Inf. Dilution	dH:-1410. (4SF)	0	MTD	6494
26	327	0	Inf. Dilution	dH:-1415. (4SF)	0	MTD	6422
27	327	0	Inf. Dilution	dH:-1409. (4SF)	0	MTD	6494

Reaction No. 56374							
2<Mg(s)> + 4<Al(s)> + 5<Si(s)> + 9<O2(g)> = 2MgO.2Al2O3.5SiO2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1516. (4SF)	5	ENS	6422
2	25	0	Inf. Dilution	lgK:1516. (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:1506. (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:1506. (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:1107. (4SF)	5	ENS	6422
6	127	0	Inf. Dilution	lgK:1107. (4SF)	4	ENS	6494
7	227	0	Inf. Dilution	lgK:867.7 (4SF)	5	ENS	6422
8	227	0	Inf. Dilution	lgK:867.5 (4SF)	4	ENS	6494
9	327	0	Inf. Dilution	lgK:708.3 (4SF)	5	ENS	6422

10	327	0	Inf. Dilution	lgK:707.9(4SF)	4	ENS	6494
11	25	0	Inf. Dilution	dG:-2055.0(0.1SD)	0	ENS	802
12	25	0	Inf. Dilution	dG:-2068.(4SF)	5	EFE	6422
13	25	0	Inf. Dilution	dG:-2067.8(5SF)	4	EFE	6482
14	25	0	Inf. Dilution	dG:-2068.(4SF)	4	EFE	6494
15	25	0	Inf. Dilution	dH:-2177.0(0.1SD)	0	ENS	802
Note (15): Low wgt for internal consistency							
16	25	0	Inf. Dilution	dH:-2190.(4SF)	5	MTD	6422
17	25	0	Inf. Dilution	dH:-2190.(4SF)	4	ENS	6437
18	25	0	Inf. Dilution	dH:-2189.0(5SF)	4	EFE	6482
19	25	0	Inf. Dilution	dH:-2190.(4SF)	4	MTD	6494
20	127	0	Inf. Dilution	dH:-2190.(4SF)	5	MTD	6422
21	127	0	Inf. Dilution	dH:-2190.(4SF)	4	MTD	6494
22	227	0	Inf. Dilution	dH:-2189.(4SF)	5	MTD	6422
23	227	0	Inf. Dilution	dH:-2190.(4SF)	4	MTD	6494
24	327	0	Inf. Dilution	dH:-2187.(4SF)	5	MTD	6422
25	327	0	Inf. Dilution	dH:-2190.(4SF)	4	MTD	6494

Reaction No. 56375							
Mg(s) + 2<O2(g)> + U(s) = MgUO4(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-418.2(0.05SD)	5	ENS	802
2	25	0	Inf. Dilution	dG:-1749.60(6SF) kJ	5	CRV	20827
3	25	0	GAMSPATH	dG:-1750.(4SF) kJ	3	CRV	12638
4	25	0	Inf. Dilution	dH:-443.9(0.1SD)	5	ENS	802
5	25	0	GAMSPATH	dH:-1857.30(6SF) kJ	3	CRV	12638

Reaction No. 56376							
2<Mg(s)> + Ti(s) + 2<O2(g)> = Mg2TiO4(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:358.8(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:356.4(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:262.2(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:205.7(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:168.0(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-489.2(0.05SD)	4	ENS	802

7	25	0	Inf. Dilution	dG:-489.2 (0.05SD)	5	ENS	802
8	25	0	Inf. Dilution	dG:-489.4 (4SF)	4	EFE	6422
9	25	0	Inf. Dilution	dH:-517.5 (0.1SD)	4	ENS	802
10	25	0	Inf. Dilution	dH:-517.5 (0.1SD)	5	ENS	802
11	25	0	Inf. Dilution	dH:-517.3 (4SF)	4	MTD	6422
12	127	0	Inf. Dilution	dH:-517.2 (4SF)	4	MTD	6422
13	227	0	Inf. Dilution	dH:-517.0 (4SF)	4	MTD	6422
14	327	0	Inf. Dilution	dH:-516.7 (4SF)	4	MTD	6422

Reaction No. 56377							
Mg(s) + Ti(s) + 1.5<O2(g)> = MgTiO3(geik,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:260.0 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:260.0 (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:258.3 (4SF)	4	ENS	6422
4	27	0	Inf. Dilution	lgK:258.4 (4SF)	4	ENS	6494
5	127	0	Inf. Dilution	lgK:189.9 (4SF)	4	ENS	6422
6	127	0	Inf. Dilution	lgK:189.9 (4SF)	4	ENS	6494
7	227	0	Inf. Dilution	lgK:148.8 (4SF)	4	ENS	6422
8	227	0	Inf. Dilution	lgK:148.9 (4SF)	4	ENS	6494
9	327	0	Inf. Dilution	lgK:121.5 (4SF)	4	ENS	6422
10	327	0	Inf. Dilution	lgK:121.5 (4SF)	4	ENS	6494
11	25	0	Inf. Dilution	dG:-354.8 (0.05SD)	4	ENS	802
12	25	0	Inf. Dilution	dG:-354.8 (0.05SD)	5	ENS	802
13	25	0	Inf. Dilution	dG:-354.7 (4SF)	4	EFE	6422
14	25	0	Inf. Dilution	dG:-354.8 (4SF)	4	EFE	6494
15	25	0	Inf. Dilution	dH:-375.9 (0.1SD)	4	ENS	802
16	25	0	Inf. Dilution	dH:-375.9 (0.1SD)	5	ENS	802
17	25	0	Inf. Dilution	dH:-375.8 (4SF)	4	MTD	6422
18	25	0	Inf. Dilution	dH:-375.9 (4SF)	4	MTD	6494
19	127	0	Inf. Dilution	dH:-375.8 (4SF)	4	MTD	6422
20	127	0	Inf. Dilution	dH:-375.8 (4SF)	4	MTD	6494
21	227	0	Inf. Dilution	dH:-375.5 (4SF)	4	MTD	6422
22	227	0	Inf. Dilution	dH:-375.5 (4SF)	4	MTD	6494
23	327	0	Inf. Dilution	dH:-375.2 (4SF)	4	MTD	6422
24	327	0	Inf. Dilution	dH:-375.2 (4SF)	4	MTD	6494

Reaction No. 56378							
$2\text{Mg(s)} + 3.5\text{O}_2\text{(g)} + 2\text{V(s)} = \text{Mg}_2\text{V}_2\text{O}_7\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:463.4 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:460.4 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:336.9 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:262.9 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:213.5 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-632.2 (0.05SD)	4	ENS	802
7	25	0	Inf. Dilution	dG:-632.2 (0.05SD)	5	ENS	802
8	25	0	Inf. Dilution	dG:-632.2 (4SF)	4	EFE	6422
9	25	0	Inf. Dilution	dG:-632.1 (4SF)	5	CRV	22971
10	25	0	Inf. Dilution	dH:-677.8 (0.1SD)	4	ENS	802
11	25	0	Inf. Dilution	dH:-677.8 (0.1SD)	5	ENS	802
12	25	0	Inf. Dilution	dH:-677.9 (4SF)	4	MTD	6422
13	25	0	Inf. Dilution	dH:-677.7 (4SF)	5	CRV	22971
14	127	0	Inf. Dilution	dH:-677.8 (4SF)	4	MTD	6422
15	227	0	Inf. Dilution	dH:-677.6 (4SF)	4	MTD	6422
16	327	0	Inf. Dilution	dH:-677.3 (4SF)	4	MTD	6422

Reaction No. 56379							
$\text{Mg(s)} + \text{W(s)} + 2\text{O}_2\text{(g)} = \text{Mg}_2\text{WO}_4\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:246.0 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:244.4 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:178.4 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:138.9 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:112.5 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-339.6 (0.05SD)	0	ENS	802
7	25	0	Inf. Dilution	dG:-335.6 (4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dH:-366.3 (0.1SD)	3	ENS	802
9	25	0	Inf. Dilution	dH:-362.3 (4SF)	4	MTD	6422
10	127	0	Inf. Dilution	dH:-362.1 (4SF)	4	MTD	6422
11	227	0	Inf. Dilution	dH:-361.8 (4SF)	4	MTD	6422
12	327	0	Inf. Dilution	dH:-361.3 (4SF)	4	MTD	6422

Reaction No. 56380							
Mg(s) + 2<Cr(s)> + 2<O2(g)> = MgO.Cr2O3(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:292.5(4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:292.4(4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:290.6(4SF)	4	ENS	6422
4	27	0	Inf. Dilution	lgK:290.5(4SF)	4	ENS	6494
5	127	0	Inf. Dilution	lgK:212.9(4SF)	4	ENS	6422
6	127	0	Inf. Dilution	lgK:212.8(4SF)	4	ENS	6494
7	227	0	Inf. Dilution	lgK:166.3(4SF)	4	ENS	6422
8	227	0	Inf. Dilution	lgK:166.3(4SF)	4	ENS	6494
9	327	0	Inf. Dilution	lgK:135.3(4SF)	4	ENS	6422
10	327	0	Inf. Dilution	lgK:135.3(4SF)	4	ENS	6494
11	25	0	Inf. Dilution	dG:-398.9(0.05SD)	4	ENS	802
12	25	0	Inf. Dilution	dG:-398.9(0.05SD)	5	ENS	802
13	25	0	Inf. Dilution	dG:-399.0(4SF)	4	EFE	6422
14	25	0	Inf. Dilution	dG:-398.9(4SF)	4	EFE	6494
15	25	0	Inf. Dilution	dH:-426.3(0.1SD)	4	ENS	802
16	25	0	Inf. Dilution	dH:-426.3(0.1SD)	5	ENS	802
17	25	0	Inf. Dilution	dH:-426.4(4SF)	4	MTD	6422
18	25	0	Inf. Dilution	dH:-426.3(4SF)	4	MTD	6494
19	127	0	Inf. Dilution	dH:-426.3(4SF)	4	MTD	6422
20	127	0	Inf. Dilution	dH:-426.2(4SF)	4	MTD	6494
21	227	0	Inf. Dilution	dH:-425.9(4SF)	4	MTD	6422
22	227	0	Inf. Dilution	dH:-425.9(4SF)	4	MTD	6494
23	327	0	Inf. Dilution	dH:-425.5(4SF)	4	MTD	6422
24	327	0	Inf. Dilution	dH:-425.5(4SF)	4	MTD	6494

Reaction No. 56693							
Mg(s) + 3<O2(g)> + 2<V(s)> = Mg+2_VO3-1(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:357.2(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:354.9(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:259.0(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:201.6(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:163.3(4SF)	4	ENS	6422

6	25	0	Inf. Dilution	dG:-487.0(0.1SD)	4	ENS	3006
7	25	0	Inf. Dilution	dG:-487.4(4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dG:-487.4(4SF)	5	CRV	22971
9	25	0	Inf. Dilution	dH:-526.(3SF)	4	ENS	3006
10	25	0	Inf. Dilution	dH:-526.2(4SF)	4	MTD	6422
11	25	0	Inf. Dilution	dH:-526.2(4SF)	5	CRV	22971
12	127	0	Inf. Dilution	dH:-526.1(4SF)	4	MTD	6422
13	227	0	Inf. Dilution	dH:-525.8(4SF)	4	MTD	6422
14	327	0	Inf. Dilution	dH:-525.3(4SF)	4	MTD	6422

Reaction No. 56758							
$\text{Mg}+2 + 2\langle\text{VO}_2+1\rangle - 4\langle\text{H}+1\rangle + 2\langle\text{H}_2\text{O}\rangle = \text{Mg}+2_ \text{VO}_3-1(2)_ (s)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-11.3(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-11.28(0.01SD)	0	ENS	766
3	25	0	Inf. Dilution	dH:32.66(0.01SD)	3	ENS	766

Reaction No. 56770							
$\text{Mg}+2_ \text{V}_12\text{O}_31-2_ (s) + 14\langle\text{H}+1\rangle = 12\langle\text{VO}_2+1\rangle + \text{Mg}+2 + 7\langle\text{H}_2\text{O}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	0.01:0.5	HNO3	lgK:-5.3(0.1SD)	0	MSL	5167
2	25	0	Inf. Dilution	lgK:-8.9(2SF)	1	ELC	

Reaction No. 56771							
$\text{H}+1(2)_ \text{V}_12\text{O}_31-2_ (s) + \text{Mg}+2 = \text{Mg}+2_ \text{V}_12\text{O}_31-2_ (s) + 2\langle\text{H}+1\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	0.01:0.5	HNO3	lgK:0.4(0.1SD)	5	MSL	5167
2	25	0	Inf. Dilution	lgK:0.663(3SF)	2	EAE	

Reaction No. 57062							
$\text{Mg}+2_ \text{NH}_3(3) + \text{NH}_3 = \text{Mg}+2_ \text{NH}_3(4)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	2	NH4NO3	lgK:-0.7(0.1SD)	5	MGL	5646
2	25	0	Inf. Dilution	lgK:-0.7(3SF)	2	EAE	

Reaction No. 57187							
$\text{S}_2\text{O}_3-2 + \text{Mg}+2 = \text{Mg}+2_ \text{S}_2\text{O}_3-2$							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.81(0.02SD)	7	CMN	140
2	25	0	Inf. Dilution	lgK:1.84(3SF)	4	MSL	140
3	25	0	Inf. Dilution	lgK:1.79(3SF)	4	MSP	140
4	25	0	Inf. Dilution	lgK:1.839(4SF)	4	EOD	12002
5	25	0	Inf. Dilution	lgK:1.84(3SF)	4	CRV	18273
Note (5): Table 3, p. 85							
6	25	0.5	NO3-1 salt	lgK:0.56(0.01SD)	6	MCL	4609
7	25	0.5	NO3-1 salt	dH:0.40(0.01SD)	6	MCL	4609
8	20		Ethanol:Water 44:56Wgt	lgK:3.31(3SF)	5	MCN	140
9	25		Ethanol:Water 44:56Wgt	lgK:3.33(3SF)	5	MCN	140
10	30		Ethanol:Water 44:56Wgt	lgK:3.36(3SF)	5	MCN	140
11	25		Ethanol:Water 50:50Wgt	lgK:3.39(3SF)	5	MSP	140

Reaction No. 57446							
Mg+2_H+1_NH3_Cl-1(3)_H2O(6)_(s) = H+1_NH3 + Mg+2 + 3<Cl-1> + 6<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.165(4SF)	5	MSL	14335

Reaction No. 57672							
Mg+2_SeO3-2_H2O(6)_(s) = Mg+2 + SeO3-2 + 6<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:-5.36(0.05SD)	4	MSL	931
2	25	0	Inf. Dilution	lgK:-5.36(3SF)	4	MSL	12931
3	25	0	Inf. Dilution	lgK:-5.36(3SF)	3	EOD	32222
4	25	0	Inf. Dilution	dH:15.877(0.654SD)kJ	3	EOD	32222

Reaction No. 57721							
Mg+2 + NO2-1 = Mg+2_NO2-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.(1SF)	1	EAC	
2	25	5.8	Unknown	lgK:0.061(2SF)	0	MSP	2261
Note (2): In error - value not logged							
3	25	8.2	ClO4-1 salt	lgK:-1.21(0.02SD)	5	MRM	5374


Reaction No. 57797							
$\text{Mg}+2_ \text{H}+1_ \text{NH}_3_ \text{PO}_4-3_ \text{H}_2\text{O}(6)_ (\text{s}) + 2<\text{H}+1> = \text{Mg}+2 + \text{H}+1_ \text{NH}_3 + \text{H}+1(2)_ \text{PO}_4-3 + 6<\text{H}_2\text{O} >$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.4(0.1SD)	3	ENS	557
2	25	0	Inf. Dilution	lgK:6.4(0.1SD)	4	ENS	557

Reaction No. 57916							
$\text{Mg}+2 + \text{Fe}+2_ \text{CN}-1(6) = \text{Fe}+2_ \text{Mg}+2_ \text{CN}-1(6)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15.2	0	Inf. Dilution	lgK:3.7(0.05SD)	5	MPT	5593
2	24.8	0	Inf. Dilution	lgK:3.8(0.05SD)	5	MPT	5593
3	35	0	Inf. Dilution	lgK:3.9(0.05SD)	5	MPT	5593
4	25	0	Inf. Dilution	dH:4.3(0.05SD)	5	MAC	5593

Reaction No. 57959							
$\text{Mg}(\text{s}) + 0.5<\text{O}_2(\text{g})> = \text{MgO}(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:99.68(4SF)	2	ENS	6422
2	25	0	Inf. Dilution	lgK:99.74(4SF)	0	ENS	6494
3	27	0	Inf. Dilution	lgK:99.03(4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:99.09(4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:72.85(4SF)	4	ENS	6422
6	127	0:4	Inf. Dilution	lgK:72.90(4SF)	2	ENS	6494
7	227	0	Inf. Dilution	lgK:57.15(4SF)	3	ENS	6422
8	227	0:4	Inf. Dilution	lgK:57.19(4SF)	3	ENS	6494
9	327	0	Inf. Dilution	lgK:46.69(4SF)	0	ENS	6422
10	327	0:4	Inf. Dilution	lgK:46.72(4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-569.3(4SF) kJ	5	CRV	6330
12	25	0	Inf. Dilution	dG:-136.0(4SF)	2	EFE	6422
13	25	0	Inf. Dilution	dG:-136.04(5SF)	4	EFE	6482
14	25	0	Inf. Dilution	dG:-569.43(5SF) kJ	2	EFE	7275
15	25	0	Inf. Dilution	dG:-569.3(4SF) kJ	5	CRV	8695
16	25	0	Inf. Dilution	dG:-569.3(4SF) kJ	6	CRV	8746
17	25	0	Inf. Dilution	dG:-569.31(0.305SD) kJ	6	CRV	14923
18	25	0	Inf. Dilution	dG:-569.31(5SF) kJ	5	EOD	29520
19	25	0	Inf. Dilution	dG:-136.05(5SF)	3	CRV	31291

20	25	0:4	Inf. Dilution	dG:-136.1(4SF)	2	EFE	6494
21	25	0	Inf. Dilution	dH:-143.8(0.07SD)	7	CRV	5605
22	25	0	Inf. Dilution	dH:-601.6(4SF)kJ	5	CRV	6330
23	25	0	Inf. Dilution	dH:-143.7(4SF)	2	MTD	6422
24	25	0	Inf. Dilution	dH:-143.76(5SF)	4	EFE	6482
25	25	0	Inf. Dilution	dH:-601.70(5SF)kJ	5	EFE	7275
26	25	0	Inf. Dilution	dH:-601.60(0.30MD)kJ	6	CRV	8746
27	25	0	Inf. Dilution	dH:-601.60(0.300SD)kJ	6	CRV	14923
28	25	0	Inf. Dilution	dH:-601.60(5SF)kJ	5	EOD	29520
29	25	0	Inf. Dilution	dH:-143.76(5SF)	3	CRV	31291
30	25	0:4	Inf. Dilution	dH:-143.8(4SF)	4	MTD	6494
31	127	0	Inf. Dilution	dH:-143.7(4SF)	4	MTD	6422
32	127	0:4	Inf. Dilution	dH:-143.8(4SF)	4	MTD	6494
33	227	0	Inf. Dilution	dH:-143.7(4SF)	3	MTD	6422
34	227	0:4	Inf. Dilution	dH:-143.7(4SF)	3	MTD	6494
35	327	0	Inf. Dilution	dH:-143.6(4SF)	0	MTD	6422
36	327	0:4	Inf. Dilution	dH:-143.7(4SF)	0	MTD	6494
37	25	0	Inf. Dilution	Cp:37.237(0.1SD)J/K	5	CRV	27292

Reaction No. 57960



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:187.7(4SF)	2	ENS	6422
2	25	0	Inf. Dilution	lgK:187.6(4SF)	2	ENS	6494
3	27	0	Inf. Dilution	lgK:186.4(4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:186.4(4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:137.5(4SF)	2	ENS	6422
6	127	0	Inf. Dilution	lgK:137.5(4SF)	2	ENS	6494
7	227	0	Inf. Dilution	lgK:108.2(4SF)	1	ENS	6422
8	227	0	Inf. Dilution	lgK:108.2(4SF)	1	ENS	6494
9	327	0	Inf. Dilution	lgK:88.65(4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:88.64(4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-1071.1(5SF)kJ	2	CRV	6330
12	25	0	Inf. Dilution	dG:-256.0(4SF)	4	EFE	6422
13	25	0	Inf. Dilution	dG:-256.0(4SF)	4	EFE	6494
14	25	0	Inf. Dilution	dG:-1071.(4SF)kJ	5	CRV	8746

15	25	0	Inf. Dilution	dG: -1071.1 (1.210SD) kJ	5	CRV	14923
16	25	0	Inf. Dilution	dH: -269. (0.3SD)	3	CRV	5605
17	25	0	Inf. Dilution	dH: -1124.2 (5SF) kJ	5	CRV	6330
18	25	0	Inf. Dilution	dH: -268.7 (4SF)	4	MTD	6422
19	25	0	Inf. Dilution	dH: -268.7 (4SF)	4	MTD	6494
20	25	0	Inf. Dilution	dH: -1124.2 (1.2MD) kJ	6	CRV	8746
21	25	0	Inf. Dilution	dH: -1124.2 (1.200SD) kJ	6	CRV	14923
22	127	0	Inf. Dilution	dH: -268.5 (4SF)	2	MTD	6422
23	127	0	Inf. Dilution	dH: -268.5 (4SF)	1	MTD	6494
24	227	0	Inf. Dilution	dH: -268.3 (4SF)	0	MTD	6422
25	227	0	Inf. Dilution	dH: -268.3 (4SF)	0	MTD	6494
26	327	0	Inf. Dilution	dH: -268.0 (4SF)	0	MTD	6422
27	327	0	Inf. Dilution	dH: -268.0 (4SF)	0	MTD	6494
28	25	0	Inf. Dilution	Cp: 61.512 (0.15SD) J/K	5	CRV	27292

Reaction No. 58001

Mg(s) = Mg(g)

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG: 112.5 (4SF) kJ	5	CRV	6330
2	25	0	Inf. Dilution	dG: 113.10 (5SF) kJ	3	EFE	7275
3	25	0	Inf. Dilution	dG: 112.5 (4SF) kJ	6	CRV	8746
4	25	0	Inf. Dilution	dG: 112.52 (0.801SD) kJ	6	CRV	14923
5	25	0	Inf. Dilution	dH: 35.1 (0.2SD)	7	CRV	5605
6	25	0	Inf. Dilution	dH: 147.1 (4SF) kJ	5	CRV	6330
7	25	0	Inf. Dilution	dH: 147.70 (5SF) kJ	3	EFE	7275
8	25	0	Inf. Dilution	dH: 147.1 (0.8MD) kJ	6	CRV	8746
9	25	0	Inf. Dilution	dH: 147.10 (0.800SD) kJ	6	CRV	14923
10	25	0	Inf. Dilution	Cp: 20.786 (0.001SD) J/K	5	CRV	27292

Reaction No. 58004

3<Mg+2> + 2<PO4-3> + 22<H2O> = Mg+2(3)_PO4-3(2)_H2O(22)_(s)

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK: 23.1 (0.1SD)	3	ENS	5606


Reaction No. 58067

Ca+2 + Mg+2 + CO3-2 = Ca+2_Mg+2_CO3-2

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	UCT_Sea	lgK:4.18 (0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:3.40 (0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:3.25 (0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:3.16 (0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:3.11 (0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:3.07 (0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:3.04 (0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:3.02 (0.01SD)	4	EDH	5390

Reaction No. 58154



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:2.51 (0.07SD)	5	MGL	1275
2	25	0.1	KNO3	lgK:2.70 (0.07SD)	5	MGL	1275
3	35	0.1	KNO3	lgK:2.84 (0.07SD)	5	MGL	1275
4	45	0.1	KNO3	lgK:3.02 (0.07SD)	5	MGL	1275
5	25	0.1	KNO3	dH:29.4 (3SF) kJ	5	MTD	1275


Reaction No. 58168



Note: Unreliable species Mg+2(2)_CO3-2, not found anywhere else in JPD. Appears in the NIST database (based on S&M Crit. Vols), coming originally from Pytkowicz & Hawley [74PyH_4996].

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:3.68 (0.01SD)	0	EDH	5390
2	25	0.1	UCT_Sea	lgK:2.94 (0.01SD)	0	EDH	5390
3	25	0.2	UCT_Sea	lgK:2.80 (0.01SD)	0	EDH	5390
4	25	0.3	UCT_Sea	lgK:2.72 (0.01SD)	0	EDH	5390
5	25	0.4	UCT_Sea	lgK:2.67 (0.01SD)	0	EDH	5390
6	25	0.5	UCT_Sea	lgK:2.63 (0.01SD)	0	EDH	5390
7	25	0.6	UCT_Sea	lgK:2.61 (0.01SD)	0	EDH	5390
8	25	0.7	UCT_Sea	lgK:2.59 (0.01SD)	0	EDH	5390
9	25	0.7	Unknown	lgK:2.59 (3SF)	0	CRV	7271

Reaction No. 58169



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0	Inf. Dilution	lgK:0.72 (2SF)	4	MSL	140
2	25	0	Inf. Dilution	lgK:0.68 (2SF)	4	EBU	6372
3	25	0	UCT_Sea	lgK:0.72 (0.01SD)	4	EDH	5390
4	25	0.1	UCT_Sea	lgK:0.38 (0.01SD)	4	EDH	5390
5	25	0.2	UCT_Sea	lgK:0.32 (0.01SD)	4	EDH	5390
6	25	0.3	UCT_Sea	lgK:0.30 (0.01SD)	4	EDH	5390
7	25	0.4	UCT_Sea	lgK:0.28 (0.01SD)	4	EDH	5390
8	25	0.5	UCT_Sea	lgK:0.27 (0.01SD)	4	EDH	5390
9	25	0.6	UCT_Sea	lgK:0.27 (0.01SD)	4	EDH	5390
10	25	0.7	UCT_Sea	lgK:0.26 (0.01SD)	4	EDH	5390

Reaction No. 58172

Mg+2_Uridine-1 + Bipy = Mg+2_Bipy_Uridine-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:2.87 (0.07SD)	5	MGL	1275
2	25	0.1	KNO3	lgK:3.00 (0.07SD)	5	MGL	1275
3	35	0.1	KNO3	lgK:3.12 (0.07SD)	5	MGL	1275
4	45	0.1	KNO3	lgK:3.22 (0.07SD)	5	MGL	1275
5	25	0.1	KNO3	dH:20.5 (3SF) kJ	5	MTD	1275

Reaction No. 58295

Mg+2_Oxalic-2(s) = Mg+2 + Oxalic-2

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-6.15 (3SF)	0	CRV	
Note (1): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
2	25	0	Inf. Dilution	lgK:-4.1 (2SF)	4	ENS	5648
3	25	0	Inf. Dilution	lgK:-4.07 (3SF)	4	CRV	22551

Reaction No. 58417

Mg+2_P2O7-4 + P2O7-4 = Mg+2_P2O7-4(2)

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.5 (1SF)	1	EOR	
2	25	1	Me4NBr	lgK:2.33 (3SF)	2	MGL	264
3	25	1	Me4NCl	lgK:2.34 (3SF)	2	MGL	140


Reaction No. 58436

P3O9-3 + Mg+2 = Mg+2_P3O9-3

--	--	--	--	--	--	--	--


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.11 (3SF)	2	MHY	140
2	23	0.1	NH ₄ Cl	lgK:2.74 (3SF)	0	MSP	140
3	25	0	Inf. Dilution	lgK:3.31 (3SF)	2	MCN	140
4	25	0.1	Me ₄ N ⁺ salt	lgK:1.80 (3SF)	0	CRV	552
5	25	1	Me ₄ N ⁺ salt	lgK:1.50 (3SF)	0	CRV	552

Reaction No. 58444




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me ₄ NBr	lgK:2.13 (3SF)	4	MGL	140
2	25	1	Me ₄ NCl	lgK:2.13 (3SF)	4	MGL	274
3	65	1	Me ₄ NBr	lgK:2.12 (3SF)	4	MGL	140

Reaction No. 58498




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	-3			lgK:1.03 (3SF)	3	MFP	140
2	0	0	Inf. Dilution	lgK:0.18 (2SF)	4	MDG	8675
3	25	0	Inf. Dilution	lgK:0.18 (2SF)	4	MDG	8675

Reaction No. 58603




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	Pr ₄ NCl	lgK:1.301 (4SF)	4	MGL	257

Reaction No. 58689



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3. (1SF)	3	MGL	931

Reaction No. 58806



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.18 (2SF)	2	EBU	6372
2	20		Ethanol	lgK:3.29 (3SF)	4	MCN	140

Reaction No. 58864							
2<DTPA-5> + Mg+2 = Mg+2_DTPA-5 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.4 (3SF)	2	EAE	
2	37	0.15	NaCl	lgK:10.6 (0.06SD)	5	MGL	1940

Reaction No. 58888							
Fe+2_Mg+2_CN-1 (6) + 2<e-1> = Mg(s) + Fe+2_CN-1 (6)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:-2.478 (4SF)	5	MEF	778

Reaction No. 58915							
SCN-1 + Mg+2 = Mg+2_SCN-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.6	Unknown	lgK:-1.3 (2SF)	0	MIR	30045
2	25	3	NaClO4	lgK:-0.91 (0.19SD)	5	MEF	399
3	25	3	NaClO4	lgK:-0.9 (1SF)	4	CRV	552
4	20		DMF	lgK:1.7 (2SF)	3	EES	5722

Reaction No. 59059							
Mg+2_5ATP-4 + NorEpinephrine-2 = Mg+2_NorEpinephrine-2_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:2. (0.3SD)	5	MGL	5977


Reaction No. 59060							
Mg+2_5ATP-4 + Tyramine-1 = Mg+2_Tyramine-1_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:2.6 (0.04SD)	5	ENS	5977

Reaction No. 59062							
Mg+2_5ATP-4 + Octopamine-1 = Mg+2_Octopamine-1_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:1.93 (3SF)	5	ENS	5977

Reaction No. 59063							
Mg+2_5ATP-4 + Epinephrine-2 = Mg+2_Epinephrine-2_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	1	KNO3	lgK:3.0(0.08SD)	5	ENS	5977
---	----	---	------	-----------------	---	-----	------

Reaction No. 59478



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:5.55(3SF)	4	MGL	905

Reaction No. 59536




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:5.36(3SF)	4	MGL	905

Reaction No. 59676




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.2	Me4NBr	lgK:-9.03(3SF)	4	MCL	1971

Reaction No. 59679




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	NaCl	lgK:0.04(1SF)	4	MGL	1437

Reaction No. 59682




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	NaCl	lgK:-0.30(2SF)	4	MGL	1437

Reaction No. 59683



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:0.2(0.4MD)	5	MGL	6118
2	25	0.2	NaCl	lgK:-0.29(2SF)	4	MGL	1437

Reaction No. 59685



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	NaCl	lgK:0.63(2SF)	4	MGL	1437

Reaction No. 59693							
$\text{Mg}+2_5\text{GTP}-4 + \text{H}_2\text{O} = \text{Mg}+2_0\text{H}-1_5\text{GTP}-4 + \text{H}+1$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.2	Me4NBr	lgK:-9.41 (3SF)	4	MCL	1971

Reaction No. 60219							
$\text{H}+1 + \text{Histamine} + \text{Mg}+2 = \text{Mg}+2_0\text{H}+1_0\text{Histamine}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8 (3SF)	2	EAE	
2	35	0.1	KNO3	lgK:12.25 (4SF)	3	CRV	5406

Reaction No. 60258							
$\text{Mg}+2_0\text{VO}3-1(2)_0(\text{s}) + 2\text{H}_2\text{O} = \text{Mg}+2 + 2\text{H}+1(2)_0\text{VO}4-3>$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.3 (2SF)	1	ELC	
2	25	0	Unknown	lgK:-3.8 (2SF)	0	ENS	6325


Reaction No. 60259							
$\text{Mg}+2(2)_0\text{V}207-4_0(\text{s}) + 2\text{H}+1 + \text{H}_2\text{O} = 2\text{Mg}+2 + 2\text{H}+1(2)_0\text{VO}4-3>$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.7 (3SF)	1	ELC	
2	25	0	Unknown	lgK:1.5 (2SF)	0	ENS	6325

Reaction No. 60312							
$1\text{GlucoseOPO}3-2 + \text{Mg}+2 = \text{Mg}+2_1\text{GlucoseOPO}3-2$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:2.386 (4SF)	5	MHY	4852
2	20	0	Inf. Dilution	lgK:2.448 (4SF)	5	MHY	4852
3	30	0	Inf. Dilution	lgK:2.520 (4SF)	5	MHY	4852
4	40	0	Inf. Dilution	lgK:2.600 (4SF)	5	MHY	4852
5	50	0	Inf. Dilution	lgK:2.690 (4SF)	5	MHY	4852

Reaction No. 60313							
$2\text{GlycerolOPO}3-2 + \text{Mg}+2 = \text{Mg}+2_2\text{GlycerolOPO}3-2$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:2.371 (4SF)	5	MHY	4852
2	20	0	Inf. Dilution	lgK:2.447 (4SF)	5	MHY	4852


3	30	0	Inf. Dilution	lgK:2.532 (4SF)	5	MHY	4852
4	40	0	Inf. Dilution	lgK:2.624 (4SF)	5	MHY	4852
5	50	0	Inf. Dilution	lgK:2.723 (4SF)	5	MHY	4852

Reaction No. 60323




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.7 (3SF)	3	CRV	2556

Reaction No. 60371



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.9 (2SF)	2	EOR	
2	25	3	NaClO4	lgK:-0.3 (1SF)	4	CRV	2556
3	100	0	Inf. Dilution	lgK:-2.9 (2SF)	1	EOR	

Reaction No. 60372




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.3 (3SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:16.28 (4SF)	0	ENS	6405
3	25	0	Inf. Dilution	lgK:16.3 (3SF)	0	CRV	6405
4	25	3	Inert	lgK:17.1 (3SF)	1	EOR	
5	25	3	NaCl	lgK:16.1 (3SF)	0	CRV	2556
6	25	3	NaClO4	lgK:18.1 (3SF)	0	CRV	2556
7	37	0	Inf. Dilution	lgK:16.43 (4SF)	2	CRV	28703
8	100	0	Inf. Dilution	lgK:14.9 (3SF)	1	EOR	

Reaction No. 60373



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-9.2 (2SF)	4	CRV	2556
2	25	1	Unknown	lgK:-9.38 (3SF)	4	CRV	2556


Reaction No. 60773



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:13.4 (3SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:12.83 (4SF)	0	EPZ	6219
3	25	3	NaClO4/m	lgK:13.14 (4SF)	5	MSL	6219
4	100	3	Inert	lgK:13.7 (3SF)	1	EOR	

Reaction No. 60774




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.42 (3SF)	3	EPZ	6219

Reaction No. 60775




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.34 (4SF)	4	EPZ	6219
2	25	3	NaClO4/m	lgK:12.56 (4SF)	5	MSL	6219

Reaction No. 60776




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.24 (3SF)	0	EPZ	6219
2	25	0	Inf. Dilution	lgK:9.41 (3SF)	0	EPZ	6219
3	25	0	Inf. Dilution	lgK:9.86 (3SF)	3	EPZ	6219
4	25	3	NaClO4/m	lgK:9.54 (3SF)	0	MSL	6219
5	25	3	NaClO4/m	lgK:10.04 (4SF)	0	MSL	6219
6	25	3	NaClO4/m	lgK:9.42 (3SF)	4	MSL	6219

Reaction No. 60777



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.18 (4SF)	5	EPZ	6219
2	25	3	NaClO4/m	lgR:14.67 (4SF)	6	MSL	6219

Reaction No. 60778



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8 (3SF)	1	ELC	
2	50	3	NaClO4/m	lgK:10.36 (0.03SD)	6	MSL	6218


Reaction No. 60779							
C(s) + 0.25<Ca(s)> + 0.75<Mg(s)> + 1.5<O2(g)> = Ca+2(0.25)_Mg+2(0.75)_CO3-2_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-251.9(4SF)	3	EFE	336
2	25	0	Inf. Dilution	dG:-249.8(4SF)	5	EFE	6218
3	25	0	Inf. Dilution	dG:-249.4(4SF)	5	EFE	6347
4	25	0	Inf. Dilution	dG:-1048.9(6.4SD)kJ	5	MEF	6659
5	25	0	Inf. Dilution	dG:-1052.(4SF)kJ	5	CRV	8739
6	25	0	GAMSPATH	dG:-1128.8(5SF)kJ	0	CRV	12638
Note (6): Low wgt for internal consistency							
7	25	0	Inf. Dilution	dH:-1133.20(6SF)kJ	5	CRV	8739
8	25	0	GAMSPATH	dH:-1132.40(6SF)kJ	3	CRV	12638

Reaction No. 60784							
Mg+2 + H+1_Salicylic-2 = Mg+2_H+1_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.59(3SF)	4	MGL	4503
2	25	0.03	NaCl	lgK:1.35(3SF)	3	MIS	4503
3	25	0.045	NaCl	lgK:1.29(3SF)	3	MIS	4503
4	35	0	Inf. Dilution	lgK:1.62(3SF)	4	MGL	4503
5	35	0.03	NaCl	lgK:1.39(3SF)	3	MIS	4503
6	35	0.045	NaCl	lgK:1.30(3SF)	3	MIS	4503
7	45	0	Inf. Dilution	lgK:1.65(3SF)	4	MGL	4503
8	45	0.03	NaCl	lgK:1.39(3SF)	6	MIS	4503
9	45	0.045	NaCl	lgK:1.35(3SF)	3	MIS	4503
10	25:45	0	Inf. Dilution	dH:-0.489(3SF)	4	MTD	4503

Reaction No. 60787							
2ClBenz-1 + Mg+2 = Mg+2_2ClBenz-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.88(2SF)	4	MGL	4503
2	25	0.03	NaCl	lgK:0.681(3SF)	4	MIS	4503
3	25	0.045	NaCl	lgK:0.658(3SF)	4	MIS	4503
4	25	0.3	NaCl	lgK:0.290(3SF)	4	MIS	4503
5	25	0.45	NaCl	lgK:0.274(3SF)	4	MIS	4503
6	35	0	Inf. Dilution	lgK:0.98(2SF)	4	MGL	4503


7	35	0.03	NaCl	lgK:0.852 (3SF)	4	MIS	4503
8	35	0.045	NaCl	lgK:0.715 (3SF)	4	MIS	4503
9	35	0.3	NaCl	lgK:0.365 (3SF)	4	MIS	4503
10	35	0.45	NaCl	lgK:0.312 (3SF)	4	MIS	4503
11	45	0	Inf. Dilution	lgK:1.04 (3SF)	4	MGL	4503
12	45	0.03	NaCl	lgK:0.934 (3SF)	4	MIS	4503
13	45	0.045	NaCl	lgK:0.808 (3SF)	4	MIS	4503
14	45	0.3	NaCl	lgK:0.389 (3SF)	4	MIS	4503
15	45	0.45	NaCl	lgK:0.341 (3SF)	4	MIS	4503
16	25:45	0	Inf. Dilution	dH:-1.47 (3SF)	4	MTD	4503

Reaction No. 60788



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.02 (3SF)	4	MGL	4503
2	25	0.03	NaCl	lgK:0.936 (3SF)	4	MIS	4503
3	25	0.045	NaCl	lgK:0.796 (3SF)	4	MIS	4503
4	25	0.3	NaCl	lgK:0.352 (3SF)	4	MIS	4503
5	25	0.45	NaCl	lgK:0.279 (3SF)	4	MIS	4503
6	35	0	Inf. Dilution	lgK:1.08 (3SF)	4	MGL	4503
7	35	0.03	NaCl	lgK:0.981 (3SF)	4	MIS	4503
8	35	0.045	NaCl	lgK:0.871 (3SF)	4	MIS	4503
9	35	0.3	NaCl	lgK:0.410 (3SF)	4	MIS	4503
10	35	0.45	NaCl	lgK:0.312 (3SF)	4	MIS	4503
11	45	0	Inf. Dilution	lgK:1.10 (3SF)	4	MGL	4503
12	45	0.03	NaCl	lgK:0.981 (3SF)	4	MIS	4503
13	45	0.045	NaCl	lgK:0.936 (3SF)	4	MIS	4503
14	45	0.3	NaCl	lgK:0.433 (3SF)	4	MIS	4503
15	45	0.45	NaCl	lgK:0.341 (3SF)	4	MIS	4503
16	25:45	0	Inf. Dilution	dH:-0.786 (3SF)	4	MTD	4503


Reaction No. 61485



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:3.2 (2SF)	3	MHY	1118
2	20	0.1	Unknown	lgK:2. (1SF)	2	MGL	1118


3	25	0	Inf. Dilution	lgK:3.2 (2SF)	1	ESC	
---	----	---	---------------	---------------	---	-----	--

Reaction No. 61704




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.38 (3SF)	2	EAE	
2	37	0.15	Unknown	lgK:1.90 (3SF)	4	CRV	552

Reaction No. 61711




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:8.81 (3SF)	6	CRV	552
2	37	0.15	Unknown	lgK:8.80 (3SF)	6	CRV	552

Reaction No. 61785




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.0 (2SF)	1	EES	
2	37	0.15	Unknown	lgK:1.19 (3SF)	1	CRV	552

Reaction No. 61973




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Unknown	lgK:1.71 (3SF)	6	CRV	552

Reaction No. 62043




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Unknown	lgK:6.96 (3SF)	6	CRV	552

Reaction No. 62044



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Unknown	lgK:7.57 (3SF)	6	CRV	552


Reaction No. 62045



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	37	0.15	Unknown	lgK:6.8 (2SF)	6	CRV	552
---	----	------	---------	---------------	---	-----	-----

Reaction No. 62046




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Unknown	lgK:1.2 (2SF)	6	CRV	552

Reaction No. 62049




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Unknown	lgK:7.85 (3SF)	6	CRV	552

Reaction No. 62050




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Unknown	lgK:8.53 (3SF)	4	CRV	552

Reaction No. 62051




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Unknown	lgK:7.5 (2SF)	4	CRV	552

Reaction No. 62052




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Unknown	lgK:1.8 (2SF)	4	CRV	552

Reaction No. 62053



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Unknown	lgK:3.9 (2SF)	4	CRV	552

Reaction No. 62107



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.1 (2SF)	1	EDH	
2	25	0.1	KNO3	lgK:4.57 (0.02SD)	2	MGL	6861
3	25	0.1	Unknown	lgK:5.47 (3SF)	2	CRV	552

Reaction No. 62108							
Mg+2_Glyphosate-3 + H+1 = Mg+2_H+1_Glyphosate-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:8.81(3SF)	6	CRV	552

Reaction No. 62315							
EtDiAmDiAcDiHydroxam-4 + Mg+2 = Mg+2_EtDiAmDiAcDiHydroxam-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:5.96(3SF)	6	CRV	552

Reaction No. 62320							
Mg+2_HBED-4 + H+1 = Mg+2_H+1_HBED-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:8.15(3SF)	6	CRV	552

Reaction No. 62321							
Mg+2_H+1_HBED-4 + H+1 = Mg+2_H+1(2)_HBED-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:7.01(3SF)	6	CRV	552

Reaction No. 62384							
Mg+2_ICRF198-2 + H+1 = Mg+2_H+1_ICRF198-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.9(2SF)	1	ESC	
2	37	0.15	Unknown	lgK:3.82(3SF)	6	CRV	552

Reaction No. 62439							
Mg+2_[12]N3O:Acet*3-3 + H+1 = Mg+2_H+1_[12]N3O:Acet*3-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:5.67(3SF)	6	CRV	552

Reaction No. 62451							
Mg+2_[12]N4:Acet*4-4 + H+1 = Mg+2_H+1_[12]N4:Acet*4-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:4.09(3SF)	6	CRV	552

Reaction No. 62524							
--------------------	--	--	--	--	--	--	--

CarbMeAsp-3 + Mg+2 = Mg+2_CarbMeAsp-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:4.57 (3SF)	6	CRV	552

Reaction No. 62559							
IDS-4 + Mg+2 = Mg+2_IDS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.16 (3SF)	4	CRV	29666
2	25	0.1	Unknown	lgK:5.50 (3SF)	6	CRV	552

Reaction No. 62633							
NBenzIDA-2 + Mg+2 = Mg+2_NBenzIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:2.65 (0.02SD)	6	CRV	552
2	30	0.1	KCl	lgK:3.0 (0.06SD)	5	MGL	2086

Reaction No. 62834							
2HexNTA-3 + Mg+2 = Mg+2_2HexNTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	K+1 salt	lgK:5.44 (3SF)	6	CRV	552

Reaction No. 62864							
2COONTA-4 + Mg+2 = Mg+2_2COONTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:5.15 (3SF)	6	CRV	552

Reaction No. 62869							
Mg+2_NPhosMeIDA-4 + H+1 = Mg+2_H+1_NPhosMeIDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:6.44 (3SF)	6	CRV	552

Reaction No. 62873							
N2OHBenzIDA-3 + Mg+2 = Mg+2_N2OHBenzIDA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	K+1 salt	lgK:7.28 (3SF)	6	CRV	552

Reaction No. 63053							
N2PrAmidoIDA-2 + Mg+2 = Mg+2_N2PrAmidoIDA-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:3.78(3SF)	6	CRV	552
2	25	0.1	Unknown	lgK:3.79(3SF)	6	CRV	552
3	10:40	0.1	Unknown	dH:1.(1SF)	6	CRV	552

Reaction No. 63070




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:11.81(4SF)	6	CRV	552

Reaction No. 63088




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:8.97(3SF)	6	CRV	552

Reaction No. 65577




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.05(1SF)	0	EBU	6372

Reaction No. 65578




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.26(2SF)	0	EBU	6372

Reaction No. 65579




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.70(2SF)	0	EBU	6372

Reaction No. 65580



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.25(3SF)	0	EBU	6372


Reaction No. 65581



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:-1.87 (3SF)	0	EBU	6372
---	----	---	---------------	-----------------	---	-----	------

Reaction No. 65582




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.29 (2SF)	4	EBU	6372

Reaction No. 65583




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.91 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:-0.91 (2SF)	4	EBU	6372

Reaction No. 65584




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.83 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:-2.83 (3SF)	4	EBU	6372

Reaction No. 65585




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-5.4 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:-5.40 (3SF)	4	EBU	6372

Reaction No. 65671



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.5 (0.09SD)	0	CRV	552
2	25	0.7	Unknown	lgK:0.9 (0.2SD)	0	CRV	552
3	10:50	0	Inf. Dilution	dH:0.0 (1SF)	0	CRV	552

Reaction No. 65765



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	50	0	Inf. Dilution	lgK:-38.8 (3SF)	0	CRV	552

Note (1): Solid +1 charge! Same problem in S&M hardcopy [76SmM_8]. Sepiolite?

Reaction No. 65823							
$\text{Mg}+2_ \text{OH}-1_ \text{P2O7}-4 + \text{H}+1 = \text{Mg}+2_ \text{P2O7}-4 + \text{H2O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.5 (3SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:11.9 (3SF)	3	CRV	552

Reaction No. 65847							
$\text{Mg}+2_ \text{OH}-1_ \text{P3O10}-5 + \text{H}+1 = \text{Mg}+2_ \text{P3O10}-5 + \text{H2O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.6 (3SF)	4	CRV	552

Reaction No. 65862							
$2<\text{Mg}+2> + \text{P4O13}-6 = \text{Mg}+2 (2)_ \text{P4O13}-6$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4N+ salt	lgK:8.23 (3SF)	6	CRV	552

Reaction No. 65880							
$2<\text{P4O12}-4> + \text{Mg}+2 = \text{Mg}+2_ \text{P4O12}-4 (2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:5.47 (3SF)	6	CRV	552

Reaction No. 65896							
$\text{P6O18}-6 + \text{Mg}+2 = \text{Mg}+2_ \text{P6O18}-6$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:5.50 (3SF)	0	CRV	552

Reaction No. 65938							
$\text{Mg}+2_ \text{SeO4}-2_ (\text{s}) = \text{Mg}+2 + \text{SeO4}-2$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.20 (3SF)	0	CRV	552
2	25	0	Inf. Dilution	dG:5.78 (3SF)	3	ENS	12931

Reaction No. 65964							
$4<\text{C}(\text{s})> + 5<\text{H2}(\text{g})> + 5<\text{Mg}(\text{s})> + 9<\text{O2}(\text{g})> = \text{Mg}+2 (5)_ \text{OH}-1 (2)_ \text{CO3}-2 (4)_ \text{H2O} (4)_ (\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1028. (4SF)	1	EDH	
2	25	0	Inf. Dilution	dG:-5870. (4SF) kJ	5	CRV	8739

3	25	0	Inf. Dilution	dG:-5878.(3.SD)kJ	0	MSL	27205
4	25	0	Inf. Dilution	dH:-6516.00(6SF)kJ	5	CRV	8739
5	25	0	Inf. Dilution	dH:-6511.80(6SF)kJ	4	CRV	26555

Reaction No. 66049							
$\text{Mg}+2_{\text{H}+1_{\text{PO4}-3}_{\text{(s)}}} = \text{Mg}+2 + \text{H}+1 + \text{PO4}-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-18.2(3SF)	4	ENS	6405

Reaction No. 66056							
$\text{H}+1 + \text{P2O7}-4 + \text{Mg}+2 = \text{Mg}+2_{\text{H}+1_{\text{P2O7}-4}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.1(3SF)	4	ENS	6405
2	25	3	Inert	lgK:14.5(3SF)	1	EOR	

Reaction No. 66084							
$\text{H}+1 + \text{EDTA}-4 + \text{Mg}+2 = \text{Mg}+2_{\text{H}+1_{\text{EDTA}-4}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.1(3SF)	4	ENS	6405

Reaction No. 66139							
$1\text{PrEDTA}-4 + \text{Mg}+2 = \text{Mg}+2_{1\text{PrEDTA}-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:10.15(4SF)	6	MPL	2011

Reaction No. 66204							
$\text{C(s)} + 0.5\langle\text{Mg(s)}\rangle + \text{Na(s)} + 1.5\langle\text{O2(g)}\rangle = \text{Mg}+2(0.5)_{\text{Na}+1_{\text{CO3}-2}_{\text{(s)}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1040.(4SF)kJ	5	CRV	8739
2	25	0	Inf. Dilution	dH:-2248.00(6SF)kJ	5	CRV	8739

Reaction No. 66535							
$2\langle\text{Na(s)}\rangle + 3\langle\text{Mg(s)}\rangle + 2\langle\text{Al(s)}\rangle + 8\langle\text{Si(s)}\rangle + \text{H2(g)} + 12\langle\text{O2(g)}\rangle = \text{Na2Mg3Al2Si8O22(OH)2(Glauc.,s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1968.(4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:1955.(4SF)	0	ENS	6494
3	127	0	Inf. Dilution	lgK:1434.(4SF)	4	ENS	6494

4	227	0	Inf. Dilution	lgK:1121.(4SF)	4	ENS	6494
5	327	0	Inf. Dilution	lgK:912.6(4SF)	4	ENS	6494
6	25	0	Inf. Dilution	dG:-2684.(4SF)	4	EFE	6494
7	25	0	Inf. Dilution	dH:-2857.(4SF)	4	ENS	6437
8	25	0	Inf. Dilution	dH:-2860.(4SF)	4	MTD	6494
9	127	0	Inf. Dilution	dH:-2862.(4SF)	4	MTD	6494
10	227	0	Inf. Dilution	dH:-2861.(4SF)	4	MTD	6494
11	327	0	Inf. Dilution	dH:-2860.(4SF)	4	MTD	6494

Reaction No. 66570							
Ca(s) + Mg(s) + O2(g) = CaO.MgO(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:206.8(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:205.5(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:151.3(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:118.9(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:97.224(5SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-282.1(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-297.3(4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-297.2(4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-297.0(4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-296.8(4SF)	4	MTD	6422

Reaction No. 66571							
Ca(s) + Mg(s) + Si(s) + 2<O2(g)> = CaO.MgO.SiO2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:374.6(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:375.9(4SF)	3	ENS	6422
3	25	0	Inf. Dilution	lgK:373.6(4SF)	3	ENS	6494
4	27	0	Inf. Dilution	lgK:373.5(4SF)	0	ENS	6422
5	27	0	Inf. Dilution	lgK:371.2(4SF)	0	ENS	6494
6	127	0	Inf. Dilution	lgK:275.0(4SF)	1	ENS	6422
7	127	0	Inf. Dilution	lgK:273.2(4SF)	1	ENS	6494
8	227	0	Inf. Dilution	lgK:215.9(4SF)	0	ENS	6422
9	227	0	Inf. Dilution	lgK:214.4(4SF)	0	ENS	6494
10	327	0	Inf. Dilution	lgK:176.5(4SF)	0	ENS	6422

11	327	0	Inf. Dilution	lgK:175.3 (4SF)	0	ENS	6494
12	25	0	Inf. Dilution	dG:-512.8 (4SF)	0	EFE	6422
13	25	0	Inf. Dilution	dG:-509.61 (5SF)	0	EFE	6482
14	25	0	Inf. Dilution	dG:-509.8 (4SF)	0	EFE	6494
15	25	0	Inf. Dilution	dH:-540.9 (4SF)	0	MTD	6422
16	25	0	Inf. Dilution	dH:-536.9 (4SF)	0	ENS	6437
17	25	0	Inf. Dilution	dH:-537.77 (5SF)	0	EFE	6482
18	25	0	Inf. Dilution	dH:-538.0 (4SF)	0	MTD	6494
19	127	0	Inf. Dilution	dH:-540.8 (4SF)	0	MTD	6422
20	127	0	Inf. Dilution	dH:-538.0 (4SF)	0	MTD	6494
21	227	0	Inf. Dilution	dH:-540.6 (4SF)	0	MTD	6422
22	227	0	Inf. Dilution	dH:-537.7 (4SF)	0	MTD	6494
23	327	0	Inf. Dilution	dH:-540.2 (4SF)	0	MTD	6422
24	327	0	Inf. Dilution	dH:-537.4 (4SF)	0	MTD	6494

Reaction No. 66572							
Ca(s) + Mg(s) + 3O ₂ (g) + 2Si(s) = CaO.MgO.2SiO ₂ (s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:531.2 (4SF)	2	ENS	6422
2	25	0	Inf. Dilution	lgK:382.6 (4SF)	0	ENS	6437
3	25	0	Inf. Dilution	lgK:530.3 (4SF)	4	ENS	6494
4	27	0	Inf. Dilution	lgK:527.7 (4SF)	0	ENS	6422
5	27	0	Inf. Dilution	lgK:526.8 (4SF)	0	ENS	6494
6	127	0	Inf. Dilution	lgK:388.1 (4SF)	1	ENS	6422
7	127	0	Inf. Dilution	lgK:387.5 (4SF)	3	ENS	6494
8	227	0	Inf. Dilution	lgK:304.4 (4SF)	2	ENS	6422
9	227	0	Inf. Dilution	lgK:303.9 (4SF)	2	ENS	6494
10	327	0	Inf. Dilution	lgK:248.6 (4SF)	0	ENS	6422
11	327	0	Inf. Dilution	lgK:248.1 (4SF)	0	ENS	6494
12	25	0	Inf. Dilution	dG:-724.7 (4SF)	2	EFE	6422
13	25	0	Inf. Dilution	dG:-723.28 (5SF)	3	EFE	6482
14	25	0	Inf. Dilution	dG:-723.4 (4SF)	4	EFE	6494
15	25	0	Inf. Dilution	dG:-3026.8 (5SF) kJ	3	EOD	12843
16	25	0	Inf. Dilution	dH:-766.3 (4SF)	2	MTD	6422
17	25	0	Inf. Dilution	dH:-764.96 (5SF)	4	EFE	6482
18	25	0	Inf. Dilution	dH:-765.2 (4SF)	4	MTD	6494

19	25	0	Inf. Dilution	dH:-3201.5 (5SF) kJ	3	EOD	12843
20	127	0	Inf. Dilution	dH:-766.4 (4SF)	2	MTD	6422
21	127	0	Inf. Dilution	dH:-765.2 (4SF)	2	MTD	6494
22	227	0	Inf. Dilution	dH:-766.1 (4SF)	2	MTD	6422
23	227	0	Inf. Dilution	dH:-764.9 (4SF)	2	MTD	6494
24	327	0	Inf. Dilution	dH:-765.6 (4SF)	0	MTD	6422
25	327	0	Inf. Dilution	dH:-764.4 (4SF)	0	MTD	6494


Reaction No. 66573							
2<Ca(s)> + Mg(s) + 2<Si(s)> + 3.5<O2(g)> = 2CaO.MgO.2SiO2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:643.3 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:644.7 (4SF)	3	ENS	6422
3	25	0	Inf. Dilution	lgK:642.5 (4SF)	3	ENS	6494
4	27	0	Inf. Dilution	lgK:640.5 (4SF)	0	ENS	6422
5	27	0	Inf. Dilution	lgK:638.4 (4SF)	0	ENS	6494
6	127	0	Inf. Dilution	lgK:471.7 (4SF)	1	ENS	6422
7	127	0	Inf. Dilution	lgK:470.2 (4SF)	1	ENS	6494
8	227	0	Inf. Dilution	lgK:370.5 (4SF)	0	ENS	6422
9	227	0	Inf. Dilution	lgK:369.3 (4SF)	0	ENS	6494
10	327	0	Inf. Dilution	lgK:303.0 (4SF)	0	ENS	6422
11	327	0	Inf. Dilution	lgK:302.1 (4SF)	0	ENS	6494
12	25	0	Inf. Dilution	dG:-879.5 (4SF)	0	EFE	6422
13	25	0	Inf. Dilution	dG:-875.66 (5SF)	0	EFE	6482
14	25	0	Inf. Dilution	dG:-876.6 (4SF)	0	EFE	6494
15	25	0	Inf. Dilution	dH:-926.7 (4SF)	0	MTD	6422
16	25	0	Inf. Dilution	dH:-924.4 (4SF)	0	ENS	6437
17	25	0	Inf. Dilution	dH:-922.67 (5SF)	0	MTD	6482
18	25	0	Inf. Dilution	dH:-923.7 (4SF)	0	MTD	6494
19	127	0	Inf. Dilution	dH:-926.6 (4SF)	0	MTD	6422
20	127	0	Inf. Dilution	dH:-923.6 (4SF)	0	MTD	6494
21	227	0	Inf. Dilution	dH:-926.2 (4SF)	0	MTD	6422
22	227	0	Inf. Dilution	dH:-923.3 (4SF)	0	MTD	6494
23	327	0	Inf. Dilution	dH:-925.7 (4SF)	0	MTD	6422
24	327	0	Inf. Dilution	dH:-923.0 (4SF)	0	MTD	6494

Reaction No. 66574							
$2\text{Ca(s)} + 5\text{Mg(s)} + 8\text{Si(s)} + 12\text{O}_2\text{(g)} + \text{H}_2\text{(g)} = 2\text{CaO} \cdot 5\text{MgO} \cdot 8\text{SiO}_2 \cdot \text{H}_2\text{O(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2038. (4SF)	0	ENS	6422
2	25	0	Inf. Dilution	lgK:2028. (4SF)	0	ENS	6494
3	27	0	Inf. Dilution	lgK:2025. (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:2014. (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:1487. (4SF)	0	ENS	6422
6	127	0	Inf. Dilution	lgK:1479. (4SF)	1	ENS	6494
7	227	0	Inf. Dilution	lgK:1164. (4SF)	0	ENS	6422
8	227	0	Inf. Dilution	lgK:1158. (4SF)	4	ENS	6494
9	327	0	Inf. Dilution	lgK:948.6 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:943.5 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-2780. (4SF)	0	EFE	6422
12	25	0	Inf. Dilution	dG:-2767.3 (5SF)	3	EFE	6482
13	25	0	Inf. Dilution	dG:-2766. (4SF)	0	EFE	6494
14	25	0	Inf. Dilution	dH:-2954. (4SF)	0	MTD	6422
15	25	0	Inf. Dilution	dH:-2943. (4SF)	2	ENS	6437
16	25	0	Inf. Dilution	dH:-2941.1 (5SF)	3	EFE	6482
17	25	0	Inf. Dilution	dH:-2941. (4SF)	0	MTD	6494
18	127	0	Inf. Dilution	dH:-2954. (4SF)	0	MTD	6422
19	127	0	Inf. Dilution	dH:-2941. (4SF)	0	MTD	6494
20	227	0	Inf. Dilution	dH:-2954. (4SF)	0	MTD	6422
21	227	0	Inf. Dilution	dH:-2940. (4SF)	0	MTD	6494
22	327	0	Inf. Dilution	dH:-2952.2 (5SF)	0	MTD	6422
23	327	0	Inf. Dilution	dH:-2938. (4SF)	0	MTD	6494

Reaction No. 66725							
$\text{Mg(s)} + 2\text{Fe(s)} + 2\text{O}_2\text{(g)} = \text{MgFe}_2\text{O}_4\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:232.6 (4SF)	1	EDH	
2	25	0	Inf. Dilution	lgK:230.8 (4SF)	0	ENS	6422
3	25	0	Inf. Dilution	lgK:232.9 (4SF)	4	ENS	6494
4	27	0	Inf. Dilution	lgK:229.3 (4SF)	0	ENS	6422
5	27	0	Inf. Dilution	lgK:231.4 (4SF)	0	ENS	6494
6	127	0	Inf. Dilution	lgK:167.1 (4SF)	2	ENS	6422


7	127	0	Inf. Dilution	lgK:168.7 (4SF)	3	ENS	6494
8	227	0	Inf. Dilution	lgK:129.8 (4SF)	3	ENS	6422
9	227	0	Inf. Dilution	lgK:131.1 (4SF)	0	ENS	6494
10	327	0	Inf. Dilution	lgK:104.9 (4SF)	0	ENS	6422
11	327	0	Inf. Dilution	lgK:106.1 (4SF)	0	ENS	6494
12	25	0	Inf. Dilution	dG:-314.9 (4SF)	0	EFE	6422
13	25	0	Inf. Dilution	dG:-317.8 (4SF)	4	EFE	6494
14	25	0	Inf. Dilution	dH:-341.5 (4SF)	4	MTD	6422
15	25	0	Inf. Dilution	dH:-344.5 (4SF)	2	MTD	6494
16	127	0	Inf. Dilution	dH:-341.3 (4SF)	2	MTD	6422
17	127	0	Inf. Dilution	dH:-344.1 (4SF)	2	MTD	6494
18	227	0	Inf. Dilution	dH:-341.2 (4SF)	3	MTD	6422
19	227	0	Inf. Dilution	dH:-343.5 (4SF)	3	MTD	6494
20	327	0	Inf. Dilution	dH:-341.2 (4SF)	0	MTD	6422
21	327	0	Inf. Dilution	dH:-342.6 (4SF)	0	MTD	6494

Reaction No. 66777



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1040. (4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:1033. (4SF)	0	ENS	6494
3	127	0	Inf. Dilution	lgK:759.3 (4SF)	4	ENS	6494
4	227	0	Inf. Dilution	lgK:595.1 (4SF)	4	ENS	6494
5	327	0	Inf. Dilution	lgK:485.7 (4SF)	4	ENS	6494
6	25	0	Inf. Dilution	dG:-1418.7 (5SF)	4	EFE	6482
7	25	0	Inf. Dilution	dG:-1418. (4SF)	4	EFE	6494
8	25	0	Inf. Dilution	dH:-1503.7 (5SF)	4	ENS	6437
9	25	0	Inf. Dilution	dH:-1502.5 (5SF)	4	EFE	6482
10	25	0	Inf. Dilution	dH:-1502. (4SF)	4	MTD	6494
11	127	0	Inf. Dilution	dH:-1502. (4SF)	4	MTD	6494
12	227	0	Inf. Dilution	dH:-1502. (4SF)	4	MTD	6494
13	327	0	Inf. Dilution	dH:-1501. (4SF)	4	MTD	6494


Reaction No. 66780



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:1024.0 (5SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:1027. (4SF)	0	ENS	6494
3	27	0	Inf. Dilution	lgK:1020. (4SF)	0	ENS	6494
4	127	0	Inf. Dilution	lgK:748.0 (4SF)	0	ENS	6494
5	227	0	Inf. Dilution	lgK:584.8 (4SF)	0	ENS	6494
6	327	0	Inf. Dilution	lgK:476.0 (4SF)	0	ENS	6494
7	25	0	Inf. Dilution	dG:-1392.7 (5SF)	0	EFE	6482
8	25	0	Inf. Dilution	dG:-1401. (4SF)	0	EFE	6494
9	25	0	Inf. Dilution	dH:-1482.8 (5SF)	2	ENS	6437
10	25	0	Inf. Dilution	dH:-1483.6 (5SF)	2	EFE	6482
11	25	0	Inf. Dilution	dH:-1493. (4SF)	0	MTD	6494
12	127	0	Inf. Dilution	dH:-1494. (4SF)	0	MTD	6494
13	227	0	Inf. Dilution	dH:-1493. (4SF)	0	MTD	6494
14	327	0	Inf. Dilution	dH:-1493. (4SF)	0	MTD	6494

Reaction No. 66781



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-2253.9 (5SF)	4	ENS	6437

Reaction No. 66782




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.1597E+4 (5SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-1.5792E+4 (5SF)	0	EFE	6482
3	25	0	GAMSPATH	dG:-6.614E+4 (4SF) kJ	0	CRV	12638

Note (3): Low wgt for internal consistency

4	25	0	Inf. Dilution	dH:-1.7060E+4 (5SF)	0	ENS	6437
5	25	0	Inf. Dilution	dH:-1.7056E+4 (5SF)	0	EFE	6482
6	25	0	GAMSPATH	dH:-7.14250E+4 (6SF) kJ	0	CRV	12638

Reaction No. 66785



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-2920. (4SF)	4	ENS	6437

Reaction No. 66787

Mg(s) + 2<Al(s)> + 2<Si(s)> + 5<O2(g)> + 2<H2(g)> = MgAl2Si2O6(OH)4(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-1146.(4SF)	4	ENS	6437

Reaction No. 66788							
Mg(s) + 2<Al(s)> + Si(s) + 3.5<O2(g)> + H2(g) = MgAl2SiO5(OH)2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-850.4(4SF)	4	ENS	6437

Reaction No. 66789							
4<Mg(s)> + 18<Al(s)> + 7.5<Si(s)> + 24<O2(g)> + 2<H2(g)> = Mg4Al18Si7.5O48H4(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-6003.5(5SF)	4	ENS	6437

Reaction No. 66791							
4<Mg(s)> + 4<Al(s)> + 2<Si(s)> + 9<O2(g)> + 4<H2(g)> = Mg4Al4Si2O10(OH)8(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-2162.(4SF)	4	ENS	6437

Reaction No. 66792							
Al(s) + H2(g) + K(s) + Mg(s) + 6<O2(g)> + 4<Si(s)> = KMgAlSi4O10(OH)2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-5464.10(6SF) kJ	3	CRV	25435
2	25	0	GAMSPATH	dG:-7971.(4SF) kJ	0	CRV	12638
3	25	0	Inf. Dilution	dH:-1394.4(5SF)	2	ENS	6437
4	25	0	Inf. Dilution	dH:-5844.50(6SF) kJ	3	CRV	25435

Reaction No. 66795							
K(s) + 2<Mg(s)> + 3<Al(s)> + 2<Si(s)> + 6<O2(g)> + H2(g) = KMg2Al3Si2O10(OH)2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-1514.5(5SF)	4	ENS	6437

Reaction No. 66796							
Na(s) + 2<Ca(s)> + 5<Mg(s)> + 7<Si(s)> + Al(s) + 12<O2(g)> + H2(g) = NaCa2Mg5Si7AlO22(OH)2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-3006.8(5SF)	4	ENS	6437

Reaction No. 66803							
$2\text{Ca(s)} + 4\text{Mg(s)} + 2\text{Al(s)} + 7\text{Si(s)} + 12\text{O}_2\text{(g)} + \text{H}_2\text{(g)} = \text{Ca}_2\text{Mg}_4\text{Al}_2\text{Si}_7\text{O}_{22}(\text{OH})_2\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH: -2968.5 (5SF)	4	ENS	6437

Reaction No. 66806							
$2\text{Na(s)} + 3\text{Mg(s)} + 2\text{Al(s)} + 8\text{Si(s)} + 12\text{O}_2\text{(g)} + \text{H}_2\text{(g)} = \text{Na}_2\text{Mg}_3\text{Al}_2\text{Si}_8\text{O}_{22}(\text{OH})_2\text{(Rieb., s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH: -2650. (4SF)	4	ENS	6437

Reaction No. 66807							
$\text{Na(s)} + 2\text{Ca(s)} + 4\text{Mg(s)} + 3\text{Al(s)} + 6\text{Si(s)} + 12\text{O}_2\text{(g)} + \text{H}_2\text{(g)} = \text{NaCa}_2\text{Mg}_4\text{Al}_3\text{Si}_6\text{O}_{22}(\text{OH})_2\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH: -3040.1 (5SF)	4	ENS	6437

Reaction No. 66811							
$3\text{Ca(s)} + \text{Mg(s)} + 2\text{Si(s)} + 4\text{O}_2\text{(g)} = 3\text{CaO.MgO.2SiO}_2\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK: 760.4 (4SF)	2	ENS	6422
2	25	0	Inf. Dilution	lgK: 754.7 (4SF)	0	ENS	6494
3	27	0	Inf. Dilution	lgK: 755.5 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK: 749.8 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK: 556.7 (4SF)	4	ENS	6422
6	127	0	Inf. Dilution	lgK: 552.3 (4SF)	0	ENS	6494
7	227	0	Inf. Dilution	lgK: 437.4 (4SF)	4	ENS	6422
8	227	0	Inf. Dilution	lgK: 433.9 (4SF)	0	ENS	6494
9	327	0	Inf. Dilution	lgK: 358.0 (4SF)	4	ENS	6422
10	327	0	Inf. Dilution	lgK: 355.0 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG: -1037. (4SF)	4	EFE	6422
12	25	0	Inf. Dilution	dG: -1030.00 (6SF)	0	EFE	6482
13	25	0	Inf. Dilution	dG: -1030. (4SF)	0	EFE	6494
14	25	0	Inf. Dilution	dH: -1092. (4SF)	2	MTD	6422
15	25	0	Inf. Dilution	dH: -1084.4 (5SF)	2	ENS	6437
16	25	0	Inf. Dilution	dH: -1084.5 (5SF)	0	EFE	6482
17	25	0	Inf. Dilution	dH: -1084. (4SF)	0	MTD	6494

18	127	0	Inf. Dilution	dH:-1092.(4SF)	0	MTD	6422
19	127	0	Inf. Dilution	dH:-1084.(4SF)	0	MTD	6494
20	227	0	Inf. Dilution	dH:-1091.(4SF)	0	MTD	6422
21	227	0	Inf. Dilution	dH:-1084.(4SF)	0	MTD	6494
22	327	0	Inf. Dilution	dH:-1090.(4SF)	0	MTD	6422
23	327	0	Inf. Dilution	dH:-1083.(4SF)	0	MTD	6494

Reaction No. 66814							
Mg(s) + 1.5<O2(g)> + Si(s) = MgO.SiO2(Enstat.,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:255.5(4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:253.8(4SF)	0	ENS	6494
3	127	0	Inf. Dilution	lgK:186.5(4SF)	2	ENS	6494
4	227	0	Inf. Dilution	lgK:146.2(4SF)	1	ENS	6494
5	327	0	Inf. Dilution	lgK:119.3(4SF)	0	ENS	6494
6	25	0	Inf. Dilution	dG:-348.51(5SF)	4	EFE	6482
7	25	0	Inf. Dilution	dG:-348.5(4SF)	4	EFE	6494
8	25	0	Inf. Dilution	dG:-1458.3(5SF)kJ	3	EOD	12843
9	25	0	GAMSPATH	dG:-1480.(4SF)kJ	0	CRV	12638
10	25	0	Inf. Dilution	dH:-395.57(5SF)	0	ENS	6437
11	25	0	Inf. Dilution	dH:-369.40(5SF)	4	EFE	6482
12	25	0	Inf. Dilution	dH:-369.4(4SF)	4	MTD	6494
13	25	0	Inf. Dilution	dH:-1549.00(6SF)kJ	2	CRV	8695
14	25	0	Inf. Dilution	dH:-1545.6(5SF)kJ	3	EOD	12843
15	25	0	GAMSPATH	dH:-1546.80(6SF)kJ	3	CRV	12638
16	127	0	Inf. Dilution	dH:-369.4(4SF)	1	MTD	6494
17	227	0	Inf. Dilution	dH:-369.2(4SF)	0	MTD	6494
18	327	0	Inf. Dilution	dH:-369.0(4SF)	0	MTD	6494

Reaction No. 66816							
2<Al(s)> + 4<H2(g)> + 5<Mg(s)> + 9<O2(g)> + 3<Si(s)> = Mg5Al2Si3O10(OH)8(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1446.3(5SF)	3	CRV	6494
2	25	0	Inf. Dilution	dG:-1971.9(5SF)	3	EFE	6482
3	25	0	Inf. Dilution	dG:-8263.40(6SF)kJ	1	CRV	25435
4	25	0	GAMSPATH	dG:-8186.(4SF)kJ	0	CRV	12638

Note (4): Low wgt for internal consistency							
5	25	0	Inf. Dilution	dH:-2133.9 (5SF)	1	ENS	6437
6	25	0	Inf. Dilution	dH:-2129.4 (5SF)	3	EFE	6482
7	25	0	Inf. Dilution	dH:-8929.90 (6SF) kJ	1	CRV	25435
8	25	0	GAMSPATH	dH:-8841.6 (5SF) kJ	0	CRV	12638

Reaction No. 66821							
Mg(s) + 2<Al(s)> + 2<O2(g)> = MgO.Al2O3(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:381.1 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:381.3 (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:378.6 (4SF)	4	ENS	6422
4	27	0	Inf. Dilution	lgK:378.8 (4SF)	4	ENS	6494
5	127	0	Inf. Dilution	lgK:278.4 (4SF)	4	ENS	6422
6	127	0	Inf. Dilution	lgK:278.7 (4SF)	4	ENS	6494
7	227	0	Inf. Dilution	lgK:218.4 (4SF)	4	ENS	6422
8	227	0	Inf. Dilution	lgK:218.7 (4SF)	4	ENS	6494
9	327	0	Inf. Dilution	lgK:178.3 (4SF)	4	ENS	6422
10	327	0	Inf. Dilution	lgK:178.7 (4SF)	4	ENS	6494
11	25	0	Inf. Dilution	dG:-519.8 (4SF)	4	EFE	6422
12	25	0	Inf. Dilution	dG:-520.20 (5SF)	5	EFE	6482
13	25	0	Inf. Dilution	dG:-520.2 (4SF)	4	EFE	6494
14	25	0	Inf. Dilution	dH:-549.7 (4SF)	4	MTD	6422
15	25	0	Inf. Dilution	dH:-551. (3SF)	4	ENS	6437
16	25	0	Inf. Dilution	dH:-549.79 (5SF)	5	EFE	6482
17	25	0	Inf. Dilution	dH:-549.5 (4SF)	4	MTD	6494
18	127	0	Inf. Dilution	dH:-549.8 (4SF)	4	MTD	6422
19	127	0	Inf. Dilution	dH:-549.7 (4SF)	4	MTD	6494
20	227	0	Inf. Dilution	dH:-549.7 (4SF)	4	MTD	6422
21	227	0	Inf. Dilution	dH:-549.6 (4SF)	4	MTD	6494
22	327	0	Inf. Dilution	dH:-549.5 (4SF)	4	MTD	6422
23	327	0	Inf. Dilution	dH:-549.4 (4SF)	4	MTD	6494

Reaction No. 66824							
C(s) + Mg(s) + 1.5<O2(g)> = Mg+2_CO3-2_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0	Inf. Dilution	lgK:177.3 (4SF)	0	ENS	6422
2	25	0	Inf. Dilution	lgK:180.4 (4SF)	1	ENS	6494
3	27	0	Inf. Dilution	lgK:176.1 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:179.2 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:128.5 (4SF)	0	ENS	6422
6	127	0	Inf. Dilution	lgK:130.7 (4SF)	1	ENS	6494
7	227	0	Inf. Dilution	lgK:99.85 (4SF)	0	ENS	6422
8	227	0	Inf. Dilution	lgK:101.7 (4SF)	0	ENS	6494
9	327	0	Inf. Dilution	lgK:80.80 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:82.30 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-1012.1 (5SF) kJ	0	CRV	6330
Note (11): See comments by Konigsberger et al., GCA,99,3105							
12	25	0	Inf. Dilution	dG:-241.9 (4SF)	0	EFE	6422
13	25	0	Inf. Dilution	dG:-246.15 (5SF)	1	EFE	6482
14	25	0	Inf. Dilution	dG:-246.1 (4SF)	1	EFE	6494
15	25	0	Inf. Dilution	dG:-1012.1 (5SF) kJ	0	EFE	7275
16	25	0	Inf. Dilution	dG:-1034. (4SF) kJ	0	CRV	8739
17	25	0	Inf. Dilution	dG:-1007.5 (5SF) kJ	0	EMD	18180
18	25	0	Inf. Dilution	dG:-1026.50 (2.MD) kJ	6	MSL	26071
19	25	0	Inf. Dilution	dG:-1027.4 (5SF) kJ	3	EOD	29025
20	25	0	GAMSPATH	dG:-1028. (4SF) kJ	0	CRV	12638
21	25	0	Inf. Dilution/m	dG:-1027.4 (5SF) kJ	2	EPZ	9073
22	25	0	Inf. Dilution	dH:-1095.8 (5SF) kJ	0	CRV	6330
23	25	0	Inf. Dilution	dH:-261.9 (4SF)	0	MTD	6422
24	25	0	Inf. Dilution	dH:-264.3 (4SF)	0	ENS	6437
25	25	0	Inf. Dilution	dH:-266.16 (5SF)	1	EFE	6482
26	25	0	Inf. Dilution	dH:-266.1 (4SF)	1	MTD	6494
27	25	0	Inf. Dilution	dH:-1095.8 (5SF) kJ	0	EFE	7275
28	25	0	Inf. Dilution	dH:-1117.90 (6SF) kJ	2	CRV	8739
29	25	0	Inf. Dilution	dH:-1111.80 (2.MD) kJ	5	MTD	26071
30	25	0	Inf. Dilution	dH:-1095.8 (5SF) kJ	0	EOD	29025
31	25	0	GAMSPATH	dH:-1111.40 (6SF) kJ	3	CRV	12638
32	127	0	Inf. Dilution	dH:-261.8 (4SF)	0	MTD	6422
33	127	0	Inf. Dilution	dH:-266.0 (4SF)	2	MTD	6494
34	227	0	Inf. Dilution	dH:-261.6 (4SF)	0	MTD	6422
35	227	0	Inf. Dilution	dH:-265.8 (4SF)	0	MTD	6494

36	327	0	Inf. Dilution	dH:-261.3 (4SF)	0	MTD	6422
37	327	0	Inf. Dilution	dH:-265.4 (4SF)	0	MTD	6494
38	25	0	Inf. Dilution	Cp:75.91 (2.MD)	5	MTD	26071
39	25	0	Inf. Dilution	Cp:75.5 (3SF) J/K	4	EOD	29025

Reaction No. 66825							
7<Mg(s)> + 8<Si(s)> + 12<O2(g)> + H2(g) = Mg7Si8O22(OH)2 (Anth.,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1991. (4SF)	0	ENS	6422
2	25	0	Inf. Dilution	lgK:1987. (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:1978. (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:1974. (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:1452. (4SF)	0	ENS	6422
6	127	0	Inf. Dilution	lgK:1449. (4SF)	4	ENS	6494
7	227	0	Inf. Dilution	lgK:1136. (4SF)	0	ENS	6422
8	227	0	Inf. Dilution	lgK:1134. (4SF)	4	ENS	6494
9	327	0	Inf. Dilution	lgK:926.0 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:923.7 (4SF)	4	ENS	6494
11	25	0	Inf. Dilution	dG:-2717. (4SF)	0	EFE	6422
12	25	0	Inf. Dilution	dG:-2710.9 (5SF)	3	EFE	6482
13	25	0	Inf. Dilution	dG:-2711. (4SF)	4	EFE	6494
14	25	0	Inf. Dilution	dH:-2889. (4SF)	0	MTD	6422
15	25	0	Inf. Dilution	dH:-2885. (4SF)	4	ENS	6437
16	25	0	Inf. Dilution	dH:-2884.6 (5SF)	3	EFE	6482
17	25	0	Inf. Dilution	dH:-2885. (4SF)	4	MTD	6494
18	127	0	Inf. Dilution	dH:-2890. (4SF)	0	MTD	6422
19	127	0	Inf. Dilution	dH:-2885. (4SF)	4	MTD	6494
20	227	0	Inf. Dilution	dH:-2889. (4SF)	0	MTD	6422
21	227	0	Inf. Dilution	dH:-2883. (4SF)	4	MTD	6494
22	327	0	Inf. Dilution	dH:-2888. (4SF)	0	MTD	6422
23	327	0	Inf. Dilution	dH:-2881. (4SF)	4	MTD	6494

Reaction No. 66827							
H2(g) + Mg(s) + O2(g) = Mg+2_OH-1(2)_ (s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:145.8 (4SF)	1	ELC	

2	25	0	Inf. Dilution	lgK:146.1 (4SF)	0	ENS	6422
3	25	0:4	Inf. Dilution	lgK:146.0 (4SF)	0	ENS	6494
4	27	0	Inf. Dilution	lgK:145.1 (4SF)	0	ENS	6422
5	27	0:4	Inf. Dilution	lgK:145.0 (4SF)	0	ENS	6494
6	127	0	Inf. Dilution	lgK:104.8 (4SF)	0	ENS	6422
7	127	0:4	Inf. Dilution	lgK:104.8 (4SF)	0	ENS	6494
8	227	0	Inf. Dilution	lgK:80.66 (4SF)	0	ENS	6422
9	227	0:4	Inf. Dilution	lgK:80.64 (4SF)	0	ENS	6494
10	269	0	Inf. Dilution	lgK:73.16 (4SF)	0	ENS	6422
11	327	0:4	Inf. Dilution	lgK:64.58 (4SF)	0	ENS	6494
12	25	0	Inf. Dilution	dG:-199.3 (4SF)	0	EFE	6422
13	25	0	Inf. Dilution	dG:-199.54 (5SF)	0	EFE	6482
14	25	0	Inf. Dilution	dG:-836.5 (4SF) kJ	0	CRV	8739
15	25	0	Inf. Dilution	dG:-832.3 (0.6SD) kJ	0	MSL	23192
16	25	0	Inf. Dilution	dG:-832.230 (6SF) kJ	0	CRV	23205
17	25	0	Inf. Dilution	dG:-832.230 (6SF) kJ	0	EOD	23205
18	25	0	Inf. Dilution	dG:-831.4 (4SF) kJ	3	EOD	29025
19	25	0	Inf. Dilution	dG:-833.42 (5SF) kJ	5	EOD	29520
20	25	0:4	Inf. Dilution	dG:-199.2 (4SF)	0	EFE	6494
21	25	0	GAMSPATH	dG:-835.3 (4SF) kJ	0	CRV	12638
22	25	0	Inf. Dilution	dH:-221.0 (4SF)	2	MTD	6422
23	25	0	Inf. Dilution	dH:-221.2 (4SF)	0	ENS	6437
24	25	0	Inf. Dilution	dH:-221.30 (5SF)	0	EFE	6482
25	25	0	Inf. Dilution	dH:-927.51 (5SF) kJ	0	CRV	8739
26	25	0	Inf. Dilution	dH:-924.5 (4SF) kJ	4	EOD	29025
27	25	0	Inf. Dilution	dH:-924.45 (5SF) kJ	5	EOD	29520
28	25	0:4	Inf. Dilution	dH:-221.0 (4SF)	0	MTD	6494
29	25	0	GAMSPATH	dH:-926.300 (6SF) kJ	0	CRV	12638
30	127	0	Inf. Dilution	dH:-220.9 (4SF)	0	MTD	6422
31	127	0:4	Inf. Dilution	dH:-220.9 (4SF)	0	MTD	6494
32	227	0	Inf. Dilution	dH:-220.7 (4SF)	0	MTD	6422
33	227	0:4	Inf. Dilution	dH:-220.7 (4SF)	0	MTD	6494
34	269	0	Inf. Dilution	dH:-220.6 (4SF)	0	MTD	6422
35	327	0:4	Inf. Dilution	dH:-220.4 (4SF)	0	MTD	6494
36	25	0	Inf. Dilution	Cp:77.0 (3SF) J/K	4	EOD	29025

Reaction No. 66838							
$\text{Mg}+2_{\text{Oxine-1}(2)}_{\text{(s)}} = \text{Mg}+2 + 2\text{Oxine-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-15.4(3SF)	4	ENS	773
2	25	0.1	Unknown	lgK:-14.8(3SF)	4	ENS	773

Reaction No. 66868							
$\text{Mg}+2_{\text{H+1_NH3_PO4-3}}_{\text{(s)}} = \text{Mg}+2 + \text{H+1_NH3} + \text{PO4-3}$							
Note: Query hydration. Probably refers to Struvite							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-12.6(3SF)	1	CRV	
Note (1): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
2	25	0	Inf. Dilution	lgK:-12.6(3SF)	0	CMN	773
3	25	0	Inf. Dilution	lgK:-12.6(3SF)	3	ENS	7694
4	25	0	Inf. Dilution	lgK:-12.6(3SF)	2	MSL	22560
Note (4): Bube, Zh. Anal. Khim., 1910, 49, 525							

Reaction No. 66964							
$2\text{As(s)} + 3\text{Mg(s)} + 4\text{O}_2\text{(g)} = \text{Mg}+2(3)_{\text{AsO4-3}(2)}_{\text{(s)}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:485.8(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:496.1(4SF)	0	ENS	6422
3	27	0	Inf. Dilution	lgK:492.8(4SF)	0	ENS	6422
4	127	0	Inf. Dilution	lgK:359.6(4SF)	0	ENS	6422
5	227	0	Inf. Dilution	lgK:279.8(4SF)	0	ENS	6422
6	327	0	Inf. Dilution	lgK:226.6(4SF)	0	ENS	6422
7	25	0	Inf. Dilution	dG:-676.8(4SF)	0	EFE	6422
8	25	0	Inf. Dilution	dH:-731.3(4SF)	0	MTD	6422
9	127	0	Inf. Dilution	dH:-731.1(4SF)	0	MTD	6422
10	227	0	Inf. Dilution	dH:-730.4(4SF)	0	MTD	6422
11	327	0	Inf. Dilution	dH:-729.7(4SF)	0	MTD	6422

Reaction No. 66965							
$2\text{B(s)} + \text{Mg(s)} = \text{MgB}_2\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.69(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:15.59(4SF)	4	ENS	6422

3	127	0	Inf. Dilution	lgK:11.58 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:9.169 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:7.549 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-21.40 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-22.0 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-22.0 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-22.2 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-22.3 (3SF)	4	MTD	6422

Reaction No. 66966							
4<B(s)> + Mg(s) = MgB ₄ (s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.19 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:18.07 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:13.50 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:10.72 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:8.853 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-24.81 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-25.1 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-25.2 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-25.5 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-25.9 (3SF)	4	MTD	6422

Reaction No. 66967							
Br ₂ (l) + Mg(s) = Mg+2_Br-1(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:88.31 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:87.74 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:64.12 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:49.67 (4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:40.07 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-503.8 (4SF) kJ	3	CRV	6330
7	25	0	Inf. Dilution	dG:-120.5 (4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dG:-503.8 (4SF) kJ	4	EOD	29025
9	25	0	Inf. Dilution	dH:-524.3 (4SF) kJ	3	CRV	6330
10	25	0	Inf. Dilution	dH:-125.3 (4SF)	3	MTD	6422

11	25	0	Inf. Dilution	dH:-524.3 (4SF) kJ	4	EOD	29025
12	127	0	Inf. Dilution	dH:-132.4 (4SF)	2	MTD	6422
13	227	0	Inf. Dilution	dH:-132.0 (4SF)	1	MTD	6422
14	327	0	Inf. Dilution	dH:-131.6 (4SF)	0	MTD	6422

Reaction No. 66968							
2<C(s)> + Mg(s) = MgC2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-14.86 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:-14.76 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:-10.91 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:-8.559 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:-6.971 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:20.27 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:21.0 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:21.4 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:21.7 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:21.9 (3SF)	4	MTD	6422

Reaction No. 66969							
3<C(s)> + 2<Mg(s)> = Mg2C3(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-13.00 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:-12.91 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:-9.410 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:-7.259 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:-5.798 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:17.73 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:19.0 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:19.5 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:19.9 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:20.2 (3SF)	4	MTD	6422

Reaction No. 66970							
H2(g) + Mg(s) = MgH2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.432 (4SF)	4	ENS	6422


2	27	0	Inf. Dilution	lgK:6.350 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:3.002 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:0.960 (3SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:-0.413 (3SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-35.9 (3SF) kJ	5	CRV	6330
7	25	0	Inf. Dilution	dG:-8.77 (3SF)	4	EFE	6422
8	25	0	Inf. Dilution	dH:-75.3 (3SF) kJ	5	CRV	6330
9	25	0	Inf. Dilution	dH:-18.2 (3SF)	4	MTD	6422
10	127	0	Inf. Dilution	dH:-18.6 (3SF)	4	MTD	6422
11	227	0	Inf. Dilution	dH:-18.8 (3SF)	4	MTD	6422
12	327	0	Inf. Dilution	dH:-18.9 (3SF)	4	MTD	6422

Reaction No. 66971							
I2(s) + Mg(s) = Mg+2_I-1(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:63.29 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:62.89 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:46.84 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:36.39 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:28.98 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-358.2 (4SF) kJ	5	CRV	6330
7	25	0	Inf. Dilution	dG:-86.34 (4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dH:-364.0 (4SF) kJ	5	CRV	6330
9	25	0	Inf. Dilution	dH:-87.7 (3SF)	4	MTD	6422
10	127	0	Inf. Dilution	dH:-91.6 (3SF)	4	MTD	6422
11	227	0	Inf. Dilution	dH:-101.9 (4SF)	4	MTD	6422
12	327	0	Inf. Dilution	dH:-101.5 (4SF)	4	MTD	6422

Reaction No. 66972							
3<Mg(s)> + N2(g) = Mg3N2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:70.17 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:69.67 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:49.62 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:37.59 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:29.57 (4SF)	4	ENS	6422


6	25	0	Inf. Dilution	dG:-95.72 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-110.1 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-110.1 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-110.1 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-110.1 (4SF)	4	MTD	6422

Reaction No. 66973



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:128.2 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:127.3 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:92.49 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:71.63 (4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:57.75 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-174.8 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-191.1 (4SF)	2	MTD	6422
8	127	0	Inf. Dilution	dH:-190.9 (4SF)	1	MTD	6422
9	227	0	Inf. Dilution	dH:-190.7 (4SF)	0	MTD	6422
10	327	0	Inf. Dilution	dH:-190.5 (4SF)	0	MTD	6422


Reaction No. 66974



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:360.5 (4SF)	0	ENS	6422
2	25	0	Inf. Dilution	lgK:359.8 (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:358.2 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:357.4 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:263.4 (4SF)	3	ENS	6422
6	127	0	Inf. Dilution	lgK:262.8 (4SF)	3	ENS	6494
7	227	0	Inf. Dilution	lgK:206.6 (4SF)	1	ENS	6422
8	227	0	Inf. Dilution	lgK:206.1 (4SF)	1	ENS	6494
9	327	0	Inf. Dilution	lgK:168.7 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:168.3 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-491.8 (4SF)	0	EFE	6422
12	25	0	Inf. Dilution	dG:-491.16 (5SF)	4	EFE	6482
13	25	0	Inf. Dilution	dG:-490.8 (4SF)	4	EFE	6494


14	25	0	Inf. Dilution	dG:-2053.6 (5SF) kJ	5	CRV	8695
Note (14): p. 169. Sign changed							
15	25	0	Inf. Dilution	dG:-2055.1 (5SF) kJ	5	CRV	8695
Note (15): p. 167. Sign changed							
16	25	0	Inf. Dilution	dG:-2053.6 (5SF) kJ	3	EOD	12843
17	25	0	Inf. Dilution	dG:-2053.5 (5SF) kJ	5	CRV	29482
18	25	0	Inf. Dilution	dH:-520.3 (4SF)	4	MTD	6422
19	25	0	Inf. Dilution	dH:-519.70 (5SF)	4	EFE	6482
20	25	0	Inf. Dilution	dH:-519.4 (4SF)	4	MTD	6494
21	25	0	Inf. Dilution	dH:-2174.0 (5SF) kJ	5	CRV	8695
22	25	0	Inf. Dilution	dH:-2173.0 (5SF) kJ	3	EOD	12843
23	25	0	Inf. Dilution	dH:-2172.6 (5SF) kJ	5	CRV	29482
24	127	0	Inf. Dilution	dH:-520.4 (4SF)	2	MTD	6422
25	127	0	Inf. Dilution	dH:-519.4 (4SF)	2	MTD	6494
26	227	0	Inf. Dilution	dH:-520.2 (4SF)	1	MTD	6422
27	227	0	Inf. Dilution	dH:-519.3 (4SF)	1	MTD	6494
28	327	0	Inf. Dilution	dH:-519.9 (4SF)	0	MTD	6422
29	327	0	Inf. Dilution	dH:-519.0 (4SF)	0	MTD	6494

Reaction No. 66975



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:415.0 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:412.3 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:303.1 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:237.6 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:193.9 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-566.1 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-599.8 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-599.6 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-599.3 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-598.8 (4SF)	4	MTD	6422


Reaction No. 66976



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:50.68 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:50.36 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:37.60 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:29.93 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:24.71 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-69.13 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-70.0 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-70.1 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-71.6 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-71.9 (3SF)	4	MTD	6422

Reaction No. 66977



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:151.8 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:143.0 (4SF)	0	ENS	6422
3	27	0	Inf. Dilution	lgK:142.0 (4SF)	0	ENS	6422
4	127	0	Inf. Dilution	lgK:102.8 (4SF)	0	ENS	6422
5	227	0	Inf. Dilution	lgK:79.36 (4SF)	0	ENS	6422
6	327	0	Inf. Dilution	lgK:63.63 (4SF)	0	ENS	6422
7	25	0	Inf. Dilution	dG:-195.0 (4SF)	0	EFE	6422
8	25	0	Inf. Dilution	dH:-215.2 (4SF)	0	MTD	6422
9	27	0	Inf. Dilution	dH:-215.1 (4SF)	0	MTD	6422
10	127	0	Inf. Dilution	dH:-214.9 (4SF)	0	MTD	6422
11	227	0	Inf. Dilution	dH:-216.0 (4SF)	0	MTD	6422
12	327	0	Inf. Dilution	dH:-215.8 (4SF)	0	MTD	6422

Reaction No. 66978



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:36.25 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:36.02 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:26.89 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:21.39 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:17.69 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-49.45 (4SF)	4	EFE	6422

7	25	0	Inf. Dilution	dH:-50.0 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-50.3 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-50.6 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-51.0 (3SF)	4	MTD	6422

Reaction No. 67301							
Oxalic-2 + 2<Mg+2> = Mg+2 (2) _Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	Inert	lgK:5.8 (2SF)	0	ELC	
2	37	0	Inf. Dilution	lgK:4.28 (3SF)	0	CRV	28703
3	38	0	Inf. Dilution	lgK:4.30 (3SF)	0	MSL	6472

Reaction No. 67302							
Mg+2_H+1_NH3_PO4-3_H2O(6)_(s) = Mg+2 + H+1_NH3 + PO4-3 + 6<H2O>							
Note: Query hydration state above ca. 35C							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:-14.36 (0.025SD)	0	EDH	29566
2	10	0	Inf. Dilution	lgK:-13.71 (4SF)	3	CRV	29733
3	10	0	Inf. Dilution	lgK:-13.27 (4SF)	0	EDH	29792
4	15	0	Inf. Dilution	lgK:-14.04 (0.015SD)	2	EDH	29566
5	15	0	Inf. Dilution	lgK:-13.29 (0.02SD)	3	CRV	29579
6	15	0	Inf. Dilution	lgK:-13.57 (4SF)	3	CRV	29733
7	15	0	Inf. Dilution	lgK:-13.16 (4SF)	2	EDH	29792
8	20	0	Inf. Dilution	lgK:-13.69 (0.01SD)	2	EDH	29566
9	20	0	Inf. Dilution	lgK:-13.22 (0.02SD)	4	CRV	29579
10	20	0	Inf. Dilution	lgK:-13.44 (4SF)	3	CRV	29733
11	20:25	0	Inf. Dilution	lgK:-13.04 (4SF)	0	EOD	29438
Note (11): implied state of hydration							
12	25	0	Inf. Dilution	lgK:-13.2 (3SF)	3	EOD	5606
13	25	0	Inf. Dilution	lgK:-13.12 (4SF)	2	MSL	6474
14	25	0	Inf. Dilution	lgK:-13.26 (4SF)	5	MSL	16935
15	25	0	Inf. Dilution	lgK:-12.6 (3SF)	0	EOD	20981
16	25	0	Inf. Dilution	lgK:-13.15 (4SF)	3	EOD	29070
17	25	0	Inf. Dilution	lgK:-13.36 (0.035SD)	4	EDH	29566
18	25	0	Inf. Dilution	lgK:-13.26 (0.06SD)	5	MSL	29567
19	25	0	Inf. Dilution	lgK:-13.17 (0.01SD)	5	CRV	29579

20	25	0	Inf. Dilution	lgK:-13.15(4SF)	3	EOD	29589
Note (20): Taylor et al., Trans. Faraday Soc., 1963, 59, 1580							
21	25	0	Inf. Dilution	lgK:-13.0(3SF)	0	MSL	29590
Note (21): Tabulated value (though also assumed -12.7 from range -12.6:-13.0)!							
22	25	0	Inf. Dilution	lgK:-13.31(4SF)	3	CRV	29733
23	25	0	Inf. Dilution	lgK:-12.6(3SF)	0	EOD	29733
Note (23): Snoeyink and Jenkins, Water Chemistry, Wiley, 1980							
24	25	0	Inf. Dilution	lgK:-9.41(3SF)	0	EOD	29733
Note (24): Borgerding J., J. Water Pollut. Control Fed., 44, 813-819 (1972)							
25	25	0	Inf. Dilution	lgK:-9.94(3SF)	0	EOD	29733
Note (25): Abbona et al., J. Cryst. Growth, 57, 6-14, (1982)							
26	25	0	Inf. Dilution	lgK:-11.84(4SF)	0	EOD	29733
Note (26): Booram et al., Trans. ASAE, 18, 340-343 (1975)							
27	25	0	Inf. Dilution	lgK:-13.36(4SF)	4	MSL	29735
28	25	0	Inf. Dilution	lgK:-12.93(4SF)	2	EDH	29792
29	25	0.002	NaCl	lgK:-13.1(3SF)	2	MSL	29566
Note (29): Read from Fig. 5							
30	25	0.004	Inert	lgK:-12.75(4SF)	0	MSL	29792
31	25	0.012	NaCl	lgK:-12.6(3SF)	2	MSL	29566
Note (31): Read from Fig. 5							
32	25	0.022	NaCl	lgK:-12.4(3SF)	2	MSL	29566
Note (32): Read from Fig. 5							
33	25	0.036	Inert	lgK:-12.42(4SF)	2	MSL	29792
34	25	0.042	NaCl	lgK:-12.2(3SF)	3	MSL	29566
Note (34): Read from Fig. 5							
35	25	0.048	Inert	lgK:-12.31(4SF)	2	MSL	29792
36	25	0.063	NaCl	lgK:-12.0(3SF)	2	MSL	29566
Note (36): Read from Fig. 5 - see spreadsheet							
37	30	0	Inf. Dilution	lgK:-13.17(0.025SD)	4	EDH	29566
38	30	0	Inf. Dilution	lgK:-13.00(0.04SD)	5	CRV	29579
39	30	0	Inf. Dilution	lgK:-12.80(4SF)	3	EDH	29792
40	35	0	Inf. Dilution	lgK:-12.97(4SF)	3	MSL	6474
41	35	0	Inf. Dilution	lgK:-13.23(0.015SD)	3	EDH	29566
42	35	0	Inf. Dilution	lgK:-13.08(0.06SD)	5	CRV	29579
43	35	0	Inf. Dilution	lgK:-13.04(4SF)	3	CRV	29733
44	38	0	Inf. Dilution	lgK:-12.94(4SF)	3	MSL	6474

45	40	0	Inf. Dilution	lgK:-13.40(0.01SD)	0	EDH	29566
46	40	0	Inf. Dilution	lgK:-12.91(4SF)	3	CRV	29733
47	40	0	Inf. Dilution	lgK:-12.52(4SF)	3	EDH	29792
48	45	0	Inf. Dilution	lgK:-12.84(4SF)	3	MSL	6474
49	45	0	Inf. Dilution	lgK:-13.60(0.03SD)	0	EDH	29566
50	45	0	Inf. Dilution	lgK:-12.78(4SF)	3	CRV	29733
51	50	0	Inf. Dilution	lgK:-13.68(0.04SD)	0	EDH	29566
Note (51): Possibly wrong polymorph, the monohydrate (Ttrans=56C [62BMS_29736])							
52	50	0	Inf. Dilution	lgK:-12.43(4SF)	5	EDH	29792
53	55	0	Inf. Dilution	lgK:-13.84(0.025SD)	0	EDH	29566
54	60	0	Inf. Dilution	lgK:-14.01(0.015SD)	0	EDH	29566

Reaction No. 67402							
$2\text{C(s)} + \text{Ca(s)} + \text{Mg(s)} + 3\text{O}_2\text{(g)} = \text{Ca}_2\text{Mg}_2\text{CO}_3\text{-2(2)}\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:378.6(4SF)	3	ENS	6494
2	27	0	Inf. Dilution	lgK:376.1(4SF)	0	ENS	6494
3	127	0	Inf. Dilution	lgK:275.0(4SF)	2	ENS	6494
4	227	0	Inf. Dilution	lgK:214.3(4SF)	1	ENS	6494
5	327	0	Inf. Dilution	lgK:173.9(4SF)	0	ENS	6494
6	25	0	Inf. Dilution	dG:-516.82(5SF)	3	EFE	6482
7	25	0	Inf. Dilution	dG:-516.6(4SF)	3	EFE	6494
8	25	0	Inf. Dilution	dG:-2172.(4SF) kJ	0	CRV	8739
9	25	0	Inf. Dilution	dG:-2161.7(5SF) kJ	3	CRV	24235
10	25	0	Inf. Dilution	dG:-2161.50(6SF) kJ	3	CRV	25435
11	25	0	GAMSPATH	dG:-2167.(4SF) kJ	2	CRV	12638
12	25	0	Inf. Dilution/m	dG:-2161.6(5SF) kJ	3	EPZ	9073
13	25	0	Inf. Dilution	dH:-555.75(5SF)	3	EFE	6482
14	25	0	Inf. Dilution	dH:-555.6(4SF)	3	MTD	6494
15	25	0	Inf. Dilution	dH:-2334.80(6SF) kJ	0	CRV	8739
16	25	0	Inf. Dilution	dH:-2324.5(5SF) kJ	3	CRV	24235
17	25	0	Inf. Dilution	dH:-2324.60(6SF) kJ	3	CRV	25435
18	25	0	GAMSPATH	dH:-2329.90(6SF) kJ	2	CRV	12638
19	127	0	Inf. Dilution	dH:-555.3(4SF)	2	MTD	6494
20	227	0	Inf. Dilution	dH:-554.8(4SF)	1	MTD	6494
21	327	0	Inf. Dilution	dH:-554.2(4SF)	0	MTD	6494


Reaction No. 67406							
$2\text{K(s)} + 2\text{Mg(s)} + 6\text{O}_2\text{(g)} + 3\text{S(s)} = \text{Mg}_2\text{K}_2\text{SO}_4\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:654.1(4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:649.7(4SF)	4	ENS	6494
3	127	0	Inf. Dilution	lgK:472.3(4SF)	4	ENS	6494
4	227	0	Inf. Dilution	lgK:365.5(4SF)	4	ENS	6494
5	327	0	Inf. Dilution	lgK:294.4(4SF)	4	ENS	6494
6	25	0	Inf. Dilution	dG:-892.3(4SF)	4	EFE	6494
7	25	0	Inf. Dilution	dH:-973.0(4SF)	4	MTD	6494
8	127	0	Inf. Dilution	dH:-976.2(4SF)	4	MTD	6494
9	227	0	Inf. Dilution	dH:-977.1(4SF)	4	MTD	6494
10	327	0	Inf. Dilution	dH:-977.2(4SF)	4	MTD	6494

Reaction No. 67407							
$\text{Al(s)} + \text{F}_2\text{(g)} + \text{K(s)} + 3\text{Mg(s)} + 5\text{O}_2\text{(g)} + 3\text{Si(s)} = \text{KMg}_3\text{AlSi}_3\text{O}_{10}\text{F}_2\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1056.(4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:1050.(4SF)	0	ENS	6494
3	127	0	Inf. Dilution	lgK:771.9(4SF)	4	ENS	6494
4	227	0	Inf. Dilution	lgK:605.4(4SF)	4	ENS	6494
5	327	0	Inf. Dilution	lgK:494.4(4SF)	4	ENS	6494
6	25	0	Inf. Dilution	dG:-1441.(4SF)	4	EFE	6494
7	25	0	GAMSPATH	dG:-6031.(4SF) kJ	3	CRV	12638
8	25	0	Inf. Dilution	dH:-1524.(4SF)	4	MTD	6494
9	127	0	Inf. Dilution	dH:-1525.(4SF)	4	MTD	6494
10	227	0	Inf. Dilution	dH:-1524.(4SF)	4	MTD	6494
11	327	0	Inf. Dilution	dH:-1523.(4SF)	4	MTD	6494

Reaction No. 67414							
$\text{Mg(s)} + 1.5\text{O}_2\text{(g)} + \text{Si(s)} = \text{MgO} \cdot \text{SiO}_2\text{(Ilmen.,s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:244.8(4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:243.2(4SF)	4	ENS	6494
3	127	0	Inf. Dilution	lgK:178.5(4SF)	4	ENS	6494
4	227	0	Inf. Dilution	lgK:139.8(4SF)	4	ENS	6494


5	327	0	Inf. Dilution	lgK:113.9(4SF)	4	ENS	6494
6	25	0	Inf. Dilution	dG:-334.0(4SF)	4	EFE	6494
7	25	0	Inf. Dilution	dH:-355.3(4SF)	4	MTD	6494
8	127	0	Inf. Dilution	dH:-355.0(4SF)	4	MTD	6494
9	227	0	Inf. Dilution	dH:-354.7(4SF)	4	MTD	6494
10	327	0	Inf. Dilution	dH:-354.4(4SF)	4	MTD	6494

Reaction No. 67415




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:523.5(4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:520.1(4SF)	4	ENS	6494
3	127	0	Inf. Dilution	lgK:382.7(4SF)	4	ENS	6494
4	227	0	Inf. Dilution	lgK:300.3(4SF)	4	ENS	6494
5	327	0	Inf. Dilution	lgK:245.4(4SF)	4	ENS	6494
6	25	0	Inf. Dilution	dG:-714.2(4SF)	4	EFE	6494
7	25	0	Inf. Dilution	dH:-754.3(4SF)	4	MTD	6494
8	127	0	Inf. Dilution	dH:-754.3(4SF)	4	MTD	6494
9	227	0	Inf. Dilution	dH:-754.0(4SF)	4	MTD	6494
10	327	0	Inf. Dilution	dH:-753.5(4SF)	4	MTD	6494

Reaction No. 67417



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1022.(4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:1016.(4SF)	0	ENS	6494
3	127	0	Inf. Dilution	lgK:747.6(4SF)	4	ENS	6494
4	227	0	Inf. Dilution	lgK:586.8(4SF)	4	ENS	6494
5	327	0	Inf. Dilution	lgK:479.7(4SF)	4	ENS	6494
6	25	0	Inf. Dilution	dG:-1395.(4SF)	4	EFE	6494
7	25	0	Inf. Dilution	dH:-1473.(4SF)	4	MTD	6494
8	127	0	Inf. Dilution	dH:-1472.(4SF)	4	MTD	6494
9	227	0	Inf. Dilution	dH:-1471.(4SF)	4	MTD	6494
10	327	0	Inf. Dilution	dH:-1470.(4SF)	4	MTD	6494

Reaction No. 67429



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-348.2 (4SF)	4	EFE	6482
2	25	0	Inf. Dilution	dH:-369.0 (4SF)	4	EFE	6482

Reaction No. 67435							
$\text{Mg}_3\text{Si}_4\text{O}_{10}(\text{OH})_2 \cdot 2\text{H}_2\text{O}(\text{s}) + 6\langle\text{H}+1\rangle + 3\langle\text{H}_2\text{O}\rangle = 3\langle\text{Mg}+2\rangle + 4\langle\text{H}+1(2)\rangle_{\text{SiH}_2\text{O}_4-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.79 (4SF)	1	ENS	6496
2	25	0	Inf. Dilution	lgK:23.54 (4SF)	1	CRV	32224
Note (2): trihydrate							

Reaction No. 67745							
$\text{HBEDPO-6} + \text{Mg}+2 = \text{Mg}+2_{\text{HBEDPO-6}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:8.0 (0.05SD)	5	MGL	6515

Reaction No. 67746							
$\text{Mg}+2 + \text{H}+1(2)_{\text{HBEDPO-6}} = \text{Mg}+2_{\text{H}+1(2)_{\text{HBEDPO-6}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.04 (3SF)	5	MGL	6515

Reaction No. 67747							
$\text{Mg}+2_{\text{HBEDPO-6}} + \text{H}+1 = \text{Mg}+2_{\text{H}+1_{\text{HBEDPO-6}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:11.05 (4SF)	5	MGL	6515

Reaction No. 67748							
$\text{Mg}+2_{\text{H}+1_{\text{HBEDPO-6}}} + \text{H}+1 = \text{Mg}+2_{\text{H}+1(2)_{\text{HBEDPO-6}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:9.10 (3SF)	5	MGL	6515

Reaction No. 67792							
$\text{Mg}+2_{\text{Picric-1}} + \text{Picric-1} = \text{Mg}+2_{\text{Picric-1}(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0	Inf. Dilution	lgK:1.49 (3SF)	4	MCN	1926
2	30		Propan-2-ol	lgK:2.85 (3SF)	4	MCN	1926

Reaction No. 68118							
--------------------	--	--	--	--	--	--	--

N6Me2PyridMeAsp-2 + Mg+2 = Mg+2_N6Me2PyridMeAsp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:3.00 (0.05MD)	5	MPT	6937
2	20	0.1	NaNO3	dH:4.8 (0.1MD)	5	MCL	6937

Reaction No. 68206							
3OH2Naphthoic-2 + Mg+2 = Mg+2_3OH2Naphthoic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Dioxan:Water 70:30Vol KNO3	lgK:4.12 (3SF)	5	MGL	6908
2	30	0	Dioxan:Water 70:30Vol Inf. Dilution	lgK:6.88 (3SF)	5	MGL	6908
3	30	0.05	Dioxan:Water 70:30Vol KNO3	lgK:5.33 (3SF)	5	MGL	6908
4	30	0.1	Dioxan:Water 70:30Vol KNO3	lgK:4.85 (3SF)	5	MGL	6908
5	30	0.15	Dioxan:Water 70:30Vol KNO3	lgK:4.22 (3SF)	5	MGL	6908
6	40	0.1	Dioxan:Water 70:30Vol KNO3	lgK:5.78 (3SF)	5	MGL	6908

Reaction No. 68207							
Mg+2_3OH2Naphthoic-2 + 3OH2Naphthoic-2 = Mg+2_3OH2Naphthoic-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Dioxan:Water 70:30Vol KNO3	lgK:3.11 (3SF)	5	MGL	6908
2	30	0	Dioxan:Water 70:30Vol Inf. Dilution	lgK:5.65 (3SF)	5	MGL	6908
3	30	0.05	Dioxan:Water 70:30Vol KNO3	lgK:4.63 (3SF)	5	MGL	6908
4	30	0.1	Dioxan:Water 70:30Vol KNO3	lgK:4.08 (3SF)	5	MGL	6908
5	30	0.15	Dioxan:Water 70:30Vol KNO3	lgK:3.87 (3SF)	5	MGL	6908

6	40	0.1	Dioxan:Water 70:30Vol KNO3	lgK:5.43(3SF)	5	MGL	6908
---	----	-----	----------------------------------	---------------	---	-----	------

Reaction No. 68219							
C(s) + Mg(s) + 1.5<O2(g)> = Mg+2_CO3-2_(syn.,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1031.(4SF)kJ	5	CRV	8739
2	25	0	Inf. Dilution	dH:-1114.40(6SF)kJ	5	CRV	8739

Reaction No. 68311							
Mg+2 + H+1_1AmEtPhos-2 = Mg+2_H+1_1AmEtPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:1.3(0.04SD)	5	MGL	6868

Reaction No. 68321							
Mg+2 + H+1_2AmEtPhos-2 = Mg+2_H+1_2AmEtPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:1.4(0.03SD)	5	MGL	6868

Reaction No. 68341							
H+1 + Glyphosate-3 + Mg+2 = Mg+2_H+1_Glyphosate-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:12.12(0.02SD)	5	MGL	6861
2	25	0.1	Unknown	lgK:12.1(0.1SD)	6	CIU	7242

Reaction No. 69094							
MePhos-2 + Mg+2 = Mg+2_MePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Many Media	lgK:2.0(0.2SD)	6	CIU	7242
2	25	0.1	NaNO3	lgK:1.86(0.02MD)	4	MGL	1860
3	25	0.1	NaNO3	lgK:1.67(0.05MD)	5	MGL	6412
4	30	0.3	Unknown	lgK:1.53(3SF)	4	MGL	4547

Reaction No. 69143							
Mg+2 + CO2(g) + H2O = Mg+2_H+1_CO3-2 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-6.9(2SF)	1	EOR	

2	25	3	NaClO4	lgK:-7.65 (0.01SD)	3	MGL	6211
3	50	3	NaClO4	lgK:-7.46 (0.01SD)	0	MGL	6211
4	25:50	3	NaClO4	dH:3.25 (3SF)	3	MTD	6211

Reaction No. 69144							
$\text{Mg}+2 + 2\text{CO}_2(\text{g}) + 2\text{H}_2\text{O} = \text{Mg}+2_{\text{H}+1(2)}\text{CO}_3-2(2) + 2\text{H}+1$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-14.8 (3SF)	1	EOR	
2	25	3	NaClO4	lgK:-15.0 (0.1SD)	5	MGL	6211
3	50	3	NaClO4	lgK:-15. (0.4SD)	5	MGL	6211
4	25:50	3	NaClO4	dH:-6.45 (3SF)	5	MTD	6211

Reaction No. 69145							
$\text{Mg}+2 + \text{CO}_2(\text{g}) + \text{H}_2\text{O} = \text{Mg}+2_{\text{CO}_3-2} + 2\text{H}+1$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-14.8 (3SF)	1	EOR	
2	25	3	NaClO4	lgK:-15.6 (0.06SD)	3	MGL	6211
Note (2): Low wgt for inter-reaction consistency							
3	50	3	NaClO4	lgK:-15.23 (0.02SD)	3	MGL	6211
4	100	0	Inf. Dilution	lgK:-15.1 (3SF)	1	EOR	
5	100	3	Inert	lgK:-15.3 (3SF)	1	EOR	
6	25:50	3	NaClO4	dH:7.19 (3SF)	3	MTD	6211

Reaction No. 69196							
$\text{PhenPhos}-2 + \text{Mg}+2 = \text{Mg}+2_{\text{PhenPhos}-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.3	Unknown	lgK:1.72 (3SF)	4	MGL	4547

Reaction No. 69197							
$\text{AcOPO}_3-2 + \text{Mg}+2 = \text{Mg}+2_{\text{AcOPO}_3-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.3	Unknown	lgK:0.78 (2SF)	4	MGL	4547

Reaction No. 69296							
$2\text{Mg}+2_{\text{5ADP}-3} = \text{Mg}+2(2)_{\text{5ADP}-3(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	75	0	Me4NOH/m	lgK:0.79 (0.01SD)	4	MCL	7086


2	100	0	Me4NOH/m	lgK:0.79 (0.01SD)	4	MCL	7086
3	75	0	Me4NOH	dH:-0.4 (0.8SD) kJ	4	MCL	7086
4	100	0	Me4NOH	dH:-0.2 (0.8SD) kJ	4	MCL	7086
5	75	0	Me4NOH	Cp:5. (16. SD) J/K	4	MCL	7086
6	100	0	Me4NOH	Cp:5. (16. SD) J/K	4	MCL	7086

Reaction No. 69297							
Mg+2_5ATP-4 + 5ATP-4 = Mg+2_5ATP-4 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.5 (2SF)	1	EES	
2	50	0	Me4NOH/m	lgK:2.82 (0.01SD)	4	MCL	7086
3	75	0	Me4NOH/m	lgK:3.15 (0.01SD)	3	MCL	7086
4	100	0	Me4NOH/m	lgK:3.50 (0.01SD)	2	MCL	7086
5	125	0	Me4NOH/m	lgK:3.84 (0.01SD)	2	MCL	7086
6	50	0	Me4NOH	dH:26.2 (0.8SD) kJ	4	MCL	7086
7	75	0	Me4NOH	dH:31.6 (0.8SD) kJ	3	MCL	7086
8	100	0	Me4NOH	dH:36.7 (0.8SD) kJ	3	MCL	7086
9	125	0	Me4NOH	dH:42.0 (0.8SD) kJ	3	MCL	7086
10	50	0	Me4NOH	Cp:210. (16. SD) J/K	3	MCL	7086
11	75	0	Me4NOH	Cp:210. (16. SD) J/K	3	MCL	7086
12	100	0	Me4NOH	Cp:210. (16. SD) J/K	2	MCL	7086
13	125	0	Me4NOH	Cp:210. (16. SD) J/K	2	MCL	7086

Reaction No. 69298							
2<Mg+2_5ATP-4> = Mg+2 (2)_5ATP-4 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	50	0	Me4NOH/m	lgK:0.53 (0.01SD)	4	MCL	7086
2	75	0	Me4NOH/m	lgK:0.46 (0.01SD)	4	MCL	7086
3	100	0	Me4NOH/m	lgK:0.41 (0.01SD)	4	MCL	7086
4	125	0	Me4NOH/m	lgK:0.36 (0.01SD)	4	MCL	7086
5	50	0	Me4NOH	dH:-5.5 (0.8SD) kJ	4	MCL	7086
6	75	0	Me4NOH	dH:-5.4 (0.8SD) kJ	4	MCL	7086
7	100	0	Me4NOH	dH:-5.3 (0.8SD) kJ	4	MCL	7086
8	125	0	Me4NOH	dH:-5.2 (0.8SD) kJ	4	MCL	7086
9	50	0	Me4NOH	Cp:4. (16. SD) J/K	4	MCL	7086
10	75	0	Me4NOH	Cp:4. (16. SD) J/K	4	MCL	7086


11	100	0	Me4NOH	Cp:4.(16.SD)J/K	4	MCL	7086
12	125	0	Me4NOH	Cp:4.(16.SD)J/K	4	MCL	7086

Reaction No. 69618




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:2.(1SF)	3	MGL	2482

Reaction No. 69698




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KCl	lgK:-6.4(2SF)	4	MKN	1503

Reaction No. 69729




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NCl	lgK:7.96(3SF)	5	MGL	274

Reaction No. 69730




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Me4NCl	lgK:2.34(3SF)	5	MGL	274

Reaction No. 69753




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:6.71(3SF)	3	MGL	2261

Reaction No. 69762



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:2.0(2SF)	0	MGL	6024

Reaction No. 69793



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.85(0.03MD)	5	MGL	1860

Reaction No. 69977							
$2\text{C(s)} + \text{Mg(s)} + 3\text{O}_2\text{(g)} + 2\text{e}^- = \text{Mg}_2\text{CO}_3\text{-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1533.(4SF) kJ	5	CRV	8739
2	25	0	Inf. Dilution	dH:-1839.4(5SF) kJ	5	CRV	8739

Reaction No. 69978							
$\text{C(s)} + \text{Mg(s)} + 1.5\text{O}_2\text{(g)} = \text{Mg}_2\text{CO}_3\text{-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-999.7(4SF) kJ	5	CRV	8739
2	25	0	Inf. Dilution	dG:-238.76(5SF)	4	CRV	10174
3	25	0	Inf. Dilution	dG:-998.980(6SF) kJ	4	CRV	23205
4	25	0	Inf. Dilution	dG:-998.980(6SF) kJ	3	EOD	23205
5	25	0	Inf. Dilution	dG:-1000.3(5SF) kJ	5	EFE	26086
6	25	0	Inf. Dilution	dG:-999.0(4SF) kJ	4	EOD	29025
7	25	0	Inf. Dilution/m	dG:-1002.50(6SF) kJ	2	CRV	24953
8	50	0	Inf. Dilution	dG:-238.14(5SF)	1	CRV	10174
9	75	0	Inf. Dilution	dG:-237.48(5SF)	1	CRV	10174
10	100	0	Inf. Dilution	dG:-236.80(5SF)	1	CRV	10174
11	125	0	Inf. Dilution	dG:-236.10(5SF)	1	CRV	10174
12	150	0	Inf. Dilution	dG:-235.38(5SF)	1	CRV	10174
13	175	0	Inf. Dilution	dG:-234.65(5SF)	4	CRV	10174
14	200	0	Inf. Dilution	dG:-233.90(5SF)	1	CRV	10174
15	225	0	Inf. Dilution	dG:-233.15(5SF)	0	CRV	10174
16	250	0	Inf. Dilution	dG:-232.38(5SF)	0	CRV	10174
17	300	0	Inf. Dilution	dG:-230.84(5SF)	0	CRV	10174
18	25	0	Inf. Dilution	dH:-1128.90(6SF) kJ	5	CRV	8739
19	25	0	Inf. Dilution	dH:-1127.(4SF) kJ	5	EFE	26086
20	25	0	Inf. Dilution	dH:-1132.1(5SF) kJ	4	EOD	29025
21	25	0	Inf. Dilution	Cp:-114.6(4SF) J/K	4	EOD	29025

Reaction No. 70582							
$\text{Mg}_2\text{Rb}_2\text{Cl}_2\text{(3)} + \text{H}_2\text{O(6)}\text{(s)} = \text{Rb}_2\text{O} + \text{Mg}_2\text{O} + 3\text{Cl}_2\text{(g)} + 6\text{H}_2\text{O(g)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.083(4SF)	5	MSL	14335

Reaction No. 71081							
--------------------	--	--	--	--	--	--	--

Mg+2_OH-1(2)_(s) + 2<e-1> = Mg(s) + 2<OH-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-90.7(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:-2.690(4SF)	0	CRV	6330
3	25	0	Inf. Dilution	E:-2.690(4SF)	0	CRV	7761
4	25	0	Inf. Dilution	E:-2.687(4SF)	0	CRV	22551
5	25	0	Inf. Dilution	dH:464.7(4SF) kJ	2	CRV	7761

Reaction No. 71082							
Mg+1 + e-1 = Mg(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:-2.70(3SF)	5	CRV	6330

Reaction No. 71181							
Mg+2_OH-1 + H+1 + 2<e-1> = Mg(s) + H2O							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:-2.022(4SF)	0	CRV	7761
2	25	0	Inf. Dilution	dH:404.6(4SF) kJ	0	CRV	7761

Reaction No. 71182							
Mg+2(4)_OH-1(4) + 4<H+1> + 8<e-1> = 4<Mg(s)> + 4<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-279.2(4SF)	1	ELC	
2	25	0	Inf. Dilution	E:-2.067(4SF)	0	CRV	7761

Reaction No. 71183							
Mg+2 + H2(g) + 2<e-1> = MgH2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-73.3(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:-2.173(4SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:391.4(4SF) kJ	2	CRV	7761

Reaction No. 71184							
MgO(s) + H2O + 2<e-1> = Mg(s) + 2<OH-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-86.4(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:-2.550(4SF)	0	CRV	7761

3	25	0	Inf. Dilution	dH:427.6(4SF)kJ	2	CRV	7761
---	----	---	---------------	-----------------	---	-----	------

Reaction No. 71185




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-88.9(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:-2.68(3SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:460.8(4SF)kJ	3	CRV	7761

Reaction No. 71223




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-968.5(4SF)kJ	5	CRV	6330

Reaction No. 71566




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.89(0.04MD)w	5	MPH	8309

Reaction No. 71567




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:0.5(0.3MD)w	5	MPH	8309

Reaction No. 71740



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2569.(4SF)kJ	5	CRV	8739
2	25	0	GAMSPATH	dG:-2569.(4SF)kJ	3	CRV	12638
3	25	0	Inf. Dilution	dH:-2920.60(6SF)kJ	5	CRV	8739
4	25	0	GAMSPATH	dH:-2920.60(6SF)kJ	3	CRV	12638

Reaction No. 71741



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2157.10(6SF)kJ	4	CRV	23205
2	25	0	Inf. Dilution	dG:-2157.10(6SF)kJ	3	EOD	23205

3	25	0	GAMSPATH	dG:-2158.(4SF)kJ	2	CRV	12638
4	25	0	GAMSPATH	dH:-2317.60(6SF)kJ	2	CRV	12638

Reaction No. 71743							
$3\text{C(s)} + 4\text{H}_2\text{(g)} + 4\text{Mg(s)} + 7\text{O}_2\text{(g)} = \text{Mg}_2(4)\text{OH-1(2)}\text{CO}_3\text{-2(3)}\text{H}_2\text{O(3)}\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-6043.(4SF)kJ	0	CRV	8739
Note (1): Not regarded any longer as the correct stoichiometry for Hydromagnesite							
2	25	0	GAMSPATH	dG:-6037.(4SF)kJ	0	CRV	12638
Note (2): Not regarded any longer as the correct stoichiometry for Hydromagnesite							
3	25	0	Inf. Dilution	dH:-6516.0(5SF)kJ	0	CRV	8739
Note (3): Not regarded any longer as the correct stoichiometry for Hydromagnesite							
4	25	0	GAMSPATH	dH:-6514.9(5SF)kJ	0	CRV	12638


Reaction No. 71745							
$\text{C(s)} + 3\text{H}_2\text{(g)} + \text{Mg(s)} + 3\text{O}_2\text{(g)} = \text{Mg}_2\text{CO}_3\text{-2H}_2\text{O(3)}\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1725.(4SF)kJ	4	CRV	8739
2	25	0	Inf. Dilution	dG:-1723.6(5SF)kJ	3	EOD	29025
3	25	0	GAMSPATH	dG:-1724.(4SF)kJ	1	CRV	12638
4	25	0	Inf. Dilution/m	dG:-1723.6(5SF)kJ	3	EPZ	9073
5	25	0	Inf. Dilution	dH:-1978.40(6SF)kJ	1	CRV	8739
6	25	0	Inf. Dilution	dH:-2001.5(5SF)kJ	1	EOD	29025
7	25	0	GAMSPATH	dH:-1977.30(6SF)kJ	3	CRV	12638
8	25	0	Inf. Dilution	Cp:200.7(4SF)J/K	4	EOD	29025

Reaction No. 71746							
$2\text{H}_2\text{(g)} + 3\text{Mg(s)} + 4.5\text{O}_2\text{(g)} + 2\text{Si(s)} = \text{Mg}_3\text{Si}_2\text{O}_5(\text{OH})_4\text{(Serp.,s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	GAMSPATH	dG:-4040.(4SF)kJ	3	CRV	12638
2	25	0	GAMSPATH	dH:-4367.70(6SF)kJ	3	CRV	12638

Reaction No. 71756							
$0.5\text{F}_2\text{(g)} + \text{Mg(s)} - \text{e-1} = \text{Mg}_2\text{F-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:131.3(4SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-177.69(5SF)	0	CRV	10174


3	25	0	GAMSPATH	dG:-744.0 (4SF) kJ	0	CRV	12638
4	50	0	Inf. Dilution	dG:-177.03 (5SF)	0	CRV	10174
5	75	0	Inf. Dilution	dG:-176.43 (5SF)	0	CRV	10174
6	100	0	Inf. Dilution	dG:-175.88 (5SF)	0	CRV	10174
7	125	0	Inf. Dilution	dG:-175.38 (5SF)	0	CRV	10174
8	150	0	Inf. Dilution	dG:-174.92 (5SF)	0	CRV	10174
9	175	0	Inf. Dilution	dG:-174.49 (5SF)	0	CRV	10174
10	200	0	Inf. Dilution	dG:-174.08 (5SF)	0	CRV	10174
11	225	0	Inf. Dilution	dG:-173.69 (5SF)	0	CRV	10174
12	250	0	Inf. Dilution	dG:-173.30 (5SF)	0	CRV	10174
13	300	0	Inf. Dilution	dG:-172.54 (5SF)	0	CRV	10174
14	25	0	GAMSPATH	dH:-778.890 (6SF) kJ	0	CRV	12638

Reaction No. 71771



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	GAMSPATH	dG:-1213. (4SF) kJ	3	CRV	12638
2	25	0	GAMSPATH	dH:-1350.60 (6SF) kJ	3	CRV	12638

Reaction No. 71818




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:109.6 (4SF)	1	EOR	
2	25	0	Inf. Dilution	dG:-625.3 (4SF) kJ	0	CRV	8739

Note (2): Low wgt for inter-reaction consistency

3	25	0	Inf. Dilution	dG:-625.870 (6SF) kJ	0	CRV	23205
4	25	0	Inf. Dilution	dG:-625.870 (6SF) kJ	3	EOD	23205
5	25	0	Inf. Dilution	dG:-626.7 (4SF) kJ	4	EOD	29025
6	25	0	Inf. Dilution	dH:-688.290 (6SF) kJ	0	MTD	8739
7	25	0	Inf. Dilution	dH:-640.0 (4SF) kJ	4	EOD	29025
8	25	0	GAMSPATH	dH:-683.000 (6SF) kJ	0	CRV	12638
9	25	0	Inf. Dilution	Cp:128.9 (4SF) J/K	4	EOD	29025


Reaction No. 71869



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.08 (1SF)	3	CRV	6405

2	100	0	Inf. Dilution	lgK:-1.4 (2SF)	1	EOR	
---	-----	---	---------------	----------------	---	-----	--


Reaction No. 71873



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-69.2 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:70.14 (4SF)	0	CRV	6405


Note (2): p. 246

Reaction No. 71953




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	Inert	lgK:-0.2 (1SF)	0	EES	
2	38	0	Inf. Dilution	lgK:0.86 (2SF)	0	CRV	8692

Reaction No. 72452




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.058	Unknown	lgK:2.32 (3SF)	5	MPS	8626
2	37	0.15	Unknown	lgK:2.04 (3SF)	5	MPS	8626
3	37	0.24	Unknown	lgK:1.95 (3SF)	5	MPS	8626

Reaction No. 72517




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.99 (4SF)	1	ELC	
2	14:17	10	NH4NO3	dH:-0.1 (1SF)	0	MCL	5699

Reaction No. 72854



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.06 (3SF)	4	MGL	5989

Reaction No. 72857



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.07 (0.05MD)	4	MGL	5989

Reaction No. 72861							
pCresol-1 + Mg+2 = Mg+2_pCresol-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.07(0.05MD)	5	MGL	5989

Reaction No. 72865							
2NitrPhenol-1 + Mg+2 = Mg+2_2NitrPhenol-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.00(0.04MD)	5	MGL	5989

Reaction No. 72869							
4NitrPhenol-1 + Mg+2 = Mg+2_4NitrPhenol-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.99(0.03MD)	5	MGL	5989

Reaction No. 72900							
Mg+2_5ATP-4 + BisTris = Mg+2_BisTris_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:0.59(0.10SD)	5	MGL	6089

Reaction No. 72918							
Mg+2_5ATP-4 + Tris = Mg+2_Trис_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:0.7(1SF)	3	MGL	6086

Reaction No. 72955							
Mg+2_SeO3-2_(s) = Mg+2 + SeO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18	0.01	Unknown	lgK:-5.74(0.04SD)	0	MSL	12931
2	20			lgK:-4.9(0.1SD)	0	MSL	12931
3	23	0	Inf. Dilution	lgK:-7.56(0.40SD)	3	MSL	12931
4	25	0	Inf. Dilution	lgK:-8.99(3SF)	4	ENS	12931
5	25	0	Inf. Dilution	lgK:-7.56(0.40SD)	3	EOD	32222
6	25	0	Inf. Dilution	dH:-76.003(0.608SD)kJ	3	EOD	32222

Reaction No. 72971							
Mg+2_SeO4-2_H2O(6)_(s) = Mg+2 + SeO4-2 + 6<H2O>							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.13(3SF)	4	MSL	12931
2	25	0	Inf. Dilution	lgK:-1.13(3SF)	3	EOD	32222
3	25	0	Inf. Dilution	dH:-2.129(0.662SD)kJ	3	EOD	32222

Reaction No. 72987							
Mg+2_SeO4-2 = Mg+2 + SeO4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.2(2SF)	2	MPT	12931
2	25	0	Inf. Dilution	lgK:-2.20(3SF)	3	EOD	32222
3	25	0	Inf. Dilution	dG:0.23(2SF)	0	ENS	12931
4	25	0	Inf. Dilution	dH:19.692(5SF)kJ	3	EOD	32222

Reaction No. 73020							
Mg+2_5CTP-4 + H+1 = Mg+2_H+1_5CTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:4.62(0.095SD)	5	MGL	6100


Reaction No. 73028							
Mg+2_5UTP-4 + H+1 = Mg+2_H+1_5UTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:4.90(0.045SD)	5	MGL	6100

Reaction No. 73055							
Mg+2_5CMP-2 + H+1 = Mg+2_H+1_5CMP-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:4.9(0.4MD)	5	MGL	6118

Reaction No. 73137							
Bu1234TetrCOO-4 + Mg+2 = Mg+2_Bu1234TetrCOO-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.39(0.02SD)	4	MGL	6124
2	25	0.04	Unknown	lgK:3.29(0.02SD)	5	MGL	6124
3	25	0.09	Unknown	lgK:3.01(0.02SD)	5	MGL	6124
4	25	0.25	Unknown	lgK:2.81(0.02SD)	5	MGL	6124
5	25	0.49	Unknown	lgK:2.89(0.02SD)	5	MGL	6124
6	25	0.64	Unknown	lgK:2.99(0.02SD)	5	MGL	6124


7	25	1	Unknown	lgK:3.23 (0.02SD)	5	MGL	6124
---	----	---	---------	-------------------	---	-----	------

Reaction No. 73138




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.47 (0.01SD)	4	MGL	6124
2	25	0.04	Unknown	lgK:9.10 (0.01SD)	5	MGL	6124
3	25	0.09	Unknown	lgK:8.77 (0.01SD)	5	MGL	6124
4	25	0.25	Unknown	lgK:8.52 (0.01SD)	5	MGL	6124
5	25	0.49	Unknown	lgK:8.64 (0.01SD)	5	MGL	6124
6	25	0.64	Unknown	lgK:8.77 (0.01SD)	5	MGL	6124
7	25	1	Unknown	lgK:9.10 (0.01SD)	5	MGL	6124

Reaction No. 73139




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.26 (0.02SD)	4	MGL	6124
2	25	0.04	Unknown	lgK:13.75 (0.02SD)	5	MGL	6124
3	25	0.09	Unknown	lgK:13.39 (0.02SD)	5	MGL	6124
4	25	0.25	Unknown	lgK:13.13 (0.02SD)	5	MGL	6124
5	25	0.49	Unknown	lgK:13.28 (0.02SD)	5	MGL	6124
6	25	0.64	Unknown	lgK:13.44 (0.02SD)	5	MGL	6124
7	25	1	Unknown	lgK:13.82 (0.02SD)	5	MGL	6124

Reaction No. 73140



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.67 (0.03SD)	4	MGL	6124
2	25	0.04	Unknown	lgK:17.16 (0.03SD)	5	MGL	6124
3	25	0.09	Unknown	lgK:16.80 (0.03SD)	5	MGL	6124
4	25	0.25	Unknown	lgK:16.56 (0.03SD)	5	MGL	6124
5	25	0.49	Unknown	lgK:16.73 (0.03SD)	5	MGL	6124
6	25	0.64	Unknown	lgK:16.91 (0.03SD)	5	MGL	6124
7	25	1	Unknown	lgK:17.33 (0.03SD)	5	MGL	6124

Reaction No. 73141



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.74 (0.02SD)	4	MGL	6124
2	25	0.04	Unknown	lgK:5.10 (0.02SD)	5	MGL	6124
3	25	0.09	Unknown	lgK:4.69 (0.02SD)	5	MGL	6124
4	25	0.25	Unknown	lgK:4.39 (0.02SD)	5	MGL	6124
5	25	0.49	Unknown	lgK:4.52 (0.02SD)	5	MGL	6124
6	25	0.64	Unknown	lgK:4.68 (0.02SD)	5	MGL	6124
7	25	1	Unknown	lgK:5.05 (0.02SD)	5	MGL	6124

Reaction No. 73142							
H+1 + Bul234TetrCOO-4 + 2<Mg+2> = Mg+2 (2) _H+1_Bul234TetrCOO-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.58 (0.03SD)	4	MGL	6124
2	25	0.04	Unknown	lgK:9.94 (0.03SD)	5	MGL	6124
3	25	0.09	Unknown	lgK:9.54 (0.03SD)	5	MGL	6124
4	25	0.25	Unknown	lgK:9.25 (0.03SD)	5	MGL	6124
5	25	0.49	Unknown	lgK:9.41 (0.03SD)	5	MGL	6124
6	25	0.64	Unknown	lgK:9.58 (0.03SD)	5	MGL	6124
7	25	1	Unknown	lgK:9.99 (0.03SD)	5	MGL	6124

Reaction No. 73167							
2<H+1> + His-1 + Mg+2 = Mg+2_H+1 (2) _His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.09 (4SF)	4	MPH	6131
2	25	0	Inf. Dilution	dH:-45. (2SF) kJ	4	MCL	6131

Reaction No. 73177							
H+1 + IDA-2 + Mg+2 = Mg+2_H+1_IDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.54 (4SF)	4	MGL	6131
2	25	0	Inf. Dilution	dH:-28. (2SF) kJ	4	MCL	6131

Reaction No. 73178							
2<H+1> + IDA-2 + Mg+2 = Mg+2_H+1 (2) _IDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.25 (4SF)	4	MGL	6131
2	25	0	Inf. Dilution	dH:-32. (2SF) kJ	4	MCL	6131

Reaction No. 73387							
$\text{Mg}+2_ \text{OHEtDiPhos-4} + \text{Mg}+2 = \text{Mg}+2(2)_ \text{OHEtDiPhos-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:3.4 (0.1SD)	6	CIU	7242
2	25	1	Unknown	lgK:2.9 (0.1SD)	6	CIU	7242

Reaction No. 73393							
$\text{Clodronic-4} + \text{Mg}+2 = \text{Mg}+2_ \text{Clodronic-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:6.20 (3SF)	6	CIU	7242

Reaction No. 73394							
$\text{Mg}+2 + \text{H}+1_ \text{Clodronic-4} = \text{Mg}+2_ \text{H}+1_ \text{Clodronic-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:3.15 (3SF)	6	CIU	7242

Reaction No. 73395							
$\text{Mg}+2_ \text{Clodronic-4} + \text{Mg}+2 = \text{Mg}+2(2)_ \text{Clodronic-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:3.0 (2SF)	6	CIU	7242

Reaction No. 73563							
$\text{Mg}+2 + \text{H}+1_ \text{Oxonic-3} = \text{Mg}+2_ \text{H}+1_ \text{Oxonic-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	Inf. Dilution	lgK:3.10 (0.08SD)	4	MPH	1853

Reaction No. 73570							
$\text{Mg}+2 + \text{H}+1(2)_ \text{Oxonic-3} = \text{Mg}+2_ \text{H}+1(2)_ \text{Oxonic-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	Inf. Dilution	lgK:2.01 (0.19SD)	4	MPH	1853

Reaction No. 73587							
$\text{Mg}+2(2)_ \text{Cl-1_OH-1(3)_H2O(4)_(s)} + 3\text{<H}+1\text{>} = 2\text{<Mg}+2\text{>} + \text{Cl-1} + 7\text{<H2O>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	lgK:26.0 (0.1SD)	5	MSL	17838

Reaction No. 73989							
--------------------	--	--	--	--	--	--	--

Mg+2 + e-1 = Mg+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-34.1(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:-2.657(4SF)	0	CRV	22551

Reaction No. 73990							
Mg+2_OH-1(2)_(s) + 2<H2O> + 4<e-1> = Mg+2_H-1(2) + 4<OH-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:-1.663(4SF)	4	CRV	22551

Reaction No. 73991							
Mg+2_H+1_NH3_PO4-3_(s) = Mg+2 + H+1_NH3_PO4-3							
Note: Query hydration. Probably refers to Struvite							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-11.60(4SF)	4	CRV	22551

Reaction No. 74414							
Mg+2 + 2<H+1(2)_PO4-3> = Mg+2_H+1(4)_PO4-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.53(0.2MD)	5	MGL	9902
2	25	3	NaClO4	lgK:0.64(0.03MD)	5	MGL	9902


Reaction No. 74415							
Mg+2 + H+1_PO4-3 + H+1(2)_PO4-3 = Mg+2_H+1(3)_PO4-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.51(0.2MD)	5	MGL	9902

Reaction No. 74416							
Mg+2 + 2<H+1(2)_PO4-3> = Mg+2_H+1_PO4-3 + H+1(3)_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.3(2SF)	1	ELC	
2	25	3	NaClO4	lgK:-3.17(0.03MD)	5	MGL	9902

Reaction No. 74417							
Mg+2 + 3<H+1(2)_PO4-3> = Mg+2_H+1(3)_PO4-3(2) + H+1(3)_PO4-3							
Note: See comment on Mg+2_H+1(2)_PO4-3 + H+1_PO4-3 = Mg+2_H+1(3)_PO4-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0	Inf. Dilution	lgK:-1.4 (2SF)	1	EOR	
2	25	3	NaClO4	lgK:-2.49 (0.02MD)	5	MGL	9902

Reaction No. 74527




Note: The species S-2 does not exist in aqueous solution See reaction: H+1 + S-2 = H+1_S-2

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.7 (2SF)	0	ELC	
2	25	0	Inf. Dilution	lgK:-14.7 (3SF)	0	CRV	22551


Note (2): p. 66

Reaction No. 74743




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:8.19 (3SF)	3	MGL	1187

Reaction No. 74744




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:3.59 (3SF)	3	MGL	1187

Reaction No. 74785




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	NaCl	lgK:0.34 (2SF)	4	MGL	21108

Reaction No. 74870



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-85.8 (3SF)	1	ELC	

Reaction No. 74874



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.76 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.736 (4SF)	5	CRV	22388

Reaction No. 74875							
$\text{Mg}^{+2} + \text{H}^{+1}(2)_{\text{Ascorbic-2}} + \text{Ascorbic-2} = \text{Mg}^{+2}_{\text{H}^{+1}(2)_{\text{Ascorbic-2}}}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.2 (3SF)	1	ELC	
2	25	1	NaClO4	lgK:3.77 (3SF)	0	MGL	22560

Reaction No. 74876							
$\text{Mg}^{+2} + \text{H}^{+1}_{\text{Ascorbic-2}} = \text{Mg}^{+2}_{\text{H}^{+1}_{\text{Ascorbic-2}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:0.98 (2SF)	5	MGL	22560
2	25	0	Inf. Dilution	lgK:1.54 (3SF)	2	EAE	

Reaction No. 74877							
$\text{Mg}^{+2} + 2\text{H}^{+1}_{\text{Ascorbic-2}} = \text{Mg}^{+2}_{\text{H}^{+1}(2)_{\text{Ascorbic-2}}}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:1.85 (3SF)	3	MGL	22560
2	25	0	Inf. Dilution	lgK:3. (1SF)	2	EES	

Reaction No. 74933							
$\text{Mg}^{+2} + \text{Histamine} = \text{Mg}^{+2}_{\text{Histamine}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.2 (2SF)	2	EES	
2	25	0.1	NaNO3	lgK:5.15 (3SF)	0	MGL	22560


Reaction No. 74934							
$\text{Mg}^{+2} + 2\text{Histamine} = \text{Mg}^{+2}_{\text{Histamine}}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:9.50 (3SF)	5	MGL	22560

Reaction No. 74986							
$\text{Mg}^{+2} + \text{H}^{+1}(2)_{\text{Malic-2}} = \text{Mg}^{+2}_{\text{H}^{+1}(2)_{\text{Malic-2}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:0.90 (2SF)	5	MGL	22560
2	25	0	Inf. Dilution	lgK:0.871 (3SF)	2	EAE	

Reaction No. 75070							
$\text{Mg}_2\text{TiO}_4(\text{s}) + 8\text{H}^{+1} + \text{e}^{-1} = 2\text{Mg}^{+2} + \text{Ti}^{+3} + 4\text{H}_2\text{O}$							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:28.2 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:21.144 (5SF)	0	CRV	32224

Reaction No. 75071



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-5.0 (2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-18.880 (5SF)	0	CRV	32224

Reaction No. 75073




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.567 (4SF)	4	CRV	32224

Reaction No. 75074




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.6 (2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-1.547 (4SF)	0	CRV	32224

Reaction No. 75163



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:819.4 (4SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-1111. (4SF)	0	EOD	13532
3	25	0	Inf. Dilution	dH:-1189. (4SF)	2	EOD	13532

Reaction No. 75196




Note: Mineral name: brandholzite

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.74 (3SF)	5	MSL	23089


Note (1): Authors also gave delta G of formation

Reaction No. 75245




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaClO4	lgK:4.56(0.02SD)	5	MGL	23134
2	25	0	Inf. Dilution	lgK:5.46(3SF)	2	EAE	

Reaction No. 75328




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:-3.764(4SF)	5	CRV	22388

Reaction No. 75353




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.0(3SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:10.7(3SF)	5	CRV	22388

Reaction No. 75357




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.26(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.266(4SF)	5	CRV	22388

Reaction No. 75358




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-5.61(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:-6.326(4SF)	5	CRV	22388

Reaction No. 75362



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.4(2SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:7.117(4SF)	5	CRV	22388


Reaction No. 75363



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.9(2SF)	1	ESC	


2	37	0.15	Blood Plasma	lgK:2.678 (4SF)	5	CRV	22388
---	----	------	--------------	-----------------	---	-----	-------

Reaction No. 75371




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:7.711 (4SF)	5	CRV	22388

Reaction No. 75372




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:3.609 (4SF)	5	CRV	22388

Reaction No. 75373




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:9.583 (4SF)	5	CRV	22388

Reaction No. 75374



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:-8.083 (4SF)	5	CRV	22388

Reaction No. 75381




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:8.338 (4SF)	5	CRV	22388

Reaction No. 75382



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:4.255 (4SF)	5	CRV	22388

Reaction No. 75383



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:10.114 (5SF)	5	CRV	22388

Reaction No. 75387

H+1_Pyridox5OPO3-3 + Mg+2 = Mg+2_H+1_Pyridox5OPO3-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:2.05 (3SF)	5	CRV	22388

Reaction No. 75388							
H+1_Pyridox5OPO3-3 + Mg+2 + H+1 = Mg+2_H+1(2)_Pyridox5OPO3-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:9.405 (4SF)	5	CRV	22388

Reaction No. 75392							
2<EtMalon-2> + Mg+2 = Mg+2_EtMalon-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:2.935 (4SF)	5	CRV	22388

Reaction No. 75553							
Br2(l) + 6<H2(g)> + Mg(s) + 3<O2(g)> = Mg+2_Br-1(2)_H2O(6)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2055.7 (5SF) kJ	2	CRV	24003
2	25	0	Inf. Dilution	dG:-2054.3 (5SF) kJ	2	EOD	29025
3	25	0	Inf. Dilution	dG:-2062.9 (5SF) kJ	3	MAC	30014
4	25	0	Inf. Dilution	dH:-2407.5 (5SF) kJ	2	EOD	29025
5	25	0	Inf. Dilution	dH:-2420.2 (5SF) kJ	3	MAC	30014


Reaction No. 75631							
Mg+2(2)_H+1(3)_SiH2O4-2(3)_H2O(4)_(s) = 2<Mg+2> + 3<H+1_SiH2O4-2> + 4<H2O >							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	50	0	Inf. Dilution	lgK:-38.8 (3SF)	0	CRV	8
Note (1): Solid +1 charge! Same problem in S&M database [95SMM_552]. Sepiolite?							

Reaction No. 75634							
0.35<Ca(s)> + 0.23<Fe(s)> + 0.42<Mg(s)> + 1.5<O2(g)> + Si(s) = Augite(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2835.3 (5SF) kJ	3	CRV	25435
2	25	0	Inf. Dilution	dH:-2888.5 (5SF) kJ	3	CRV	25435

Reaction No. 75635							
0.4<Fe(s)> + 1.6<Mg(s)> + 2<O2(g)> + Si(s) = Olivine(s)							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1919.7 (5SF) kJ	3	CRV	25435
2	25	0	Inf. Dilution	dH:-2022.9 (5SF) kJ	3	CRV	25435

Reaction No. 75824



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.46 (3SF)	2	EAE	
2	37	0.15	NaClO4	lgK:2.39 (3SF)	6	MGL	2181


Reaction No. 75857



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.7 (2SF)	1	EES	
2	25	0.01	Unknown	lgK:3.01 (3SF)	0	MGL	11516


Note (2): Maley L et al., Australian J. Sci. Res., 1949, 92, 579

Reaction No. 75881



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NC1	lgK:1.93 (3SF)	5	MGL	152
2	37	0.15	NaClO4	lgK:1.79 (3SF)	5	MGL	2181


Reaction No. 75910



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Unknown	lgK:0.57 (2SF)	5	MQH	11516


Note (1): Verbeek F et al., Anal. Chim. Acta, 1965, 33, 378

Reaction No. 76188




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.45 (3SF)	2	EAE	
2	37	0.15	NaCl	lgK:2.07 (3SF)	5	MGL	1940

Reaction No. 76428




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.03	NaCl	lgK:0.936(3SF)	5	MIS	4503

Reaction No. 76493



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	300	0	Inf. Dilution/m	lgK:1.45(3SF)	0	MCL	12628
2	300	0	Inf. Dilution/m	dH:246.(3SF)kJ	0	MCL	12628

Reaction No. 76524




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.517(4SF)	0	MSL	14335
2	25	0	Inf. Dilution	lgK:3.61(3SF)	2	EOD	24835

Note (2): Taken from Altmaier et al., THEREDA database, 2011

3	25	0	Inf. Dilution	lgK:4.06(3SF)	2	CRV	26565
---	----	---	---------------	---------------	---	-----	-------

Note (3): Authors state this value should replace their earlier one

Reaction No. 76525




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-4.70(3SF)	3	EOD	24835

Note (1): Taken from Altmaier et al., THEREDA database, 2011

2	25	0	Inf. Dilution	lgK:-4.26(3SF)	3	CRV	26565
---	----	---	---------------	----------------	---	-----	-------


Note (2): Authors state this value should replace their earlier one

Reaction No. 76532



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.212(4SF)	5	MSL	14335

Reaction No. 76533



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.542(4SF)	5	MSL	14335
2	75	0	Inf. Dilution	lgK:6.927(4SF)	3	MSL	27463

Reaction No. 76535							
$\text{Mg}+2_{\text{Rb}+1_{\text{Br}-1(3)}_{\text{H}_2\text{O}(6)}_{\text{(s)}}} = \text{Rb}+1 + \text{Mg}+2 + 3\langle\text{Br}-1\rangle + 6\langle\text{H}_2\text{O}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.612(4SF)	5	MSL	14335

Reaction No. 76537							
$\text{Mg}+2_{\text{Cs}+1_{\text{Br}-1(3)}_{\text{H}_2\text{O}(6)}_{\text{(s)}}} = \text{Cs}+1 + \text{Mg}+2 + 3\langle\text{Br}-1\rangle + 6\langle\text{H}_2\text{O}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.498(4SF)	5	MSL	14335

Reaction No. 76570							
$\text{MgO(s)} + \text{H}_2\text{O} = \text{Mg}+2 + 2\langle\text{OH}-1\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-7.63(3SF)	0	CRV	
Note (1): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							


Reaction No. 76659							
$4\langle\text{H}_2(\text{g})\rangle + \text{Mg(s)} + 2\langle\text{Na(s)}\rangle + 6\langle\text{O}_2(\text{g})\rangle + 2\langle\text{S(s)}\rangle = \text{Mg}+2_{\text{Na}+1(2)}_{\text{SO}_4-2(2)}_{\text{H}_2\text{O}(4)}_{\text{(s)}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	dG:-3429.9(5SF) kJ	4	EPZ	8833

Reaction No. 76660							
$1.5\langle\text{Cl}_2(\text{g})\rangle + 6\langle\text{H}_2(\text{g})\rangle + \text{K(s)} + \text{Mg(s)} + 3\langle\text{O}_2(\text{g})\rangle = \text{Mg}+2_{\text{K}+1_{\text{Cl}-1(3)}_{\text{H}_2\text{O}(6)}_{\text{(s)}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2529.6(5SF) kJ	3	EPZ	14335
2	25	0	Inf. Dilution/m	dG:-2529.3(5SF) kJ	4	EPZ	8833
3	25	0	Inf. Dilution/m	dG:-2529.3(5SF) kJ	3	EPZ	9073

Reaction No. 76661							
$7\langle\text{H}_2(\text{g})\rangle + \text{Mg(s)} + 5.5\langle\text{O}_2(\text{g})\rangle + \text{S(s)} = \text{Mg}+2_{\text{SO}_4-2_{\text{H}_2\text{O}(7)}_{\text{(s)}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2870.2(5SF) kJ	2	EOD	29025
2	25	0	Inf. Dilution	dG:-2869.0(5SF) kJ	5	MSL	29947
3	25	0	Inf. Dilution	dG:-2870.4(5SF) kJ	3	MAC	30014
4	25	0	Inf. Dilution/m	dG:-2870.2(5SF) kJ	3	EPZ	8833
5	25	0	Inf. Dilution/m	dG:-2870.2(5SF) kJ	3	EPZ	9073
6	25	0	Inf. Dilution	dH:-3388.7(5SF) kJ	2	EOD	29025


7	25	0	Inf. Dilution	dH:-3390.5 (5SF) kJ	5	MSL	29947
8	25	0	Inf. Dilution	dH:-3391.8 (5SF) kJ	3	MAC	30014
9	25	0	Inf. Dilution	Cp:390.0 (4SF) J/K	2	EOD	29025

Reaction No. 76664




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2631.7 (5SF) kJ	2	EOD	29025
2	25	0	Inf. Dilution	dG:-2630.3 (5SF) kJ	5	MSL	29947
3	25	0	Inf. Dilution	dG:-2632.2 (5SF) kJ	3	MAC	30014
4	25	0	Inf. Dilution/m	dG:-2631.70 (6SF) kJ	3	EPZ	8833
5	25	0	Inf. Dilution/m	dG:-2631.7 (5SF) kJ	3	EPZ	9073
6	25	0	Inf. Dilution	dH:-3087.0 (5SF) kJ	2	EOD	29025
7	25	0	Inf. Dilution	dH:-3087.4 (5SF) kJ	5	MSL	29947
8	25	0	Inf. Dilution	dH:-3097.5 (5SF) kJ	1	MAC	30014
9	25	0	Inf. Dilution	Cp:348.1 (4SF) J/K	2	EOD	29025

Reaction No. 76665



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	dG:-2325.8 (5SF) kJ	4	EPZ	8833
2	25	0	Inf. Dilution/m	dG:-2325.8 (5SF) kJ	3	EPZ	9073

Reaction No. 76666



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:250.3 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:251.0 (4SF)	0	ERG	
3	25	0	Inf. Dilution	dG:-1437.3 (5SF) kJ	0	EOD	29025
4	25	0	Inf. Dilution	dG:-1435.6 (5SF) kJ	0	MSL	29947
5	25	0	Inf. Dilution	dG:-1433.6 (5SF) kJ	0	MAC	30014
6	25	0	Inf. Dilution/m	dG:-1437.3 (5SF) kJ	0	EPZ	8833
7	25	0	Inf. Dilution/m	dG:-1437.3 (5SF) kJ	0	EPZ	9073
8	25	0	Inf. Dilution	dH:-1602.1 (5SF) kJ	1	EOD	29025
9	25	0	Inf. Dilution	dH:-1614.0 (5SF) kJ	2	MSL	29947
10	25	0	Inf. Dilution	dH:-1602.5 (5SF) kJ	1	MAC	30014


11	25	0	Inf. Dilution	Cp:138.4 (4SF) J/K	2	EOD	29025
----	----	---	---------------	--------------------	---	-----	-------

Reaction No. 76668




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2174.6 (5SF) kJ	0	EOD	29025
2	25	0	Inf. Dilution	dG:-2151.7 (5SF) kJ	3	MSL	29947
3	25	0	Inf. Dilution/m	dG:-2153.1 (5SF) kJ	0	EPZ	8833
4	25	0	Inf. Dilution	dH:-2496.6 (5SF) kJ	1	EOD	29025
5	25	0	Inf. Dilution	dH:-2498.0 (5SF) kJ	3	MSL	29947
6	25	0	Inf. Dilution	Cp:264.2 (4SF) J/K	4	EOD	29025

Reaction No. 76669




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	dG:-3480.4 (5SF) kJ	4	EPZ	8833
2	25	0	Inf. Dilution/m	dG:-3480.4 (5SF) kJ	3	EPZ	9073

Reaction No. 76670




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2390.9 (5SF) kJ	5	MSL	29947
2	25	0	Inf. Dilution/m	dG:-2392.5 (5SF) kJ	4	EPZ	8833
3	25	0	Inf. Dilution	dH:-2790.9 (5SF) kJ	5	MSL	29947

Reaction No. 76671



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	dG:-5659.0 (5SF) kJ	4	EPZ	8833
2	25	0	Inf. Dilution/m	dG:-5658.2 (5SF) kJ	3	EPZ	9073

Reaction No. 76672



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	dG:-3956.7 (5SF) kJ	4	EPZ	8833
2	25	0	Inf. Dilution/m	dG:-3956.7 (5SF) kJ	3	EPZ	9073

Reaction No. 76674							
$\text{Ca(s)} + 3\text{Cl}_2(\text{g}) + 12\text{H}_2(\text{g}) + 2\text{Mg(s)} + 6\text{O}_2(\text{g}) = \text{Ca}_2\text{Mg}_2(2)\text{Cl}_2(6)\text{H}_2\text{O}(12)\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	dG:-4997.3 (5SF) kJ	4	EPZ	8833
2	25	0	Inf. Dilution/m	dG:-4997.3 (5SF) kJ	3	EPZ	9073

Reaction No. 76678							
$0.5\text{Cl}_2(\text{g}) + 5.5\text{H}_2(\text{g}) + 2\text{Mg(s)} + 3.5\text{O}_2(\text{g}) = \text{Mg}_2(2)\text{Cl}_2(1)\text{OH}(1)\text{H}_2\text{O}(4)\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution/m	dG:-2552.3 (5SF) kJ	3	EPZ	9073

Reaction No. 76815							
$\text{UO}_2 + 2\text{Mg} + 3\text{CO}_3 = \text{Mg}_2\text{UO}_2 + 2\text{CO}_3(3)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.02 (0.08SD)	0	EOD	27392
2	25	0	Inf. Dilution	lgK:25.8 (0.5SD)	2	EOD	27392
3	25	0	Inf. Dilution	lgK:26.24 (0.13SD)	2	EOD	27392
4	25	0	Inf. Dilution	lgK:26.11 (0.04SD)	3	EOD	27392
5	25	0	Inf. Dilution	lgK:26.11 (4SF)	2	EOD	29484
6	25	0	Inf. Dilution	lgK:26.24 (4SF)	2	EOD	29484
7	25	0	Inf. Dilution	lgK:25.8 (0.3SD)	4	MMX	30627
8	25	0	Inf. Dilution	lgK:26.13 (4SF)	4	CRV	31231

Reaction No. 76925							
$\text{N}_3\text{Carb}_2\text{OH}_5\text{SulfBenzIDA-4} + \text{Mg}_2 = \text{Mg}_2\text{N}_3\text{Carb}_2\text{OH}_5\text{SulfBenzIDA-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:8.2 (2SF)	3	CRV	7271

Reaction No. 76937							
$\text{SemiXylenolOrange-4} + \text{Mg}_2 = \text{Mg}_2\text{SemiXylenolOrange-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:6.89 (3SF)	3	CRV	7271

Reaction No. 76938							
$\text{Mg}_2\text{SemiXylenolOrange-4} + \text{H}_2 = \text{Mg}_2\text{H}_2\text{SemiXylenolOrange-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:6.92 (3SF)	3	CRV	7271

Reaction No. 76939							
$\text{Mg+2_SemiXylenolOrange-4} + \text{OH-1} = \text{Mg+2_OH-1_SemiXylenolOrange-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:2.43 (3SF)	3	CRV	7271

Reaction No. 76967							
$\text{SemiMethylThymolBlue-4} + \text{Mg+2} = \text{Mg+2_SemiMethylThymolBlue-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:7.05 (3SF)	3	CRV	7271

Reaction No. 76968							
$\text{Mg+2_SemiMethylThymolBlue-4} + \text{H+1} = \text{Mg+2_H+1_SemiMethylThymolBlue-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:7.55 (3SF)	3	CRV	7271

Reaction No. 76969							
$\text{Mg+2_SemiMethylThymolBlue-4} + \text{OH-1} = \text{Mg+2_OH-1_SemiMethylThymolBlue-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:2.35 (3SF)	3	CRV	7271

Reaction No. 77389							
$1.5\langle\text{Br}_2(1)\rangle + 6\langle\text{H}_2(\text{g})\rangle + \text{K}(\text{s}) + \text{Mg}(\text{s}) + 3\langle\text{O}_2(\text{g})\rangle = \text{Mg+2_K+1_Br-1(3)_H}_2\text{O(6)_(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2441.50 (6SF) kJ	3	EPZ	14335

Reaction No. 77390							
$1.5\langle\text{Cl}_2(\text{g})\rangle + 6\langle\text{H}_2(\text{g})\rangle + \text{Mg}(\text{s}) + 3\langle\text{O}_2(\text{g})\rangle + \text{Rb}(\text{s}) = \text{Mg+2_Rb+1_Cl-1(3)_H}_2\text{O(6)_(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2538.2 (5SF) kJ	3	EPZ	14335

Reaction No. 77391							
$1.5\langle\text{Br}_2(1)\rangle + 6\langle\text{H}_2(\text{g})\rangle + \text{Mg}(\text{s}) + 3\langle\text{O}_2(\text{g})\rangle + \text{Rb}(\text{s}) = \text{Mg+2_Rb+1_Br-1(3)_H}_2\text{O(6)_(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2447.9 (5SF) kJ	3	EPZ	14335

Reaction No. 77392							
$1.5\langle\text{Br}_2(1)\rangle + \text{Cs}(\text{s}) + 6\langle\text{H}_2(\text{g})\rangle + \text{Mg}(\text{s}) + 3\langle\text{O}_2(\text{g})\rangle = \text{Mg+2_Cs+1_Br-1(3)_H}_2\text{O(6)_(s)}$							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2450.7 (5SF) kJ	3	EPZ	14335

Reaction No. 77393




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2537.8 (5SF) kJ	3	EPZ	14335

Reaction No. 77394




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2327.4 (5SF) kJ	3	EPZ	14335

Reaction No. 77395




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2239.0 (5SF) kJ	3	EPZ	14335

Reaction No. 77421




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1. (1SF)	1	EAC	

Reaction No. 77535




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.88 (4SF)	1	ELC	

Reaction No. 77631



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.05931 (4SF)	1	ELC	

Reaction No. 77668



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.14 (4SF)	1	ELC	

Reaction No. 78186							
$3\text{<Oxalic-2>} + \text{Mg+2} + \text{Co+3} = \text{Co+3_Mg+2_Oxalic-2(3)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-8.916(4SF)	1	ELC	

Reaction No. 78204							
$\text{As(s)} + \text{H}_2(\text{g}) + \text{Mg(s)} + 2\text{<O}_2(\text{g}) - \text{e-1} = \text{Mg+2_H+1(2)_AsO4-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1217.20(6SF)kJ	5	CRV	29482
2	25	0	Inf. Dilution	dH:-1392.10(6SF)kJ	5	CRV	29482

Reaction No. 78437							
$\text{Mg+2} + 2\text{<H+1>} + 2\text{<CO}_3\text{-2>} = \text{Mg+2_H+1(2)_CO}_3\text{-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.53(4SF)	1	ELC	

Reaction No. 78600							
$2\text{<SO}_4\text{-2>} + \text{Mg+2} = \text{Mg+2_SO}_4\text{-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.521(4SF)	1	ELC	

Reaction No. 78661							
$\text{Mg+2} + 2\text{<CO}_3\text{-2>} = \text{Mg+2_CO}_3\text{-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.893(4SF)	1	ELC	

Reaction No. 78662							
$\text{Na+1} + 0.5\text{<Mg+2>} + \text{CO}_3\text{-2} = \text{Mg+2(0.5)_Na+1_CO}_3\text{-2(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.982(4SF)	1	ELC	

Reaction No. 78663							
$0.75\text{<Mg+2>} + \text{CO}_3\text{-2} + 0.25\text{<Ca+2>} = \text{Ca+2(0.25)_Mg+2(0.75)_CO}_3\text{-2(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.102(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:7.63(3SF)	4	CRV	32224

Reaction No. 78993							
OH-1 + Mg+2 + Cl-1 = Mg+2_Cl-1_OH-1_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.073(4SF)	1	ELC	

Reaction No. 79052							
3<SO4-2> + 2<Mg+2> + 2<K+1> = Mg+2(2)_K+1(2)_SO4-2(3)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.7(2SF)	1	ELC	

Reaction No. 79196							
Mg+2 + CO3-2 = Mg+2_CO3-2_(syn.,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.428(4SF)	1	ELC	

Reaction No. 79287							
Ankerite(s) = 1.17<Ca+2> + 0.68<Mg+2> + 0.13<Fe+2> + 0.02<Mn+2> + 2<CO3-2>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-17.09(4SF)	3	EOD	29419

Reaction No. 79360							
2<PO4-3> + Mg+2 + 4<H+1> = Mg+2_H+1(4)_PO4-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:40.57(4SF)	1	ELC	

Reaction No. 79408							
Mg+2 + SO4-2 + 4<H2O> = Mg+2_SO4-2_H2O(4)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.7(1SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:1.4(2SF)	1	MTD	
3	75	0	Inf. Dilution	lgK:0.7153(4SF)	4	CRV	31793
4	80	0	Inf. Dilution	lgK:0.6003(4SF)	4	CRV	31793
5	85	0	Inf. Dilution	lgK:0.4943(4SF)	4	CRV	31793
6	90	0	Inf. Dilution	lgK:0.3978(4SF)	4	CRV	31793
7	100	0	Inf. Dilution	lgK:0.2332(4SF)	4	CRV	31793

Reaction No. 79409							
--------------------	--	--	--	--	--	--	--

SO4-2 + Mg+2 + 5<H2O> = Mg+2_SO4-2_H2O(5)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.7678(4SF)	1	ELC	

Reaction No. 79472							
5<Mg+2_OH-1(2)_(s)> + 4<CO3-2> + 8<H+1> = Mg+2(5)_OH-1(2)_CO3-2(4)_H2O(4)_(s) + 4<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:95.5(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:96.81(1.33SD)	3	EOD	
Note (2): Xiong Y, GCA, 2016. doi: http://dx.doi.org/10.1016/j.gca.2016.04.013							

Reaction No. 79473							
5<Mg+2_OH-1(2)_(s)> + 4<CO2(g)> = Mg+2(5)_OH-1(2)_CO3-2(4)_H2O(4)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.17(1.33SD)	5	EOD	
Note (1): Xiong Y, GCA, 2016. doi: http://dx.doi.org/10.1016/j.gca.2016.04.013							

Reaction No. 79474							
Mg+2(5)_OH-1(2)_CO3-2(4)_H2O(4)_(s) = 4<CO3-2> + 5<Mg+2> + 2<OH-1> + 4<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-37.8(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-37.08(4SF)	0	MSL	26477
Note (2): Criticism in Xiong Y, Geochim. Cosmochim. Acta, 2016, in press							
3	25	0	Inf. Dilution	lgK:-39.55(1.33SD)	3	EOD	29527
Note (3): Xiong Y, GCA, 2016. doi: http://dx.doi.org/10.1016/j.gca.2016.04.013							

Reaction No. 79475							
Mg+2(5)_OH-1(2)_CO3-2(4)_H2O(4)_(s) + 10<H+1> = 5<Mg+2> + 4<CO2(g)> + 10<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:62.5(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:59.07(0.72SD)	0	MSL	27205
Note (2): Other forms of hydromagnesite yield lgK0 = 57.93:61.04							
3	25	0	Inf. Dilution	lgK:61.08(1.33SD)	2	EOD	29527
Note (3): Xiong Y, GCA, 2016. doi: http://dx.doi.org/10.1016/j.gca.2016.04.013							

Reaction No. 79495							
--------------------	--	--	--	--	--	--	--

8<Fe(s)> + 23.5<H2(g)> + Mg(s) + 24<O2(g)> + 6<P(s)> = Fe+3_Fe+2(7)_Mg+2_OH-1_PO4-3(6)_H2O(23)_ (s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1.3317E+4 (57.SD) kJ	5	MCL	29465
2	25	0	Inf. Dilution	dH:1.5357E+4 (57.SD) kJ	5	MCL	29465

Reaction No. 79551							
2<H2(g)> + Mg(s) + 3<O2(g)> + S(s) = Mg+2_SO4-2_H2O(2)_ (s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1672.6 (5SF) kJ	3	EOD	29025
2	25	0	Inf. Dilution	dH:-1896.2 (5SF) kJ	3	EOD	29025
3	25	0	Inf. Dilution	Cp:180.4 (4SF) J/K	3	EOD	29025

Reaction No. 79572							
Mg+2 + H+1(2)_EDTA-4 = Mg+2_EDTA-4 + 2<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-7.19 (3SF)	1	ELC	
2	25	0	Inf. Dilution	dH:56.3 (3SF) kJ	1	ELC	

Reaction No. 79621							
H+1_CO3-2 + Mg+2 = Mg+2_CO3-2 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-7.2 (2SF)	1	EES	

Reaction No. 79626							
H+1_CO3-2 + Mg+2 + 3<H2O> = Mg+2_CO3-2_H2O(3)_ (s) + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-5.4 (2SF)	1	EES	

Reaction No. 79630							
Mg+2_CO3-2_H2O(5)_ (s) + H+1 = Mg+2 + H+1_CO3-2 + 5<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.0 (2SF)	1	EES	

Reaction No. 79655							
Ca+2_Mg+2_CO3-2(2)_ (ord.,s) + 2<H+1> = Ca+2 + Mg+2 + 2<H+1_CO3-2>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.5 (2SF)	1	ELC	

Reaction No. 79657							
$\text{Ca}+2_ \text{Mg}+2_ \text{CO3-2(2)}_ (\text{disord.}, \text{s}) + 2\text{<H+1>} = \text{Ca}+2 + \text{Mg}+2 + 2\text{<H+1_CO3-2>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.1 (2SF)	1	ELC	

Reaction No. 79678							
$\text{Mg}+2 + \text{H}+1_ \text{Cis-2} = \text{Mg}+2_ \text{H}+1_ \text{Cis-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:1.93 (0.05SD)	4	MGL	29298
2	25	1	NaCl	lgK:1.48 (0.03SD)	4	MGL	29298

Reaction No. 79681							
$\text{H}+1 + 2\text{MeNTA-3} + \text{Mg}+2 = \text{Mg}+2_ \text{H}+1_ 2\text{MeNTA-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	NaCl	lgK:2.09 (0.08SD)	3	MGL	29125
2	25	0.15	NaCl	lgK:1.83 (0.07SD)	3	MGL	29125
3	25	0.5	NaCl	lgK:1.60 (0.05SD)	3	MGL	29125
4	25	1	NaCl	lgK:1.61 (0.07SD)	3	MGL	29125


Reaction No. 79682							
$2\text{MeNTA-3} + 2\text{<Mg}+2> = \text{Mg}+2(2)_ 2\text{MeNTA-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	NaCl	lgK:2.13 (0.12SD)	2	MGL	29125
2	25	0.15	NaCl	lgK:1.86 (0.11SD)	3	MGL	29125
3	25	0.5	NaCl	lgK:1.81 (0.10SD)	3	MGL	29125
4	25	1	NaCl	lgK:1.72 (0.20SD)	3	MGL	29125

Reaction No. 79697							
$\text{Mg}+2_ \text{H}+1_ \text{DTPA-5} + \text{H}+1 = \text{Mg}+2_ \text{H}+1(2)_ \text{DTPA-5}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.9 (2SF)	1	EES	
2	37	0.15	NaCl	lgK:4.68 (3SF)	3	CRV	13242

Reaction No. 79698							
$\text{Mg}+2_ \text{H}+1(2)_ \text{DTPA-5} + \text{H}+1 = \text{Mg}+2_ \text{H}+1(3)_ \text{DTPA-5}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:3.9(2SF)	1	EES	
2	37	0.15	NaCl	lgK:3.74(0.05SD)	5	CRV	13242

Reaction No. 79699




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.1(2SF)	1	EES	
2	37	0.15	NaCl	lgK:2.07(3SF)	5	CRV	13242

Reaction No. 79753




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1182.60(6SF) kJ	5	CRV	29482
2	25	0	Inf. Dilution	dH:-1365.90(6SF) kJ	5	CRV	29482

Reaction No. 79765




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1135.90(6SF) kJ	5	CRV	29482
2	25	0	Inf. Dilution	dH:-1285.80(6SF) kJ	5	CRV	29482

Reaction No. 79778




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1051.90(6SF) kJ	5	CRV	29482
2	25	0	Inf. Dilution	dH:-1197.40(6SF) kJ	5	CRV	29482

Reaction No. 79804



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.041(4SF)	4	EOD	29487
2	90	0	Inf. Dilution	lgK:0.60(2SF)	4	EOD	29487
3	25	0	Inf. Dilution	dH:-45.819(5SF) kJ	4	EOD	29487

Reaction No. 79873



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0	Inf. Dilution	lgK:-10.9(3SF)	2	ERS	5606
---	----	---	---------------	----------------	---	-----	------

Reaction No. 80000							
$\text{Mg}+2_{\text{H}+1_{\text{NH}_3}\text{PO}_4-3_{\text{H}_2\text{O}}(\text{s})} = \text{Mg}+2 + \text{H}+1_{\text{NH}_3} + \text{PO}_4-3 + \text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-13.1(3SF)	1	EES	
2	55	0	Inf. Dilution	lgK:-13.84(4SF)	1	EDH	29566
Note (2): Assuming this value refers to the monohydrate							
3	60	0	Inf. Dilution	lgK:-14.01(4SF)	0	EDH	29566
Note (3): Assuming this value refers to the monohydrate							

Reaction No. 80034							
$2<\text{F}-1> + \text{Mg}+2 = \text{Mg}+2_{\text{F}-1(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.2(2SF)	0	MSL	12941
Note (1): Suspect investigation; $\text{Ca}+2_{\text{F}-1(2)}$ value rejected							


Reaction No. 80059							
$\text{Mg}+2 + \text{Mg}+2_{\text{DTPMP}-9} = \text{Mg}+2(2)_{\text{DTPMP}-9}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.78(3SF)	2	EDH	29755
2	25	0.127	NaCl	lgK:3.81(0.15SD)	4	MGL	29755
3	25	0.319	NaCl	lgK:3.15(0.13SD)	4	MGL	29755
4	25	0.958	NaCl	lgK:3.48(0.21SD)	4	MGL	29755

Reaction No. 80060							
$\text{Mg}+2 + \text{Mg}+2_{\text{H}+1(2)_{\text{DTPMP}-9}} = \text{Mg}+2(2)_{\text{H}+1(2)_{\text{DTPMP}-9}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.00(3SF)	2	EDH	29755
2	25	0.127	NaCl	lgK:2.87(0.21SD)	4	MGL	29755
3	25	0.319	NaCl	lgK:2.34(0.21SD)	4	MGL	29755
4	25	0.958	NaCl	lgK:2.68(0.25SD)	4	MGL	29755

Reaction No. 80064							
$\text{Cl}_2(\text{g}) + 8<\text{H}_2(\text{g})> + \text{Mg}(\text{s}) + 4<\text{O}_2(\text{g})> = \text{Mg}+2_{\text{Cl}-1(2)_{\text{H}_2\text{O}(8)}(\text{s})}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2595.8(5SF)kJ	3	MAC	30014


2	25	0	Inf. Dilution	dH:-3090.3 (5SF) kJ	3	MAC	30014
---	----	---	---------------	---------------------	---	-----	-------

Reaction No. 80065




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-3547.4 (5SF) kJ	3	MAC	30014
2	25	0	Inf. Dilution	dH:-4257.4 (5SF) kJ	3	MAC	30014

Reaction No. 80066




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2778.5 (5SF) kJ	3	MAC	30014
2	25	0	Inf. Dilution	dH:-3294.0 (5SF) kJ	3	MAC	30014

Reaction No. 80067




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-3017.0 (5SF) kJ	3	MAC	30014
2	25	0	Inf. Dilution	dH:-3579.3 (5SF) kJ	3	MAC	30014

Reaction No. 80068




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-4056.2 (5SF) kJ	3	MAC	30014
2	25	0	Inf. Dilution	dH:-4829.8 (5SF) kJ	3	MAC	30014

Reaction No. 80069



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1113.7 (5SF) kJ	3	MAC	30014
2	25	0	Inf. Dilution	dH:-1482.8 (5SF) kJ	3	MAC	30014

Reaction No. 80070



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2797.1 (5SF) kJ	3	MAC	30014
2	25	0	Inf. Dilution	dH:-3474.0 (5SF) kJ	3	MAC	30014

Reaction No. 80236							
$11\text{H}_2(\text{g}) + \text{Mg}(\text{s}) + 7.5\text{O}_2(\text{g}) + \text{S}(\text{s}) = \text{Mg}_2\text{SO}_4\cdot 2\text{H}_2\text{O}(\text{l})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-3815.3 (5SF) kJ	5	MSL	29947
2	25	0	Inf. Dilution	dH:-4565.8 (5SF) kJ	5	MSL	29947

Reaction No. 80238							
$\text{AsO}_4\cdot 3 + \text{Mg}_2 = \text{Mg}_2\text{AsO}_4\cdot 3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.95 (0.02SD)	5	MPH	29969
2	25	0	Inf. Dilution	lgK:6.41 (0.03SD)	3	EDH	29940
3	25	0.1	NaCl	lgK:5.21 (0.01SD)	5	MGL	29940
4	25	0.25	NaCl	lgK:4.86 (0.02SD)	5	MGL	29940
5	25	0.5	NaCl	lgK:4.66 (0.03SD)	5	MGL	29940
6	25	1	NaCl	lgK:4.97 (0.045SD)	5	MGL	29940
7	25	0.7	NaCl	dH:-2. (1.SD) kJ	4	MCL	29940

Reaction No. 80239							
$\text{H} + \text{AsO}_4\cdot 3 + \text{Mg}_2 = \text{Mg}_2\text{HAsO}_4\cdot 3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:12.86 (4SF)	3	MPH	29969
2	25	0	Inf. Dilution	lgK:14.44 (0.025SD)	3	EDH	29940
3	25	0.1	NaCl	lgK:13.15 (0.01SD)	5	MGL	29940
4	25	0.25	NaCl	lgK:12.93 (0.03SD)	5	MGL	29940
5	25	0.5	NaCl	lgK:12.90 (0.06SD)	4	MGL	29940
6	25	1	NaCl	lgK:13.74 (0.02SD)	5	MGL	29940
7	25	0.7	NaCl	dH:-33. (1.SD) kJ	4	MCL	29940

Reaction No. 80240							
$2\text{H} + \text{AsO}_4\cdot 3 + \text{Mg}_2 = \text{Mg}_2\text{H}_2\text{AsO}_4\cdot 3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.40 (0.01SD)	3	EDH	29940
2	25	0.1	NaCl	lgK:19.15 (0.02SD)	5	MGL	29940
3	25	0.25	NaCl	lgK:18.95 (0.02SD)	5	MGL	29940
4	25	0.5	NaCl	lgK:19.05 (0.035SD)	5	MGL	29940
5	25	1	NaCl	lgK:19.92 (0.02SD)	5	MGL	29940
6	25	0.7	NaCl	dH:-38. (1.5SD) kJ	4	MCL	29940

Reaction No. 80335							
$\text{Mg}+2 + \text{UO}_2+2_ \text{CO}_3-2(3) = \text{Mg}+2_ \text{UO}_2+2_ \text{CO}_3-2(3)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.9(0.03SD)	5	MMX	30627

Reaction No. 80336							
$2<\text{Mg}+2> + \text{UO}_2+2_ \text{CO}_3-2(3) = \text{Mg}+2(2)_ \text{UO}_2+2_ \text{CO}_3-2(3)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.4(0.03SD)	0	MMX	30627

Reaction No. 80337							
$2<\text{Mg}+2> + \text{UO}_2+2 + 3<\text{CO}_3-2> = \text{Mg}+2(2)_ \text{UO}_2+2_ \text{CO}_3-2(3)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:27.1(0.6SD)	5	MMX	30627

Reaction No. 80655							
$\text{Mg}+2_ \text{ClO}_4-1(2)_ (\text{s}) = \text{Mg}+2 + 2<\text{ClO}_4-1>$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-36.6(0.1SD)	2	MCL	31303


Reaction No. 80701							
$\text{Glp}-1 + \text{Mg}+2 = \text{Mg}+2_ \text{Glp}-1$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.95(2SF)	1	ESC	
2	37	0.15	NaCl	lgK:0.84(0.09SD)	3	MGL	28777
3	37	0.15	NaCl	lgK:0.85(0.12SD)	3	MIS	28777

Reaction No. 80702							
$\text{H}+1 + \text{Glp}-1 + \text{Mg}+2 = \text{Mg}+2_ \text{H}+1_ \text{Glp}-1$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-9.5(2SF)	1	ESC	
2	37	0.15	NaCl	lgK:-9.79(0.17SD)	3	MGL	28777

Reaction No. 80705							
$\text{Pyridoxine}-1 + \text{Mg}+2 = \text{Mg}+2_ \text{Pyridoxine}-1$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.8(2SF)	1	ESC	


2	37	0.15	NaCl	lgK:1.44 (0.22SD)	2	MGL	28777
3	37	0.15	NaCl	lgK:1.81 (0.37SD)	2	MIS	28777

Reaction No. 80707




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-9.0 (2SF)	1	ESC	
2	37	0.15	NaCl	lgK:-9.46 (0.03SD)	4	MGL	28777

Reaction No. 80708




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.7 (2SF)	1	ESC	
2	37	0.15	NaCl	lgK:9.29 (0.26SD)	2	MGL	28777
3	37	0.15	NaCl	lgK:9.91 (0.23SD)	1	MIS	28777

Reaction No. 80709



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:31.0 (3SF)	1	ESC	
2	37	0.15	NaCl	lgK:30.69 (0.23SD)	2	MIS	28777

Reaction No. 80812




Note: Mineral name: bystroemite

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1053	HNO3	lgK:-9.44 (0.10SD)	4	MSL	30052


Note (1): Authors also give deltaG of formation

Reaction No. 80842




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.0 (1SF)	1	EES	
2	37	0	Inf. Dilution	lgK:0.0043 (2SF)	2	CRV	28703

Reaction No. 80845




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.(1SF)	1	EES	
2	37	0	Inf. Dilution	lgK:1.(1SF)	1	CRV	28703

Reaction No. 80867



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.82(3SF)	5	CRV	31748


Reaction No. 80869



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-113.75(5SF)	5	MSL	31749
2	37	0	Inf. Dilution	lgK:-106.34(5SF)	2	EOD	31749


Note (2): Indicative only

Reaction No. 80878




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.311(4SF)	7	MSL	31759

Reaction No. 80879




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-9724.7(5SF)kJ	5	MSL	31759

Reaction No. 80943



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:3.28(0.008SD)	5	MGL	32051

Reaction No. 80944



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:7.97(0.01SD)	5	MGL	32051

Reaction No. 80945

2<H+1> + HydroxyCitric-3 + Mg+2 = Mg+2_H+1(2)_HydroxyCitric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:11.55(0.01SD)	5	MGL	32051

Reaction No. 80963							
Mg+2_SO4-2_H2O(11)_(s) = Mg+2 + SO4-2 + 11<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:-2.158(4SF)	3	CRV	31793
2	25	0	Inf. Dilution	lgK:-1.8(2SF)	1	CRV	

Reaction No. 80995							
Mg+2 + H+1_Se-2 = Mg+2_Se-2_(s) + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-21.41(7.48SD)	3	EOD	32222
2	25	0	Inf. Dilution	dH:158.220(41.844SD)kJ	3	EOD	32222

Reaction No. 81012							
Mg+2 + SeO3-2 = Mg+2_SeO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.87(3SF)	3	EOD	32222

Reaction No. 81355							
Ca+2_Mg+2_UO2+2_CO3-2(3)_H2O(12)_(s) = Ca+2 + Mg+2 + UO2+2 + 3<CO3-2> + 12<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-37.7(3SF)	3	EES	

Reaction No. 81356							
Ca+2_Mg+2_UO2+2_CO3-2(3)_H2O(12)_(s) + 4<H+1> + 2<e-1> = Ca+2 + Mg+2 + U+4 + 3<CO3-2> + 14 <H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-28.66(4SF)	1	CRV	32224
Note (1): not best form of rxn							

Reaction No. 81455							
KMg3AlSi3O10(OH)2(s) + 10<H+1> = K+1 + 3<Mg+2> + Al+3 + 3<H+1(2)_SiH2O4-2>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:38.17(4SF)	4	CRV	32224

Reaction No. 81459							
$\text{Mg}^{+2}_{\text{S}-2}(\text{s}) + 4\text{H}_2\text{O} = \text{Mg}^{+2} + \text{SO}_4^{2-} + 8\text{H}^{+1} + 8\text{e}^{-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: -15.94 (4\text{SF})$	4	CRV	32224

Reaction No. 81460							
$\text{Mg}^{+2}_{\text{MoO}_4-2}(\text{s}) = \text{Mg}^{+2} + \text{MoO}_4^{2-}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: -0.87 (2\text{SF})$	4	CRV	32224

Reaction No. 81461							
$\text{Mg}^{+2}_{(4)\text{OH}-1(2)\text{CO}_3-2(3)\text{H}_2\text{O}(3)}(\text{s}) + 2\text{H}^{+1} = 4\text{Mg}^{+2} + 3\text{CO}_3^{2-} + 5\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: -2.64 (3\text{SF})$	4	CRV	32224

Reaction No. 81462							
$\text{Mg}^{+2}_{\text{VO}_3-1(2)}(\text{s}) + 2\text{H}_2\text{O} = \text{Mg}^{+2} + 2\text{VO}_4^{3-} + 4\text{H}^{+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: -47.6 (3\text{SF})$	1	ELC	
2	25	0	Inf. Dilution	$\lg K: -45.66 (4\text{SF})$	0	CRV	32224

Reaction No. 81463							
$\text{Mg}^{+2}_{(2)\text{V}_2\text{O}_7-4}(\text{s}) + \text{H}_2\text{O} = 2\text{Mg}^{+2} + 2\text{VO}_4^{3-} + 2\text{H}^{+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: -32.6 (3\text{SF})$	1	ELC	
2	25	0	Inf. Dilution	$\lg K: -30.59 (4\text{SF})$	0	CRV	32224

Reaction No. 81464							
$\text{MgH}_2(\text{s}) = \text{Mg}^{+2} + 2\text{H}^{+1} + 4\text{e}^{-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 73.39 (4\text{SF})$	4	CRV	32224

Reaction No. 81465							
$\text{MgO} \cdot \text{Cr}_2\text{O}_3(\text{s}) + 4\text{H}_2\text{O} = \text{Mg}^{+2} + 2\text{CrO}_4^{2-} + 8\text{H}^{+1} + 6\text{e}^{-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: -121.6 (4\text{SF})$	1	ELC	
2	25	0	Inf. Dilution	$\lg K: -123.91 (5\text{SF})$	0	CRV	32224

Reaction No. 81466							
$\text{MgFe}_2\text{O}_4(\text{s}) + 8\langle\text{H}+1\rangle + 2\langle\text{e}-1\rangle = \text{Mg}+2 + 2\langle\text{Fe}+2\rangle + 4\langle\text{H}_2\text{O}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:44.8 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:42.77 (4SF)	0	CRV	32224

Reaction No. 81467							
$\text{Mg}_2\text{Si}(\text{s}) + 4\langle\text{H}_2\text{O}\rangle = 2\langle\text{Mg}+2\rangle + \text{H}+1(2)_{\text{-SiH}_2\text{O}_4-2} + 4\langle\text{H}+1\rangle + 8\langle\text{e}-1\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:209.12 (5SF)	4	CRV	32224

Reaction No. 81468							
$\text{MgCu}_2(\text{beta},\text{s}) = \text{Mg}+2 + 2\langle\text{Cu}+2\rangle + 6\langle\text{e}-1\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:96.72 (4SF)	4	CRV	32224

Reaction No. 81469							
$\text{MgCd}(\text{s}) = \text{Mg}+2 + \text{Cd}+2 + 4\langle\text{e}-1\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:90.57 (4SF)	4	CRV	32224

Reaction No. 81470							
$\text{MgCd}_3(\text{s}) = \text{Mg}+2 + 3\langle\text{Cd}+2\rangle + 8\langle\text{e}-1\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:117.02 (5SF)	4	CRV	32224

Reaction No. 81471							
$\text{Mg}_3\text{Cd}(\text{s}) = 3\langle\text{Mg}+2\rangle + \text{Cd}+2 + 8\langle\text{e}-1\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:248.90 (5SF)	4	CRV	32224

Reaction No. 81472							
$\text{MgNi}_2(\text{s}) = \text{Mg}+2 + 2\langle\text{Ni}+2\rangle + 6\langle\text{e}-1\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:86.22 (4SF)	4	CRV	32224

Reaction No. 81473							
$2\text{MgO}.2\text{Al}_2\text{O}_3.5\text{SiO}_2.\text{H}_2\text{O}(\text{s}) + 16\langle\text{H}+1\rangle + \text{H}_2\text{O} = 2\langle\text{Mg}+2\rangle + 4\langle\text{Al}+3\rangle + 5\langle\text{H}+1(2)_{\text{-SiH}_2\text{O}_4-2}\rangle$							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:51.39 (4SF)	4	CRV	32224

Reaction No. 81474




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:483.58 (5SF)	4	CRV	32224

Reaction No. 81475




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:30.94 (4SF)	4	CRV	32224

Reaction No. 81476



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:49.03 (4SF)	4	CRV	32224

Reaction No. 81506



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:103.45 (5SF)	4	CRV	32224

Data Assessment

Weight	Assessment
9	highest accuracy
8	multi-determined; excellent dependability
7	trustworthy; outstanding single determination
6	better than average reliability
5	average single determination
4	some doubt
3	poorly known
2	guess to achieve consistency (or just as bad)

1	no information but consistent
0	problematic/inconsistent

Techniques

Abbrev	Method
CIU	Critical IUPAC publication (crit.)
CMN	Several experimental values (crit.)
CRV	Critical review
CSM	Smith & Martell Vols 1-6 (crit.)
EAC	Activity Coefficient
EAE	Automated extrapolation
EBP	By Proxy
EBU	Brown's Unified Theory
EDH	Debye-Hueckel corrections
EDT	Debye-Hueckel & Temperature corrections
EES	Personal estimate
EEX	One experiment
EFE	Free Energy relations
EIE	Interpolation/Extrapolation (not Debye-Hueckel)
EIU	Critical IUPAC review (estim.)
ELC	Linear Combination of Reactions
EMD	Molecular Dynamics
EMS	Mean Spherical Approximation
EMU	Method unknown
ENS	Not specified
EOD	Calculated from data of others
EOR	Other Reaction Constants
EPZ	Pitzer model correction
ERG	Relative Gibbs energy
ERS	Rough subjective
ESC	Standard conditions anchor
ESL	Similar Ligand
ESR	Similar reaction(s)

ETS	Ternary (statistical)
EUN	Original source unknown
EVK	Variation of lgK with T
MAC	Activity coefficient (not specified)
MAG	Silver electrode e.m.f.
MCE	Cation exchange
MCG	Chromatography, Gel
MCL	Calorimetry
MCN	Conductivity
MCO	Colorimetry (often for measuring pH)
MCT	Coulometric titration
MCV	Cyclic voltammetry
MDG	Combination of Thermodynamic Data
MDS	Distribution between two phases
MEF	Electromotoric force, not specified
MEP	Electrophoresis
MFL	Fluorescence
MFP	Freezing point
MGL	Glass electrode
MHG	Emf with amalgam electrode
MHY	Emf with hydrogen electrode
MIR	Infrared spectra
MIS	Ion selective electrode
MIX	Ion exchange
MKN	Rate of reaction
MMR	Nuclear magnetic resonance
MMX	Mixed techniques
MPH	pH method, not specified
MPL	Polarography
MPS	Potentiometry and Spectrophotometry
MPT	Potentiometry
MQH	Quinhydrone electrode
MRM	Raman spectra
MRX	Emf with redox electrode
MSC	Miscellaneous
MSL	Solubility

MSP	Spectroscopy
MTD	Temperature difference
MVM	Voltametric Methods
MVP	Vapour phase osmometry

References

Reference No.: 3(69Hol)

J. Chem. Phys., 1969, 50, 4424 - 4428; Holzappel WB; Effect of Pressure and Temperature on the Conductivity and Ionic Dissociation of Water up to 100 kbar and 1000C

Reference No.: 8(76SmM)

Critical Stability Constants, Vol. 4, 1976 Smith RM; Martell AE; Plenum, New York

Reference No.: 10(82SmM)

Critical Stability Constants, Vol. 5, 1982 Smith RM; Martell AE; Plenum, New York

Reference No.: 20(63Lew)

Acta Chem. Scand., 1963, 17, 1891 Lewis D; Studies on the Hydrolysis of Metal Ions. 45. The Hydrolysis of Magnesium in Chloride Self-Medium

Reference No.: 22(48StD)

Trans. Faraday Soc., 1948, 44, 856 - 859; Stock DI; Davies CW; The Second Dissociation Constant of Magnesium Hydroxide

Reference No.: 53(57Bje)

Metal Ammine Formation in Aqueous Solution, 1957 Bjerrum J; P.Haase and Son,Copenhagen

Reference No.: 90(73HeP)

J. Chem. Soc., Dalton Trans., 1973,, 798 - 801; Hedwig GR; Powell HKJ; A Reinvestigation of the Enthalpy Changes for the Interaction of the Sulphate Ion with some Transition-metal Ions in Aqueous Solution

Reference No.: 92(52JoM)

Trans. Faraday Soc., 1952, 48, 929 - 933; Jones HW; Monk CB; EMF Studies of Electrolytic Dissociation. Part 2. Magnesium and Lanthanum Sulphates in Water

Reference No.: 94(77MLW)

J. Chem. Soc., Dalton Trans., 1977,, 588 - 595; May PM; Linder PW; Williams DR; Computer Simulation of Metal-ion Equilibria in Biofluids: Models for the Low-Molecular-Weight Complex Distribution of Calcium(II), Magnesium(II), Manganese(II), Iron(III), Copper(II), Zinc(II), and Lead(II) Ions in Human Blood Plasma

Reference No.: 97(82HMQ)

Agents Actions, 1982, 12, 536 - 542; Huang Z-X; May PM; Quinlan KM; Williams DR; Creighton AM; Metal Binding by Pharmaceuticals. Part 2. Interactions of Ca(II), Cu(II), Fe(II), Mg(II), Mn(II) and Zn(II) with the Intracellular Hydrolysis Products of the Antitumour Agent ICRF 159 and its Inactive Homologue ICRF 192

Reference No.: 107(78AKW)

J. Inorg. Nucl. Chem., 1978, 40, 1221 - 1226; Arena G; Kavv G; Williams DR; Metal-ligand Complexes Involved in Rheumatoid Arthritis. V. Formation Constants for Calcium(II)-, Magnesium(II), and Copper(II)-Salicylate and Acetylsalicylate Interactions

Reference No.: 128(70ABP)

J. Chem. Soc. (A), 1970,, 2691 Advani AT; Barnes DS; Pettit LD; Absence of Stereoselectivity in Complexes of Optically Active and Racemic 1,2-Diamines

Reference No.: 135(68WiR)

Suomen Kemi., 1968, B41, 177 - 183; Wikberg H; Ringbom A; Stability Constants of the Silver Complexes of Some Polyaminopolycarboxylic Acids

Reference No.: 139(65WHR)

Anal. Chem., 1965, 37, 884 Wright DL; Holloway JH; Reilley CN; Heats and Entropies of Formation of Metal Chelates of Polyamine and Polyaminocarboxylate Ligands

Reference No.: 140(64SiM)

Stability Constants of Metal-ion Complexes SP17, 1964 Sillen LG; Martell AE; The Chemical Soc., London

Reference No.: 146(56SaR)

J. Indian Chem. Soc., 1956, 33, 841 - 851; Sarma BD; Ray P; Stability of Inner-metal Complexes

Reference No.: 152(70GTD)

J. Chem. Soc. (A), 1970,, 241 - 245; Grzybowski AK; Tate SS; Datta SP; Magnesium and Manganese Complexes of Citric and Isocitric Acids

Reference No.: 153(65TGD)

J. Chem. Soc., 1965,, 3905 - 3912; Tate SS; Grzybowski AK; Datta SP; The Stability Constants of Magnesium Citrate Complexes

Reference No.: 154(64COM)

J. Inorg. Nucl. Chem., 1964, 26, 553 - 564; Campi E; Ostacoli G; Meirone M; Saini G; Stability of the Complexes of Tricarballic and Citric Acids with Bivalent Metal Ions in Aqueous Solution

Reference No.: 162(59LLW)

J. Inorg. Nucl. Chem., 1959, 12, 122 - 128; Li NC; Lindenbaum A; White JM; Some Metal Complexes of Citric and Tricarballic Acids

Reference No.: 183(69HoL)

J. Am. Chem. Soc., 1969, 91, 3740 - 3750; Hopgood D; Leussing DL; Kinetic and Equilibrium Studies of Formation of N-Salicylidene-glycinato Complexes. The Promnastic Effect of the Divalent Ions of Magnesium, Manganese, Zinc, Cadmium, and Lead

Reference No.: 187(65And)

Helv. Chim. Acta, 1965, 48, 1722 - 1725; Anderegg G; Complexons. XXXIX. Entropy and Enthalpy of Formation of the Metal Complexes of the Diethylenetriaminepentaacetate Ion Komplexe XXXIX. Die Bildungs-Enthalpie und -Entropie der Metallokomplexe des Diathylentriaminpentaacetat-Ions

Reference No.: 197(54SGA)

Helv. Chim. Acta, 1954, 37, 937 - 957; Schwarzenbach G; Gut R; Anderegg G; Complexons. XXV. Polarographic Study of Exchange Equilibria. New Data on the Formation Constants of Metal Complexes of Ethylenediaminetetraacetic Acid and 1, 2-Diaminocyclohexanetetraacetic Acid (Komplexe XXV. Die Prographische Untersuchung von

Austauschgleichgewichten Neue Daten der Bildungskonstanten von Metallkomplexen der Athylendiamin-tetraessigsäure und der 1,2-Diaminocyclohexan-tetraessigsäure)

Reference No.: 198(63ToM)

J. Chem. Soc., 1963,, 734 - 736; Tobia SK; Milad NE; Ion-exchange Study of the Stability and Composition of Magnesium Citrate Complex

Reference No.: 222(87Bec)

Pure Appl. Chem., 1987, 59, 1703 - 1720; Beck MT; Critical Survey of Stability Constants of Cyano Complexes

Reference No.: 233(89SmM)

Critical Stability Constants, Vol. 6, 1989 Smith RM; Martell AE; Plenum, New York

Reference No.: 234(67SBM)

Biochim. Biophys. Acta, 1967, 148, 655 - 664; Sigel H; Becker K; McCormick DB; Ternary Complexes in Solution. Influence of 2,2'-Bipyridyl on the Stability of 1:1 Complexes of Cobalt(II), Nickel(II), Copper(II), and Zinc(II) with Hydrogen Phosphate, Adenosine 5'-monophosphate and Adenosine 5'-triphosphate

Reference No.: 242(74HaH)

Chem. Scr., 1974, 5, 164 Havel J; Hogfeldt E; On Some Phosphate Equilibria. V. The System Magnesium - Phosphoric Acid in 3M (Na,Mg)ClO₄

Reference No.: 255(70Chi)

Inorg. Chem., 1970, 9, 2465 - 2469; Childs CW; A Potentiometric Study of Equilibria in Aqueous Divalent Metal Orthophosphate Solutions

Reference No.: 256(63TFG)

Trans. Faraday Soc., 1963, 59, 1580 Taylor AW; Frazier AW; Gurney EL; Solubility Products of Magnesium Ammonium and Magnesium Potassium Phosphates

Reference No.: 257(56SmA)

J. Am. Chem. Soc., 1956, 78, 2376 - 2380; Smith RM; Alberty RA; The Apparent Stability Constants of Ionic Complexes of Various Adenosine Phosphates with Divalent Cations

Reference No.: 259(72FrS)

J. Am. Chem. Soc., 1972, 94, 8898 - 8904; Frey CM; Stuehr JE; Interactions of Divalent Metal Ions with Inorganic and Nucleoside Phosphates. I. Thermodynamics

Reference No.: 264(61Ira)

J. Phys. Chem., 1961, 65, 1463 - 1465; Irani RR; Metal Complexing by Phosphorus Compounds. V. Temperature Dependence of Acidity and Magnesium Complexing Constants

Reference No.: 267(59WoO)

Recueil. Trav. Chim. Pays-Bas, 1959, 78, 759 - 782; Wolhoff JA; Overbeek JTG; Equilibrium Constants for a Number of Metal-phosphate Complexes

Reference No.: 274(57LaW)

J. Am. Chem. Soc., 1957, 79, 5606 - 5608; Lambert SM; Watters JI; The Complexes of Magnesium Ion with Pyrophosphate and Triphosphate Ions

Reference No.: 277(64ElM)

J. Inorg. Nucl. Chem., 1964, 26, 1555 - 1560; Ellison H; Martell AE; Chelating Tendencies of Triphosphate Ions

Reference No.: 280(56MaS)

Helv. Chim. Acta, 1956, 39, 653 - 661; Martell AE; Schwarzenbach G; Adenosinephosphate and Adenosinetriphosphate as Complexing Agents for Calcium and Magnesium

Reference No.: 281(73KhR)

J. Inorg. Nucl. Chem., 1973, 35, 179 - 186; Khan MMT; Reddy PR; Thermodynamic Quantities Associated with the Interaction of Tripolyphosphoric Acid with Metal Ions

Reference No.: 283(63JoW)

Talanta, 1963, 10, 769 - 777; Johansson A; Wanninen E; The Complexometric Analysis of Pyro- and Triphosphates. I. Stability Constants of the Proton and Metal Complexes of the Acids

Reference No.: 284(65And)

Helv. Chim. Acta, 1965, 48, 1712 - 1717; Anderegg G; Entropy-Conditioned Complex Formation. Thermodynamic Data Concerning Complex Formation by the Tripolyphosphate Ion Entropiebedingte Komplexbildung. Thermodynamische Daten der Komplexbildung mit dem Tripolyphosphat-Ion

Reference No.: 307(54CoT)

J. Am. Chem. Soc., 1954, 76, 5311 - 5314; Connick RE; Tsao M-S; Complexing of Magnesium Ion by Fluoride Ion

Reference No.: 309(69AzL)

Anal. Chim. Acta, 1969, 47, 49 Aziz A; Lyle SJ; Applications of the Fluoride-Sensitive Electrode to the Study of Metal-Fluoride Ion Association Constants

Reference No.: 310(68TWC)

J. Inorg. Nucl. Chem., 1968, 30, 2067 - 2070; Tanner SP; Walker JB; Choppin GR; Thermodynamic Parameters of the Alkaline Earth Monofluorides

Reference No.: 312(71BoH)

J. Inorg. Nucl. Chem., 1971, 33, 429 - 434; Bond AM; Hefter G; Use of the Fluoride Ion-selective Electrode for the Detection of Weak Fluoride Complexes

Reference No.: 317(67Ler)

Geochim. Cosmochim. Acta, 1967, 31, 2309 - 2330; Lerman A; Model of Chemical Evolution of a Chloride Lake - The Dead Sea

Reference No.: 336(60GTS)

Am. J. Sci., 1960, 258, 402 - 418; Garrels RM; Thompson ME; Siever R; Stability of some Carbonates at 25C and One Atmosphere Total Pressure

Reference No.: 337(71Nak)

J. Chem. Eng. Data, 1971, 16, 178 - 181; Nakayama FS; Magnesium Complex and Ion-pair in MgCO₃-CO₂ Solution System

Reference No.: 338(69RGS)

Chimia, 1969, 23, 186 Riesen W; Gamsjager H; Schindler PW; Schweizerische Chemische Gesellschaft Winterversammlung vom 15 Feb. 1969 in Neuenburg

Reference No.: 339(63Hos)

J. Phys. Chem., 1963, 67, 720 - 721; Hostetler PB; Complexing of Magnesium with Bicarbonate

Reference No.: 341(62Hal)

Monatsh. Chem., 1962, 93, 948 - 951; Halla F; Thermodynamics of the Hydrates of Magnesium Carbonate

Reference No.: 373(76Rea)

Chem. Geol., 1976, 18, 309 - 325; Reardon EJ; Dissociation Constants for Alkali Earth and Sodium Borate Ion Pairs from 10 to 50 degrees Celsius

Reference No.: 380(56Nan)

J. Chem. Soc., 1956,, 744 - 749; Nancollas GH; Thermodynamics of Ion Association. Part II. Alkaline-earth Acetates and Formates

Reference No.: 381(64ArM)

J. Chem. Soc., 1964,, 3117 - 3122; Archer DW; Monk CB; Ion-association Constants of Some Acetates by pH (Glass Electrode) Measurements

Reference No.: 382(70BuT)

Can. J. Chem., 1970, 48, 1654 - 1656; Bunting JW; Thong KM; Stability Constants for Some 1:1 Metal-carboxylate Complexes

Reference No.: 386(50JoM)

J. Chem. Soc., 1950,, 3475 - 3478; Jones HW; Monk CB; The Condensed Phosphoric Acids and Their Salts. Part V. Dissociation Constants of Some Tetrametaphosphates

Reference No.: 388(68WaM)

J. Inorg. Nucl. Chem., 1968, 30, 2163 Watters JI; Machen RC; A Study of the Complexes of Tetrphosphate with Alkaline Earth Metal Ions by Acidimetric PH Titrations

Reference No.: 394(81OMO)

J. Inorg. Nucl. Chem., 1981, 43, 3323 - 3327; Onaka T; Miyajima T; Ohashi S; On the binding of Magnesium to Long-Chain Polyphosphate Ions

Reference No.: 398(73PaT)

J. Phys. Chem., 1973, 77, 2318 - 2323; Patel RC; Taylor RS; Kinetics of Binding of Pyrophosphate to Magnesium Ions

Reference No.: 399(73HaH)

Acta Chem. Scand., 1973, 27, 3323 - 3334; Havel J; Hogfeldt E; Activities in the System Mg^{+2} - Na^{+} - ClO_4^{-} with $X = Cl^{-}$, Br^{-} , and SCN^{-} . The Possible Formation of MgX^{+} Ion Pairs

Reference No.: 405(73DyH)

Mar. Chem., 1973, 1, 137 - 149; Dyrssen D; Hansson I; Ionic Medium Effects in Seawater - A Comparison of Acidity Constants of Carbonic Acid and Boric Acid in Sodium Chloride and Synthetic Seawater

Reference No.: 406(80Bas)

Geochim. Cosmochim. Acta, 1980, 44, 1151 - 1160; Bassett RL; A Critical Evaluation of the Thermodynamic Data for Boron Ions, Ion pairs, Complexes, and Polyanions in Aqueous Solution at 298.5K and 1 bar

Reference No.: 436(84VDD)

Inorg. Chem., 1984, 23, 1922 - 1926; Verbeeck RMH; De Bruyne PAM; Driessens FCM; Verbeek F; Solubility of Magnesium Hydrogen Phosphate Trihydrate and Ion-Pair Formation in the System $Mg(OH)_2$ - H_3PO_4 - H_2O at 25 degrees C

Reference No.: 437(80BoH)

IUPAC Chemical Data Series No. 27, 1980 Bond AM; Hefter GT; Critical Survey of Stability Constants and Related Thermodynamic Data of Fluoride Complexes in Aqueous Solution; Pergamon, Oxford, U.K.

Reference No.: 440(78HDN)

Am. J. Sci., 1978, 278, 1 - 229; Helgeson HC; Delany JM; Nesbitt HW; Bird DK; Summary and Critique of the Thermodynamic Properties of Rock-forming Minerals

Reference No.: 441(73CHS)

Am. J. Sci., 1973, 273, 65 - 83; Christ CL; Hostetler PB; Siebert RM; Studies in the System MgO - SiO_2 - CO_2 - H_2O (III): The Activity- Product Constant of Sepiolite

Reference No.: 455(74SaS)

J. Chem. Soc., Dalton Trans., 1974,, 181 - 184; Santschi PH; Schindler PW; Complex Formation in the Ternary Systems $\text{Ca}^{+2}\text{-H}_4\text{SiO}_4\text{-H}_2\text{O}$ and $\text{Mg}^{+2}\text{-H}_4\text{SiO}_4\text{-H}_2\text{O}$

Reference No.: 476(68OVR)

Ric. Sci., 1968, 38, 318 - 321; Ostacoli G; Vanni A; Roletto E; Complex Formation between Alkyl-substituted Malonic Acids and Bivalent Metal ions in Aqueous Solutions

Reference No.: 552(95SMM)

NIST Critical Stability Constants of Metal Complexes Database, 1995 Smith RM; Martell AE; Motekaitis RJ; Version 2.0; National Institute of Standards and Technology, Gaithersburg, USA

Reference No.: 557(79Lin)

Chemical Equilibria in Soils, 1979 Lindsay WL; Wiley-Interscience, New York

Reference No.: 620(94Sha)

Monatsh. Chem., 1994, 125, 267 - 274; Sharma RK; Stabilities of Mixed Metal Complexes with Biologically Active Colchicine in Dioxan-Water and their Relation to Quantitative Softness Values: A New Approach

Reference No.: 665(63TFG)

Trans. Faraday Soc., 1963, 59, 1585 Taylor AW; Frazier AW; Gurney EL; Smith JP; Solubility Products of Di- and Trimagnesium Phosphates and the Dissociation of Magnesium Phosphate Solutions

Reference No.: 698(68Pra)

J. Indian Chem. Soc., 1968, 45, 1037 - 1046; Prasad B; Incomplete Dissociation of Salts

Reference No.: 766(87BrA)

Report EPA/600/3-87/012, 1987 Brown DS; Allison JD; MINTEQA1, An Equilibrium Metal Speciation Model: Users Manual; U.S. Environmental Protection Agency, Athens, Georgia 30613

Reference No.: 769(88RoV)

Talanta, 1988, 35, 271 - 275; Rogers HR; van den Berg CMG; Determination of Borate Ion-Pair Stability Constants by Potentiometry and Non-approximative Linearization of Titration Data

Reference No.: 773(85KoS)

Handbook of Chemical Equilibria in Analytical Chemistry, 1985 Kotrly S; Sucha L; Ellis Horwood Series in Anal. Chem.; Eds. Chalmers RA & Masson M; Ellis Horwood, Chichester

Reference No.: 778(78MiC)

Tables of Standard Electrode Potentials, 1978 Milazzo G; Caroli S; Wiley, N.Y.

Reference No.: 802(90Wea)

CRC Handbook of Chemistry and Physics, 70th Edn., 1990 Weast RC; A Ready-Reference Book of Chemical and Physical Data; CRC Press, Cleveland, Ohio

Reference No.: 903(77And)

Critical Survey of Stability Constants of EDTA Complexes, 1977 Anderegg G; IUPAC Chemical Data Series. 14; Pergamon Press, Oxford

Reference No.: 905(95Ber)

Pure Appl. Chem., 1995, 67, 1117 - 143; Berthon G; Critical Review of Formation Constants of Selected Amino Acids with Polar Side Chains

Reference No.: 906(79Per)

IUPAC Chemical Data Series No. 22, 1979 Perrin DD; Stability Constants of Metal-Ion Complexes, First Edition Part B, Organic Ligands; Pergamon, Oxford

Reference No.: 931(71SiM)

Stability Constants of Metal-ion Complexes SP25, 1971 Sillen LG; Martell AE; Supplement No 1 to Special Publication No 25; Chemical Society, London

Reference No.: 956(88GDS)

J. Chem. Res. (S), 1988,, 12 - 13; Gianguzza A; Dia G; Sammartano S; De Stefano C; Mixed-metal Complexes in Solution. Formation and Stability of Homobinuclear and Heterobinuclear Species in the Ca²⁺-Mg²⁺-ATP System

Reference No.: 957(88BSV)

Inorg. Chim. Acta, 1988, 152, 233 - 239; Burger K; Sipos P; Veber M; Horvath I; Noszal B; Low M; Formation Microequilibria of Proton, Calcium and Magnesium Complexes of the gamma-Carboxyglutamate Ion and Related Compounds

Reference No.: 963(90BJS)

J. Inorg. Biochem., 1990, 39, 59 - 73; Bieth H; Jost P; Spiess B; Complexation Studies on Inositol-Phosphates. I. Ca(II) and Mg(II) Complexes of D-Myo-inositol 1,2,6-Triphosphate

Reference No.: 978(88LaB)

Inorg. Chim. Acta, 1988, 151, 33 - 43; Lambs I; Berthon G; Metal Ion- Tetracycline Interactions in Biological Fluids. Part 7. Quantitative Investigation of Methacycline Complexes with Ca(II), Mg(II), Cu(II) and Zn(II) Ions and Assessment of their Biological Significance

Reference No.: 999(91MaM)

Estimation of Constants for JESS Database, 1991 May PM; May RF

Reference No.: 1007(89DDV)

J. Chem. Soc., Dalton Trans., 1989,, 133 - 137; Delgado R; da Silva JJRF; Vaz MCTA; Paoletti P; Micheloni M; Thermodynamics of the Formation of Metal Complexes of 1,4,10-Trioxa-7,13-diazacyclopentadecane-N,N'-diacetic acid and of 1,4,10,13-Tetraoxa-7,16-diazacyclo-octadecane-N,N'-diacetic acid

Reference No.: 1031(86ReR)

J. Chem. Soc., Dalton Trans., 1986,, 2331 - 2334; Reddy PR; Rao VBM; Metal Complexes of Uridine in Solution

Reference No.: 1069(89GAH)

Polyhedron, 1989, 8, 189 - 195; Ghandour MA; Azab HA; Hassan A; Ali AM; Potentiometric Studies on the Mixed Ligand Complexes in Solution: M II-Tetracycline-glycine Systems

Reference No.: 1089(90RAA)

Polyhedron, 1990, 9, 665 - 668; Rey F; Antelo JM; Arce F; Penedo FJ; Equilibrium Constants of Metal Amino Acid Complexes

Reference No.: 1103(89FRR)

Polyhedron, 1989, 8, 1365 - 1370; Fuentes J; Reboso R; Rodriguez A; 2,5-Toluenediamine-N,N'-Disuccinic Acid. Preparation, Dissociation Constants and Coordinating Capacity with Divalent Cations

Reference No.: 1118(82And)

Pure Appl. Chem., 1982, 54, 2693 - 2758; Anderegg G; Critical Survey of Stability Constants of NTA Complexes

Reference No.: 1144(88LVD)

J. Inorg. Biochem., 1988, 33, 193 - 210; Lambs L; Venturini M; Decock-Le Reverend B; Kozlowski H; Berthon G; Metal Ion-Tetracycline Interactions in Biological Fluids. Part 8. Potentiometric and Spectroscopic Studies on the Formation of Ca(II) and Mg(II) Complexes with 4-Dedimethylamino-Tetracycline and 6-Desoxy-6-Demethyl-Tetracycline

Reference No.: 1176(87DDV)

Polyhedron, 1987, 6, 29 - 38; Delgado R; da Silva JJRF; Vaz MCTA; Metal Complexes of 1,4,10-Trioxa-7,13-Diazacyclopentadecane- N,N"-Diacetic Acid

Reference No.: 1183(86ReR)

Polyhedron, 1986, 5, 1947 - 1952; Reddy PR; Reddy BM; Ternary Complexes of 5'-Cytidine Monophosphate and Cytosine with some Biologically Important Secondary Ligands

Reference No.: 1187(85ReR)

Polyhedron, 1985, 4, 1603 - 1609; Reddy PR; Rao VBM; Role of Secondary Ligands in the Structure and Stability of Metal-Cytidine Complexes in Solution

Reference No.: 1207(90CBG)

Inorg. Chem., 1990, 29, 5 - 9; Cortes S; Brucher E; Geraldles CFGC; Sherry AD; Potentiometry and NMR Studies of 1,5,9-Triazacyclododecane- N,N',N"-triacetic Acid and Its Metal Ion Complexes

Reference No.: 1217(89MoM)

Inorg. Chem., 1989, 28, 3499 - 3503; Motekaitis RJ; Martell AE; Potentiometry of Mixtures: Metal Chelate Stability Constants of 1-Hydroxy-3-oxapentane-1,2,4,5-tetracarboxylic Acid and 3,6-Dioxaoctane-1,2,4,5,7,8-hexacarboxylic Acid

Reference No.: 1231(81HMW)

Inorg. Chim. Acta, 1981, 56, 41 - 44; Huang Z-X; May PM; Williams DR; Metal Complexing Ability of Two Inducers of Reverse Transformation

Reference No.: 1237(76MMM)

Inorg. Chem., 1976, 15, 2303 - 2306; Motekaitis RJ; Murase I; Martell AE; Equilibria of EDTPO with Cu(II), Ni(II), Co(II), Zn(II), Mg(II), Ca(II), and Fe(III) Ions in Aqueous Solution

Reference No.: 1257(84MoM)

J. Coord. Chem., 1984, 13, 265 - 271; Motekaitis RJ; Martell AE; New Multidentate Ligands. XXV. The Coordination Chemistry of Divalent Metal Ions with Diglycolic Acid, Carboxymethyltartronic Acid and Ditartronic Acid

Reference No.: 1258(89RVM)

J. Coord. Chem., 1989, 20, 69 - 72; Rao AK; Venkataiah P; Mohan MS; Studies on Biologically Relevant Binary and Ternary Metal Complexes. IV. Stability of Binary and Ternary Metal Complexes Containing Bis(Imidazol-2-yl)Methane and Amino Acids

Reference No.: 1274(89SLN)

J. Coord. Chem., 1989, 19, 359 - 369; Strasak M; Lucansky J; Novomesky P; Dvorakova E; Diastereoselectivity in Metal Complexes of some Phenyl- substituted Ethylenediamine- N,N,N,N'-Tetraacetate Derivatives

Reference No.: 1275(87KRZ)

J. Coord. Chem., 1987, 16, 237 - 244; Khan BT; Raju RM; Zakeeruddin SM; Binary and Ternary Metal Complexes of Uridine and Thermodynamic Quantities Associated with the Interaction of Uridine with Bivalent Metal Ions in Solution

Reference No.: 1276(88BFJ)

J. Coord. Chem., 1988, 17, 245 - 253; Bottari E; Festa MR; Jasionowska R; Serine as a Ligand: Complex Formation with Cadmium(II)

Reference No.: 1297(86CCS)

Inorg. Chim. Acta, 1986, 123, 69 - 73; Cini R; Cinquantini A; Seeber R; Complexes of Magnesium(II) and other Divalent Metal Ions with Adenosine 5'-Triphosphate and 2,2'-Dipyridylamine in Aqueous Solution

Reference No.: 1306(91DeD)

Talanta, 1991, 38, 439 - 444; De Robertis A; De Stefano C; Studies of Polyfunctional O-Ligands: Formation and Stability of Mg+2 and Ca+2 Complexes of 1,2,4,5-Benzenetetracarboxylic Acid in Aqueous Solution at 25 degrees

Reference No.: 1318(90DSK)

Helv. Chim. Acta, 1990, 73, 140 - 148; Delgado R; Siegfried LC; Kaden TA; Metal Complexes with Macrocyclic Ligands. Part XXXI. Protonation Studies and Complexation Properties of Tetraazamacrocyclic Methylenephosphonates with Earth-Alkali-Ions

Reference No.: 1337(88LDK)

Inorg. Chem., 1988, 27, 3001 - 3012; Lambs L; Decock-Le Reverend B; Kozlowski H; Berthon G; Metal Ion-Tetracycline Interactions in Biological Fluids. 9. Circular Dichroism Spectra of Calcium and Magnesium Complexes with Tetracycline, Oxytetracycline, Doxycycline and Chlortetra- cycline and Discussion of their Binding Modes

Reference No.: 1338(87SAS)

Inorg. Chem., 1987, 26, 1199 - 1204; Sawada K; Araki T; Suzuki T; Complex Formation of Amino Polyphosphonates. 1. Potentiometric and Nuclear Magnetic Resonance Studies of Nitrilotris(methylenephosphonato) Complexes of the Alkaline-Earth-Metal Ions

Reference No.: 1345(88MaS)

Inorg. Chem., 1988, 27, 1447 - 1453; Massoud SS; Sigel H; Metal Ion Coordinating Properties of Pyrimidine-Nucleoside 5'-Monophosphates (CMP,UMP,TMP) and of Simple Phosphate Monoesters, Including D-Ribose 5'-Monophosphate. Establish- ment of Relations between Complex Stability and Phosphate Basicity

Reference No.: 1348(82KaR)

Inorg. Chem., 1982, 21, 3437 - 3442; Kappel MJ; Raymond KN; Ferric Ion Sequestering Agents. 10. Selectivity of Sulfonated Poly(catechoylamides) for Ferric Ion

Reference No.: 1354(87ChW)

Prog. Inorg. Chem., 1987, 35, 329 - 435; Chaudhuri P; Weighardt K; The Chemistry of 1,4,7-Triazacyclononane and Related Tridentate Macrocyclic Compounds

Reference No.: 1369(87STM)

Inorg. Chem., 1987, 26, 2149 - 2157; Sigel H; Tribolet R; Malini-Balakrishnan R; Martin RB; Comparison if the Stabilities of Monomeric Metal Ion Complexes Formed with Adenosine 5'-Triphosphate (ATP) and Pyrimidine-Nucleoside 5'-Triphosphates (CTP, UTP, TTP) and Evaluation of the Isomeric Equilibria in the Complexes of ATP and CTP

Reference No.: 1370(78MoA)

Inorg. Chem., 1978, 17, 2203 - 2207; Mohan MS; Abbott EH; Metal Complexes of Amino Acid Phosphate Esters

Reference No.: 1379(87BGH)

Inorg. Chem., 1987, 26, 2699 - 2706; Bevilacqua A; Gelb RI; Hebard WB; Zompa LJ; Equilibrium and Thermodynamic Study of the Aqueous Complexation of 1,4,7-Triazacyclononane-N,N',N'',- triacetic Acid with Protons, Alkaline-Earth-Metal Cations, and Copper(II)

Reference No.: 1394(70Nan)

Coord. Chem. Rev., 1970, 5, 379 - 415; Nancollas GH; The Thermodynamics of Metal-Complex and Ion-Pair Formation

Reference No.: 1437(91SMC)

Pure Appl. Chem., 1991, 63, 1015 - 1080; Smith RM; Martell AE; Chen YT; Critical Evaluation of Stability Constants for Nucleotide Complexes with Protons and Metal Ions

Reference No.: 1456(78MCG)

Acta Chem. Scand., 1978, A32, 79 - 83; Madsen HEL; Christensen HH; Gottlieb-Petersen C; Stability Constants of Copper(II), Zinc(II), Manganese(II), Calcium(II), and Magnesium(II) Complexes of N-(Phosphonomethyl)glycine (Glyphosphate)

Reference No.: 1467(88ADD)

Talanta, 1988, 35, 741 - 745; Amorim MTS; Delgado R; da Silva JJRF; Vaz MCTA; Vilhena MF; Metal Complexes of 1-Oxa-4,7,10-Triazacyclododecane- N,N',N''-Triacetic Acid

Reference No.: 1483(87ShC)

Inorg. Chim. Acta, 1987, 139, 119 - 120; Shanbhag SM; Choppin GR; Thermodynamics of Ln(III) Complexation with AMP and ATP

Reference No.: 1491(86ChO)

Inorg. Chem., 1986, 25, 355 - 358; Chang CA; Ochaya VO; Potential Lanthanide Selective Reagents. 3. 1,2 Metal Complex Formation with 1,7-Diaza-4,10,13-trioxacyclopentadecane- N,N'-diacetic Acid

Reference No.: 1503(82BiL)

Inorg. Chem., 1982, 21, 374 - 380; Birus M; Leussing DL; Comparison of an Enzymatic Reaction and Its Model: Metal Ion Promoted Decarboxylation of Oxalacetate

Reference No.: 1506(80Aru)

Inorg. Chem., 1980, 19, 2895 - 2896; Aruga R; Association Reactions of Magnesium(II), Calcium(II), Strontium(II), and Barium(II) with Malate Ion in Aqueous Solution. Influence of Enthalpy and Entropy Factors on the Stability Order of the Complexes

Reference No.: 1511(81MaL)

Inorg. Chem., 1981, 20, 4240 - 4247; Mao H-K; Leussing DL; An Investigation of an Enzyme Model. The Influence of Solvent on the Metal-Ion-Catalyzed Decarboxylation of Oxalacetate

Reference No.: 1520(85CDD)

Talanta, 1985, 32, 675 - 677; Capone S; De Robertis A; De Stefano C; Scarcella R; Thermodynamics of Formation of Magnesium, Calcium, Strontium and Barium Complexes with 2,2'-Bipyridyl and 1,10-Phenanthroline at Different Ionic Strengths in Aqueous Solution

Reference No.: 1529(87Har)

Talanta, 1987, 34, 817 - 820; Harju L; Determination of Stability Constants for Alkaline- Earth and Alkali Metal Ion Complexes of Glycine by Spectrophotometry

Reference No.: 1539(78Kra)

Atlas of Metal-Ligand Equilibria in Aqueous Solution, 1978 Kragten J; Ellis Horwood, Chichester UK

Reference No.: 1541(80HaM)

Inorg. Chem., 1980, 19, 2709 - 2714; Hancock RD; Marsicano F; Parametric Correlation of Formation Constants in Aqueous Solution. 2. Ligands with Large Donor Atoms

Reference No.: 1572(75And)

Helv. Chim. Acta, 1975, 58, 1218 - 1225; Anderegg G; Thermodynamik der Metallkomplexbildung mit Polyoxadiazamacrocyclen

Reference No.: 1595(79RiK)

Talanta, 1979, 26, 507 - 510; Rizkalla EN; Kazi MTM; Metal Chelates of Phosphonate-

containing Ligands - 1 Stability of Some N,N,N',N'-Ethylenediaminetetra(methylene-phosphonic) Acid Metal Chelates

Reference No.: 1599(80RZI)

Talanta, 1980, 27, 715 - 719; Rizkalla EN; Zaki MTM; Ismail MI; Metal Chelates of Phosphonate-containing Ligands - V Stability of Some 1-Hydroxyethane-1,1-Diphosphonic Acid Metal Chelates

Reference No.: 1602(74BaW)

J. Chem. Soc., Dalton Trans., 1974,, 1117 - 1120; Baxter AC; Williams DR; Thermodynamic Considerations in Co-ordination. Part XV. Potentiometric and Calorimetric Study of the Complexes Formed between Protons, First Transition Series Metal Ions, and Asparaginate and Glutamate Anions

Reference No.: 1685(83EwH)

J. Chem. Soc., Dalton Trans., 1983,, 865 - 868; Ewin G; Hill JO; A Thermometric Titrimetric Study of the Complexation of Alkaline-earth Metals by Linear Poly(aminocarboxylic) Acids

Reference No.: 1716(84TaW)

J. Chem. Soc., Faraday Trans. 1, 1984, 80, 2255 - 2267; Tam S-C; Williams RJP; Electrostatic Interactions between Organic Ions

Reference No.: 1744(92LCB)

J. Am. Chem. Soc., 1992, 114, 7780 - 7785; Liang G; Chen D; Bastian M; Sigel H; Metal Ion Binding Properties of Dihydroxyacetone Phosphate and Glycerol 1-Phosphate

Reference No.: 1747(92MoM)

Inorg. Chem., 1992, 31, 11 - 15; Motekaitis RJ; Martell AE; Stabilities of Metal Complexes of the Meso and SS Isomers of Oxydisuccinic Acid

Reference No.: 1760(90Bur)

Biocoordination Chemistry, 1990 Burger K; Coordination Equilibria in Biologically Active Systems; Ellis Horwood

Reference No.: 1779(81JMW)

J. Inorg. Nucl. Chem., 1981, 43, 825 - 829; Jackson GE; May PM; Williams DR; Metal-Ligand Complexes Involved in Rheumatoid Arthritis - VII Formation of Binary and Ternary Complexes between 2,3-Diamino- Propionic Acid, Histidine and Cu(II), Ni(II) and Zn(II)

Reference No.: 1783(92GiV)

J. Chem. Soc., Dalton Trans., 1992,, 1375 - 1379; Gibson JF; Vaughan OJ; Chelating Tendencies of N,N'-Bis(2-hydroxyphenyl)-ethylenediamine- N,N'-diacetic Acid

Reference No.: 1823(92LRB)

Inorg. Chim. Acta, 1992, 195, 89 - 93; Lazar I; Ramasamy R; Brucher E; Geraldès CFGC; Sherry AD; NMR and Potentiometric Studies of 1,4,7-triazacyclononane-N,M',N''-tris(Methylenephosphonate monoethylester) and its Complexes with Metal Ions

Reference No.: 1853(81LDD)

J. Inorg. Nucl. Chem., 1981, 43, 2429 - 2432; Lalart D; Dodin G; Dubois J-E; Complexation between Oxonic Acid and Divalent Metal Cations. Influence of Metal Salt Addition on Decarboxylation Kinetics under Acidic Conditions

Reference No.: 1860(92SCC)

Helv. Chim. Acta, 1992, 75, 2634 - 2656; Sigel H; Chen D; Corfu NA; Holy A; Strasak B; Metal-Ion-Coordinating Properties of Various Phosphonate Derivatives including 9-[2-(Phosphonylmethoxy)ethyl]adenine (PMEA)- Adenosine Monophosphate (AMP) Analogue with Antiviral Properties

Reference No.: 1867(92GHN)

Talanta, 1992, 39, 1555 - 1559; Glab S; Hulanicki A; Nowicka U; Coulometric Titration in the Study of Metal Ion-Ligand Equilibria

Reference No.: 1884(78RRK)

J. Inorg. Nucl. Chem., 1978, 40, 1265 - 1267; Reddy PR; Reddy KV; Khan MMT; Thermodynamic Quantities Associated with the Interaction of Xanthosine with Metal Ions

Reference No.: 1892(78KhJ)

J. Inorg. Nucl. Chem., 1978, 40, 1731 - 1733; Khan MMT; Jyoti MS; Mixed Ligand Ternary Chelates of Metal-Cytosine Complexes

Reference No.: 1902(79PoB)

J. Inorg. Nucl. Chem., 1979, 41, 205 - 207; Poldoski JE; Bydalek TJ; Metal Ion Complexes of Ethylene-Bis-N,N'-(2,6-Dicarboxy)Piperidine

Reference No.: 1905(79RRK)

J. Inorg. Nucl. Chem., 1979, 41, 423 - 427; Reddy PR; Reddy KV; Khan MMT; Ternary Complexes of Xanthosine in Solution

Reference No.: 1926(79PSJ)

J. Inorg. Nucl. Chem., 1979, 41, 1759 - 1763; Poonia NS; Sarad SK; Jayakumar A; Kumar GC; Coordination Chemistry of Alkali and Alkaline Earth Cations - 1. Lower Glycols as Ligands

Reference No.: 1937(93LTG)

J. Chem. Thermodyn., 1993, 25, 73 - 90; Larson JW; Tewari YB; Goldberg RN; Thermochemistry of the Reactions between Adenosine, Adenosine 5'-monophosphate, Inosine, and Inosine 5'-monophosphate; the Conversion of L-Histidine to (Urocanic Acid + Ammonia)

Reference No.: 1940(84DMW)

J. Inorg. Biochem., 1984, 20, 199 - 214; Duffield JR; May PM; Williams DR; Computer Simulation of Metal Ion Equilibria in Biofluids. IV. Plutonium Speciation in Human Blood Plasma and Chelation Therapy Using Polyaminopolycarboxylic Acids

Reference No.: 1941(67LMM)

J. Am. Chem. Soc., 1967, 89, 837 - 843; L'Eplattenier F; Murase I; Martell AE; New Multidentate Ligands. VI. Chelating Tendencies of N,N'-Di(2-hydroxybenzyl)ethylenediamine-N,N'-diacetic Acid

Reference No.: 1947(66IrP)

J. Inorg. Nucl. Chem., 1966, 28, 1629 - 1631; Irving HMNH; Parkins R; Meso- and dl-2,3-Diaminobutane-NNN'N'-Tetra-Acetic Acid and their Metal Complexes

Reference No.: 1956(64And)

Helv. Chim. Acta, 1964, 47, 1801 - 1814; Anderegg G; Komplexe XXXVI. Reaktionsenthalpie und -entropie bei der Bildung der Metalkomplexe der höheren EDTA-Homologen

Reference No.: 1957(57SSA)

Helv. Chim. Acta, 1957, 40, 1886 - 1900; Schwarzenbach G; Senn H; Anderegg G; Complexones. XXIX. A Large Chelation Effect of a Special Sort (Komplexe XXIX. Ein Grosser Chelateffekt besonderer Art)

Reference No.: 1963(63And)

Helv. Chim. Acta, 1963, 46, 1833 - 1842; Anderegg G; Komplexe XXXIII. Reaktionsenthalpie und -entropie bei der Bildung der Metallkomplexe von Athylendiamin- und Diaminocyclohexan-tetra-essigsäure

Reference No.: 1971(73SaB)

J. Am. Chem. Soc., 1973, 95, 7491 - 7500; Sari JC; Belaich JP; Microcalorimetric Studies on the Formation of Magnesium Complexes with 5' Ribonucleotides of Guanine, Uracil, and Hypoxanthine

Reference No.: 1972(73KhR)

J. Inorg. Nucl. Chem., 1973, 35, 2813 - 2819; Khan HMT; Reddy PR; Thermodynamic Quantities Associated with the Interaction of Guanosine Triphosphate and Inosine Triphosphate with Bivalent Metal Ions

Reference No.: 1978(78NLM)

Chem. Zvesti, 1978, 32, 19 - 26; Novak V; Lucansky J; Majer J; Meue Komplexane. XXXII. Synthese und Studium der Eigenschaften der 2-Methyl-1,2-diaminopropan-N,N,N',N'-tetraessigsäure

Reference No.: 1979(74RMB)

Chem. Zvesti, 1974, 28, 332 - 335; Riecanska E; Majer J; Bumbalova A; Kalina M; Neue Komplexane. XXIX. Potentiometrisches Studium chelatbildender Eigenschaften von N,N-Biskarboxymethyl-2-aminoalkansäuren

Reference No.: 1981(79MBN)

Chem. Zvesti, 1979, 33, 742 - 748; Majer J; Butvin P; Novak V; Svcekova M; Fuleova E; Valaskova I; Novak J; New Complexanes. XXXV. Properties of 1,2-Diaminooctane-N,N,N',N'-tetraacetic Acid

Reference No.: 1982(63And)

Helv. Chim. Acta, 1963, 46, 1011 - 1017; Anderegg G; Pyridinderivate als Komplexbildner IV. Die Metalkomplexe der Chelidamsäure

Reference No.: 1988(63And)

Helv. Chim. Acta, 1963, 46, 2813 - 2822; Anderegg G; Pyridinderivate als Komplexbildner VI. Reaktionsenthalpie und -entropie bei der Bildung der Metallkomplexe von 1,10-Phenathroline und alpha,alpha'-Dipyridyl

Reference No.: 1996(80MRP)

Chem. Zvesti, 1980, 34, 93 - 103; Majer J; Riecanska E; Pikulikova Z; Svcekova M; Neue Komplexane. XXXVIII. d,l-N-(2,3-Dihydroxypropyl)-N-karboxy- methylaminoessigsäure Synthese, Studium der azidobasischen Eigenschaften, Chelatbildung mit Kationen der Erdalkalimetalle und mit zweiwertigen Kationen von Schwermetallen

Reference No.: 1997(68MaR)

Chem. Zvesti, 1968, 22, 15 - 24; Majer J; Riecanska E; Nove Komplexany (XI). Komplexotvorne Vlastnosti Kyseliny beta- hydroxyetylaminomonopropionovej-alpha-monooctovej a N,N-bishydroxy- etylalaninu-alpha

Reference No.: 2000(63MaD)

Chem. Zvesti, 1963, 17, 402 - 410; Majer J; Dvorakova E; Nove Komplexony. (I). Komplexy mezo-kyseliny a Racemickej Kyseliny 2,3-diaminobutan-N,N,N',N'-tetraoctovej s Kovmi Alkalických Zemin

Reference No.: 2004(66MKD)

Chem. Zvesti, 1966, 20, 242 - 251; Majer J; Kotoucek M; Dvorakova E; Nove Komplexany. (V). Komplexy Kyseliny Ethylendiamin-N,N'- dipropionove-alpha,alpha' a Kyseliny Ethylendiamin-N,N'-diprop- ionove-alpha,alpha'-N,N'-dioctove s Kationty Alkalických Zemin a s Nekterymi Dalsimi Dvojmočnymi Kationty

Reference No.: 2006(68MJD)

Chem. Zvesti, 1968, 22, 415 - 423; Majer J; Jokl V; Dvorakova E; Jurcova M; Nove Komplexany. (XIII). Potenciometrické a Elektroforetické Studium Kyseliny Etylendiamin-N,N'-dijantarovej a jej Kovových Chelátov

Reference No.: 2008(69NDS)

Chem. Zvesti, 1969, 23, 861 - 868; Novak V; Dvorakova E; Svickova M; Majer J; New Complexanes. XIX. Complex-forming Properties of Ethylenediamine- N,N'-diacetic-N,N'-(2,2'-dialkanecarboxylic) Acids

Reference No.: 2009(80MVV)

Chem. Zvesti, 1980, 34, 637 - 644; Majer J; van Quy T; Valaskova I; Elektrophoretisches Studium der Komplexbildenden Eigenschaften der N-(Methylphosphon)iminodiessigsäure und der Glycin-N,N-bis(methyl- phosphonsäure)

Reference No.: 2010(69NDS)

Chem. Zvesti, 1969, 23, 330 - 335; Novak V; Dvorakova E; Svickova M; Majer J; Neue Komplexane. XVII. Studium der Chelate der Phenylathylendiamin- tetraessigsäure

Reference No.: 2011(69NDM)

Chem. Zvesti, 1969, 23, 161 - 165; Novak V; Dvorakova E; Majer J; Neue Komplexane. XVI. Acidobasische und Chelatbildende Eigenschaften der Komplexane vom Typ der 1,2-Diaminoalkan- und 1,2-Diaminoiso- alkan-N,N,N',N'-tetraessigsäuren

Reference No.: 2015(70AIP)

J. Chem. Soc. (A), 1970,, 2649 - 2651; Advani AT; Irving HMNH; Pettit LD; Formation Constants of Bis- and Tris-complexes of Optically Active Bidentate Ligands

Reference No.: 2016(82DeF)

Talanta, 1982, 29, 815 - 822; Delgado R; Frausto da Silva JJR; Metal Complexes of Cyclic Tetra-azatetra-acetic Acids

Reference No.: 2017(80SHP)

Aust. J. Chem., 1980, 33, 2207 - 2220; Stunzi H; Harris RLN; Perrin DD; Teitei T; Stability Constants for Metal Complexation by Isomers of Mimosine and Related Compounds

Reference No.: 2018(69SSP)

J. Inorg. Nucl. Chem., 1969, 31, 2085 - 2090; Simeon VI; Svigir B; Paulic N; Thermodynamics of Co-ordination of Alkaline-earth Cations to some C.C'-Substituted EDTA Derivatives

Reference No.: 2019(63GHW)

J. Inorg. Nucl. Chem., 1963, 25, 1225 - 1238; Grimes JH; Huggard AJ; Wilford SP; The Stabilities of the Alkaline Earth Chelates of some Polyaminopolycarboxylic Acids

Reference No.: 2028(62Tho)

J. Inorg. Nucl. Chem., 1962, 24, 1083 - 1087; Thompson LC; Complexes of the Rare Earths-II. N,N'-Ethylenediamine-diacetic Acid

Reference No.: 2031(85VBH)

Inorg. Chem., 1985, 24, 1208 - 1213; van der Merwe M; Boeyens JCA; Hancock RD; Crystallographic and Thermodynamic Study of Metal Ion Size Selectivity in the Ligand 1,4,7-Triazacyclononane-N,N',N''-triacetate

Reference No.: 2039(68And)

Helv. Chim. Acta, 1968, 51, 1856 - 1863; Anderegg G; Zur Deutung der thermodynamischen Daten von Komplexbildungs- reaktionen I

Reference No.: 2040(65And)

Helv. Chim. Acta, 1965, 48, 1718 - 1721; Anderegg G; Komplexe XXXVIII. Reaktionsenthalpie und -entropie bei der Bildung der 1:1- und 1:2-Metallkomplexe von Methyliniminodiessigsäure

Reference No.: 2041(65AnB)

Helv. Chim. Acta, 1965, 48, 887 - 892; Anderegg G; Bottari E; Pyridinderivate als Komplexbildner VII. Über die Koordinationstendenz von substituierten Dipicolinatonen

Reference No.: 2043(64LeA)

Helv. Chim. Acta, 1964, 47, 1792 - 1800; L'Eplattenier F; Anderegg G; Komplexe XXXV. Die Metallkomplexe der Tri- und der Tetramethylendiamin-NN'-tetraessigsäure

Reference No.: 2060(59Bur)

Biochem. J., 1959, 71, 388 - 395; Burton K; Formation Constants for the Complexes of Adenosine Di- or Tri- phosphate with Magnesium or Calcium Ions

Reference No.: 2086(66Sht)

J. Inorg. Nucl. Chem., 1966, 28, 845 - 861; Shtacher G; Potentiometric Determination of Stability Constants of Metal Complexes with Certain Amino Dicarboxylic Acids

Reference No.: 2099(78ILL)

Biochem. J., 1978, 169, 61 - 69; Iyer KS; Lau S-J; Laurie SH; Sarkar B; Synthesis of the Native Copper(II)-Transport Site of Human Serum Albumin and its Copper(II)-Binding Properties

Reference No.: 2131(93SKN)

J. Chem. Soc., Dalton Trans., 1993,, 2557 - 2562; Sawada K; Kanda T; Naganuma Y; Suzuki T; Formation and Protonation of Aminopolyphosphonate Complexes of Alkaline-earth and Divalent Transition-metal Ions in Aqueous Solution

Reference No.: 2134(93Sig)

Chem. Soc. Rev., 1993,, 255 - 267; Sigel H; Interactions of Metal Ions with Nucleotides and Nucleic Acids and their Constituents

Reference No.: 2141(79StP)

J. Inorg. Biochem., 1979, 10, 309 - 316; Stunzi H; Perrin DD; Stability Constants of Metal Complexes of Phosphonoacetic Acid

Reference No.: 2152(83Mor)

Principles of Aquatic Chemistry, 1983 Morel FMM; John Wiley & Sons

Reference No.: 2155(83BBL)

J. Inorg. Biochem., 1983, 19, 1 - 18; Berthon G; Brion M; Lambs L; Metal Ion-Tetracycline Interactions in Biological Fluids. 2. Potentiometric Study of Magnesium Complexes with Tetracycline, Oxytetracycline, Doxycycline, and Minocycline, and Discussion of their Possible Influence on the Bioavailability of these Antibiotics in Blood Plasma

Reference No.: 2160(84LBB)

Agents Actions, 1984, 14, 743 - 750; Lambs L; Brion M; Berthon G; Metal Ion-tetracycline Interactions in Biological Fluids. Part 3. Formation of Mixed-metal Ternary Complexes in Tetracycline, Oxytetracycline, Doxycycline and Minocycline with Calcium and Magnesium, and their Involvement in the Bioavailability of these Antibiotics in Blood Plasma

Reference No.: 2170(85LBB)

Inorg. Chim. Acta, 1985, 106, 151 - 158; Lambs L; Brion M; Berthon G; Metal Ion-Tetracycline Interactions in Biological Fluids. Part 4. Potential Influence of Ca²⁺ and Mg²⁺ Ions on the Bioavailability of Chlortetracycline and Demethylchlortetracycline, as Expected from their Computer-Simulated Distributions in Blood Plasma

Reference No.: 2181(87BlB)

Inorg. Chim. Acta, 1987, 135, 179 - 189; Blaquiere C; Berthon G; Speciation Studies in

Relation to Magnesium Bioavailability. Formation of Mg(II) Complexes with Glutamate, Aspartate, Glycinate, Lactate, Pyroglutamate, Pyridoxine and Citrate, and Appraisal of their Potential Significance towards Magnesium Gastrointestinal Absorption

Reference No.: 2182(85HCW)

Inorg. Chim. Acta, 1985, 107, L29 - L32; Huang Z-X; Creighton AM; Williams DR; Metal Binding Properties of Two Homologues of Razoxane, a Bisdioxopiperazine Antitumour Drug

Reference No.: 2194(88KRZ)

J. Chem. Soc., Dalton Trans., 1988,, 67 - 71; Khan BT; Raju M; Zakeeruddin SM; Binary and Ternary Complexes of Guanosine: Stability and Thermodynamic Parameters

Reference No.: 2209(93KLR)

Talanta, 1993, 40, 999 - 1003; Kaila L; Lajunen LHJ; Rizkalla EN; Eloranta J; Thermodynamics of Complexation of Magnesium and Calcium Ions with Dichloromethylenediphosphonate

Reference No.: 2260(90DaO)

Acta Chem. Scand., 1990, 44, 321 - 327; Dahlund M; Olin A; A Spectrophotometric Study of the Complexation of Olsalazine and Salicyclic Acid with Calcium and Magnesium

Reference No.: 2261(93PeP)

IUPAC Stability Constants Database, 1993 Pettit LD; Powell HKJ; IUPAC (in co-operation with Academic Software), Otley, UK

Reference No.: 2281(93WLH)

J. Chem. Soc., Dalton Trans., 1993,, 2017 - 2021; Wambeke DM; Lippens W; Herman GG; Goeminne AM; Metal-ion Complexation in Aqueous Solutions of 1-Thia-4,7-diazacyclononane-, 1-Thia-4,8-diazacyclodecane- and 2,5-Diazahehexane-N,N-diacetic Acid

Reference No.: 2308(74MSM)

J. Inorg. Nucl. Chem., 1974, 36, 2033 - 2038; Miyazaki M; Shimoishi Y; Miyata H; Toei K; The Reaction of Dicarboxylic Acids Containing Ether Linkages with Alkaline Earth Metals

Reference No.: 2326(74KhK)

J. Inorg. Nucl. Chem., 1974, 36, 711 - 714; Khan MMT; Krishnamoorthy CR; Interactions of Metal Ions with Pyrimidines

Reference No.: 2350(89Lau)

Comprehensive Coordination Chemistry, Vol. 2, 1989, 739 - 776; Laurie SH; Amino Acids, Peptides and Proteins

Reference No.: 2360(83Van)

Polyhedron, 1983, 2, 285 - 289; van Uitert LG; Chelate Compound Stability Constant Calculations on Metal Diketonate Complexes

Reference No.: 2371(83ReR)

Polyhedron, 1983, 2, 1171 - 1175; Reddy PR; Reddy MH; Ternary Complexes of Mixed N/O Donor Ligands in Solution

Reference No.: 2373(89And)

Comprehensive Coordination Chemistry, Vol. 2, 1989, 777 - 792; Anderegg G; Complexones

Reference No.: 2392(93SKG)

Pure Appl. Chem., 1993, 65, 1029 - 1080; Sovago I; Kiss T; Gergely A; Critical Survey of the Stability Constants of Complexes of Aliphatic Amino Acids

Reference No.: 2408(79WoN)

Talanta, 1979, 26, 1135 - 1141; Wozniak M; Nowogrocki G; Acidites et Complexes des Acides (Alkyl- et Aminoalkyl-) Phosphoniques -IV. Acides Aminoalkylphosphoniques R1R2N(CH2)nCR3R4PO3H2

Reference No.: 2469(92GhS)

J. Coord. Chem., 1992, 26, 337 - 344; Ghasemi J; Shamsipur M; Fluorimetric Study of Complexation of Alkali and Alkaline Earth Cations with 1,10-Phenanthroline, 2,2'-Bipyridine and 8-Hydroxy-Quinoline in Nonaqueous Solvents

Reference No.: 2482(72GoJ)

J. Chem. Soc., Dalton Trans., 1972,, 310 - 312; Gorton JE; Jameson RF; Complexes of Doubly Chelating Ligands. Part IV. Nickel(II), Zinc(II), Magnesium(II), and Uranyl(VI) Complexes of L-beta-(3,4-Dihydroxyphenyl)-alanine (DOPA)

Reference No.: 2516(91DLL)

Inorg. Chim. Acta, 1991, 188, 55 - 59; Duckworth PA; Lincoln SF; Lucas J; The Complexation of Divalent Metal Ions by the Cryptand 4,7,13-Trioxa-1,10-diazabicyclo[8.5.5]eicosane (C21C5) in Water and 95% Methanol/Water Solutions

Reference No.: 2527(91ClM)

Inorg. Chim. Acta, 1991, 190, 27 - 36; Clarke ET; Martell AE; Stabilities of the Alkaline Earth and Divalent Transition Metal Complexes of the Tetraazamacrocyclic Tetraacetic Acid Ligands

Reference No.: 2542(82SSP)

Inorg. Chim. Acta, 1982, 66, 147 - 155; Sigel H; Scheller KH; Prus B; Metal Ion/Buffer Interactions. Stability of Alkali and Alkaline Earth Ion Complexes with Triethanolamine (Tea), 2-Amino-2(hydroxy- methyl)-1,3-Propanediol (Tris) and 2-[Bis(2-hydroxyethyl)amino]2 (hydroxymethyl)-1,3-propanediol (BisTris) in Aqueous and Mixed Solvents

Reference No.: 2551(91And)

Inorg. Chim. Acta, 1991, 180, 69 - 72; Anderegg G; Correlation between Thermodynamic Functions of Metal Complex Formation and Basicities of the Iminodiacetate Derivatives

Reference No.: 2556(93MSM)

NIST Critical Stability Constants of Metal Complexes Database, 1993 Martell AE; Smith RM; Motekaitis RJ; Version 1.0; National Institute of Standards and Technology, Gaithersburg, USA

Reference No.: 2558(54Cha)

J. Am. Chem. Soc., 1954, 76, 5854 - 5858; Charles RG; Heats and Entropies of Reaction of Metal Ions with Ethylenediaminetetraacetate

Reference No.: 2591(66IrM)

J. Chem. Soc. (A), 1966,, 1268 - 1275; Irving HMNH; Miles MG; Analogues of Nitrilotriacetic Acid, and the Stabilities of their Proton and Metal Complexes

Reference No.: 2595(66IrM)

J. Chem. Soc. (A), 1966,, 727 - 732; Irving HMNH; Miles MG; Aryl Derivatives of Nitrilotriacetic Acid, and the Stability of Their Proton and Metal Complexes

Reference No.: 2596(67CCI)

Inorg. Chem., 1967, 6, 943 - 946; Carter RP; Crutchfield MM; Irani RR; Nitrilotri(methylenephosphonic acid)N-Oxide and Nitrilotriacetic Acid N-Oxide: Acidity and Complexing of Calcium and Magnesium Ions

Reference No.: 2599(88JTJ)

J. Chem. Soc., Faraday Trans. 1, 1988, 84, 951 - 958; Juillard J; Tissier C; Jeminet G;

Interactions between Metal Cations and the Ionophore Lasalocid Part 1. Complexation of Alkaline-earth-metal Cations by Lasalocid, Bromolasalocid and Salicylic Acid in Methanol

Reference No.: 2603(56CaS)

J. Chem. Soc., 1956,, 4571 - 4579; Care RA; Staveley LAK; The Thermodynamics of the Formation of Complex Ions of Ethlenediaminetetra-acetic Acid and Bivalent Cations

Reference No.: 2604(82BDJ)

Can. J. Chem., 1982, 60, 981 - 989; Bolte J; Demuynck C; Jeminet G; Juillard J; Tissier C; Etude Comparee de Trois Antibiotiques Ionophores: X.537 A (Lasalocide), A.23187 (Calcimycine) et X.14547 A. Complexation des Cations IA et IIA, Transport de Ca++

Reference No.: 2648(77Sig)

J. Inorg. Nucl. Chem., 1977, 39, 1903 - 1911; Sigel H; Comparison of the Stabilities of Binary and Ternary Complexes of Divalent Metal Ions with the 5'-Triphosphates of Adenosine, Inosine, Guanosine, Cytidine, Uridine and Thymidine

Reference No.: 2699(45SKS)

Helv. Chim. Acta, 1945, 28, 1133 - 1143; Schwarzenbach G; Kampitsch E; Steiner R; Komplexe II. Das Komplexbildungsvermogen von Iminodiessigsaeure, Methylimino-diessigsaeure, Aminomalonsaeure und Aminomalonsaeure -diessigsaeure

Reference No.: 2713(93GhS)

J. Coord. Chem., 1993, 28, 231 - 236; Ghasemi J; Shamsipur M; Spectrophotometric Study of Complex Formation between some Alkali and Alkaline Earth Cations and Several Conventional (N,N), (N,O) and (O,O) Ligands in 95% Ethanol

Reference No.: 2717(93BGE)

J. Chem. Soc., Chem. Commun., 1993,, 574 - 575; Brucher E; Gyori B; Emri J; Solymosi P; Sztanyik LB; Varga I; 1,10-Diaza-4,7,13,16-tetraoxacyclooctadecane-1,10-bis(malonate), a Ligand With High Sr²⁺/Ca²⁺ and Pb²⁺/Zn²⁺ Selectivities in Aqueous Solution

Reference No.: 2756(72WaF)

Anal. Chem., 1972, 44, 1640 - 1643; Wada H; Fernando Q; Interaction of Methanehydroxyphosphonic Acid and Ethane-1-hydroxy-1,1-diphosphonic Acid with Alkali and Alkaline Earth Metal Ions

Reference No.: 2780(80RiZ)

Talanta, 1980, 27, 769 - 770; Rizkalla EN; Zaki MTM; Metal Chelates of Phosphonate-containing Ligands - VI. Complexes of Ethylenediaminetetra(methylenephosphonic) Acid with Cd, Mg, Ca and Ba

Reference No.: 2804(80Pea)

Aust. J. Chem., 1980, 33, 1511 - 1517; Pearce KN; Formation Constants for Magnesium and Calcium Citrate Complexes

Reference No.: 2876(93SMS)

J. Chem. Soc., Dalton Trans., 1993,, 3777 - 3784; Sawada K; Miyagawa T; Sakaguchi T; Doi K; Structure and Thermodynamic Properties of Aminopolyphosphonate Complexes of the Alkaline-earth Metal Ions

Reference No.: 2906(88SMT)

J. Am. Chem. Soc., 1988, 110, 6857 - 6865; Sigel H; Massoud SS; Tribolet R; Comparison of the Metal Ion Coordinating Properties of Tubercidin 5'-Monophosphate (7-Deaza-AMP) with Those of Adenosine 5'-Monophosphate (AMP) and 1,N6-Ethenoadenosine 5'-Monophosphate (epsilon-AMP). Definite Evidence for Metal Ion-Base Backbinding to N-7 and Extent of Macrochelate Formation in M(AMP) and M(epsilon-AMP)

Reference No.: 2961(78MiS)

J. Am. Chem. Soc., 1978, 100, 1564 - 1570; Mitchell PR; Sigel H; Enhanced Stability of Ternary Metal Ion/Adenosine 5'-Triphosphate Complexes. Cooperative Effects Caused by Stacking Interactions in Complexes Containing Adenosine Triphosphate, Phenanthroline, and Magnesium, Calcium, or Zinc Ions

Reference No.: 3006(85BPJ)

Standard Potentials in Aqueous Solution, 1985 Bard AJ; Parsons R; Jordan J; Monographs in Electroanalytical Chemistry and Electrochemistry; Marcel Dekker Inc., New York and Basel

Reference No.: 3082(73StC)

J. Inorg. Nucl. Chem., 1973, 35, 1621 - 1636; Steger HF; Corsini A; Stability of Metal Oxinates - I. Effect of Ligand Basicity

Reference No.: 3083(68CaI)

J. Inorg. Nucl. Chem., 1968, 30, 2971 - 2976; Carroll RL; Irani RR; On the ΔH and ΔS of Metal Ion Interaction with Substituted Methylene Diphosphonates

Reference No.: 3133(73CGC)

J. Inorg. Nucl. Chem., 1973, 35, 4217 - 4220; Cetina R; Gomez-Lara J; Contreras R; Stability Constants of Substituted Salicylaldehydes Complexes

Reference No.: 3147(76RRK)

J. Inorg. Nucl. Chem., 1976, 38, 1923 - 1924; Reddy PR; Reddy KV; Khan MMT; Interaction of Metal Ions with Xanthosine

Reference No.: 3159(76KhR)

J. Inorg. Nucl. Chem., 1976, 38, 1234 - 1236; Khan MMT; Reddy PR; Interaction of Metal Ions with Uridine Triphosphate

Reference No.: 3186(75KhR)

J. Inorg. Nucl. Chem., 1975, 37, 771 - 774; Khan MMT; Reddy PR; Interaction of Metal Ions with Cytidinetriphosphate

Reference No.: 3201(77DCV)

J. Inorg. Nucl. Chem., 1977, 39, 613 - 619; da Silva JJRF; Candida M; Vaz TA; The Thermodynamics of Complex Formation between Uramildiacetic Acid and the Alkaline-Earth Metals

Reference No.: 3215(68NaP)

Inorg. Chem., 1968, 7, 58 - 62; Nancollas GH; Park AC; Thermodynamics of Ion Association. XVI. Bivalent Metal Complexes Involving Nitrogen and Oxygen Coordination

Reference No.: 3283(75LeS)

J. Am. Chem. Soc., 1975, 97, 6700 - 6707; Lehn J-M; Sauvage JP; [2]-Cryptates: Stability and Selectivity of Alkali and Alkaline-Earth Macrobicyclic Complexes

Reference No.: 3480(62KhM)

J. Am. Chem. Soc., 1962, 84, 3037 - 3041; Khan MMT; Martell AE; Metal Chelates of Adenosinediphosphoric and Adenosinemonophosphoric Acids

Reference No.: 3481(67KhM)

J. Am. Chem. Soc., 1967, 89, 5585 - 5590; Khan MMT; Martell AE; Thermodynamic Quantities Associated with the Interaction of Adenosinediphosphoric and Adenosinemonophosphoric Acids with Metal Ions

Reference No.: 3482(66KhM)

J. Am. Chem. Soc., 1966, 88, 668 - 671; Khan MMT; Martell AE; Thermodynamic Quantities Associated with the Interaction of Adenosine Triphosphate with Metal Ions

Reference No.: 3486(55SAS)

Helv. Chim. Acta, 1955, 38, 1147 Schwarzenbach G; Anderegg G; Schneider W; Senn H; Complexons. XXVI. The Co-ordination Tendency of N-Substituted Iminoacetic Acids (Komplexe XXVI. Über die Koordinationstendenz von N-Substituierten Iminodiestersäuren)

Reference No.: 3504(68Doo)

Pharm. Weekbl., 1968, 103, 1213 - 1227; Doornbos DA; Stability Constants of Metal Complexes of L-Cysteine, D-Penicillamine and N-Acetyl-D-Penicillamine and Some Biguanidides

Reference No.: 3511(70ClM)

J. Inorg. Nucl. Chem., 1970, 32, 911 Clarke ER; Martell AE; Metal Chelates of Arginine and Related Ligands

Reference No.: 3514(50Alb)

Biochem. J., 1950, 47, 531 - 537; Albert A; Quantitative Studies of the Avidity of Naturally Occurring Substances for Trace Metals. 1. Amino Acids Having Only Two Ionizing Groups

Reference No.: 3519(75FCM)

Anal. Chim. Acta, 1975, 74, 101 Field TB; Coburn J; McCourt JL; McBryde WAE; Composition and Stability of Some Metal Citrate and Diglycolate Complexes in Aqueous Solution

Reference No.: 3520(74Mey)

Anal. Biochem., 1974, 62, 295 Meyer JL; Formation Constants for Interaction of Citrate with Calcium and Magnesium Ions

Reference No.: 3565(85ReR)

J. Chem. Soc., Dalton Trans., 1985,, 239 - 242; Reddy PR; Reddy MH; Influence of Secondary Ligands on the Stability of Metal-Xanthosine Complexes in Solution

Reference No.: 3572(63ALS)

Helv. Chim. Acta, 1963, 46, 1400 - 1408; Anderegg G; L'Eplattenier F; Schwarzenbach G; Hydroxamatkomplexe II. Die Anwendung der pH-Methode

Reference No.: 3584(85SmM)

Biochim. Biophys. Acta, 1985, 839, 287 - 299; Smith GL; Miller DJ; Potentiometric Measurements and Constants of EGTA for Protons and Divalent Ions including Calcium

Reference No.: 3595(86DDS)

J. Chem. Res. (S), 1986,, 164 - 165; De Robertis A; De Stefano C; Sammartano S; Cali R; Purrello R; Rigano C; Alkali-metal and Alkaline-earth-metal Ion Complexes with Adenosine 5'-triphosphate in Aqueous Solution. Thermodynamic Parameters and their Dependence on Temperature and Ionic Strength

Reference No.: 3617(82HaN)

S. Afr. J. Chem., 1982, 35, 153 - 156; Hancock RD; Nankani BS; Linear Free Energy Relationships and the Chelate Effect in Oxygen Donor Ligands

Reference No.: 3682(56AlR)

Nature (London), 1956, 177, 433 - 434; Albert A; Rees CW; Avidity of the Tetracyclines for the Cations of Metals

Reference No.: 3802(89FRR)

Polyhedron, 1989, 8, 2693 - 2699; Fuentes J; Reboso R; Rodriguez A; Binary and Ternary Complexes of 1,3-Phenylenediamine-N,N'-Disuccinic Acid with Divalent Cations

Reference No.: 3819(88KGM)

Polyhedron, 1988, 7, 1227 - 1230; Kashanian S; Gholivand MB; Madaeni S; Nikrahi A; Shamsipur M; Spectrophotometric Study of the Complexation Reactions between Alkaline Earth Cations and Murexide in some Non-Aqueous Solutions

Reference No.: 3832(90KLV)

Russ. J. Inorg. Chem., 1990, 35, 73 - 75; Kozlovskii EV; Ledenkov SF; Vasil'ev VP; Thermodynamics of the Formation of Calcium and Magnesium Ethylenediaminedisuccinates in Solution

Reference No.: 3853(86KhZ)

Inorg. Chim. Acta, 1986, 124, 5 - 11; Khan BT; Zakeeruddin SM; Metal Complexes of Substituted Pyrimidines

Reference No.: 3867(83ReR)

Inorg. Chim. Acta, 1983, 80, 95 - 98; Reddy PR; Reddy KV; Stabilities and thermodynamic Parameters of 1:2 Metal-Xanthosine Complexes in Solution

Reference No.: 3870(84BLS)

Inorg. Chim. Acta, 1984, 82, 141 - 144; Blomqvist K; Still ER; Solution Studies of Systems with Polynuclear Complex Formation. 4. Heteronuclear Copper(II) Citrate Complexes with Nickel(II) or Magnesium(II)

Reference No.: 3882(82FaP)

Inorg. Chim. Acta, 1982, 59, 87 - 91; Farmer RM; Popov AI; ESR Study of Manganese(II) Complexes in Aqueous Solutions

Reference No.: 3905(87ShC)

Inorg. Chim. Acta, 1987, 138, 187 - 192; Shanbhag SM; Choppin GR; Thermodynamics of Mg and Ca Complexation with AMP, ADP, ATP

Reference No.: 3910(89KaS)

Inorg. Chim. Acta, 1989, 155, 203 - 206; Kashanian S; Shamsipur M; Complex Formation of Alkaline Earth Cations with Benzo-15-Crown-5 and some 18-Crowns in methanol, Dimethylformamide and Dimethyl sulfoxide Solutions

Reference No.: 3913(88RPR)

Inorg. Chim. Acta, 1988, 144, 21 - 23; Ruangpornvisuti VW; Probst MM; Rode BM; Magnesium and Lithium Complexation by 1,4,7,10-Tetraazacyclododecane

Reference No.: 3925(85RAA)

Inorg. Chim. Acta, 1985, 96, 171 - 178; Rizkalla EN; Antonious MS; Anis SS; X-Ray Photoelectron and Potentiometric Studies of Some Calcium Complexes

Reference No.: 4245(62IrM)

J. Phys. Chem., 1962, 66, 1349 - 1353; Irani RR; Moedritzer K; Metal Complexing by Phosphorus Compounds. VI Acidity Constants and Calcium and Magnesium Complexing by Mono- and Polymethylene Diphosphonates

Reference No.: 4250(57TiB)

J. Am. Chem. Soc., 1957, 79, 1293 - 1296; Tichane RM; Bennett WE; Coordination Compounds of Metal Ions with Derivatives and Analogs of Ammoniadiacetic Acid

Reference No.: 4455(47MeM)

Nature (London), 1947, 159, 370 - 370; Mellor DP; Maley L; Stability Constants of Internal Complexes

Reference No.: 4460(94SMC)

J. Am. Chem. Soc., 1994, 116, 2958 - 2971; Sigel H; Massoud SS; Corfu NA; Comparison of the Extent of Macrochelate Formation in Complexes of Divalent Metal Ions with Guanosine (GMP-2), Inosine (IMP-2) and Adenosine 5'-Monophosphate (AMP-2). The Crucial Role of N-7 Basicity in Metal Ion-Nucleic Base Recognition

Reference No.: 4478(94SCB)

Helv. Chim. Acta, 1994, 77, 1738 - 1756; Song B; Chen D; Bastian M; Martin RB; Sigel H; Metal-Ion-Coordinating Properties of a Viral Inhibitor, a Pyrophosphate Analogue, and a Herbicide Metabolite, a Glycinate Analogue: The Solution Properties of the Potentially Five-Membered Chelates Derived from Phosphonoformic Acid and (Aminomethyl)phosphonic Acid

Reference No.: 4482(94She)

J. Chem. Soc., Faraday Trans., 1994, 90, 3401 - 3404; Shehata HA; Conductometric Study of Association Phenomena of Some Metal(II) Complexes in Water at Different Temperatures

Reference No.: 4496(77Ein)

J. Chem. Soc., Dalton Trans., 1977,, 912 - 914; Einaga H; Hydrolysis of Magnesium(II) in 1.0 mol dm⁻³ Aqueous (Na,H)NO₃ Solution

Reference No.: 4503(82EFW)

Electrochim. Acta, 1982, 27, 647 - 651; Emara MM; Farid NA; Wasfi AM; Thermodynamics of Ionic-Association in Aqueous Solutions of Ca and Mg Organic Salts using Ion-Selective Electrode Technique - II. Benzoate, o-Toluate, o-Chlorobenzoate and Salicylate

Reference No.: 4547(75KWN)

J. Am. Chem. Soc., 1975, 97, 4298 - 4303; Kluger R; Wasserstein P; Nakaoka K; Factors Controlling Association of Magnesium Ion and Acyl Phosphates

Reference No.: 4603(81Ein)

J. Inorg. Nucl. Chem., 1981, 43, 229 - 233; Einaga H; The Hydrolytic Precipitation Reaction of Mg(II) From Aqueous NaNO₃ Solution

Reference No.: 4609(74Aru)

J. Inorg. Nucl. Chem., 1974, 36, 3779 - 3782; Aruga R; Thermodynamics of Association of Thiosulphate Ion with Several Mono- and Bivalent Metal Ions

Reference No.: 4631(81KuM)

J. Inorg. Nucl. Chem., 1981, 43, 1299 - 1304; Kulstad S; Malmsten LA; Diaza-Crown Ethers -V. Stability Constants of N,N'-Disubstituted Diaza-Crown Ether Complexes with Various Metal Ions

Reference No.: 4763(84CVR)

J. Chem. Soc., Faraday Trans. 1, 1984, 80, 3275 - 3284; Cox BG; van Truong Ng.; Rzeszotarska J; Schneider H; Stability Constants of Complexes of Monensin and Lasalocid with Alkali-metal and Alkaline-earth-metal Ions in Protic and Polar Aprotic Solvents

Reference No.: 4795(88PPJ)

J. Chem. Soc., Faraday Trans. 1, 1988, 84, 1713 - 1722; Pointud Y; Passelaigue E; Juillard J; Interactions between Metal Cations and the Ionophore Lasalocid Part 4 ΔH and ΔS for Formation of 1-1 and 2-1 Complexes of the Lasalocid Anion and Salicylate with Alkaline-earth Metal Cations in Methanol

Reference No.: 4852(54CCD)

Biochem. J., 1954, 58, 146 - 154; Clarke HB; Cusworth DC; Datta SP; Thermodynamic

Quantities for the Dissociation Equilibria of Biologically Important Compounds. 3. The Dissociation of the Magnesium Salts of Phosphoric Acid, Glucose 1-Phosphoric Acid and Glycerol 2-Phosphoric Acid

Reference No.: 4861(76KlO)

J. Chem. Soc., Faraday Trans. 1, 1976, 72, 513 - 525; Klaning UK; Osterby O; Hydration and Ion Pairing of Maleinates, Malonates, and Substituted Malonates in Aqueous Solution

Reference No.: 4896(95PiL)

Acta Chem. Scand., 1995, 49, 235 - 240; Piispanen J; Lajunen LHJ; Complex Formation Equilibria of Some Aliphatic alpha-Hydroxycarboxylic Acids. 1. The Determination of Protonation Constants and the Study of Calcium(II) and Magnesium(II) Complexes

Reference No.: 4910(95JWJ)

J. Chem. Soc., Dalton Trans., 1995,, 1411 - 1415; Jarvis NV; Wagener JM; Jackson GE; Metal-ion Speciation in Blood Plasma as a Tool for Elucidating the in vivo Behaviour of Radiopharmaceuticals Containing Sm and Ho

Reference No.: 4920(38CaK)

J. Am. Chem. Soc., 1938, 60, 2314 - 2320; Cannan K; Kibrick AC; Complex Formation between Carboxylic Acids and Divalent Metal Cations

Reference No.: 4935(77GrF)

J. Am. Chem. Soc., 1977, 99, 4963 - 4968; Granot J; Fiat D; NMR Studies of Catecholamines. Interactions with Adenine Nucleotides and Divalent Metal Ions in Aqueous Solution

Reference No.: 4990(51DuJ)

J. Chem. Soc., 1951,, 2925 - 2930; Dunsmore HS; James JC; The Electrolytic Dissociation of Magnesium Sulphate and Lanthanum Ferricyanide in Mixed Solvents

Reference No.: 4996(74PyH)

Limnol. Oceanogr., 1974, 19, 223 - 234; Pytkowicz RM; Hawley JE; Bicarbonate and Carbonate Ion-pairs and a Model of Seawater at 25C

Reference No.: 4998(86BaM)

The Hydrolysis of Cations, 1986 Baes CF Jr; Mesmer RE; Robert E. Krieger Publ. Co. Malabar, Florida

Reference No.: 5019(82MaS)

Talanta, 1982, 29, 145 - 148; Majer V; Stulik K; A Study of the Stability of Alkaline-Earth Metal Complexes with Fluoride and Chloride Ions at various Temperatures by Potentiometry with Ion-Selective Electrodes

Reference No.: 5043(71Duf)

J. Chem. Soc. (A), 1971,, 2736 - 2740; Duff EJ; Orthophosphates. Part VIII. The Transformation of Newberryite into Bobierite in Aqueous Alkaline Solutions

Reference No.: 5071(91RZM)

J. Solution Chem., 1991, 20, 361 - 373; Roy RN; Zhang J-Z; Millero FJ; The Ionization of Sulfurous Acid in Na-Mg-Cl Solutions at 25 degrees Celsius

Reference No.: 5086(80JPW)

Mar. Chem., 1980, 8, 191 - 198; Johansson O; Persson I; Wedborg M; Calorimetric Study of the Thermodynamics of Formation of MgSO₄ and NaSO₄-Ion Pairs at the Ionic Strength of Seawater

Reference No.: 5087(75LeM)

J. Solution Chem., 1975, 4, 145 - 159; Leung WH; Millero FJ; The Enthalpy of Formation of Magnesium Sulphate Ion Pairs

Reference No.: 5101(78ElW)

Mar. Chem., 1978, 6, 243 - 252; Elgquist B; Wedborg M; Stability Constants of NaSO_4^- , MgSO_4 , MgF^+ , MgCl^+ Ion Pairs at the Ionic Strength of Seawater by Potentiometry

Reference No.: 5156(91ReB)

Radiochim. Acta, 1991, 52/53, 453 - 456; Read D; Broyd TW; Recent Progress in Testing Chemical Equilibrium Models: The CHEMVAL Project

Reference No.: 5167(76ICP)

Russ. J. Inorg. Chem., 1976, 21, 1759 - 1761; Ivakin AA; Chufarova IG; Petunina NI; Solubility and Ion-Exchange Properties of Alkaline Earth Element Polyvanadates of the type MVl_2O_3

Reference No.: 5217(85LiL)

Talanta, 1985, 32, 83 - 85; Linder PW; Little JC; Formation Constants for the Complexes of Orthophosphate with Magnesium and Hydrogen Ions

Reference No.: 5262(78KaH)

Anal. Chem., 1978, 50, 1209 - 1212; Karweik DH; Huber CO; Polyphosphate Currents at the Lead Dioxide Electrode for Hydrolysis Rate in Instability Constant Measurements

Reference No.: 5304(82Aru)

Can. J. Chem., 1982, 60, 1828 - 1831; Aruga R; Solute-Solvent Interactions in the Association of Hexacyanoferrate(III) with Group IIA Cations. A Calorimetric Study

Reference No.: 5306(66MiR)

Russ. J. Inorg. Chem., 1966, 11, 958 - 961; Mironov VE; Rutkovskii YI; Hexacyanoferrate(III) Associates of Sodium, Potassium, Caesium, Magnesium, Strontium, and Barium

Reference No.: 5322(79JoW)

Mar. Chem., 1979, 8, 57 - 69; Johansson O; Wedborg M; Stability Constants of Phosphoric Acid in Seawater of 5-40% Salinity and Temperatures of 5-25C

Reference No.: 5373(83BVK)

J. Solution Chem., 1983, 12, 581 - 595; Byrne RH; van der Weijden CH; Kester DR; Zuehlke RW; Evaluation of the CuCl^+ Stability Constant and Molar Absorptivity in Aqueous Media

Reference No.: 5374(80BrD)

J. Solution Chem., 1980, 9, 279 - 288; Brooker MH; DeYoung BS; Measurement of the Stability Constants for Aqueous Calcium and Magnesium Nitrite by Raman Spectroscopic Methods

Reference No.: 5378(74HaI)

J. Solution Chem., 1974, 3, 57 - 70; Hanania GIH; Israelian SA; Thermodynamics of the Association of Aqueous Calcium and Hexacyanoferrate Ions

Reference No.: 5384(89HFM)

J. Solution Chem., 1989, 18, 875 - 891; Hershey JP; Fernandez M; Millero FJ; The Dissociation of Phosphoric Acid in NaCl and NaMgCl Solutions at 25c

Reference No.: 5390(95Woo)

Thesis, Univ. Cape Town, 1995 Woolard C; A Computer Simulation of the Trace Metal Speciation in Seawater; Univ. Cape Town, South Africa

Reference No.: 5398(82Hog)

IUPAC Chemical Data Series No. 21, 1982 Hogfeldt E; Stability Constants of Metal-ion Complexes, 2nd Suppl., Part A, Inorganic Ligands; Pergamon, Oxford

Reference No.: 5406(97Sjo)

Pure Appl. Chem., 1997, 69, 1549 - 1570; Sjoberg S; Critical Evaluation of Stability Constants of Metal-Imidazole and Metal-Histamine Systems

Reference No.: 5416(86Chi)

ISEI Tech. Report, Ser. B, No. 3, 1986 Chiba H; Compilation of Dissociation Constants of Major Aqueous Species Present in Geothermal Fluids. Comparison of Thermodynamic Data Base of Aqueous Speciation Codes.; Inst. Study Earth's Interior, Okayama Univ., Japan

Reference No.: 5429(59YaV)

Konstanty Nestoikosti Komplexnykh Soedinenii, Moskva, 1959, 103 - 200; Yatsimirskii KB; Vasil'ev VP

Reference No.: 5433(55Pau)

Thesis, Univ. California, Berkley, 1955 Paul AD

Reference No.: 5435(23Bot)

Landolt-Bornstein Tabellen, 1923, HWII, 1185 Bottger W

Reference No.: 5437(79Ile)

The Chemistry of Silica, 1979 Iler RK; Solubility, Polymerization, Colloid and Surface Properties, and Biochemistry; John Wiley & Sons, New York

Reference No.: 5458(80BeT)

Report LBL-11448, 1980 Benson LV; Teague LS; Tabulation of Thermodynamic Data for Chemical Reactions Involving 58 Elements Common to Radioactive Waste

Reference No.: 5468(77Wag)

Water Res., 1977, 12, 139 - 145; Wagemann R; Some Theoretical Aspects of Stability and Solubility of Inorganic Arsenic in the Fresh Water Environment

Reference No.: 5484(90NPL)

ACS Symp. Ser., 1990, 416, 398 - 413; Nordstrom DK; Plummer LN; Langmuir D; Busenberg E; May HM; Jones BF; Parkhurst DL; Revised Chemical Equilibrium Data for Major Water-Mineral Reactions and their Limitations

Reference No.: 5520(94CDI)

J. Am. Chem. Soc., 1994, 116, 10267 - 10274; Corradini R; Dossena A; Impellizzeri G; Maccarrone RM; Rizzarelli E; Sartor G; Vecchio G; Chiral Recognition and Separation of Amino Acids by Mean of a Copper(II) Complex of Histamine Monofunctionalized beta-Cyclodextrin

Reference No.: 5522(88NIT)

Arsenic Metallurgy Fundamentals and Applications, 1988, 77 - 98; Nishimura T; Itoh CT; Tozawa K; Stabilities and Solubilities of Metal Arsenites and Arsenates in Water and Effect of Sulfate and Carbonate Ions on their Solubilities

Reference No.: 5574(94DDS)

Chem. Speciation Bioavail., 1994, 6, 65 - 84; De Robertis A; De Stefano C; Sammartano S; Gianguzza A; Equilibrium Studies in Natural Fluids: a Chemical Speciation Model for the Major Constituents of Sea Water

Reference No.: 5575(87MPA)

Metall. Trans., 1987, 18B, 41 - 47; Majima H; Peters E; Awakura Y; Park SK; Electrical Conductivity of Acidic Sulfate Solution

Reference No.: 5593(75JaL)

J. Solution Chem., 1975, 4, 1023 - 1031; Jackman FA; Lister MW; The Association of Hexacyanoferrate(II) Ions and Group IIA Cations

Reference No.: 5605(78CDH)

J. Chem. Thermodyn., 1978, 10, 903 - 906; Cox JD; Drowart J; Hepler LG; Medvedev VA; Wagman DD; CODATA recommended Key Values for Thermodynamics, 1977. Report of the CODATA Task Group on Key Values for Thermodynamics, 1977

Reference No.: 5606(91SWW)

Talanta, 1991, 38, 889 - 895; Scott WD; Wrigley TJ; Webb KM; A Computer Model of Struvite Solution Chemistry

Reference No.: 5644(87MoM)

Mar. Chem., 1987, 21, 101 - 116; Motekaitis RJ; Martell AE; Speciation of Metals in the Oceans. I. Inorganic Complexes in Seawater, and Influence of Added Chelating Agents

Reference No.: 5646(75Gue)

Chemical Equilibrium, 1975 Guenther WB; A Practical Introduction for the Physical and Life Sciences; Plenum Press, N.Y.

Reference No.: 5648(72MoO)

Ions in Aqueous Systems, 1972 Moller T; O'Connor R; An Introduction to Chemical Equilibrium and Solution Chemistry; McGraw-Hill Book Co., N.Y.

Reference No.: 5653(71MMM)

J. Inorg. Nucl. Chem., 1971, 33, 3353 - 3365; Motekaitis RJ; Murase I; Martell AE; New Multidentate Ligands. XI. Synthesis and Chelating Tendencies of Ethylene-diamine-N,N'-di(methylenephosphinic) Acid, Ethylenediamine-N,N,N',N'-tetra(methylene-phosphinic) Acid and Ethylenediamine-N,N'-di(methylenephosphonic) Acid

Reference No.: 5674(74DeF)

Biochemistry, 1974, 13, 5022 - 5032; Degani H; Friedman HL; Ion Binding by X-537A. Formulas, Formation Constants, and Spectra of Complexes

Reference No.: 5699(52Fyf)

J. Chem. Soc., 1952,, 2023 - 2027; Fyfe WS; Complex-ion Formation. Part II. The Entropies of Formation of Some Metal Ammines

Reference No.: 5703(53KlM)

J. Am. Chem. Soc., 1953, 75, 4159 - 4162; Klotz IM; Ming WCL; Stability Constants for Some Metal Chelates of Pyridine-2-azo-rho-dimethylaniline

Reference No.: 5722(94GGL)

J. Chem. Soc., Faraday Trans., 1994, 90, 315 - 320; Gans P; Gill JB; Longdon PJ; Spectrochemistry of Solutions. Part 26. Alkali-metal and Alkaline-earth-metal Thiocyanates in Dimethylformamide and Acetonitrile Solutions: Hot Bands, Stability Constants and Thermicity for the Formation of Inner- and Outer-sphere Ion Pairs

Reference No.: 5748(62JoS)

J. Chem. Soc., 1962,, 306 - 311; Jones RH; Stock DI; The Dissociation Constants in Water of Some Bivalent Metal Alkanedicarboxylates

Reference No.: 5977(72RDC)

J. Neurochem., 1972, 19, 1099 Rajan KS; Davis JM; Colburn RW; Jarke FH

Reference No.: 5987(97LPP)

Pure Appl. Chem., 1997, 69, 329 - 381; Lajunen LHJ; Portanova R; Piispanen J; Tolazzi M; Stability Constants for alpha-Hydroxycarboxylic Acid Complexes with Protons and

Metal Ions and the Accompanying Enthalpy Changes. Part I: Aromatic ortho-Hydroxycarboxylic Acids

Reference No.: 5989(95DDG)

Environ. Toxicol. Chem., 1995, 14, 767 - 773; Demianov P; De Stefano C; Gianguzza A; Sammartano S; Equilibrium Studies in Natural Waters: Speciation of Phenolic Compounds in Synthetic Seawater at Different Salinities

Reference No.: 6000(96YaO)

Pure Appl. Chem., 1996, 68, 469 - 496; Yamauchi O; Odani A; Stability Constants of Metal Complexes of Amino Acids with Charged Side Chains - Part I: Positively Charged Side Chains

Reference No.: 6024(52Alb)

Biochem. J., 1952, 50, 690 - 698; Albert A; Quantitative Studies of the Avidity of Naturally Occurring Substances for Trace Metals. 2. Amino-Acids having Three Ionizing Groups

Reference No.: 6055(64SiB)

Helv. Chim. Acta, 1964, 47, 1701 - 1717; Sigel H; Brintzinger H; Adenosin-5'-Monophosphat-N(1)-Oxid Ein (Ambivalentes) Ligandensystem

Reference No.: 6086(79FHT)

Eur. J. Biochem., 1979, 94, 523 - 530; Fischer BE; Haring UK; Tribolet R; Sigel H; Metal Ion/Buffer Interactions. Stability of Binary and Ternary Complexes Containing 2-Amino-2(hydroxymethyl)-1,3-Propanediol (Tris) and Adenosine 5'-Triphosphate (ATP)

Reference No.: 6089(80SAP)

Eur. J. Biochem., 1980, 107, 455 - 466; Scheller KH; Abel THJ; Polanyi PE; Wenk PK; Fischer BE; Sigel H; Metal Ion/Buffer Interactions. Stability of Binary and Ternary Complexes Containing 2-[Bis(2-Hydroxyethyl) Amino]-2(Hydroxymethyl)-1,3-Propanediol (BisTris) and Adenosine 5'-Triphosphate (ATP)

Reference No.: 6097(84SiS)

Eur. J. Biochem., 1984, 138, 291 - 299; Sigel H; Scheller KH; On the Metal-Ion Coordinating Properties of the 5'-Monophosphates of 1, N6-Ethenoadenosine (epsilon-AMP), Adenosine and Uridine. Comparison of the Macrochelate formation in the Complexes of epsilon-AMP, AMP, ADP and ATP

Reference No.: 6100(87Sig)

Eur. J. Biochem., 1987, 165, 65 - 72; Sigel H; Isomeric Equilibria in Complexes of Adenosine 5'-Triphosphate with Divalent Metal Ions. Solution Structures of M(ATP)-2 Complexes

Reference No.: 6104(89MaS)

Eur. J. Biochem., 1989, 179, 451 - 458; Massoud SS; Sigel H; Evaluation of the Metal-ion-coordinating Differences between the 2'-, 3'- and 5'-Monophosphates of Adenosine

Reference No.: 6105(89KTC)

Inorg. Chem., 1989, 28, 1480 - 1489; Kinjo Y; Tribolet R; Corfu NA; Sigel H; Stability and Structure of Xanthosine-Metal Ion Complexes in Aqueous Solution, Together with Intramolecular Adenosine-Metal Ion Equilibria

Reference No.: 6115(92KJC)

Inorg. Chem., 1992, 31, 5588 - 5596; Kinjo Y; Ji L-N; Corfu NA; Sigel H; Ambivalent Metal Ion Binding Properties of Cytidine in Aqueous Solution

Reference No.: 6118(95SFB)

Inorg. Chim. Acta, 1995, 235, 99 - 109; Song B; Feldmann G; Bastian M; Lippert B; Sigel H; Acid-base and Metal Ion-binding Properties of 2'-Deoxycytidine 5'-Monophosphate

(dCMP-2) Alone and Coordinated to cis-Diammine-Platinum(II). Formation of Mixed Metal Ion Nucleotide Complexes

Reference No.: 6124(93DFG)

Ann. Chim. (Rome), 1993, 83, 485 - 497; De Robertis A; Foti C; Gianguzza A; Studies on Polyfunctional O-Ligands. Alkali and Alkaline Earth Metal Complexes of Butanetetra-carboxylate in Aqueous Solution

Reference No.: 6125(93DGS)

Thermochim. Acta, 1993, 214, 325 - 338; De Stefano C; Gianguzza A; Sammartano S; Protonation Thermodynamics of 2,2'-Bipyridyl in Aqueous Solution. Salt Effects and Weak Complex Formation

Reference No.: 6128(95CDD)

Thermochim. Acta, 1995, 255, 109 - 141; Casale A; De Robertis A; De Stefano C; Gianguzza A; Patane G; Rigano C; Sammartano S; Thermodynamic Parameters for the Formation of Glycine Complexes with Magnesium(II), Calcium(II), Lead(II), Manganese(II), Cobalt(II), Nickel(II), Zinc(II) and Cadmium(II) at Different Temperatures and Ionic Strengths, with Particular Reference to Natural Fluid Conditions

Reference No.: 6131(95DFG)

Chem. Speciation Bioavail., 1995, 7, 1 - 8; De Stefano C; Foti C; Gianguzza A; Rigano C; Sammartano S; Chemical Speciation of Amino Acids in Electrolyte Solutions Containing Major Components of Natural Fluids

Reference No.: 6135(95BGE)

J. Chem. Soc., Dalton Trans., 1995,, 3353 - 3357; Brucher E; Gyori B; Emri J; Jakab S; Kovacs Z; Solymosi P; Toth I; Complexation Properties of 1,4,10,13-Tetraoxa-7,16-diazacyclo-octadecane-7-malonate, -7,16-bis(Malonate) and -7,16-bis (alpha-Methylacetate)

Reference No.: 6147(92CIP)

Ann. Chim. (Rome), 1992, 82, 121 - 135; Ciavatta L; Iuliano M; Porto R; Complex Formation Equilibria in Aqueous Iron(II) Orthophosphate Solutions

Reference No.: 6211(77RGS)

Geochim. Cosmochim. Acta, 1977, 41, 1193 - 1200; Riesen W; Gamsjager H; Schindler PW; Complex Formation in the Ternary System Mg(II)-CO₂-H₂O

Reference No.: 6218(87KoG)

Ber. Bunsenges. Phys. Chem., 1987, 91, 785 - 790; Konigsberger E; Gamsjager H; Solid-Solute Phase Equilibria in Aqueous Solution Solubility Constant and Free Enthalpy of Formation of Huntite

Reference No.: 6219(92KSG)

J. Solution Chem., 1992, 21, 1195 - 1216; Konigsberger E; Schmidt P; Gamsjager H; Solid-Solute Phase Equilibria in Aqueous Solution. VI. Solubilities, Complex Formation, and Ion-Interaction Parameters for the System Na⁺ - Mg²⁺ - ClO₄⁻ - CO₂ - H₂O at 25C

Reference No.: 6256(96BDP)

J. Chem. Soc., Dalton Trans., 1996,, 3071 - 3075; Brown PL; Drummond SE Jnr; Palmer DA; Hydrolysis of Magnesium(II) at Elevated Temperatures

Reference No.: 6265(83MiT)

J. Solution Chem., 1983, 12, 401 - 412; Millero FJ; Thurmond V; The Ionization of Carbonic Acid in Na-Mg-Cl Solutions at 25C

Reference No.: 6298(81FHP)

J. Solution Chem., 1981, 10, 523 - 532; Farmer RM; Heubel P-H C; Popov AI; Complexation Properties of Phosphonocarboxylic Acids in Aqueous Solutions

Reference No.: 6325(88Sad)

Mar. Chem., 1988, 23, 87 - 96; Sadiq M; Thermodynamic Solubility Relationships of Inorganic Vanadium in the Marine Environment

Reference No.: 6330(95LiF)

CRC Handbook of Chemistry and Physics, 76th Edn., 1995 Lide DR; Frederikse HPR; A Ready-Reference Book of Chemical and Physical Data; CRC Press, Cleveland, Ohio, U.S.A.

Reference No.: 6344(69GSK)

Chimia, 1969, 23, 229 - 230; Gamsjager H; Schindler P; Kleinert B; Potentiometrische Untersuchung der Komplexbildung im System Mg+2-F--H2O

Reference No.: 6347(75ScD)

C. R. Acad. Sci., Ser. C, 1975, 288, 1247 Schott J; Dandurand JL

Reference No.: 6350(74ReL)

Am. J. Sci., 1974, 274, 599 - 612; Reardon EJ; Langmuir D; Thermodynamic Properties of the Ion Pairs MgCO3 and CaCO3 from 10 to 50C

Reference No.: 6366(95KPW)

Geochim. Cosmochim. Acta, 1995, 59, 3843 - 3851; Kettler RM; Palmer DA; Wesolowski DJ; Comment on "Predictions of Diagenetic Reactions in the Presence of Organic Acids" by W.J.Harrison and D.G.Thyne

Reference No.: 6372(87BrW)

OECD NEA Report, 1987 Brown PL; Wanner H; Predicted Formation Constants Using the Unified Theory of Metal Ion Complexation; Nuclear Energy Authority, Paris

Reference No.: 6405(93MoH)

Principles and Applications of Aquatic Chemistry, 1993 Morel FMM; Hering JG; John Wiley & Sons, Inc

Reference No.: 6412(96SSJ)

J. Biol. Inorg. Chem., 1996, 1, 231 - 238; Saha A; Saha N; Ji L-N; Zhao J; Grogan F; Sajadi SAA; Song B; Sigel H; Stability of Metal Ion Complexes Formed with Methyl Phosphate and Hydrogen Phosphate

Reference No.: 6422(95BaP)

Thermochemical Data of Pure Substances, 3rd Edn., 1995 Barin I; Platzki G; Weinheim, Germany

Reference No.: 6426(97GSH)

Hydrothermal Reactions, Proc. 5th Int. Symp., 1997, 52 - 55; Giordano TH; Syracuse M; Hilton R; Boyers C; Calcium and Magnesium Acetate Complexing in Hydrothermal Solutions

Reference No.: 6428(97BWP)

Hydrothermal Reactions, Proc. 5th Int. Symp., 1997, 236 Brown PL; Wesolowski DJ; Palmer DA; The Hydrolysis of Magnesium(II) at Elevated Temperatures

Reference No.: 6437(97Sax)

Modelling in Aquatic Chemistry, 1997, 289 - 323; Saxena SP; Systematization and Estimation of Thermochemical Data on Silicates

Reference No.: 6472(75FSD)

Invest. Urol., 1975, 13, 20 Finlayson B; Smith A; DuBois L; The Stability Constants of Magnesium Oxalate Complexes

Reference No.: 6474(82BuF)

J. Urol., 1982, 128, 426 - 428; Burns JR; Finlayson B; Solubility Product of Magnesium Ammonium Phosphate Hexahydrate at Various Temperatures

Reference No.: 6478(81BaM)

Am. J. Sci., 1981, 281, 935 - 962; Baes CF Jr; Mesmer RE; The Thermodynamics of Cation Hydrolysis

Reference No.: 6482(88Ber)

J. Petrology, 1988, 29, 445 - 522; Berman RG; Internally-Consistent Thermodynamic Data for Minerals in the System Na₂O-K₂O-CaO-MgO-FeO-Fe₂O₃-Al₂O₃-SiO₂-TiO₂-H₂O-CO₂

Reference No.: 6488(88ShH)

Geochim. Cosmochim. Acta, 1988, 52, 2009 - 2036; Shock EL; Helgeson HC; Calculation of the Thermodynamic and Transport Properties of Aqueous Species at High Pressures and Temperatures: Correlation Algorithms for Ionic Species and Equation of State Predictions to 5 kb and 1000 C

Reference No.: 6494(95RoH)

U.S. Geol. Surv. Bull. 2131, 1995 Robie RA; Hemingway BS; Thermodynamic Properties of Minerals and Related Substances at 298.15 K and 1 Bar (10⁵ Pascals) Pressure and at Higher Temperatures; U.S. Government Printing Office, Washington, U.S.A

Reference No.: 6495(97SSH)

Geochim. Cosmochim. Acta, 1997, 61, 1359 - 1412; Sverjensky DA; Shock EL; Helgeson HC; Prediction of the Thermodynamic Properties of Aqueous Metal Complexes to 1000C and 5kb

Reference No.: 6496(96StM)

Aquatic Chemistry, 3rd Edn., 1996 Stumm W; Morgan JJ; Chemical Equilibria and Rates in Natural Waters; John Wiley & Sons, Inc., New York

Reference No.: 6500(52ChM)

J. Am. Chem. Soc., 1952, 74, 6228 - 6231; Chaberek S Jr; Martell AE; Stability of Metal Chelates. IV. N,N'-Ethylenediaminediacetic Acid and N,N'-Ethylenediamindiacetic-N,N'-dipropionic Acid

Reference No.: 6515(75MMM)

Inorg. Chem., 1975, 14, 468 - 473; MacMillan DT; Murase I; Martell AE; New Multidentate Ligands. XIV. Aqueous Coordination Chemistry of N,N'-Bis(2-hydroxybenzyl)ethylenediamine-N,N'-bis(methylphosphonic) Acid

Reference No.: 6627(81CVD)

J. Inorg. Nucl. Chem., 1981, 43, 1573 - 1578; Candida M; Vaz TA; da Silva JJRF; Thermodynamic Parameters for the Reactions of Uramildiacetic Acid with Transition Metal Ions

Reference No.: 6631(83LRN)

Anal. Biochem., 1983, 133, 492 - 501; Lance EA; Rhodes CW III; Nakon R; Free Metal Ion Depletion by "Goods" Buffers. III. N-(2-Acetamido)iminodiacetic Acid, 2:1 Complexes with Zinc(II), Cobalt(II), Nickel(II), and Copper(II); Amide Deprotonation by Zn(II), Co(II), and Cu(II)

Reference No.: 6659(95WRC)

Am. Mineral., 1995, 80, 355 - 360; Walling EM; Rock PA; Casey WH; The Gibbs Energy of Formation of Huntite, CaMg₃(CO₃)₄, at 298K and 1 bar from Electrochemical Cell Measurements

Reference No.: 6710(53LuM)

J. Phys. Chem., 1953, 57, 690 - 693; Lumb RF; Martell AE; Metal Chelating Tendencies of Glutamic and Aspartic Acids

Reference No.: 6759(49ScG)

Helv. Chim. Acta, 1949, 32, 1314 - 1325; Schwarzenbach G; Gysling H; Metallindikatoren. I. Murexid als Indikator auf Calcium- und andere Metall-Ionen. Komplexbildung und Lichtabsorption

Reference No.: 6833(67UhK)

J. Inorg. Nucl. Chem., 1967, 29, 1164 - 1168; Uhlig E; Krannich R; Stabilitätsmessungen an Metallchelaten vierzahliger Aminopolycarbonsäuren

Reference No.: 6845(62CoR)

Trans. Faraday Soc., 1962, 58, 2058 - 2065; Coates E; Rigg B; Complex Formation Solochrome Violet R. Part 4 - Some Metal-Dye Stability Constants

Reference No.: 6861(85MoM)

J. Coord. Chem., 1985, 14, 139 - 149; Motekaitis RJ; Martell AE; Metal Chelate Formation by N-Phosphonomethylglycine and Related Ligands

Reference No.: 6864(83SrK)

J. Coord. Chem., 1983, 12, 231 - 236; Sridharan R; Krishnamoorthy CR; Equilibrium Study on Binary Complexes of Cu(II), Ni(II), Co(II) and Mg(II) with Nucleic Acid Bases

Reference No.: 6868(78MoA)

J. Coord. Chem., 1978, 8, 175 - 182; Mohan MS; Abbott EH; Metal Complexes of Biologically Occurring Aminophosphonic Acids

Reference No.: 6908(76SaS)

Thermochim. Acta, 1976, 17, 325 - 328; Sandhu RS; Singh K; A Thermodynamic Study of the Complexation Reaction of Beryllium(II), Magnesium(II) and Calcium(II) with 3-Hydroxy-2-naphthoic Acid

Reference No.: 6927(84DFC)

Inorg. Chim. Acta, 1984, 90, 185 - 190; Delgado R; Frausto da Silva JJR; Candida M; Vaz TA; The Thermodynamics of Complex Formation of Cyclic Tetra-aza-tetracetic Acids

Reference No.: 6937(81And)

J. Coord. Chem., 1981, 11, 171 - 175; Anderegg G; Pyridine Derivatives as Complexing Agents. XII. Thermodynamics of Complex Formation with 2-Pyridylmethyl-iminodiacetic Acid and its 6-Methyl Substitute

Reference No.: 7000(69FlB)

J. Electroanal. Chem., 1969, 21, 157 - 167; Florence TM; Belew WL; Interpretation of the Polarographic Behaviour of Metal-Solochrome Violet RS Complexes

Reference No.: 7086(95WOI)

J. Solution Chem., 1995, 24, 989 - 1012; Wang P; Oscarson JL; Izatt RM; Watt GD; Larsen CD; Thermodynamic Parameters for the Interaction of Adenosine 5'-Diphosphate and Adenosine 5'-Triphosphate with Mg+2 from 323.15 to 398.15 K

Reference No.: 7090(96DFG)

J. Solution Chem., 1996, 25, 597 - 606; De Robertis A; Foti C; Gianguzza A; Rigano C; Protonation Thermodynamics of 1,10-Phenanthroline in Aqueous Solution. Salt Effects and Weak Complex Formation

Reference No.: 7168(97GaW)

Chem. Speciation Bioavail., 1997, 91, 37 Gangoda CK; Williams DR; Linear Free Energy Relationships and the Chemical Speciation of Amino-carboxylate Ligand Complexes

Reference No.: 7177(76ACP)

Mar. Chem., 1976, 4, 243 - 254; Atlas E; Culberson CH; Pytkowicz RM; Phosphate Association with Na⁺, Ca²⁺, and Mg²⁺ in Seawater

Reference No.: 7229(75ElW)

Mar. Chem., 1975, 3, 215 - 225; Elgquist B; Wedborg M; Stability of Ion Pairs from Gypsum Solubility Degree of Ion Pair Formation between the Major Constituents of Seawater

Reference No.: 7242(68Tru)

J. Geol. Educ., 1968, 16, 17 - 20; Truesdell AH; The Advantage of Using pE Rather than Eh in Redox Equilibrium Calculations

Reference No.: 7271(98SMM)

NIST Critical Stability Constants of Metal Complexes Database, 1998 Smith RM; Martell AE; Motekaitis RJ; Version 5.0; U.S. Dept. Commerce, Gaithersburg, MD, U.S.A.

Reference No.: 7273(84HiJ)

Dictionary of Electrochemistry, 2nd Edn., 1984 Hibbert DB; James AM; Macmillan Press, London, U.K.

Reference No.: 7275(98Atk)

Physical Chemistry, 6th Edn., 1998 Atkins PW; Oxford University Press, Oxford, U.K.

Reference No.: 7276(88CoW)

Advanced Inorganic Chemistry, 5th Edn., 1988 Cotton FA; Wilkinson G; John Wiley & Sons Inc., N.Y., U.S.A

Reference No.: 7321(97PaW)

J. Solution Chem., 1997, 26, 217 - 232; Palmer DA; Wesolowski DJ; Potentiometric Measurements of the First Hydrolysis Quotient of Magnesium(II) to 250C and 5 Molal Ionic Strength (NaCl)

Reference No.: 7362(97KMR)

Talanta, 1997, 44, 1365 - 1369; Khalil MM; Mohamed SA; Radalla AM; Potentiometric and Conductometric Studies on the Binary and Mixed Ligand Complexes in Solution: M(II)-Dipicolinic Acid-Glycine Systems

Reference No.: 7372(78BDJ)

Vogel's Textbook of Quantitative Inorganic Analysis, 1978 Bassett J; Denney RC; Jeffery GH; Mendham J; including Elementary Instrumental Analysis; Longman, London, U.K.

Reference No.: 7373(96WBF)

Water Resources Res., 1996, 32, 3173 - 3187; Wunderly MD; Blowes DW; Frind EO; Ptacek CJ; Sulfide Mineral Oxidation and Subsequent Reactive Transport of Oxidation Products in Mine Tailings Impoundments: A Numerical Model

Reference No.: 7381(97Woo)

Physical Chemistry, 1997 Woodbury G; Brooks/Cole Publishing Co., Pacific Grove, U.S.A.

Reference No.: 7391(82MiS)

Am. J. Sci., 1982, 282, 1508 - 1540; Millero FJ; Schreiber DR; Use of the Ion Pairing Model to Estimate Activity Coefficients of the Ionic Components of Natural Waters

Reference No.: 7397(79FiF)

J. Solution Chem., 1979, 8, 309 - 328; Fisher FH; Fox AP; Divalent Sulfate Ion Pairs in Aqueous Solutions at Pressures up to 2000 atm

Reference No.: 7421(97Mar)

Ion Properties, 1997 Marcus Y; Marcel Dekker Inc., New York, U.S.A.

Reference No.: 7645(70Lar)

J. Phys. Chem., 1970, 74, 3392 - 3396; Larson JW; Thermodynamics of Divalent Metal Sulfate Dissociation and the Structure of the Solvated Metal Sulfate Ion Pair

Reference No.: 7694(84IPZ)

Russ. J. Inorg. Chem., 1984, 29, 860 - 862; Ivanov-Emin BN; Petrishcheva LP; Zaitsev BE; Izmailovich AS; Hydroxo-compounds of Copper(II)

Reference No.: 7703(03PLT)

Pure Appl. Chem., 2003, 75, 495 - 540; Portanova R; Lajunen LHJ; Tolazzi M; Piispanen J; Stability Constants for alpha-Hydroxycarboxylic Acid Complexes with Protons and Metal Ions and the Accompanying Enthalpy Changes - Part II: Aliphatic 2-Hydroxycarboxylic Acids

Reference No.: 7761(89Bra)

J. Phys. Chem. Ref. Data, 1989, 18, 1 - 21; Bratsch SG; Standard Electrode Potentials and Temperature Coefficients in Water at 298.15 K

Reference No.: 7927(51BAR)

J. Am. Chem. Soc., 1951, 73, 3785 - 3788; Barney JE II; Argersinger WJ Jr; Reynolds CA; A Study of Some Complex Chlorides and Oxalates by Solubility Measurements

Reference No.: 8309(99BSH)

J. Chem. Soc., Dalton Trans., 1999,, 3661 - 3671; Blindauer CA; Sjastad TI; Holy A; Sletten E; Sigel H; Aspects of the Co-ordination Chemistry of the Antiviral Nucleotide Analogue, 9-[2-(Phosphonomethoxy)ethyl]-2,6-diaminopurine (PMEDAP)

Reference No.: 8385(85LDM)

Bull. Soc. Chim. Fr., 1985,, 638 - 643; Le Guyader M; Dorange G; Marchand A; Solubilité de la Calcite et Constantes de Stabilité d'Ions Complexes. II. Influence de la Mineralisation

Reference No.: 8389(75Tam)

Bull. Chem. Soc. Jpn., 1975, 48, 705 - 706; Tamamushi R; A Method of Determining the Degree of Dissociation of Symmetrical Associated Electrolytes from Conductivity and Activity Data

Reference No.: 8390(73Kat)

Bull. Chem. Soc. Jpn., 1973, 46, 106 - 109; Katayama S; Conductometric Determination of Ion-association Constants for Magnesium and Nickel Sulphates in Aqueous Solutions at Various Temperatures between 0 C and 45 C

Reference No.: 8391(80ELA)

Bull. Soc. Chim. Fr., 1980,, I-173 - I-180; Emara MM; Lin C-T; Atkinson G; The Spectrophotometric and Ion-selective Electrode Determination of MgSO₄ Association at High Ionic Strengths.

Reference No.: 8394(58NaN)

J. Chem. Soc., 1958,, 3706 - 3711; Nair VSK; Nancollas GH; Thermodynamics of Ion Association. Part IV. Magnesium and Zinc Sulphates

Reference No.: 8397(67Mar)

J. Phys. Chem., 1967, 71, 3584 - 3588; Marshall WL; Aqueous Systems at High Temperature. XX. The Dissociation Constant and Thermodynamic Functions for Magnesium Sulfate to 200 C

Reference No.: 8402(69IEC)

J. Chem. Soc. (A), 1969,, 47 - 53; Izatt RM; Eatough DJ; Christensen JJ; Bartholomew CH; Calorimetrically Determined Log K, ΔH , and ΔS Values for the Interaction of Sulphate Ion with Several Bi- and Ter-valent Metal Ions

Reference No.: 8497(57JoA)

Anal. Chem., 1957, 29, 9 - 13; Jordan J; Alleman TG; Thermochemical Titrations. Enthalpy Titrations

Reference No.: 8618(66AtP)

J. Phys. Chem., 1966, 70, 3122 - 3128; Atkinson G; Petrucci S; Ion Association of Magnesium Sulfate in Water at 25 C

Reference No.: 8626(70Nor)

Acta Chem. Scand., 1970, 24, 3276 - 3286; Norby JG; Stability Constants of Mg-Complexes with ATP, Phosphoenolpyruvate, and Sulphate

Reference No.: 8631(70KeP)

Geochim. Cosmochim. Acta, 1970, 34, 1039 - 1051; Kester DR; Pytkowicz RM; Effect of Temperature and Pressure on Sulfate Ion Association in Sea Water.

Reference No.: 8636(55BrP)

Proc. R. Soc. London Ser. A, 1955, 232, 320 - 336; Brown PGM; Prue JE; A Study of Ionic Association in Aqueous Solutions of Bi-valent Electrolytes by Freezing-point Measurements

Reference No.: 8640(68KeP)

Limnol. Oceanogr., 1968, 13, 670 - 674; Kester DR; Pytkowicz RM; Magnesium Sulfate Association at 25C in Synthetic Seawater

Reference No.: 8647(77KGN)

Zh. Neorg. Khim., 1977, 22, 1210 - 662; Kul'ba FYa; Gavryuchenkov FG; Nikolaeva SA; Reshetnikova ZV; Complexes Formed by Magnesium with Phosphato-, Sulphato-, and Fluoro-Ligands

Reference No.: 8670(32MoD)

Trans. Faraday Soc., 1932, 28, 609 - 614; Money RW; Davies CW; The Extent of Dissociation of Salts in Water. Part IV. Bi-Bivalent Salts

Reference No.: 8672(75MVK)

Dokl. Akad. Nauk SSSR, 1975,, 862 - 865; Martynova OI; Vasina LG; Krotova IS; Determination of the Dissociation Constant of Magnesium Sulfate ($MgSO_4$) Ion Pair at 25-90C

Reference No.: 8675(72Pit)

J. Chem. Soc., Faraday Trans. 2, 1972, 68, 101 - 113; Pitzer KS; Thermodynamic Properties of Aqueous Solutions of Bivalent Sulphates

Reference No.: 8681(87DRS)

Thermochim. Acta, 1987, 115, 241 - 248; De Robertis A; Rigano C; Sammartano S; Zerbinati O; Ion Association of Cl^- with Na^+ , K^+ , Mg^{2+} and Ca^{2+} in Aqueous Solutions at $10 < T < 45$ C and $0 < I < 1$ mol L⁻¹ . A Literature Data Analysis

Reference No.: 8692(77Fin)

Calcium Metabolism in Renal Failure and Nephrolithiasis, 1977, 337 - 382; Finlayson B; Calcium Stones: Some Physical and Clinical Aspects

Reference No.: 8695(00KlR)

Chemical Thermodynamics, 6th Edn., 2000 Klotz IM; Rosenberg RM; Basic Theory and Methods; John Wiley & Sons, N.Y., U.S.A.

Reference No.: 8739(99KKG)

Geochim. Cosmochim. Acta, 1999, 63, 3105 - 3119; Konigsberger E; Konigsberger L-C; Gamsjager H; Low-temperature Thermodynamic Model for the System Na₂CO₃-MgCO₃-CaCO₃-H₂O

Reference No.: 8746(89CWM)

CODATA Key Values for Thermodynamics, 1989 Cox JD; Wagman DD; Medvedev VA; Values obtained from www.codata.org/codata/databases Apr. 2000 and <http://www.codata.org/resources/databases/key1.html> Sept. 2011; Hemisphere Publishing Corp., N.Y., U.S.A.

Reference No.: 8749(98MiP)

Aquat. Geochem., 1998, 4, 153 - 199; Millero FJ; Pierrot D; A Chemical Equilibrium Model for Natural Waters

Reference No.: 8833(80HaW)

Geochim. Cosmochim. Acta, 1980, 44, 981 - 997; Harvie CE; Weare JH; The Prediction of Mineral Solubilities in Natural Waters: The Na-K-Mg-Ca-Cl-SO₄-H₂O System from Zero to High Concentration at 25C

Reference No.: 8875(81HKF)

Am. J. Sci., 1981, 281, 1249 - 1516; Helgeson HC; Kirkham DH; Flowers GC; Theoretical Prediction of the Thermodynamic Behavior of Aqueous Electrolytes at High Pressures and Temperatures. IV. Calculation of Activity Coefficients, Osmotic Coefficients and Apparent Molal and Standard and Relative Partial Molal Properties to 600 C and 5 Kb

Reference No.: 8888(93ShK)

Geochim. Cosmochim. Acta, 1993, 57, 4899 - 4922; Shock EL; Koretsky CM; Metal-organic Complexes in Geochemical Processes: Calculation of Standard Partial Molal Thermodynamic Properties of Aqueous Acetate Complexes at High Pressures and Temperatures

Reference No.: 8898(78JoP)

Am. J. Sci., 1978, 278, 1428 - 1447; Johnson KS; Pytkowicz RM; Ion Association of Cl⁻ with H⁺, Na⁺, K⁺, Ca²⁺, and Mg²⁺ in Aqueous Solutions at 25C

Reference No.: 9023(77SiH)

Am. J. Sci., 1977, 277, 697 - 715; Siebert RM; Hostetler PB; The Stability of the Magnesium Bicarbonate Ion Pair from 10 to 90C

Reference No.: 9024(77SiH)

Am. J. Sci., 1977, 277, 716 - 734; Siebert RM; Hostetler PB; The Stability of the Magnesium Carbonate Ion Pair from 10 to 90C

Reference No.: 9029(97SSW)

Geochim. Cosmochim. Acta, 1997, 61, 907 - 950; Shock EL; Sassani DC; Willis M; Sverjensky DA; Inorganic Species in Geologic Fluids: Correlations among Standard Molal Thermodynamic Properties of Aqueous Ions and Hydroxide Complexes

Reference No.: 9073(84HMW)

Geochim. Cosmochim. Acta, 1984, 48, 723 - 751; Harvie CE; Moller N; Weare JH; The Prediction of Mineral Solubilities in Natural Waters: The Na-K-Mg-Ca-H-Cl-SO₄-OH-HCO₃-CO₃-CO₂-H₂O System to High Ionic Strengths at 25C

Reference No.: 9387(01KHM)

J. Solution Chem., 2001, 30, 19 - 29; Kratsis S; Hefter G; May PM; Potentiometric Study of the Association of Magnesium and Sulfate Ions at 25C in High Ionic Strength Media

Reference No.: 9402(86Wan)

EIR-Bericht Nr. 589, 1986 Wanner H; Modelling Interaction of Deep Groundwaters with Bentonite and Radionuclide Speciation; Swiss Federal Institute for Reactor Research, Wurenlingen, Suisse

Reference No.: 9424(82ADR)

Ann. Chim. (Rome), 1982, 72, 1 - 24; Amico P; Daniele PG; Rigano C; Sammartano S; Stability of Calcium and Magnesium Citrate Complexes in Aqueous Solution

Reference No.: 9667(96BoF)

Ann. Chim. (Rome), 1996, 86, 133 - 142; Bottari E; Festa MR; The Behavior of Asparagine as a Ligand for Cations

Reference No.: 9683(82BoP)

Monatsh. Chem., 1982, 113, 1245 - 1252; Bottari E; Porto R; Complex Formation between Glycine and Magnesium(II), Calcium(II), and Iron(II) at 25C in 3.00 M Sodium Perchlorate

Reference No.: 9902(94CIP)

Ann. Chim. (Rome), 1994, 84, 95 - 112; Ciavatta L; Iuliano M; Porto R; Complex Formation Equilibria in Magnesium Orthophosphate Aqueous Solutions

Reference No.: 9919(74Cia)

Ann. Chim. (Rome), 1974, 64, 667 - 683; Ciavatta L; Equilibriums in the Iron(III)-Phosphoric Acid System

Reference No.: 9983(82DRS)

Ann. Chim. (Rome), 1982, 72, 341 - 353; Daniele PG; Rigano C; Sammartano S; Formation and Stability of Calcium- and Magnesium-Phosphate Complexes in Aqueous Solution at 37C. A Potentiometric Investigation by Glass and Calcium Ion-Selective Electrodes in the Ionic Strength Range $0.03 < I < 0.5$

Reference No.: 10174(95OHS)

J. Phys. Chem. Ref. Data, 1995, 24, 1401 - 1560; Oelkers EH; Helgeson HC; Shock EL; Sverjensky DA; Johnson JW; Pokrovskii VA; Summary of the Apparent Standard Partial Molal Gibbs Free Energies of Formation of Aqueous Species, Minerals, and Gases at Pressures 1 to 5000 Bars and Temperatures 25 to 1000C

Reference No.: 11516(00PeP)

IUPAC Stability Constants Database, 2000 Pettit LD; Powell HKJ; Release 4; Academic Software, U.K.

Reference No.: 11762(77Kat)

Rikagaku Kenkyusho Hokoku, 1977, 53, 212 - 238; Katayama S; Conductimetric Study of the Ion Association in Aqueous Solutions

Reference No.: 11763(81YoY)

Bull. Chem. Soc. Jpn., 1981, 54, 2286 - 2289; Yokoyama H; Yamatera H; Ion Association of Some 2:2 Electrolytes in Water at 25C. III. A New Interpretation of Experimental Results and the Determination of Formation Constants of Inner-sphere Ion-pairs

Reference No.: 11928(41OwB)

Chem. Rev., 1941, 29, 461 - 474; Owen BB; Brinkley SR Jr; Calculation of the Effect of Pressure upon Ionic Equilibria in Pure Water and in Salt Solutions

Reference No.: 11989(58HaO)

The Physical Chemistry of Electrolytic Solutions, 3rd Edn., 1958 Harned HS; Owen BB; American Chemical Society Monograph Series No: 137; Reinhold Publishing Corp., N.Y.

Reference No.: 12002(59RoS)

Electrolyte Solutions, 2nd Rev. Edn., 1959 Robinson RA; Stokes RH; An Unabridged Re-publication of the Fifth Impression of the Second Revised Edition of the Work Originally Published in 1970 with New Preface Specially Prepared by Dr. Stokes; Dover Publications, N.Y., USA (previously Butterworth & Co., London)

Reference No.: 12227(75SCH)

Collect. Czech. Chem. Commun., 1975, 40, 2020 - 2024; Sucha L; Cadek J; Hrabek K; Vesely J; The Stability of the Chloro Complexes of Magnesium and of the Alkaline Earth Metals at Elevated Temperatures

Reference No.: 12547(98SBB)

J. Phys. Chem., 1998, B102, 4411 - 4417; Simonin J-P; Bernard O; Blum L; Real Ionic Solutions in the Mean Spherical Approximation. 3. Osmotic and Activity Coefficients for Associating Electrolytes in the Primitive Model

Reference No.: 12584(00KKH)

Aquat. Geochem., 2000, 6, 147 - 199; Kulik DA; Kersten M; Heiser U; Neumann T; Application of Gibbs Energy Minimization to Model Early-Diagenetic Solid-Solution Aqueous-Solution Equilibria Involving Authigenic Rhodochrosites in Anoxic Baltic Sea Sediments

Reference No.: 12628(01OGC)

J. Solution Chem., 2001, 30, 31 - 53; Oscarson JL; Gillespie SE; Chen X; Schuck PC; Izatt RM; Enthalpies of Dilution of Aqueous Solutions of HCl, MgCl₂, CaCl₂, and BaCl₂ at 300, 325, and 350C

Reference No.: 12632(82GEE)

Wiss. Z. Wilhelm-Pieck-Univ. Rostock, Naturwiss. Reihe, 1982, 31, 15 - 24; Grigo M; Einfeldt J; Ebeling W; Ion Association of Electrolytic Solutions

Reference No.: 12638(99TPG)

GAMSPATH Users Manual, 1999 Talman SJ; Perkins EH; Gunter WD; A Reaction Path - Mass Transfer Program

Reference No.: 12843(01Ste)

Chem. Geol., 2001, 172, 225 - 250; Stefansson A; Dissolution of Primary Minerals of Basalt in Natural Waters. I. Calculation of Mineral Solubilities from 0C to 350C

Reference No.: 12931(01SPG)

Chem. Geol., 2001, 171, 173 - 194; Seby F; Potin-Gautier M; Giffaut E; Borge G; Donard OFX; A Critical Review of Thermodynamic Data for Selenium Species at 25C

Reference No.: 12941(00FoG)

Talanta, 2000, 53, 617 - 626; Fovet Y; Gal J-Y; Formation Constants beta₂ of Calcium and Magnesium Fluorides at 25C

Reference No.: 13242(05AAD)

Pure Appl. Chem., 2005, 77, 1445 - 1495; Anderegg G; Arnaud-Neu F; Delgado R; Felcman J; Popov K; Critical Evaluation of Stability Constants of Metal Complexes of Complexones for Biomedical and Environmental Applications

Reference No.: 13297(03ADC)

Pure Appl. Chem., 2003, 75, 71 - 102; Arnaud-Neu F; Delgado R; Chaves S; Critical Evaluation of Stability Constants and Thermodynamic Functions of Metal Complexes of Crown-ethers

Reference No.: 13532(78Ian)

Geochim. Cosmochim. Acta, 1978, 42, 547 - 569; Langmuir D; Uranium Solution-Mineral Equilibria at Low Temperatures with Applications to Sedimentary Ore Deposits

Reference No.: 14335(93BCV)

J. Solution Chem., 1993, 22, 173 - 181; Balarew C; Christov C; Valyashko V; Petrenko S; Thermodynamics of Formation of Carnallite Type Double Salts

Reference No.: 14764(64StS)

Solubilities of Inorganic and Organic Compounds, Vol. 2, Part 2, 1964 Stephen H; Stephen T; Ternary and Multicomponent Systems, Part 2; Pergamon Press, The Macmillan Company, New York, 1964

Reference No.: 14923(05ONO)

OECD Chemical Thermodynamics Series, Volume 7, 2005 Olin A; Nolang B; Ohman L-O; Osadchii EG; Rosen E; Chemical Thermodynamics of Selenium

Reference No.: 16058(00KhA)

J. Chem. Eng. Data, 2000, 45, 1108 - 1111; Khalil MM; Attia AE; Potentiometric Studies on the Formation Equilibria of Binary and Ternary Complexes of Some Metal Ions with Dipicolinic Acid and Amino Acids

Reference No.: 16285(95ReK)

J. Chem. Eng. Data, 1995, 40, 1091 - 1093; Ren H; Kratochvil B; Determination of the Thermodynamic Stability Constant of the Magnesium Complex of Malonic Acid by Using an Ion-Exchange/ Inductively Coupled Plasma Atomic Emission Spectroscopy Method

Reference No.: 16935(98OYS)

Water Res., 1998, 32, 3607 - 3614; Ohlinger KN; Young TM; Schroeder ED; Predicting Struvite Formation in Digestion

Reference No.: 16981(11OrB)

Russ. J. Inorg. Chem., 2011, 56, 975 - 980; Orlov YF; Belkina EI; Correlations between the Stability Constants of Metal Hydroxo Complexes and the Solubility Products of Crystalline Hydroxides. Series of the Polarizing Effect of Metal Cations

Reference No.: 17019(71Iso)

Sci. Pap. Inst. Phys. Chem. Res. (Jpn), 1971, 65, 95 - 99; Isono T; Osmotic Coefficients, Stoichiometric Activity Coefficients, and Dissociation Constants of Magnesium and Nickel Sulfates in Aqueous Solutions at the Freezing-point

Reference No.: 17698(04AAS)

J. Chem. Eng. Data, 2004, 49, 62 - 72; Azab HA; Anwar ZM; Sokar M; Metal Ion Complexes Containing Nucleobases and Some Zwitterionic Buffers

Reference No.: 17838(03AMN)

Geochim. Cosmochim. Acta, 2003, 67, 3595 - 3601; Altmaier M; Metz V; Neck V; Muller R; Fanghanel T; Solid-liquid Equilibria of $\text{Mg}(\text{OH})_2(\text{cr})$ and $\text{Mg}_2(\text{OH})_3\text{Cl} \cdot 4\text{H}_2\text{O}(\text{cr})$ in the System Mg-Na-H-OH-Cl-H₂O at 25C

Reference No.: 18180(01RMC)

Am. J. Sci., 2001, 301, 103 - 111; Rock PA; Mandell GK; Casey WH; Walling EM; Gibbs Energy of Formation of Dolomite from Electrochemical Cell Measurements and Theoretical Calculations

Reference No.: 18273(57Dav)

Discuss. Faraday Soc., 1957, 24, 83 - 86; Davies CW; Incomplete Dissociation. Introductory Paper

Reference No.: 18276(57Nan)

Discuss. Faraday Soc., 1957, 24, 108 - 113; Nancollas GH; Thermodynamics of Ion Association

Reference No.: 19653(48ScB)

Helv. Chim. Acta, 1948, 31, 678 - 687; Schwarzenbach G; Biedermann W; Complexons. X. Alkaline Earth Complexes of o,o-dihydroxy Azo Dyes

Reference No.: 20368(61Wal)

J. Phys. Chem., 1961, 65, 159 - 161; Walser M; Ion Association. V. Dissociation Constants for Complexes of Citrate with Sodium, Potassium, Calcium, and Magnesium Ions

Reference No.: 20827(03GFF)

OECD Chemical Thermodynamics Series, Volume 5, 2003 Guillaumont R; Fanghanel T; Fuger J; Grenthe I; Neck V; Palmer DA; Rand MH; Update on the Chemical Thermodynamics of Uranium, Neptunium, Plutonium, Americium and Technetium; Elsevier Science

Reference No.: 20830(05HAP)

OECD Chemical Thermodynamics Series, Volume 9, 2005 Hummel W; Anderegg G; Puigdomenech I; Rao L; Tochiyama O; Chemical Thermodynamics of Compounds and Complexes of U, Np, Pu, Am, Tc, Se, Ni and Zr with Selected Organic Ligands; Elsevier Science

Reference No.: 20981(06MiP)

Talanta, 2006, 68, 594 - 601; Michalowski T; Pietrzyk A; A Thermodynamic Study of Struvite + Water System

Reference No.: 21108(06SMM)

Mar. Chem., 2006, 99, 52 - 61; Sharma VK; Moulin A; Millero FJ; De Stefano C; Dissociation Constants of Protonated Cysteine Species in Seawater Media

Reference No.: 21336(52EvM)

Trans. Faraday Soc., 1952, 48, 934 - 937; Evans JI; Monk CB; E.m.f. Studies of Electrolytic Dissociation. III. Magnesium Malonate in Water

Reference No.: 21342(51Mon)

Trans. Faraday Soc., 1951, 47, 1233 - 1240; Monk CB; Electrolytes in Solutions of Amino Acids. V. Solubilities of Calcium, Barium, and Lanthanum Iodates in Glycine, Alanine, and Glycylglycine

Reference No.: 21442(05BBP)

J. Mol. Liq., 2005, 118, 111 - 118; Bester-Rogac M; Babic V; Perger TM; Neueder R; Barthel J; Conductometric Study of Ion Association of Divalent Symmetric Electrolytes: I. CoSO₄, NiSO₄ and ZnSO₄ in Water

Reference No.: 22388(09Ber)

Private Communication, 2009 Berthon G; Toulouse Blood Plasma Database

Reference No.: 22551(06Inz)

Encyclopedia of Electrochemistry, Vol. 7a, 2006, 17 - 75; Inzelt G; Standard, Formal and Other Characteristic Potentials of Selected Electrode Reactions

Reference No.: 22560(05PeP)

IUPAC Stability Constants Database, 2005 Pettit LD; Powell HKJ; Release 4.71; Academic Software, U.K.

Reference No.: 22612(93GML)

Anal. Chim. Acta, 1993, 273, 493 - 497; Glab S; Maj-Zurawska M; Lukomski P; Hulanicki A; Ion-selective Electrode Control Based on Coulometrically Determined Stability Constants of Biologically Important Calcium and Magnesium Complexes

Reference No.: 22958(10AML)

Appl. Geochem., 2010, 25, 242 - 260; Accornero M; Marini L; Lelli M; Prediction of the Thermodynamic Properties of Metal-chromate Aqueous Complexes to High Temperatures and

Pressures and Implications for the Speciation of Hexavalent Chromium in Some Natural Waters

Reference No.: 22971(71HWH)

Chem. Rev., 1971, 71, 127 - 137; Hill JO; Worsley IG; Hepler LG; Thermochemistry and Oxidation Potentials of Vanadium, Niobium and Tantalum

Reference No.: 23089(09DFL)

Pure Appl. Chem., 2009, 81, 1547 - 1553; Diemar GA; Filella M; Leverett P; Williams PA; Dispersion of Antimony from Oxidizing Ore Deposits

Reference No.: 23134(10TPD)

J. Solution Chem., 2010, 39, 1 - 10; Torres J; Pintos V; Dominguez S; Kremer C; Kremer E; Selenite and Selenate Speciation in Natural Waters: Interaction with Divalent Metal Ions

Reference No.: 23192(08Xio)

Aquat. Geochem., 2008, 14, 223 - 238; Xiong Y; Thermodynamic Properties of Brucite Determined by Solubility Studies and Their Significance to Nuclear Waste Isolation

Reference No.: 23205(09SDK)

Appl. Geochem., 2009, 24, 1287 - 1300; Shao H; Dmytrieva SV; Kolditz O; Kulik DA; Pfingsten W; Kosakowski G; Modeling Reactive Transport in Non-ideal Aqueous-solid Solution System

Reference No.: 23288(08Hac)

J. Solution Chem., 2008, 37, 155 - 163; Hacht B; Complex Formation of Acetic Acid with Ca(II) and Mg(II) Under Physiological Conditions

Reference No.: 23739(11MaT)

J. Chem. Eng. Data, 2011, 56, 889 - 898; Madekufamba M; Tremaine PR; Ion Association in Dilute Aqueous Magnesium Sulfate and Nickel Sulfate Solutions Under Hydrothermal Conditions by Flow Conductivity Measurements

Reference No.: 24003(10Bal)

Collect. Czech. Chem. Commun., 2010, 75, 21 - 31; Balej J; Verification of Accuracy of Standard Thermodynamic Data of Inorganic Substances

Reference No.: 24235(79RHF)

U.S. Geol. Surv. Bull. 1452 (corrected edition), 1979 Robie RA; Hemingway BS; Fisher JR; Thermodynamic Properties of Minerals and Related Substances at 298.15K and 1 bar (10⁵ Pascals) Pressure and at Higher Temperatures; US Govt Printing Office, Washington

Reference No.: 24835(12SMM)

J. Chem. Eng. Data, 2012, 57, 1637 - 1647; Scharge T; Munoz AG; Moog HC; Activity Coefficients of Fission Products in Highly Salinary Solutions of Na⁺, K⁺, Mg²⁺, Ca²⁺, Cl⁻, and SO₄²⁻: Cs⁺

Reference No.: 24953(85PPS)

Report LBL-14996, 1985 Phillips SL; Phillips CA; Skeen J; Hydrolysis, Formation and Ionization Constants at 25C, and at High Temperature - High Ionic Strength; Lawrence Berkeley Laboratory, Univ. California, U.S.A.

Reference No.: 25435(12ASJ)

Chem. Geol., 2012, 304-305, 26 - 38; Aradottir ESP; Sonnenthal EL; Jonsson H; Development and Evaluation of a Thermodynamic Dataset for Phases of Interest in CO₂ Mineral Sequestration in Basaltic Rocks

Reference No.: 25849(75MVK)

Dokl. Akad. Nauk SSSR, 1975, 225, 862 - 865; Martynova OI; Vasina LG; Krotova IS; Determination of the Dissociation Constant of the MgSO_4 Ion Pairs in the Temperature Range from 25 to 90C

Reference No.: 26071(11BSD)

Chem. Geol., 2011, 286, 21 - 31; Benezeth P; Saldi GD; Dandurand JL; Schott J; Experimental Determination of the Solubility Product of Magnesite at 50 to 200 C

Reference No.: 26086(18BBB)

Geochim. Cosmochim. Acta, 2018, 224, 262 - 275; Benezeth P; Berninger U-N; Bovet N; Schott J; Oelkers EH; Experimental Determination of the Solubility Product of Dolomite at 50-253 C

Reference No.: 26477(14GBM)

Geochim. Cosmochim. Acta, 2014, 138, 1 - 20; Gautier Q; Benezeth P; Mavromatis V; Schott J; Hydromagnesite Solubility Product and Growth Kinetics in Aqueous Solution from 25 to 75 C

Reference No.: 26555(12WaL)

Ind. Eng. Chem. Res., 2012, 51, 16299 - 16310; Wang D; Li Z; Gas-Liquid Reactive Crystallization Kinetics of Hydromagnesite in the $\text{MgCl}_2\text{-CO}_2\text{-NH}_3\text{-H}_2\text{O}$ System: Its Potential in CO_2 Sequestration

Reference No.: 26565(13SMM)

J. Chem. Eng. Data, 2013, 58, 187 - 188; Scharge T; Munoz AG; Moog HC; Addition to "Activity Coefficients of Fission Products in Highly Salinary Solutionsof Na^+ , K^+ , Mg^{2+} , Ca^{2+} , Cl^- , and SO_4^{2-} Cs^+ "

Reference No.: 27114(14SBS)

Geochim. Cosmochim. Acta, 2014, 138, 21 - 31; Stefansson A; Benezeth P; Schott J; Potentiometric and Spectrophotometric Study of the Stability of Magnesium Carbonate and Bicarbonate Ion Pairs to 150 C and Aqueous Inorganic Carbon Speciation and Magnesite Solubility

Reference No.: 27205(11Xio)

Chem. Geol., 2011, 284, 262 - 269; Xiong Y; Experimental Determination of Solubility Constant of Hydromagnesite (5424) in NaCl Solutions up to 4.4 m at Room Temperature

Reference No.: 27292(13LBM)

OECD Chemical Thermodynamics Series, Volume 13a, 2013 Lemire RJ; Berner U; Musikas C; Palmer DA; Taylor P; Tochiyama O; Chemical Thermodynamics of Iron Part 1; OECD (NEA) Issy-les-Moulineaux, France

Reference No.: 27392(15VRA)

Appl. Geochem., 2015, 55, 192 - 198; Vercouter T; Reiller PE; Ansoborlo E; Fevrier L; Gilbin R; Lomenech C; Philippini V; A Modelling Exercise on the Importance of Ternary Alkaline Earth Carbonate Species of Uranium(VI) in the Inorganic Speciation of Natural Waters

Reference No.: 27463(15HSZ)

Fluid Phase Equilib., 2015, 392, 127 - 131; Hu J; Sang S-H; Zhou M-F; Huang W-Y; Phase Equilibria in the Ternary Systems $\text{KBr-MgBr}_2\text{-H}_2\text{O}$ and $\text{NaBr-MgBr}_2\text{-H}_2\text{O}$ at 348.15 K

Reference No.: 28080(82HAC)

J. Chem. Soc., Faraday Trans. 1, 1982, 78, 2455 - 2466; Hsieh A-K; Ang K-P; Chang M; Conductance of Calcium Sulphate and Magnesium Sulphate in Aqueous Solution at High Pressure

Reference No.: 28172(15DCC)

J. Chem. Eng. Data, 2015, 60, 3792 - 3799; Djamali E; Chapman WG; Cox KR; Prediction of the Standard State Partial Molar Volume of Aqueous Electrolytes to High Temperatures and High Pressures

Reference No.: 28703(16PrM)

Fluid Phase Equilib., 2016, 425, 282 - 288; Prywer J; Mielniczek-Brzoska E; Chemical Equilibria of Complexes in Urine. A Contribution to the Physicochemistry of Infectious Urinary Stone Formation

Reference No.: 28777(09CoD)

J. Solution Chem., 2009, 38, 1449 - 1462; Covington AK; Danish EY; Measurement of Magnesium Stability Constants of Biologically Relevant Ligands by Simultaneous Use of pH and Ion-Selective Electrodes

Reference No.: 28992(71NRK)

Handbook of Thermodynamic Data, 1971 Naumov GB; Ryzhenko BN; Khodakovskiy IL; Translated by G.J. Soleimani and edited by I. Barnes & V. Speltz (U.S. Geological Survey); U.S. National Technical Information Service, Springfield VA

Reference No.: 29025(14ThL)

Desalination, 2014, 346, 54 - 69; Thiel GP; Lienhard JH V; Treating Produced Water from Hydraulic Fracturing: Composition Effects on Scale Formation and Desalination System Selection

Reference No.: 29070(85VVM)

Eur. Urol., 1985, 11, 44 - 51; Verplaetse H; Verbeek RMH; Minnaert H; Oosterlinck W; Solubility of Inorganic Kidney Stone Components in the Presence of Acid-Base Sensitive Complexing Agents

Reference No.: 29124(16BCD)

Chemosphere, 2016, 150, 341 - 356; Bretti C; Cigala RM; De Stefano C; Lando G; Sammartano S; Understanding the Bioavailability and Sequestration of Different Metal Cations in the Presence of a Biodegradable Chelant S,S-EDDS in Biological Fluids and Natural Waters

Reference No.: 29125(17BCD)

Fluid Phase Equilib., 2017, 434, 63 - 73; Bretti C; Cigala RM; De Stefano C; Lando G; Sammartano S; Thermodynamic Solution Properties of a Biodegradable Chelant (MGDA) and its Interaction with the Major Constituents of Natural Fluids

Reference No.: 29186(17SLB)

Geochim. Cosmochim. Acta, 2017, 198, 271 - 284; Stefansson A; Lemke KH; Benezeth P; Schott J; Magnesium Bicarbonate and Carbonate Interactions in Aqueous Solutions: An Infrared Spectroscopic and Quantum Chemical Study

Reference No.: 29284(17ToC)

J. Chem. Eng. Data, 2017, 62, 995 - 1010; Toner JD; Catling DC; A Low-Temperature Thermodynamic Model for the Na-K-Ca-Mg-Cl System Incorporating New Experimental Heat Capacities in KCl, MgCl₂, and CaCl₂ Solutions

Reference No.: 29298(17BFG)

J. Solution Chem., 2017, 46, 215 - 224; Bottari E; Festa MR; Gentile L; Cystine as Ligand of Calcium(II) and Magnesium(II) in Two Ionic Media and at Two Different Temperatures (25 and 37 °C)

Reference No.: 29419(16JeJ)

Environ. Earth Sci., 2016, 75, 1333-1 - 1333-14; Jeong HY; Jeon S-W; Geochemical Interactions of Mine Seepage Water with an Aquifer: Laboratory Tests and Reactive Transport Modeling

Reference No.: 29438(68RPN)

Clin. Sci., 1968, 34, 579 - 594; Robertson WG; Peacock M; Nordin BEC; Activity Products in Stone-forming and Non-stone-forming Urine

Reference No.: 29465(17OVM)

J. Chem. Thermodyn., 2017, 110, 193 - 200; Ogorodova L; Vigasina M; Melchakova L; Rusakov V; Kosova D; Ksenofontov D; Bryzgalov I; Enthalpy of Formation of Natural Hydrated Iron Phosphate: Vivianite

Reference No.: 29482(16ZZL)

Comput. Geosci., 2016, 90, 97 - 111; Zimmer K; Zhang Y; Lu P; Chen Y; Zhang G; Dalkilic M; Zhu C; SUPCRTBL: A Revised and Extended Thermodynamic Dataset and Software Package of SUPCRT92

Reference No.: 29484(11NaM)

Aquat. Geochem., 2011, 17, 209 - 219; Nair S; Merkel BJ; Impact of Alkaline Earth Metals on Aqueous Speciation of Uranium(VI) and Sorption on Quartz

Reference No.: 29487(09CDF)

Geochim. Cosmochim. Acta, 2009, 73, 2283 - 2298; Curti E; Dahn R; Farges F; Vespa M; Na, Mg, Ni and Cs Distribution and Speciation after Long-term Alteration of a Simulated Nuclear Waste Glass: A Micro-XAS/XRF/XRD and Wet Chemical Study

Reference No.: 29489(87POG)

Report PNL-6112 UC-70, 1987 Peterson SR; Opitz BE; Graham MJ; Eary LE; An Overview of the Geochemical Code MINTEQA: Applications to Performance Assessment for Low-Level Wastes; Battelle Mem. Inst., Pacific Northwest Lab., Dept. Energy, USA

Reference No.: 29520(17WoC)

Geochim. Cosmochim. Acta, 2017, 213, 635 - 676; Wolery TJ; Colon CFJ; Chemical Thermodynamic Data. 1. The Concept of Links to The Chemical Elements and the Historical Development of Key Thermodynamic Data

Reference No.: 29527(17Xio)

Geochim. Cosmochim. Acta, 2017, 213, 677 - 680; Xiong Y; Comment on "Hydromagnesite Solubility Product and Growth Kinetics in Aqueous Solution from 25 to 75 C" by Gautier, Q., Benezeth, P., Mavromatis, V., and Schott, J.

Reference No.: 29566(07BMB)

Environ. Technol., 2007, 28, 1015 - 1026; Bhuiyan MIH; Mavrinic DS; Beckie RD; A Solubility and Thermodynamic Study of Struvite

Reference No.: 29567(07RMG)

Water Res., 2007, 41, 977 - 984; Ronteltap M; Maurer M; Gujer W; Struvite Precipitation Thermodynamics in Source-Separated Urine

Reference No.: 29579(11HMA)

Chem. Eng. J., 2011, 167, 50 - 58; Hanhoun M; Montastruc L; Azzaro-Pantel C; Biscans B; Freche M; Pibouleau L; Temperature Impact Assessment on Struvite Solubility Product: A Thermodynamic Modeling Approach

Reference No.: 29589(94BMR)

Trans. Am. Soc. Agric. Engineer., 1994, 37, 617 - 621; Buchanan JR; Mote CR; Robinson RB; Thermodynamics of Struvite Formation

Reference No.: 29590(94MPC)

Water Env. Res., 1994, 66, 912 - 918; Mamais D; Pitt PA; Cheng YW; Loiacono J; Jenkins DM; Determination of Ferric Chloride Dose to Control Struvite Precipitation in Anaerobic Sludge Digesters

Reference No.: 29666(12YLL)

J. Appl. Solution Chem. Model., 2012, 1, 46 - HBED; Yunta F; Lopez-Rayó S; Lucena JJ; Thermodynamic Database Update to Model Synthetic Chelating Agents in Soil Systems

Reference No.: 29733(06RMB)

Environ. Technol., 2006, 27, 951 - 961; Rahaman MS; Mavinic DS; Bhuiyan MIH; Koch FA; Exploring the Determination of Struvite Solubility Product from Analytical Results

Reference No.: 29735(02BKK)

Croat. Chem. Acta, 2002, 75, 89 - 106; Babic-Ivancici V; Kontrec J; Kralj D; Brecvic L; Precipitation Diagrams of Struvite and Dissolution Kinetics of Different Struvite Morphologies

Reference No.: 29755(14CCC)

Ind. Eng. Chem. Res., 2014, 53, 9544 - 9553; Cigala RM; Cordaro M; Crea F; De Stefano C; Fracassetti V; Marchesi M; Milea D; Sammartano S; Acid-Base Properties and Alkali and Alkaline Earth Metal Complex Formation in Aqueous Solution of Diethylenetriamine-N,N,N',N'',N''-pentakis(methylenephosphonic acid) Obtained by an Efficient Synthetic Procedure

Reference No.: 29792(97AAB)

J. Radioanal. Nucl. Chem., 1997, 223, 213 - 215; Aage HK; Andersen BL; Blom A; Jensen I; The Solubility of Struvite

Reference No.: 29801(82DaM)

Ann. Chim. (Rome), 1982, 72, 25 - 38; Daniele PG; Marangella M; Ionic Equilibria in Urine: A Computer Model System Improved by Accurate Stability Constant Values

Reference No.: 29940(18CFG)

Chemosphere, 2018, 190, 72 - 79; Chille D; Foti C; Giuffrè O; Thermodynamic Parameters for the Protonation and the Interaction of Arsenate with Mg²⁺, Ca²⁺ and Sr²⁺: Application to Natural Waters

Reference No.: 29947(18LZY)

Calphad, 2018, 60, 163 - 176; Li D; Zeng D; Yin X; Gao D; Phase Diagrams and Thermochemical Modeling of Salt Lake Brine Systems. III. Li₂SO₄+H₂O, Na₂SO₄+H₂O, K₂SO₄+H₂O, MgSO₄+H₂O, and CaSO₄+H₂O Systems

Reference No.: 29969(17TSF)

J. Solution Chem., 2017, 46, 2231 - 2247; Torres J; Santos P; Ferrari C; Kremer C; Kremer E; Solution Chemistry of Arsenic Anions in the Presence of Metal Cations

Reference No.: 30014(17STK)

Ind. Eng. Chem. Res., 2017, 56, 1074 - 1089; Schlaikjer A; Thomsen K; Kontogeorgis GM; Simultaneous Description of Activity Coefficients and Solubility with eCPA

Reference No.: 30045(96GGH)

Quim. Anal. (Barcelona), 1996, 15(Supp_1), 534 - 537; Gans P; Gill B; Holden KML; Spectrochemistry of Solutions, Part 28.1 Hydrogen-bonding of the Thiocyanate Ion in Aqueous Solutions

Reference No.: 30052(15RLM)

Miner. Mag., 2015, 79, 537 - 544; Roper AJ; Leverett P; Murphy TD; Williams PA; Stabilities of Byströmite, MgSb₂O₆, Ordonezite, ZnSb₂O₆ and Rosiaite, PbSb₂O₆, and their Possible Roles in Limiting Antimony Mobility in the Supergene Zone

Reference No.: 30627(17LVG)

Radiochim. Acta, 2017, 105, 171 - 185; Lee J-Y; Vespa M; Gaona X; Dardenne K; Rothe J; Rabung T; Altmaier M; Yun J-I; Formation, Stability and Structural Characterization of Ternary MgUO₂(CO₃)₃²⁻ and Mg₂UO₂(CO₃)₃(aq) Complexes

Reference No.: 30743(77McH)

J. Res. U.S. Geol. Surv., 1977, 5, 227 - 233; McGee KA; Hostetler PB; Activity-product Constants of Brucite from 10 to 90 C

Reference No.: 30797(18XKW)

J. Solution Chem., 2018, 47, 595 - 610; Xiong Y; Kirkes L; Westfall T; Experimental Determination of Solubilities of Brucite $[Mg(OH)_2(cr)]$ in Na_2SO_4 Solutions with Borate to High Ionic Strengths: Interactions of $MgB(OH)_4^+$ with Na_2SO_4

Reference No.: 30858(17BKL)

J. Environ. Eng. Sci., 2017, 12, 93 - 103; Bennett AM; Koch FA; Lobanov S; Mavrinic DS; Improving Potassium Recovery with New Solubility Product Values for K-Struvite

Reference No.: 31120(18BCC)

Sci. Total Environ., 2018, 643, 704 - 714; Bretti C; Cardiano P; Cigala RM; De Stefano C; Irto A; Lando G; Sammartano S; Exploring Various Ligand Classes for the Efficient Sequestration of Stannous Cations in the Environment

Reference No.: 31154(58Wal)

Acta Chem. Scand., 1958, 12, 528 - 536; Walaas E; Stability Constants of Metal Complexes with Mononucleotides

Reference No.: 31231(19MWW)

Appl. Geochem., 2019, 100, 213 - 222; Muhr-Ebert EL; Wagner F; Walther C; Speciation of Uranium: Compilation of a Thermodynamic Database and Its Experimental Evaluation Using Different Analytical Techniques

Reference No.: 31291(84PSG)

U.S. Bur. Mines Bull. 677, 1984 Pankratz LB; Stuve JM; Gokcen NA; Thermodynamic Data for Mineral Technology; US Det. Interior, Bur. Mines, Washington, DC, USA

Reference No.: 31303(11KBK)

J. Phys. Org. Chem., 2011, 24, 29 - 37; Kiselev VD; Bolotov AV; Kashaeva HA; Shakirova I; Averyanova A; Satonin A; Konovalov AI; Solvent Effect on the Heat of Solution and Partial Molar Volume of Magnesium Perchlorate

Reference No.: 31748(19GoG)

J. Mol. Liq., 2019, 291, 111260-1 - 111260-10; Golovanova OA; Ghyngazov SA; Thermodynamic and Experimental Modeling of the Formation of the Mineral Phase of Calcification

Reference No.: 31749(18MaC)

Monatsh. Chem., 2018, 149, 253 - 260; Magalhaes MCF; Costa MOG; On the Solubility of Whitlockite, $Ca_9Mg(HPO_4)(PO_4)_6$, in Aqueous Solution at 298.15 K

Reference No.: 31759(20LGL)

J. Chem. Eng. Data, 2020, 65, 3613 - 3626; Lassin A; Guignot S; Lach A; Christov C; Andre L; Made B; Modeling the Solution Properties and Mineral-Solution Equilibria in Radionuclide-Bearing Aqueous Nitrate Systems: Application to Binary and Ternary Systems Containing U, Th, or Lanthanides at 25 C

Reference No.: 31766(19YLW)

Comput. Mater. Sci., 2019, 157, 51 - 59; Yang Y; Liu J; Wang B; Liu R; Zhang T; A Thermodynamic Modeling Approach for Solubility Product from Struvite-k

Reference No.: 31793(18Kru)

J. Phys. Chem. Ref. Data, 2018, 47, 023101-1 - 023101-30; Krumgalz BS; Temperature Dependence of Mineral Solubility in Water. Part 3. Alkaline and Alkaline Earth Sulfates

Reference No.: 32051(21ARE)

J. Cryst. Growth, 2021, 558, 125956-1 - 125956-7; Ahmed A; Rodgers AL; Elmagbari F; Jackson GE; In Support of Hydroxycitrate Being Clinically Investigated as a Potential Therapy of Calcium Nephrolithiasis: Theoretical Modelling and in vitro Investigation of Thermodynamic Effects

Reference No.: 32152(20AAG)

Chem. Geol., 2020, 550, 119699-1 - 119699-12; Aranovich LYa; Akinfiev NN; Golunova M; Quartz Solubility in Sodium Carbonate Solutions at High Pressure and Temperature

Reference No.: 32222(06DGC)

Technical Report TR-O6-17, 2006 Duro L; Grive M; Cera E; Domenech C; Bruno J; Update of a Thermodynamic Database for Radionuclides to Assist Solubility Limits Calculation for Performance Assessment; Swedish Nucl. Fuel & Waste Management Co, Stockholm, Sweden

Reference No.: 32224(80BeT)

Lawrence Berkeley Laboratory Report LBL-11448, 1980 Benson LV; Teague LS; A Tabulation of Thermodynamic Data for Chemical Reactions Involving 8 Elements Common to Radioactive Waste Package Systems