

JESS Thermodynamic Database v8.9

Manganese

24-Jan-23

Reaction No. 303							
Mn+2 + H2O = Mn+2_OH-1 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:-10.9(0.05SD)	5	MGL	50
2	15	0	Inf. Dilution	lgK:-10.9(0.03SD)	6	MGL	50
3	20	0	Inf. Dilution	lgK:-10.8(0.04SD)	6	MGL	50
4	25	0	Inf. Dilution	lgK:-10.6(0.05SD)	5	MGL	50
5	25	0	Inf. Dilution	lgK:-10.6(0.04SD)	6	MGL	50
6	25	0	Inf. Dilution	lgK:-10.59(4SF)	4	CRV	6478
7	25	0	Inf. Dilution	lgK:-10.60(4SF)	4	CRV	9402
8	25	0	Inf. Dilution	lgK:-10.54(4SF)	4	CRV	32224
9	25	0	CHEMVAL1	lgK:-10.59(0.01SD)	0	ENS	5156
10	25	0	CHEMVAL2	lgK:-10.59(0.01SD)	0	ENS	5156
11	25	0	CHEMVAL3	lgK:-10.59(0.01SD)	0	ENS	5156
12	25	0	CHEMVAL4	lgK:-10.20(0.01SD)	3	ENS	5156
13	25	0	UCT_Sea	lgK:-10.59(0.01SD)	3	EDH	5390
14	25	0.1	UCT_Sea	lgK:-10.79(0.01SD)	2	EDH	5390
15	25	0.2	UCT_Sea	lgK:-10.81(0.01SD)	0	EDH	5390
16	25	0.3	UCT_Sea	lgK:-10.83(0.01SD)	0	EDH	5390
17	25	0.4	UCT_Sea	lgK:-10.85(0.01SD)	0	EDH	5390
18	25	0.5	UCT_Sea	lgK:-10.85(0.01SD)	0	EDH	5390
19	25	0.6	UCT_Sea	lgK:-10.86(0.01SD)	2	EDH	5390
20	25	0.7	UCT_Sea	lgK:-10.86(0.01SD)	3	EDH	5390
21	25	1	Na2SO4	lgK:-10.5(0.1SD)	5	MGL	424
22	30	0	Inf. Dilution	lgK:-10.4(0.03SD)	6	MGL	50
23	30	0.1	KCl	lgK:-10.6(0.1SD)	4	ENS	763
24	36	0	Inf. Dilution	lgK:-10.2(0.05SD)	6	MGL	50
25	37	0.15	Blood Plasma	lgK:-10.1(0.05SD)	0	ENS	94
26	42	0	Inf. Dilution	lgK:-10.1(0.05SD)	5	MGL	50
27	42	0	Inf. Dilution	lgK:-10.1(0.06SD)	6	MGL	50
28	100	0.25	Cl-1 salt	lgK:-9.5(0.08SD)	0	ENS	763

29	15:42	0	Inf. Dilution	dH:14.4 (0.2SD)	5	EVH	50
30	25	0	Inf. Dilution	dH:14.0 (3SF)	3	CRV	6478
31	25	0	Inf. Dilution	dH:14.4 (1.SD)	5	CRV	6478
32	25	0	Inf. Dilution	dH:13.34 (4SF)	4	CRV	9402

Reaction No. 304							
$\text{Mn}^{2+} + 4\text{OH}^{-1} = \text{Mn}_2\text{OH}_4$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.7 (2SF)	3	EOD	16981
2	25	0	KNO3	lgK:7.7 (0.1SD)	4	ENS	4998

Reaction No. 305							
$2\text{Mn}^{2+} + \text{OH}^{-1} = \text{Mn}_2\text{OH}_2$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.5 (2SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:6.8 (2SF)	0	CRV	2556
3	25	2	KNO3	lgK:4.1 (0.1SD)	3	CSM	8
4	25	2	Unknown	lgK:7.6 (2SF)	0	CRV	2556


Reaction No. 306							
$2\text{Mn}^{2+} + 3\text{OH}^{-1} = \text{Mn}_2\text{OH}_3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.1 (3SF)	4	CRV	2556
2	25	2	KNO3	lgK:16.4 (0.1SD)	7	CSM	8

Reaction No. 307							
$\text{Mn}_2\text{OH}_2(\text{act.,s}) = \text{Mn}^{2+} + 2\text{OH}^{-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-12.8 (3SF)	5	CMN	30
2	25	1	Unknown	lgK:-11.94 (4SF)	4	CMN	773

Reaction No. 308							
$\text{NH}_3 + \text{Mn}^{2+} = \text{Mn}_2\text{NH}_3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	2	NH4NO3	lgK:1.0 (2SF)	5	MGL	208
2	20	2	NH4NO3	lgK:1.0 (0.01SD)	5	MGL	4992
3	20:30	0.5:5	Unknown	lgK:0.8 (1SF)	3	MSC	140

4	25	0	Inf. Dilution	lgK:0.9376(4SF)	1	EOR	
5	25	0	Inf. Dilution	lgK:1.0(2SF)	4	ENS	6405
6	25	0	Inf. Dilution	lgK:0.70(2SF)	4	CRV	9402
7	25	0.1	NaNO3	lgK:1.3(0.1MD)	5	MGL	411
8	25	0.4	NH4Cl	lgK:0.90(2SF)	4	MEF	5398
9	25	1	Unknown	lgK:0.90(2SF)	6	CRV	552
10	25	3	NH4NO3	lgK:1.02(3SF)	6	CRV	552
11	25	4	NH4NO3	lgK:1.07(3SF)	6	CRV	552
12	25	5	NH4NO3	lgK:1.14(3SF)	6	CRV	552
13	25	5	Unknown	lgK:0.8(1SF)	4	EES	1548
14	37	0.15	Blood Plasma	lgK:0.5(0.05SD)	4	ENS	94
15	10:40	2	NH4NO3	dH:-1.(1SF)	5	CRV	2556
16	25	0.4	t-Butanol:Water 24.8:75.2Wgt NH4Cl	lgK:1.00(3SF)	5	MEF	5398
17	25	0.4	t-Butanol:Water 43.5:56.5Wgt NH4Cl	lgK:1.30(3SF)	5	MEF	5398
18	25	0.4	t-Butanol:Water 8.1:91.9Wgt NH4Cl	lgK:1.08(3SF)	5	MEF	5398

Reaction No. 309



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	2	NH4NO3	lgK:0.54(0.04SD)	5	MGL	4992
2	20:30	0.5:5	Unknown	lgK:0.5(1SF)	3	MSC	140
3	25	0.4	NH4Cl	lgK:0.67(2SF)	4	MEF	5398
4	25	0.4	t-Butanol:Water 24.8:75.2Wgt NH4Cl	lgK:0.81(2SF)	5	MEF	5398
5	25	0.4	t-Butanol:Water 43.5:56.5Wgt NH4Cl	lgK:0.60(2SF)	5	MEF	5398
6	25	0.4	t-Butanol:Water 8.1:91.9Wgt NH4Cl	lgK:0.60(2SF)	5	MEF	5398

Reaction No. 310



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	20	2	NH4NO3	lgK:0.16(0.06SD)	5	MGL	4992
2	25	0	Inf. Dilution	lgK:0.0(1SF)	1	EOR	
3	25	0.4	NH4Cl	lgK:-0.40(2SF)	3	MEF	5398
4	25	2	NH4NO3	lgK:0.3(1SF)	5	MGL	22560
5	25	0.4	t-Butanol:Water 24.8:75.2Wgt NH4Cl	lgK:0.23(2SF)	5	MEF	5398
6	25	0.4	t-Butanol:Water 43.5:56.5Wgt NH4Cl	lgK:0.48(2SF)	5	MEF	5398
7	25	0.4	t-Butanol:Water 8.1:91.9Wgt NH4Cl	lgK:-0.30(2SF)	5	MEF	5398

Reaction No. 311							
Mn+2_NH3(3) + NH3 = Mn+2_NH3(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	2	NH4NO3	lgK:-0.40(0.1SD)	3	MGL	4992
2	25	0	Inf. Dilution	lgK:-0.1(1SF)	1	ELC	
3	25	0.4	NH4Cl	lgK:0.30(2SF)	0	MEF	5398
4	25	2	NH4NO3	lgK:-0.01(1SF)	0	MGL	22560
5	25	0.4	t-Butanol:Water 24.8:75.2Wgt NH4Cl	lgK:-0.30(2SF)	5	MEF	5398
6	25	0.4	t-Butanol:Water 43.5:56.5Wgt NH4Cl	lgK:-0.30(2SF)	5	MEF	5398
7	25	0.4	t-Butanol:Water 8.1:91.9Wgt NH4Cl	lgK:0.40(2SF)	5	MEF	5398

Reaction No. 312							
SO4-2 + Mn+2 = Mn+2_SO4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution/m	lgK:2.01(3SF)	4	MHY	8380
2	10	0	Inf. Dilution	lgK:2.08(3SF)	4	MCN	8371
3	10	0	Inf. Dilution/m	lgK:2.11(3SF)	4	MHY	8380
4	20	0	Inf. Dilution	lgK:2.4(2SF)	0	MSC	140
5	20	0	Inf. Dilution/m	lgK:2.20(3SF)	4	MHY	8380
6	20	5	Unknown	lgK:0.09(1SF)	0	MMR	5398
7	23	1	NH4NO3	lgK:0.60(0.05SD)	0	MPS	4999

8	23	7.5	NH4NO3	lgK:0.60 (2SF)	0	MEF	5398
9	23			lgK:0.60 (2SF)	0	MSP	5398
10	25	0	Inf. Dilution	lgK:2.28 (3SF)	4	MCE	140
11	25	0	Inf. Dilution	lgK:2.12 (3SF)	3	MCN	140
12	25	0	Inf. Dilution	lgK:2.30 (3SF)	4	ENS	356
13	25	0	Inf. Dilution	lgK:2.26 (3SF)	4	MDG	931
14	25	0	Inf. Dilution	lgK:2.14 (3SF)	3	MSC	931
15	25	0	Inf. Dilution	lgK:2.35 (3SF)	3	EMU	5398
16	25	0	Inf. Dilution	lgK:2.86 (3SF)	0	MCL	5398
17	25	0	Inf. Dilution	lgK:2.25 (3SF)	4	ENS	6496
18	25	0	Inf. Dilution	lgK:2.20 (3SF)	4	MCN	8371
19	25	0	Inf. Dilution	lgK:2.03 (3SF)	0	MSC	8396
20	25	0	Inf. Dilution	lgK:2.86 (0.05SD)	0	MCL	8402
21	25	0	Inf. Dilution	lgK:2.36 (3SF)	3	MCN	8619
22	25	0	Inf. Dilution	lgK:2.30 (3SF)	3	MCN	8634
23	25	0	Inf. Dilution	lgK:2.35 (3SF)	3	MDG	8675
24	25	0	Inf. Dilution	lgK:2.26 (3SF)	4	CRV	9402
25	25	0	Inf. Dilution	lgK:2.4 (2SF)	3	MSC	11516
Note (25): Kor S, Z. Phys. Chem., 1959, 210, 288							
26	25	0	Inf. Dilution	lgK:2.17 (0.03SD)	4	MIX	11767
27	25	0	Inf. Dilution	lgK:2.284 (4SF)	4	EOD	12002
28	25	0	Inf. Dilution	lgK:2.06 (3SF)	2	EMS	12547
29	25	0	Inf. Dilution	lgK:2.01 (3SF)	0	MCN	12632
30	25	0	Inf. Dilution	lgK:2.28 (3SF)	3	CRV	18273
Note (30): Table 3, p. 85							
31	25	0	Inf. Dilution	lgK:2.32 (0.23SD)	3	EOD	22958
32	25	0	Inf. Dilution	lgK:2.26 (3SF)	4	CRV	32224
33	25	0	CHEMVAL1	lgK:2.26 (0.01SD)	0	ENS	5156
34	25	0	CHEMVAL2	lgK:2.26 (0.01SD)	0	ENS	5156
35	25	0	CHEMVAL3	lgK:2.86 (0.01SD)	0	ENS	5156
36	25	0	CHEMVAL4	lgK:2.86 (0.01SD)	0	ENS	5156
37	25	0	Inf. Dilution/m	lgK:2.26 (3SF)	4	MHY	8380
38	25	0	UCT_Sea	lgK:2.26 (0.01SD)	4	EDH	5390
39	25	0.1	UCT_Sea	lgK:1.40 (0.01SD)	4	EDH	5390
40	25	0.2	UCT_Sea	lgK:1.18 (0.01SD)	4	EDH	5390
41	25	0.3	UCT_Sea	lgK:1.00 (0.01SD)	4	EDH	5390

42	25	0.4	UCT_Sea	lgK:0.84(0.01SD)	3	EDH	5390
43	25	0.5	UCT_Sea	lgK:0.77(0.01SD)	3	EDH	5390
44	25	0.5	Unknown	lgK:0.77(2SF)	3	CRV	552
45	25	0.6	UCT_Sea	lgK:0.73(0.01SD)	3	EDH	5390
46	25	0.7	UCT_Sea	lgK:0.70(0.01SD)	3	EDH	5390
47	25	1	NaClO4	lgK:0.57(2SF)	3	MSL	11516
Note (47): Fedorov V et al., Koord. Khim., 1975, 1, 836							
48	25	2	Unknown	lgK:0.60(2SF)	6	CRV	552
49	25	3	LiClO4	lgK:-0.16(2SF)	0	MCL	5398
50	25	4	Unknown	lgK:0.72(2SF)	4	CRV	552
51	25			lgK:2.19(3SF)	0	MES	5398
52	25			lgK:1.76(3SF)	4	MMR	8378
53	35	0	Inf. Dilution/m	lgK:2.27(3SF)	4	MHG	698
54	35	0	Inf. Dilution/m	lgK:2.33(3SF)	4	MHY	8380
55	37	0.15	Blood Plasma	lgK:2.0(0.05SD)	0	ENS	94
56	45	0	Inf. Dilution/m	lgK:2.42(3SF)	4	MHY	8380
57	50	0	Inf. Dilution	lgK:2.5(2SF)	4	EMU	5398
58	60	0	Inf. Dilution	lgK:2.6(2SF)	4	EMU	5398
59	100	0	Inf. Dilution	lgK:3.0(2SF)	4	EMU	5398
60	100	0	Inf. Dilution/m	lgK:2.86(0.05SD)	3	ESR	4914
61	120	0	Inf. Dilution/m	lgK:3.08(0.05SD)	3	ESR	4914
62	140	0	Inf. Dilution/m	lgK:3.26(0.09SD)	3	ESR	4914
63	150	0	Inf. Dilution	lgK:3.6(2SF)	4	EMU	5398
64	170	0	Inf. Dilution/m	lgK:3.76(0.13SD)	4	ESR	4914
65	200	0	Inf. Dilution	lgK:4.3(2SF)	3	EMU	5398
66	10:25	0	Inf. Dilution	dH:3.2(2SF)	3	MCL	5398
67	25	0	Inf. Dilution	dH:9.09(0.19SD) kJ	0	MCL	90
68	25	0	Inf. Dilution	dH:3.37(3SF)	4	MTD	140
69	25	0	Inf. Dilution	dH:3.62(3SF)	3	MDG	931
70	25	0	Inf. Dilution	dH:0.61(2SF)	0	MCL	5398
71	25	0	Inf. Dilution	dH:2.17(3SF)	0	MCL	5398
72	25	0	Inf. Dilution	dH:2.01(3SF)	0	MDG	5398
73	25	0	Inf. Dilution	dH:3.37(3SF)	4	ENS	6496
74	25	0	Inf. Dilution	dH:0.61(0.01SD)	0	MCL	8402
75	25	0	Inf. Dilution	dH:2.10(3SF)	0	CRV	9402
76	25	3	LiClO4	dH:2.3(0.1SD)	0	MCL	5000

77	25		Acetone:Water 19.8:80.2Wgt	lgK:2.88 (3SF)	4	MCN	931
78	25		Acetone:Water 29.9:70.1Wgt	lgK:3.24 (3SF)	4	MCN	931
79	25		Acetone:Water 40.2:59.8Wgt	lgK:3.75 (3SF)	4	MCN	931
80	25		Acetone:Water 9.9:90.1Wgt	lgK:2.44 (3SF)	4	MCN	931
81	25		Methanol:Water 11:89Mol	lgK:2.72 (3SF)	5	MES	5398
82	25		Methanol:Water 26:74Mol	lgK:3.20 (3SF)	5	MES	5398
83	25	0	Methanol:Water 50:50Wgt Inf. Dilution	lgK:3.59 (3SF)	4	MCN	931
84	25	0	Methanol:Water 60:40Wgt Inf. Dilution	lgK:3.98 (3SF)	4	MCN	931
85	25	0	Methanol:Water 70:30Wgt Inf. Dilution	lgK:4.47 (3SF)	4	MCN	931
86	25	0	Methanol:Water 80:20Wgt Inf. Dilution	lgK:4.95 (3SF)	4	MCN	931

Reaction No. 313							
Phthalic-2 + Mn+2 = Mn+2_Phthalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.74 (0.004SD)	4	MHY	999
2	25	0	Inf. Dilution/m	lgK:2.74 (0.05SD)	4	MEF	104
3	25	0	UCT_Sea	lgK:2.74 (0.01SD)	4	EDH	5390
4	25	0.1	UCT_Sea	lgK:1.96 (0.01SD)	4	EDH	5390
5	25	0.1	Unknown	lgK:2.23 (3SF)	5	MGL	11516
Note (5): Skorik N et al., Zhur. Neorg. Khim., 1989, 34, 27							
6	25	0.2	UCT_Sea	lgK:1.79 (0.01SD)	4	EDH	5390
7	25	0.3	UCT_Sea	lgK:1.70 (0.01SD)	4	EDH	5390
8	25	0.4	UCT_Sea	lgK:1.63 (0.01SD)	4	EDH	5390
9	25	0.5	UCT_Sea	lgK:1.59 (0.01SD)	4	EDH	5390
10	25	0.6	UCT_Sea	lgK:1.55 (0.01SD)	4	EDH	5390
11	25	0.7	UCT_Sea	lgK:1.52 (0.01SD)	4	EDH	5390
12	25	0.1	Inf. Dilution/m	dH:2.20 (0.05SD)	4	MCL	104

Reaction No. 314							
Salicylic-2 + Mn+2 = Mn+2_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1:0.15	KCl	lgK:5.90(3SF)	5	MGL	140
2	20	0.13	NaClO4	lgK:5.9(0.06SD)	4	MGL	109
3	20	0.15	Unknown	lgK:5.90(3SF)	4	ENS	773
4	25	0	Inf. Dilution	lgK:6.8(2SF)	4	ENS	4454
5	25	0	UCT_Sea	lgK:6.79(0.01SD)	4	EDH	5390
6	25	0.1	UCT_Sea	lgK:6.01(0.01SD)	4	EDH	5390
7	25	0.2	UCT_Sea	lgK:5.88(0.01SD)	4	EDH	5390
8	25	0.3	UCT_Sea	lgK:5.79(0.01SD)	4	EDH	5390
9	25	0.4	UCT_Sea	lgK:5.72(0.01SD)	4	EDH	5390
10	25	0.5	UCT_Sea	lgK:5.68(0.01SD)	4	EDH	5390
11	25	0.6	UCT_Sea	lgK:5.64(0.01SD)	4	EDH	5390
12	25	0.7	UCT_Sea	lgK:5.61(0.01SD)	4	EDH	5390
13	30	0.1	NaClO4	lgK:7.90(3SF)	0	MGL	11516
Note (13): Jahagirdar D et al., Indian J. Chem., 1975, 13, 168							
14	35	0.1	KNO3	lgK:6.1(0.1SD)	6	MPT	1618
15	37	0.15	Blood Plasma	lgK:5.5(0.05SD)	3	ENS	94
16	25	0	Methanol Inf. Dilution	lgK:4.5(2SF)	5	MGL	2601

Reaction No. 315							
2<Salicylic-2> + Mn+2 = Mn+2_Salicylic-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.13	NaClO4	lgK:9.8(0.06SD)	3	MGL	109
2	20	0.15	Unknown	lgK:9.8(2SF)	4	ENS	773
3	25	0	Inf. Dilution	lgK:10.7(3SF)	4	ENS	2152
4	25	0	UCT_Sea	lgK:10.66(0.01SD)	4	EDH	5390
5	25	0.1	UCT_Sea	lgK:9.89(0.01SD)	4	EDH	5390
6	25	0.2	UCT_Sea	lgK:9.74(0.01SD)	4	EDH	5390
7	25	0.3	UCT_Sea	lgK:9.65(0.01SD)	4	EDH	5390
8	25	0.4	UCT_Sea	lgK:9.60(0.01SD)	4	EDH	5390
9	25	0.5	UCT_Sea	lgK:9.56(0.01SD)	4	EDH	5390
10	25	0.6	UCT_Sea	lgK:9.53(0.01SD)	4	EDH	5390
11	25	0.7	UCT_Sea	lgK:9.52(0.01SD)	4	EDH	5390
12	37	0.15	Blood Plasma	lgK:9.0(0.05SD)	4	ENS	94


13	25	0	Methanol Inf. Dilution	lgK:7.6 (2SF)	5	MGL	2601
----	----	---	---------------------------	---------------	---	-----	------

Reaction No. 316							
EtDiAm + Mn+2 = Mn+2_EtDiAm							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:2.8 (2SF)	5	MGL	7112
2	20	0.1	Unknown	lgK:2.80 (3SF)	6	ENS	1539
3	25	0	Inf. Dilution	lgK:2.8 (2SF)	4	ENS	6405
4	25	0.1	NaClO4	lgK:2.7 (0.06SD)	5	MGL	125
5	25	1:1.4	Many Media	lgK:2.8 (0.04SD)	8	CRV	184
6	25	1	KCl	lgK:2.76 (3SF)	4	ENS	184
7	25	1	KCl	lgK:2.77 (3SF)	5	MSP	2022
8	25	1.4	KCl	lgK:2.8 (0.07SD)	4	MGL	115
9	25	1.4	Unknown	lgK:2.77 (3SF)	5	MGL	140
10	30	1	KCl	lgK:2.73 (3SF)	5	MHY	148
11	25	1	KCl	dH:-2.8 (0.1SD)	5	MGL	116
12	25	1	KCl	dH:-2.79 (3SF)	7	CRV	184
13	25	0.1	DMF:Water 20:80Vol KNO3	lgK:2.98 (3SF)	5	MGL	3733
14	25	0.1	DMF:Water 40:60Vol KNO3	lgK:3.14 (3SF)	5	MGL	3733
15	25	0.1	DMF:Water 50:50Vol KNO3	lgK:3.26 (3SF)	5	MGL	3733
16	25	0.1	DMF:Water 60:40Vol KNO3	lgK:3.40 (3SF)	5	MGL	3733
17	25	0.1	DMF:Water 70:30Vol KNO3	lgK:3.59 (3SF)	5	MGL	3733
18	25	0.1	DMF:Water 75:25Vol KNO3	lgK:3.71 (3SF)	5	MGL	3733
19	25	0.1	DMF:Water 80:20Vol KNO3	lgK:3.95 (3SF)	5	MGL	3733
20	25	0.1	DMSO KClO4	lgK:3.7 (0.2SD)	5	MAG	906
21	25	0.1	Dioxan:Water 20:80Vol NaClO4	lgK:2.93 (3SF)	5	MGL	3733

22	25	0.1	Dioxan:Water 40:60Vol NaClO4	lgK:3.16(3SF)	5	MGL	3733
23	25	0.1	Dioxan:Water 50:50Vol NaClO4	lgK:3.33(3SF)	5	MGL	3733
24	25	0.1	Dioxan:Water 60:40Vol NaClO4	lgK:3.57(3SF)	5	MGL	3733
25	25	0.1	Dioxan:Water 70:30Vol NaClO4	lgK:3.90(3SF)	5	MGL	3733
26	25	0.1	Dioxan:Water 75:25Vol NaClO4	lgK:4.06(3SF)	5	MGL	3733
27	25	0.1	Dioxan:Water 80:20Vol NaClO4	lgK:4.27(3SF)	5	MGL	3733
28	25	0.1	MeCN:Water 20:80Vol KNO3	lgK:2.98(3SF)	5	MGL	3733
29	25	0.1	MeCN:Water 40:60Vol KNO3	lgK:3.29(3SF)	5	MGL	3733
30	25	0.1	MeCN:Water 50:50Vol KNO3	lgK:3.44(3SF)	5	MGL	3733
31	25	0.1	MeCN:Water 60:40Vol KNO3	lgK:3.65(3SF)	5	MGL	3733
32	25	0.1	MeCN:Water 70:30Vol KNO3	lgK:3.90(3SF)	5	MGL	3733
33	25	0.1	MeCN:Water 75:25Vol KNO3	lgK:4.1(2SF)	3	MGL	3733
34	25	0.1	MeCN:Water 80:20Vol KNO3	lgK:4.4(2SF)	3	MGL	3733
35	25	0.1	Methanol:Water 55:45Vol KNO3	lgK:3.03(3SF)	5	MGL	3733
36	25	0.1	Methanol:Water 60:40Vol KNO3	lgK:3.07(3SF)	5	MGL	3733
37	25	0.1	Methanol:Water 65:35Vol KNO3	lgK:3.11(3SF)	5	MGL	3733


38	25	0.1	Methanol:Water 70:30Vol KNO3	lgK:3.15(3SF)	5	MGL	3733
39	25	0.1	Methanol:Water 75:25Vol KNO3	lgK:3.23(3SF)	5	MGL	3733
40	25	0.1	Methanol:Water 80:20Vol KNO3	lgK:3.26(3SF)	5	MGL	3733

Reaction No. 317



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:4.80(3SF)	6	ENS	1539
2	25	0	Inf. Dilution	lgK:3.7(2SF)	4	ENS	6405
3	25	1:1.4	Many Media	lgK:4.9(0.04SD)	8	CRV	184
4	25	1	KCl	lgK:4.86(3SF)	4	ENS	184
5	25	1.4	KCl	lgK:4.9(0.05SD)	4	MGL	115
6	30	1	KCl	lgK:4.79(3SF)	5	MHY	148
7	25	1	KCl	dH:-6.0(0.1SD)	5	MGL	116
8	25	1	KCl	dH:-6.00(3SF)	7	CRV	184
9	25	0.1	DMSO KClO4	lgK:6.9(0.2SD)	5	MAG	906

Reaction No. 318



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:5.80(3SF)	6	ENS	1539
2	25	0	Inf. Dilution	lgK:5.8(2SF)	4	ENS	6405
3	25	1:1.4	Many Media	lgK:5.8(0.04SD)	8	CRV	184
4	25	1	KCl	lgK:5.80(3SF)	4	ENS	184
5	25	1.4	KCl	lgK:5.79(3SF)	4	MGL	115
6	25	1.4	KCl	lgK:5.8(0.05SD)	4	MGL	115
7	30	1	KCl	lgK:5.67(3SF)	5	MHY	148
8	25	1	KCl	dH:-11.0(3SF)	7	CRV	184
9	25	1	NaClO4	dH:-11.1(0.1SD)	5	MIS	125
10	25	0.1	DMSO KClO4	lgK:10.1(0.2SD)	5	MAG	906

Reaction No. 319


Mn+2 + Citric-3 = Mn+2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18	0	Unknown	lgK:3.6(2SF)	0	MEF	22560
2	20	0.1	Unknown	lgK:3.70(3SF)	5	ENS	1539
3	25	0	Inf. Dilution	lgK:3.7(0.03SD)	0	MES	3882
Note (3): Low wgt for internal consistency							
4	25	0	Inf. Dilution	lgK:4.3(0.04SD)	0	MES	3882
5	25	0	Inf. Dilution	lgK:4.15(0.02SD)	0	MPT	3882
6	25	0	Inf. Dilution	lgK:5.5(2SF)	0	ENS	6405
7	25	0.1	KNO3	lgK:3.81(3SF)	5	MGL	17895
8	25	0.1	Me4N+ salt	lgK:2.16(3SF)	0	MGL	152
9	25	0.1	Me4N+ salt	lgK:4.15(3SF)	4	MGL	773
10	25	0.15	NaCl	lgK:3.72(3SF)	5	MIX	999
11	25	0.15	Unknown	lgK:3.67(3SF)	5	MGL	162
12	25	0.16	Unknown	lgK:3.54(3SF)	5	MIX	419
13	28	0	Unknown	lgK:2.84(3SF)	0	MCN	22560
14	37	0.15	Blood Plasma	lgK:3.8(0.05SD)	5	ENS	94
15	37	0.15	Inert	lgK:3.93(3SF)	5	MGL	2703
16	37	0.15	KNO3	lgK:3.79(0.02SD)	5	MGL	2703
17	37	0.15	NaClO4	lgK:3.83(3SF)	4	MPL	2156

Reaction No. 320							
Mn+2 + H+1_Citric-3 = Mn+2_H+1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:2.40(3SF)	6	ENS	1539
2	25	0.1	Me4N+ salt	lgK:2.16(3SF)	6	MGL	773
3	25	0.15	Unknown	lgK:2.08(3SF)	6	MGL	162
4	25	0.15	Unknown	lgK:2.08(3SF)	4	MGL	22560

Reaction No. 321							
Histamine + Mn+2 = Mn+2_Histamine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.2	KNO3	lgK:2.98(3SF)	6	MGL	166
2	25	0.1	KCl	lgK:3.33(3SF)	3	MGL	5406
3	25	0.1	Unknown	lgK:3.3(0.2SD)	7	CRV	5406
4	37	0.15	Blood Plasma	lgK:2.0(0.05SD)	0	ENS	94

5	40	0.2	KNO3	lgK:3.0(0.05SD)	4	MGL	166
6	25	0.2	KNO3	dH:-0.5(1SF)	3	MTD	166

Reaction No. 322




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:13.58(4SF)	0	MHY	140
2	20	0.1	KCl	lgK:13.9(0.05SD)	4	MGL	903
3	20	0.1	KClO4	lgK:12.9(0.05SD)	0	MDS	931
4	20	0.1	KNO3	lgK:14.0(0.2SD)	3	MGL	136
5	20	0.1	KNO3	lgK:14.2(0.2SD)	3	MGL	903
6	20	0.1	KNO3	lgK:14.01(0.02SD)	5	MHG	903
7	20	0.1	KNO3	lgK:14.04(4SF)	6	MGL	1956
8	20	0.1	KNO3	lgK:14.0(0.2SD)	5	MGL	2003
9	20	0.1	KNO3	lgK:13.95(4SF)	5	ENS	2373
10	20	0.1	KNO3	lgK:14.5(3SF)	0	MEP	11516

Note (10): Jokl V et al., Chem. Zvesti, 1965, 19, 249

11	20	0.1	Unknown	lgK:14.0(0.07SD)	7	EIU	903
12	21.7	0.1	NaNO3	lgK:13.98(4SF)	6	MEF	999
13	23			lgK:13.8(3SF)	0	MSP	3977
14	25	0	Inf. Dilution	lgK:13.8(3SF)	0	MDS	3977
15	25	0	Inf. Dilution	lgK:15.6(3SF)	4	ENS	6405
16	25	0.1	KNO3	lgK:14.05(4SF)	3	MGL	906
17	25	0.1	KNO3	lgK:14.2(0.2SD)	3	MGL	1981
18	25	0.1	NaClO4	lgK:13.8(0.1SD)	4	MHG	146
19	25	0.1	Unknown	lgK:13.81(4SF)	4	ENS	773
20	25	0.2	KNO3	lgK:13.64(4SF)	4	MPL	931
21	25	1	KCl	lgK:13.81(4SF)	5	MSP	2022
22	37	0.15	Blood Plasma	lgK:13.0(0.05SD)	0	ENS	94
23	37	0.15	NaCl	lgK:12.42(0.01SD)	0	MGL	1940
24	20	0.1	KNO3	dG:-18.5(3SF)	3	MGL	2039
25	20	0.1	KNO3	dH:-4.6(0.1SD)	5	MCL	1963
26	25	0.1	Me4N+ salt	dH:-5.2(2SF)	5	MCL	2558

Reaction No. 323



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.1 (2SF)	4	MGL	136
2	25	0.1	KNO3	lgK:3.1 (0.1SD)	4	MGL	145
3	25	0.1	Unknown	dH:-1. (0.3SD)	5	MCL	1379

Reaction No. 328							
DTPA-5 + Mn+2 = Mn+2_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:15.6 (0.1SD)	1	CRV	13242
2	20	0.1	Unknown	lgK:15.60 (4SF)	2	MEF	999
3	20	0.1	Unknown	lgK:15.13 (4SF)	2	MGL	8226
4	25	0.1	KNO3	lgK:15.1 (3SF)	6	MGL	189
5	25	0.1	KNO3	lgK:15.5 (0.1SD)	0	MHG	193
6	25	0.1	KNO3	lgK:15.5 (3SF)	1	CRV	13242
7	37	0.15	Blood Plasma	lgK:14.3 (0.05SD)	2	ENS	94
8	37	0.15	NaCl	lgK:14.31 (0.006SD)	1	MGL	1940
9	37	0.15	NaCl	lgK:14.3 (0.1SD)	2	CRV	13242
10	20	0.1	KNO3	dH:-7. (0.4SD)	5	MCL	187
11	25	0.1	KNO3	dH:-7.5 (2SF)	5	MCL	139


Reaction No. 343							
Mn+2 + H+1_EDTA-4 = Mn+2_H+1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:6.9 (0.1SD)	5	CMN	197
2	20	0.1	Unknown	lgK:6.70 (3SF)	3	ENS	1539
3	25	0	Inf. Dilution	lgK:8.13 (3SF)	2	EAE	
4	25	0.1	KNO3	lgK:5.47 (3SF)	0	MGL	906

Reaction No. 412							
2AmButan-1 + Mn+2 = Mn+2_2AmButan-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	NaClO4	lgK:3.1 (2SF)	5	MPL	2261

Reaction No. 413							
2<2AmButan-1> + Mn+2 = Mn+2_2AmButan-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.72 (3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:4.0(0.05SD)	4	ENS	94
---	----	------	--------------	-----------------	---	-----	----

Reaction No. 445




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	-15	0.5	HClO4	lgK:3.(0.3SD)	0	MIX	6000
2	20	0.01	HCl	lgK:2.00(3SF)	0	MGL	6024
3	25	0.1	KNO3	lgK:2.55(3SF)	6	MGL	3511
4	25			lgK:2.64(3SF)	0	MGL	140
5	37	0.15	Blood Plasma	lgK:2.4(0.05SD)	4	ENS	94
6	40			lgK:2.60(3SF)	0	MGL	140

Reaction No. 446




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Unknown	lgK:4.58(3SF)	4	MGL	22560
2	37	0.15	Blood Plasma	lgK:3.9(0.05SD)	4	ENS	94

Reaction No. 480




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO4	lgK:3.1(0.04SD)	4	MGL	1602
2	37	0.15	Blood Plasma	lgK:2.4(0.05SD)	4	ENS	94
3	25	3	NaClO4	dH:-7.26(0.8MD) kJ	5	MCL	1602

Reaction No. 481



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:4.5(2SF)	3	MGL	3514
2	20	0.01	Unknown	lgK:4.5(2SF)	5	MGL	3514
3	25	3	NaClO4	lgK:5.2(0.09SD)	4	MGL	1602
4	37	0.15	Blood Plasma	lgK:4.0(0.05SD)	4	ENS	94
5	25	3	NaClO4	dH:-14.23(1.6MD) kJ	4	MCL	1602


Reaction No. 517



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	20	0.01	Unknown	lgK:4.0(2SF)	3	MGL	6024
2	20	0.01	Unknown	lgK:4.(1SF)	5	MGL	6024
3	25	0	UCT_Sea	lgK:4.48(0.01SD)	4	EDH	5390
4	25	0.1	KCl	lgK:3.74(3SF)	4	MGL	184
5	25	0.1	KCl	lgK:3.74(3SF)	6	MGL	184
6	25	0.1	KNO3	lgK:4.74(3SF)	0	MGL	9311
7	25	0.1	KNO3	lgK:3.45(3SF)	3	MGL	22560
8	25	0.1	NaNO3	lgK:4.82(3SF)	0	MGL	16058
9	25	0.1	UCT_Sea	lgK:3.70(0.01SD)	4	EDH	5390
10	25	0.2	UCT_Sea	lgK:3.54(0.01SD)	4	EDH	5390
11	25	0.3	UCT_Sea	lgK:3.44(0.01SD)	4	EDH	5390
12	25	0.4	UCT_Sea	lgK:3.38(0.01SD)	4	EDH	5390
13	25	0.5	UCT_Sea	lgK:3.33(0.01SD)	4	EDH	5390
14	25	0.6	UCT_Sea	lgK:3.29(0.01SD)	4	EDH	5390
15	25	0.7	UCT_Sea	lgK:3.27(0.01SD)	4	EDH	5390
16	37	0.15	Blood Plasma	lgK:3.2(0.05SD)	4	ENS	94

Reaction No. 518




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.79(3SF)	5	MGL	22560
2	25	1	NaClO4	lgK:8.30(3SF)	5	MGL	1255
3	37	0.15	Blood Plasma	lgK:5.2(0.05SD)	4	ENS	94

Reaction No. 549



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.59(3SF)	4	MGL	3511
2	37	0.15	Blood Plasma	lgK:1.7(0.05SD)	3	ENS	94

Reaction No. 550



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.32(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.6(0.05SD)	4	ENS	94

Reaction No. 590

Mn+2 + Cys-2 = Mn+2_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:4.1(2SF)	5	MGL	3514
2	20	0.025	HBr	lgK:4.1(2SF)	3	MGL	6024
3	20	0.1	NaClO4	lgK:4.907(4SF)	6	MGL	3504
4	25	0	Inf. Dilution	lgK:5.6(2SF)	4	ENS	6405
5	25	0	UCT_Sea	lgK:5.48(0.01SD)	4	EDH	5390
6	25	0.1	KCl	lgK:5.11(3SF)	4	MGL	184
7	25	0.1	KNO3	lgK:4.56(3SF)	6	MGL	3516
8	25	0.1	UCT_Sea	lgK:4.70(0.01SD)	4	EDH	5390
9	25	0.2	UCT_Sea	lgK:4.54(0.01SD)	4	EDH	5390
10	25	0.3	UCT_Sea	lgK:4.44(0.01SD)	4	EDH	5390
11	25	0.4	UCT_Sea	lgK:4.38(0.01SD)	4	EDH	5390
12	25	0.5	UCT_Sea	lgK:4.33(0.01SD)	4	EDH	5390
13	25	0.6	UCT_Sea	lgK:4.29(0.01SD)	4	EDH	5390
14	25	0.7	UCT_Sea	lgK:4.27(0.01SD)	4	EDH	5390
15	37	0.15	Blood Plasma	lgK:4.1(0.05SD)	4	ENS	94

Reaction No. 591							
2<Cys-2> + Mn+2 = Mn+2_Cys-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:8.651(4SF)	6	MGL	3504
2	25	0	Inf. Dilution	lgK:9.04(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:7.1(0.05SD)	4	ENS	94

Reaction No. 630							
Cis-2 + Mn+2 + H+1 = Mn+2_H+1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.0(0.05SD)	4	ENS	94

Reaction No. 631							
2<Cis-2> + Mn+2 + 2<H+1> = Mn+2_H+1(2)_Cis-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.0(0.05SD)	4	ENS	94

Reaction No. 671							
Mn+2 + Glu-2 = Mn+2_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:3.3(2SF)	3	MGL	6024
2	20	0.1	KNO3	lgK:3.4(2SF)	3	MSC	999
3	25	0.1	KNO3	lgK:4.09(3SF)	0	MGL	11516
Note (3): Girdhar H et al., Indian J. Chem., 1976, 14A, 1021							
4	25	0.1	KNO3	lgK:2.98(3SF)	4	MGL	22560
5	25	0.1	NaClO4	lgK:2.94(3SF)	3	MGL	3107
6	25	0.1	NaNO3	lgK:4.04(3SF)	0	MGL	16058
7	25	3	NaClO4	lgK:2.86(3SF)	4	MGL	2161
8	37	0.15	Blood Plasma	lgK:3.1(0.05SD)	4	ENS	94

Reaction No. 672							
Mn+2 + 2<Glu-2> = Mn+2_Glu-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:7.62(3SF)	0	MGL	11516
Note (1): Girdhar H et al., Indian J. Chem., 1976, 14A, 1021							
2	25	0.1	KNO3	lgK:5.53(3SF)	5	MGL	22560
3	25	3	NaClO4	lgK:4.62(3SF)	4	MGL	2161
4	37	0.15	Blood Plasma	lgK:4.9(0.05SD)	4	ENS	94

Reaction No. 708							
Gln-1 + Mn+2 = Mn+2_Gln-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.94(3SF)	5	MMX	3107
2	25	3	NaClO4	lgK:2.9(0.04SD)	4	MGL	2161
3	37	0.15	Blood Plasma	lgK:2.6(0.05SD)	4	ENS	94

Reaction No. 709							
2<Gln-1> + Mn+2 = Mn+2_Gln-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.3(2SF)	1	EOR	
2	25	3	NaClO4	lgK:4.62(3SF)	6	MGL	2161
3	37	0.15	Blood Plasma	lgK:4.0(0.05SD)	4	ENS	94

Reaction No. 728							
------------------	--	--	--	--	--	--	--


NTA-3 + Mn+2 + Val-1 = Mn+2_Val-1_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.6 (2SF)	1	EES	
2	37	0.15	Blood Plasma	lgK:9.30 (3SF)	3	ENS	94

Reaction No. 777							
Mn+2 + His-1 = Mn+2_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.2	KNO3	lgK:3.35 (3SF)	5	MGL	6048
2	20	0.01	Unknown	lgK:4. (1SF)	0	MGL	6024
3	25	0.1	KCl	lgK:3.58 (3SF)	6	MGL	184
4	25	0.1	KCl	lgK:3.30 (3SF)	4	MGL	22560
5	25	0.1	KNO3	lgK:3.01 (3SF)	4	MGL	9311
6	25	0.1	Unknown	lgK:3.32 (0.02SD)	6	CRV	552
7	25	3	ClO4-1 salt	lgK:3.91 (3SF)	4	MGL	2157
8	35	0.1	KNO3	lgK:3.85 (3SF)	4	MGL	1187
9	35	0.1	KNO3	lgK:6.26 (3SF)	0	MGL	3565
10	37	0.15	Blood Plasma	lgK:3.2 (0.05SD)	4	ENS	94
11	37	0.15	KNO3	lgK:3.2 (0.1MD)	6	MGL	2126
12	37	0.15	KNO3	lgK:3.24 (3SF)	5	MGL	2126
13	40	0.2	KNO3	lgK:3.32 (3SF)	5	MGL	6048
14	25	3	ClO4-1 salt	dH:-2.71 (3SF)	5	MCL	2157
15	32	1:1.5	D2O KNO3	lgK:3.5 (2SF)	4	MIR	6510

Reaction No. 778							
Mn+2 + 2<His-1> = Mn+2_His-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.2	KNO3	lgK:5.78 (3SF)	4	EIU	904
2	15	0.2	KNO3	lgK:5.78 (3SF)	4	MGL	6048
3	25	0.01	Unknown	lgK:7.74 (3SF)	0	MGL	140
4	25	0.1	KCl	lgK:6.26 (3SF)	4	MGL	22560
5	25	0.1	Unknown	lgK:6.3 (0.04SD)	6	CRV	552
6	25	3	ClO4-1 salt	lgK:6.61 (3SF)	4	MGL	2157
7	37	0.15	Blood Plasma	lgK:6.2 (0.05SD)	4	ENS	94
8	37	0.15	KNO3	lgK:6.2 (0.09MD)	4	MGL	2126
9	40	0.2	KNO3	lgK:5.71 (3SF)	4	EIU	904


10	15:40	0.2	KNO3	dH:-1.2(2SF)	4	MTD	6048
11	25	3	ClO4-1 salt	dH:-5.23(3SF)	5	MCL	2157
12	25	3	NaClO4	dH:-5.25(3SF)	5	MCL	904

Reaction No. 808




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.43(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.4(0.05SD)	4	ENS	94
3	25	0.2	KNO3	dH:-1.0(2SF)	3	EES	166

Reaction No. 837




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.6(3SF)	2	EAE	
2	30	0.1	NaClO4	lgK:3.45(3SF)	5	MGL	3369
3	37	0.15	Blood Plasma	lgK:2.7(0.05SD)	4	ENS	94

Reaction No. 838




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.62(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.9(0.05SD)	4	ENS	94

Reaction No. 869



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.08(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.6(0.05SD)	4	ENS	94

Reaction No. 870



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.42(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.7(0.05SD)	4	ENS	94

Reaction No. 906

Leu-1 + Mn+2 = Mn+2_Leu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.9(2SF)	0	MEP	2392
2	25	0.01	Unknown	lgK:2.78(3SF)	6	MGL	2392
3	25	0.1	KCl	lgK:2.15(3SF)	0	MGL	184
4	25	0.1	KCl	lgK:2.83(3SF)	6	MGL	3499
5	25	1	Unknown	lgK:2.30(0.02SD)	6	CRV	552
6	35	0.1	KCl	lgK:2.76(3SF)	6	MGL	3499
7	37	0.15	Blood Plasma	lgK:2.3(0.05SD)	0	ENS	94
8	45	0.1	KCl	lgK:2.73(3SF)	6	MGL	3499
9	25:45	0.1	KCl	dH:-2.17(3SF)	6	MCL	3499

Reaction No. 907							
2<Leu-1> + Mn+2 = Mn+2_Leu-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.7(2SF)	3	MEP	2392
2	25	0.01	Unknown	lgK:5.45(3SF)	6	MGL	2392
3	37	0.15	Blood Plasma	lgK:4.2(0.05SD)	4	ENS	94

Reaction No. 954							
Lys-1 + Mn+2 + H+1 = Mn+2_H+1_Lys-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.2(0.05SD)	4	ENS	94

Reaction No. 955							
2<Lys-1> + Mn+2 + H+1 = Mn+2_H+1_Lys-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.5(0.05SD)	3	ENS	94

Reaction No. 956							
2<Lys-1> + Mn+2 + 2<H+1> = Mn+2_H+1(2)_Lys-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:24.4(0.05SD)	4	ENS	94


Reaction No. 992							
Mn+2 + Met-1 = Mn+2_Met-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:2.87 (3SF)	6	MGL	905
2	20	0.1	KNO3	lgK:3.2 (2SF)	0	MSC	905
3	25	0.1	KCl	lgK:2.89 (3SF)	6	MGL	3499
4	25	0.1	KNO3	lgK:2.77 (3SF)	6	MGL	905
5	25	0.1	KNO3	lgK:2.77 (3SF)	6	MGL	3516
6	25	0.1	KNO3	lgK:4.88 (3SF)	0	MGL	9311
7	30	0.1	KNO3	lgK:2.81 (3SF)	6	MGL	905
8	35	0.1	KCl	lgK:2.85 (3SF)	6	MGL	3499
9	37	0.15	Blood Plasma	lgK:2.7 (0.05SD)	4	ENS	94
10	40	0.1	KNO3	lgK:2.79 (3SF)	6	MGL	905
11	45	0.1	KCl	lgK:2.78 (3SF)	6	MGL	3499
12	50	0.1	KNO3	lgK:2.75 (3SF)	6	MGL	905
13	60	0.1	KNO3	lgK:2.72 (3SF)	6	MGL	905
14	20:60	0.1	KNO3	dH:-1.69 (3SF)	5	MGL	905
15	25:45	0.1	KCl	dH:-2.37 (3SF)	4	MGL	3499

Reaction No. 993							
2<Met-1> + Mn+2 = Mn+2_Met-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.92 (3SF)	4	MGL	905
2	20	0.1	KNO3	lgK:4.7 (2SF)	0	MSC	905
3	20	0.1	KNO3	lgK:4.70 (3SF)	5	MEP	22560
4	25	0.1	KNO3	lgK:4.57 (3SF)	4	MGL	905
5	30	0.1	KNO3	lgK:4.87 (3SF)	4	MGL	905
6	37	0.15	Blood Plasma	lgK:4.3 (0.05SD)	4	ENS	94
7	40	0.1	KNO3	lgK:4.83 (3SF)	4	MGL	905
8	50	0.1	KNO3	lgK:4.78 (3SF)	4	MGL	905
9	60	0.1	KNO3	lgK:4.75 (3SF)	4	MGL	905
10	20:60	0.1	KNO3	dH:-1.88 (3SF)	5	MGL	905

Reaction No. 1033							
Orn-1 + Mn+2 + H+1 = Mn+2_H+1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:12.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.0(0.05SD)	4	ENS	94

Reaction No. 1034




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:19.0(0.05SD)	4	ENS	94

Reaction No. 1035



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.7(0.05SD)	4	ENS	94

Reaction No. 1070




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:2.39(3SF)w	5	MPH	999
2	20	0.1	KNO3	lgK:2.13(3SF)	3	ENS	11516

Note (2): Berezhina L et al., Zhur. Neorg. Khim., 1973, 18, 393

3	20	0.15	NaCl	lgK:2.30(3SF)	5	MGL	22560
4	25	0.1	KCl	lgK:2.94(3SF)	0	MGL	3499
5	25	0.1	Unknown	lgK:2.4(2SF)	4	CRV	552
6	30	0.1	KNO3	lgK:2.37(3SF)w	5	MPH	999
7	35	0.1	KCl	lgK:2.89(3SF)	0	MGL	3499
8	37	0.15	Blood Plasma	lgK:2.4(0.05SD)	3	ENS	94
9	40	0.1	KNO3	lgK:2.33(3SF)w	5	MPH	999
10	45	0.1	KCl	lgK:2.84(3SF)	0	MGL	3499
11	50	0.1	KNO3	lgK:2.31(3SF)w	5	MPH	999
12	60	0.1	KNO3	lgK:2.39(3SF)w	3	MPH	999
13	25	0.1	KCl	dH:-2.19(3SF)	4	MTD	904
14	25	0.1	KNO3	dH:-1.09(3SF)	4	MTD	904
15	25:45	0.1	KCl	dH:-2.16(3SF)	6	MCL	3499

Reaction No. 1071



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	KCl	lgK:4.7(2SF)	4	EIU	904
2	25	0.1	Unknown	lgK:4.7(2SF)	4	CRV	552
3	37	0.15	Blood Plasma	lgK:4.3(0.05SD)	4	ENS	94

Reaction No. 1102							
Pro-1 + Mn+2 = Mn+2_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.34(3SF)	4	MGL	184
2	27	0.3	Unknown	lgK:2.84(3SF)	5	MMR	1173
3	37	0.15	Blood Plasma	lgK:2.8(0.05SD)	4	ENS	94
4	37	0.15	KNO3	lgK:2.8(0.09SD)	7	MGL	181

Reaction No. 1103							
2<Pro-1> + Mn+2 = Mn+2_Pro-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:5.5(2SF)	3	MGL	3514
2	20	0.03	Unknown	lgK:5.5(2SF)	4	MGL	999
3	25	0	Inf. Dilution	lgK:6.09(3SF)	2	EAE	
4	27	0.3	Unknown	lgK:5.53(3SF)	5	MMR	1173
5	37	0.15	Blood Plasma	lgK:5.5(0.05SD)	4	ENS	94
6	37	0.15	KNO3	lgK:5.5(0.06SD)	7	MGL	181

Reaction No. 1104							
3<Pro-1> + Mn+2 = Mn+2_Pro-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.57(3SF)	2	EAE	
2	27	0.3	Unknown	lgK:6.74(3SF)	5	MMR	1173
3	37	0.15	Blood Plasma	lgK:6.7(0.05SD)	4	ENS	94
4	37	0.15	KNO3	lgK:6.74(3SF)	7	MGL	181

Reaction No. 1105							
Pro-1 + Mn+2 + H+1 = Mn+2_H+1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:11.8(0.05SD)	4	ENS	94


Reaction No. 1106							
2<Pro-1> + Mn+2 + H+1 = Mn+2_H+1_Pro-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.9(0.05SD)	4	ENS	94

Reaction No. 1143							
Ser-1 + Mn+2 = Mn+2_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.2	KNO3	lgK:2.51(3SF)	4	MGL	999
2	20	0.1	KNO3	lgK:3.91(3SF)	0	MGL	905
3	20	0.15	NaCl	lgK:2.38(3SF)	3	MGL	905
4	25	0	Inf. Dilution	lgK:3.4(2SF)	4	MSC	931
5	25	0	UCT_Sea	lgK:2.93(0.01SD)	2	EDH	5390
6	25	0.1	UCT_Sea	lgK:2.56(0.01SD)	2	EDH	5390
7	25	0.1	Unknown	lgK:2.50(3SF)	6	CRV	552
8	25	0.2	UCT_Sea	lgK:2.50(0.01SD)	2	EDH	5390
9	25	0.3	UCT_Sea	lgK:2.47(0.01SD)	2	EDH	5390
10	25	0.4	UCT_Sea	lgK:2.46(0.01SD)	2	EDH	5390
11	25	0.5	UCT_Sea	lgK:2.46(0.01SD)	2	EDH	5390
12	25	0.6	UCT_Sea	lgK:2.47(0.01SD)	2	EDH	5390
13	25	0.7	UCT_Sea	lgK:2.47(0.01SD)	2	EDH	5390
14	25	3	NaClO4	lgK:2.9(0.04SD)	4	MGL	2161
15	30	0.1	KNO3	lgK:3.87(3SF)	0	MGL	905
16	37	0.15	Blood Plasma	lgK:2.5(0.05SD)	4	ENS	94
17	37	0.15	NaClO4	lgK:2.32(3SF)	3	MGL	905
18	40	0.1	KNO3	lgK:3.81(3SF)	0	MGL	905
19	40	0.2	KNO3	lgK:2.48(3SF)	4	MGL	999
20	50	0.1	KNO3	lgK:3.77(3SF)	0	MGL	905
21	60	0.1	KNO3	lgK:3.72(3SF)	0	MGL	905
22	20:60	0.1	KNO3	dH:-2.10(3SF)	4	MGL	905
23	25	0.1	Unknown	dH:-1.(1SF)	6	CRV	552

Reaction No. 1144							
2<Ser-1> + Mn+2 = Mn+2_Ser-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	15	0.2	KNO3	lgK:4.00 (3SF)	0	MGL	905
Note (1): Low wgt for internal consistency							
2	20	0.1	KNO3	lgK:6.31 (3SF)	4	MGL	905
3	25	0	Inf. Dilution	lgK:6.7 (2SF)	3	MSC	931
4	25	0	UCT_Sea	lgK:4.63 (0.01SD)	0	EDH	5390
5	25	0.1	UCT_Sea	lgK:4.07 (0.01SD)	0	EDH	5390
6	25	0.1	Unknown	lgK:3.98 (3SF)	0	CRV	552
Note (6): Low wgt for internal consistency							
7	25	0.2	UCT_Sea	lgK:3.98 (0.01SD)	0	EDH	5390
8	25	0.3	UCT_Sea	lgK:3.94 (0.01SD)	0	EDH	5390
9	25	0.4	UCT_Sea	lgK:3.93 (0.01SD)	0	EDH	5390
10	25	0.5	UCT_Sea	lgK:3.93 (0.01SD)	0	EDH	5390
11	25	0.6	UCT_Sea	lgK:3.95 (0.01SD)	0	EDH	5390
12	25	0.7	UCT_Sea	lgK:3.96 (0.01SD)	0	EDH	5390
13	25	3	NaClO4	lgK:4.791 (4SF)	4	MGL	2161
14	30	0.1	KNO3	lgK:6.27 (3SF)	4	MGL	905
15	37	0.15	Blood Plasma	lgK:5.0 (0.05SD)	0	ENS	94
16	40	0.1	KNO3	lgK:6.22 (3SF)	4	MGL	905
17	40	0.2	KNO3	lgK:3.95 (3SF)	0	MGL	905
Note (17): Low wgt for internal consistency							
18	50	0.1	KNO3	lgK:6.18 (3SF)	4	MGL	905
19	60	0.1	KNO3	lgK:6.15 (3SF)	4	MGL	905
20	20:60	0.1	KNO3	dH:-1.79 (3SF)	5	MGL	905
21	25	0.1	Unknown	dH:-1. (1SF)	6	CRV	552
22	25	0.2	KNO3	dH:-0.40 (2SF)	0	MTD	905

Reaction No. 1179



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.2	KNO3	lgK:2.59 (3SF)	5	MGL	905
2	20	0.15	NaCl	lgK:2.17 (3SF)	4	MGL	905
3	25	0.1	Unknown	lgK:2.58 (3SF)	6	CRV	552
4	37	0.15	Blood Plasma	lgK:2.6 (0.05SD)	4	ENS	94
5	37	0.15	NaCl	lgK:2.34 (3SF)	5	MGL	2261
6	37	0.15	NaClO4	lgK:2.07 (3SF)	4	MGL	905
7	40	0.2	KNO3	lgK:2.56 (3SF)	5	MGL	905

8	10:40	0.1	Unknown	dH:-1.(1SF)	4	CRV	2556
---	-------	-----	---------	-------------	---	-----	------


Reaction No. 1180							
2<Thr-1> + Mn+2 = Mn+2_Thr-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.2	KNO3	lgK:3.98(3SF)	5	MGL	905
2	25	0.1	Unknown	lgK:3.96(3SF)	4	CRV	552
3	37	0.15	Blood Plasma	lgK:3.9(0.05SD)	3	ENS	94
4	37	0.15	NaCl	lgK:4.94(3SF)	0	MGL	2261
5	40	0.2	KNO3	lgK:3.93(3SF)	5	MGL	905
6	25	0.2	KNO3	dH:-0.78(2SF)	5	MGL	905

Reaction No. 1213							
Trp-1 + Mn+2 = Mn+2_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:2.88(3SF)	3	MPT	999
2	20	0.15	NaCl	lgK:2.59(3SF)	3	MGL	11516
Note (2): Vlasova N et al., Zhur. Neorg. Khim., 1985, 30, 1738							
3	25	0.1	KNO3	lgK:2.53(3SF)	3	MGL	2261
4	25	0.1	NaClO4	lgK:2.5(0.03SD)	3	MGL	4540
5	25	3	ClO4-1 salt	lgK:2.84(3SF)	6	MGL	2157
6	30	0.1	KNO3	lgK:2.86(3SF)	3	MPT	999
7	37	0.15	Blood Plasma	lgK:2.6(0.05SD)	4	ENS	94
8	40	0.1	KNO3	lgK:2.82(3SF)	6	MPT	999
9	50	0.1	KNO3	lgK:2.79(3SF)	6	MPT	999
10	60	0.1	KNO3	lgK:2.76(3SF)	6	MPT	999
11	20:60	0.1	KNO3	dH:-1.29(3SF)	4	MTD	904
12	25	3	ClO4-1 salt	dH:-1.1(0.09SD)	4	MCL	2157
13	25	3	NaClO4	dH:-2.7(2SF)	4	MCL	904

Reaction No. 1214							
2<Trp-1> + Mn+2 = Mn+2_Trp-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:5.(1SF)	3	MGL	3514
2	25	0.1	KNO3	lgK:4.98(3SF)	5	MGL	2261
3	25	3	NaClO4	lgK:5.15(3SF)	4	MGL	2157
4	37	0.15	Blood Plasma	lgK:4.3(0.05SD)	4	ENS	94


5	25	3	ClO4-1 salt	dH:-2.3(0.1SD)	5	MCL	2157
---	----	---	-------------	----------------	---	-----	------

Reaction No. 1215




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	ClO4-1 salt	lgK:8.0(2SF)	4	MGL	2157
2	37	0.15	Blood Plasma	lgK:5.7(0.05SD)	4	ENS	94

Reaction No. 1262




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.91(3SF)	5	MGL	11516
Note (1): Manorik P et al., Zhur. Neorg. Khim., 1983, 28, 2292							
2	37	0.15	Blood Plasma	lgK:1.2(0.05SD)	3	ENS	94

Reaction No. 1263




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.(2SF)	3	EES	
2	25	0.1	Unknown	lgK:11.64(4SF)	0	ENS	2350
3	25	0.2	KCl	lgK:13.08(4SF)	6	MGL	1050
4	37	0.15	Blood Plasma	lgK:12.4(0.05SD)	0	ENS	94
5	25	0.2	KCl	dH:-24.(2SF)kJ	5	MCL	1050

Reaction No. 1264



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:16.8(3SF)	4	MGL	1050
2	25	0.2	KCl	dH:-25.(2SF)kJ	4	MCL	1050

Reaction No. 1265




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:25.28(4SF)	5	ENS	2350
2	25	0.2	KCl	lgK:25.7(3SF)	5	MGL	1050
3	37	0.15	Blood Plasma	lgK:23.9(0.05SD)	0	ENS	94

Note (3): Low wgt for internal consistency


4	25	0.2	KCl	dH:-48. (2SF) kJ	5	MCL	1050
---	----	-----	-----	------------------	---	-----	------

Reaction No. 1303




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.1 (3SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:12.9 (0.05SD)	4	ENS	94

Reaction No. 1304



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.0 (0.05SD)	3	ENS	94

Reaction No. 1305



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.41 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.7 (0.05SD)	4	ENS	94
3	37	0.15	KNO3	lgK:5.7 (0.2SD)	6	MGL	181

Reaction No. 1306



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:6.08 (3SF)	3	MGL	2392
2	20	0.1	KNO3	lgK:5.3 (2SF)	3	MEP	2392
3	23	0.5	NaNO3	lgK:6.74 (3SF)	0	MIX	906
4	25	0	UCT_Sea	lgK:4.72 (0.01SD)	0	EDH	5390
5	25	0.01	Unknown	lgK:6.05 (3SF)	3	MGL	2392
6	25	0.1	UCT_Sea	lgK:4.13 (0.01SD)	0	EDH	5390
7	25	0.2	KNO3	lgK:4.2 (0.06SD)	0	MGL	2392

Note (7): Low wgt for internal consistency

8	25	0.2	UCT_Sea	lgK:4.01 (0.01SD)	0	EDH	5390
9	25	0.3	UCT_Sea	lgK:3.95 (0.01SD)	0	EDH	5390
10	25	0.4	UCT_Sea	lgK:3.91 (0.01SD)	0	EDH	5390
11	25	0.5	UCT_Sea	lgK:3.88 (0.01SD)	0	EDH	5390
12	25	0.6	UCT_Sea	lgK:3.87 (0.01SD)	0	EDH	5390

13	25	0.7	UCT_Sea	lgK:3.86(0.01SD)	0	EDH	5390
14	30	0.1	KNO3	lgK:5.96(3SF)	3	MGL	2392
15	37	0.15	Blood Plasma	lgK:4.9(0.05SD)	0	ENS	94
16	37	0.15	KNO3	lgK:4.3(0.06SD)	0	MGL	181
Note (16): Low wgt for internal consistency							
17	40	0.1	KNO3	lgK:5.87(3SF)	3	MGL	2392
18	50	0.1	KNO3	lgK:5.80(3SF)	3	MGL	2392
19	60	0.1	KNO3	lgK:5.74(3SF)	3	MGL	2392
20	20:60	0.1	KNO3	dH:-6.2(2SF)	0	MTD	2392

Reaction No. 1307							
Ala-1 + Mn+2 = Mn+2_Ala-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.08(3SF)	3	MGL	2392
2	20	0.1	KNO3	lgK:3.4(2SF)	0	MEP	2392
3	20	1	NaNO3	lgK:3.15(3SF)	3	MIX	2392
4	20	1	Unknown	lgK:3.15(3SF)	4	MSL	999
5	23	0.5	NaNO3	lgK:3.02(3SF)	3	MIX	906
6	25	0.05:0.2	Many Media	lgK:2.6(0.2SD)	7	CIU	2392
7	25	0	Inf. Dilution	lgK:3.02(3SF)	4	MGL	2392
8	25	0	UCT_Sea	lgK:2.96(0.01SD)	0	EDH	5390
9	25	0.01	Unknown	lgK:3.24(3SF)	3	MGL	2392
10	25	0.01	Unknown	lgK:3.24(3SF)	3	MGL	2392
11	25	0.05	KCl	lgK:2.45(3SF)	0	MGL	2392
12	25	0.1	KCl	lgK:2.60(3SF)	3	MGL	2392
13	25	0.1	NaClO4	lgK:2.67(3SF)	3	MGL	6073
14	25	0.1	UCT_Sea	lgK:2.56(0.01SD)	0	EDH	5390
15	25	0.2	KNO3	lgK:2.27(0.02SD)	0	MGL	2392
16	25	0.2	UCT_Sea	lgK:2.49(0.01SD)	0	EDH	5390
17	25	0.3	UCT_Sea	lgK:2.44(0.01SD)	0	EDH	5390
18	25	0.4	UCT_Sea	lgK:2.42(0.01SD)	0	EDH	5390
19	25	0.5	UCT_Sea	lgK:2.40(0.01SD)	0	EDH	5390
20	25	0.6	UCT_Sea	lgK:2.39(0.01SD)	0	EDH	5390
21	25	0.7	UCT_Sea	lgK:2.38(0.01SD)	0	EDH	5390
22	25	1	Unknown	lgK:2.45(3SF)	3	CRV	552
23	30	0.1	KNO3	lgK:3.00(3SF)	3	MGL	2392


24	37	0.15	KNO3	lgK:2.4 (0.08SD)	3	MGL	181
25	40	0.1	KNO3	lgK:2.94 (3SF)	3	MGL	2392
26	40	1	NaNO3	lgK:3.07 (3SF)	3	MIX	2392
27	40	1	Unknown	lgK:3.07 (3SF)	5	MSL	999
28	50	0.1	KNO3	lgK:2.89 (3SF)	3	MGL	2392
29	60	0.1	KNO3	lgK:2.85 (3SF)	3	MGL	2392
30	60	1	NaNO3	lgK:2.94 (3SF)	3	MIX	2392
31	60	1	Unknown	lgK:2.94 (3SF)	5	MSL	999
32	20:60	0.1	KNO3	dH:-2.5 (2SF)	3	MTD	2392

Reaction No. 1343							
CO3-2 + Mn+2 = Mn+2_CO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.90 (3SF)	4	ENS	5181
2	25	0	Inf. Dilution	lgK:4.90 (3SF)	4	ENS	6496
3	25	0	Inf. Dilution	lgK:4.97 (3SF)	6	MSL	9040
4	25	0	Inf. Dilution	lgK:6.5 (2SF)	0	CRV	32224
5	25	0	CHEMVAL1	lgK:6.50 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL2	lgK:6.50 (0.01SD)	0	ENS	5156
7	25	0	CHEMVAL3	lgK:6.50 (0.01SD)	0	ENS	5156
8	25	0	CHEMVAL4	lgK:6.50 (0.01SD)	0	ENS	5156
9	25	0	NaCl	lgK:4.8 (2SF)	5	MSL	17327
10	25	0	UCT_Sea	lgK:4.32 (0.01SD)	2	EDH	5390
11	25	0.1	UCT_Sea	lgK:3.61 (0.01SD)	0	EDH	5390
12	25	0.2	UCT_Sea	lgK:3.49 (0.01SD)	0	EDH	5390
13	25	0.3	UCT_Sea	lgK:3.30 (0.01SD)	0	EDH	5390
14	25	0.4	UCT_Sea	lgK:3.12 (0.01SD)	0	EDH	5390
15	25	0.5	UCT_Sea	lgK:3.06 (0.01SD)	0	EDH	5390
16	25	0.6	UCT_Sea	lgK:3.02 (0.01SD)	2	EDH	5390
17	25	0.7	UCT_Sea	lgK:2.98 (0.01SD)	2	EDH	5390
18	25	3	(Na)ClO4	lgK:3.5 (0.2SD)	5	MGL	5220
19	25	3	NaClO4	lgK:3.54 (3SF)	4	MSL	5220
20	37	0.15	Blood Plasma	lgK:3.1 (0.05SD)	4	ENS	94

Reaction No. 1344							
H+1 + CO3-2 + Mn+2 = Mn+2_H+1_CO3-2							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.4 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:11.6 (0.05SD)	0	ENS	766
3	25	0	Inf. Dilution	lgK:12.1 (3SF)	0	ENS	6405
4	25	0	Inf. Dilution	lgK:12.10 (4SF)	0	CRV	9402
5	25	0	Inf. Dilution	lgK:11.25 (4SF)	0	CRV	32224
6	25	0	CHEMVAL1	lgK:11.60 (0.01SD)	0	ENS	5156
7	25	0	CHEMVAL2	lgK:11.60 (0.01SD)	0	ENS	5156
8	25	0	CHEMVAL3	lgK:11.60 (0.01SD)	0	ENS	5156
9	25	0	CHEMVAL4	lgK:11.20 (0.01SD)	0	ENS	5156
10	25	0	UCT_Sea	lgK:11.60 (0.01SD)	0	EDH	5390
11	25	0.1	UCT_Sea	lgK:10.80 (0.01SD)	0	EDH	5390
12	25	0.2	UCT_Sea	lgK:10.62 (0.01SD)	0	EDH	5390
13	25	0.3	UCT_Sea	lgK:10.47 (0.01SD)	0	EDH	5390
14	25	0.4	UCT_Sea	lgK:10.38 (0.01SD)	0	EDH	5390
15	25	0.5	UCT_Sea	lgK:10.29 (0.01SD)	0	EDH	5390
16	25	0.6	UCT_Sea	lgK:10.22 (0.01SD)	0	EDH	5390
17	25	0.7	UCT_Sea	lgK:10.17 (0.01SD)	0	EDH	5390
18	37	0.15	Blood Plasma	lgK:11.5 (0.05SD)	0	ENS	94

Reaction No. 1373



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-86.29 (4SF)	3	CRV	10174
2	50	0	Inf. Dilution	dG:-86.62 (4SF)	2	CRV	10174
3	75	0	Inf. Dilution	dG:-87.01 (4SF)	2	CRV	10174
4	100	0	Inf. Dilution	dG:-87.44 (4SF)	1	CRV	10174
5	125	0	Inf. Dilution	dG:-87.91 (4SF)	1	CRV	10174
6	150	0	Inf. Dilution	dG:-88.42 (4SF)	1	CRV	10174
7	175	0	Inf. Dilution	dG:-88.96 (4SF)	0	CRV	10174
8	200	0	Inf. Dilution	dG:-89.53 (4SF)	0	CRV	10174
9	225	0	Inf. Dilution	dG:-90.11 (4SF)	0	CRV	10174
10	250	0	Inf. Dilution	dG:-90.72 (4SF)	0	CRV	10174
11	300	0	Inf. Dilution	dG:-91.95 (4SF)	0	CRV	10174

Reaction No. 1410

H+1 + PO4-3 + Mn+2 = Mn+2_H+1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.20(4SF)	4	CRV	9402
2	25	0	CHEMVAL2	lgK:16.09(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:16.09(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:16.30(0.01SD)	3	ENS	5156
5	25	0	UCT_Sea	lgK:15.29(0.01SD)	3	EDH	5390
6	25	0.1	UCT_Sea	lgK:13.82(0.01SD)	3	EDH	5390
7	25	0.2	UCT_Sea	lgK:13.45(0.01SD)	3	EDH	5390
8	25	0.3	UCT_Sea	lgK:13.24(0.01SD)	0	EDH	5390
9	25	0.4	UCT_Sea	lgK:13.07(0.01SD)	0	EDH	5390
10	25	0.5	UCT_Sea	lgK:12.95(0.01SD)	0	EDH	5390
11	25	0.6	UCT_Sea	lgK:12.86(0.01SD)	0	EDH	5390
12	25	0.7	UCT_Sea	lgK:12.81(0.01SD)	0	EDH	5390
13	37	0.15	Blood Plasma	lgK:14.0(0.05SD)	3	ENS	94

Reaction No. 1411							
2<PO4-3> + Mn+2 + 2<H+1> = Mn+2_H+1(2)_PO4-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL2	lgK:29.52(0.01SD)	6	ENS	5156
2	25	0	CHEMVAL3	lgK:29.52(0.01SD)	6	ENS	5156
3	25	0	CHEMVAL4	lgK:30.00(0.01SD)	6	ENS	5156
4	37	0.15	Blood Plasma	lgK:25.6(0.05SD)	4	ENS	94

Reaction No. 1451							
SCN-1 + Mn+2 = Mn+2_SCN-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1.5	NaClO4	lgK:0.73(2SF)	5	MDS	11516
Note (1): Tribalat S et al., Compt. Rend., 1964, 258, 2828							
2	20	1.5	Unknown	lgK:1.30(3SF)	4	CRV	552
3	23	0	Inf. Dilution	lgK:1.23(3SF)	5	MSP	11516
Note (3): Yatsimirskii K et al., Zhur. Neorg. Khim., 1958, 3, 339							
4	25	0	Inf. Dilution	lgK:1.23(3SF)	3	CRV	552
5	25	0	Inf. Dilution	lgK:1.26(0.03SD)	4	MIX	11767
6	25	0	Inf. Dilution	lgK:1.15(3SF)	5	MEF	13040
7	25	0.5	Unknown	lgK:0.80(2SF)	6	CRV	552

8	25	1	NaClO ₄	lgK:0.65 (2SF)	5	MKN	516
9	25	2.3	NaClO ₄	lgK:0.72 (2SF)	5	MVM	11516
Note (9): Tribalat S et al., J. Electroanal. Chem., 1963, 5, 176							
10	35	0	Inf. Dilution/m	lgK:1.57 (3SF)	4	MHG	698
11	37	0.15	Blood Plasma	lgK:1.1 (0.05SD)	4	ENS	94
12	25	0	Inf. Dilution	dH:-0.9 (1SF)	4	CRV	552
13	25	0.4	DMF Et ₄ NClO ₄	lgK:2.3 (0.1MD)	5	MCL	7212
14	25	0.4	DMF Et ₄ NClO ₄	dH:-0.24 (2SF)	5	MCL	7212
15	25	0.2	DiMeAcetamide Bu ₄ NBF ₄	lgK:2.7 (0.1MD)	5	MCL	7239
16	25	0.2	DiMeAcetamide Bu ₄ NBF ₄	dH:0.78 (2SF)	5	MCL	7239

Reaction No. 1481							
Ascorbic-2 + Mn+2 + H+1 = Mn+2_H+1_Ascorbic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.9 (3SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:10.8 (0.05SD)	4	ENS	94


Reaction No. 1538							
2<Citric-3> + Mn+2 = Mn+2_Citric-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO ₃	lgK:12.83 (4SF)	0	MGL	17895
2	25	0.1	Me ₄ N ⁺ salt	lgK:4.15 (3SF)	0	MGL	152
3	25	1	KNO ₃	lgK:5.72 (3SF)	3	MPL	22560
4	37	0.15	Blood Plasma	lgK:4.3 (0.05SD)	0	ENS	94

Reaction No. 1539							
H+1 + Citric-3 + Mn+2 = Mn+2_H+1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.4 (2SF)	4	ENS	6405
2	25	0.1	KNO ₃	lgK:8.15 (3SF)	4	MGL	17895
3	37	0.15	Inert	lgK:8.06 (3SF)	5	MGL	2703
4	37	0.15	KNO ₃	lgK:7.84 (0.03SD)	6	MGL	2703

Reaction No. 1540							
Mn+2 + Citric-3 + H ₂ O = Mn+2_OH-1_Citric-3 + H+1							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-3.9(2SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:-5.5(0.05SD)	3	ENS	94

Reaction No. 1574




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.428(4SF)	6	MCN	999
2	25	0.16	Inf. Dilution	lgK:1.428(4SF)	5	MCN	7731
3	25	0.16	Unknown	lgK:1.19(3SF)	5	MIX	419
4	25	1	NaClO ₄	lgK:0.92(2SF)	6	MQH	999
5	37	0.15	Blood Plasma	lgK:1.0(0.05SD)	6	ENS	94

Reaction No. 1575




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO ₄	lgK:1.46(3SF)	5	MQH	22560
2	37	0.15	Blood Plasma	lgK:1.4(0.05SD)	3	ENS	94

Reaction No. 1619




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:3.14(0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:2.35(0.01SD)	4	EDH	5390
3	25	0.1	Unknown	lgK:2.24(3SF)	6	MGL	1217
4	25	0.16	Unknown	lgK:2.24(3SF)	5	MIX	419
5	25	0.16	Unknown	lgK:2.24(3SF)	5	MIX	22560
6	25	0.2	UCT_Sea	lgK:2.19(0.01SD)	4	EDH	5390
7	25	0.3	UCT_Sea	lgK:2.09(0.01SD)	4	EDH	5390
8	25	0.4	UCT_Sea	lgK:2.03(0.01SD)	4	EDH	5390
9	25	0.5	UCT_Sea	lgK:1.98(0.01SD)	4	EDH	5390
10	25	0.6	UCT_Sea	lgK:1.95(0.01SD)	4	EDH	5390
11	25	0.7	UCT_Sea	lgK:1.92(0.01SD)	4	EDH	5390
12	37	0.15	Blood Plasma	lgK:2.0(0.05SD)	4	ENS	94

Reaction No. 1620




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.96(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.0(0.05SD)	4	ENS	94

Reaction No. 1621



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.66(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.7(0.05SD)	4	ENS	94

Reaction No. 1664



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:3.92(3SF)	4	MGL	140
2	0	0	Unknown	lgK:5.18(3SF)	0	MGL	13109
3	15	0	Inf. Dilution	lgK:3.92(3SF)	4	MGL	140
4	18	0	Inf. Dilution	lgK:3.89(3SF)	4	MCN	8670
5	20	0.1	KClO4	lgK:3.75(0.05SD)	2	MDS	931
6	20	0.1	Unknown	lgK:3.90(3SF)	3	ENS	1539
7	23	0.25	KClO3	lgK:2.40(3SF)	0	MPL	906
8	25	0	Inf. Dilution	lgK:3.96(3SF)	4	MSL	140
9	25	0	Inf. Dilution	lgK:3.82(3SF)	5	MSL	11516

Note (9): Money R et al., J. Chem. Soc., 1934, , 400


10	25	0	Inf. Dilution	lgK:3.886(4SF)	4	EOD	12002
11	25	0	Inf. Dilution	lgK:3.91(3SF)	4	CRV	18273

Note (11): Table 3, p. 85

12	25	0	Inf. Dilution/m	lgK:3.97(3SF)	4	MEF	104
13	25	0.1	NaClO4	lgK:3.15(0.1SD)	2	MPL	906
14	25	0.1	Unknown	lgK:3.2(2SF)	4	ENS	773
15	25	0.16	Unknown	lgK:2.93(3SF)	5	MIX	419
16	25			lgK:2.15(3SF)	0	MSP	906
17	35	0	Inf. Dilution	lgK:4.02(3SF)	4	MGL	140
18	35	0.1	KNO3	lgK:5.14(3SF)	0	MGL	1187
19	37	0.15	Blood Plasma	lgK:3.5(0.05SD)	2	ENS	94
20	45	0	Inf. Dilution	lgK:4.06(3SF)	4	MGL	140
21	0:35	0	Inf. Dilution	dH:1.4(0.2SD)	4	MHY	1394

22	25	0	Inf. Dilution	dH:1.42 (3SF)	5	CMN	1394
----	----	---	---------------	---------------	---	-----	------

Reaction No. 1665




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:5.30 (3SF)	6	ENS	1539
2	23	0.25	KClO3	lgK:5.66 (3SF)	0	MPL	906
3	25	0	Inf. Dilution	lgK:5.25 (3SF)	4	MSL	140
4	25	0	Inf. Dilution	lgK:5.80 (3SF)	5	MGL	11516

Note (4): Zolotarev E, Dissertation, 1956


5	25	0.1	NaClO4	lgK:4.41 (0.1SD)	4	MPL	906
6	25			lgK:4.05 (3SF)	0	MSP	906
7	37	0.15	Blood Plasma	lgK:4.8 (0.05SD)	4	ENS	94

Reaction No. 1666




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.96 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.0 (0.05SD)	4	ENS	94

Reaction No. 1693



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.65	KCl	lgK:1.20 (3SF)	6	MGL	179
2	25	0.65	KCl	lgK:1.26 (3SF)	6	MGL	179
3	37	0.15	Blood Plasma	lgK:1.0 (0.05SD)	6	ENS	94

Reaction No. 1744



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:2.11 (3SF)	4	MGL	999
2	0	0.2	NaClO4	lgK:2.11 (0.13SD)	5	MGL	5685
3	15	0	Inf. Dilution	lgK:2.18 (3SF)	4	MGL	999
4	15	0.2	NaClO4	lgK:2.19 (0.02SD)	5	MGL	5685
5	23	0.035	KCl	lgK:2.33 (3SF)	4	MSP	5748
6	25	0	Inf. Dilution	lgK:2.26 (3SF)	4	MGL	999
7	25	0	Inf. Dilution	lgK:2.25 (3SF)	4	CRV	18273


Note (7): Table 3, p. 85							
8	25	0	Inf. Dilution/m	lgK:2.26(3SF)	4	MEF	104
9	25	0	UCT_Sea	lgK:2.26(0.01SD)	1	EDH	5390
10	25	0.1	UCT_Sea	lgK:1.46(0.01SD)	1	EDH	5390
11	25	0.16	Unknown	lgK:1.26(3SF)	0	MIX	419
12	25	0.2	NaClO4	lgK:2.27(0.04SD)	5	MGL	5685
13	25	0.2	UCT_Sea	lgK:1.27(0.01SD)	1	EDH	5390
14	25	0.2	Unknown	lgK:1.48(3SF)	6	ENS	773
15	25	0.3	UCT_Sea	lgK:1.17(0.01SD)	1	EDH	5390
16	25	0.4	UCT_Sea	lgK:1.09(0.01SD)	1	EDH	5390
17	25	0.5	UCT_Sea	lgK:1.04(0.01SD)	1	EDH	5390
18	25	0.6	UCT_Sea	lgK:1.00(0.01SD)	1	EDH	5390
19	25	0.7	UCT_Sea	lgK:0.97(0.01SD)	1	EDH	5390
20	35	0	Inf. Dilution	lgK:2.32(3SF)	4	MGL	999
21	35	0.2	NaClO4	lgK:2.33(0.07SD)	5	MGL	5685
22	37	0.15	NaClO4	lgK:2.7(0.04SD)	0	MGL	2156
23	45	0.2	NaClO4	lgK:2.43(0.10SD)	5	MGL	5685
24	0:45	0.2	NaClO4	dH:2.95(0.1SD)	5	MTD	5685
25	25	0	Inf. Dilution	dH:2.95(3SF)	4	MGL	999
26	25	0	Unknown	dH:3.02(3SF)	5	CMN	1394
27	25	0.1	KCl	dH:3.0(0.2SD)	5	MCL	5329

Reaction No. 1745							
2<Succinic-2> + Mn+2 = Mn+2_Succinic-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.4(2SF)	1	ELC	
2	37	0.15	NaClO4	lgK:5.4(0.05SD)	3	MGL	2156

Reaction No. 1746							
H+1 + Succinic-2 + Mn+2 = Mn+2_H+1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:6.84(0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:6.05(0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:5.91(0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:5.82(0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:5.77(0.01SD)	4	EDH	5390

6	25	0.5	UCT_Sea	lgK:5.74 (0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:5.73 (0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:5.72 (0.01SD)	4	EDH	5390
9	37	0.15	NaClO4	lgK:7.4 (0.03SD)	3	MGL	2156

Reaction No. 1783




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:1.44 (3SF)	6	ENS	1539
2	25	0.1	Unknown	lgK:2.49 (3SF)	6	MGL	1217
3	32	0.1	NaClO4	lgK:1.44 (3SF)	6	MGL	999
4	37	0.15	Blood Plasma	lgK:1.5 (0.05SD)	3	ENS	94

Reaction No. 1784




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:2.5 (0.05SD)	4	ENS	94

Reaction No. 1785




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:5.16 (3SF)	6	MGL	1217
2	37	0.15	Blood Plasma	lgK:5.2 (0.05SD)	4	ENS	94

Reaction No. 1813



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:5.803 (4SF)	5	MGL	3504
2	37	0.15	Blood Plasma	lgK:5.0 (0.05SD)	4	ENS	94

Reaction No. 1814



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:10.322 (5SF)	5	MGL	3504
2	37	0.15	Blood Plasma	lgK:8.9 (0.05SD)	4	ENS	94

Reaction No. 1840

OxPen-2 + Mn+2 + H+1 = Mn+2_H+1_OxPen-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:10.6(0.05SD)	3	ENS	94

Reaction No. 1841							
2<OxPen-2> + Mn+2 + 2<H+1> = Mn+2_H+1(2)_OxPen-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:22.0(0.05SD)	4	ENS	94


Reaction No. 1876							
GSH-3 + Mn+2 = Mn+2_GSH-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	KNO3	lgK:2.7(2SF)	3	MGL	931
2	37	0.15	Blood Plasma	lgK:3.0(0.05SD)	3	ENS	94

Reaction No. 1877							
2<GSH-3> + Mn+2 = Mn+2_GSH-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.2(2SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:6.0(0.05SD)	4	ENS	94

Reaction No. 1919							
Trien + Mn+2 = Mn+2_Trien							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.9(0.05SD)	4	MGL	1960
2	25	0.1	Unknown	lgK:4.90(3SF)	6	ENS	773
3	25	1	Unknown	lgK:5.46(3SF)	6	ENS	773
4	30	1	KCl	lgK:5.43(3SF)	5	MGL	6805
5	30	1	KNO3	lgK:5.43(3SF)	5	MGL	6805
6	37	0.15	Blood Plasma	lgK:4.7(0.05SD)	4	ENS	94
7	40	1	KCl	lgK:5.31(3SF)	5	MGL	6805
8	40	1	KNO3	lgK:5.31(3SF)	5	MGL	6805
9	25	0.1	KCl	dH:-2.3(0.05SD)	5	MCL	6535
10	25	0.1	Unknown	dH:-2.3(2SF)	5	CRV	2556
11	30:45	1	KCl	dH:-4.(1SF)	5	MTD	6805
12	35	1	KNO3	dH:-4.(1SF)	5	MGL	999


13	25	0.1	Dioxan:Water 50:50Vol KNO3	lgK:5.6(0.1SD)	5	MGL	5693
----	----	-----	----------------------------------	----------------	---	-----	------

Reaction No. 1937




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.1(3SF)	3	ENS	6405
2	37	0.15	Blood Plasma	lgK:16.5(0.05SD)	0	ENS	94
3	37	0.15	NaCl	lgK:15.280(0.002SD)	3	MGL	1940

Reaction No. 1988




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KCl	lgK:5.23(3SF)	6	MGL	999
2	37	0.15	Blood Plasma	lgK:5.0(0.05SD)	4	ENS	94

Reaction No. 1989




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KCl	lgK:10.43(4SF)	6	MGL	999
2	37	0.15	Blood Plasma	lgK:9.9(0.05SD)	3	ENS	94

Reaction No. 2014




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:7.0(0.05SD)	4	ENS	94

Reaction No. 2042



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:18.7(0.05SD)	4	ENS	94
3	37	0.15	NaCl	lgK:18.72(0.004SD)	5	MGL	1940


Reaction No. 2043



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:25.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:21.5(0.05SD)	4	ENS	94
3	37	0.15	NaCl	lgK:21.49(0.01SD)	5	MGL	1940

Reaction No. 2044




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:16.9(0.05SD)	4	ENS	94

Reaction No. 2060




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.(2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:22.4(3SF)	1	ENS	6405
3	37	0.15	Blood Plasma	lgK:18.7(0.05SD)	2	ENS	94

Reaction No. 2061



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KClO4	lgK:14.7(0.06SD)	0	MDS	999
2	20	0.1	KNO3	lgK:17.43(4SF)	0	MGL	1963
3	20	0.1	KNO3	lgK:16.8(0.2SD)	5	MGL	2003
4	20	0.1	Unknown	lgK:17.48(4SF)	2	ENS	773
5	25	0	Inf. Dilution	lgK:19.2(3SF)	0	ENS	6405
6	25	0.1	KNO3	lgK:16.8(0.2SD)	6	MGL	197
7	25	0.1	Unknown	lgK:17.43(4SF)	2	ENS	773
8	37	0.15	Blood Plasma	lgK:16.9(0.05SD)	0	ENS	94
9	20	0.1	KNO3	dH:-4.14(3SF)	2	MCL	1963
10	25	0.1	KNO3	dH:-7.1(2SF)	2	MCL	139

Reaction No. 2095



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:7.71(3SF)	0	MGL	1941
2	25	0.1	KNO3	lgK:6.8(0.05SD)	6	MGL	2054
3	25	0.1	KNO3	lgK:7.05(0.02SD)	4	MGL	6771

4	37	0.15	Blood Plasma	lgK:6.9(0.05SD)	4	ENS	94
5	37	0.15	NaCl	lgK:6.90(3SF)	5	MDG	1779
6	25	0.1	KNO3	dH:-0.7(0.1SD)	6	MCL	2054
7	25	0.1	KNO3	dH:-0.8(0.1SD)	5	MCL	6771
8	25	0.1	KNO3	dS:29.2(0.05SD)	6	EFE	2054

Reaction No. 2122							
EGTA-4 + Mn+2 = Mn+2_EGTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:12.28(4SF)	6	MGL	1956
2	25	0.1	KNO3	lgK:12.3(3SF)	4	MEF	999
3	25	0.1	Unknown	lgK:12.18(4SF)	6	ENS	773
4	37	0.15	Blood Plasma	lgK:12.0(0.05SD)	4	ENS	94
5	20	0.1	KNO3	dH:-8.16(3SF)	5	MCL	1956
6	25	0.1	KNO3	dH:-8.8(2SF)	5	MCL	139
7	20	0.1	KNO3	dS:21.5(3SF)	5	EFE	1956

Reaction No. 2123							
EGTA-4 + Mn+2 + H+1 = Mn+2_H+1_EGTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.6(3SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:16.0(0.05SD)	2	ENS	94

Reaction No. 2170							
EEDTA-4 + Mn+2 = Mn+2_EEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:13.2(3SF)	0	MGL	999
2	20	0.1	KNO3	lgK:13.76(4SF)	6	MGL	1956
3	37	0.15	Blood Plasma	lgK:13.4(0.05SD)	2	ENS	94
4	20	0.1	KNO3	dH:-5.9(2SF)	5	MCL	1956
5	25	0.1	KNO3	dH:-5.6(2SF)	5	MCL	139


Reaction No. 2171							
EEDTA-4 + Mn+2 + H+1 = Mn+2_H+1_EEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:16.5(0.05SD)	4	ENS	94

Reaction No. 2204							
NTA-3 + Mn+2 = Mn+2_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:8.527(4SF)	4	MHY	140
2	0	0	Inf. Dilution	lgK:8.525(4SF)	4	MGL	1118
3	10	0	Inf. Dilution	lgK:8.534(4SF)	4	MHY	140
4	20	0	Inf. Dilution	lgK:8.573(4SF)	4	MHY	140
5	20	0	Inf. Dilution	lgK:10.(2SF)	0	MGL	1118
6	20	0.1	KCl	lgK:7.44(3SF)	6	MGL	3486
7	20	0.1	KClO4	lgK:7.4(0.05SD)	4	MDS	931
8	20	0.1	KNO3	lgK:7.44(3SF)	6	CMN	1118
9	20	0.1	KNO3	lgK:8.6(2SF)	0	MEP	11516
Note (9): Jokl V, J. Chromatography, 1964, 14, 71							
10	20	0.1	NaClO4	lgK:7.36(3SF)	5	MDS	11516
Note (10): Stary J, Anal. Chim. Acta, 1963, 28, 132							
11	25	0	Inf. Dilution	lgK:8.573(4SF)	4	CRV	552
12	25	0	Inf. Dilution	lgK:8.7(2SF)	4	ENS	6405
13	25	0.1	Unknown	lgK:7.5(0.08SD)	6	CRV	552
14	25	0.15	NaCl	lgK:7.15(0.006SD)	4	MGL	3750
15	25	1	KCl	lgK:7.46(3SF)	5	MSP	2022
16	30	0	Inf. Dilution	lgK:8.644(4SF)	4	MHY	140
17	37	0.15	Blood Plasma	lgK:7.1(0.05SD)	3	ENS	94
18	20	0.1	KNO3	dH:1.3(2SF)	5	CMN	1118
19	20	0.1	KNO3	dH:1.44(3SF)	5	MCL	1118
20	20	0.1	KNO3	dH:1.14(3SF)	5	MCL	3683
21	25	0	Inf. Dilution	dH:1.4(2SF)	4	CRV	552
22	25	0.1	KNO3	dH:1.41(3SF)	5	MTD	6627

Reaction No. 2205							
2<NTA-3> + Mn+2 = Mn+2_NTA-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:11.60(4SF)	0	MEP	11516
Note (1): Jokl V, J. Chromatography, 1964, 14, 71							
2	20	0.1	Unknown	lgK:10.99(4SF)	3	ENS	773
3	25	0	Inf. Dilution	lgK:11.6(3SF)	4	ENS	6405
4	25	0.1	Unknown	lgK:10.94(4SF)	3	CRV	552


5	25	0.15	NaCl	lgK:10.20(0.02SD)	5	MGL	3750
6	37	0.15	Blood Plasma	lgK:9.8(0.05SD)	3	ENS	94
7	25	0.1	Unknown	dH:-4.1(2SF)	6	CRV	552

Reaction No. 2206




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-4.4(2SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:-4.4(0.05SD)	4	ENS	94

Reaction No. 2272




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:3.2(0.05SD)	4	ENS	94

Reaction No. 2273




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:6.2(0.05SD)	4	ENS	94

Reaction No. 2274




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:9.6(0.05SD)	3	ENS	94

Reaction No. 2339




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:22.6(0.05SD)	4	ENS	94

Reaction No. 2340



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Blood Plasma	lgK:23.9(0.05SD)	4	ENS	94


Reaction No. 2380



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:10.3(3SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:7.3(0.05SD)	4	ENS	94

Reaction No. 2381



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.5(3SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:15.2(0.05SD)	4	ENS	94

Reaction No. 2567



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	3.3	0.7	NaCl	lgK:8.6(0.05SD)	0	MSL	412
2	25	0	Inf. Dilution	lgK:10.7(3SF)	1	CRV	

Note (2): <http://www.saltlakemetals.com/SolubilityProducts.htm> (15/7/14)

3	25	0	Inf. Dilution	lgK:10.6(0.05SD)	2	MSL	412
4	25	0	Inf. Dilution	lgK:9.3(2SF)	0	ENS	773
5	25	0	Inf. Dilution	lgK:10.4(3SF)	3	ENS	5181
6	25	0	Inf. Dilution	lgK:10.65(4SF)	0	CRV	6330

Note (6): p. 8-58


7	25	0	Inf. Dilution	lgK:9.3(2SF)	0	CRV	6405
8	25	0	Inf. Dilution	lgK:10.39(4SF)	3	ENS	6496
9	25	0	Inf. Dilution	lgK:10.52(4SF)	3	CRV	9402
10	25	0	Inf. Dilution	lgK:9.29(3SF)	0	CRV	22551
11	25	0	Inf. Dilution	lgK:10.5(0.3SD)	3	CRV	24993
12	25	0	Inf. Dilution	lgK:10.31(4SF)	4	CRV	28992
13	25	0	CHEMVAL1	lgK:9.30(0.01SD)	0	ENS	5156
14	25	0	CHEMVAL2	lgK:9.30(0.01SD)	0	ENS	5156
15	25	0	CHEMVAL3	lgK:9.30(0.01SD)	0	ENS	5156
16	25	0	CHEMVAL4	lgK:10.50(0.01SD)	3	ENS	5156
17	25	0.5	Unknown	lgK:8.49(3SF)	0	CRV	552
18	25	0.7	NaCl	lgK:8.5(0.05SD)	0	MSL	412
19	25	3	(Na)ClO4	lgK:9.8(0.04SD)	4	MGL	5220
20	25	3	NaClO4	lgK:9.68(3SF)	6	CRV	552
21	50	0	Inf. Dilution	lgK:10.43(4SF)	3	CRV	28992
22	100	0	Inf. Dilution	lgK:10.84(4SF)	3	CRV	28992

23	150	0	Inf. Dilution	lgK:11.48 (4SF)	2	CRV	28992
24	200	0	Inf. Dilution	lgK:12.27 (4SF)	2	CRV	28992
25	3:25	0.7	NaCl	dH:-2.4 (0.4SD)	0	MSL	412
26	25	0	Inf. Dilution	dH:2. (0.3SD)	4	CRV	552
27	25	0	Inf. Dilution	dH:2.07 (3SF)	4	CRV	9402
28	25	0	Inf. Dilution	Cp:102.00 (5SF)	4	CRV	9402

Reaction No. 2568							
Acetic-1 + Mn+2 = Mn+2_Acetic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:1.36 (3SF)	3	MGL	8888
2	25	0	Inf. Dilution	lgK:1.40 (3SF)	4	MGL	381
3	25	0	Inf. Dilution	lgK:1.4 (0.05SD)	4	MGL	381
4	25	0	Inf. Dilution	lgK:1.20 (3SF)	5	MSC	477
5	25	0	Inf. Dilution	lgK:1.22 (3SF)	3	MGL	8888
6	25	0.1	NaCl	lgK:0.80 (0.004SD)	7	MGL	415
7	25	0.16	Unknown	lgK:0.61 (2SF)	5	MIX	419
8	25	1	NaClO4	lgK:0.7 (0.05SD)	4	MKN	516
9	50	0	Inf. Dilution	lgK:1.24 (3SF)	3	MGL	8888
10	75	0	Inf. Dilution	lgK:1.34 (3SF)	3	MGL	8888
11	100	0	Inf. Dilution	lgK:1.50 (3SF)	3	MGL	8888
12	125	0	Inf. Dilution	lgK:1.69 (3SF)	3	MGL	8888
13	150	0	Inf. Dilution	lgK:1.92 (3SF)	3	MGL	8888
14	175	0	Inf. Dilution	lgK:2.19 (3SF)	3	MGL	8888
15	200	0	Inf. Dilution	lgK:2.47 (3SF)	3	MGL	8888
16	225	0	Inf. Dilution	lgK:2.78 (3SF)	3	MGL	8888
17	250	0	Inf. Dilution	lgK:3.12 (3SF)	3	MGL	8888
18	275	0	Inf. Dilution	lgK:3.50 (3SF)	3	MGL	8888
19	300	0	Inf. Dilution	lgK:3.93 (3SF)	3	MGL	8888
20	325	0	Inf. Dilution	lgK:4.44 (3SF)	3	MGL	8888
21	350	0	Inf. Dilution	lgK:4.96 (3SF)	3	MGL	8888
22	25	0.1	Dioxan:Water 25:75Vol KCl	lgK:1.42 (3SF)	4	MPS	1511
23	25	0.1	Dioxan:Water 50:50Vol KCl	lgK:1.91 (3SF)	4	MPS	1511


24	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:1.97 (3SF)	4	MGL	6070
25	25	0.1	Dioxan:Water 75:25Vol KCl	lgK:2.18 (3SF)	4	MPS	1511

Reaction No. 2593




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.8 (2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:5.8 (2SF)	3	EOD	16981
3	25	0	Na+1 salt	lgK:6. (0.3SD)	0	ENS	4998

Reaction No. 2594




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.3 (2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:7.2 (2SF)	3	EOD	16981
3	25	0	Na+1 salt	lgK:7. (0.3SD)	0	ENS	4998

Reaction No. 2595




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaCl	lgK:0.75 (0.01SD)	6	MGL	415

Reaction No. 2596




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaCl	lgK:1.6 (0.04SD)	6	MGL	415

Reaction No. 2621



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.45 (3SF)	5	MGL	6073

Reaction No. 2627



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0.1	NaClO4	lgK:2.47 (3SF)	4	MGL	6073
---	----	-----	--------	----------------	---	-----	------

Reaction No. 2713							
F-1 + Mn+2 = Mn+2_F-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	100	0	P=500 Inf. Dilution	lgK:1.58 (3SF)	4	EOD	6495
2	150	0	P=500 Inf. Dilution	lgK:1.93 (3SF)	4	EOD	6495
3	200	0	P=500 Inf. Dilution	lgK:2.35 (3SF)	4	EOD	6495
4	250	0	P=500 Inf. Dilution	lgK:2.85 (3SF)	3	EOD	6495
5	300	0	P=500 Inf. Dilution	lgK:3.42 (3SF)	3	EOD	6495
6	100	0	P=1000 Inf. Dilution	lgK:1.53 (3SF)	4	EOD	6495
7	150	0	P=1000 Inf. Dilution	lgK:1.86 (3SF)	4	EOD	6495
8	200	0	P=1000 Inf. Dilution	lgK:2.24 (3SF)	4	EOD	6495
9	250	0	P=1000 Inf. Dilution	lgK:2.68 (3SF)	3	EOD	6495
10	300	0	P=1000 Inf. Dilution	lgK:3.16 (3SF)	3	EOD	6495
11	100	0	P=2000 Inf. Dilution	lgK:1.46 (3SF)	4	EOD	6495
12	150	0	P=2000 Inf. Dilution	lgK:1.75 (3SF)	4	EOD	6495
13	200	0	P=2000 Inf. Dilution	lgK:2.08 (3SF)	4	EOD	6495
14	250	0	P=2000 Inf. Dilution	lgK:2.45 (3SF)	3	EOD	6495
15	300	0	P=2000 Inf. Dilution	lgK:2.84 (3SF)	3	EOD	6495
16	100	0	P=3000 Inf. Dilution	lgK:1.41 (3SF)	4	EOD	6495
17	150	0	P=3000 Inf. Dilution	lgK:1.67 (3SF)	4	EOD	6495
18	200	0	P=3000 Inf. Dilution	lgK:1.97 (3SF)	4	EOD	6495
19	250	0	P=3000 Inf. Dilution	lgK:2.3 (2SF)	3	EOD	6495
20	300	0	P=3000 Inf. Dilution	lgK:2.64 (3SF)	3	EOD	6495

21	100	0	P=4000 Inf. Dilution	lgK:1.38 (3SF)	4	EOD	6495
22	150	0	P=4000 Inf. Dilution	lgK:1.62 (3SF)	4	EOD	6495
23	200	0	P=4000 Inf. Dilution	lgK:1.89 (3SF)	4	EOD	6495
24	250	0	P=4000 Inf. Dilution	lgK:2.19 (3SF)	3	EOD	6495
25	300	0	P=4000 Inf. Dilution	lgK:2.49 (3SF)	3	EOD	6495
26	100	0	P=5000 Inf. Dilution	lgK:1.36 (3SF)	4	EOD	6495
27	150	0	P=5000 Inf. Dilution	lgK:1.58 (3SF)	4	EOD	6495
28	200	0	P=5000 Inf. Dilution	lgK:1.83 (3SF)	4	EOD	6495
29	250	0	P=5000 Inf. Dilution	lgK:2.1 (2SF)	3	EOD	6495
30	300	0	P=5000 Inf. Dilution	lgK:2.38 (3SF)	3	EOD	6495
31	0	0	Inf. Dilution	lgK:1.35 (3SF)	5	EOD	6495
32	25	0	Inf. Dilution	lgK:1.6 (2SF)	4	CRV	552
33	25	0	Inf. Dilution	lgK:5.52 (3SF)	0	MPL	5398
34	25	0	Inf. Dilution	lgK:1.3 (2SF)	4	ENS	6405
35	25	0	Inf. Dilution	lgK:1.32 (3SF)	5	EOD	6495
36	25	0	Inf. Dilution	lgK:0.84 (2SF)	4	ENS	6496
37	25	0	Inf. Dilution	lgK:0.85 (2SF)	4	CRV	32224
38	25	0	CHEMVAL1	lgK:0.85 (0.01SD)	0	ENS	5156
39	25	0	CHEMVAL2	lgK:1.25 (0.01SD)	0	ENS	5156
40	25	0	CHEMVAL3	lgK:0.85 (0.01SD)	0	ENS	5156
41	25	0	CHEMVAL4	lgK:0.85 (0.01SD)	2	ENS	5156
42	25	0	UCT_Sea	lgK:1.46 (0.01SD)	4	EDH	5390
43	25	0.1	UCT_Sea	lgK:1.06 (0.01SD)	4	EDH	5390
44	25	0.1	Unknown	lgK:1.2 (2SF)	3	CRV	552
45	25	0.2	UCT_Sea	lgK:0.96 (0.01SD)	4	EDH	5390
46	25	0.3	UCT_Sea	lgK:0.91 (0.01SD)	4	EDH	5390
47	25	0.4	UCT_Sea	lgK:0.87 (0.01SD)	4	EDH	5390
48	25	0.5	UCT_Sea	lgK:0.85 (0.01SD)	4	EDH	5390
49	25	0.5	Unknown	lgK:0.9 (1SF)	6	CRV	552
50	25	0.6	UCT_Sea	lgK:0.83 (0.01SD)	4	EDH	5390


51	25	0.7	UCT_Sea	lgK:0.82(0.01SD)	4	EDH	5390
52	25	1	NaClO4	lgK:0.79(0.05SD)	4	MHY	301
53	25	1	NaClO4	lgK:0.6(0.05SD)	5	CMN	437
54	25	1	NaClO4	lgK:1.0(2SF)	0	MPL	437
55	25	1	NaClO4	lgK:0.62(2SF)	4	MIS	497
56	25	2	Unknown	lgK:0.9(1SF)	6	CRV	552
57	25	3	NaClO4	lgK:1.0(2SF)	3	MIS	437
58	50	0	Inf. Dilution	lgK:1.38(3SF)	5	EOD	6495
59	75	0	Inf. Dilution	lgK:1.5(2SF)	5	EOD	6495
60	100	0	Inf. Dilution	lgK:1.65(3SF)	4	EOD	6495
61	125	0	Inf. Dilution	lgK:1.82(3SF)	4	EOD	6495
62	150	0	Inf. Dilution	lgK:2.03(3SF)	4	EOD	6495
63	175	0	Inf. Dilution	lgK:2.25(3SF)	4	EOD	6495
64	200	0	Inf. Dilution	lgK:2.5(2SF)	4	EOD	6495
65	225	0	Inf. Dilution	lgK:2.78(3SF)	3	EOD	6495
66	250	0	Inf. Dilution	lgK:3.08(3SF)	3	EOD	6495
67	275	0	Inf. Dilution	lgK:3.44(3SF)	3	EOD	6495
68	300	0	Inf. Dilution	lgK:3.85(3SF)	3	EOD	6495
69	25	0.5	NaNO3	dH:3.25(3SF)	4	MCL	5398
70	25	0.5	Unknown	dH:2.8(2SF)	6	CRV	552
71	25	3	NaClO4	dH:3.6(5.SD)	3	MCL	437

Reaction No. 2776



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	LiClO4	lgK:2.6(0.2SD)	3	MRX	724
2	23	5.3	HClO4	lgR:2.4(2SF)	4	MSP	731
3	23	5.35	HClO4	lgR:2.20(3SF)	4	MSP	5398
4	23	6.1	HClO4	lgR:2.7(2SF)	4	MSP	731
5	25	2	HClO4	lgR:2.5(0.2SD)	3	MSP	437
6	25	6	HClO4	lgR:2.88(3SF)	4	MSP	730
7	25.2	2	HClO4	lgR:2.51(3SF)	3	MSP	733


Reaction No. 2829



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	0:60	0	Inf. Dilution	lgK:1.(1SF)	0	CRV	552
2	5	0.58	Cl-1 salt	lgK:1.26(0.02SD)	7	MPT	5219
3	10	0.58	Cl-1 salt	lgK:1.24(0.01SD)	7	MPT	5219
4	15	0.58	Cl-1 salt	lgK:1.23(0.003SD)	7	MPT	5219
5	25	0	Inf. Dilution	lgK:1.8(2SF)	4	MSL	140
6	25	0	Inf. Dilution	lgK:1.95(3SF)	4	ENS	5181
7	25	0	Inf. Dilution	lgK:1.3(0.05SD)	4	ENS	5495
8	25	0	Inf. Dilution	lgK:1.95(3SF)	4	ENS	6496
9	25	0	Inf. Dilution	lgK:2.2(2SF)	6	MSL	9040
10	25	0.29	NaCl	lgK:3.52(3SF)	0	MDM	140
11	25	0.58	Cl-1 salt	lgK:1.28(0.004SD)	7	MPT	5219
12	25	3	(Na)ClO4	lgK:0.3(0.08SD)	6	MGL	5220
13	25	3	NaClO4	lgK:0.5(0.05SD)	4	MGL	414
14	25	3	NaClO4	lgK:0.32(2SF)	4	MSL	5220
15	25	3	Unknown	lgK:0.45(2SF)	6	CRV	552
16	40	0.58	Cl-1 salt	lgK:1.33(0.009SD)	7	MPT	5219
17	55	0.58	Cl-1 salt	lgK:1.39(0.02SD)	7	MPT	5219

Reaction No. 2985



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.6(1SF)	5	EES	
2	25	3	LiClO4	lgK:0.1(0.1SD)	5	MIS	5456

Reaction No. 2986



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	12.4	3	NaClO4	lgK:0.2(0.05SD)	3	MKN	763
2	23	5	ClO4-1 salt	lgK:0.2(1SF)	3	MSP	2261
3	23	6	ClO4-1 salt	lgK:0.6(1SF)	3	MSP	2261
4	23	6	NaClO4	lgK:-0.7(0.2SD)	3	MSP	763
5	25	0	Inf. Dilution	lgK:-0.032(2SF)	0	ENS	7276
6	25	1.9	NaNO3	lgK:0.04(1SF)	3	MKN	2261
7	25	3	LiClO4	lgK:0.4(0.1SD)	4	MRX	5456
8	25	4	ClO4-1 salt	lgK:0.03(1SF)	3	MSP	2261
9	25	4	ClO4-1 salt	lgK:0.06(1SF)	3	MSP	2261

10	23	4	HClO ₄	lgR:-0.0177(0.05SD)	3	MSP	726
11	1:35	4	HClO ₄	dH:4.8(0.1SD)	5	MSP	728

Reaction No. 3017							
Cl-1 + Mn+2 = Mn+2_Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.69	HClO ₄	lgK:0.59(0.15SD)	0	MCE	12709
2	23	1.5	NaClO ₄	lgK:0.04(1SF)	0	MPL	140
3	25	0	Inf. Dilution	lgK:0.0(1SF)	0	MCN	140
4	25	0	Inf. Dilution	lgK:0.6(0.05SD)	4	ENS	557
5	25	0	Inf. Dilution	lgK:0.1(1SF)	3	MAC	931
6	25	0	Inf. Dilution	lgK:-0.14(2SF)	0	MGL	2261
Note (6): From:J.Sol.Chem,1975,4,1011. Logged in error.							
7	25	0	Inf. Dilution	lgK:0.61(2SF)	4	ENS	6496
8	25	0	Inf. Dilution	lgK:0.585(3SF)	4	ENS	7276
9	25	0	Inf. Dilution	lgK:1.10(3SF)	0	CRV	9402
10	25	0	Inf. Dilution	lgK:0.61(2SF)	4	CRV	32224
11	25	0	CHEMVAL1	lgK:0.61(0.01SD)	0	ENS	5156
12	25	0	CHEMVAL2	lgK:0.61(0.01SD)	0	ENS	5156
13	25	0	CHEMVAL3	lgK:0.61(0.01SD)	0	ENS	5156
14	25	0	CHEMVAL4	lgK:0.61(0.01SD)	5	ENS	5156
15	25	0	H(Cl,ClO ₄)/m	lgK:0.72(0.02SD)	3	MPT	5592
16	25	0	UCT_Sea	lgK:0.35(0.01SD)	4	EDH	5390
17	25	0.1	UCT_Sea	lgK:-0.04(0.01SD)	3	EDH	5390
18	25	0.2	UCT_Sea	lgK:-0.12(0.01SD)	3	EDH	5390
19	25	0.3	UCT_Sea	lgK:-0.12(0.01SD)	3	EDH	5390
20	25	0.4	UCT_Sea	lgK:-0.18(0.01SD)	3	EDH	5390
21	25	0.5	UCT_Sea	lgK:-0.19(0.01SD)	3	EDH	5390
22	25	0.6	UCT_Sea	lgK:-0.20(0.01SD)	3	EDH	5390
23	25	0.7	UCT_Sea	lgK:-0.20(0.01SD)	3	EDH	5390
24	25	1	H(Cl,ClO ₄)/m	lgK:0.14(0.02SD)	3	MPT	5592
25	25	1	NaClO ₄	lgK:-0.2(0.3SD)	3	EMN	516
26	25	1	NaClO ₄	lgK:0.04(1SF)	0	MIS	5398
27	25	1	NaClO ₄	lgK:-0.33(2SF)	5	MKN	5398
28	25	1.5	H(Cl,ClO ₄)/m	lgK:0.19(0.02SD)	3	MPT	5592
29	25	2	H(Cl,ClO ₄)/m	lgK:0.28(0.02SD)	4	MPT	5592

30	25	2.5	H(Cl,C1O4)/m	lgK:0.38(0.02SD)	4	MPT	5592
31	25	3	H(Cl,C1O4)/m	lgK:0.50(0.02SD)	3	MPT	5592
32	25	5	NaClO4	lgK:-0.77(2SF)	5	MPS	11814
33	25			lgK:0.20(2SF)	3	MES	5398
34	100	0	Inf. Dilution/m	lgK:1.20(0.02SD)	4	ESR	4914
35	120	0	Inf. Dilution/m	lgK:1.57(0.03SD)	4	ESR	4914
36	140	0	Inf. Dilution/m	lgK:1.94(0.03SD)	4	ESR	4914
37	170	0	Inf. Dilution/m	lgK:2.30(0.04SD)	4	ESR	4914
38	25	5	NaClO4	dH:0.0(1SF) kJ	5	MTD	11814
39	25	0.4	DMF Et4NClO4	lgK:3.69(0.05MD)	5	MGL	7205
40	25		DMF	lgK:3.81(3SF)	5	MES	5398
41	25	0.4	DMF Et4NClO4	dH:0.26(2SF)	5	MCL	7205
42	25		DMF	dH:-1.2(2SF)	4	MCL	5398
43	25	0.4	DMSO Et4NBF4	lgK:2.20(0.04MD)	5	MCL	7215
44	25	0.4	DMSO Et4NBF4	dH:1.48(3SF)	5	MCL	7215
45	25	0.1	DiMeAcetamide Et4NBF4	lgK:4.1(0.2MD)	5	MGL	7222
46	45	0.1	DiMeAcetamide Et4NBF4	lgK:4.6(0.3MD)	5	MGL	7222
47	25	0.1	DiMeAcetamide Et4NBF4	dH:4.45(3SF)	5	MCL	7222
48	45	0.1	DiMeAcetamide Et4NBF4	dH:5.04(3SF)	5	MCL	7222
49	25	0.1	HMPA Unknown	lgK:5.80(3SF)	5	ENS	7187
50	25	0.1	HMPA Unknown	dH:-0.41(2SF)	5	ENS	7187
51	23		Methanol	lgK:2.0(2SF)	0	MES	5398
52	25		Methanol	lgK:2.74(3SF)	4	MES	5398
53	25		Methanol:Water 11:89Mol	lgK:0.30(2SF)	4	MES	5398
54	25		Methanol:Water 26:74Mol	lgK:0.49(2SF)	4	MES	5398
55	25		Methanol:Water 43:57Mol	lgK:0.92(2SF)	4	MES	5398
56	25		Methanol:Water 54:46Mol	lgK:1.20(3SF)	4	MES	5398

57	25		Methanol:Water 67:33Mol	lgK:1.34 (3SF)	4	MES	5398
58	25		Methanol:Water 80:20Mol	lgK:1.82 (3SF)	4	MES	5398

Reaction No. 3018							
NO3-1 + Mn+2 = Mn+2_NO3-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL4	lgK:0.16 (0.01SD)	5	ENS	5156
2	25	0	LiClO4	lgK:0.20 (0.05SD)	4	MSL	5014
3	25	0	UCT_Sea	lgK:0.20 (0.01SD)	4	EDH	5390
4	25	0.1	UCT_Sea	lgK:-0.20 (0.01SD)	4	EDH	5390
5	25	0.2	UCT_Sea	lgK:-0.28 (0.01SD)	4	EDH	5390
6	25	0.3	UCT_Sea	lgK:-0.32 (0.01SD)	4	EDH	5390
7	25	0.4	UCT_Sea	lgK:-0.35 (0.01SD)	4	EDH	5390
8	25	0.5	LiClO4	lgK:-0.4 (0.05SD)	5	MSL	5014
9	25	0.5	UCT_Sea	lgK:-0.37 (0.01SD)	4	EDH	5390
10	25	0.6	UCT_Sea	lgK:-0.39 (0.01SD)	4	EDH	5390
11	25	0.7	UCT_Sea	lgK:-0.40 (0.01SD)	4	EDH	5390
12	25	1	LiClO4	lgK:-0.43 (0.05SD)	5	MSL	5014
13	25	1	NaClO4	lgK:-0.2 (0.05SD)	5	MKN	5398
14	25	2	LiClO4	lgK:-0.41 (0.05SD)	5	MSL	5014
15	25	3	LiClO4	lgK:-0.24 (0.05SD)	5	MSL	5014
16	25	4	LiClO4	lgK:-0.14 (0.05SD)	5	MSL	5014
17	25	1	NaNO3	lgR:-0.15 (0.06SD)	6	MDG	4701
18	25	1	NaNO3	dH:-4.74 (0.10SD) kJ	5	MDG	4701
19	23		Methanol	lgK:0.7 (1SF)	4	EES	5398
20	23	0.5	Propan-2-ol:Water 90:10Wgt Unknown	lgK:0.46 (2SF)	4	MCE	931

Reaction No. 3019							
2<NO3-1> + Mn+2 = Mn+2_NO3-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.4 (1SF)	2	CRV	32224
2	25	0	CHEMVAL4	lgK:0.50 (0.01SD)	5	ENS	5156
3	25	0	LiClO4	lgK:0.60 (0.05SD)	4	MSL	5014
4	25	0	UCT_Sea	lgK:0.60 (0.01SD)	4	EDH	5390

5	25	0.1	UCT_Sea	lgK:-0.04 (0.01SD)	4	EDH	5390
6	25	0.2	UCT_Sea	lgK:-0.20 (0.01SD)	4	EDH	5390
7	25	0.3	UCT_Sea	lgK:-0.30 (0.01SD)	4	EDH	5390
8	25	0.4	UCT_Sea	lgK:-0.37 (0.01SD)	4	EDH	5390
9	25	0.5	LiClO4	lgK:-0.30 (0.05SD)	2	MSL	5014
10	25	0.5	UCT_Sea	lgK:-0.43 (0.01SD)	4	EDH	5390
11	25	0.6	UCT_Sea	lgK:-0.47 (0.01SD)	4	EDH	5390
12	25	0.7	UCT_Sea	lgK:-0.50 (0.01SD)	4	EDH	5390
13	25	1	LiClO4	lgK:-0.70 (0.05SD)	5	MSL	5014
14	25	2	LiClO4	lgK:-0.92 (0.05SD)	2	MSL	5014
15	25	3	LiClO4	lgK:-0.77 (0.05SD)	5	MSL	5014
16	25	4	LiClO4	lgK:-0.72 (0.05SD)	5	MSL	5014
17	23	0.5	Propan-2-ol:Water 90:10Wgt Unknown	lgK:0.36 (2SF)	4	MCE	931

Reaction No. 3020							
Mn+2 + H+1_PO4-3 = Mn+2_H+1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.2	Pr4NC1	lgK:2.272 (4SF)	3	MGL	257
2	25	0.1	NaNO3	lgK:2.45 (0.01MD)	5	MGL	6412
3	25	0.2	Pr4NC1	lgK:2.58 (3SF)	4	MGL	257
4	25	0.5	NaClO4	lgK:2.9 (0.1SD)	0	MPL	5426
5	25	3	Li+1 salt	lgK:9.6 (2SF)	0	CRV	2556

Reaction No. 3021							
Mn+2 + 2<H+1_PO4-3> = Mn+2_H+1(2)_PO4-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaClO4	lgK:4.2 (0.1SD)	5	MPL	5426

Reaction No. 3022							
2<Cl-1> + Mn+2 = Mn+2_Cl-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.69	HClO4	lgK:0.26 (0.1SD)	3	MCE	12709
2	25	0	Inf. Dilution	lgK:0.04 (0.05SD)	0	ENS	557
3	25	0	Inf. Dilution	lgK:0.25 (2SF)	3	ENS	6496
4	25	0	Inf. Dilution	lgK:1.10 (3SF)	0	CRV	9402
5	25	0	Inf. Dilution	lgK:0.04 (1SF)	3	CRV	32224

6	25	0	CHEMVAL1	lgK:0.04 (0.01SD)	0	ENS	5156
7	25	0	CHEMVAL2	lgK:0.04 (0.01SD)	0	ENS	5156
8	25	0	CHEMVAL3	lgK:0.04 (0.01SD)	0	ENS	5156
9	25	0	CHEMVAL4	lgK:0.25 (0.01SD)	3	ENS	5156
10	25	0.4	DMF Et4NC1O4	lgK:6.1 (0.4MD)	5	MGL	7205
11	25	0.4	DMF Et4NC1O4	dH:6.38 (3SF)	5	MCL	7205

Reaction No. 3023							
Mn+2 + SO4-2 = Mn+2_SO4-2_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.2 (2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:3.4 (2SF)	0	ENS	557
3	25	0	Inf. Dilution	lgK:-2.78 (3SF)	3	CRV	28992
4	25	0	Inf. Dilution	lgK:-2.68 (3SF)	4	CRV	32224
5	25	0	CHEMVAL2	lgK:9.30 (3SF)	0	ENS	5156
6	25	0	CHEMVAL3	lgK:9.00000 (3.SD)	0	ENS	5156
7	25	0	CHEMVAL4	lgK:2.68 (3SF)	0	ENS	5156
8	50	0	Inf. Dilution	lgK:-1.90 (3SF)	3	CRV	28992
9	100	0	Inf. Dilution	lgK:-0.18 (2SF)	3	CRV	28992
10	150	0	Inf. Dilution	lgK:1.5 (2SF)	2	CRV	28992
11	200	0	Inf. Dilution	lgK:3.2 (2SF)	2	CRV	28992

Reaction No. 3024							
Mn+2 + SO4-2 + H2O = Mn+2_SO4-2_H2O_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.5 (0.05SD)	4	ENS	557

Reaction No. 3025							
H+1(2)_SiH2O4-2 + Mn+2 = MnO.SiO2(s) + 2<H+1> + H2O							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-10.3 (0.05SD)	3	ENS	557
2	25	0	Inf. Dilution	lgK:-9.72 (3SF)	3	CRV	32224

Reaction No. 3033							
MnO(s) + 2<H+1> = Mn+2 + H2O							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0	Inf. Dilution	lgK:17.7 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:18.4 (0.05SD)	0	ENS	557
3	25	0	Inf. Dilution	lgK:17.91 (4SF)	4	CRV	32224
4	25	0	CHEMVAL1	lgK:18.37 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL2	lgK:18.37 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL3	lgK:18.37 (0.01SD)	0	ENS	5156
7	25	0	CHEMVAL4	lgK:17.90 (0.01SD)	0	ENS	5156

Reaction No. 3034							
Mn+4 + e-1 = Mn+3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.3 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:25.5 (0.05SD)	0	ENS	557

Reaction No. 3035							
Mn+3 + e-1 = Mn+2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.6 (0.05SD)	0	ENS	557
2	25	0	Inf. Dilution	lgK:25.51 (4SF)	4	CRV	32224
3	25	0	CHEMVAL1	lgK:25.51 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:25.51 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:25.51 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:25.50 (0.01SD)	3	ENS	5156
7	25	3	HClO4	lgK:26.1 (0.05SD)	5	MEF	767
8	25	0	Inf. Dilution	E:1.5415 (5SF)	3	CRV	6330
9	25	0	Inf. Dilution	E:1.54 (3SF)	2	ENS	7276
10	25	0	Inf. Dilution	E:1.56 (3SF)	0	CRV	7761
11	25	0	Inf. Dilution	E:1.51 (3SF)	3	CRV	18118
12	25	0	Inf. Dilution	E:1.5 (2SF)	3	CRV	22551
13	25	3	LiClO4	E:1.559 (4SF)	2	ENS	7276
14	25	0	Inf. Dilution	dH:-98.7 (3SF) kJ	5	CRV	7761

Reaction No. 3036							
MnO4-1 + 8<H+1> + 5<e-1> = Mn+2 + 4<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:127.8 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:127.7 (0.05SD)	0	ENS	557

3	25	0	Inf. Dilution	lgK:127.5 (4SF)	0	CRV	6405
4	25	0	Inf. Dilution	lgK:127.79 (5SF)	4	CRV	32224
5	25	0	CHEMVAL1	lgK:127.28 (0.01SD)	0	ENS	5156
6	25	0	CHEMVAL2	lgK:127.82 (0.01SD)	0	ENS	5156
7	25	0	CHEMVAL3	lgK:127.82 (0.01SD)	0	ENS	5156
8	25	0	CHEMVAL4	lgK:128.00 (0.01SD)	2	ENS	5156
9	25	0	Inf. Dilution	E:1.507 (4SF)	0	CRV	6330
10	25	0	Inf. Dilution	E:1.5 (2SF)	0	ENS	7276
11	25	0	Inf. Dilution	E:1.507 (4SF)	0	ENS	7381
12	25	0	Inf. Dilution	E:1.507 (4SF)	0	CRV	7761
13	25	0	Inf. Dilution	E:1.51 (3SF)	0	CRV	22551
14	25	0	Inf. Dilution	dH:-177. (0.4SD)	0	ENS	766
15	25	0	Inf. Dilution	dH:-819.9 (4SF) kJ	3	CRV	7761

Reaction No. 3038							
Mn+3 + H+1(3)_PO4-3 = Mn+3_H+1(2)_PO4-3 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	LiClO4	lgK:1.3 (0.2SD)	3	MRX	725


Reaction No. 3039							
Mn+3 + H+1(3)_PO4-3 = Mn+3_H+1_PO4-3 + 2<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	LiClO4	lgK:1.5 (0.1SD)	5	MRX	725

Reaction No. 3040							
Mn+3 + 2<H+1(3)_PO4-3> = Mn+3_H+1(4)_PO4-3(2) + 2<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	LiClO4	lgK:2.9 (0.1SD)	5	MRX	725

Reaction No. 3041							
Mn+3 + H+1_SO4-2 = Mn+3_H+1_SO4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	2.7	HClO4	lgK:0.0800000 (0.1SD)	4	MSP	726
2	23	4.3	HClO4	lgK:0.2 (0.1SD)	4	MSP	726
3	23	5	HClO4	lgK:0.3 (0.1SD)	4	MSP	726
4	23	6.6	HClO4	lgK:0.4 (0.1SD)	4	MSP	726
5	23	8.2	HClO4	lgK:0.6 (0.1SD)	4	MSP	726


6	25	0	Inf. Dilution	lgK:1.13(3SF)	2	EAE	
---	----	---	---------------	---------------	---	-----	--

Reaction No. 3042




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.2(2SF)	1	EOR	
2	25	3	LiClO4	lgK:4.4(0.1SD)	3	MRX	724

Reaction No. 3043




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.9(2SF)	1	ELC	
2	25	3	LiClO4	lgK:4.9(0.2SD)	0	MRX	724

Reaction No. 3044




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	LiClO4	lgK:2.9(0.2SD)	3	MRX	724

Reaction No. 3045



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.015(4SF)	1	EOR	
2	25	2	HClO4	lgK:1.(0.05SD)	5	MKN	733
3	25	3.26	NaClO4	lgK:1.1(0.05SD)	5	MSP	732
4	25.2	2	HClO4	lgK:0.95(2SF)	4	MKN	140

Reaction No. 3046




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.162(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:6.(2.SD)	3	ENS	766
3	25	0	CHEMVAL1	lgK:5.11(0.01SD)	6	ENS	5156
4	25	0	CHEMVAL2	lgK:5.11(0.01SD)	6	ENS	5156
5	25	0	CHEMVAL3	lgK:5.11(0.01SD)	6	ENS	5156
6	25	0	CHEMVAL4	lgK:5.11(0.01SD)	6	ENS	5156
7	25	0	Inf. Dilution	dH:39.(2.SD)	5	ENS	766

Reaction No. 3055							
2<Mn+2> + H2O = Mn+2(2)_OH-1 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-10.6(0.05SD)	4	ENS	557
2	25	0	Inf. Dilution	lgK:-10.59(4SF)	2	CRV	32224
3	25	0	CHEMVAL1	lgK:-10.60(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:-10.60(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:-10.60(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:-10.10(0.01SD)	4	ENS	5156
7	25	0	UCT_Sea	lgK:-10.56(0.01SD)	3	EDH	5390
8	25	0.1	UCT_Sea	lgK:-10.32(0.01SD)	2	EDH	5390
9	25	0.2	UCT_Sea	lgK:-10.24(0.01SD)	0	EDH	5390
10	25	0.3	UCT_Sea	lgK:-10.20(0.01SD)	0	EDH	5390
11	25	0.4	UCT_Sea	lgK:-10.16(0.01SD)	0	EDH	5390
12	25	0.5	UCT_Sea	lgK:-10.14(0.01SD)	0	EDH	5390
13	25	0.6	UCT_Sea	lgK:-10.11(0.01SD)	2	EDH	5390
14	25	0.7	UCT_Sea	lgK:-10.09(0.01SD)	3	EDH	5390
15	25	1	Na2SO4	lgK:-9.9(0.1SD)	4	MGL	424

Reaction No. 3056							
2<Mn+2> + 3<H2O> = Mn+2(2)_OH-1(3) + 3<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-23.9(0.05SD)	4	ENS	557
2	25	0	Inf. Dilution	lgK:-23.87(4SF)	2	CRV	32224
3	25	0	CHEMVAL1	lgK:-23.90(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:-23.90(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:-23.90(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:-24.90(0.01SD)	3	ENS	5156
7	25	0	UCT_Sea	lgK:-23.90(0.01SD)	3	EDH	5390
8	25	0.1	UCT_Sea	lgK:-24.40(0.01SD)	2	EDH	5390
9	25	0.2	UCT_Sea	lgK:-24.53(0.01SD)	0	EDH	5390
10	25	0.3	UCT_Sea	lgK:-24.63(0.01SD)	0	EDH	5390
11	25	0.4	UCT_Sea	lgK:-24.69(0.01SD)	0	EDH	5390
12	25	0.5	UCT_Sea	lgK:-24.75(0.01SD)	0	EDH	5390
13	25	0.6	UCT_Sea	lgK:-24.79(0.01SD)	2	EDH	5390


14	25	0.7	UCT_Sea	lgK:-24.83(0.01SD)	3	EDH	5390
15	25	1	Na2SO4	lgK:-25.5(0.1SD)	4	MGL	424

Reaction No. 3060




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.01	Unknown	lgK:12.86(0.07SD)	5	MSL	747

Reaction No. 3061



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.69	HClO4	lgK:-0.36(0.08SD)	4	MCE	12709
2	25	0	Inf. Dilution	lgK:-0.4(0.07SD)	4	ENS	5458
3	25	0	Inf. Dilution	lgK:-0.31(2SF)	4	ENS	6496
4	25	0	Inf. Dilution	lgK:0.60(2SF)	0	CRV	9402
5	25	0	Inf. Dilution	lgK:-0.31(2SF)	4	CRV	32224
6	25	0	CHEMVAL1	lgK:-0.31(0.01SD)	0	ENS	5156
7	25	0	CHEMVAL2	lgK:-0.31(0.01SD)	0	ENS	5156
8	25	0	CHEMVAL3	lgK:-0.31(0.01SD)	0	ENS	5156
9	25	0	CHEMVAL4	lgK:-0.31(0.01SD)	5	ENS	5156
10	25	0.4	DMF Et4NClO4	lgK:10.0(0.1MD)	5	MGL	7205
11	25	0.4	DMF Et4NClO4	dH:7.6(2SF)	5	MCL	7205

Reaction No. 3066



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-118.3(4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-118.3(0.05SD)	0	ENS	557
3	25	0	Inf. Dilution	lgK:-118.4(4SF)	4	CRV	32224
4	25	0	CHEMVAL1	lgK:-118.44(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL2	lgK:-118.44(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL3	lgK:-118.44(0.01SD)	0	ENS	5156
7	25	0	CHEMVAL4	lgK:-118.00(0.01SD)	2	ENS	5156
8	25	0	Inf. Dilution	dH:150.(0.4SD)	3	ENS	766

Reaction No. 3069

NTA-3 + Mn+2 + Ala-1 = Mn+2_Ala-1_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.6(2SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:9.40(3SF)	6	ENS	94

Reaction No. 3074							
NTA-3 + Mn+3 = Mn+3_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:20.25(4SF)	6	MSP	1118
2	25	0	Inf. Dilution	lgK:20.6(3SF)	1	ESC	

Reaction No. 3120							
NTA-3 + Mn+2 + Gly-1 = Mn+2_Gly-1_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.5(3SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:9.40(3SF)	4	ENS	94

Reaction No. 3143							
2AmBenz-1 + Mn+2 = Mn+2_2AmBenz-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.99(2SF)	6	MGL	999

Reaction No. 3162							
HOEDTA-3 + Mn+2 = Mn+2_HOEDTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:10.9(3SF)	4	ENS	773
2	25	0.1	KNO3	lgK:10.75(4SF)	6	MGL	145
3	25	0.1	Unknown	lgK:11.4(0.1SD)	6	CRV	552
4	25	0.1	Unknown	lgK:10.8(3SF)	4	ENS	773
5	29.6	0.1	KCl	lgK:10.7(3SF)	4	MGL	999
6	25	0.1	KNO3	dH:-5.2(2SF)	5	MCL	139

Reaction No. 3163							
HOEDTA-3 + Mn+3 = Mn+3_HOEDTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18:22			lgK:13.55(4SF)	0	MSP	906
2	25	0.2	NaClO4	lgK:22.7(3SF)	4	MSP	999

Reaction No. 3274							
Dien + Mn+2 = Mn+2_Dien							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	1	KCl	lgK:3.99 (3SF)	5	MGL	6805
2	30	1	KNO3	lgK:3.99 (3SF)	5	MGL	6805
3	40	1	KCl	lgK:3.89 (3SF)	5	MGL	6805
4	40	1	KNO3	lgK:3.89 (3SF)	5	MGL	6805
5	30:40	1	KNO3	dH:-4. (1SF)	5	MTD	6805


Reaction No. 3275							
2<Dien> + Mn+2 = Mn+2_Dien(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Unknown	lgK:6.91 (3SF)	6	ENS	773
2	25	0.1	KCl	dH:-6.95 (3SF)	5	MCL	6538

Reaction No. 3306							
Pyridine + Mn+2 = Mn+2_Pyridine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	HNO3	lgK:0.14 (2SF)	0	MGL	999
Note (1): Strong NO3- binding?							
2	25	0.5	NH4NO3	lgK:0.14 (2SF)	0	MGL	999
3	25	1	NaClO4	lgK:1.86 (3SF)	6	MGL	999
4	25	1	NaClO4	dH:-2.4 (2SF)	5	MCL	999
5	25	0.1	DMF Et4NClO4	dH:-16.7 (0.7SD) kJ	4	MCL	2334
6	25	0.1	MeCN Et4NCl	lgK:2.74 (0.06MD)	5	MCL	4493
7	25	0.1	MeCN Et4NCl	dH:-25.3 (0.6MD) kJ	5	MCL	4493

Reaction No. 3369							
Tetren + Mn+2 = Mn+2_Tetren							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:6.60 (3SF)	5	ENS	1539
2	25	0.1	KCl	lgK:6.55 (3SF)	4	MGL	6619
3	25	0.1	KNO3	lgK:7.0 (2SF)	0	MGL	999
4	25	0.15	KClO4	lgK:7.62 (3SF)	0	MGL	999


5	35	0.15	KClO ₄	lgK:7.55 (3SF)	0	MGL	999
6	45	0.15	KClO ₄	lgK:7.46 (3SF)	0	MGL	999
7	25	0.1	KCl	dH:-3.70 (3SF)	5	MCL	6619
8	25:35	0.15	KClO ₄	dH:-3.67 (3SF)	0	MGL	999

Reaction No. 3437




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	16	0.1	Unknown	lgK:5.9 (0.04SD)	4	MKN	906
2	16	0.1	Unknown	lgK:6.2 (0.03SD)	4	MSP	999
3	20	0.01	Unknown	lgK:6.8 (2SF)	4	MGL	999
4	25	0.1	Unknown	lgK:6.24 (3SF)	4	ENS	773
5	25	0.1	Unknown	lgK:5.84 (3SF)	4	MKN	906
6	25	0.1	Dioxan:Water 60:40Vol NaClO ₄	lgK:7.62 (3SF)	5	MGL	3082

Reaction No. 3472




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:6.6 (2SF)	4	MGL	999
2	25	0	Inf. Dilution	lgK:6.94 (3SF)	6	MGL	999
3	25	0.1	KNO ₃	lgK:5.67 (3SF)	6	MGL	999
4	25	0.1	Dioxan:Water 60:40Wgt NaClO ₄	lgK:7.43 (3SF)	4	MGL	906

Reaction No. 3473



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:10.72 (4SF)	6	ENS	773


Reaction No. 3482



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO ₃	lgK:2.6 (2SF)	4	MGL	1988
2	25	0	Unknown	lgK:2.6 (2SF)	4	MGL	1660
3	25	0.01	Unknown	lgK:2.48 (3SF)	6	MSP	999
4	25	0.1	KCl	lgK:2.62 (3SF)	6	MDS	999


5	25	0.1	KCl	lgK:2.62 (3SF)	6	MDS	3075
6	25	0.1	Unknown	lgK:2.62 (3SF)	6	ENS	1384
7	25	0.3	NaClO ₄	lgK:2.6 (0.08SD)	5	MKN	3290
8	25	0.3	NaClO ₄	lgK:2.6 (0.2SD)	5	MPS	3290
9	25	1	Unknown	lgK:2.61 (3SF)	6	ENS	773
10	27	0.5	Unknown	lgK:2.5 (2SF)	4	MSP	999
11	30	1	KNO ₃	lgK:2.54 (3SF)	6	MDS	999
12	20	0.1	NaNO ₃	dH:-3.5 (2SF)	5	MCL	1988
13	30	1	KNO ₃	dH:-5.73 (3SF)	5	MCL	999
14	25	0.4	DMF Et ₄ NClO ₄	lgK:1.53 (3SF)	5	MCL	7257
15	25	0.4	DMF Et ₄ NClO ₄	dH:-1.4 (2SF)	5	MCL	7257
16	25	0.2	Methanol NaClO ₄	lgK:2.7 (2SF)	4	MKN	906

Reaction No. 3483




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:4.62 (3SF)	5	ENS	773
2	25	1	Unknown	lgK:4.47 (3SF)	5	ENS	773
3	30	1	KNO ₃	dH:-6.11 (3SF)	5	MCL	999

Reaction No. 3484



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:5.6 (2SF)	4	ENS	773
2	25	1	Unknown	lgK:6.0 (2SF)	4	ENS	773
3	30	1	KNO ₃	dH:-6.23 (3SF)	5	MCL	999

Reaction No. 3543



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.8 (0.05SD)	4	MGL	1959
2	25	0.1	Unknown	lgK:5.8 (2SF)	4	ENS	1396
3	25	0.1	KCl	dH:-3.0 (0.05SD)	5	MCL	1396

Reaction No. 3560

Phenanth + Mn+2 = Mn+2_Phenanth							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.13 (3SF)	5	MGL	999
2	20	0.1	NaNO3	lgK:4.13 (3SF)	6	MGL	1988
3	25	0.1	K2SO4	lgK:3.5 (2SF)	4	MRX	999
4	25	0.1	KCl	lgK:4.50 (3SF)	4	MDS	3075
5	25	0.1	KCl	lgK:4.10 (3SF)	6	MDS	3077
6	25	0.1	NaClO4	lgK:4.01 (0.01SD)	6	MGL	2961
7	25	0.15	K2SO4	lgK:4.18 (0.01SD)	5	MEF	906
8	35	0.1	KNO3	lgK:4.0 (0.05SD)	6	MPT	1618
9	20	0.1	NaNO3	dH:-3.5 (2SF)	5	MCL	1988
10	25	0.15	Ethanol:Water 50:50Wgt K2SO4	lgK:4.1 (0.03SD)	4	MEF	906
11	25	0.2	Methanol NaClO4	lgK:3.8 (2SF)	4	MKN	906

Reaction No. 3561							
2<Phenanth> + Mn+2 = Mn+2_Phenanth(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:7.61 (3SF)	6	MGL	1988
2	25	0.1	Unknown	lgK:7.3 (2SF)	4	ENS	773
3	25	0.15	K2SO4	lgK:7.1 (0.04SD)	4	MEF	906
4	20	0.1	NaNO3	dH:-7.0 (2SF)	5	MCL	1988
5	25	0.15	Ethanol:Water 50:50Wgt K2SO4	lgK:8.2 (0.04SD)	4	MEF	906

Reaction No. 3562							
3<Phenanth> + Mn+2 = Mn+2_Phenanth(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:10.3 (3SF)	4	MGL	1988
2	25	0.1	KCl	lgK:10.40 (4SF)	6	MDS	3077
3	25	0.1	Unknown	lgK:10.3 (3SF)	4	ENS	773
4	25	0.15	K2SO4	lgK:10.50 (0.02SD)	5	MEF	906
5	20	0.1	NaNO3	dH:-9.0 (2SF)	5	MCL	1988
6	25	0.15	Ethanol:Water 50:50Wgt K2SO4	lgK:11.69 (4SF)	4	MEF	906

Reaction No. 3605							
5MePhenanth + Mn+2 = Mn+2_5MePhenanth							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.28 (3SF)	6	MDS	3077

Reaction No. 3606							
2<5MePhenanth> + Mn+2 = Mn+2_5MePhenanth(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:7.61 (3SF)	5	MDS	3077

Reaction No. 3607							
3<5MePhenanth> + Mn+2 = Mn+2_5MePhenanth(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:11.21 (4SF)	4	MDS	3077
2	25	0.1	Unknown	lgK:15.3 (3SF)	0	CRV	2556

Reaction No. 3728							
Oxalic-2 + Mn+3 = Mn+3_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.4 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:10.4 (3SF)	1	EOR	
3	25	2	HClO4	lgK:9.98 (3SF)	5	MKN	733

Reaction No. 3729							
2<Oxalic-2> + Mn+3 = Mn+3_Oxalic-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.47 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:17.5 (3SF)	1	EOR	
3	25	2	Unknown	lgK:16.57 (4SF)	3	ENS	773

Reaction No. 3730							
3<Oxalic-2> + Mn+3 = Mn+3_Oxalic-2(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.89 (4SF)	1	EOR	
2	25	2	Unknown	lgK:18.42 (4SF)	6	ENS	773

Reaction No. 3784							
-------------------	--	--	--	--	--	--	--

Glycolic-1 + Mn+2 = Mn+2_Glycolic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.6 (2SF)	4	ENS	2152
2	25	0	Unknown	lgK:1.58 (3SF)	6	ENS	773
3	25	0.16	Unknown	lgK:1.06 (3SF)	5	MIX	419
4	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:2.48 (3SF)	5	MGL	6070


Reaction No. 3833							
Malonic-2 + Mn+2 = Mn+2_Malonic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:3.11 (3SF)	4	MGL	999
2	15	0	Inf. Dilution	lgK:3.19 (3SF)	4	MGL	999
3	23	0.035	KCl	lgK:3.29 (3SF)	0	MSP	5748
4	25	0	Inf. Dilution	lgK:3.28 (3SF)	4	ENS	773
5	25	0	Inf. Dilution	lgK:3.27 (3SF)	4	MGL	999
6	25	0	Inf. Dilution	lgK:3.292 (4SF)	4	EOD	12002
7	25	0	Inf. Dilution	lgK:3.33 (3SF)	4	CRV	18273
Note (7): Table 3, p. 85							
8	25	0	Inf. Dilution/m	lgK:3.19 (3SF)	4	MEF	104
9	25	0.04	Unknown	lgK:3.29 (3SF) w	3	MPH	999
10	25	0.1	NaClO4	lgK:2.7 (0.03SD)	3	MGL	125
11	25	0.16	Unknown	lgK:2.30 (3SF)	5	MIX	419
12	25	1	KCl	lgK:2.30 (3SF)	5	MSP	2022
13	35	0	Inf. Dilution	lgK:3.37 (3SF)	4	MGL	999
14	45	0	Inf. Dilution	lgK:3.48 (3SF)	4	MGL	999
15	25	0	Inf. Dilution	dH:3.7 (0.1SD)	4	MCL	5843
16	25	0	Unknown	dH:3.68 (3SF)	5	CMN	1394

Reaction No. 3871							
Maleic-2 + Mn+2 = Mn+2_Maleic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:1.68 (3SF)	6	MGL	1217
2	25	0.16	Unknown	lgK:1.68 (3SF)	5	MIX	419

Reaction No. 3897							
Mn+2 + H+1_Succinic-2 = Mn+2_H+1_Succinic-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Unknown	lgK:1.2 (2SF)	4	ENS	773
2	25	0.2	Unknown	lgK:0.7 (1SF)	4	ENS	773

Reaction No. 3946




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Unknown	lgK:1.1 (2SF)	4	ENS	773

Reaction No. 4014




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1:0.15	KCl	lgK:5.10 (3SF)	6	MGL	999
2	25	0.1	KCl	lgK:5.25 (3SF)	5	MGL	931
3	25	0.1	NaClO4	lgK:5.24 (3SF)	6	MGL	2122
4	25	1	NaClO4	lgK:4.77 (3SF)	6	MGL	5987

Reaction No. 4015




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:8.65 (3SF)	6	ENS	1539
2	25	0.1	Unknown	lgK:8.24 (3SF)	5	ENS	773
3	25	1	Unknown	lgK:8.19 (3SF)	6	ENS	773

Reaction No. 4049



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:0.72 (2SF)	6	ENS	773

Reaction No. 4074



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.8 (0.4SD)	5	MMR	3886
2	25	0	Inf. Dilution	lgK:2.15 (3SF)	4	MGL	140
3	25	0.02	Unknown	lgK:2.19 (3SF)	5	MGL	140
4	35	0.1	KNO3	lgK:2.6 (0.1SD)	6	MPT	1618
5	40	0.02	Unknown	lgK:1.99 (3SF)	5	MGL	140

Reaction No. 4116							
MIDA-2 + Mn+2 = Mn+2_MIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.40 (3SF)	6	MGL	3486
2	20	0.1	KCl	lgK:5.4 (0.1SD)	5	CRV	13242
3	20	0.1	KNO3	lgK:5.4 (2SF)	6	MGL	2040
4	25	0	Inf. Dilution	lgK:5.87 (3SF)	4	CRV	552
5	25	0.1	Unknown	lgK:5.39 (3SF)	6	CRV	552
6	20	0.1	KNO3	dG:-7.24 (3SF)	6	MGL	2040
7	20	0.1	KNO3	dH:0.56 (2SF)	5	MCL	2040
8	25	0.1	Unknown	dH:0.6 (1SF)	6	CRV	552
9	20	0.1	KNO3	dS:26.6 (3SF)	6	EFE	2040

Reaction No. 4117							
2<MIDA-2> + Mn+2 = Mn+2_MIDA-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:9.6 (0.1SD)	5	CRV	13242
2	20	0.1	KNO3	lgK:9.56 (3SF)	6	MGL	2040
3	25	0.1	Unknown	lgK:9.55 (3SF)	6	CRV	552
4	20	0.1	KNO3	dG:-12.83 (4SF)	6	MGL	2040
5	20	0.1	KNO3	dH:0.23 (2SF)	6	MCL	2040
6	25	0.1	Unknown	dH:0.2 (1SF)	6	CRV	552

Reaction No. 4148							
Picolinic-1 + Mn+2 = Mn+2_Picolinic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:3.57 (3SF)	6	MGL	999
2	25	0	Inf. Dilution	lgK:3.88 (3SF)	4	MGL	999
3	25	0	Inf. Dilution	lgK:4.0 (2SF)	4	ENS	6405

Reaction No. 4149							
2<Picolinic-1> + Mn+2 = Mn+2_Picolinic-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:6.32 (3SF)	0	ENS	773
2	25	0	Inf. Dilution	lgK:11.0 (3SF)	1	ELC	
3	25	0	Inf. Dilution	lgK:7.1 (2SF)	0	ENS	6405

Reaction No. 4150							
3<Picolinic-1> + Mn+2 = Mn+2_Picolinic-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:8.1(2SF)	4	ENS	773
2	25	0	Inf. Dilution	lgK:8.8(2SF)	4	ENS	6405

Reaction No. 4276							
Mn+2_DTPA-5 + H+1 = Mn+2_H+1_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:4.03(0.05SD)	2	CRV	13242
2	20	0.1	Unknown	lgK:4.64(3SF)	2	ENS	773
3	25	0.1	KNO3	lgK:4.40(3SF)	2	MGL	189

Reaction No. 4277							
Mn+2_DTPA-5 + Mn+2 = Mn+2(2)_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:2.09(3SF)	3	MEF	999
2	20	0.1	NaNO3	lgK:2.1(0.1SD)	2	CRV	13242
3	25	0	Inf. Dilution	lgK:3.33(3SF)	2	EAE	


Reaction No. 4278							
DTPA-5 + Mn+3 = Mn+3_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18:22			lgK:19.35(4SF)	3	MSP	906
2	20	1	NaClO4	lgK:31.06(4SF)	4	MSP	999
3	25	0	Inf. Dilution	lgK:35.5(3SF)	2	EAE	

Reaction No. 4321							
Mn+2_EGTA-4 + H+1 = Mn+2_H+1_EGTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:4.1(2SF)	4	ENS	773
2	25	0	Inf. Dilution	lgK:4.2(2SF)	1	ESC	

Reaction No. 4322							
EGTA-4 + Mn+3 = Mn+3_EGTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0.2	Unknown	lgK:22.7 (3SF)	4	ENS	773
---	----	-----	---------	----------------	---	-----	-----

Reaction No. 4374




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:14.65 (4SF)	4	MGL	906
2	25	0.1	KNO3	lgK:14.30 (4SF)	2	MHG	906
3	25	0.1	KNO3	lgK:14.7 (0.2SD)	4	CRV	13242
4	25	0.1	Unknown	lgK:16.0 (3SF)	0	ENS	773

Reaction No. 4375




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:8.74 (3SF)	3	MGL	999
2	25	0.1	KNO3	lgK:9.0 (0.2SD)	3	CRV	13242

Reaction No. 4376




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.45 (3SF)	6	MGL	999
2	25	0.1	KNO3	lgK:3.5 (2SF)	5	CRV	13242

Reaction No. 4377



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:6.3 (0.2SD)	5	CRV	13242
2	25	0.1	Unknown	lgK:6.54 (3SF)	6	ENS	773


Reaction No. 4563



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:4.28 (3SF)	6	MGL	999
2	20	0	Inf. Dilution	lgK:4.24 (3SF)	6	MGL	999
3	25	0	UCT_Sea	lgK:4.21 (0.01SD)	4	EDH	5390
4	25	0.1	NaClO4	lgK:4.07 (3SF)	6	MGL	999
5	25	0.1	UCT_Sea	lgK:3.90 (0.01SD)	4	EDH	5390
6	25	0.2	UCT_Sea	lgK:3.82 (0.01SD)	4	EDH	5390

7	25	0.3	UCT_Sea	lgK:3.80 (0.01SD)	4	EDH	5390
8	25	0.4	UCT_Sea	lgK:3.80 (0.01SD)	4	EDH	5390
9	25	0.5	UCT_Sea	lgK:3.81 (0.01SD)	4	EDH	5390
10	25	0.6	UCT_Sea	lgK:3.82 (0.01SD)	4	EDH	5390
11	25	0.7	UCT_Sea	lgK:3.84 (0.01SD)	4	EDH	5390
12	25			lgK:5.70 (3SF)	4	MPT	906
13	30	0	Inf. Dilution	lgK:4.18 (3SF)	6	MGL	999
14	30	0.26	Acetate buffer	lgK:3.40 (3SF)	5	MDS	3508
15	40	0	Inf. Dilution	lgK:4.11 (3SF)	6	MGL	999
16	25	0.1	NaClO ₄	dH:-1.5 (2SF)	5	MCL	999
17	30	0.26	Methanol:Water 20:80Vol Acetate buffer	lgK:3.32 (3SF)	5	MDS	3508

Reaction No. 4564




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:7.35 (3SF)	6	ENS	1539
2	25	0	Inf. Dilution	lgK:7.3 (2SF)	5	MGL	2360
3	25	0	UCT_Sea	lgK:7.30 (0.01SD)	4	EDH	5390
4	25	0	Unknown	lgK:7.30 (3SF)	6	ENS	773
5	25	0.1	UCT_Sea	lgK:6.81 (0.01SD)	4	EDH	5390
6	25	0.2	UCT_Sea	lgK:6.70 (0.01SD)	4	EDH	5390
7	25	0.3	UCT_Sea	lgK:6.67 (0.01SD)	4	EDH	5390
8	25	0.4	UCT_Sea	lgK:6.66 (0.01SD)	4	EDH	5390
9	25	0.5	UCT_Sea	lgK:6.67 (0.01SD)	4	EDH	5390
10	25	0.6	UCT_Sea	lgK:6.69 (0.01SD)	4	EDH	5390
11	25	0.7	UCT_Sea	lgK:6.71 (0.01SD)	4	EDH	5390
12	25			lgK:10.50 (4SF)	3	MPT	906

Reaction No. 4565



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	Unknown	lgK:3.86 (3SF)	6	ENS	773

Reaction No. 4605



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0.1	KNO3	lgK:3.95 (3SF)	6	MGL	999
2	25	2	Unknown	lgK:3.66 (3SF)	6	ENS	773

Reaction No. 4606							
2<Kojic-1> + Mn+2 = Mn+2_Kojic-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:6.78 (3SF)	6	ENS	773
2	25	2	Unknown	lgK:6.65 (3SF)	6	ENS	773

Reaction No. 4607							
3<Kojic-1> + Mn+2 = Mn+2_Kojic-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	2	Unknown	lgK:8.5 (2SF)	4	ENS	773

Reaction No. 4646							
Tiron-4 + Mn+2 = Mn+2_Tiron-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:8.30 (0.02SD)	5	MGL	3858
2	25	0.1	KNO3	lgK:8.6 (2SF)	4	MGL	6508
3	25	1	NaClO4	lgK:7.20 (3SF)	6	MGL	4734

Reaction No. 4647							
2<Tiron-4> + Mn+2 = Mn+2_Tiron-4(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:13.7 (0.05SD)	5	MGL	3858
2	25	1	NaClO4	lgK:12.75 (4SF)	6	MGL	4734

Reaction No. 4648							
3<Tiron-4> + Mn+2 = Mn+2_Tiron-4(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:17.6 (0.06SD)	5	MGL	3858
2	25	1	NaClO4	lgK:16.28 (4SF)	6	MGL	4734

Reaction No. 4649							
Mn+2 + H+1_Tiron-4 = Mn+2_H+1_Tiron-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Unknown	lgK:2.05 (3SF)	6	ENS	773

Reaction No. 4666							
SalAld-1 + Mn+2 = Mn+2_SalAld-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KCl	lgK:2.15 (3SF)	6	MGL	999
2	25	0.5	KNO3	lgK:2.10 (3SF)	6	MGL	183

Reaction No. 4667							
2<SalAld-1> + Mn+2 = Mn+2_SalAld-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KCl	lgK:4.0 (2SF)	4	MGL	999

Reaction No. 4692							
Tropolone-1 + Mn+2 = Mn+2_Tropolone-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:4.60 (3SF)	6	MSP	999

Reaction No. 4849							
2<3SHHis-1> + Mn+2 = Mn+2_3SHHis-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:8.6 (2SF)	5	CRV	2556

Reaction No. 4850							
3SHHis-1 + Mn+2 = Mn+2_3SHHis-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:4.1 (2SF)	5	CRV	2556

Reaction No. 4874							
dBiocytinSulfon-1 + Mn+2 = Mn+2_dBiocytinSulfon-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.44 (3SF)	5	MGL	6073

Reaction No. 4957							
AcHydroxam-1 + Mn+2 = Mn+2_AcHydroxam-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:4.0 (2SF)	5	MGL	3676

Reaction No. 4958							
2<AcHydroxam-1> + Mn+2 = Mn+2_AcHydroxam-1 (2)							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:6.9 (2SF)	5	MGL	3676


Reaction No. 5185							
Cat-2 + Mn+2 = Mn+2_Cat-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:9.03 (0.01SD)	4	EDH	5390
2	25	0	Unknown	lgK:7.47 (3SF)	5	ENS	773
3	25	0.1	KCl	lgK:7.5 (0.03SD)	5	MGL	999
4	25	0.1	NaClO4	lgK:7.97 (0.02SD)	5	MGL	125
5	25	0.1	UCT_Sea	lgK:7.90 (0.01SD)	4	EDH	5390
6	25	0.1	Unknown	lgK:7.72 (3SF)	5	ENS	773
7	25	0.2	UCT_Sea	lgK:7.68 (0.01SD)	4	EDH	5390
8	25	0.3	UCT_Sea	lgK:7.61 (0.01SD)	4	EDH	5390
9	25	0.4	UCT_Sea	lgK:7.54 (0.01SD)	4	EDH	5390
10	25	0.5	UCT_Sea	lgK:7.52 (0.01SD)	4	EDH	5390
11	25	0.6	UCT_Sea	lgK:7.50 (0.01SD)	4	EDH	5390
12	25	0.7	UCT_Sea	lgK:7.51 (0.01SD)	4	EDH	5390
13	35	0.1	KNO3	lgK:6.55 (3SF)	4	MGL	3565

Reaction No. 5186							
2<Cat-2> + Mn+2 = Mn+2_Cat-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:14.91 (0.01SD)	4	EDH	5390
2	25	0	Unknown	lgK:12.8 (3SF)	0	ENS	773
3	25	0.1	UCT_Sea	lgK:13.40 (0.01SD)	4	EDH	5390
4	25	0.1	Unknown	lgK:13.6 (3SF)	4	ENS	773
5	25	0.2	UCT_Sea	lgK:13.12 (0.01SD)	4	EDH	5390
6	25	0.3	UCT_Sea	lgK:13.01 (0.01SD)	4	EDH	5390
7	25	0.4	UCT_Sea	lgK:12.91 (0.01SD)	4	EDH	5390
8	25	0.5	UCT_Sea	lgK:12.89 (0.01SD)	4	EDH	5390
9	25	0.6	UCT_Sea	lgK:12.86 (0.01SD)	4	EDH	5390
10	25	0.7	UCT_Sea	lgK:12.87 (0.01SD)	4	EDH	5390

Reaction No. 5251							
NTA-3 + Mn+2 + His-1 = Mn+2_His-1_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:10.8 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:9.7 (2SF)	0	ESC	
3	37	0.15	Blood Plasma	lgK:9.50 (3SF)	3	ENS	94

Reaction No. 5252




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.6 (2SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:9.40 (3SF)	6	ENS	94

Reaction No. 5253




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.4 (2SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:9.20 (3SF)	6	ENS	94

Reaction No. 5400




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.9 (0.05SD)	4	ENS	94

Reaction No. 5401




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.0 (0.05SD)	3	ENS	94

Reaction No. 5456



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.0 (3SF)	1	ELC	
2	37	0.15	Blood Plasma	lgK:12.7 (0.05SD)	4	ENS	94


Reaction No. 5468



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	10	0.65	KCl	lgK:6.0 (2SF)	2	MGL	179
2	25	0.5	KNO3	lgK:4.87 (3SF)	0	MGL	183
3	25	0.5	Unknown	lgK:5.3 (2SF)	5	ENS	2350
4	25	0.65	KCl	lgK:5.7 (2SF)	2	MGL	179
5	27	0.3	Unknown	lgK:5.57 (3SF)	5	MMR	1174
6	37	0.15	Blood Plasma	lgK:5.5 (0.05SD)	0	ENS	94
7	37	0.15	KNO3	lgK:5. (0.3SD)	7	MGL	181

Reaction No. 5469



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.8 (3SF)	2	EAE	
2	27	0.3	Unknown	lgK:0.80 (2SF)	5	MMR	1174
3	37	0.15	KNO3	lgK:0.6 (0.5SD)	7	MGL	181

Reaction No. 5470



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0	NaCl/m	lgK:5.30 (0.05SD)	4	MGL	6128
2	5	0.01	NaCl/m	lgK:5.23 (0.05SD)	5	MGL	6128
3	5	0.04	NaCl/m	lgK:5.03 (0.05SD)	5	MGL	6128
4	5	0.09	NaCl/m	lgK:4.88 (0.05SD)	5	MGL	6128
5	5	0.5	Many Media	lgK:5.06 (0.10SD)	6	CMN	6128
6	10	0	NaCl/m	lgK:5.49 (0.04SD)	4	MGL	6128
7	10	0.01	NaCl/m	lgK:5.22 (0.04SD)	5	MGL	6128
8	10	0.04	NaCl/m	lgK:5.02 (0.04SD)	5	MGL	6128
9	10	0.09	NaCl/m	lgK:4.87 (0.04SD)	5	MGL	6128
10	10	0.65	KCl	lgK:4.71 (3SF)	6	MGL	179
11	15	0	NaCl/m	lgK:5.48 (0.03SD)	4	MGL	6128
12	15	0.01	NaCl/m	lgK:5.22 (0.03SD)	5	MGL	6128
13	15	0.04	NaCl/m	lgK:5.01 (0.03SD)	5	MGL	6128
14	15	0.09	NaCl/m	lgK:4.86 (0.03SD)	5	MGL	6128
15	15	0.5	Many Media	lgK:5.06 (0.10SD)	6	CMN	6128
16	20	0	NaCl/m	lgK:5.48 (0.03SD)	4	MGL	6128
17	20	0.01	NaCl/m	lgK:5.21 (0.03SD)	5	MGL	6128
18	20	0.01	Unknown	lgK:5.5 (2SF)	4	MGL	3514

19	20	0.01	Unknown	lgK:5.50 (3SF)	5	MGL	13488
20	20	0.04	NaCl/m	lgK:5.01 (0.02SD)	5	MGL	6128
21	20	0.09	NaCl/m	lgK:4.86 (0.02SD)	5	MGL	6128
22	20	0.1	KNO3	lgK:5.60 (3SF)	5	MEP	11516
Note (22): Jokl V, J. Chromatography, 1964, 14, 71							
23	20	0.1	Unknown	lgK:4.72 (3SF)	6	ENS	1539
24	25	0	Inf. Dilution	lgK:5.47 (0.02SD)	4	MPT	6128
25	25	0	NaCl/m	lgK:5.47 (0.02SD)	4	MGL	6128
26	25	0.01	NaCl/m	lgK:5.21 (0.02SD)	5	MGL	6128
27	25	0.01	Unknown	lgK:6.63 (3SF)	3	MGL	11516
Note (27): Maley L et al., Australian J. Sci. Res., 1949, 92, 579							
28	25	0.04	NaCl/m	lgK:5.00 (0.02SD)	5	MGL	6128
29	25	0.09	NaCl/m	lgK:4.85 (0.02SD)	5	MGL	6128
30	25	0.1	Unknown	lgK:4.8 (2SF)	6	CRV	552
31	25	0.5	KCl	lgK:4.7 (0.2SD)	4	MGL	180
32	25	0.5	KNO3	lgK:4.27 (3SF)	5	MGL	183
33	25	0.5	Many Media	lgK:5.05 (0.09SD)	6	CMN	6128
34	25	0.5	Unknown	lgK:4.6 (0.1SD)	6	CRV	552
35	25	0.5	Unknown	lgK:4.5 (2SF)	5	ENS	2350
36	25	0.65	KCl	lgK:4.58 (3SF)	6	MGL	179
37	27	0.3	Unknown	lgK:4.76 (3SF)	5	MMR	1174
38	30	0	NaCl/m	lgK:5.47 (0.02SD)	4	MGL	6128
39	30	0.01	NaCl/m	lgK:5.20 (0.02SD)	5	MGL	6128
40	30	0.04	NaCl/m	lgK:5.00 (0.02SD)	5	MGL	6128
41	30	0.09	NaCl/m	lgK:4.85 (0.01SD)	5	MGL	6128
42	35	0	NaCl/m	lgK:5.47 (0.02SD)	4	MGL	6128
43	35	0.01	NaCl/m	lgK:5.20 (0.02SD)	5	MGL	6128
44	35	0.04	NaCl/m	lgK:5.00 (0.02SD)	5	MGL	6128
45	35	0.09	NaCl/m	lgK:4.85 (0.01SD)	5	MGL	6128
46	35	0.5	Many Media	lgK:5.04 (0.09SD)	6	CMN	6128
47	37	0.15	Blood Plasma	lgK:4.8 (0.05SD)	4	ENS	94
48	37	0.15	KNO3	lgK:4.8 (0.06SD)	7	MGL	181
49	37	0.15	Unknown	lgK:4.7 (2SF)	6	CRV	552
50	40	0	NaCl/m	lgK:5.47 (0.02SD)	4	MGL	6128
51	40	0.01	NaCl/m	lgK:5.20 (0.02SD)	5	MGL	6128
52	40	0.04	NaCl/m	lgK:5.00 (0.02SD)	5	MGL	6128

53	40	0.09	NaCl/m	lgK:4.85 (0.02SD)	5	MGL	6128
54	45	0	NaCl/m	lgK:5.47 (0.03SD)	4	MGL	6128
55	45	0.01	NaCl/m	lgK:5.21 (0.03SD)	5	MGL	6128
56	45	0.04	NaCl/m	lgK:5.00 (0.03SD)	5	MGL	6128
57	45	0.09	NaCl/m	lgK:4.85 (0.02SD)	5	MGL	6128
58	45	0.5	Many Media	lgK:5.02 (0.11SD)	6	CMN	6128
59	5	0	NaCl/m	dH:-3.0 (2. SD) kJ	4	MTD	6128
60	10	0	NaCl/m	dH:-2.5 (2. SD) kJ	4	MTD	6128
61	15	0	NaCl/m	dH:-2.0 (2. SD) kJ	4	MTD	6128
62	20	0	NaCl/m	dH:-1.5 (2. SD) kJ	4	MTD	6128
63	25	0	Inf. Dilution	dH:-1.0 (2. SD) kJ	4	MCL	6128
64	25	0	NaCl/m	dH:-1.0 (2. SD) kJ	4	MTD	6128
65	25	0.65	KCl	dH:-3.3 (2SF)	5	MCL	179
66	30	0	NaCl/m	dH:-0.5 (2. SD) kJ	4	MTD	6128
67	35	0	NaCl/m	dH:0.0 (2. SD) kJ	4	MTD	6128
68	40	0	NaCl/m	dH:0.4 (2. SD) kJ	4	MTD	6128
69	45	0	NaCl/m	dH:0.9 (2. SD) kJ	4	MTD	6128

Reaction No. 5471

Gly-1 + Mn+2 = Mn+2_Gly-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution/m	lgK:3.199 (0.009SD)	4	MEF	185
2	5	0	NaCl/m	lgK:3.20 (0.01SD)	4	MGL	6128
3	5	0.01	NaCl/m	lgK:3.02 (0.01SD)	5	MGL	6128
4	5	0.04	NaCl/m	lgK:2.88 (0.01SD)	5	MGL	6128
5	5	0.09	NaCl/m	lgK:2.78 (0.02SD)	5	MGL	6128
6	5	0.5	Many Media	lgK:3.01 (0.04SD)	6	CMN	6128
7	10	0	Inf. Dilution	lgK:3.23 (0.02SD)	4	MGL	2491
8	10	0	NaCl/m	lgK:3.19 (0.01SD)	4	MGL	6128
9	10	0.01	NaCl/m	lgK:3.01 (0.01SD)	5	MGL	6128
10	10	0.04	NaCl/m	lgK:2.88 (0.01SD)	5	MGL	6128
11	10	0.09	NaCl/m	lgK:2.78 (0.02SD)	5	MGL	6128
12	10	0.65	KCl	lgK:2.66 (3SF)	6	MGL	179
13	15	0	Inf. Dilution/m	lgK:3.179 (0.009SD)	4	MEF	185
14	15	0	NaCl/m	lgK:3.18 (0.01SD)	4	MGL	6128
15	15	0.01	NaCl/m	lgK:3.01 (0.01SD)	5	MGL	6128

16	15	0.04	NaCl/m	lgK:2.87 (0.01SD)	5	MGL	6128
17	15	0.09	NaCl/m	lgK:2.78 (0.01SD)	5	MGL	6128
18	15	0.5	Many Media	lgK:3.00 (0.03SD)	6	CMN	6128
19	20	0	NaCl/m	lgK:3.18 (0.01SD)	4	MGL	6128
20	20	0.01	NaCl/m	lgK:3.00 (0.01SD)	5	MGL	6128
21	20	0.01	Unknown	lgK:3.2 (2SF)	5	MGL	13488
22	20	0.04	NaCl/m	lgK:2.87 (0.01SD)	5	MGL	6128
23	20	0.09	NaCl/m	lgK:2.77 (0.01SD)	5	MGL	6128
24	20	0.1	KNO3	lgK:3.9 (2SF)	0	MEP	11516
Note (24): Jokl V, J. Chromatography, 1964, 14, 71							
25	20	0.1	Unknown	lgK:2.80 (3SF)	6	ENS	1539
26	25	0	Inf. Dilution	lgK:3.19 (0.02SD)	4	CRV	552
27	25	0	Inf. Dilution	lgK:3.21 (0.02SD)	4	MGL	2491
28	25	0	Inf. Dilution	lgK:3.18 (0.01SD)	4	MPT	6128
29	25	0	Inf. Dilution	lgK:3.44 (3SF)	3	CRV	18273
Note (29): Table 3, p. 85							
30	25	0	Inf. Dilution	lgK:3.44 (3SF)	5	MGL	18471
31	25	0	Inf. Dilution/m	lgK:3.167 (0.006SD)	4	MEF	185
32	25	0	NaCl/m	lgK:3.18 (0.01SD)	4	MGL	6128
33	25	0.01	NaCl/m	lgK:3.00 (0.01SD)	5	MGL	6128
34	25	0.01	Unknown	lgK:3.66 (3SF)	2	MGL	11516
Note (34): Maley L et al., Australian J. Sci. Res., 1949, 92, 579							
35	25	0.04	NaCl/m	lgK:2.87 (0.01SD)	5	MGL	6128
36	25	0.09	NaCl/m	lgK:2.77 (0.01SD)	5	MGL	6128
37	25	0.1	KCl	lgK:2.85 (0.07SD)	4	MGL	184
38	25	0.1	KNO3	lgK:3.0 (2SF)	4	MGL	173
39	25	0.1	Many Media	lgK:2.80 (3SF)	8	CMN	3837
40	25	0.1	NaClO4	lgK:1.94 (3SF)	0	MGL	3733
41	25	0.1	Unknown	lgK:2.8 (0.05SD)	6	CRV	552
42	25	0.5	KCl	lgK:2.65 (3SF)	6	MGL	999
43	25	0.5	KNO3	lgK:2.56 (3SF)	6	MGL	183
44	25	0.5	Many Media	lgK:2.99 (0.03SD)	6	CMN	6128
45	25	0.5	Unknown	lgK:2.60 (3SF)	5	ENS	2350
46	25	0.65	KCl	lgK:2.60 (3SF)	6	MGL	179
47	25	1	KCl	lgK:2.65 (3SF)	5	MSP	2022
48	27	0.3	Unknown	lgK:2.71 (3SF)	5	MMR	1174

49	30	0	NaCl/m	lgK:3.17 (0.01SD)	4	MGL	6128
50	30	0.01	NaCl/m	lgK:3.00 (0.01SD)	5	MGL	6128
51	30	0.04	NaCl/m	lgK:2.87 (0.01SD)	5	MGL	6128
52	30	0.09	NaCl/m	lgK:2.77 (0.01SD)	5	MGL	6128
53	35	0	Inf. Dilution/m	lgK:3.161 (0.006SD)	4	MEF	185
54	35	0	NaCl/m	lgK:3.17 (0.01SD)	4	MGL	6128
55	35	0.01	NaCl/m	lgK:3.00 (0.01SD)	5	MGL	6128
56	35	0.04	NaCl/m	lgK:2.86 (0.01SD)	5	MGL	6128
57	35	0.09	NaCl/m	lgK:2.77 (0.01SD)	5	MGL	6128
58	35	0.1	KNO3	lgK:3.8 (0.06SD)	0	MGL	2371
59	35	0.5	Many Media	lgK:2.99 (0.03SD)	6	CMN	6128
60	37	0.15	Blood Plasma	lgK:2.7 (0.05SD)	4	ENS	94
61	37	0.15	KNO3	lgK:2.7 (0.03SD)	7	MGL	181
62	37	0.15	Unknown	lgK:2.72 (3SF)	6	CRV	552
63	40	0	Inf. Dilution	lgK:3.15 (0.02SD)	4	MGL	2491
64	40	0	NaCl/m	lgK:3.17 (0.01SD)	4	MGL	6128
65	40	0.01	NaCl/m	lgK:3.00 (0.01SD)	5	MGL	6128
66	40	0.04	NaCl/m	lgK:2.86 (0.01SD)	5	MGL	6128
67	40	0.09	NaCl/m	lgK:2.77 (0.02SD)	5	MGL	6128
68	45	0	Inf. Dilution/m	lgK:3.161 (0.006SD)	4	MEF	185
69	45	0	NaCl/m	lgK:3.17 (0.01SD)	4	MGL	6128
70	45	0.01	NaCl/m	lgK:2.99 (0.01SD)	5	MGL	6128
71	45	0.04	NaCl/m	lgK:2.86 (0.01SD)	5	MGL	6128
72	45	0.09	NaCl/m	lgK:2.77 (0.02SD)	5	MGL	6128
73	45	0.5	Many Media	lgK:2.99 (0.04SD)	6	CMN	6128
74	0:45	0	Inf. Dilution	dH:-0.3 (0.2SD)	4	MEF	185
75	0:45	0	Inf. Dilution/m	dH:-0.29 (0.08SD)	4	MCL	185
76	5	0	NaCl/m	dH:-2.0 (0.5SD) kJ	4	MTD	6128
77	10	0	Inf. Dilution	dH:-0.40 (0.02SD)	4	MCL	2491
78	10	0	NaCl/m	dH:-1.8 (0.4SD) kJ	4	MTD	6128
79	15	0	NaCl/m	dH:-1.5 (0.3SD) kJ	4	MTD	6128
80	20	0	NaCl/m	dH:-1.3 (0.3SD) kJ	4	MTD	6128
81	25	0	Inf. Dilution	dH:-0.3 (1SF)	4	CRV	552
82	25	0	Inf. Dilution	dH:-0.3 (0.1SD)	4	MCL	2491
83	25	0	Inf. Dilution	dH:-1.1 (0.2SD) kJ	4	MCL	6128
84	25	0	NaCl/m	dH:-1.1 (0.2SD) kJ	4	MTD	6128

85	25	0.65	KCl	dH:-1.4 (2SF)	5	MCL	179
86	30	0	NaCl/m	dH:-0.8 (0.3SD) kJ	4	MTD	6128
87	35	0	NaCl/m	dH:-0.6 (0.3SD) kJ	4	MTD	6128
88	40	0	Inf. Dilution	dH:-0.04 (0.1SD)	4	MCL	2491
89	40	0	NaCl/m	dH:-0.3 (0.4SD) kJ	4	MTD	6128
90	45	0	NaCl/m	dH:-0.1 (0.5SD) kJ	4	MTD	6128
91	25	0.1	DMF:Water 20:80Vol KNO3	lgK:3.18 (3SF)	5	MGL	3733
92	25	0.1	DMF:Water 40:60Vol KNO3	lgK:3.52 (3SF)	5	MGL	3733
93	25	0.1	DMF:Water 50:50Vol KNO3	lgK:3.67 (3SF)	5	MGL	3733
94	25	0.1	DMF:Water 60:40Vol KNO3	lgK:3.9 (2SF)	3	MGL	3733
95	25	0.1	DMF:Water 70:30Vol KNO3	lgK:4.3 (2SF)	5	MGL	3733
96	25	0.1	DMF:Water 75:25Vol KNO3	lgK:4.6 (2SF)	0	MGL	3733
97	25	0.1	DMF:Water 80:20Vol KNO3	lgK:4.7 (2SF)	0	MGL	3733
98	25	0.1	Dioxan:Water 20:80Vol NaClO4	lgK:3.43 (3SF)	5	MGL	3733
99	25	0.1	Dioxan:Water 40:60Vol NaClO4	lgK:3.8 (2SF)	3	MGL	3733
100	25	0.1	Dioxan:Water 50:50Vol NaClO4	lgK:4.1 (2SF)	3	MGL	3733
101	25	0.1	Dioxan:Water 60:40Vol NaClO4	lgK:4.4 (2SF)	3	MGL	3733
102	25	0.1	Dioxan:Water 70:30Vol NaClO4	lgK:4.7 (2SF)	3	MGL	3733
103	25	0.1	Dioxan:Water 75:25Vol NaClO4	lgK:4.9 (2SF)	0	MGL	3733
104	25	0.1	MeCN:Water 20:80Vol KNO3	lgK:3.36 (3SF)	5	MGL	3733

105	25	0.1	MeCN:Water 40:60Vol KNO3	lgK:3.74 (3SF)	5	MGL	3733
106	25	0.1	MeCN:Water 50:50Vol KNO3	lgK:3.9 (2SF)	3	MGL	3733
107	25	0.1	MeCN:Water 60:40Vol KNO3	lgK:4.2 (2SF)	3	MGL	3733
108	25	0.1	MeCN:Water 70:30Vol KNO3	lgK:4.4 (2SF)	3	MGL	3733
109	25	0.1	MeCN:Water 75:25Vol KNO3	lgK:4.6 (2SF)	3	MGL	3733
110	25	0.1	MeCN:Water 80:20Vol KNO3	lgK:4.8 (2SF)	0	MGL	3733
111	25	0.1	Methanol:Water 55:45Vol KNO3	lgK:3.55 (3SF)	5	MGL	3733
112	25	0.1	Methanol:Water 60:40Vol KNO3	lgK:3.57 (3SF)	5	MGL	3733
113	25	0.1	Methanol:Water 65:35Vol KNO3	lgK:3.65 (3SF)	5	MGL	3733
114	25	0.1	Methanol:Water 70:30Vol KNO3	lgK:3.76 (3SF)	5	MGL	3733
115	25	0.1	Methanol:Water 75:25Vol KNO3	lgK:3.87 (3SF)	5	MGL	3733
116	25	0.1	Methanol:Water 80:20Vol KNO3	lgK:4.01 (3SF)	5	MGL	3733

Reaction No. 5474							
Val-1 + Mn+2 + H+1 = Mn+2_H+1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:10.5 (0.05SD)	3	ENS	94

Reaction No. 5507							
EDTA-4 + Mn+3 = Mn+3_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18:20			lgK:17.35 (4SF)	0	MSP	906

2	22	0.2	NaClO ₄	lgK:27.3(0.2SD)	0	MJM	903
Note (2): Low wgt for internal consistency							
3	22	1	NaClO ₄	lgK:27.0(0.2SD)	3	MSP	906
4	23			lgK:14.76(4SF)	0	MPL	906
5	25	0	Inf. Dilution	lgK:27.23(4SF)	1	EOR	
6	25	0.1	Unknown	lgK:25.30(0.01SD)	6	CRV	552
7	25	0.2	KCl	lgK:24.9(3SF)	4	MRX	903
8	25	0.2	Many Media	lgK:24.85(4SF)	7	EIU	903
9	25	0.2	NaClO ₄	lgK:24.8(3SF)	4	MRX	903

Reaction No. 5600							
3<Val-1> + Mn+2 = Mn+2_Val-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.91(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.2(0.05SD)	6	ENS	94
3	37	0.15	KNO ₃	lgK:5.19(3SF)	6	MGL	181

Reaction No. 5901							
Mn+2_NTA-3 + Ser-1 = Mn+2_Ser-1_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO ₄	lgK:1.28(3SF)	4	MGL	905

Reaction No. 5909							
2<Val-1> + Mn+2 = Mn+2_Val-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.67(3SF)	2	EAE	
2	25	0.01	Unknown	lgK:5.56(3SF)	0	MGL	2392
3	37	0.15	KNO ₃	lgK:3.97(3SF)	6	MGL	181
4	37	0.15	Unknown	lgK:3.8(2SF)	6	CRV	552

Reaction No. 5929							
Val-1 + Mn+2 = Mn+2_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:2.86(3SF)	5	MGL	11516
Note (1): Vlasova N et al., Zhur. Neorg. Khim., 1985, 30, 1738							
2	25	0.01	Unknown	lgK:2.84(3SF)	3	MGL	2392
3	37	0.15	KNO ₃	lgK:2.3(0.09SD)	6	MGL	181


Reaction No. 6804							
Mn+2_EtDiAm + EtDiAm = Mn+2_EtDiAm(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.1 (2SF)	4	MGL	7112
2	25	1	KCl	lgK:2.10 (3SF)	5	MSP	2022
3	25	1.4	Unknown	lgK:2.10 (3SF)	4	MGL	115
4	30	1	KCl	lgK:2.06 (3SF)	5	MHY	140
5	25	0.1	DMF:Water 40:60Vol KNO3	lgK:2.26 (3SF)	5	MGL	3733
6	25	0.1	DMF:Water 50:50Vol KNO3	lgK:2.34 (3SF)	5	MGL	3733
7	25	0.1	DMF:Water 60:40Vol KNO3	lgK:2.47 (3SF)	5	MGL	3733
8	25	0.1	DMF:Water 70:30Vol KNO3	lgK:2.66 (3SF)	5	MGL	3733
9	25	0.1	DMF:Water 75:25Vol KNO3	lgK:2.76 (3SF)	5	MGL	3733
10	25	0.1	DMF:Water 80:20Vol KNO3	lgK:2.89 (3SF)	5	MGL	3733
11	25	0.1	Dioxan:Water 20:80Vol NaClO4	lgK:2.01 (3SF)	5	MGL	3733
12	25	0.1	Dioxan:Water 40:60Vol NaClO4	lgK:2.2 (2SF)	3	MGL	3733
13	25	0.1	Dioxan:Water 50:50Vol NaClO4	lgK:2.4 (2SF)	3	MGL	3733
14	25	0.1	Dioxan:Water 60:40Vol NaClO4	lgK:2.61 (3SF)	5	MGL	3733
15	25	0.1	Dioxan:Water 70:30Vol NaClO4	lgK:2.95 (3SF)	5	MGL	3733
16	25	0.1	Dioxan:Water 75:25Vol NaClO4	lgK:3.13 (3SF)	5	MGL	3733
17	25	0.1	Dioxan:Water 80:20Vol NaClO4	lgK:3.29 (3SF)	5	MGL	3733

18	25	0.1	MeCN:Water 40:60Vol KNO3	lgK:2.3 (2SF)	0	MGL	3733
19	25	0.1	MeCN:Water 50:50Vol KNO3	lgK:2.5 (2SF)	3	MGL	3733
20	25	0.1	MeCN:Water 60:40Vol KNO3	lgK:2.7 (2SF)	3	MGL	3733
21	25	0.1	MeCN:Water 70:30Vol KNO3	lgK:2.9 (2SF)	3	MGL	3733
22	25	0.1	MeCN:Water 75:25Vol KNO3	lgK:3.1 (2SF)	3	MGL	3733
23	25	0.1	MeCN:Water 80:20Vol KNO3	lgK:3.8 (2SF)	3	MGL	3733
24	25	0.1	Methanol:Water 55:45Vol KNO3	lgK:2.08 (3SF)	5	MGL	3733
25	25	0.1	Methanol:Water 60:40Vol KNO3	lgK:2.10 (3SF)	5	MGL	3733
26	25	0.1	Methanol:Water 65:35Vol KNO3	lgK:2.15 (3SF)	5	MGL	3733
27	25	0.1	Methanol:Water 70:30Vol KNO3	lgK:2.18 (3SF)	5	MGL	3733
28	25	0.1	Methanol:Water 75:25Vol KNO3	lgK:2.28 (3SF)	5	MGL	3733
29	25	0.1	Methanol:Water 80:20Vol KNO3	lgK:2.31 (3SF)	5	MGL	3733

Reaction No. 6834							
Mn+2_EtDiAm(2) + EtDiAm = Mn+2_EtDiAm(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:0.9 (1SF)	5	MGL	7112
2	25	1.4	Unknown	lgK:0.92 (2SF)	4	MGL	140
3	30	1	KCl	lgK:0.88 (2SF)	4	MHY	140
4	25	0.1	DMF:Water 50:50Vol KNO3	lgK:1.6 (2SF)	3	MGL	3733


5	25	0.1	DMF:Water 60:40Vol KNO3	lgK:1.85 (3SF)	5	MGL	3733
6	25	0.1	DMF:Water 70:30Vol KNO3	lgK:1.96 (3SF)	5	MGL	3733
7	25	0.1	DMF:Water 75:25Vol KNO3	lgK:2.03 (3SF)	5	MGL	3733
8	25	0.1	DMF:Water 80:20Vol KNO3	lgK:2.17 (3SF)	5	MGL	3733
9	25	0.1	Dioxan:Water 70:30Vol NaClO4	lgK:1.7 (2SF)	0	MGL	3733
10	25	0.1	Dioxan:Water 75:25Vol NaClO4	lgK:1.8 (2SF)	0	MGL	3733
11	25	0.1	Dioxan:Water 80:20Vol NaClO4	lgK:2.1 (2SF)	0	MGL	3733

Reaction No. 7056




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.43	HNO3	lgK:0.23 (2SF)	6	MGL	4431

Reaction No. 7202




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:0.69 (2SF)	3	MPL	2653
2	25	0.1	NaNO3	lgK:0.25 (2SF)	6	MPL	2654

Reaction No. 7203



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:0.64 (2SF)	3	MPL	2653
2	25	0.1	NaNO3	lgK:0.34 (2SF)	6	MPL	2654

Reaction No. 7213



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.2 (0.05SD)	7	CRV	5406


2	25	0.1	NaNO ₃	lgK:1.25 (3SF)	4	MGL	411
3	25	0.1	Unknown	lgK:1.2 (0.05SD)	7	CRV	5406
4	25	0.16	Unknown	lgK:1.65 (3SF)	0	MGL	140
5	25	0.5	KNO ₃	lgK:1.32 (3SF)	4	CRV	5406
6	30	0.16	KNO ₃	lgK:1.25 (3SF)	4	MSC	931

Reaction No. 7214




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.8 (0.05SD)	7	CRV	5406
2	25	0.1	Unknown	lgK:0.8 (0.05SD)	7	CRV	5406
3	25	0.16	KNO ₃	lgK:0.70 (2SF)	4	MSC	931
4	25	0.16	Unknown	lgK:1.25 (3SF)	0	MGL	140
5	25	0.5	KNO ₃	lgK:0.98 (2SF)	4	CRV	5406

Reaction No. 7389




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KCl	lgK:4.3 (2SF)	4	MGL	999
2	15	0.1	KCl	lgK:4.3 (2SF)	4	MGL	999
3	25	0.1	Unknown	lgK:4.38 (3SF)	6	MGL	999
4	35	0.1	KCl	lgK:4.48 (3SF)	6	MGL	999
5	40	0.1	KCl	lgK:4.3 (2SF)	4	MGL	999

Reaction No. 7390



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KCl	lgK:7.48 (3SF)	0	MGL	140
2	15	0.1	KCl	lgK:7.3 (2SF)	4	MGL	140
3	25	0.1	Unknown	lgK:7.56 (3SF)	5	MGL	140
4	35	0.1	KCl	lgK:7.70 (3SF)	5	MGL	140
5	40	0.1	KCl	lgK:7.3 (2SF)	4	MGL	140

Reaction No. 7470



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Unknown	lgK:11.2 (3SF)	0	ENS	1125

Note (1): Low wgt for internal consistency							
2	25	0.1	KCl	lgK:11.15 (4SF)	3	MGL	999

Reaction No. 7473							
EDTMP-8 + Mn+3 = Mn+3_EDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	NaNO3	lgK:12.70 (4SF)	4	MCV	3761

Reaction No. 7744							
2<H+1> + 25TDDS-4 + Mn+2 = Mn+2_H+1(2)_25TDDS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:12.1 (0.05SD)	4	MPS	1103

Reaction No. 7745							
H+1 + 25TDDS-4 + Mn+2 = Mn+2_H+1_25TDDS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:8.0 (0.02SD)	4	MPS	1103

Reaction No. 7746							
25TDDS-4 + Mn+2 = Mn+2_25TDDS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:2.49 (0.02SD)	6	MPS	1103

Reaction No. 8150							
Tartronic-2 + Mn+2 = Mn+2_Tartronic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KCl	lgK:2.37 (3SF)	6	MGL	1034

Reaction No. 8160							
Mn+2 + Uridine-1 = Mn+2_Uridine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:3.4 (0.03SD)	4	MGL	1275
2	25	0.1	KNO3	lgK:3.4 (0.03SD)	4	MGL	1275
3	35	0.1	KNO3	lgK:3.2 (0.03SD)	4	MGL	1031
4	45	0.1	KNO3	lgK:3.6 (0.03SD)	4	MGL	1275
5	25	0.1	KNO3	dH:5. (0.5SD)	5	MCL	1275

Reaction No. 8773							
-------------------	--	--	--	--	--	--	--

H+1 + AlaHydroxam-1 + Mn+2 = Mn+2_H+1_AlaHydroxam-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:10.9(0.05SD)	4	MGL	996

Reaction No. 8774							
AlaHydroxam-1 + Mn+2 = Mn+2_AlaHydroxam-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:3.47(0.01SD)	6	MGL	996

Reaction No. 8775							
AlaHydroxam-1 + Mn+2 = H+1 + Mn+2_H+1(-1)_AlaHydroxam-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:-5.99(0.02SD)	4	MGL	996

Reaction No. 8776							
H+1 + 2<AlaHydroxam-1> + Mn+2 = Mn+2_H+1_AlaHydroxam-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:14.3(0.07SD)	4	MGL	996

Reaction No. 8777							
2<AlaHydroxam-1> + Mn+2 = Mn+2_AlaHydroxam-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:6.0(0.03SD)	4	MGL	996

Reaction No. 9218							
Mn+2_NTA-3 + NTA-3 = Mn+2_NTA-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.7(2SF)	0	MGL	999
2	20	0.1	KNO3	lgK:3.55(3SF)	0	MGL	1118
3	20	0.1	KNO3	lgK:3.0(2SF)	5	MEP	11516
Note (3): Jokl V, J. Chromatography, 1964, 14, 71							
4	25	0.03	Unknown	lgK:3.02(0.02SD)	4	MMR	1118
5	25	0.15	NaCl	lgK:3.05(3SF)	5	MGL	3750
6	25	1	KCl	lgK:3.48(3SF)	5	MSP	2022
7	20	0.1	KNO3	dH:-5.58(3SF)	5	MCL	1118

Reaction No. 9265							
-------------------	--	--	--	--	--	--	--

Mn+2_NTA-3 + Gly-1 = Mn+2_Gly-1_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.073	KNO3	lgK:2.24(0.005SD)w	5	MPH	1206
2	25	0.1	KNO3	lgK:1.8(0.1SD)w	3	MPH	1118

Reaction No. 9281							
Mn+2_NTA-3 + Asp-2 = Mn+2_Asp-2_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.1(0.04SD)w	4	MPH	3535

Reaction No. 9287							
Mn+2_NTA-3 + GlyGly-1 = Mn+2_GlyGly-1_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.1(0.08SD)w	3	MPH	1118

Reaction No. 9305							
Mn+2_NTA-3 + Glu-2 = Mn+2_Glu-2_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.2(0.04SD)w	4	MPH	3535

Reaction No. 9313							
Mn+2_NTA-3 + His-1 = Mn+2_His-1_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.8(2SF)	2	ELC	
2	25	0.1	NaClO4	lgK:2.5(0.05SD)w	2	MPH	1118


Reaction No. 9321							
Mn+2_NTA-3 + ValOEt = Mn+2_ValOEt_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.077	KNO3	lgK:2.39(0.02SD)w	5	MPH	1206

Reaction No. 9327							
Mn+2_NTA-3 + Arg-1 = Mn+2_Arg-1_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:1.9(0.04SD)w	4	MPH	1118

Reaction No. 9492							
EDMA-1 + Mn+2 = Mn+2_EDMA-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KCl	lgK:3.63 (0.02SD)	6	MGL	1048

Reaction No. 9723




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:13.47 (4SF)	6	MGL	1050
2	25	0.2	KCl	dH:-26. (2SF) kJ	5	MCL	1050

Reaction No. 9724




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:17.8 (3SF)	4	MGL	1050
2	25	0.2	KCl	dH:-29. (2SF) kJ	5	MCL	1050

Reaction No. 9725




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:7.7 (2SF)	4	MGL	1050
2	25	0.2	KCl	dH:-5. (1SF) kJ	5	MCL	1050

Reaction No. 9726




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:12.72 (4SF)	6	MGL	1050
2	25	0.2	KCl	dH:-26. (2SF) kJ	5	MCL	1050

Reaction No. 9727



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:24.6 (3SF)	4	MGL	1050
2	25	0.2	KCl	dH:-51. (2SF) kJ	5	MCL	1050


Reaction No. 9728



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:15.7 (3SF)	4	MGL	1050


2	25	0.2	KCl	dH:-28. (2SF) kJ	5	MCL	1050
---	----	-----	-----	------------------	---	-----	------

Reaction No. 9729



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:5.6 (2SF)	4	MGL	1050
2	25	0.2	KCl	dH:13. (2SF) kJ	5	MCL	1050

Reaction No. 9730




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:6.42 (3SF)	3	MGL	11516

Note (1): Manorik P et al., Zhur. Neorg. Khim., 1983, 28, 2292


2	25	0.2	KCl	lgK:6.7 (2SF)	3	MGL	1050
3	25	0.2	KCl	dH:15. (2SF) kJ	3	MCL	1050

Reaction No. 10203




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:12.6 (0.04SD)	4	MGL	1093

Reaction No. 10204



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:7.0 (0.02SD)	4	MGL	1093

Reaction No. 10342



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.2	KNO3	lgK:1.49 (3SF)	0	MGL	999
2	20	0.1	KNO3	lgK:2.40 (3SF)	0	MGL	11516

Note (2): Berezina L et al., Zhur. Neorg. Khim., 1973, 18, 393

3	25	0	Inf. Dilution	lgK:3.6 (2SF)	1	EOR	
4	25	0	Unknown	lgK:3.30 (3SF)	3	MSC	11516

Note (4): Sychev A, Zhur. Neorg. Khim., 1964, 9, 1270

5	25	3	NaClO4	lgK:1.90 (3SF)	4	MGL	2161
6	40	0.2	KNO3	lgK:1.47 (3SF)	0	MGL	999

Reaction No. 10382							
PO4Ser-3 + Mn+2 = Mn+2_PO4Ser-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:3.9 (2SF)	4	MGL	140
2	25	0.2	KNO3	lgK:3.8 (0.03SD)	4	MGL	1370

Reaction No. 10383							
Mn+2 + H+1_PO4Ser-3 = Mn+2_H+1_PO4Ser-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:1.91 (3SF)	3	MGL	999
2	25	0.2	KNO3	lgK:2.3 (0.04SD)	2	MGL	1370

Reaction No. 10396							
Squaric-2 + Mn+2 = Mn+2_Squaric-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaClO4	lgK:1.51 (3SF)	6	MCG	999

Reaction No. 10455							
Fumaric-2 + Mn+2 = Mn+2_Fumaric-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:0.99 (2SF)	6	ESL	1217
2	25	0.16	Unknown	lgK:0.99 (2SF)	5	MIX	419

Reaction No. 10471							
OxAcet-2 + Mn+2 = Mn+2_OxAcet-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:1.58 (3SF)	4	MSP	1511
2	25	0.1	Unknown	lgK:2.8 (2SF)	4	MGL	999
3	25	0.5	KCl	lgK:1.23 (3SF)	4	MKN	1503
4	25	0.5	KCl	lgK:1.25 (3SF)	4	MPS	1503
5	25	0.1	Dioxan:Water 25:75Vol KCl	lgK:2.52 (3SF)	4	MSP	1511
6	25	0.1	Dioxan:Water 50:50Vol KCl	lgK:3.44 (3SF)	4	MSP	1511

Reaction No. 10472							
--------------------	--	--	--	--	--	--	--

Mn+2_OxAcet-2 + Mn+2 = Mn+2(2)_OxAcet-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:2.0 (2SF)	4	MGL	999

Reaction No. 10861							
2OH2MePropan-1 + Mn+2 = Mn+2_2OH2MePropan-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:1.49 (0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:1.10 (0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:1.02 (0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:0.98 (0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:0.95 (0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:0.93 (0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:0.92 (0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:0.91 (0.01SD)	4	EDH	5390
9	25	1	NaClO4	lgK:0.90 (2SF)	6	MQH	999

Reaction No. 10862							
Mn+2_2OH2MePropan-1 + 2OH2MePropan-1 = Mn+2_2OH2MePropan-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:0.58 (2SF)	6	MQH	999

Reaction No. 10863							
Mn+2_2OH2MePropan-1(2) + 2OH2MePropan-1 = Mn+2_2OH2MePropan-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:0.2 (1SF)	4	MQH	999

Reaction No. 10927							
Mn+2_Dien + Dien = Mn+2_Dien(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	1	KCl	lgK:2.83 (3SF)	5	MGL	6805
2	30	1	KNO3	lgK:2.83 (3SF)	5	MGL	6805
3	40	1	KCl	lgK:2.72 (3SF)	5	MGL	6805
4	40	1	KNO3	lgK:2.72 (3SF)	5	MGL	6805
5	30:40	1	KNO3	dH:-5. (1SF)	5	MTD	6805

Reaction No. 10950							
--------------------	--	--	--	--	--	--	--

ThioDiAcet-2 + Mn+2 = Mn+2_ThioDiAcet-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:1.7 (2SF)	5	MPT	2088
2	25	0.1	NaClO4	lgK:1.7 (0.1SD)	6	MGL	2502

Reaction No. 10951							
Mn+2 + H+1_ThioDiAcet-2 = Mn+2_H+1_ThioDiAcet-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:0.6 (0.2SD)	6	MGL	2502

Reaction No. 11301							
Mn+2_Thr-1 + Thr-1 = Mn+2_Thr-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.2	KNO3	lgK:1.39 (3SF)	3	MGL	999
2	25	0	Inf. Dilution	lgK:1.63 (3SF)	2	EAE	
3	37	0.15	NaCl	lgK:2.60 (3SF)	0	MGL	11516
Note (3): Xiliang X et al., Acta Chimica Sinica, 1986, , 1005							
4	40	0.2	KNO3	lgK:1.37 (3SF)	3	MGL	999


Reaction No. 11308							
HomoSer-1 + Mn+2 = Mn+2_HomoSer-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.47 (3SF)	6	MGL	999

Reaction No. 11327							
Etbis(ImMePhos)-4 + Mn+2 = Mn+2_Etbis(ImMePhos)-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:7.55 (3SF)	6	MGL	999
2	25	0.1	Unknown	lgK:7.25 (3SF)	6	MGL	999

Reaction No. 11425							
Mn+2_Acac-1 + Acac-1 = Mn+2_Acac-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:3.25 (3SF)	6	MGL	999
2	20	0	Inf. Dilution	lgK:3.11 (3SF)	6	MGL	999
3	25	0	Inf. Dilution	lgK:3.1 (2SF)	1	ESC	
4	30	0	Inf. Dilution	lgK:3.07 (3SF)	6	MGL	999


5	40	0	Inf. Dilution	lgK:2.96(3SF)	6	MGL	999
6	10:50	0	Inf. Dilution	dH:-4.7(2SF)	5	MCL	999

Reaction No. 11426




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	Unknown	lgK:3.86(3SF)	6	MGL	999

Reaction No. 11504




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.035	KCl	lgK:1.56(3SF)	4	MSP	5748
2	25	0.1	KNO3	lgK:1.13(3SF)	5	MGL	2551
3	25	0.1	NaClO4	lgK:1.5(2SF)	4	MPT	2088
4	25	0.16	Unknown	lgK:1.13(3SF)	5	MIX	419

Reaction No. 11635




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.15(3SF)	2	EAE	
2	27	0.3	Unknown	lgK:1.15(3SF)	3	MMR	1173
3	37	0.15	KNO3	lgK:1.5(0.1SD)	3	MGL	181

Reaction No. 11636




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.53(3SF)	2	EAE	
2	27	0.3	Unknown	lgK:1.53(3SF)	5	MMR	1173
3	37	0.15	KNO3	lgK:1.74(3SF)	7	MGL	181

Reaction No. 11646



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	Unknown	lgK:1.77(3SF)	5	MIX	419

Reaction No. 11661



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.16 (3SF)	6	MGL	3486
2	25	0.1	NaClO4	lgK:4.0 (0.2SD)	4	ENS	999
3	20	0.1	KNO3	dH:0.23 (2SF)	5	MCL	999

Reaction No. 11733							
Mn+2_Val-1 + Val-1 = Mn+2_Val-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.7 (2SF)	1	ELC	
2	25	0.01	Unknown	lgK:2.72 (3SF)	0	MGL	999
3	37	0.15	KNO3	lgK:1.63 (3SF)	5	MGL	181

Reaction No. 11746							
Mn+2 + H+1_Orn-1 = Mn+2_H+1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	HBr	lgK:2. (1SF)	3	MGL	6024
2	20			lgK:2. (1SF)	0	MGL	6000
3	25	0.1	KNO3	lgK:1.60 (3SF)	6	MGL	3511

Reaction No. 11767							
Mn+2_Met-1 + Met-1 = Mn+2_Met-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:2.05 (3SF)	3	MEF	11516
Note (1): Berezina I et al., Zhur. Neorg. Khim., 1973, 18, 393							
2	20	0.1	KNO3	lgK:1.5 (2SF)	3	MEP	11516
Note (2): Jokl V, J. Chromatography, 1964, 14, 71							
3	25	0.1	KNO3	lgK:1.80 (3SF)	3	MGL	3516

Reaction No. 11816							
Mn+2_Cat-2 + Cat-2 = Mn+2_Cat-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.7 (0.1SD)	4	MGL	999

Reaction No. 11817							
Mn+2 + H+1 (2)_Cat-2 = Mn+2_H+1_Cat-2 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:-6.41 (3SF)	6	MGL	999

Reaction No. 11818							
$\text{Mn}^{+2} + \text{H}^{+1}(2)_{\text{Cat-2}} = \text{Mn}^{+2}_{\text{Cat-2}} + 2\text{H}^{+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:-14.66(0.02SD)	6	MGL	999
2	25	1	KNO3	lgK:-14.807(5SF)	6	MGL	999

Reaction No. 11819							
$\text{Mn}^{+2}_{\text{Cat-2}} + \text{H}^{+1}(2)_{\text{Cat-2}} = \text{Mn}^{+2}_{\text{Cat-2}}(2) + 2\text{H}^{+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-16.8(3SF)	1	ELC	
2	25	1	KNO3	lgK:-16.996(5SF)	5	MGL	999

Reaction No. 11922							
$\text{Mn}^{+2}_{\text{Kojic-1}} + \text{Kojic-1} = \text{Mn}^{+2}_{\text{Kojic-1}}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.83(3SF)	6	MGL	999

Reaction No. 12017							
$\text{H}^{+1} + \text{NorEpinephrine-2} + \text{Mn}^{+2} = \text{Mn}^{+2}_{\text{H}^{+1}\text{NorEpinephrine-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:16.93(0.01SD)	4	MGL	1222

Reaction No. 12018							
$\text{NorEpinephrine-2} + \text{Mn}^{+2} = \text{Mn}^{+2}_{\text{NorEpinephrine-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:7.44(0.02SD)	6	MGL	1222

Reaction No. 12019							
$\text{H}^{+1} + 2\text{NorEpinephrine-2} + \text{Mn}^{+2} = \text{Mn}^{+2}_{\text{H}^{+1}\text{NorEpinephrine-2}}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:22.0(0.2SD)	3	MGL	1222

Reaction No. 12020							
$2\text{NorEpinephrine-2} + \text{Mn}^{+2} = \text{Mn}^{+2}_{\text{NorEpinephrine-2}}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:12.07(0.02SD)	4	MGL	1222

Reaction No. 12039							
H+1 + Epinephrine-2 + Mn+2 = Mn+2_H+1_Epinephrine-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:17.56(0.01SD)	6	MGL	1222

Reaction No. 12040							
Epinephrine-2 + Mn+2 = Mn+2_Epinephrine-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:7.7(0.03SD)	4	MGL	1222

Reaction No. 12042							
H+1 + 2<Epinephrine-2> + Mn+2 = Mn+2_H+1_Epinephrine-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:22.5(0.2SD)	3	MGL	1222

Reaction No. 12043							
2<Epinephrine-2> + Mn+2 = Mn+2_Epinephrine-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:12.46(0.02SD)	6	MGL	1222

Reaction No. 12121							
Tricarballic-3 + Mn+2 = Mn+2_Tricarballic-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	Unknown	lgK:1.99(3SF)	5	MIX	491

Reaction No. 12154							
Thiaproline-1 + Mn+2 = Mn+2_Thiaproline-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:1.9(0.02SD)	4	MGL	1231

Reaction No. 12214							
Isocitric-3 + Mn+2 = Mn+2_Isocitric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NC1	lgK:1.76(3SF)	4	MGL	906
2	25	0.16	Unknown	lgK:2.55(3SF)	5	MIX	419

Reaction No. 12228							
2AmMePyridine + Mn+2 = Mn+2_2AmMePyridine							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO ₃	lgK:2.66(3SF)w	6	MPH	1967
2	25	0.1	Unknown	lgK:2.66(3SF)	6	ENS	1384
3	25	0.15	NaCl	lgK:2.4(0.03SD)	6	MPT	3627

Reaction No. 12403

Mn+2_Picolinic-1 + Picolinic-1 = Mn+2_Picolinic-1(2)

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.08(3SF)	6	MGL	999

Reaction No. 12531

Mn+2_His-1 + His-1 = Mn+2_His-1(2)

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.2	KNO ₃	lgK:2.43(3SF)	5	MGL	6048
2	25	0.1	KCl	lgK:2.96(3SF)	3	MGL	11516
Note (2): Davidenko N et al., Zhur. Neorg. Khim., 1980, 25, 883							
3	25	3	NaClO ₄	lgK:2.70(3SF)	4	MGL	2157
4	37	0.15	KNO ₃	lgK:2.9(0.09SD)	4	MGL	2126
5	40	0.2	KNO ₃	lgK:2.39(3SF)	0	MGL	6048

Reaction No. 12600

12BisCOOMeThioEthan-2 + Mn+2 = Mn+2_12BisCOOMeThioEthan-2

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO ₄	lgK:1.0(0.08SD)	5	MGL	2503

Reaction No. 12601

Mn+2 + H+1_12BisCOOMeThioEthan-2 = Mn+2_H+1_12BisCOOMeThioEthan-2

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO ₄	lgK:0.7(0.1SD)	5	MGL	2503

Reaction No. 12690

GlyGlyGly-1 + Mn+2 = Mn+2_GlyGlyGly-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.41(0.005SD)	6	MHY	2618
2	35	0.09	KCl	lgK:1.85(3SF)	5	MGL	140

Reaction No. 12756

HIMDA-2 + Mn+2 = Mn+2_HIMDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.55 (3SF)	6	MGL	3486
2	20	0.1	KNO3	lgK:6.4 (2SF)	0	MSC	999
3	25	0.1	Unknown	lgK:5.6 (0.2SD)	6	CRV	552
4	30	0.1	KCl	lgK:5.65 (3SF)	6	MGL	999
5	25	0.1	Unknown	dH:0.4 (1SF)	6	CRV	552

Reaction No. 12757							
Mn+2_HIMDA-2 + HIMDA-2 = Mn+2_HIMDA-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.76 (3SF)	6	MGL	3486
2	20	0.1	KNO3	lgK:3.3 (2SF)	4	MSC	999
3	30	0.1	KCl	lgK:3.93 (3SF)	6	MGL	999

Reaction No. 12853							
Mn+2_Leu-1 + Leu-1 = Mn+2_Leu-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:1.8 (2SF)	0	MEP	11516
Note (1): Jokl V et al., J.Chromatography, 1964, 14, 71							
2	25	0.01	Unknown	lgK:2.67 (3SF)	2	MGL	999

Reaction No. 12867							
DHEGly-1 + Mn+2 = Mn+2_DHEGly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Many Media	lgK:3.10 (3SF)	7	CMN	3837
2	29.5	0.1	KCl	lgK:3.27 (3SF)	6	MGL	999
3	30	0.1	KCl	lgK:3.15 (3SF)	6	MGL	999
4	30	0.1	Unknown	lgK:3.18 (3SF)	6	CRV	552

Reaction No. 12868							
Mn+2_DHEGly-1 + DHEGly-1 = Mn+2_DHEGly-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	29.5	0.1	KCl	lgK:2.33 (3SF)	6	MGL	999
2	30	0.1	KCl	lgK:2.33 (3SF)	6	MGL	999

Reaction No. 13002							
--------------------	--	--	--	--	--	--	--

Mn+2_Salicylic-2 + Salicylic-2 = Mn+2_Salicylic-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1:0.15	KCl	lgK:3.9(2SF)	4	MGL	140
2	25	0	Inf. Dilution	lgK:3.9(3SF)	2	EAE	

Reaction No. 13037							
34DHB-3 + Mn+2 = Mn+2_34DHB-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:7.22(3SF)	5	MGL	140

Reaction No. 13038							
Mn+2_34DHB-3 + 34DHB-3 = Mn+2_34DHB-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:5.06(3SF)	5	MGL	140


Reaction No. 13097							
6Me2AmMePyridine + Mn+2 = Mn+2_6Me2AmMePyridine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:1.95(3SF)w	6	MPH	1967

Reaction No. 13161							
Pimelic-2 + Mn+2 = Mn+2_Pimelic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.33(0.02SD)	5	MGL	2610
2	25	0.16	Unknown	lgK:1.08(3SF)	5	MIX	419

Reaction No. 13187							
35DiNitrSal-2 + Mn+2 = Mn+2_35DiNitrSal-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.3(2SF)	1	EDH	
2	25	0	KCl	lgK:4.36(3SF)	6	MPT	3101
3	25	0.1	KCl	lgK:3.52(3SF)	6	MPT	3101
4	30	0.1	NaClO4	lgK:3.06(3SF)	0	MPT	906
5	35	0	KCl	lgK:4.45(3SF)	6	MPT	3101
6	35	0.1	KCl	lgK:3.61(3SF)	6	MPT	3101
7	35	0.1	KNO3	lgK:2.95(3SF)	0	MGL	906
8	45	0	KCl	lgK:4.53(3SF)	6	MPT	3101

9	45	0.1	KCl	lgK:3.69 (3SF)	6	MPT	3101
10	25:45	0.1	KCl	dH:14.05 (4SF) kJ	2	MCL	3101

Reaction No. 13283




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:5.01 (3SF)	6	MEF	999
2	25	0	Unknown	lgK:5.0 (2SF)	4	MGL	1660

Reaction No. 13284




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:3.48 (3SF)	6	MEF	999

Reaction No. 13329




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.8 (2SF)	1	EDH	
2	25	0	Inf. Dilution	lgK:5.83 (3SF)	4	MGL	2612
3	25	0.1	KCl	lgK:4.99 (3SF)	5	MGL	2612
4	30	0.1	NaClO4	lgK:4.41 (3SF)	0	MPT	906
5	35	0	Inf. Dilution	lgK:5.94 (3SF)	4	MGL	2612
6	35	0.1	KCl	lgK:5.10 (3SF)	5	MGL	2612
7	45	0	Inf. Dilution	lgK:6.03 (3SF)	4	MGL	2612
8	45	0.1	KCl	lgK:5.19 (3SF)	5	MGL	2612
9	25:45	0.1	KCl	dH:18.15 (0.12SD) kJ	3	MCL	2612

Reaction No. 13384




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1:0.15	KCl	lgK:2.90 (3SF)	5	MGL	140
2	25	0.1	KCl	lgK:3.4 (2SF)	4	MGL	931
3	25	0.1	NaClO4	lgK:3.00 (3SF)	6	MGL	2122
4	25	1	NaClO4	lgK:3.42 (3SF)	6	MGL	5987

Reaction No. 13396




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.87(3SF)	6	MGL	999

Reaction No. 13424



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:2.3(0.1SD)	5	MMR	3886
2	25	0.02	Unknown	lgK:2.29(3SF)	5	MGL	140

Reaction No. 13425




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.02	Unknown	lgK:2.04(3SF)	5	MGL	140

Reaction No. 13551




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:7.62(3SF)	6	ENS	1539

Reaction No. 13612




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:1.7(0.1SD)	5	MGL	2504

Reaction No. 13613




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:0.6(0.2SD)	5	MGL	2504

Reaction No. 13652



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.50(3SF)	5	MGL	6073

Reaction No. 13731



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:5.8(2SF)	4	MGL	999

2	25	0.1	Dioxan:Water 60:40Vol NaClO4	lgK:6.70 (3SF)	5	MGL	3082
---	----	-----	------------------------------------	----------------	---	-----	------

Reaction No. 13807




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:4.9 (2SF)	4	MGL	999
2	25	0.1	KNO3	lgK:5.05 (3SF)	6	MGL	999
3	25	0.1	Dioxan:Water 60:40Wgt NaClO4	lgK:6.31 (3SF)	4	MGL	906

Reaction No. 13860




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.00 (3SF)	6	MDS	3075
2	25	0.1	Unknown	lgK:2.00 (3SF)	3	ENS	125
3	30	1	KNO3	lgK:1.85 (3SF)	6	MDS	999
4	25	0.4	DMF Et4NClO4	lgK:0.69 (2SF)	5	MCL	7257
5	25	0.4	DMF Et4NClO4	dH:-1.7 (2SF)	5	MCL	7257

Reaction No. 13861



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:1.1 (2SF)	3	MDS	3075
2	30	1	KNO3	lgK:1.51 (3SF)	6	MDS	999


Reaction No. 13875



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:9.37 (3SF)	6	MGL	1964
2	25	0.1	KCl	lgK:9.30 (3SF)	5	MCL	6618
3	25	0.1	KNO3	lgK:9.24 (3SF) w	6	MPH	1965
4	25	0.1	Unknown	lgK:9.3 (2SF)	4	MGL	1218
5	25	0.1	KCl	dH:-8.85 (0.01SD)	5	MCL	6618
6	25	0.1	KNO3	dH:-8.85 (3SF)	5	MCL	1965


7	25	0.1	Unknown	dH:-8.85 (3SF)	5	MCL	1394
---	----	-----	---------	----------------	---	-----	------

Reaction No. 13936




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.96 (3SF)	6	MGL	999

Reaction No. 13937



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.92 (3SF)	6	MGL	999

Reaction No. 13971




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.11 (3SF)	6	MGL	999

Reaction No. 13972




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.86 (3SF)	6	MGL	999

Reaction No. 14106



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:8.95 (3SF)	3	MGL	2006
2	20	0.1	KNO3	lgK:11.7 (3SF)	0	MEP	2006
3	25	0	Inf. Dilution	lgK:10.77 (4SF)	4	CRV	29666
4	25	0.15	Cl-1 salt	lgK:8.95 (3SF)	5	MGL	17919
5	30	0.1	KNO3	lgK:5.11 (3SF)	0	MGL	906

Reaction No. 14183




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:4.97 (0.02SD)	0	MGL	3482
2	1	0.2	Me4NBr	lgK:5.444 (4SF)	0	MGL	3469
3	1.5	0.0085	NETmorph buffer	lgK:5.869 (4SF)	0	MEP	3468

4	3	0.2	Me4NBr	lgK:5.446(4SF)	0	MGL	3469
5	8	0.2	Me4NBr	lgK:5.482(4SF)	0	MGL	3469
6	11.8	0.0085	NEtMorph buffer	lgK:5.69(3SF)	0	MEP	3468
7	12	0.1	KNO3	lgK:4.82(0.02SD)	3	MGL	3482
8	13	0.2	Me4NBr	lgK:5.542(4SF)	0	MGL	3469
9	20	0.1	KCl	lgK:4.52(3SF)	2	MGL	1437
10	22	0.1	KCl	lgK:4.78(3SF)	4	MGL	1437
11	22	0.2	Me4NBr	lgK:5.705(4SF)	0	MGL	3469
12	22	0.25	KNO3	lgK:4.55(3SF)	3	MGL	1437
13	23	0.1	NaCl	lgK:4.75(3SF)	3	MIX	1437
14	23	0.1	NaCl	lgK:4.75(3SF)	5	MIX	31154
15	23	0.25	NaCl	lgK:4.13(3SF)	2	MIX	1437
16	24.8	0.0085	NEtMorph buffer	lgK:5.518(4SF)	0	MEP	3468
17	24.8	0.11	NaCl	lgK:4.75(3SF)	5	MEP	3468
18	25	0	Na+1 salt	lgK:6.49(3SF)	4	MIS	1437
19	25	0.1	KCl	lgK:4.51(3SF)	0	MIX	999
20	25	0.1	KCl	lgK:4.85(3SF)	4	MGL	1437
21	25	0.1	KNO3	lgK:4.70(3SF)	4	MGL	1437
22	25	0.1	KNO3	lgK:4.78(0.02SD)	5	MGL	3482
23	25	0.1	Me4N+ salt	lgK:5.1(0.07SD)	4	CIU	1437
24	25	0.1	NaClO4	lgK:4.70(0.02SD)	3	MGL	125
25	25	0.1	NaClO4	lgK:5.3(0.04SD)	0	MGL	1297
Note (25): Low wgt for internal consistency							
26	25	0.1	NaClO4	lgK:5.01(0.025SD)	3	MGL	1369
27	25	0.1	NaClO4	lgK:4.91(0.02SD)	6	MGL	2961
28	25	0.1	Unknown	lgK:4.58(3SF)	6	MSP	999
29	25	0.12	NaCl	lgK:4.56(3SF)	2	MGL	1437
30	25	0.15	NaCl	lgK:4.7(0.05SD)	5	MGL	3750
31	25	0.2	Pr4NC1	lgK:3.982(4SF)	0	MGL	257
32	26	0.11	NaCl	lgK:4.60(3SF)	3	MIX	3468
33	28	0.1	Na+1 salt	lgK:4.49(3SF)	0	MEP	1437
34	30	0.1	Et4NBr	lgK:4.94(3SF)	5	MGL	999
35	30	0.1	Me4NBr	lgK:5.19(0.02SD)	2	MGL	1437
36	31.8	0.0085	NEtMorph buffer	lgK:4.447(4SF)	0	MEP	3468
37	33	0.2	Me4NBr	lgK:5.959(4SF)	0	MGL	3469
38	35	0.1	KNO3	lgK:5.25(3SF)	2	MGL	1437


39	37	0.15	KCl	lgK:5.15 (3SF)	0	MEP	1437
40	37	0.15	Na+1 salt	lgK:4.8 (0.07SD)	8	CIU	1437
41	40	0.1	KNO3	lgK:4.63 (0.02SD)	0	MGL	3482
42	41	0.11	NaCl	lgK:4.52 (3SF)	0	MIX	3468
Note (42): Low wgt for internal consistency							
43	41	0.2	Me4NBr	lgK:6.176 (4SF)	0	MGL	3469
44	47.2	0.0085	NEtMorph buffer	lgK:5.342 (4SF)	0	MEP	3468
45	64	0.1	Unknown	lgK:4.99 (3SF)	6	MSP	999
46	1:43	0.2	Me4NBr	dH:9.0 (2SF)	0	MTD	3469
47	1:47	0.2	Me4NBr	dH:9. (1SF)	0	MTD	3469
48	2:47	0.1	NEtMorph buffer	dH:-4.9 (2SF)	0	MTD	3468
49	6	0.2	Me4NBr	dH:3.2 (0.1SD)	3	MTD	3470
50	15	0.2	Me4NBr	dH:4. (0.2SD)	5	MTD	3470
51	25	0.1	Inert	dH:18.0 (0.2SD) kJ	5	CIU	1437
52	25	0.1	KNO3	dH:-3.0 (2SF)	0	MTD	3482
53	26:41	0.1	NaCl	dH:-2.51 (3SF)	0	MCL	1437
54	30	0.2	Me4NBr	dH:4.6 (0.2SD)	5	MTD	3470

Reaction No. 14202



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	0.1	KCl	lgK:10.4 (3SF)	4	MGL	999
2	25	0.1	NaClO4	lgK:10.7 (3SF)	4	MGL	6082

Reaction No. 14203



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:2.55 (0.02SD)	4	MGL	3482
2	12	0.1	KNO3	lgK:2.50 (0.02SD)	5	MGL	3482
3	20	0.1	KCl	lgK:2.61 (3SF)	4	MGL	1437
4	25	0	Inf. Dilution	lgK:4.0 (2SF)	1	EDH	
5	25	0	Na+1 salt	lgK:4.57 (3SF)	0	MIS	1437
6	25	0.1	KCl	lgK:2.93 (3SF)	4	MGL	1437
7	25	0.1	KNO3	lgK:2.39 (0.02SD)	0	MGL	3482
8	25	0.1	Me4N+ salt	lgK:2.7 (0.09SD)	8	CIU	1437
9	25	0.1	NaClO4	lgK:2.74 (0.03SD)	4	MGL	1369

10	25	0.1	NaClO ₄	lgK:3.20 (3SF)	0	MGL	1437
11	25	0.15	NaCl	lgK:2.80 (3SF)	4	MGL	1437
12	25	0.2	Pr ₄ NC1	lgK:1.566 (4SF)	0	MGL	257
13	30	0.1	Et ₄ NBr	lgK:2.84 (3SF)	6	MGL	999
14	30	0.1	Me ₄ NBr	lgK:2.6 (0.05SD)	0	MGL	1437
15	35	0.1	KNO ₃	lgK:3.11 (3SF)	4	MGL	1437
16	40	0.1	KNO ₃	lgK:2.30 (0.02SD)	0	MGL	3482
17	25	0.1	KNO ₃	dH:-2. (0.3SD)	0	MCL	3482

Reaction No. 14204							
Mn+2 + H+1(2)_5ATP-4 = Mn+2_H+1(2)_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.03 (3SF)	2	MGL	1437
2	25	0	Inf. Dilution	lgK:3.1 (2SF)	1	EDH	
3	25	0.1	NaClO ₄	lgK:2.77 (3SF)	0	MGL	1437
4	25	0.15	NaCl	lgK:2.29 (3SF)	4	MGL	1437

Reaction No. 14364							
TriMDTA-4 + Mn+2 = Mn+2_TriMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO ₃	lgK:9.99 (3SF)	6	MGL	1956
2	20	0.1	Unknown	lgK:10.0 (3SF)	5	ENS	2373
3	25	0.1	Unknown	lgK:10.1 (0.04SD)	6	CRV	552
4	25	0.2	KNO ₃	lgK:10.8 (3SF)	0	MPL	999
5	20	0.1	KNO ₃	dH:-0.72 (2SF)	5	MCL	1956
6	20	0.1	Unknown	dH:2.1 (2SF)	6	CRV	552

Reaction No. 14365							
Mn+2 + H+1_TriMDTA-4 = Mn+2_H+1_TriMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO ₃	lgK:4.82 (3SF)	6	MGL	1956

Reaction No. 14407							
MeEDTA-4 + Mn+2 = Mn+2_MeEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO ₃	lgK:15.28 (4SF)	6	MPL	1978
2	25	0.1	Unknown	lgK:15.00 (0.02SD)	6	CRV	552

3	25	0.2	KNO3	lgK:14.85 (4SF)	6	MPL	999
4	25	0.1	Unknown	dH:-5.3 (2SF)	6	CRV	552

Reaction No. 14436							
2OHTriMDTA-4 + Mn+2 = Mn+2_2OHTriMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:8.90 (3SF)	6	MHY	999
2	20	0.1	KNO3	lgK:9. (1SF)	3	MSC	999
3	23			lgK:9.06 (3SF)	5	MSP	3977

Reaction No. 14437							
Mn+2_2OHTriMDTA-4 + 2OHTriMDTA-4 = Mn+2_2OHTriMDTA-4 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:9.1 (0.04SD)	4	MGL	999

Reaction No. 14438							
Mn+2_2OHTriMDTA-4 + H+1 = Mn+2_H+1_2OHTriMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.1 (0.1SD)	4	MGL	999

Reaction No. 14478							
Mn+2_Phenanth + Phenanth = Mn+2_Phenanth (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.48 (3SF)	3	MGL	999
2	20	0.1	NaNO3	lgK:3.48 (3SF)	3	MGL	1989
3	25	0.1	K2SO4	lgK:3.25 (3SF)	3	MRX	999
4	25	0.1	KCl	lgK:4.15 (3SF)	0	MDS	3075
5	25	0.1	KCl	lgK:3.10 (3SF)	3	MDS	3077
6	25	0.1	Unknown	lgK:3.16 (3SF)	4	MEF	999

Reaction No. 14479							
Mn+2_Phenanth (2) + Phenanth = Mn+2_Phenanth (3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:2.7 (2SF)	4	MGL	999
2	20	0.1	NaNO3	lgK:2.7 (2SF)	4	MGL	1989
3	25	0.1	K2SO4	lgK:3.0 (2SF)	4	MRX	999
4	25	0.1	KCl	lgK:4.05 (3SF)	0	MDS	3075

5	25	0.1	KCl	lgK:3.20 (3SF)	3	MDS	3077
6	25	0.1	Unknown	lgK:3.07 (3SF)	6	MEF	999

Reaction No. 14505							
dlBDTA-4 + Mn+2 = Mn+2_dlBDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:16.72 (4SF)	5	MEF	1933
2	20	0.1	KNO3	lgK:16.7 (0.1SD)	5	MPL	1999
3	20	0.1	KNO3	lgK:16.72 (4SF)	6	MPT	1999
4	20	0.1	KNO3	lgK:16.3 (0.1SD)	5	MGL	2003

Reaction No. 14534							
mBDTA-4 + Mn+2 = Mn+2_mBDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:14.10 (4SF)	6	MEF	1933
2	20	0.1	KNO3	lgK:14.1 (0.05SD)	6	MPT	1999
3	20	0.1	KNO3	lgK:14.2 (0.1SD)	6	MPL	2003

Reaction No. 14586							
EDDG-4 + Mn+2 = Mn+2_EDDG-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:6.74 (3SF)	2	CRV	552
2	30	0.1	KNO3	lgK:5.18 (3SF)	1	MGL	999

Reaction No. 14614							
Pyrid2Azo4DiMeAniline + Mn+2 = Mn+2_Pyrid2Azo4DiMeAniline							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaNO3	lgK:0.7 (1SF)	4	MSP	5703

Reaction No. 14660							
CDTA-4 + Mn+3 = Mn+3_CDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	NaClO4	lgK:28.9 (3SF)	4	MSP	999

Reaction No. 14690							
Mn+2_CDTA-4 + H+1 = Mn+2_H+1_CDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	20	0.1	KNO3	lgK:2.28 (3SF)	0	MPL	999
2	20	0.1	Unknown	lgK:2.8 (2SF)	0	CRV	552
3	25	0	Inf. Dilution	lgK:3.9 (2SF)	1	ELC	
4	25	0.1	Methanol:Water 50:50Vol NaClO4	lgK:3. (0.5SD)	5	MGL	2446

Reaction No. 14851							
Mn+2 + H+1_DTPA-5 = Mn+2_H+1_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:8.63 (3SF)	0	MEF	999
2	20	0.1	Unknown	lgK:9.70 (3SF)	3	ENS	1539
3	25	0.1	KNO3	lgK:9.1 (2SF)	5	MGL	189

Reaction No. 14891							
HexMDTA-4 + Mn+2 = Mn+2_HexMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:9.03 (3SF)	6	MGL	1956
2	20	0.1	KNO3	dH:0.87 (2SF)	5	MCL	1956

Reaction No. 14892							
Mn+2 + H+1_HexMDTA-4 = Mn+2_H+1_HexMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.69 (3SF)	6	MGL	1956

Reaction No. 14920							
Mn+2 + H+1_EGTA-4 = Mn+2_H+1_EGTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:7.02 (3SF)	6	MGL	1956
2	20	0.1	Unknown	lgK:6.91 (3SF)	6	ENS	1539
3	25	0	Inf. Dilution	lgK:7.2 (2SF)	1	ESC	

Reaction No. 15275							
8QuinOPO3-2 + Mn+2 = Mn+2_8QuinOPO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:1.91 (0.02SD)	4	MGL	1336

Reaction No. 15470							
--------------------	--	--	--	--	--	--	--

Mn+2_[9]N3 + [9]N3 = Mn+2_[9]N3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:3.6(2SF)	4	CMN	1354

Reaction No. 15471							
Mn+2 + [9]N3 = Mn+2_[9]N3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:5.8(2SF)	4	CMN	1354

Reaction No. 15492							
Mn+2 + [9]N3:Acet*3-3 = Mn+2_[9]N3:Acet*3-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NC1	lgK:14.9(3SF)	4	MSP	1207
2	25	0.1	Unknown	lgK:14.6(3SF)	4	CRV	552
3	25	0.1	Unknown	lgK:14.3(3SF)	4	ENS	1354

Reaction No. 15630							
Mn+2 + Diglycol-2 = Mn+2_Diglycol-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.54(3SF)	6	MGL	1257
2	25	0.1	NaClO4	lgK:2.4(2SF)	5	MPT	2088

Reaction No. 15649							
Mn+2 + COOMeTartronic-3 = Mn+2_COOMeTartronic-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.76(3SF)	6	MGL	1257

Reaction No. 15650							
Mn+2_COOMeTartronic-3 + H+1 = Mn+2_H+1_COOMeTartronic-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.84(3SF)	6	MGL	1257

Reaction No. 15673							
Mn+2 + DiTartronic-4 = Mn+2_DiTartronic-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.51(3SF)	6	MGL	1257

Reaction No. 15674							
--------------------	--	--	--	--	--	--	--

Mn+2_DiTartronic-4 + H+1 = Mn+2_H+1_DiTartronic-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.23(3SF)	6	MGL	1257

Reaction No. 15933							
Mn+2 + TDS-6 = Mn+2_TDS-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:7.00(3SF)	6	MGL	1217

Reaction No. 15934							
Mn+2_TDS-6 + H+1 = Mn+2_H+1_TDS-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.67(3SF)	6	MGL	1217

Reaction No. 15935							
Mn+2_H+1_TDS-6 + H+1 = Mn+2_H+1(2)_TDS-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.03(3SF)	6	MGL	1217

Reaction No. 15936							
Mn+2_H+1(2)_TDS-6 + H+1 = Mn+2_H+1(3)_TDS-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.54(3SF)	6	MGL	1217

Reaction No. 15937							
Mn+2_TDS-6 + Mn+2 = Mn+2(2)_TDS-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.57(3SF)	6	MGL	1217

Reaction No. 15963							
Mn+2 + TMS-4 = Mn+2_TMS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.69(3SF)	6	MGL	1217

Reaction No. 15964							
Mn+2_TMS-4 + 2<H+1> = Mn+2_H+1(2)_TMS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:7.25(3SF)	6	MGL	1217

Reaction No. 16113							
ICRF198-2 + Mn+2 = Mn+2_ICRF198-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.1(3SF)	1	ESC	
2	37	0.15	NaCl	lgK:9.76(0.006SD)	6	MGL	97

Reaction No. 16114							
H+1 + ICRF198-2 + Mn+2 = Mn+2_H+1_ICRF198-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.3(3SF)	1	ESC	
2	37	0.15	NaCl	lgK:11.0(0.06SD)	4	MGL	97

Reaction No. 16115							
2<ICRF198-2> + Mn+2 = Mn+2_ICRF198-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.9(3SF)	1	ESC	
2	37	0.15	NaCl	lgK:11.6(0.03SD)	4	MGL	97

Reaction No. 16133							
ICRF226-2 + Mn+2 = Mn+2_ICRF226-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.6(2SF)	1	ESC	
2	37	0.15	NaCl	lgK:9.38(0.004SD)	6	MGL	97


Reaction No. 16327							
Mn+2 + BIM = Mn+2_BIM							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.16	KNO3	lgK:3.0(0.03SD)	4	MGL	931
2	35	0.2	KNO3	lgK:3.18(0.02SD)	4	MGL	1258

Reaction No. 16506							
5ATP-4 + 2<Mn+2> = Mn+2(2)_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:7.4(0.08SD)	5	MGL	1297

Reaction No. 16507							
2<H+1> + 2<5ATP-4> + Mn+2 = Mn+2_H+1(2)_5ATP-4(2)							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:18.8(0.06SD)	5	MGL	1297

Reaction No. 16508




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:7.4(0.08SD)	4	MGL	1297

Reaction No. 16509




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:8.5(0.03SD)	6	MGL	1297

Reaction No. 16510




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:15.5(0.04SD)	4	MGL	1297

Reaction No. 16511




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:20.3(0.04SD)	3	MGL	1297

Reaction No. 16685




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NCl	lgK:12.8(3SF)	4	MSP	1207

Reaction No. 16737



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KCl	lgK:8.6(0.1SD)	3	MGL	1218

Reaction No. 16738



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KCl	lgK:8.1(0.1SD)	4	MGL	1218

Reaction No. 16769							
Ptetraen + Mn+2 = Mn+2_Ptetraen							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.3(0.05SD)w	4	MPH	1965
2	25	0.1	KNO3	lgK:5.3(0.05SD)w	4	MPH	1965
3	25	0.1	KNO3	dH:-2.6(0.1SD)	5	MCL	1965

Reaction No. 16783							
EtSen + Mn+2 = Mn+2_EtSen							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:8.2(2SF)	4	MGL	1943

Reaction No. 16891							
PhenEDTA-4 + Mn+2 = Mn+2_PhenEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:14.6(0.1SD)	4	MPL	2010

Reaction No. 16920							
DiPhenEDTA-4 + Mn+2 = Mn+2_DiPhenEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:15.1(0.1SD)	4	MGL	1274

Reaction No. 16938							
NTMP-6 + Mn+2 = Mn+2_NTMP-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:10.9(0.1SD)	3	MGL	1197

Reaction No. 16939							
Mn+2_NTMP-6 + H+1 = Mn+2_H+1_NTMP-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:7.37(0.02SD)	6	MGL	1197

Reaction No. 16940							
Mn+2_H+1_NTMP-6 + H+1 = Mn+2_H+1(2)_NTMP-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.9(0.04SD)	4	MGL	1197

Reaction No. 16941							
--------------------	--	--	--	--	--	--	--

Mn+2_H+1(2)_NTMP-6 + H+1 = Mn+2_H+1(3)_NTMP-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.7(0.1SD)	4	MGL	1197

Reaction No. 16971							
Mn+2_Uridine-1 + Uridine-1 = Mn+2_Uridine-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:3.3(0.03SD)	4	MGL	1275
2	25	0.1	KNO3	lgK:3.4(0.03SD)	4	MGL	1275
3	35	0.1	KNO3	lgK:3.6(0.03SD)	6	MGL	1275
4	45	0.1	KNO3	lgK:3.7(0.03SD)	4	MGL	1275


Reaction No. 17050							
5GTP-4 + Mn+2 = Mn+2_5GTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.1	NaCl	lgK:4.73(3SF)	0	MIX	1437
2	25	0.1	KNO3	lgK:5.2(0.06SD)	3	MGL	1972
3	25	0.1	Me4N+ salt	lgK:5.1(0.07SD)	3	CIU	1437
4	25	0.1	NaClO4	lgK:4.64(0.01MD)	0	MGL	2648
5	35	0.1	KNO3	lgK:5.3(0.06SD)	3	MGL	1972
6	45	0.1	KNO3	lgK:5.1(0.06SD)	3	MGL	1972
7	25:45	0.1	KNO3	dH:-2.1(0.1SD)	3	MTD	1972

Reaction No. 17058							
5ITP-4 + Mn+2 = Mn+2_5ITP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.1	NaCl	lgK:4.57(3SF)	4	MIX	1437
2	25	0.1	KNO3	lgK:4.4(0.06SD)	6	MGL	1972
3	25	0.1	Me4N+ salt	lgK:5.1(0.07SD)	7	CIU	1437
4	25	0.1	NaClO4	lgK:4.66(0.02SD)	5	MGL	125
5	35	0.1	KNO3	lgK:4.6(0.06SD)	6	MGL	1972
6	45	0.1	KNO3	lgK:4.3(0.06SD)	6	MGL	1972
7	25:45	0.1	KNO3	dH:-2.4(0.1SD)	6	MTD	1972

Reaction No. 17068							
5CTP-4 + Mn+2 = Mn+2_5CTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	23	0.1	NaCl	lgK:4.78 (3SF)	4	MIX	1437
2	25	0.1	KCl	lgK:4.63 (3SF)	3	MGL	1437
3	25	0.1	KNO3	lgK:4.56 (3SF)	3	MGL	1437
4	25	0.1	Me4N+ salt	lgK:5.1 (0.08SD)	8	CIU	1437
5	25	0.1	NaClO4	lgK:4.90 (0.01SD)	4	MGL	1369
6	25	0.1	NaClO4	lgK:4.74 (0.08MD)	4	MGL	2648
7	35	0.1	KNO3	lgK:4.43 (3SF)	3	MGL	1437
8	35	0.1	KNO3	lgK:4.4 (0.06SD)	3	MGL	3186
9	45	0.1	KNO3	lgK:4.85 (3SF)	3	MGL	1437
10	25:45	0.1	KNO3	dH:-4.5 (2SF)	4	MTD	1437

Reaction No. 17069



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.5 (2SF)	0	MGL	1437
2	25	0.1	KNO3	lgK:4.24 (3SF)	0	MGL	1437
3	25	0.1	Me4N+ salt	lgK:3. (0.3SD)	4	CIU	1437
4	25	0.1	NaClO4	lgK:3.1 (0.15SD)	0	MGL	1369
5	35	0.1	KNO3	lgK:4.10 (3SF)	3	MGL	1437
6	35	0.1	KNO3	lgK:4.1 (0.06SD)	3	MGL	3186
7	45	0.1	KNO3	lgK:4.01 (3SF)	3	MGL	1437
8	25:45	0.1	KNO3	dH:-5.0 (2SF)	4	MTD	1437

Reaction No. 17085



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.1	NaCl	lgK:4.78 (3SF)	0	MIX	1437
2	25	0.1	KNO3	lgK:6.31 (3SF)	3	MGL	1437
3	25	0.1	Me4N+ salt	lgK:5.1 (0.07SD)	4	CIU	1437
4	25	0.1	NaClO4	lgK:4.91 (0.025SD)	0	MGL	1369
5	25	0.1	NaClO4	lgK:4.58 (0.02MD)	0	MGL	2648
6	35	0.1	KNO3	lgK:6.21 (3SF)	3	MGL	1437
7	35	0.1	KNO3	lgK:6.2 (0.06SD)	3	MGL	3159
8	45	0.1	KNO3	lgK:6.10 (3SF)	2	MGL	1437
9	25:45	0.1	KNO3	dH:-6.6 (2SF)	4	MTD	1437

Reaction No. 17086


Mn+2 + H+1_5UTP-4 = Mn+2_H+1_5UTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:2.6(0.09SD)	7	CIU	1437
2	25	0.1	NaClO4	lgK:2.70(0.04SD)	4	MGL	1369

Reaction No. 17097							
5TTP-4 + Mn+2 = Mn+2_5TTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:5.1(0.1SD)	7	CIU	1437
2	25	0.1	NaClO4	lgK:5.0(0.1SD)	4	MGL	1369

Reaction No. 17111							
5ADP-3 + Mn+2 = Mn+2_5ADP-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:4.50(0.02SD)	0	MGL	3481
2	1	0.2	Me4NBr	lgK:4.245(4SF)	0	MGL	3469
3	1.5	0.0085	NEtMorph buffer	lgK:4.908(4SF)	4	MEP	3468
4	8	0.2	Me4NBr	lgK:4.241(4SF)	2	MGL	3469
5	11.8	0.0085	NEtMorph buffer	lgK:4.949(4SF)	4	MEP	3468
6	12	0.1	KNO3	lgK:4.24(0.02SD)	3	MGL	3481
7	15	0.2	Me4NBr	lgK:4.230(4SF)	2	MGL	3469
8	22	0.25	KNO3	lgK:3.0(2SF)	0	MGL	1437
9	23	0.1	NaCl	lgK:3.94(3SF)	0	MIX	1437
10	23	0.1	NaCl	lgK:3.94(3SF)	2	MIX	31154
11	24.8	0.0085	NEtMorph buffer	lgK:4.982(4SF)	4	MEP	3468
12	25	0.1	KCl	lgK:3.80(3SF)	2	MGL	1437
13	25	0.1	KNO3	lgK:4.16(0.01SD)	5	MGL	3481
14	25	0.1	Me4N+ salt	lgK:4.3(0.07SD)	8	CIU	1437
15	25	0.11	NaCl	lgK:4.20(3SF)	4	MEP	
16	25	0.2	Me4NBr	lgK:4.311(4SF)	2	MGL	3469
17	25	0.2	Pr4NC1	lgK:3.542(4SF)	0	MGL	257
18	26	0.11	NaCl	lgK:4.15(3SF)	4	MIX	
19	27	0.02	NEtMorph buffer	lgK:4.48(3SF)	4	MEP	1437
20	30	0.02	NEtMorph buffer	lgK:4.40(3SF)	2	MSP	1437
21	31.8	0.0085	NEtMorph buffer	lgK:5.061(4SF)	4	MEP	3468
22	35	0.2	Me4NBr	lgK:4.404(4SF)	2	MGL	3469


23	37	0.15	KCl	lgK:4.05 (3SF)	4	MEP	1437
24	37	0.15	Na+1 salt	lgK:4.1 (0.07SD)	6	CIU	1437
25	40	0.1	KNO3	lgK:4.06 (0.02SD)	2	MGL	3481
26	41	0.11	NaCl	lgK:4.30 (3SF)	4	MIX	
27	45	0.2	Me4NBr	lgK:4.474 (4SF)	2	MGL	3469
28	47.2	0.0085	NEtMorph buffer	lgK:5.173 (4SF)	4	MEP	3468
29	0:40	0.1	KNO3	dH:-2.0 (0.4SD)	0	MCL	3481
30	1:43	0.2	Me4NBr	dH:3.5 (2SF)	4	MTD	3469
31	1:45	0.2	Me4NBr	dH:3.5 (2SF)	5	MTD	3469
32	2:47	0.1	NEtMorph buffer	dH:2.6 (2SF)	4	MTD	3468
33	6	0.2	Me4NBr	dH:1.8 (0.08SD)	3	MTD	3470
34	15	0.2	Me4NBr	dH:2.7 (0.06SD)	5	MTD	3470
35	25	0.1	Inert	dH:13.4 (0.8SD) kJ	5	CIU	1437
36	26:41	0.1	NaCl	dH:3.6 (2SF)	4	MCL	1437
37	30	0.2	Me4NBr	dH:3.5 (0.08SD)	5	MTD	3470

Reaction No. 17112



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:2.00 (0.02SD)	4	MGL	3481
2	12	0.1	KNO3	lgK:1.95 (0.02SD)	5	MGL	3481
3	25	0.1	KNO3	lgK:1.89 (0.02SD)	5	MGL	3481
4	25	0.1	Me4N+ salt	lgK:1.9 (0.1SD)	7	CIU	1437
5	25	0.2	Pr4NCl	lgK:1.491 (4SF)	5	MGL	257
6	40	0.1	KNO3	lgK:1.81 (0.02SD)	4	MGL	3481
7	25	0.1	KNO3	dH:-1.9 (0.3SD)	0	MCL	3481


Reaction No. 17131



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:2.46 (0.02SD)	4	MGL	3481
2	1	0.2	Me4NBr	lgK:2.456 (4SF)	5	MGL	3469
3	6	0.2	Me4NBr	lgK:2.346 (4SF)	5	MGL	3469
4	12	0.1	KNO3	lgK:2.43 (0.02SD)	5	MGL	3481
5	13	0.2	Me4NBr	lgK:2.276 (4SF)	5	MGL	3469
6	23	0.1	NaCl	lgK:2.31 (3SF)	4	MIX	1437

7	23	0.2	Me4NBr	lgK:2.334 (4SF)	5	MGL	3469
8	25	0.1	KCl	lgK:2.02 (3SF)	0	MGL	1437
9	25	0.1	KNO3	lgK:2.35 (3SF)	5	MPT	1760
10	25	0.1	KNO3	lgK:2.35 (3SF)	5	MGL	3464
11	25	0.1	KNO3	lgK:2.40 (0.02SD)	5	MGL	3481
12	25	0.1	Me4N+ salt	lgK:2.5 (0.07SD)	8	CIU	1437
13	25	0.1	NaClO4	lgK:2.14 (3SF)	5	MGL	6055
14	25	0.1	NaNO3	lgK:2.23 (0.01MD)	6	MGL	2906
15	25	0.1	NaNO3	lgK:2.23 (0.01MD)	6	MGL	6104
16	25	0.1	Unknown	lgK:2.19 (3SF)	4	MIX	1437
17	25	0.2	Me4NC1	lgK:2.19 (3SF)	6	MGL	999
18	25	0.2	Pr4NC1	lgK:2.193 (4SF)	5	MGL	257
19	25	0.2	Unknown	lgK:2.3 (0.05SD)	4	MPT	1760
20	33	0.2	Me4NBr	lgK:2.279 (4SF)	3	MGL	3469
21	37	0.15	Na+1 salt	lgK:2.4 (0.07SD)	8	CIU	1437
22	40	0.1	KNO3	lgK:2.37 (0.02SD)	4	MGL	3481
23	43	0.2	Me4NBr	lgK:2.387 (4SF)	5	MGL	3469
24	0:40	0.1	KNO3	dH:-1.0 (0.2SD)	0	MCL	3481
25	1:43	0.2	Me4NBr	dH:1.0 (2SF)	4	MTD	3469
26	1:43	0.2	Me4NBr	dH:1.0 (2SF)	5	MTD	3469
27	6	0.2	Me4NBr	dH:1. (0.08SD)	5	MTD	3470
28	15	0.2	Me4NBr	dH:1.9 (0.1SD)	5	MTD	3470
29	15:45	0.2	Me4NBr	dH:1.0 (2SF)	4	MTD	1437
30	25	0.1	Inert	dH:9.2 (0.2SD) kJ	5	CIU	1437
31	30	0.2	Me4NBr	dH:2.3 (0.2SD)	5	MTD	3470


Reaction No. 17141



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:2.34 (0.02SD)	4	MGL	3481
2	12	0.1	KNO3	lgK:2.31 (0.02SD)	5	MGL	3481
3	25	0.1	KClO4	lgK:1.86 (3SF)	5	MIX	3464
4	25	0.1	KNO3	lgK:2.28 (0.01SD)	5	MGL	3481
5	25	0.1	Me4N+ salt	lgK:2.3 (0.07SD)	8	CIU	1437
6	25	0.1	Me4NBr	lgK:1.98 (3SF)	5	MGL	3464
7	25	0.1	NaNO3	lgK:2.06 (0.02MD)	6	MGL	6104


8	40	0.1	KNO3	lgK:2.25(0.02SD)	4	MGL	3481
9	0:40	0.1	KNO3	dH:-0.9(0.2SD)	0	MCL	3481
10	25	0.1	Inert	dH:9.6(2.SD)kJ	5	CIU	1437

Reaction No. 17152




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0.1	KNO3	lgK:2.43(0.02SD)	4	MGL	3481
2	12	0.1	KNO3	lgK:2.41(0.02SD)	5	MGL	3481
3	25	0.1	KNO3	lgK:2.38(0.02SD)	5	MGL	3481
4	25	0.1	Me4N+ salt	lgK:2.4(0.07SD)	8	CIU	1437
5	25	0.1	NaNO3	lgK:2.14(0.02MD)	6	MGL	6104
6	40	0.1	KNO3	lgK:2.35(0.02SD)	4	MGL	3481
7	0:40	0.1	KNO3	dH:-1.0(0.2SD)	0	MCL	3481
8	25	0.1	Inert	dH:9.2(2.SD)kJ	5	CMN	1437

Reaction No. 17173




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.4(2SF)	4	MGL	1437
2	25	0.1	Me4N+ salt	lgK:2.4(0.07SD)	7	CIU	1437
3	25	0.1	NaNO3	lgK:2.10(0.04MD)	4	MGL	1345
4	35	0.1	KNO3	lgK:2.7(0.03SD)	6	MPT	1618

Reaction No. 17189



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:2.4(0.07SD)	7	CIU	1437
2	25	0.1	NaNO3	lgK:2.1(0.2MD)	4	MGL	1345
3	25	0.1	NaNO3	lgK:2.01(0.03MD)	5	MGL	6097

Reaction No. 17199



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:2.4(0.07SD)	7	CIU	1437
2	25	0.1	NaNO3	lgK:2.11(0.05MD)	4	MGL	1345

Reaction No. 17282							
$\text{Mn}^{+2} + 12\text{PhenDTA-4} = \text{Mn}^{+2}_{12\text{PhenDTA-4}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	$\lg K: 11.37 (4\text{SF})$	6	MGL	1368
2	25	1	NaClO4	$\text{dH}: -0.78 (0.02\text{SD})$	5	MCL	1368

Reaction No. 17383							
$\text{Mn}^{+2}_{\text{MIDA-2}(2)} + \text{EDTA-4} = \text{Mn}^{+2}_{\text{EDTA-4}} + 2\langle\text{MIDA-2}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 5.1 (2\text{SF})$	1	ELC	
2	25	0	Inf. Dilution	$\lg K: 5. (1\text{SF})$	1	EOR	
3	25	0	Unknown	$\text{dG}: -5.68 (3\text{SF})$	0	MCL	1394
4	25	0	Unknown	$\text{dH}: -4.33 (3\text{SF})$	2	MCL	1394

Reaction No. 17407							
$\text{Mn}^{+2} + \text{H}^{+1}_{\text{PO4EtAm-2}} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{PO4EtAm-2}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	$\lg K: 1.72 (3\text{SF})$	6	MGL	999
2	25	0.2	KNO3	$\lg K: 1.9 (0.03\text{SD})$	4	MGL	1370

Reaction No. 17442							
$\text{Mn}^{+2} + \text{H}^{+1}_{\text{PO4MeSer-3}} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{PO4MeSer-3}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	$\lg K: 1.9 (0.08\text{SD})$	3	MGL	1370


Reaction No. 17443							
$\text{Mn}^{+2} + \text{PO4MeSer-3} = \text{Mn}^{+2}_{\text{PO4MeSer-3}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	$\lg K: 3.7 (0.03\text{SD})$	4	MGL	1370

Reaction No. 17460							
$\text{Mn}^{+2} + \text{H}^{+1}_{\text{PO4Thr-3}} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{PO4Thr-3}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	$\lg K: 2.2 (0.04\text{SD})$	4	MGL	1370

Reaction No. 17461							
$\text{Mn}^{+2} + \text{PO4Thr-3} = \text{Mn}^{+2}_{\text{PO4Thr-3}}$							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:3.8(0.03SD)	4	MGL	1370

Reaction No. 17480




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	ClO4-1 salt	lgK:4.6(0.08SD)	4	MGL	1428

Reaction No. 17557




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.0(0.1MD)	3	MGL	411

Reaction No. 17563




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.3(0.09MD)	3	MGL	411

Reaction No. 17761




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.87(0.04MD)	4	MGL	1345

Reaction No. 17768




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:2.12(0.03MD)	4	MGL	1345

Reaction No. 17776



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:2.34(0.01MD)	6	MGL	1345

Reaction No. 17786



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:2.20(0.02MD)	6	MGL	1345

Reaction No. 17793							
MeOPO3-2 + Mn+2 = Mn+2_MeOPO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:2.19(3SF)	6	MGL	1345
2	65	0.1	Unknown	lgK:2.55(3SF)	5	MSP	931

Reaction No. 18011							
Mn+2 + H+1_CDTA-4 = Mn+2_H+1_CDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:8.50(3SF)	6	ENS	1539
2	25	0	Inf. Dilution	lgK:8.7(2SF)	1	ESC	

Reaction No. 18173							
Mn+2_Citric-3 + H2O = Mn+2_OH-1_Citric-3 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:-8.50(3SF)	3	ENS	1539
2	25	0	Inf. Dilution	lgK:-8.96(3SF)	2	EAE	
3	33	0.25	NaClO4	lgK:-8.5(2SF)	3	MGL	22560

Reaction No. 18249							
2<26PyridineDiCOO-2> + Mn+2 = Mn+2_26PyridineDiCOO-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:8.49(3SF)	6	ENS	1539

Reaction No. 18316							
Mn+2_Tartaric-2 + 2<H2O> = Mn+2_OH-1(2)_Tartaric-2 + 2<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:17.76(4SF)	6	ENS	1539

Reaction No. 18339							
Glyphosate-3 + Mn+2 = Mn+2_Glyphosate-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.53(3SF)	6	MGL	1456
2	25	0.1	KNO3	lgK:5.47(0.003SD)	5	MGL	6861
3	25	0.1	Many Media	lgK:5.50(0.03SD)	7	CIU	7242

Reaction No. 18340							
--------------------	--	--	--	--	--	--	--

Mn+2_Glyphosate-3 + H+1 = Mn+2_H+1_Glyphosate-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:6.92(3SF)	6	MGL	1456
2	25	0.1	Unknown	lgK:6.83(3SF)	6	CRV	552

Reaction No. 18341							
Mn+2_Glyphosate-3 + OH-1 = Mn+2_OH-1_Glyphosate-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.30(3SF)	6	MGL	1456

Reaction No. 18446							
Tapen + Mn+2 = Mn+2_Tapen							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:6.1(0.03SD)	4	MGL	1494

Reaction No. 18722							
Mn+2 + H+1_[12]N3O:Acet*3-3 = Mn+2_H+1_[12]N3O:Acet*3-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:8.6(0.05SD)	4	MGL	1467

Reaction No. 18723							
[12]N3O:Acet*3-3 + Mn+2 = Mn+2_[12]N3O:Acet*3-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:16.1(0.03SD)	4	MGL	1467

Reaction No. 18834							
Xanthine-1 + Mn+2 = Mn+2_Xanthine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.5(0.04SD)	3	MGL	1557

Reaction No. 18839							
Xanthosine-1 + Mn+2 = Mn+2_Xanthosine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.5(0.06SD)	6	MGL	3147
2	25	0.1	NaNO3	lgK:0.8(0.05SD)	0	MGL	1557
Note (2): Low wgt for internal consistency							
3	25	0.1	NaNO3	lgK:0.84(0.05MD)	0	MGL	6105

4	35	0.1	KNO3	lgK:2.9(0.06SD)	4	MGL	1884
5	35	0.1	KNO3	lgK:2.6(0.06SD)	6	MGL	2371
6	45	0.1	KNO3	lgK:2.5(0.06SD)	6	MGL	1884
7	25	0.1	KNO3	dG:-3.4(0.06SD)	6	MGL	1884
8	25	0.1	KNO3	dH:-0.5(0.1SD)	6	MCL	1884
9	25	0.1	KNO3	dS:10.9(0.2SD)	6	EFE	1884

Reaction No. 19088							
N2COOEtIDA-3 + Mn+2 = Mn+2_N2COOEtIDA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:7.33(3SF)	5	MGL	6833
2	25	0.1	Unknown	dH:1.1(2SF)	6	CRV	552

Reaction No. 19089							
Mn+2 + H+1_N2COOEtIDA-3 = Mn+2_H+1_N2COOEtIDA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.51(3SF)	5	MGL	6833

Reaction No. 19228							
2OHMePyridine + Mn+2 = Mn+2_2OHMePyridine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Unknown	lgK:1.(1SF)	6	MGL	1660
2	25	0.1	KNO3	lgK:1.(1SF)	3	MGL	999

Reaction No. 19229							
Terpy + Mn+2 = Mn+2_Terpy							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.002:0.1	Unknown	lgK:4.4(2SF)	5	MKN	999
2	25	0	Unknown	lgK:4.4(2SF)	5	MGL	1660
3	25	0.1	Unknown	lgK:4.4(2SF)	6	ENS	1384
4	25	0.2	Methanol NaClO4	lgK:5.0(2SF)	4	MKN	906

Reaction No. 19508							
Mn+2_Gly-1 + H+1_Gly-1 = Mn+2_H+1_Gly-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.92(3SF)	2	EAE	
2	27	0.3	Unknown	lgK:0.92(2SF)	5	MMR	1174

3	37	0.15	KNO3	lgK:0.800000 (0.4SD)	7	MGL	181
---	----	------	------	----------------------	---	-----	-----

Reaction No. 19575							
Mn+2_Ala-1 + H+1_Ala-1 = Mn+2_H+1_Ala-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.998(3SF)	2	EAE	
2	37	0.15	KNO3	lgK:1.(0.5SD)	7	MGL	181

Reaction No. 19654							
Mn+2_Pyridine + Pyridine = Mn+2_Pyridine(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	HNO3	lgK:-0.5(1SF)	0	MGL	999
Note (1): Low wgt for internal consistency							
2	25	1	NaClO4	lgK:1.59(3SF)	6	MGL	999

Reaction No. 19754							
Mn+2_EDDA-2 + EtDiAm = Mn+2_EtDiAm_EDDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.1(0.2SD)	3	MGL	6771


Reaction No. 19916							
EtOlAm + Mn+2 = Mn+2_EtOlAm							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.43	HNO3	lgK:0.87(2SF)	6	MGL	4431

Reaction No. 19941							
Mn+2_Lactic-1 + Lactic-1 = Mn+2_Lactic-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:0.54(2SF)	6	MQH	999

Reaction No. 19973							
Mn+2_Ala-1 + Ala-1 = Mn+2_Ala-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.00(3SF)	3	MGL	11516
Note (1): Berezina L et al., Zhur. Neorg. Khim., 1973, 18, 393							
2	20	0.1	KNO3	lgK:1.9(2SF)	0	MEP	11516
Note (2): Jokl V et al., J. Chromatography, 1964, 14, 71							


3	25	0	Inf. Dilution	lgK:3.2 (2SF)	1	ELC	
4	25	0.01	Unknown	lgK:2.81 (3SF)	0	MGL	999
5	37	0.15	KNO3	lgK:1.90 (3SF)	0	MGL	181

Reaction No. 20099




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.4 (2SF)	1	ELC	
2	33	0.25	NaClO4	lgK:4.7 (2SF)	0	MGL	999

Reaction No. 20103




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	1	KCl	lgK:2.84 (3SF)	6	MGL	999
2	30	1	KNO3	lgK:2.84 (3SF)	6	MGL	999
3	40	1	KCl	lgK:2.72 (3SF)	6	MGL	999
4	40	1	KNO3	lgK:2.72 (3SF)	6	MGL	999

Reaction No. 20114




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:6.82 (3SF)	6	MGL	999

Reaction No. 20115




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:4.66 (3SF)	6	MGL	999

Reaction No. 20158



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KCl	lgK:7.26 (3SF)	6	MGL	999
2	25	0.5	KNO3	lgK:7.29 (3SF)	6	MGL	183

Reaction No. 20159



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0.5	KCl	lgK:9.15 (3SF)	3	MGL	999
2	25	0.5	KNO3	lgK:9.95 (3SF)	2	MGL	183
3	25	0.5	KNO3	lgK:9.51 (3SF)	2	MGL	999

Reaction No. 20160							
Mn+2 + 2<SalAld-1> + 2<Gly-1> = Mn+2_Gly-1(2)_SalAld-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KCl	lgK:13.04 (4SF)	6	MGL	999

Reaction No. 20257							
dl23BuDiAm + Mn+2 = Mn+2_dl23BuDiAm							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.94 (0.02SD)	4	MGL	1635

Reaction No. 20275							
m23BuDiAm + Mn+2 = Mn+2_m23BuDiAm							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.6 (0.05SD)	4	MGL	1635

Reaction No. 20303							
mODS-4 + Mn+2 = Mn+2_mODS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.69 (3SF)	6	MGL	1747

Reaction No. 20304							
Mn+2_mODS-4 + H+1 = Mn+2_H+1_mODS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.23 (3SF)	6	MGL	1747

Reaction No. 20305							
Mn+2_H+1_mODS-4 + H+1 = Mn+2_H+1(2)_mODS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.4 (2SF)	4	MGL	1747

Reaction No. 20306							
Mn+2_H+1(2)_mODS-4 + H+1 = Mn+2_H+1(3)_mODS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.25 (3SF)	6	MGL	1747

Reaction No. 20348							
$\text{racODS-4} + \text{Mn+2} = \text{Mn+2_racODS-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	$\lg K: 5.40 (3\text{SF})$	6	MGL	1747

Reaction No. 20349							
$\text{Mn+2_racODS-4} + \text{H+1} = \text{Mn+2_H+1_racODS-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	$\lg K: 4.02 (3\text{SF})$	6	MGL	1747

Reaction No. 20350							
$\text{Mn+2_H+1_racODS-4} + \text{H+1} = \text{Mn+2_H+1(2)_racODS-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	$\lg K: 3.72 (3\text{SF})$	6	MGL	1747

Reaction No. 20351							
$\text{Mn+2_H+1(2)_racODS-4} + \text{H+1} = \text{Mn+2_H+1(3)_racODS-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	$\lg K: 3.13 (3\text{SF})$	6	MGL	1747

Reaction No. 20524							
$[12]\text{N3O} + \text{Mn+2} = \text{Mn+2_}[12]\text{N3O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	$\lg K: 5.85 (0.01\text{SD})$	6	MGL	1743


Reaction No. 20525							
$\text{Mn+2} + [12]\text{N3O} + \text{H2O} = \text{Mn+2_}[12]\text{N3O_OH-1} + \text{H+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	$\lg K: -4.6 (0.04\text{SD})$	4	MGL	1743

Reaction No. 20526							
$\text{Mn+2_}[12]\text{N3O} + [12]\text{N3O} = \text{Mn+2_}[12]\text{N3O(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	$\lg K: 9.1 (0.08\text{SD})$	3	MGL	1743

Reaction No. 20551							
$[13]\text{N3O} + \text{Mn+2} = \text{Mn+2_}[13]\text{N3O}$							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.0(0.09SD)	4	MGL	1743

Reaction No. 20552




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:-5.9(0.06SD)	4	MGL	1743

Reaction No. 20598




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.37(3SF)	6	MGL	1743

Reaction No. 20611




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.93(3SF)	6	MGL	1743

Reaction No. 20688




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.37(3SF)	6	MGL	999
2	25	0	Inf. Dilution	lgK:1.4(2SF)	1	ESC	

Reaction No. 20722




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Unknown	lgK:6.97(3SF)	6	ENS	773

Reaction No. 20977



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.49(3SF)	2	MPT	1760
2	25	0.1	NaClO4	lgK:3.50(3SF)	1	MPT	1760

Reaction No. 20984



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0.5	NaNO3	lgK:0.19 (0.08MD)	5	MGL	6115
2	35	0.1	KNO3	lgK:2.51 (3SF)	3	MGL	1187

Reaction No. 21063							
Mn+2 + H+1_Tyr-2 = Mn+2_H+1_Tyr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:3.14 (3SF)	6	MGL	1050
2	25	0.2	KCl	dH:-3. (1SF) kJ	5	MCL	1050

Reaction No. 21064							
Mn+2 + 2<H+1_Tyr-2> = Mn+2_H+1 (2)_Tyr-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:2.4 (2SF)	0	MGL	6024
2	25	0.1	Unknown	lgK:5.8 (2SF)	4	ENS	233
3	25	0.1	Unknown	dH:-1.2 (2SF)	5	ENS	233


Reaction No. 21065							
Mn+2_H+1_Tyr-2 (2) + H+1 = Mn+2_H+1 (2)_Tyr-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:8.9 (2SF)	4	ENS	233
2	25	0.2	KCl	lgK:8.9 (2SF)	4	MGL	1050
3	25	0.1	Unknown	dH:-5.5 (2SF)	5	ENS	233
4	25	0.2	KCl	dH:-23. (2SF) kJ	5	MCL	1050

Reaction No. 21066							
Mn+2_Tyr-2 (2) + H+1 = Mn+2_H+1_Tyr-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:10.1 (3SF)	4	ENS	233
2	25	0.2	KCl	lgK:10.1 (3SF)	4	MGL	1050
3	25	0.1	Unknown	dH:-9.6 (2SF)	5	ENS	233
4	25	0.2	KCl	dH:-40. (2SF) kJ	5	MCL	1050

Reaction No. 21378							
PO4EtAm-2 + Mn+2 = Mn+2_PO4EtAm-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:3.85 (3SF)	4	MGL	6795
2	25	0.15	KCl	lgK:2.55 (3SF)	0	MGL	999


Note (2): Low wgt for internal consistency

Reaction No. 21502




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:7.87 (3SF)	6	MGL	999

Reaction No. 21503




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:4.66 (3SF)	6	MGL	999

Reaction No. 21595




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:8.41 (3SF)	6	MGL	999

Reaction No. 21596




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:6.31 (3SF)	6	MGL	999

Reaction No. 21597




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.34 (3SF)	6	MGL	999

Reaction No. 21598



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.64 (3SF)	6	MGL	999

Reaction No. 21599



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.94 (3SF)	6	MGL	999

Reaction No. 21600

Mn+2 + H+1(6)_DTPMP-9 = Mn+2_H+1(6)_DTPMP-9							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.64(3SF)	6	MGL	999

Reaction No. 21650							
Mn+2_Oxalic-2 + Oxalic-2 = Mn+2_Oxalic-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.43(3SF)	6	MSL	999
2	25	0.1	NaClO4	lgK:1.26(3SF)	5	MVM	11516
Note (2): Verdier E et al., Ann. Chim. (France), 1969, 4, 213							

Reaction No. 21651							
Mn+3_Oxalic-2 + Oxalic-2 = Mn+3_Oxalic-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	2	HClO4	lgK:6.59(3SF)	5	MKN	733

Reaction No. 21652							
Mn+3_Oxalic-2(2) + Oxalic-2 = Mn+3_Oxalic-2(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:2.42(3SF)	4	MSP	999
2	25	2	HClO4	lgK:2.85(3SF)	5	MKN	733


Reaction No. 21780							
Mn+2_EDTA-4 + EtDiAm = Mn+2_EtDiAm_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1.5	HCl	lgK:0.91(2SF)	6	MSP	999

Reaction No. 21781							
Mn+2_EtDiAm_EDTA-4 + Mn+2_EtDiAm(3) = Mn+2(2)_EtDiAm(4)_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1.5	HCl	lgK:3.62(3SF)	6	MSP	999

Reaction No. 21821							
Gly-1 + Mn+2 + Pyruvic-1 = Mn+2_Gly-1_Pyruvic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.65	KCl	lgK:5.51(0.02SD)	6	MGL	179
2	25	0.65	KCl	lgK:5.36(0.02SD)	6	MGL	179


3	25	0.65	KCl	dH:-4.0 (2SF)	5	MCL	179
---	----	------	-----	---------------	---	-----	-----

Reaction No. 21822




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.65	KCl	lgK:7.7 (0.6SD)	3	MGL	179
2	25	0.65	KCl	lgK:6.9 (0.03SD)	4	MGL	179

Reaction No. 21823




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.65	KCl	lgK:10.25 (0.03SD)	3	MGL	179
2	25	0.65	KCl	lgK:9.79 (0.03SD)	3	MGL	179
3	25	0.65	KCl	dH:-11.8 (3SF)	5	MCL	179

Reaction No. 22220




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.16 (3SF)	2	MGL	931
2	25	0.1	KNO3	lgK:3.5 (0.05SD) w	2	MPH	1565
3	25	0.1	KNO3	dG:-4.8 (0.07SD)	2	MPH	1565
4	25	0.1	KNO3	dH:-2.5 (0.05SD)	2	MCL	1565

Reaction No. 22221



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:6.05 (0.01SD) w	6	MPH	1565
2	25	0.1	KNO3	dG:-8.2 (0.1SD)	6	MPH	1565
3	25	0.1	KNO3	dH:-5. (1.SD)	6	MCL	1565
4	25	0.1	KNO3	dS:9. (1.SD)	6	EFE	1565

Reaction No. 22222



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.91 (3SF)	6	MGL	931
2	25	0.1	KNO3	dH:-5.0 (0.1SD)	5	MCL	1801

Reaction No. 22248							
Tri2PicAm + Mn+2 = Mn+2_Tri2PicAm							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.6(0.06SD)w	6	MPH	1565
2	25	0.1	Unknown	lgK:5.6(2SF)	6	ENS	1384
3	20	0.1	KNO3	dG:-7.54(3SF)	6	MPH	1565
4	20	0.1	KNO3	dH:-6.(0.3SD)	6	MCL	1565
5	20	0.1	KNO3	dS:4.(1.SD)	6	EFE	1565

Reaction No. 22271							
Tet2PicEtDiAm + Mn+2 = Mn+2_Tet2PicEtDiAm							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:10.3(0.06SD)	6	MHG	1565
2	25	0.1	Unknown	lgK:10.3(3SF)	6	ENS	1384
3	20	0.1	KNO3	dG:-13.77(4SF)	6	MHG	1565
4	20	0.1	KNO3	dH:-11.(0.7SD)	6	MCL	1565
5	20	0.1	KNO3	dS:7.8(2SF)	5	EFE	1565

Reaction No. 22298							
DHAP-2 + Mn+2 = Mn+2_DHAP-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:2.11(0.02SD)	4	MGL	1744

Reaction No. 22310							
1GlycerolOPO3-2 + Mn+2 = Mn+2_1GlycerolOPO3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:2.2(0.04SD)	4	MGL	1744

Reaction No. 22348							
[18]dieneN6dipyo + Mn+2 = Mn+2_[18]dieneN6dipyo							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:12.5(3SF)w	4	MPH	1835

Reaction No. 22585							
DiAmButan-1 + Mn+2 = Mn+2_DiAmButan-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:4.2(2SF)	4	MGL	999

Reaction No. 22627							
$\text{Smc-1} + \text{Mn+2} = \text{Mn+2_Smc-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.52 (3SF)	6	MGL	3516

Reaction No. 22628							
$\text{Mn+2_Smc-1} + \text{Smc-1} = \text{Mn+2_Smc-1(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.75 (3SF)	6	MGL	3516

Reaction No. 22819							
$\text{Mn+2_OH-1_SarGly-1} + \text{H+1} = \text{Mn+2_SarGly-1} + \text{H2O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.02	Unknown	lgK:3.85 (3SF)	5	MGL	140

Reaction No. 22820							
$\text{Mn+2_OH-1(2)_SarGly-1} + \text{H+1} = \text{Mn+2_OH-1_SarGly-1} + \text{H2O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.02	Unknown	lgK:9.46 (3SF)	5	MGL	140

Reaction No. 22821							
$\text{SarGly-1} + \text{Mn+2} = \text{Mn+2_SarGly-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.02	Unknown	lgK:0.4 (1SF)	4	MGL	140

Reaction No. 22895							
$\text{Glyphosine-5} + \text{Mn+2} = \text{Mn+2_Glyphosine-5}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:7. (0.5SD)	3	MGL	999

Reaction No. 22914							
$\text{Tri2PicAm6Me} + \text{Mn+2} = \text{Mn+2_Tri2PicAm6Me}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:2.62 (3SF)	6	MGL	1565
2	20	0.1	KNO3	dG:-3.52 (3SF)	6	MPH	1565

Reaction No. 23135							
--------------------	--	--	--	--	--	--	--

OHLys-1 + Mn+2 = Mn+2_OHLys-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.3(2SF)	4	MGL	931

Reaction No. 23271							
EBDP-4 + Mn+2 = Mn+2_EBDP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:11.20(0.01SD)	6	MGL	1902

Reaction No. 23373							
3NitrSal-2 + Mn+2 = Mn+2_3NitrSal-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	NaClO4	lgK:4.85(3SF)	6	MGL	5987

Reaction No. 23536							
EDD2P-2 + Mn+2 = Mn+2_EDD2P-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:6.10(0.01SD)	6	MPT	2004

Reaction No. 23545							
Azelaic-2 + Mn+2 = Mn+2_Azelaic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	Unknown	lgK:1.03(3SF)	5	MIX	419

Reaction No. 23555							
Mn+2_NTA-3 + Oxine-1 = Mn+2_Oxine-1_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	16	0.1	Unknown	lgK:4.6(0.06SD)	4	MSP	906
2	16	0.1	Unknown	lgK:5.3(0.04SD)	4	MKN	999
3	25	0.1	Unknown	lgK:5.58(3SF)	4	MKN	999

Reaction No. 23556							
Mn+2_5ATP-4 + Oxine-1 = Mn+2_Oxine-1_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	16	0.03	Unknown	lgK:4.6(0.03SD)	4	MSP	906
2	16	0.3	Unknown	lgK:4.5(0.04SD)	4	MKN	999
3	25	0.3	Unknown	lgK:4.92(3SF)	5	MKN	999

Reaction No. 23557							
Mn+2_5ADP-3 + Oxine-1 = Mn+2_Oxine-1_5ADP-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	Unknown	lgK:4.98 (3SF)	6	MKN	999

Reaction No. 23579							
Carnosine-1 + Mn+2 = Mn+2_Carnosine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.40 (0.02SD)	6	MGL	999

Reaction No. 23580							
Mn+2 + H+1_Carnosine-1 = Mn+2_H+1_Carnosine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.14 (0.02SD)	4	MGL	999

Reaction No. 23855							
Mn+2_Ptetraen + Mn+2 = Mn+2(2)_Ptetraen							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:2.2 (0.2SD) w	3	MPH	1965

Reaction No. 23955							
Mn+2 + H+1_EtSen = Mn+2_H+1_EtSen							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:5.1 (2SF)	4	MGL	1943

Reaction No. 23988							
TetMDTA-4 + Mn+2 = Mn+2_TetMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:9.53 (3SF)	6	MGL	1956
2	20	0.1	KNO3	lgK:9.53 (3SF) w	6	MPH	2043
3	25	0.1	Unknown	lgK:9.59 (3SF)	6	CRV	552
4	20	0.1	KNO3	dH:3.41 (3SF)	5	MCL	1956

Reaction No. 23989							
Mn+2_TetMDTA-4 + Mn+2 = Mn+2(2)_TetMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:1.82 (3SF)	6	MGL	1956

Reaction No. 23990							
$\text{Mn}^{+2} + \text{H}^{+1}_{\text{TetMDTA-4}} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{TetMDTA-4}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.45 (3SF)	6	MGL	1956

Reaction No. 24081							
$\text{TEDTA-4} + \text{Mn}^{+2} = \text{Mn}^{+2}_{\text{TEDTA-4}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:9.64 (3SF)	2	MGL	999
2	20	0.1	KNO3	lgK:10.07 (4SF)	2	MGL	1956
3	25	0	Inf. Dilution	lgK:11.3 (3SF)	1	EDH	
4	20	0.1	KNO3	dH:-1.53 (3SF)	2	MCL	1956

Reaction No. 24082							
$\text{Mn}^{+2} + \text{H}^{+1}_{\text{TEDTA-4}} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{TEDTA-4}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.08 (3SF)	2	MGL	999
2	20	0.1	KNO3	lgK:5.53 (3SF)	2	MGL	1956
3	25	0	Inf. Dilution	lgK:6.5 (2SF)	1	EES	

Reaction No. 24105							
$\text{Mn}^{+2}_{\text{5MePhenanth}} + \text{5MePhenanth} = \text{Mn}^{+2}_{\text{5MePhenanth}(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.33 (3SF)	6	MDS	3077


Reaction No. 24106							
$\text{Mn}^{+2}_{\text{5MePhenanth}(2)} + \text{5MePhenanth} = \text{Mn}^{+2}_{\text{5MePhenanth}(3)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.60 (3SF)	6	MDS	3077

Reaction No. 24182							
$\text{EDTP-4} + \text{Mn}^{+2} = \text{Mn}^{+2}_{\text{EDTP-4}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KCl	lgK:4.7 (2SF)	4	MGL	999

Reaction No. 24199							
$\text{Mn}^{+2}_{\text{dlBDTA-4}} + \text{H}^{+1} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{dlBDTA-4}}}$							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:2.68 (3SF)	6	MEF	1933

Reaction No. 24204




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.46 (3SF)	6	MEF	1933

Reaction No. 24270




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:9.01 (3SF)	6	MGL	1956
2	20	0.1	KNO3	dH:0.5 (1SF)	5	MCL	1956

Reaction No. 24271




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.7 (2SF)	4	MGL	1956

Reaction No. 24306




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:14.78 (4SF)	6	MGL	1941

Reaction No. 24307




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:9.98 (3SF)	6	MGL	1941

Reaction No. 24308



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.56 (3SF)	6	MGL	1941
2	25	0.1	KNO3	dH:2.15 (3SF)	5	MCL	1941


Reaction No. 24334



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	20	0.1	KNO3	lgK:8.7 (2SF)	4	MGL	1956
2	20	0.1	KNO3	dH:0.9 (1SF)	5	MCL	1956

Reaction No. 24335




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.6 (2SF)	4	MGL	1956

Reaction No. 24377




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:7.1 (2SF)	3	MGL	1956
2	25	0.1	Unknown	lgK:7.82 (3SF)	6	CRV	552

Reaction No. 24378




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.65 (3SF)	3	MGL	2551
2	20	0.1	Unknown	lgK:4.35 (3SF)	0	ENS	1982
3	25	0.1	Unknown	lgK:4.72 (3SF)	3	CRV	552
4	25	1	KCl	lgK:5.37 (3SF)	3	MSP	2022

Reaction No. 24407




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:6.7 (2SF)	4	MGL	1982

Reaction No. 24408



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:6.02 (3SF)	6	MGL	1982

Reaction No. 24490



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.16 (3SF)	2	EAE	
2	37	0.15	KNO3	lgK:1.16 (3SF)	7	MGL	181

Reaction No. 24491							
$\text{Mn}^{+2}_{\text{Val}-1} + \text{H}^{+1}_{\text{Val}-1} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{Val}-1}}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.07(3SF)	2	EAE	
2	37	0.15	KNO3	lgK:1.07(3SF)	7	MGL	181

Reaction No. 24568							
$\text{Mn}^{+2} + \text{H}^{+1}_{\text{His}-1} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{His}-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.898(3SF)	2	EAE	
2	37	0.15	KNO3	lgK:0.9(1SF)	3	MGL	2126
3	32	1:1.5	D2O KNO3	lgK:0.9(1SF)	4	MIR	6510

Reaction No. 24718							
$2\text{<Folic-3>} + \text{Mn}^{+2} = \text{Mn}^{+2}_{\text{Folic-3}}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaClO4	lgK:6.6(0.1SD)	3	MGL	2156

Reaction No. 24762							
$\text{Mn}^{+2} + \text{H}^{+1}(-1)_{\text{Citric-3}} = \text{Mn}^{+2}_{\text{H}^{+1}(-1)_{\text{Citric-3}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.4(2SF)	1	ELC	


Reaction No. 24763							
$\text{Mn}^{+2} + \text{H}^{+1}(-1)_{\text{Citric-3}} + \text{H}^{+1} = \text{Mn}^{+2}_{\text{Citric-3}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.7(3SF)	1	ELC	

Reaction No. 24774							
$\text{Mn}^{+2} + \text{H}^{+1}_{\text{mTyr-2}} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{mTyr-2}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:2.85(3SF)	6	MGL	1050
2	25	0.2	KCl	dH:-4.(1SF)kJ	5	MCL	1050

Reaction No. 24777							
$\text{Mn}^{+2} + \text{H}^{+1}_{\text{oTyr-2}} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{oTyr-2}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0.2	KCl	lgK:2.73 (3SF)	6	MGL	1050
2	25	0.2	KCl	dH:-3. (1SF) kJ	5	MCL	1050

Reaction No. 24785




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:2.1 (2SF)	4	MGL	1050
2	25	0.2	KCl	dH:-2. (1SF) kJ	5	MCL	1050

Reaction No. 24789




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.4 (2SF)	1	EOR	
2	25	0.2	KCl	lgK:2.7 (2SF)	4	MGL	1050
3	25	0.2	KCl	dH:-2. (1SF) kJ	5	MCL	1050

Reaction No. 24794




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:-8.9 (2SF)	4	MGL	1050
2	25	0.2	KCl	dH:23. (2SF) kJ	5	MCL	1050

Reaction No. 24801




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:-10.1 (3SF)	4	MGL	1050
2	25	0.2	KCl	dH:25. (2SF) kJ	5	MCL	1050

Reaction No. 24805



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:-10.2 (3SF)	4	MGL	1050
2	25	0.2	KCl	dH:41. (2SF) kJ	5	MCL	1050


Reaction No. 25001



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0.1	KNO3	lgK:11.5 (0.1SD)	3	MGL	2054
---	----	-----	------	------------------	---	-----	------

Reaction No. 25133




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:7.62 (0.004SD)	6	MGL	2182

Reaction No. 25134




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:9.5 (0.05SD)	4	MGL	2182

Reaction No. 25147




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:10.63 (0.008SD)	6	MGL	2182

Reaction No. 25148




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:12.2 (0.06SD)	4	MGL	2182

Reaction No. 25149




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	NaCl	lgK:1.27 (0.02SD)	4	MGL	2182

Reaction No. 25202



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:8.48 (0.02SD)	6	MGL	2281

Reaction No. 25203



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.36 (0.08SD)	6	MGL	2281

Reaction No. 25220

[10]N2S:Acet*2-2 + Mn+2 = Mn+2_[10]N2S:Acet*2-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:8.97 (0.01SD)	6	MGL	2281

Reaction No. 25230							
[9]N2S:Acet*2-2 + Mn+2 = Mn+2_[9]N2S:Acet*2-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:9.25 (0.01SD)	6	MGL	2281

Reaction No. 25258							
Mn+2_AcHydroxam-1 + AcHydroxam-1 = Mn+2_AcHydroxam-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:2.9 (2SF)	5	MGL	3676

Reaction No. 25275							
Guanosine-1 + Mn+2 = Mn+2_Guanosine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:2.70 (3SF)	5	MGL	2194
2	25	0.1	KNO3	lgK:2.65 (3SF)	5	MGL	2194
3	35	0.1	KNO3	lgK:2.61 (3SF)	5	MGL	2194
4	45	0.1	KNO3	lgK:2.58 (3SF)	5	MGL	2194
5	15:45	0.1	KNO3	dH:-7. (1.SD) kJ	5	MCL	2194

Reaction No. 25276							
2<Guanosine-1> + Mn+2 = Mn+2_Guanosine-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:3.55 (3SF)	5	MGL	2194
2	25	0.1	KNO3	lgK:3.49 (3SF)	5	MGL	2194
3	35	0.1	KNO3	lgK:3.44 (3SF)	5	MGL	2194
4	45	0.1	KNO3	lgK:3.39 (3SF)	5	MGL	2194
5	15:45	0.1	KNO3	dH:-9.3 (1.SD) kJ	5	MCL	2194

Reaction No. 25284							
Guanosine-1 + Mn+2 + Bipy = Mn+2_Bipy_Guanosine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:6.2 (0.07SD)	5	MGL	2194
2	25	0.1	KNO3	lgK:6.2 (0.07SD)	5	MGL	2194

3	35	0.1	KNO3	lgK:6.1(0.07SD)	5	MGL	2194
4	45	0.1	KNO3	lgK:6.0(0.07SD)	5	MGL	2194
5	15:45	0.1	KNO3	dH:-15.(1.SD)kJ	5	MCL	2194

Reaction No. 25291

Guanosine-1 + Mn+2 + Phenanth = Mn+2_Phenanth_Guanosine-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:7.0(0.07SD)	6	MGL	2194
2	25	0.1	KNO3	lgK:7.0(0.07SD)	6	MGL	2194
3	35	0.1	KNO3	lgK:6.9(0.07SD)	6	MGL	2194
4	45	0.1	KNO3	lgK:6.9(0.07SD)	6	MGL	2194
5	25	0.1	KNO3	dH:-11.(1.SD)kJ	5	MTD	2194

Reaction No. 25298

Guanosine-1 + Mn+2 + SulfSal-3 = Mn+2_Guanosine-1_SulfSal-3

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:2.8(0.07SD)	6	MGL	2194
2	25	0.1	KNO3	lgK:2.8(0.07SD)	6	MGL	2194
3	35	0.1	KNO3	lgK:2.7(0.07SD)	6	MGL	2194
4	45	0.1	KNO3	lgK:2.7(0.07SD)	6	MGL	2194
5	25	0.1	KNO3	dH:-8.(1.SD)kJ	5	MTD	2194

Reaction No. 25325

Mn+2_H+1(-1)_Arg-1 + H+1 = Mn+2_Arg-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:11.56(4SF)	5	ENS	2350

Reaction No. 25361

UramilIDA-3 + Mn+2 = Mn+2_UramilIDA-3

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:9.87(3SF)	5	ENS	999
2	25	0.1	Me4N+ salt	lgK:10.28(4SF)	6	CRV	552
3	25	0.1	Unknown	lgK:9.95(3SF)	6	CRV	552
4	10:40	0.1	Unknown	dH:-3.(1SF)	6	CRV	552
5	25	0.1	KNO3	dH:-2.51(3SF)	5	MTD	6627

Reaction No. 25362

Mn+2 + H+1_UramilIDA-3 = Mn+2_H+1_UramilIDA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.48(3SF)	5	ENS	999

Reaction No. 25555							
N2PyridMeAsp-2 + Mn+2 = Mn+2_N2PyridMeAsp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:6.97(0.01SD)	5	MGL	999
2	20	0.1	NaNO3	lgK:7.10(0.05MD)	5	MPT	6937
3	20	0.1	NaNO3	dH:-0.4(0.1MD)	5	MCL	6937

Reaction No. 25556							
Mn+2_N2PyridMeAsp-2 + N2PyridMeAsp-2 = Mn+2_N2PyridMeAsp-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.63(0.01SD)	6	MGL	999
2	20	0.1	NaNO3	lgK:3.5(0.1MD)	5	MPT	6937

Reaction No. 25569							
N2COOPhenIDA-3 + Mn+2 = Mn+2_N2COOPhenIDA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.85(3SF)	5	MGL	6833

Reaction No. 25570							
Mn+2 + H+1_N2COOPhenIDA-3 = Mn+2_H+1_N2COOPhenIDA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.(1SF)	3	MGL	6833

Reaction No. 25953							
NPhosMeIDA-4 + Mn+2 = Mn+2_NPhosMeIDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:7.24(3SF)	2	MGL	999
2	30	0.1	KCl	lgK:8.0(2SF)	1	MGL	140

Reaction No. 25956							
Mn+2 + H+1_NPhosMeIDA-4 = Mn+2_H+1_NPhosMeIDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.5(2SF)	6	MEP	2009

Reaction No. 26211							
Uracil-1 + Mn+2 = Mn+2_Uracil-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.35 (3SF)	4	MPT	1760
2	45	0.1	KNO3	lgK:2.9 (0.1SD)	4	MGL	2326

Reaction No. 26218							
Thymine-1 + Mn+2 = Mn+2_Thymine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.52 (3SF)	5	MPT	1760
2	45	0.1	KNO3	lgK:3.4 (0.1SD)	5	MGL	2326

Reaction No. 26239							
Mn+2 + H+1_TAR-2 = Mn+2_H+1_TAR-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:2.02 (3SF)	5	MSP	1166

Reaction No. 26240							
TAR-2 + Mn+2 = Mn+2_TAR-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:5.52 (3SF)	5	MSP	1166


Reaction No. 26360							
Mn+2_TetMDTA-4 + H+1 = Mn+2_H+1_TetMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.47 (3SF) w	2	MPH	2043
2	20	0.1	Unknown	lgK:6.6 (2SF)	2	ENS	2373
3	25	0	Inf. Dilution	lgK:5.8 (2SF)	1	EDH	

Reaction No. 26459							
OHEtDiPhos-4 + Mn+2 = Mn+2_OHEtDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:6.94 (3SF)	3	MGL	1599

Reaction No. 26460							
Mn+2 + H+1_OHEtDiPhos-4 = Mn+2_H+1_OHEtDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0.1	KNO3	lgK:4.42 (3SF)	3	MGL	1599
---	----	-----	------	----------------	---	-----	------

Reaction No. 26461




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.18 (3SF)	3	MGL	1599

Reaction No. 26607




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:10. (2SF)w	3	MPH	1565

Reaction No. 26879




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:20.20 (0.008SD)	5	MGL	1771
2	25	0.1	Me4NNO3	lgK:20.0 (0.2SD)	5	CRV	13242

Reaction No. 26880




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:24.35 (0.005SD)	5	MGL	1771

Reaction No. 26881




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:22.6 (0.08SD)	5	MGL	1771

Reaction No. 26882



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:26.8 (0.07SD)	5	MGL	1771

Reaction No. 26904



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:16.74 (0.02SD)	5	MGL	1771

Reaction No. 26905							
$\text{H}+1 + [\text{13}]\text{N4:Acet*4-4} + \text{Mn}+2 = \text{Mn}+2_ \text{H}+1_ [\text{13}]\text{N4:Acet*4-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:20.7 (0.08SD)	5	MGL	1771

Reaction No. 26906							
$2<\text{Mn}+2> + [\text{13}]\text{N4:Acet*4-4} = \text{Mn}+2(2)_ [\text{13}]\text{N4:Acet*4-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:20.1 (0.08SD)	5	MGL	1771

Reaction No. 26907							
$2<\text{Mn}+2> + \text{H}+1 + [\text{13}]\text{N4:Acet*4-4} = \text{Mn}+2(2)_ \text{H}+1_ [\text{13}]\text{N4:Acet*4-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:24.0 (0.07SD)	5	MGL	1771

Reaction No. 26927							
$[\text{14}]\text{N4:Acet*4-4} + \text{Mn}+2 = \text{Mn}+2_ [\text{14}]\text{N4:Acet*4-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:11.50 (4SF)	4	CRV	552
2	25	0.1	KNO3	lgK:11.27 (0.007SD)	4	MGL	1771
3	25	0.1	KNO3	lgK:11.3 (0.1SD)	4	CRV	13242

Reaction No. 27039							
$\text{AmPhenMeDiPhos-4} + \text{Mn}+2 = \text{Mn}+2_ \text{AmPhenMeDiPhos-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:9.93 (3SF)	5	MGL	999

Reaction No. 27040							
$\text{Mn}+2 + \text{H}+1_ \text{AmPhenMeDiPhos-4} = \text{Mn}+2_ \text{H}+1_ \text{AmPhenMeDiPhos-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:7.29 (3SF)	5	MGL	999

Reaction No. 27041							
$2<\text{Mn}+2> + \text{AmPhenMeDiPhos-4} = \text{Mn}+2(2)_ \text{AmPhenMeDiPhos-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:15.41 (4SF)	5	MGL	999

Reaction No. 27099							
--------------------	--	--	--	--	--	--	--

Mn+2 + H+1_PAR-2 = Mn+2_H+1_PAR-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:2.40 (3SF)	5	MSP	1166

Reaction No. 27100							
PAR-2 + Mn+2 = Mn+2_PAR-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:8.48 (3SF)	5	MSP	1166

Reaction No. 27312							
1BuEDTA-4 + Mn+2 = Mn+2_1BuEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:15.6 (0.1SD)	6	MPL	1994

Reaction No. 27333							
4AmPyrid26DiCOO-2 + Mn+2 = Mn+2_4AmPyrid26DiCOO-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.89 (3SF)	6	MGL	2041

Reaction No. 27334							
Mn+2_4AmPyrid26DiCOO-2 + 4AmPyrid26DiCOO-2 = Mn+2_4AmPyrid26DiCOO-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.81 (3SF)	6	MGL	2041


Reaction No. 27360							
4NitrBenz-1 + Mn+2 = Mn+2_4NitrBenz-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Vol NaClO4	lgK:1.67 (3SF)	5	MGL	6070

Reaction No. 27714							
Mn+2_Phenanth + 5CMP-2 = Mn+2_Phenanth_5CMP-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:3.7 (0.1SD)	5	MPT	1618

Reaction No. 27719							
Mn+2_GlyGly-1 + 5CMP-2 = Mn+2_GlyGly-1_5CMP-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:1.4 (2SF)	1	ESC	
2	35	0.1	KNO3	lgK:1.4 (0.1SD)	5	MPT	1618

Reaction No. 27724




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:0.2 (0.03SD)	5	MPT	1618

Reaction No. 27727




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:11.84 (4SF)	3	MGL	1187

Reaction No. 27730




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.9 (3SF)	1	ELC	
2	35	0.1	KNO3	lgK:12.34 (4SF)	3	MGL	1187

Reaction No. 27733




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:11.95 (4SF)	3	MGL	1187

Reaction No. 27742




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.8 (2SF)	1	ESC	
2	35	0.1	KNO3	lgK:9.53 (3SF)	3	MGL	1187

Reaction No. 27747




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.6 (2SF)	1	ESC	
2	35	0.1	KNO3	lgK:8.43 (3SF)	5	MGL	1187

Reaction No. 27748




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.0(2SF)	1	ESC	
2	35	0.1	KNO3	lgK:3.91(3SF)	5	MGL	1187

Reaction No. 27757




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:3.02(3SF)	0	MGL	1187

Reaction No. 27760




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:8.36(3SF)	5	MGL	1187

Reaction No. 27761




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:3.48(3SF)	5	MGL	1187

Reaction No. 27803




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.08(3SF)	2	EAE	
2	27	0.3	Unknown	lgK:0.08(1SF)	5	MMR	1174

Reaction No. 27811




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.2(3SF)	2	EAE	
2	27	0.3	Unknown	lgK:0.2(0.1SD)	5	MMR	1173

Reaction No. 27886




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:8.05(3SF)	5	MPT	1183

Reaction No. 27892




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:4.10 (3SF)	5	MPT	1183

Reaction No. 27900




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.4 (2SF)	1	ESC	
2	35	0.1	KNO3	lgK:9.07 (3SF)	5	MPT	1183

Reaction No. 27906




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:3.45 (3SF)	5	MPT	1183

Reaction No. 28857




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20		Dioxan:Water 3:1Vol	lgK:10.24 (4SF)	5	MGL	2261

Reaction No. 28858




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20		Dioxan:Water 3:1Vol	lgK:17.47 (4SF)	5	MGL	2261

Reaction No. 28894




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:1.07 (3SF)	5	MGL	2261

Reaction No. 28895



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:1.83 (3SF)	5	MGL	2261

Reaction No. 28919



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0.1	K+1 salt	lgK:7.20 (3SF)	6	CRV	2556
---	----	-----	----------	----------------	---	-----	------

Reaction No. 28973							
Mn+2 + H+1_MetNNDiAcet-3 = Mn+2_H+1_MetNNDiAcet-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Na+1 salt	lgK:3.16 (3SF)	6	CRV	2556

Reaction No. 29020							
2PyridNHNH2 + Mn+2 = Mn+2_2PyridNHNH2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:2.64 (3SF)w	6	MPH	1967

Reaction No. 29034							
PyridCHNHNHPPyrid + Mn+2 = Mn+2_PyridCHNHNHPPyrid							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.68 (3SF)w	6	MPH	1967

Reaction No. 29035							
Mn+2_PyridCHNHNHPPyrid + PyridCHNHNHPPyrid = Mn+2_PyridCHNHNHPPyrid(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:2. (1SF)w	6	MPH	1967

Reaction No. 29091							
3FPropan-1 + Mn+2 = Mn+2_3FPropan-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:1.65 (3SF)	5	MGL	6036

Reaction No. 29095							
Mn+2 + Xanthosine-1 + H+1_TMEDA = Mn+2_H+1_TMEDA_Xanthosine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:5.0 (0.2SD)	5	MGL	1905

Reaction No. 29111							
Mn+2_TriMDTA-4 + H+1 = Mn+2_H+1_TriMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:5.3 (2SF)	5	ENS	2373

Reaction No. 29119							
Mn+2_PentMDTA-4 + H+1 = Mn+2_H+1_PentMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:7.6 (2SF)	5	ENS	2373

Reaction No. 29230							
Norval-1 + Mn+2 = Mn+2_Norval-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:3.30 (3SF)	6	MGL	2392
2	20	0.15	NaCl	lgK:2.90 (3SF)	6	MGL	2392
3	30	0.1	KNO3	lgK:3.25 (3SF)	6	MGL	2392
4	40	0.1	KNO3	lgK:3.19 (3SF)	6	MGL	2392
5	50	0.1	KNO3	lgK:3.11 (3SF)	6	MGL	2392
6	60	0.1	KNO3	lgK:3.03 (3SF) w	6	MPH	2392
7	20:60	0.1	KNO3	dH:13.0 (3SF)	0	MTD	2392
Note (7): Low wgt for internal consistency							

Reaction No. 29231							
2<Norval-1> + Mn+2 = Mn+2_Norval-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.19 (3SF)	6	MGL	2392
2	30	0.1	KNO3	lgK:5.15 (3SF)	6	MGL	2392
3	40	0.1	KNO3	lgK:5.12 (3SF)	6	MGL	2392
4	50	0.1	KNO3	lgK:5.09 (3SF)	6	MGL	2392
5	60	0.1	KNO3	lgK:5.06 (3SF)	6	MGL	2392
6	20:60	0.1	KNO3	dH:-4.60 (3SF)	6	MTD	2392

Reaction No. 29237							
2<Norleu-1> + Mn+2 = Mn+2_Norleu-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:5. (1SF)	3	MGL	3514

Reaction No. 29260							
bAla-1 + Mn+2 = Mn+2_bAla-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:2.13 (3SF)	6	MGL	906
2	20	1	NaNO3	lgK:2.54 (3SF)	6	MIX	2392

3	20	1	Unknown	lgK:2.53(3SF)	4	MSL	906
4	20	1	Unknown	lgK:2.53(3SF)	4	MSL	11516
Note (4): Berezina L et al., Zhur. Neorg. Khim., 1969, 14, 1854							
5	23	0.5	NaNO ₃	lgK:2.52(3SF)	4	MIX	906
6	25	0	Inf. Dilution	lgK:2.1(2SF)	1	EAE	
7	25	1	KCl	lgK:2.52(3SF)	5	MSP	2022
8	30	0.1	KNO ₃	lgK:2.06(3SF)	6	MGL	906
9	40	0.1	KNO ₃	lgK:2.01(3SF)	6	MGL	906
10	40	1	NaNO ₃	lgK:2.41(3SF)	6	MIX	2392
11	40	1	Unknown	lgK:2.41(3SF)	4	MSL	906
12	50	0.1	KNO ₃	lgK:1.97(3SF)	6	MGL	906
13	60	0.1	KNO ₃	lgK:1.94(3SF)	6	MGL	906
14	60	1	NaNO ₃	lgK:2.28(3SF)	4	MSL	906
15	20:60	0.1	KNO ₃	dH:-2.1(2SF)	6	MTD	2392

Reaction No. 29633							
2<Xanthosine-1> + Mn+2 = Mn+2_Xanthosine-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	5	0.1	KNO ₃	lgK:6.4(0.05SD)	3	MGL	3867
2	25	0.1	KNO ₃	lgK:5.3(0.09SD)	0	MGL	3867
3	35	0.1	KNO ₃	lgK:5.8(0.06SD)	3	MGL	3867
4	45	0.1	KNO ₃	lgK:5.6(0.1SD)	5	MGL	1905
5	25	0.1	KNO ₃	dH:-3.(0.5SD)	3	MCL	3867


Reaction No. 29640							
Mn+2_Gly-1 + H+1_Xanthosine-1 = Mn+2_Gly-1_Xanthosine-1 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO ₃	lgK:2.8(2SF)	4	MGL	2371

Reaction No. 29658							
Mn+2 + Xanthosine-1 + H+1_SulfSal-3 = Mn+2_H+1_Xanthosine-1_SulfSal-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.8(2SF)	1	ESC	
2	45	0.1	KNO ₃	lgK:2.8(0.05SD)	5	MGL	1905

Reaction No. 29665							
Mn+2 + Xanthosine-1 + Bipy = Mn+2_Bipy_Xanthosine-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:7. (0.5SD)	5	MGL	1905

Reaction No. 29672




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:7. (0.3SD)	5	MGL	1905

Reaction No. 29930




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Unknown	lgK:0.57 (2SF)	4	CRV	2556

Reaction No. 29931




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Unknown	lgK:0.89 (2SF)	4	CRV	2556

Reaction No. 29932




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Unknown	lgK:1.02 (3SF)	4	CRV	2556

Reaction No. 29951




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Unknown	lgK:0.74 (2SF)	4	CRV	2556

Reaction No. 30068



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:13.4 (0.1SD)	6	MPL	1998
2	20	0.1	KNO3	lgK:13.3 (0.03SD)	6	MPT	2004

Reaction No. 30156



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:16. (0.2SD)	4	MGL	1783

Reaction No. 30157							
$\text{Mn}^{+2} + \text{H}^{+1}_{\text{HPEDDA-4}} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{HPEDDA-4}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:10. (0.3SD)	4	MGL	1783

Reaction No. 30158							
$\text{Mn}^{+2} + \text{H}^{+1(2)}_{\text{HPEDDA-4}} = \text{Mn}^{+2}_{\text{H}^{+1(2)}_{\text{HPEDDA-4}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5. (0.3SD)	4	MGL	1783

Reaction No. 30269							
$\text{NONWAcid-2} + \text{Mn}^{+2} = \text{Mn}^{+2}_{\text{NONWAcid-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.19 (3SF)	5	CRV	2556

Reaction No. 30410							
$2\text{Am3SulfPropan-2} + \text{Mn}^{+2} = \text{Mn}^{+2}_{2\text{Am3SulfPropan-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:3.30 (3SF)	5	MGL	2261

Reaction No. 30550							
$\text{DiThioDiCOO-2} + \text{Mn}^{+2} = \text{Mn}^{+2}_{\text{DiThioDiCOO-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:1.7 (2SF)	5	MGL	999


Reaction No. 30698							
$\text{EtEDTA-4} + \text{Mn}^{+2} = \text{Mn}^{+2}_{\text{EtEDTA-4}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:15.7 (0.09SD)	6	MPL	1995

Reaction No. 30712							
$11\text{DiMeEDTA-4} + \text{Mn}^{+2} = \text{Mn}^{+2}_{11\text{DiMeEDTA-4}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:15.31 (4SF)	6	MPL	1978

Reaction No. 30735							
$\text{HexEDTA-4} + \text{Mn}^{+2} = \text{Mn}^{+2}_{\text{HexEDTA-4}}$							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:15.5 (0.1SD)	6	MPT	1981

Reaction No. 31033




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:0.93 (2SF)	4	MGL	2261

Reaction No. 31034




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:1.67 (3SF)	4	MGL	2261

Reaction No. 31035




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.0 (1SF)	1	EDH	
2	25	0.1	KNO3	lgK:-0.30 (2SF)	2	MPL	2653
3	25	0.5	KNO3	lgK:0.44 (2SF)	2	MGL	2261

Reaction No. 31036




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:0.32 (2SF)	2	MPL	2653
2	25	0.5	KNO3	lgK:0.99 (2SF)	1	MGL	2261

Reaction No. 31041




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:1.34 (3SF)	5	MGL	2261

Reaction No. 31042




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:2.08 (3SF)	5	MGL	2261

Reaction No. 31043




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:3.08 (3SF)	5	MGL	2261

Reaction No. 31226




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:0.48 (2SF)	3	MPL	2653
2	25	0.5	KNO3	lgK:0.27 (2SF)	3	MGL	2261

Reaction No. 31227




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:0.56 (2SF)	3	MPL	2653
2	25	0.5	KNO3	lgK:0.90 (2SF)	3	MGL	2261

Reaction No. 31228




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:0.95 (2SF)	3	MPL	2653

Reaction No. 31426




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	K+1 salt	lgK:6.94 (3SF)	5	CRV	2556
2	25	1	KNO3	lgK:6.94 (3SF)	5	MGL	2261

Reaction No. 31427




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:3.29 (3SF)	5	MGL	2261

Reaction No. 31432




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	K+1 salt	lgK:8.33 (3SF)	5	CRV	2556

Reaction No. 31487




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:3.79 (3SF)	5	MGL	2261

Reaction No. 31488




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:2.33 (3SF)	5	MGL	2261

Reaction No. 31502




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:4.38 (3SF)	5	MGL	2261
2	25	0.15	NaCl	lgK:4.30 (3SF)	5	MGL	2261

Reaction No. 31503



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:2.49 (3SF)	5	MGL	2261

Reaction No. 31521




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	1	Dioxan:Water 60:40Vol NaNO3	lgK:4.1 (2SF)	5	MGL	906

Reaction No. 31522



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	1	Dioxan:Water 60:40Vol NaNO3	lgK:3.5 (2SF)	5	MGL	906

Reaction No. 31542



Note: Weighted out coz its thermodynamically isolated; not nec. bad data

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.05 (3SF)	0	MPL	2653

Reaction No. 31576							
H+1 + Thr-1 + Mn+2 = Mn+2_H+1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.2(3SF)	2	EAE	
2	37	0.15	NaCl	lgK:9.916(4SF)	4	MGL	2261

Reaction No. 31694							
2SHHis-2 + Mn+2 = Mn+2_2SHHis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:4.1(0.1SD)	5	MGL	2697

Reaction No. 31695							
Mn+2_2SHHis-2 + 2SHHis-2 = Mn+2_2SHHis-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:4.5(0.09SD)	4	MGL	2697

Reaction No. 31723							
2<H+1> + Citric-3 + Mn+2 = Mn+2_H+1(2)_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.2(3SF)	2	EAE	
2	37	0.15	Inert	lgK:11.6(3SF)	5	MGL	2703
3	37	0.15	KNO3	lgK:11.4(0.07SD)	6	MGL	2703


Reaction No. 31724							
2<Citric-3> + 2<Mn+2> = 2<H+1> + Mn+2(2)_H+1(-2)_Citric-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-4.7(3SF)	2	EAE	
2	37	0.15	Inert	lgK:-5.59(3SF)	3	MGL	2703
3	37	0.15	KNO3	lgK:-5.73(0.05SD)	3	MGL	2703

Reaction No. 31738							
2SHHistamine-1 + Mn+2 = Mn+2_2SHHistamine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:5.3(0.09SD)	5	MGL	2697

Reaction No. 31739							
Mn+2_2SHHistamine-1 + 2SHHistamine-1 = Mn+2_2SHHistamine-1(2)							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:4.3(0.2SD)	5	MGL	2697

Reaction No. 32016




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:8.33(3SF)	5	MGL	2261

Reaction No. 32017




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:8.09(3SF)	5	MGL	2261

Reaction No. 32098




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:0.850(3SF)	5	MGL	2261

Reaction No. 32257




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:4.90(0.01SD)	5	MGL	6868

Reaction No. 32258




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:2.60(3SF)	5	MGL	6868

Reaction No. 32352



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:7.35(0.04MD)	6	MGL	2648

Reaction No. 32354



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:7.40(0.03MD)	6	MGL	2648

Reaction No. 32363							
Mn+2 + Bipy_5UTP-4 = Mn+2_Bipy_5UTP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:7.21 (0.14MD)	6	MGL	2648

Reaction No. 32469							
Ala-1 + Mn+2 + LDopa-3 = Mn+2_Ala-1_LDopa-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:10.14 (4SF)	5	MGL	2710

Reaction No. 32470							
Ala-1 + Mn+2 + Dopamine-2 = Mn+2_Ala-1_Dopamine-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:10.12 (4SF)	5	MGL	2710

Reaction No. 32471							
Ala-1 + Mn+2 + NorEpinephrine-2 = Mn+2_Ala-1_NorEpinephrine-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:9.61 (3SF)	5	MGL	2710

Reaction No. 32472							
Ala-1 + Mn+2 + Epinephrine-2 = Mn+2_Ala-1_Epinephrine-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:9.63 (3SF)	5	MGL	2710


Reaction No. 32537							
H+1 + His-1 + Mn+2 + LDopa-3 = Mn+2_H+1_His-1_LDopa-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:20.47 (4SF)	6	MGL	2710

Reaction No. 32538							
H+1 + His-1 + Mn+2 + Dopamine-2 = Mn+2_H+1_His-1_Dopamine-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:20.81 (4SF)	6	MGL	2710

Reaction No. 32539							
H+1 + His-1 + Mn+2 + NorEpinephrine-2 = Mn+2_H+1_His-1_NorEpinephrine-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0.2	KCl	lgK:19.71(4SF)	6	MGL	2710
---	----	-----	-----	----------------	---	-----	------

Reaction No. 32540




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:20.26(4SF)	6	MGL	2710

Reaction No. 32557




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:20.08(4SF)	6	MGL	2710

Reaction No. 32558




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:20.32(4SF)	6	MGL	2710

Reaction No. 32559




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:19.62(4SF)	6	MGL	2710

Reaction No. 32560




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KCl	lgK:19.83(4SF)	6	MGL	2710

Reaction No. 32619



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.69(0.10MD)	6	MGL	2648

Reaction No. 32664



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:1.94(0.01SD)	5	MGL	2702

Reaction No. 32675

2AmOxButan-1 + Mn+2 = Mn+2_2AmOxButan-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:1.5(0.04SD)	5	MGL	2702

Reaction No. 32834							
4NitrCat-2 + Mn+2 = Mn+2_4NitrCat-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:6.51(3SF)	5	MGL	999

Reaction No. 32835							
Mn+2_4NitrCat-2 + 4NitrCat-2 = Mn+2_4NitrCat-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:4.74(3SF)	5	MGL	999

Reaction No. 32878							
F*3Acac-1 + Mn+2 = Mn+2_F*3Acac-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Unknown	lgK:0.94(2SF)	3	CRV	2556

Reaction No. 32879							
2<F*3Acac-1> + Mn+2 = Mn+2_F*3Acac-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Unknown	lgK:2.96(3SF)	3	CRV	2556


Reaction No. 32900							
[18]N2O4:DiMalon-4 + Mn+2 = Mn+2_[18]N2O4:DiMalon-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:7.41(3SF)	5	MGL	6135
2	25	0.16	NaCl	lgK:7.40(3SF)	5	MGL	2717

Reaction No. 32961							
2PrEDTA-4 + Mn+2 = Mn+2_2PrEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:15.5(0.1SD)	6	MPT	2012

Reaction No. 32980							
2MePrEDTA-4 + Mn+2 = Mn+2_2MePrEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	20	0.1	KNO3	lgK:15.4 (0.1SD)	6	MPT	2012
---	----	-----	------	------------------	---	-----	------

Reaction No. 33189




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:9.0 (0.04SD)	6	MGL	2961

Reaction No. 33190




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:4.13 (3SF)	5	MGL	2961

Reaction No. 33537




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3. (1SF)	3	MDS	3076

Reaction No. 33858




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.3	NaClO4	lgK:2.1 (0.08SD)	5	MKN	3290

Reaction No. 33859




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.3 (2SF)	1	ELC	
2	25	0.1	NaClO4	lgK:7.3 (0.04SD)	0	MGL	125

Reaction No. 33860



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.3	NaClO4	lgK:2.8 (0.06SD)	5	MKN	3290

Reaction No. 33861



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.3	NaClO4	lgK:2.4 (0.06SD)	5	MKN	3290
2	25	0.3	NaClO4	lgK:2.6 (0.2SD)	5	MSP	3290

Reaction No. 33862							
Mn+2_Bipy + UramilIDA-3 = Mn+2_Bipy_UramilIDA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.3	NaClO4	lgK:2.1(0.08SD)	5	MKN	3290

Reaction No. 33863							
Mn+2_Bipy + EDDA-2 = Mn+2_Bipy_EDDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.3	NaClO4	lgK:2.6(0.07SD)	5	MKN	3290

Reaction No. 33864							
Mn+2_Bipy + Dien = Mn+2_Bipy_Dien							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.3	NaClO4	lgK:2.7(0.1SD)	5	MKN	3290

Reaction No. 33865							
Mn+2_Bipy + Trien = Mn+2_Bipy_Trien							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.3	NaClO4	lgK:2.4(0.08SD)	5	MKN	3290

Reaction No. 33866							
Mn+2_Bipy + Tren = Mn+2_Bipy_Tren							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.3	NaClO4	lgK:2.4(0.07SD)	5	MKN	3290
2	25	0.3	NaClO4	lgK:2.5(0.2SD)	5	MSP	3290

Reaction No. 33867							
Mn+2_Bipy + 232Tet = Mn+2_232Tet_Bipy							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.3	NaClO4	lgK:2.4(0.08SD)	5	MKN	3290

Reaction No. 33889							
Mn+2 + H+1_Tetracycline-2 = Mn+2_H+1_Tetracycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:3.9(0.03SD)	5	MGL	3335

Reaction No. 34070							
--------------------	--	--	--	--	--	--	--

5ATP-4 + Mn+2 + Gly-1 = Mn+2_Gly-1_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	40:60		Glycerol:Water 2:3Vol	dH:7.2 (0.2SD)	5	MMR	2913
2	40:60		Glycerol:Water 2:3Vol	dS:-3. (0.7SD)	5	EFE	2913

Reaction No. 34220							
2COCH33OHThiophene-1 + Mn+2 = Mn+2_2COCH33OHThiophene-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 10:90Wgt NaClO4	lgK:3.0 (0.2SD)	5	MGL	6061
2	25	0.1	Dioxan:Water 10:90Wgt NaClO4	lgK:2.9 (0.1SD)	5	MPS	6061

Reaction No. 34501							
Mn+3_OH-1_2SHAcet-2 + H+1 = Mn+3_2SHAcet-2 + H2O							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.2	NaClO4	lgK:8.11 (3SF)	5	MGL	3429

Reaction No. 34536							
Di2KetPyrid + Mn+2 = Mn+2_Di2KetPyrid							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaClO4	lgK:1.0 (0.2SD)	6	MGL	3100

Reaction No. 34537							
Mn+2_Di2KetPyrid_OH-1 + H+1 = Mn+2_Di2KetPyrid + H2O							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:8. (0.3SD)	6	MGL	3100

Reaction No. 34654							
PAN-1 + Mn+2 = Mn+2_PAN-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Dioxan:Water 50:50Vol	lgK:8.5 (2SF)	5	MGL	999

Reaction No. 34655							
Mn+2_PAN-1 + PAN-1 = Mn+2_PAN-1 (2)							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Dioxan:Water 50:50Vol	lgK:7.9 (2SF)	5	MGL	999

Reaction No. 34656							
2<PAN-1> + Mn+2 = Mn+2_PAN-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	29:33	0.1	NaClO4	lgK:15.30 (4SF)	5	MDS	999
2	23:25	0.1	Ethanol:Water 40:60Vol NaClO4	lgK:15.7 (0.08SD)	5	MSP	999

Reaction No. 35265							
2MePhenanth + Mn+2 = Mn+2_2MePhenanth							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.0 (2SF)	5	MDS	3076

Reaction No. 35266							
Mn+2_2MePhenanth + 2MePhenanth = Mn+2_2MePhenanth (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.5 (2SF)	5	MDS	3076

Reaction No. 35267							
Mn+2_2MePhenanth (2) + 2MePhenanth = Mn+2_2MePhenanth (3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.4 (2SF)	5	MDS	3076


Reaction No. 35380							
Pyridoxine-1 + Mn+2 = Mn+2_Pyridoxine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KCl	lgK:1.70 (3SF)	5	MGL	3146

Reaction No. 35386							
Pyridoxamine-1 + Mn+2 = Mn+2_Pyridoxamine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KCl	lgK:3.46 (3SF)	5	MGL	3146

Reaction No. 35391							
Pyridoxal-1 + Mn+2 = Mn+2_Pyridoxal-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KCl	lgK:1.70 (3SF)	5	MGL	3146

Reaction No. 35520




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:3.4 (2SF)	5	MGL	140

Reaction No. 35548




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.02	Unknown	lgK:1.3 (2SF)	3	MGL	140

Reaction No. 35856




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:10.9 (0.08SD)	5	MGL	3802

Reaction No. 35857




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:7.17 (0.01SD)	5	MGL	3802

Reaction No. 35858




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:2.31 (0.009SD)	5	MGL	3802

Reaction No. 35859



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:3.1 (0.03SD)	5	MGL	3802

Reaction No. 35901



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:2.3 (2SF)	5	MGL	13488
2	20	0.1	KNO3	lgK:1.7 (2SF)	5	MEP	11516

Note (2): Jokl V, J. Chromatography, 1964, 14, 71							
3	25	0.01	Unknown	lgK:2.97 (3SF)	5	MGL	11516
Note (3): Maley L et al., Australian J. Sci. Res., 1949, 92, 579							
4	25	0.5	KCl	lgK:2.05 (3SF)	5	MGL	180
5	25	0.5	KNO3	lgK:1.71 (3SF)	5	MGL	183
6	25	0.65	KCl	lgK:1.98 (3SF)	5	MGL	179
7	25	1	KCl	lgK:2.05 (3SF)	5	MSP	2022
8	27	0	Unknown	lgK:2.05 (3SF)	5	MMR	1174
9	37	0.15	KNO3	lgK:2.05 (3SF)	5	MGL	181
10	25	0.1	DMF:Water 40:60Vol KNO3	lgK:2.58 (3SF)	5	MGL	3733
11	25	0.1	DMF:Water 50:50Vol KNO3	lgK:2.72 (3SF)	5	MGL	3733
12	25	0.1	DMF:Water 60:40Vol KNO3	lgK:3.0 (2SF)	3	MGL	3733
13	25	0.1	DMF:Water 70:30Vol KNO3	lgK:3.41 (3SF)	5	MGL	3733
14	25	0.1	DMF:Water 75:25Vol KNO3	lgK:3.6 (2SF)	0	MGL	3733
15	25	0.1	DMF:Water 80:20Vol KNO3	lgK:3.8 (2SF)	0	MGL	3733
16	25	0.1	Dioxan:Water 20:80Vol NaClO4	lgK:2.6 (2SF)	3	MGL	3733
17	25	0.1	Dioxan:Water 40:60Vol NaClO4	lgK:3.0 (2SF)	0	MGL	3733
18	25	0.1	MeCN:Water 20:80Vol KNO3	lgK:2.43 (3SF)	5	MGL	3733
19	25	0.1	MeCN:Water 40:60Vol KNO3	lgK:2.76 (3SF)	5	MGL	3733
20	25	0.1	MeCN:Water 50:50Vol KNO3	lgK:2.9 (2SF)	3	MGL	3733
21	25	0.1	MeCN:Water 60:40Vol KNO3	lgK:3.2 (2SF)	3	MGL	3733

22	25	0.1	MeCN:Water 70:30Vol KNO3	lgK:3.6 (2SF)	3	MGL	3733
23	25	0.1	MeCN:Water 75:25Vol KNO3	lgK:3.6 (2SF)	3	MGL	3733
24	25	0.1	MeCN:Water 80:20Vol KNO3	lgK:3.8 (2SF)	0	MGL	3733
25	25	0.1	Methanol:Water 55:45Vol KNO3	lgK:2.53 (3SF)	5	MGL	3733
26	25	0.1	Methanol:Water 60:40Vol KNO3	lgK:2.61 (3SF)	5	MGL	3733
27	25	0.1	Methanol:Water 65:35Vol KNO3	lgK:2.68 (3SF)	5	MGL	3733
28	25	0.1	Methanol:Water 70:30Vol KNO3	lgK:2.77 (3SF)	5	MGL	3733
29	25	0.1	Methanol:Water 75:25Vol KNO3	lgK:2.87 (3SF)	5	MGL	3733
30	25	0.1	Methanol:Water 80:20Vol KNO3	lgK:3.00 (3SF)	5	MGL	3733

Reaction No. 35902							
Mn+2_Gly-1(2) + Gly-1 = Mn+2_Gly-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	DMF:Water 60:40Vol KNO3	lgK:2.4 (2SF)	3	MGL	3733
2	25	0.1	DMF:Water 70:30Vol KNO3	lgK:2.7 (2SF)	3	MGL	3733
3	25	0.1	DMF:Water 75:25Vol KNO3	lgK:2.9 (2SF)	0	MGL	3733
4	25	0.1	DMF:Water 80:20Vol KNO3	lgK:3.1 (2SF)	0	MGL	3733
5	25	0.1	MeCN:Water 60:40Vol KNO3	lgK:2.3 (2SF)	3	MGL	3733
6	25	0.1	MeCN:Water 70:30Vol KNO3	lgK:2.4 (2SF)	3	MGL	3733

7	25	0.1	MeCN:Water 75:25Vol KNO3	lgK:2.5 (2SF)	3	MGL	3733
8	25	0.1	MeCN:Water 80:20Vol KNO3	lgK:2.8 (2SF)	0	MGL	3733

Reaction No. 36052							
Tiron-4 + Mn+2 + Bipy = Mn+2_Bipy_Tiron-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:11.2 (0.09SD)	5	MGL	3858

Reaction No. 36068							
Mn+2_S-2_(green,s) + H+1 = Mn+2 + H+1_S-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.0 (2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:0.4 (1SF)	3	EOD	12584

Reaction No. 36111							
DMG-1 + Mn+2 = Mn+2_DMG-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Many Media	lgK:2.0 (2SF)	7	CMN	3837

Reaction No. 36113							
DEG-1 + Mn+2 = Mn+2_DEG-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Many Media	lgK:1.5 (2SF)	7	CMN	3837

Reaction No. 36128							
222Dpa + Mn+2 = Mn+2_222Dpa							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.60 (3SF)	5	MGL	6935
2	25	0.1	Unknown	lgK:5.90 (3SF)	6	ENS	1384
3	25	0.1	KNO3	dH:-4.5 (2SF)	5	MCL	6935

Reaction No. 36232							
EtDiAm + Mn+2 + Malonic-2 = Mn+2_EtDiAm_Malonic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:5.3 (0.2SD)	5	MGL	125

Reaction No. 36233							
EtDiAm + Mn+2 + 5ATP-4 = Mn+2_EtDiAm_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:6.6(0.2SD)	5	MGL	125

Reaction No. 36234							
Bipy + Mn+2 + Malonic-2 = Mn+2_Bipy_Malonic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:5.4(0.07SD)	5	MGL	125

Reaction No. 36235							
Bipy + Mn+2 + Cat-2 = Mn+2_Bipy_Cat-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:11.0(0.03SD)	5	MGL	125

Reaction No. 36236							
Bipy + Mn+2 + EtDiAm = Mn+2_Bipy_EtDiAm							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:4.3(2SF)	3	MGL	125

Reaction No. 36237							
Bipy + Mn+2 + 5ITP-4 = Mn+2_Bipy_5ITP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.4(3SF)	2	ENS	6845
2	25	0.1	NaClO4	lgK:7.4(0.03SD)	0	MGL	125

Reaction No. 36407							
H+1 + 5ATP-4 + Mn+2 = Mn+2_H+1_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:9.8(0.06SD)	5	MGL	1297
2	25	0.15	NaCl	lgK:9.2(0.07SD)	5	MGL	3750

Reaction No. 36408							
2<H+1> + 5ATP-4 + Mn+2 = Mn+2_H+1(2)_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:13.5(0.07SD)	2	MGL	1297
2	25	0.15	NaCl	lgK:12.7(0.1SD)	2	MGL	3750

Reaction No. 36409							
NTA-3 + Mn+2 + 5ATP-4 = Mn+2_NTA-3_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:9.1(0.07SD)	5	MGL	3750

Reaction No. 36410							
H+1 + NTA-3 + Mn+2 + 5ATP-4 = Mn+2_H+1_NTA-3_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaCl	lgK:15.6(0.1SD)	5	MGL	3750

Reaction No. 36797							
2<GlyGly-1> + Mn+2 = Mn+2_GlyGly-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.83(3SF)	5	MMR	3886
2	25	0	Inf. Dilution	lgK:2.0(2SF)	1	ESC	

Reaction No. 36799							
GlyAla-1 + Mn+2 = Mn+2_GlyAla-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:2.0(2SF)	4	CRV	7271
2	20	0.2	KCl	lgK:2.2(0.2SD)	5	MMR	3886

Reaction No. 36800							
2<GlyAla-1> + Mn+2 = Mn+2_GlyAla-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.79(3SF)	5	MMR	3886

Reaction No. 36801							
GlyLeu-1 + Mn+2 = Mn+2_GlyLeu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:2.(0.3SD)	5	MMR	3886

Reaction No. 36802							
2<GlyLeu-1> + Mn+2 = Mn+2_GlyLeu-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.94(3SF)	5	MMR	3886

Reaction No. 36807							
2<GlyPro-1> + Mn+2 = Mn+2_GlyPro-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:2.27(3SF)	0	MMR	3886
2	25	0	Inf. Dilution	lgK:4.9(2SF)	1	ELC	

Reaction No. 36808							
AlaGly-1 + Mn+2 = Mn+2_AlaGly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.9(0.1SD)	5	MMR	3886

Reaction No. 36809							
2<AlaGly-1> + Mn+2 = Mn+2_AlaGly-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.85(3SF)	5	MMR	3886

Reaction No. 36812							
AlaAla-1 + Mn+2 = Mn+2_AlaAla-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.9(0.1SD)	5	MMR	3886

Reaction No. 36813							
2<AlaAla-1> + Mn+2 = Mn+2_AlaAla-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.95(3SF)	5	MMR	3886


Reaction No. 36814							
AlaLeu-1 + Mn+2 = Mn+2_AlaLeu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.8(0.2SD)	5	MMR	3886

Reaction No. 36815							
2<AlaLeu-1> + Mn+2 = Mn+2_AlaLeu-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.89(3SF)	5	MMR	3886

Reaction No. 36819							
LeuGly-1 + Mn+2 = Mn+2_LeuGly-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:2.0(0.2SD)	5	MMR	3886

Reaction No. 36820




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.91(3SF)	5	MMR	3886

Reaction No. 36821




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.9(0.2SD)	5	MMR	3886

Reaction No. 36822




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.96(3SF)	5	MMR	3886

Reaction No. 36827




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:2.2(0.1SD)	5	MMR	3886

Reaction No. 36828




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:1.96(3SF)	5	MMR	3886

Reaction No. 36829



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:2.(0.2SD)	5	MMR	3886

Reaction No. 36830



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:2.34(3SF)	5	MMR	3886

Reaction No. 36835							
ProAla-1 + Mn+2 = Mn+2_ProAla-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:2. (0.3SD)	5	MMR	3886

Reaction No. 36836							
2<ProAla-1> + Mn+2 = Mn+2_ProAla-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:2.57 (3SF)	5	MMR	3886

Reaction No. 36837							
ProLeu-1 + Mn+2 = Mn+2_ProLeu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:2.5 (0.1SD)	5	MMR	3886

Reaction No. 36838							
2<ProLeu-1> + Mn+2 = Mn+2_ProLeu-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	KCl	lgK:2.40 (3SF)	5	MMR	3886

Reaction No. 37094							
Mn+2 + H+1_Etbis(ImMePhos)-4 = Mn+2_H+1_Etbis(ImMePhos)-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.63 (3SF)	3	MGL	931

Reaction No. 37157							
Mn+2 + H+1_3MeSal-2 = Mn+2_3MeSal-2 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.87 (3SF)	3	MGL	931

Reaction No. 37175							
1OHAAnthraquinone-1 + Mn+2 = Mn+2_1OHAAnthraquinone-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:9.03 (3SF)	5	MGL	140

Reaction No. 37176							
Mn+2_1OHAAnthraquinone-1 + 1OHAAnthraquinone-1 = Mn+2_1OHAAnthraquinone-1(2)							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:8.80 (3SF)	5	MGL	140

Reaction No. 37211							
DiBenzoylmethane-1 + Mn+2 = Mn+2_DiBenzoylmethane-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:9.32 (3SF)	5	MGL	140

Reaction No. 37212							
Mn+2_DiBenzoylmethane-1 + DiBenzoylmethane-1 = Mn+2_DiBenzoylmethane-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:8.47 (3SF)	5	MGL	140

Reaction No. 37229							
oOHDiBenzoylmethane-1 + Mn+2 = Mn+2_oOHDiBenzoylmethane-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:8.56 (3SF)	5	MGL	140

Reaction No. 37230							
Mn+2_oOHDiBenzoylmethane-1 + oOHDiBenzoylmethane-1 = Mn+2_oOHDiBenzoylmethane-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:7.77 (3SF)	5	MGL	140

Reaction No. 37300							
Mn+2 + H+1_Salicylaldehyde-2 = Mn+2_H+1_Salicylaldehyde-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Dioxan:Water 75:25Wgt NaClO4	lgK:5.8 (0.2SD)	4	MGL	931

Reaction No. 37301							
Mn+2_H+1_Salicylaldehyde-2 + H+1_Salicylaldehyde-2 = Mn+2_H+1(2)_Salicylaldehyde-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Dioxan:Water 75:25Wgt NaClO4	lgK:6.1 (0.2SD)	3	MGL	931

Reaction No. 37327							
6MePicol-1 + Mn+2 = Mn+2_6MePicol-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:3.35 (3SF)	5	MGL	140

Reaction No. 37328							
Mn+2_6MePicol-1 + 6MePicol-1 = Mn+2_6MePicol-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:2.4 (2SF)	5	MGL	140

Reaction No. 37385							
Benzoylacetone-1 + Mn+2 = Mn+2_Benzoylacetone-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:8.66 (3SF)	5	MGL	140

Reaction No. 37386							
Mn+2_Benzoylacetone-1 + Benzoylacetone-1 = Mn+2_Benzoylacetone-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:7.12 (3SF)	5	MGL	140

Reaction No. 37404							
OHBenzoylacetone-1 + Mn+2 = Mn+2_OHBenzoylacetone-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:7.66 (3SF)	5	MGL	140

Reaction No. 37405							
Mn+2_OHBenzoylacetone-1 + OHBenzoylacetone-1 = Mn+2_OHBenzoylacetone-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30		Dioxan:Water 75:25Wgt	lgK:6.61 (3SF)	5	MGL	140

Reaction No. 37479							
OPhosSerLys-3 + Mn+2 = Mn+2_OPhosSerLys-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:2.33 (3SF)	5	MGL	931

Reaction No. 37488							
12PhenDioxDiacet-2 + Mn+2 = Mn+2_12PhenDioxDiacet-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.8 (2SF)	5	MGL	931

Reaction No. 37562							
CNMeIDA-2 + Mn+2 = Mn+2_CNMeIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.50 (3SF)	6	MGL	3486

Reaction No. 37563							
Mn+2_CNMeIDA-2 + CNMeIDA-2 = Mn+2_CNMeIDA-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.00 (3SF)	6	MGL	3486

Reaction No. 37730							
CarbMeIDA-2 + Mn+2 = Mn+2_CarbMeIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.93 (3SF)	6	MGL	3486
2	25	0.1	KNO3	lgK:4.72 (0.01SD)	5	MGL	6631

Reaction No. 37731							
Mn+2_CarbMeIDA-2 + CarbMeIDA-2 = Mn+2_CarbMeIDA-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.30 (3SF)	6	MGL	3486
2	25	0.1	KNO3	lgK:2.21 (0.02SD)	5	MGL	6631

Reaction No. 37897							
Colchiceine-1 + Mn+2 = Mn+2_Colchiceine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	NaClO4	lgK:6.88 (3SF)	3	MGL	620
2	20	0.025	NaClO4	lgK:6.59 (3SF)	3	MGL	620
3	20	0.05	NaClO4	lgK:6.22 (3SF)	3	MGL	620
4	20	0.1	NaClO4	lgK:5.89 (3SF)	3	MGL	620

Reaction No. 37898							
2<Colchiceine-1> + Mn+2 = Mn+2_Colchiceine-1 (2)							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	NaClO4	lgK:12.92 (4SF)	0	MGL	620
Note (1): Low wgt for internal consistency							
2	20	0.025	NaClO4	lgK:11.62 (4SF)	0	MGL	620
3	20	0.05	NaClO4	lgK:11.05 (4SF)	0	MGL	620
4	20	0.1	NaClO4	lgK:11.60 (4SF)	4	MGL	620

Reaction No. 38324							
N33DiMeBuIDA-2 + Mn+2 = Mn+2_N33DiMeBuIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.55 (3SF)	6	MGL	3486

Reaction No. 38325							
Mn+2_N33DiMeBuIDA-2 + N33DiMeBuIDA-2 = Mn+2_N33DiMeBuIDA-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.45 (3SF)	6	MGL	3486

Reaction No. 38344							
NPhenIDA-2 + Mn+2 = Mn+2_NPhenIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.58 (3SF)	6	MGL	3486
2	25	0.1	KNO3	lgK:1.7 (0.2MD)	5	MGL	2551
3	25	0.1	KNO3	dH:5.8 (0.1MD)	5	MCL	2551


Reaction No. 38358							
N2MeoxEtIDA-2 + Mn+2 = Mn+2_N2MeoxEtIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.53 (3SF)	6	MGL	3486

Reaction No. 38359							
Mn+2_N2MeoxEtIDA-2 + N2MeoxEtIDA-2 = Mn+2_N2MeoxEtIDA-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.09 (3SF)	6	MGL	3486

Reaction No. 38396							
N2SHEtIDA-2 + Mn+2 = Mn+2_N2SHEtIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	20	0.1	KCl	lgK:9.32 (3SF)	6	MGL	3486
---	----	-----	-----	----------------	---	-----	------

Reaction No. 38397




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.69 (3SF)	6	MGL	3486

Reaction No. 38419




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:5.10 (3SF)	6	MGL	3486

Reaction No. 38420




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.60 (3SF)	6	MGL	3486

Reaction No. 38447




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:7.71 (3SF)	6	MGL	3486

Reaction No. 38448




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:3.70 (3SF)	6	MGL	3486

Reaction No. 38482



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:7.2 (0.03SD)	5	MGL	125

Reaction No. 38489



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.87 (3SF)	6	MGL	3486

Reaction No. 38509

N2EtOxFormAmEtIDA-2 + Mn+2 = Mn+2_N2EtOxFormAmEtIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:4.60 (3SF)	6	MGL	3486

Reaction No. 38510							
Mn+2_N2EtOxFormAmEtIDA-2 + N2EtOxFormAmEtIDA-2 = Mn+2_N2EtOxFormAmEtIDA-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:2.96 (3SF)	6	MGL	3486

Reaction No. 38651							
Mn+2_Acetic-1 + Acetic-1 = Mn+2_Acetic-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.85 (2SF)	5	MGL	11516
Note (1): Siddhanta S et al., J. Indian Chem. Soc., 1958, 35, 419							
2	25	0.1	Dioxan:Water 50:50Vol KCl	lgK:1.3 (2SF)	4	MPS	1511


Reaction No. 38720							
2<Mn+2> + OxAcet-2 = Mn+2 (2)_H+1 (-1)_OxAcet-2 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:-3.67 (3SF)	1	MSP	1511
2	25	0.5	KCl	lgK:-4.83 (3SF)	3	MKN	1503
3	25	0.5	KCl	lgK:-4.81 (3SF)	3	MPS	1503
4	25	0.1	Dioxan:Water 25:75Vol KCl	lgK:-2.50 (3SF)	4	MSP	1511
5	25	0.1	Dioxan:Water 50:50Vol KCl	lgK:-6.76 (3SF)	4	MSP	1511

Reaction No. 39070							
[21]N7 + Mn+2 = Mn+2_[21]N7							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaClO4	lgK:9.79 (0.01SD)	6	MPT	4259
2	25	0.15	NaClO4	dH:-5.0 (2SF)	5	MCL	4259

Reaction No. 39100							
Mn+2_5ADP-3 + 5ADP-3 = Mn+2_5ADP-3 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25			lgK:2.6(0.2SD)	4	MMR	4036
2	25			dH:-1.5(2SF)	4	MCL	4036

Reaction No. 39354




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Et4NC1O4	lgK:4.1(0.1SD)	5	MGL	2516
2	25	0.1	Methanol:Water 95:5Vol Et4NC1O4	lgK:5.2(0.05SD)	5	MGL	2516

Reaction No. 39521




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Dioxan:Water 75:25Vol	lgK:18.2(3SF)	5	MGL	2360

Reaction No. 39548




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.27(0.06SD)	5	MGL	2292

Reaction No. 39549




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:0.77(0.15SD)	5	MGL	2292

Reaction No. 39550



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-10.43(0.18SD)	5	MGL	2292

Reaction No. 39551



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-19.31(0.20SD)	5	MGL	2292

Reaction No. 39552							
2<DGalactCOOThiaproline-2> + 2<Mn+2> = 4<H+1> + Mn+2(2)_H+1(-4)_DGalactCOOThiaproline-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-30.19(0.22SD)	5	MGL	2292

Reaction No. 39630							
NNDiMeAmMePhos-2 + Mn+2 = Mn+2_NNDiMeAmMePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.22(3SF)	5	MGL	2131

Reaction No. 39631							
Mn+2_NNDiMeAmMePhos-2 + H+1 = Mn+2_H+1_NNDiMeAmMePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:8.98(3SF)	5	MGL	2131

Reaction No. 40195							
2Thenoic-1 + Mn+2 = Mn+2_2Thenoic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:1.65(3SF)	5	MGL	6068

Reaction No. 40304							
MeDiPhos-4 + Mn+2 = Mn+2_MeDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:12.95(4SF)	5	MGL	931

Reaction No. 40305							
2<MeDiPhos-4> + Mn+2 = Mn+2_MeDiPhos-4(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:18.77(4SF)	5	MGL	931

Reaction No. 40306							
Mn+2 + H+1_MeDiPhos-4 = Mn+2_H+1_MeDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:7.20(3SF)	5	MGL	931

Reaction No. 40307							
--------------------	--	--	--	--	--	--	--

Mn+2 + 2<H+1_MeDiPhos-4> = Mn+2_H+1(2)_MeDiPhos-4(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:13.26(4SF)	5	MGL	931

Reaction No. 40308							
2<Mn+2> + MeDiPhos-4 = Mn+2(2)_MeDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:15.85(4SF)	5	MGL	931

Reaction No. 40309							
2<Mn+2> + H+1_MeDiPhos-4 = Mn+2(2)_H+1_MeDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:9.60(3SF)	5	MGL	931

Reaction No. 40418							
2PhosGlyceric-3 + Mn+2 = Mn+2_2PhosGlyceric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1:0.4	Pr4NI	lgK:3.09(3SF)	5	MGL	931

Reaction No. 40472							
SelenDiAcet-2 + Mn+2 = Mn+2_SelenDiAcet-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.02(0.01SD)	5	MGL	2610
2	25	0.1	NaClO4	lgK:1.6(2SF)	5	MGL	931


Reaction No. 40511							
5NitrOrotic-2 + Mn+2 = Mn+2_5NitrOrotic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:1.79(3SF)	5	MGL	931
2	25	0.1	KClO4	lgK:1.74(3SF)	4	MIX	3464

Reaction No. 40521							
IOrotic-2 + Mn+2 = Mn+2_IOrotic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KClO4	lgK:2.16(3SF)	4	MIX	3464

Reaction No. 40547							
5BrOrotic-2 + Mn+2 = Mn+2_5BrOrotic-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NBr	lgK:1.88 (3SF)	5	MGL	931

Reaction No. 40557




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NBr	lgK:2.25 (3SF)	5	MGL	931

Reaction No. 40576




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:2.63 (3SF)	5	MGL	931

Reaction No. 40577




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:1.89 (3SF)	5	MGL	931

Reaction No. 40578



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	KCl	lgK:1.54 (3SF)	5	MGL	931

Reaction No. 40639




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Dioxan:Water 75:25Wgt NaClO4	lgK:4.8 (0.1SD)	5	MGL	931

Reaction No. 40640




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Dioxan:Water 75:25Wgt NaClO4	lgK:5.7 (0.1SD)	5	MGL	931

Reaction No. 40650



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.07 (3SF)	5	MGL	931

Reaction No. 40710




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:7.40 (0.01SD)	6	MGL	931

Reaction No. 40784




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.16	KNO3	lgK:2.8 (0.03SD)	4	MGL	931

Reaction No. 40862




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.9 (0.03SD)	6	MGL	931

Reaction No. 40863




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:4.35 (0.02SD)	6	MGL	931

Reaction No. 41006




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0	Inf. Dilution	lgK:5.41 (3SF)	3	MGL	931

Reaction No. 41102



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Methanol:Water 50:50Wgt NaClO4	lgK:5.6 (2SF)	4	MGL	931


Reaction No. 41103



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0.1	Methanol:Water 50:50Wgt NaClO4	lgK:7.0 (2SF)	4	MGL	931
---	----	-----	--------------------------------------	---------------	---	-----	-----

Reaction No. 41177




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	KNO3	lgK:2.9 (0.1SD)	5	MGL	2576

Reaction No. 41199




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.2 (2SF)	1	ELC	

Reaction No. 41244




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NCl	lgK:8.657 (0.004SD)	6	MGL	1007
2	25	0.1	Me4NNO3	lgK:8.657 (0.004SD)	6	MGL	1007
3	25	0.1	Me4NNO3	dH:-1.6 (2SF)	3	MCL	1007

Reaction No. 41329



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:0.613 (3SF)	5	MSL	3515
2	25	0.4	DMF Et4NBF4	lgK:1.2 (0.1MD)	5	MCL	538
3	25	0.4	DMF Et4NBF4	dH:-0.98 (2SF)	5	MCL	538

Reaction No. 41330



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:0.69 (2SF)	0	MSL	906
2	25			lgK:0.079 (2SF)	5	MSL	3515
3	25	0.4	DMF Et4NBF4	lgK:1.0 (0.3MD)	5	MCL	538
4	25	0.4	DMF Et4NBF4	dH:-1.94 (3SF)	4	MCL	538

Reaction No. 41331							
Thiourea + Mn+2 = Mn+2_Thiourea							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:1.477 (4SF)	5	MSL	3515

Reaction No. 41332							
2<Thiourea> + Mn+2 = Mn+2_Thiourea(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:3.58 (3SF)	0	MSL	906
2	25			lgK:2.104 (4SF)	5	MSL	3515

Reaction No. 41333							
3<Thiourea> + Mn+2 = Mn+2_Thiourea(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:5.20 (3SF)	0	MSL	906
2	25			lgK:1.633 (4SF)	5	MSL	3515

Reaction No. 41375							
H+1 + Tiron-4 + Mn+2 = Mn+2_H+1_Tiron-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:15.3 (0.05SD)	5	MGL	3858
2	25	1	NaClO4	lgK:13.88 (4SF)	5	MGL	4734

Reaction No. 41444							
Mn+2 + H+1_LDopa-3 = Mn+2_H+1_LDopa-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:4.36 (3SF)	6	CRV	2556

Reaction No. 41445							
Mn+2 + 2<H+1_LDopa-3> = Mn+2_H+1(2)_LDopa-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:10.20 (4SF)	6	CRV	2556

Reaction No. 41446							
Mn+2_H+1_LDopa-3(2) + H+1 = Mn+2_H+1(2)_LDopa-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:9.68 (3SF)	6	CRV	2556

Reaction No. 41447							
Mn+2_LDopa-3(2) + H+1 = Mn+2_H+1_LDopa-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:11.32 (4SF)	6	CRV	2556

Reaction No. 41692							
SolochromeVR-3 + Mn+2 = Mn+2_SolochromeVR-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.947 (5SF)	4	MDG	4409
2	25	0	Inf. Dilution	lgK:11.45 (4SF)	4	MPS	7000

Reaction No. 41695							
Calmagite-2 + Mn+2 = Mn+2_Calmagite-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.460 (5SF)	5	MDG	4409

Reaction No. 41716							
DiEtOlAm + Mn+2 = Mn+2_DiEtOlAm							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.43	HNO3	lgK:1.55 (3SF)	5	MGL	4431

Reaction No. 41717							
Mn+2_DiEtOlAm + DiEtOlAm = Mn+2_DiEtOlAm(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.43	HNO3	lgK:0.45 (2SF)	5	MGL	4431


Reaction No. 41723							
TriEtOlAm + Mn+2 = Mn+2_TriEtOlAm							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.43	HNO3	lgK:1.47 (3SF)	5	MGL	4431

Reaction No. 41724							
Mn+2_TriEtOlAm + TriEtOlAm = Mn+2_TriEtOlAm(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.43	HNO3	lgK:0.67 (2SF)	5	MGL	4431

Reaction No. 41815							
EDD3P-2 + Mn+2 = Mn+2_EDD3P-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KCl	lgK:3.4 (2SF)	3	MGL	140

Reaction No. 41829




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	29.6	0.1	Unknown	lgK:3.02 (3SF)	4	MGL	140

Reaction No. 41830




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	29.6	0.1	Unknown	lgK:2.44 (3SF)	4	MGL	140

Reaction No. 41978




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:3.82 (3SF)	5	MGL	4540

Reaction No. 42149




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Methanol:Water 50:50Vol NaClO4	lgK:1. (0.3SD)	5	MGL	2446

Reaction No. 42203




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Methanol Inf. Dilution	lgK:4.6 (2SF)	5	MGL	2601

Reaction No. 42204



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Methanol Inf. Dilution	lgK:7.6 (2SF)	5	MGL	2601

Reaction No. 42207



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Methanol Inf. Dilution	lgK:4.6(2SF)	5	MGL	2601
2	25	1	Methanol Tris buffer	lgK:4.40(3SF)	4	MPH	5674

Reaction No. 42208							
2<Lasalocid-1> + Mn+2 = Mn+2_Lasalocid-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Methanol Inf. Dilution	lgK:7.7(2SF)	5	MGL	2601

Reaction No. 42271							
Mn+3 + H+1(2)_EDTMP-8 = Mn+3_H+1(2)_EDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:11.20(4SF)	4	ENS	3761

Reaction No. 42272							
Mn+2 + H+1(2)_EDTMP-8 = Mn+2_H+1(2)_EDTMP-8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:7.00(3SF)	4	ENS	3761

Reaction No. 42425							
NACPen-2 + Mn+2 = Mn+2_NACPen-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:3.471(4SF)	5	MGL	3504


Reaction No. 42426							
2<NACPen-2> + Mn+2 = Mn+2_NACPen-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:6.350(4SF)	5	MGL	3504

Reaction No. 42454							
Tetracycline-2 + Mn+2 = Mn+2_Tetracycline-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:4.4(2SF)	5	MGL	3682

Reaction No. 42456							
2<Tetracycline-2> + Mn+2 = Mn+2_Tetracycline-2(2)							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:8. (1SF)	3	MGL	3682

Reaction No. 42503




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.3(0.1SD)	4	MES	3882
2	25	0.05	Me4NC1	lgK:5.3(0.06SD)	5	MES	3882

Reaction No. 42504




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.5(0.2SD)	4	MES	3882
2	25	0.05	Me4NC1	lgK:3.0(0.06SD)	5	MES	3882

Reaction No. 42505



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Me4NC1	lgK:3.1(0.04SD)	5	MES	3882

Reaction No. 42506




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Me4NC1	lgK:1.6(0.2SD)	5	MES	3882

Reaction No. 42538



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:1. (0.3SD)	5	ENS	3837

Reaction No. 42781



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Unknown	lgK:0.80(2SF)	5	MIX	11516
Note (1): Tsubota H et al., Bull. Chem. Soc. Jpn., 1962, 35, 640							
2	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:1.82(3SF)	5	MGL	6070

Reaction No. 42854							
3<Oxalic-2> + Mn+2 = Mn+2_Oxalic-2(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.25	KClO3	lgK:6.00 (3SF)	0	MPL	906
2	25			lgK:5.80 (3SF)	0	MSP	906

Reaction No. 42998							
ClAcet-1 + Mn+2 = Mn+2_ClAcet-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:1.66 (3SF)	5	MGL	6070

Reaction No. 43058							
Propanoic-1 + Mn+2 = Mn+2_Propanoic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:1.40 (0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:0.90 (0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:0.82 (0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:0.76 (0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:0.75 (0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:0.74 (0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:0.73 (0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:0.72 (0.01SD)	4	EDH	5390
9	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:1.92 (3SF)	5	MGL	6070

Reaction No. 43109							
3ClPropan-1 + Mn+2 = Mn+2_3ClPropan-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:1.88 (3SF)	6	MGL	6070

Reaction No. 43130							
2<bAla-1> + Mn+2 = Mn+2_bAla-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.5	NaNO3	lgK:6.13 (3SF)	4	MIX	906

2	25	0	Inf. Dilution	lgK:6.5 (2SF)	1	EAE	
---	----	---	---------------	---------------	---	-----	--

Reaction No. 43164							
DMPS-3 + Mn+2 = Mn+2_DMPS-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.1	KNO3	lgK:16.10 (4SF)	4	MPT	906

Reaction No. 43165							
Mn+2_DMPS-3 + DMPS-3 = Mn+2_DMPS-3 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.1	KNO3	lgK:5.00 (3SF)	4	MPT	906

Reaction No. 43185							
2Am2PrPhos-2 + Mn+2 = Mn+2_2Am2PrPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.03 (3SF)	5	MGL	906

Reaction No. 43186							
2<2Am2PrPhos-2> + Mn+2 = Mn+2_2Am2PrPhos-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:7.43 (3SF)	5	MGL	906

Reaction No. 43187							
Mn+2 + H+1_2Am2PrPhos-2 = Mn+2_H+1_2Am2PrPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.94 (3SF)	5	MGL	906

Reaction No. 43206							
8AzaAdenine + Mn+2 = Mn+2_8AzaAdenine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:4.0 (2SF)	5	MGL	906

Reaction No. 43416							
EtThioAcet-1 + Mn+2 = Mn+2_EtThioAcet-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:1.85 (3SF)	5	MGL	906

Reaction No. 43474							
Thiovioluric-3 + Mn+2 = Mn+2_Thiovioluric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:2.93 (3SF)	5	MGL	906

Reaction No. 43518							
Adenine-1 + Mn+2 = Mn+2_Adenine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:3.4 (0.03SD)	4	MGL	906

Reaction No. 43525							
26DiAmPurine-1 + Mn+2 = Mn+2_26DiAmPurine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:7.5 (2SF)	4	MGL	906

Reaction No. 43540							
Oxolane2COO-1 + Mn+2 = Mn+2_Oxolane2COO-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:2.36 (3SF)	6	MGL	6070

Reaction No. 43548							
5IMP-2 + Mn+2 = Mn+2_5IMP-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:2.31 (0.02MD)	6	MGL	4460

Reaction No. 43555							
5GMP-2 + Mn+2 = Mn+2_5GMP-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:2.39 (0.02MD)	6	MGL	4460

Reaction No. 43564							
Mn+2_5IMP-2 = Mn+2_H+1(-1)_5IMP-2 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:8.2 (0.09MD)	6	MGL	4460

Reaction No. 43574							
$\text{Mn+2_5GMP-2} = \text{Mn+2_H+1(-1)_5GMP-2} + \text{H+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:8.6(0.1MD)	6	MGL	4460

Reaction No. 43606							
$6\text{ClPurine} + \text{Mn+2} = \text{Mn+2_6ClPurine}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:6.6(0.2SD)	4	MGL	906

Reaction No. 43611							
$6\text{SHPurine-1} + \text{Mn+2} = \text{Mn+2_6SHPurine-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:7.(0.3SD)	4	MGL	906

Reaction No. 43739							
$\text{Mn+3} + \text{H+1(3)_Citric-3} = \text{Mn+3_H+1(2)_Citric-3} + \text{H+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.7	KNO3	lgK:-1.44(3SF)	4	MEP	906
2	25	0	Inf. Dilution	lgK:-0.838(3SF)	2	EAE	


Reaction No. 43740							
$\text{Mn+3_H+1(2)_Citric-3} = \text{Mn+3_Citric-3} + 2\langle\text{H+1}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.7	KNO3	lgK:-8.6(2SF)	2	MEP	906
2	25	0	Inf. Dilution	lgK:-9.3(2SF)	1	ELC	

Reaction No. 43741							
$\text{Citric-3} + \text{Mn+3} = \text{Mn+3_Citric-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18			lgK:3.6(2SF)	4	MPT	906
2	25	0	Inf. Dilution	lgK:4.032(4SF)	1	EOR	
3	25	0.1	Me4NC1	lgK:2.16(3SF)	4	MGL	906

Reaction No. 43742							
$2\langle\text{Citric-3}\rangle + \text{Mn+3} = \text{Mn+3_Citric-3(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:6.022 (4SF)	1	EOR	
2	25	0.1	Me4NC1	lgK:4.15 (3SF)	4	MGL	906

Reaction No. 43762



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NC1	lgK:3.06 (3SF)	4	MGL	906

Reaction No. 43822




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.6 (2SF) w	5	MPH	2404

Reaction No. 43823




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:3.1 (2SF) w	5	MPH	2404

Reaction No. 44084




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	1	NaClO4	lgK:6.8 (0.08SD)	4	MSP	906

Reaction No. 44129




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:3.2 (2SF)	4	MGL	906

Reaction No. 44130



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:3.5 (2SF)	4	MGL	906

Reaction No. 44173



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	NaClO4	lgK:2.06 (3SF)	5	MGL	11516

Note (1): Tummavuori J et al., Finn. Chem. Lett., 1979, 35

2	25	1	NaClO4	lgK:0.62 (2SF)	1	MGL	11516
Note (2): Basaran B et al., Thermochim. Acta, 1991, 186, 145							
3	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:1.90 (3SF)	5	MGL	6070

Reaction No. 44288							
3ClBenz-1 + Mn+2 = Mn+2_3ClBenz-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:1.81 (3SF)	5	MGL	6070

Reaction No. 44313							
2SHBenz-2 + Mn+2 = Mn+2_2SHBenz-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	17	0.05	Ethanol:Water 50:50Wgt NaClO4	lgK:5.07 (3SF)	5	MGL	906


Reaction No. 44391							
BenzHydroxam-1 + Mn+2 = Mn+2_BenzHydroxam-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0	Dioxan:Water 50:50Wgt Inf. Dilution	lgK:5.97 (3SF)	5	MGL	906
2	25		Dioxan:Water 70:30Wgt	lgK:4.90 (3SF)	4	MGL	906

Reaction No. 44392							
Mn+2_BenzHydroxam-1 + BenzHydroxam-1 = Mn+2_BenzHydroxam-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0	Dioxan:Water 50:50Wgt Inf. Dilution	lgK:4.52 (3SF)	5	MGL	906
2	25		Dioxan:Water 70:30Wgt	lgK:3.96 (3SF)	4	MGL	906

Reaction No. 44464							
2OHAcPhenone-1 + Mn+2 = Mn+2_2OHAcPhenone-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	30	0.1	Dioxan:Water 75:25Wgt NaClO4	lgK:7.42 (3SF)	4	MGL	906
---	----	-----	------------------------------------	----------------	---	-----	-----

Reaction No. 44467




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:1.88 (3SF)	5	MGL	6070

Reaction No. 44513




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Vol NaClO4	lgK:1.93 (0.02SD)	5	MGL	5991
2	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:2.01 (3SF)	5	MGL	6071

Reaction No. 44636




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	16	0.1	Unknown	lgK:5.2 (0.04SD)	5	MKN	906
2	16	0.1	Unknown	lgK:4.7 (0.03SD)	5	MSP	906
3	25	0.1	Unknown	lgK:5.71 (3SF)	4	MKN	906

Reaction No. 44637



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	16	0.03	Unknown	lgK:4.0 (0.04SD)	4	MKN	906
2	16	0.03	Unknown	lgK:4.0 (0.06SD)	4	MSP	906
3	25	0.3	Unknown	lgK:4.12 (3SF)	4	MKN	906

Reaction No. 44693



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.2	Dioxan:Water 75:25Vol NaClO4	lgK:5.9 (0.05SD)	5	MGL	906

Reaction No. 44694							
Mn+2_57DiCl8OHQuin-1 + 57DiCl8OHQuin-1 = Mn+2_57DiCl8OHQuin-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.2	Dioxan:Water 75:25Vol NaClO4	lgK:4.6(0.08SD)	5	MGL	906

Reaction No. 44849							
Co+3_Cl-1_EDTA-4 + Mn+2 = Co+3_Mn+2_Cl-1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:0.8(0.09SD)	5	MKN	516

Reaction No. 44850							
Mn+3 + H+1_EDTA-4 = Mn+3_H+1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18:20			lgK:8.89(3SF)	3	MSP	906
2	25	0	Inf. Dilution	lgK:8.8(2SF)	1	ESC	

Reaction No. 45058							
2<PAR-2> + Mn+2 = Mn+2_PAR-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.1	Unknown	lgK:15.6(3SF)	4	MSP	906

Reaction No. 45133							
EEDTA-4 + Mn+3 = Mn+3_EEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18:20			lgK:17.18(4SF)	4	MSP	906

Reaction No. 45134							
Mn+3 + H+1_EEDTA-4 = Mn+3_H+1_EEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18:20			lgK:10.04(4SF)	4	MSP	906

Reaction No. 45187							
Dithizone-1 + Mn+2 = Mn+2_Dithizone-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	24:26	0.1	NaClO4	lgK:4.9(0.09SD)	5	MSP	906

Reaction No. 45188							
--------------------	--	--	--	--	--	--	--

2<Dithizone-1> + Mn+2 = Mn+2_Dithizone-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	24:26	0.1	NaClO4	lgK:9.6(0.07SD)	5	MSP	906

Reaction No. 45266							
Mn+3 + H+1(2)_DTPA-5 = Mn+3_H+1(2)_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18:22			lgK:5.36(3SF)	0	MSP	906
2	25	0	Inf. Dilution	lgK:5.4(2SF)	1	ESC	

Reaction No. 45267							
Mn+2 + H+1(3)_DTPA-5 = Mn+2_H+1(3)_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18:22			lgK:3.70(3SF)	0	MSP	906
2	25	0	Inf. Dilution	lgK:3.7(2SF)	1	ESC	

Reaction No. 45461							
1Phenazo2naphthol-1 + Mn+2 = Mn+2_1Phenazo2naphthol-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Acetone:Water 75:25Wgt KNO3	lgK:7.3(0.04SD)	4	MGL	906

Reaction No. 45485							
Mn+2 + H+1_12OHPhenazo2naphthol-2 = Mn+2_H+1_12OHPhenazo2naphthol-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Acetone:Water 75:25Wgt KNO3	lgK:7.2(0.04SD)	4	MGL	906

Reaction No. 45512							
EDD3Me2BuDA-4 + Mn+2 = Mn+2_EDD3Me2BuDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:9.7(0.03SD)	5	MGL	2008

Reaction No. 45540							
EDDPentDA-4 + Mn+2 = Mn+2_EDDPentDA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:13.2(0.07SD)	5	MPL	2008

Reaction No. 45810							
5CDP-3 + Mn+2 = Mn+2_5CDP-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.82 (3SF)	4	MGL	1437

Reaction No. 45829							
1GlucoseOP03-2 + Mn+2 = Mn+2_1GlucoseOP03-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KClO4	lgK:2.19 (3SF)	5	MIX	3464

Reaction No. 45906							
Trp-1 + Mn+2 + 5ATP-4 = Mn+2_Trp-1_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:6.3 (0.07SD)	5	MGL	4540

Reaction No. 45908							
Mn+2_Ala-1 + 5ATP-4 = Mn+2_Ala-1_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:3.47 (3SF)	5	MGL	4540

Reaction No. 45984							
Mn+2 + H+1(2)_Citric-3 = Mn+2_H+1(2)_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.98 (3SF)	2	EAE	
2	37	0.15	Unknown	lgK:1.5 (2SF)	4	CRV	2556

Reaction No. 46259							
AmMePhos-2 + Mn+2 = Mn+2_AmMePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:3.90 (3SF)	5	MGL	6795
2	25	0.1	NaNO3	lgK:3.6 (0.08MD)w	5	MPH	4478
3	25	0.1	Unknown	lgK:3.6 (0.1SD)	6	CIU	7242

Reaction No. 46260							
Mn+2 + H+1_AmMePhos-2 = Mn+2_H+1_AmMePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:1.77 (0.04MD)w	5	MPH	4478

Reaction No. 46279							
PhosForm-3 + Mn+2 = Mn+2_PhosForm-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Me4NC1	lgK:5.3(0.05SD)	5	MES	3882
2	25	0.1	NaNO3	lgK:5.1(0.1MD)w	5	MPH	4478

Reaction No. 46280							
Mn+2 + H+1_PhosForm-3 = Mn+2_H+1_PhosForm-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Me4NC1	lgK:2.6(0.05SD)	5	MES	3882
2	25	0.1	NaNO3	lgK:2.4(0.2MD)w	5	MPH	4478

Reaction No. 46392							
Mn+2_His-1 + H+1_Xanthosine-1 = Mn+2_His-1_Xanthosine-1 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.0(2SF)	1	ESC	
2	35	0.1	KNO3	lgK:2.9(2SF)	4	MGL	3565

Reaction No. 46402							
Mn+2 + Xanthosine-1 + H+1_Cat-2 = Mn+2_H+1_Xanthosine-1_Cat-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:8.94(3SF)	4	MGL	3565


Reaction No. 46409							
Mn+2_Oxalic-2 + H+1_Xanthosine-1 = Mn+2_Xanthosine-1_Oxalic-2 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.0(2SF)	1	ESC	
2	35	0.1	KNO3	lgK:8.70(3SF)	4	MGL	3565

Reaction No. 46419							
Aconitic:trans-3 + Mn+2 = Mn+2_Aconitic:trans-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	Unknown	lgK:2.27(3SF)	4	MIX	419

Reaction No. 50504							
Mn+2 + Ala-1 + bAla-1 = Mn+2_Ala-1_bAla-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:4.6(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:4.44(0.01SD)	3	ETS	94

Reaction No. 50505




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.11(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.39(0.01SD)	3	ETS	94

Reaction No. 50506




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.4(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:4.25(0.01SD)	3	ETS	94

Reaction No. 50507




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.16(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.44(0.01SD)	3	ETS	94

Reaction No. 50508




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.4(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:4.30(0.01SD)	3	ETS	94

Reaction No. 50509



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.97(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.25(0.01SD)	3	ETS	94


Reaction No. 50510



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.0(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:5.04 (0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 50511




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.0 (2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:4.90 (0.01SD)	3	ETS	94

Reaction No. 50512




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.81 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.85 (0.01SD)	3	ETS	94

Reaction No. 50513




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.86 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.90 (0.01SD)	3	ETS	94

Reaction No. 50514




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.46 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.74 (0.01SD)	3	ETS	94

Reaction No. 50515



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.7 (2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:3.60 (0.01SD)	3	ETS	94

Reaction No. 50516



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.27 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.55 (0.01SD)	3	ETS	94

Reaction No. 50517							
Mn+2 + Asn-1 + Citrul-1 = Mn+2_Asn-1_Citrul-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.32(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.60(0.01SD)	3	ETS	94

Reaction No. 50518							
Mn+2 + Asp-2 + Citrul-1 = Mn+2_Citrul-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.16(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.20(0.01SD)	3	ETS	94

Reaction No. 50519							
Mn+2 + Ala-1 + Cys-2 = Mn+2_Ala-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.95(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.99(0.01SD)	3	ETS	94

Reaction No. 50520							
Mn+2 + bAla-1 + Cys-2 = Mn+2_bAla-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.0(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:5.85(0.01SD)	3	ETS	94

Reaction No. 50521							
Mn+2 + Arg-1 + Cys-2 = Mn+2_Arg-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.76(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.80(0.01SD)	3	ETS	94

Reaction No. 50522							
Mn+2 + Asn-1 + Cys-2 = Mn+2_Asn-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.81(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.85(0.01SD)	3	ETS	94

Reaction No. 50523							
--------------------	--	--	--	--	--	--	--

Mn+2 + Asp-2 + Cys-2 = Mn+2_Asp-2_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.41(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.45(0.01SD)	3	ETS	94

Reaction No. 50524							
Mn+2 + Citrul-1 + Cys-2 = Mn+2_Citrul-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.11(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.15(0.01SD)	3	ETS	94

Reaction No. 50525							
Mn+2 + Ala-1 + Glu-2 = Mn+2_Ala-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.85(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.89(0.01SD)	3	ETS	94

Reaction No. 50526							
Mn+2 + bAla-1 + Glu-2 = Mn+2_bAla-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.9(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:4.75(0.01SD)	3	ETS	94


Reaction No. 50527							
Mn+2 + Arg-1 + Glu-2 = Mn+2_Arg-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.66(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.70(0.01SD)	3	ETS	94

Reaction No. 50528							
Mn+2 + Asn-1 + Glu-2 = Mn+2_Asn-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.71(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.75(0.01SD)	3	ETS	94

Reaction No. 50529							
Mn+2 + Asp-2 + Glu-2 = Mn+2_Asp-2_Glu-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.35(0.01SD)	3	ETS	94

Reaction No. 50530




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.01(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.05(0.01SD)	3	ETS	94

Reaction No. 50531




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.26(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.30(0.01SD)	3	ETS	94

Reaction No. 50532




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.16(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.44(0.01SD)	3	ETS	94

Reaction No. 50533




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.4(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:4.30(0.01SD)	3	ETS	94

Reaction No. 50534



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.97(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.25(0.01SD)	3	ETS	94


Reaction No. 50535



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:5.02(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.30(0.01SD)	3	ETS	94

Reaction No. 50536




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.86(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.90(0.01SD)	3	ETS	94

Reaction No. 50537




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.32(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.60(0.01SD)	3	ETS	94

Reaction No. 50538




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.81(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.85(0.01SD)	3	ETS	94

Reaction No. 50539




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.71(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.75(0.01SD)	3	ETS	94

Reaction No. 50540



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.54(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.82(0.01SD)	3	ETS	94


Reaction No. 50541



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.8(2SF)	1	EAE	


2	37	0.15	Blood Plasma	lgK:4.68 (0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 50542




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.35 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.63 (0.01SD)	3	ETS	94

Reaction No. 50543




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.4 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:5.4 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:4.68 (0.01SD)	3	ETS	94

Reaction No. 50544




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.24 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:6.24 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:5.28 (0.01SD)	3	ETS	94

Reaction No. 50545



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.7 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:4.7 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.98 (0.01SD)	3	ETS	94

Reaction No. 50546



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.19 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:7.19 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:6.23 (0.01SD)	3	ETS	94

Reaction No. 50547

Gly-1 + Glu-2 + Mn+2 = Mn+2_Gly-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.09(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:6.09(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:5.13(0.01SD)	3	ETS	94

Reaction No. 50548							
Gly-1 + Gln-1 + Mn+2 = Mn+2_Gln-1_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.4(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:5.4(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:4.68(0.01SD)	3	ETS	94

Reaction No. 50549							
Mn+2 + Ala-1 + His-1 = Mn+2_Ala-1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.24(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.52(0.01SD)	3	ETS	94

Reaction No. 50550							
Mn+2 + bAla-1 + His-1 = Mn+2_bAla-1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.5(2SF)	1	EAE	
2	25	0	Inf. Dilution	lgK:5.6(2SF)	1	ESC	
3	37	0.15	Blood Plasma	lgK:5.38(0.01SD)	3	ETS	94

Reaction No. 50551							
Mn+2 + Arg-1 + His-1 = Mn+2_Arg-1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.05(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.33(0.01SD)	3	ETS	94

Reaction No. 50552							
Mn+2 + Asn-1 + His-1 = Mn+2_Asn-1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.38(0.01SD)	3	ETS	94

Reaction No. 50553							
Mn+2 + Asp-2 + His-1 = Mn+2_His-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.94(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.98(0.01SD)	3	ETS	94

Reaction No. 50554							
Mn+2 + Citrul-1 + His-1 = Mn+2_Citrul-1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.68(0.01SD)	3	ETS	94

Reaction No. 50555							
Mn+2 + Cys-2 + His-1 = Mn+2_His-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.89(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.93(0.01SD)	3	ETS	94

Reaction No. 50556							
Mn+2 + Glu-2 + His-1 = Mn+2_His-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.79(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.83(0.01SD)	3	ETS	94

Reaction No. 50557							
Mn+2 + Gln-1 + His-1 = Mn+2_Gln-1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.38(0.01SD)	3	ETS	94

Reaction No. 50558							
Mn+2 + Gly-1 + His-1 = Mn+2_Gly-1_His-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.48(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.76(0.01SD)	3	ETS	94

Reaction No. 50559							
--------------------	--	--	--	--	--	--	--

Mn+2 + Ala-1 + Histamine = Mn+2_Histamine_Ala-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.62 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.14 (0.01SD)	3	ETS	94

Reaction No. 50560							
Mn+2 + bAla-1 + Histamine = Mn+2_Histamine_bAla-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.1 (2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:4.00 (0.01SD)	3	ETS	94

Reaction No. 50561							
Mn+2 + Arg-1 + Histamine = Mn+2_Histamine_Arg-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.43 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.95 (0.01SD)	3	ETS	94

Reaction No. 50562							
Mn+2 + Asn-1 + Histamine = Mn+2_Histamine_Asn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.48 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.00 (0.01SD)	3	ETS	94


Reaction No. 50563							
Mn+2 + Asp-2 + Histamine = Mn+2_Histamine_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.56 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.60 (0.01SD)	3	ETS	94

Reaction No. 50564							
Mn+2 + Citrul-1 + Histamine = Mn+2_Histamine_Citrul-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.78 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.30 (0.01SD)	3	ETS	94

Reaction No. 50565							
Mn+2 + Cys-2 + Histamine = Mn+2_Histamine_Cys-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.51(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.55(0.01SD)	3	ETS	94

Reaction No. 50566




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.41(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.45(0.01SD)	3	ETS	94

Reaction No. 50567




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.48(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.00(0.01SD)	3	ETS	94

Reaction No. 50568




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.86(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.38(0.01SD)	3	ETS	94

Reaction No. 50569




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.56(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.08(0.01SD)	3	ETS	94

Reaction No. 50570



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.61(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.89(0.01SD)	3	ETS	94


Reaction No. 50571



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:4.9(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:4.75(0.01SD)	3	ETS	94

Reaction No. 50572




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.42(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.70(0.01SD)	3	ETS	94

Reaction No. 50573




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.47(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.75(0.01SD)	3	ETS	94

Reaction No. 50574




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.35(0.01SD)	3	ETS	94

Reaction No. 50575




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.77(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.05(0.01SD)	3	ETS	94

Reaction No. 50576



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.26(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.30(0.01SD)	3	ETS	94


Reaction No. 50577



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.16(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:5.20(0.01SD)	3	ETS	94
---	----	------	--------------	------------------	---	-----	----

Reaction No. 50578




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.47(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.75(0.01SD)	3	ETS	94

Reaction No. 50579




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.85(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.13(0.01SD)	3	ETS	94

Reaction No. 50580




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.55(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.83(0.01SD)	3	ETS	94

Reaction No. 50581




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.93(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.45(0.01SD)	3	ETS	94

Reaction No. 50582



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.51(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.79(0.01SD)	3	ETS	94

Reaction No. 50583



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.8(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:4.65(0.01SD)	3	ETS	94

Reaction No. 50584							
Mn+2 + Arg-1 + Ile-1 = Mn+2_Arg-1_Ile-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.32(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.60(0.01SD)	3	ETS	94

Reaction No. 50585							
Mn+2 + Asn-1 + Ile-1 = Mn+2_Asn-1_Ile-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.37(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.65(0.01SD)	3	ETS	94

Reaction No. 50586							
Mn+2 + Asp-2 + Ile-1 = Mn+2_Ile-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.21(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.25(0.01SD)	3	ETS	94

Reaction No. 50587							
Mn+2 + Citrul-1 + Ile-1 = Mn+2_Citrul-1_Ile-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.67(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.95(0.01SD)	3	ETS	94

Reaction No. 50588							
Mn+2 + Cys-2 + Ile-1 = Mn+2_Ile-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.16(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.20(0.01SD)	3	ETS	94

Reaction No. 50589							
Mn+2 + Glu-2 + Ile-1 = Mn+2_Ile-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.06(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.10(0.01SD)	3	ETS	94

Reaction No. 50590							
--------------------	--	--	--	--	--	--	--

Mn+2 + Gln-1 + Ile-1 = Mn+2_Gln-1_Ile-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.37(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.65(0.01SD)	3	ETS	94

Reaction No. 50591							
Mn+2 + Gly-1 + Ile-1 = Mn+2_Gly-1_Ile-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.75(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.03(0.01SD)	3	ETS	94

Reaction No. 50592							
Mn+2 + His-1 + Ile-1 = Mn+2_His-1_Ile-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.45(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.73(0.01SD)	3	ETS	94

Reaction No. 50593							
Mn+2 + Histamine + Ile-1 = Mn+2_Histamine_Ile-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.83(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.35(0.01SD)	3	ETS	94


Reaction No. 50594							
Mn+2 + Hyp-1 + Ile-1 = Mn+2_Hyp-1_Ile-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.82(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.10(0.01SD)	3	ETS	94

Reaction No. 50595							
Mn+2 + Ala-1 + Leu-1 = Mn+2_Ala-1_Leu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.26(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.54(0.01SD)	3	ETS	94

Reaction No. 50596							
Mn+2 + bAla-1 + Leu-1 = Mn+2_bAla-1_Leu-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.5 (2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:4.40 (0.01SD)	3	ETS	94

Reaction No. 50597




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.07 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.35 (0.01SD)	3	ETS	94

Reaction No. 50598




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.12 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.40 (0.01SD)	3	ETS	94

Reaction No. 50599




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.96 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.00 (0.01SD)	3	ETS	94

Reaction No. 50600




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.42 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.70 (0.01SD)	3	ETS	94

Reaction No. 50601



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.91 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.95 (0.01SD)	3	ETS	94


Reaction No. 50602



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:5.81(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.85(0.01SD)	3	ETS	94

Reaction No. 50603




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.12(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.40(0.01SD)	3	ETS	94

Reaction No. 50604




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.78(0.01SD)	3	ETS	94

Reaction No. 50605




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.48(0.01SD)	3	ETS	94

Reaction No. 50606




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.58(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.10(0.01SD)	3	ETS	94

Reaction No. 50607



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.57(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.85(0.01SD)	3	ETS	94


Reaction No. 50608



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.47(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:4.75 (0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 50609




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.29 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.57 (0.01SD)	3	ETS	94

Reaction No. 50610




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.5 (2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:4.42 (0.01SD)	3	ETS	94

Reaction No. 50611




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.09 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.37 (0.01SD)	3	ETS	94

Reaction No. 50612




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.14 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.42 (0.01SD)	3	ETS	94

Reaction No. 50613



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.99 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.03 (0.01SD)	3	ETS	94

Reaction No. 50614



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.45 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.73 (0.01SD)	3	ETS	94

Reaction No. 50615							
Mn+2 + Cys-2 + Met-1 = Mn+2_Met-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.94 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.98 (0.01SD)	3	ETS	94

Reaction No. 50616							
Mn+2 + Glu-2 + Met-1 = Mn+2_Met-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.83 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.87 (0.01SD)	3	ETS	94

Reaction No. 50617							
Mn+2 + Gln-1 + Met-1 = Mn+2_Gln-1_Met-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.14 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.42 (0.01SD)	3	ETS	94

Reaction No. 50618							
Mn+2 + Gly-1 + Met-1 = Mn+2_Gly-1_Met-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.52 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.80 (0.01SD)	3	ETS	94

Reaction No. 50619							
Mn+2 + His-1 + Met-1 = Mn+2_His-1_Met-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.22 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.50 (0.01SD)	3	ETS	94

Reaction No. 50620							
Mn+2 + Histamine + Met-1 = Mn+2_Histamine_Met-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.12 (0.01SD)	3	ETS	94

Reaction No. 50621							
--------------------	--	--	--	--	--	--	--

Mn+2 + Hyp-1 + Met-1 = Mn+2_Hyp-1_Met-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.59(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.87(0.01SD)	3	ETS	94

Reaction No. 50622							
Mn+2 + Ile-1 + Met-1 = Mn+2_Ile-1_Met-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.49(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.77(0.01SD)	3	ETS	94

Reaction No. 50623							
Mn+2 + Leu-1 + Met-1 = Mn+2_Leu-1_Met-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.25(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.53(0.01SD)	3	ETS	94

Reaction No. 50624							
Mn+2 + Ala-1 + Phe-1 = Mn+2_Ala-1_Phe-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.59(0.01SD)	3	ETS	94


Reaction No. 50625							
Mn+2 + bAla-1 + Phe-1 = Mn+2_bAla-1_Phe-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.6(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:4.45(0.01SD)	3	ETS	94

Reaction No. 50626							
Mn+2 + Arg-1 + Phe-1 = Mn+2_Arg-1_Phe-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.12(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.40(0.01SD)	3	ETS	94

Reaction No. 50627							
Mn+2 + Asn-1 + Phe-1 = Mn+2_Asn-1_Phe-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.17(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.45(0.01SD)	3	ETS	94

Reaction No. 50628




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.01(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.05(0.01SD)	3	ETS	94

Reaction No. 50629




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.47(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.75(0.01SD)	3	ETS	94

Reaction No. 50630




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.96(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.00(0.01SD)	3	ETS	94

Reaction No. 50631




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.86(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.90(0.01SD)	3	ETS	94

Reaction No. 50632



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.17(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.45(0.01SD)	3	ETS	94


Reaction No. 50633



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:5.55(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.83(0.01SD)	3	ETS	94

Reaction No. 50634




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.25(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.53(0.01SD)	3	ETS	94

Reaction No. 50635




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.63(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.15(0.01SD)	3	ETS	94

Reaction No. 50636




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.62(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.90(0.01SD)	3	ETS	94

Reaction No. 50637




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.52(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.80(0.01SD)	3	ETS	94

Reaction No. 50638



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.27(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.55(0.01SD)	3	ETS	94


Reaction No. 50639



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.29(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:4.57(0.01SD)	3	ETS	94
---	----	------	--------------	------------------	---	-----	----

Reaction No. 50640




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.93(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.21(0.01SD)	3	ETS	94

Reaction No. 50641




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.2(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:5.07(0.01SD)	3	ETS	94

Reaction No. 50642




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.74(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.02(0.01SD)	3	ETS	94

Reaction No. 50643




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.79(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.07(0.01SD)	3	ETS	94

Reaction No. 50644



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.62(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.66(0.01SD)	3	ETS	94

Reaction No. 50645



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.09(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.37(0.01SD)	3	ETS	94

Reaction No. 50646							
Mn+2 + Cys-2 + Pro-1 = Mn+2_Pro-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.58(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.62(0.01SD)	3	ETS	94

Reaction No. 50647							
Mn+2 + Glu-2 + Pro-1 = Mn+2_Pro-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.48(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.52(0.01SD)	3	ETS	94

Reaction No. 50648							
Mn+2 + Gln-1 + Pro-1 = Mn+2_Gln-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.79(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.07(0.01SD)	3	ETS	94

Reaction No. 50649							
Mn+2 + Gly-1 + Pro-1 = Mn+2_Gly-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.17(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.45(0.01SD)	3	ETS	94

Reaction No. 50650							
Mn+2 + His-1 + Pro-1 = Mn+2_His-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.87(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.15(0.01SD)	3	ETS	94

Reaction No. 50651							
Mn+2 + Histamine + Pro-1 = Mn+2_Histamine_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.24(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.76(0.01SD)	3	ETS	94

Reaction No. 50652							
--------------------	--	--	--	--	--	--	--

Mn+2 + Hyp-1 + Pro-1 = Mn+2_Hyp-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.24(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.52(0.01SD)	3	ETS	94

Reaction No. 50653							
Mn+2 + Ile-1 + Pro-1 = Mn+2_Ile-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.14(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.42(0.01SD)	3	ETS	94

Reaction No. 50654							
Mn+2 + Leu-1 + Pro-1 = Mn+2_Leu-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.89(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.17(0.01SD)	3	ETS	94

Reaction No. 50655							
Mn+2 + Met-1 + Pro-1 = Mn+2_Met-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.91(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.19(0.01SD)	3	ETS	94


Reaction No. 50656							
Mn+2 + Phe-1 + Pro-1 = Mn+2_Phe-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.94(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.22(0.01SD)	3	ETS	94

Reaction No. 50657							
Mn+2 + Ala-1 + Ser-1 = Mn+2_Ala-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.16(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.44(0.01SD)	3	ETS	94

Reaction No. 50658							
Mn+2 + bAla-1 + Ser-1 = Mn+2_bAla-1_Ser-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.4 (2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:4.30 (0.01SD)	3	ETS	94

Reaction No. 50659




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.97 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.25 (0.01SD)	3	ETS	94

Reaction No. 50660




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.02 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.30 (0.01SD)	3	ETS	94

Reaction No. 50661




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.86 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.90 (0.01SD)	3	ETS	94

Reaction No. 50662




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.32 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.60 (0.01SD)	3	ETS	94

Reaction No. 50663



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.81 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.85 (0.01SD)	3	ETS	94


Reaction No. 50664



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:5.71(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.75(0.01SD)	3	ETS	94

Reaction No. 50665




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.02(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.30(0.01SD)	3	ETS	94

Reaction No. 50666




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.68(0.01SD)	3	ETS	94

Reaction No. 50667




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.38(0.01SD)	3	ETS	94

Reaction No. 50668




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.48(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.00(0.01SD)	3	ETS	94

Reaction No. 50669



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.47(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.75(0.01SD)	3	ETS	94


Reaction No. 50670



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.37(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:4.65 (0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 50671




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.12 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.40 (0.01SD)	3	ETS	94

Reaction No. 50672




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.14 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.42 (0.01SD)	3	ETS	94

Reaction No. 50673




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.17 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.45 (0.01SD)	3	ETS	94

Reaction No. 50674




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.79 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.07 (0.01SD)	3	ETS	94

Reaction No. 50675



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.11 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.39 (0.01SD)	3	ETS	94

Reaction No. 50676



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.4 (2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:4.25 (0.01SD)	3	ETS	94

Reaction No. 50677							
Mn+2 + Arg-1 + Thr-1 = Mn+2_Arg-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.92(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.20(0.01SD)	3	ETS	94

Reaction No. 50678							
Mn+2 + Asn-1 + Thr-1 = Mn+2_Asn-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.97(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.25(0.01SD)	3	ETS	94

Reaction No. 50679							
Mn+2 + Asp-2 + Thr-1 = Mn+2_Thr-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.81(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.85(0.01SD)	3	ETS	94

Reaction No. 50680							
Mn+2 + Citrul-1 + Thr-1 = Mn+2_Citrul-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.27(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.55(0.01SD)	3	ETS	94

Reaction No. 50681							
Mn+2 + Cys-2 + Thr-1 = Mn+2_Thr-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.76(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.80(0.01SD)	3	ETS	94

Reaction No. 50682							
Mn+2 + Glu-2 + Thr-1 = Mn+2_Thr-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.66(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.70(0.01SD)	3	ETS	94

Reaction No. 50683							
--------------------	--	--	--	--	--	--	--

Mn+2 + Gln-1 + Thr-1 = Mn+2_Gln-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.97(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.25(0.01SD)	3	ETS	94

Reaction No. 50684							
Mn+2 + Gly-1 + Thr-1 = Mn+2_Gly-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.35(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.63(0.01SD)	3	ETS	94

Reaction No. 50685							
Mn+2 + His-1 + Thr-1 = Mn+2_His-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.05(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.33(0.01SD)	3	ETS	94

Reaction No. 50686							
Mn+2 + Histamine + Thr-1 = Mn+2_Histamine_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.43(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.95(0.01SD)	3	ETS	94


Reaction No. 50687							
Mn+2 + Hyp-1 + Thr-1 = Mn+2_Hyp-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.42(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.70(0.01SD)	3	ETS	94

Reaction No. 50688							
Mn+2 + Ile-1 + Thr-1 = Mn+2_Ile-1_Thr-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.32(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.60(0.01SD)	3	ETS	94

Reaction No. 50689							
Mn+2 + Leu-1 + Thr-1 = Mn+2_Leu-1_Thr-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.07(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.35(0.01SD)	3	ETS	94

Reaction No. 50690




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.09(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.37(0.01SD)	3	ETS	94

Reaction No. 50691




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.12(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.40(0.01SD)	3	ETS	94

Reaction No. 50692




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.74(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.02(0.01SD)	3	ETS	94

Reaction No. 50693




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.97(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.25(0.01SD)	3	ETS	94

Reaction No. 50694



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.59(0.01SD)	3	ETS	94


Reaction No. 50695



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:4.6(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:4.45(0.01SD)	3	ETS	94

Reaction No. 50696




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.12(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.40(0.01SD)	3	ETS	94

Reaction No. 50697




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.17(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.45(0.01SD)	3	ETS	94

Reaction No. 50698




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.01(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.05(0.01SD)	3	ETS	94

Reaction No. 50699




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.47(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.75(0.01SD)	3	ETS	94

Reaction No. 50700



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.96(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.00(0.01SD)	3	ETS	94


Reaction No. 50701



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.86(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:4.90 (0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 50702




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.17 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.45 (0.01SD)	3	ETS	94

Reaction No. 50703




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.55 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.83 (0.01SD)	3	ETS	94

Reaction No. 50704




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.25 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.53 (0.01SD)	3	ETS	94

Reaction No. 50705




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.63 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.15 (0.01SD)	3	ETS	94

Reaction No. 50706



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.62 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.90 (0.01SD)	3	ETS	94

Reaction No. 50707



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.52 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.80 (0.01SD)	3	ETS	94

Reaction No. 50708							
Mn+2 + Leu-1 + Trp-1 = Mn+2_Leu-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.27(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.55(0.01SD)	3	ETS	94

Reaction No. 50709							
Mn+2 + Met-1 + Trp-1 = Mn+2_Met-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.29(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.57(0.01SD)	3	ETS	94

Reaction No. 50710							
Mn+2 + Phe-1 + Trp-1 = Mn+2_Phe-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.32(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.60(0.01SD)	3	ETS	94

Reaction No. 50711							
Mn+2 + Pro-1 + Trp-1 = Mn+2_Pro-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.94(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.22(0.01SD)	3	ETS	94

Reaction No. 50712							
Mn+2 + Ser-1 + Trp-1 = Mn+2_Ser-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.17(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.45(0.01SD)	3	ETS	94

Reaction No. 50713							
Mn+2 + Thr-1 + Trp-1 = Mn+2_Thr-1_Trp-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.12(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.40(0.01SD)	3	ETS	94

Reaction No. 50714							
--------------------	--	--	--	--	--	--	--

Mn+2 + Ala-1 + Val-1 = Mn+2_Ala-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.14 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.42 (0.01SD)	3	ETS	94

Reaction No. 50715							
Mn+2 + bAla-1 + Val-1 = Mn+2_bAla-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.4 (2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:4.29 (0.01SD)	3	ETS	94

Reaction No. 50716							
Mn+2 + Arg-1 + Val-1 = Mn+2_Arg-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.96 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.24 (0.01SD)	3	ETS	94

Reaction No. 50717							
Mn+2 + Asn-1 + Val-1 = Mn+2_Asn-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.01 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.29 (0.01SD)	3	ETS	94


Reaction No. 50718							
Mn+2 + Asp-2 + Val-1 = Mn+2_Val-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.84 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.88 (0.01SD)	3	ETS	94

Reaction No. 50719							
Mn+2 + Citrul-1 + Val-1 = Mn+2_Citrul-1_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.31 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.59 (0.01SD)	3	ETS	94

Reaction No. 50720							
Mn+2 + Cys-2 + Val-1 = Mn+2_Val-1_Cys-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.84(0.01SD)	3	ETS	94

Reaction No. 50721




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.69(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.73(0.01SD)	3	ETS	94

Reaction No. 50722




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.01(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.29(0.01SD)	3	ETS	94

Reaction No. 50723




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.39(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.67(0.01SD)	3	ETS	94

Reaction No. 50724




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.09(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.37(0.01SD)	3	ETS	94

Reaction No. 50725



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.46(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.98(0.01SD)	3	ETS	94


Reaction No. 50726



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:5.45(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.73(0.01SD)	3	ETS	94

Reaction No. 50727




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.36(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.64(0.01SD)	3	ETS	94

Reaction No. 50728




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.38(0.01SD)	3	ETS	94

Reaction No. 50729




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.13(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.41(0.01SD)	3	ETS	94

Reaction No. 50730




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.16(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.44(0.01SD)	3	ETS	94

Reaction No. 50731



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.77(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.05(0.01SD)	3	ETS	94


Reaction No. 50732



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.01(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:4.29(0.01SD)	3	ETS	94
---	----	------	--------------	------------------	---	-----	----

Reaction No. 50733




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.96(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.24(0.01SD)	3	ETS	94

Reaction No. 50734




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.16(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.44(0.01SD)	3	ETS	94

Reaction No. 50735




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.79(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.59(0.01SD)	3	ETS	94

Reaction No. 50736




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.6(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:4.45(0.01SD)	3	ETS	94

Reaction No. 50737



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.40(0.01SD)	3	ETS	94


Reaction No. 50738



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.65(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:5.65(3SF)	2	EAE	


3	37	0.15	Blood Plasma	lgK:4.45 (0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 50739




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.01 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:6.01 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:5.05 (0.01SD)	3	ETS	94

Reaction No. 50740




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.95 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.75 (0.01SD)	3	ETS	94

Reaction No. 50741




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.96 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.00 (0.01SD)	3	ETS	94

Reaction No. 50742




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.86 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.90 (0.01SD)	3	ETS	94

Reaction No. 50743



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.65 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.45 (0.01SD)	3	ETS	94

Reaction No. 50744



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.03 (3SF)	2	EAE	

2	37	0.15	Blood Plasma	lgK:4.83(0.01SD)	3	ETS	94
---	----	------	--------------	------------------	---	-----	----

Reaction No. 50745							
Mn+2 + His-1 + Citric-3 = Mn+2_His-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.73(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.53(0.01SD)	3	ETS	94

Reaction No. 50746							
Mn+2 + Histamine + Citric-3 = Mn+2_Histamine_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.58(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.15(0.01SD)	3	ETS	94

Reaction No. 50747							
Mn+2 + Hyp-1 + Citric-3 = Mn+2_Hyp-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.90(0.01SD)	3	ETS	94

Reaction No. 50748							
Mn+2 + Ile-1 + Citric-3 = Mn+2_Ile-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.80(0.01SD)	3	ETS	94

Reaction No. 50749							
Mn+2 + Leu-1 + Citric-3 = Mn+2_Leu-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.75(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.55(0.01SD)	3	ETS	94

Reaction No. 50750							
Mn+2 + Met-1 + Citric-3 = Mn+2_Met-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.77(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.57(0.01SD)	3	ETS	94

Reaction No. 50751							
Mn+2 + Phe-1 + Citric-3 = Mn+2_Phe-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.60(0.01SD)	3	ETS	94

Reaction No. 50752							
Mn+2 + Pro-1 + Citric-3 = Mn+2_Pro-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.42(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.22(0.01SD)	3	ETS	94

Reaction No. 50753							
Mn+2 + Ser-1 + Citric-3 = Mn+2_Ser-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.65(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.45(0.01SD)	3	ETS	94

Reaction No. 50754							
Mn+2 + Thr-1 + Citric-3 = Mn+2_Thr-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.40(0.01SD)	3	ETS	94

Reaction No. 50755							
Mn+2 + Trp-1 + Citric-3 = Mn+2_Trp-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.60(0.01SD)	3	ETS	94

Reaction No. 50756							
Mn+2 + Val-1 + Citric-3 = Mn+2_Val-1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.64(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.44(0.01SD)	3	ETS	94

Reaction No. 50757							
--------------------	--	--	--	--	--	--	--

Mn+2 + Ala-1 + Lactic-1 = Mn+2_Ala-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.86(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.14(0.01SD)	3	ETS	94

Reaction No. 50758							
Mn+2 + bAla-1 + Lactic-1 = Mn+2_bAla-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.1(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:3.00(0.01SD)	3	ETS	94

Reaction No. 50759							
Mn+2 + Arg-1 + Lactic-1 = Mn+2_Arg-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.67(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.95(0.01SD)	3	ETS	94

Reaction No. 50760							
Mn+2 + Asn-1 + Lactic-1 = Mn+2_Asn-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.72(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.00(0.01SD)	3	ETS	94


Reaction No. 50761							
Mn+2 + Asp-2 + Lactic-1 = Mn+2_Lactic-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.56(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.60(0.01SD)	3	ETS	94

Reaction No. 50762							
Mn+2 + Citrul-1 + Lactic-1 = Mn+2_Citrul-1_Lactic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.02(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.30(0.01SD)	3	ETS	94

Reaction No. 50763							
Mn+2 + Cys-2 + Lactic-1 = Mn+2_Lactic-1_Cys-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.51(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.55(0.01SD)	3	ETS	94

Reaction No. 50764




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.41(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.45(0.01SD)	3	ETS	94

Reaction No. 50765




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.72(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.00(0.01SD)	3	ETS	94

Reaction No. 50766




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.38(0.01SD)	3	ETS	94

Reaction No. 50767




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.08(0.01SD)	3	ETS	94

Reaction No. 50768



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.18(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.70(0.01SD)	3	ETS	94


Reaction No. 50769



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:4.17(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.45(0.01SD)	3	ETS	94

Reaction No. 50770




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.07(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.35(0.01SD)	3	ETS	94

Reaction No. 50771




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.82(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.10(0.01SD)	3	ETS	94

Reaction No. 50772




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.85(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.13(0.01SD)	3	ETS	94

Reaction No. 50773




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.87(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.15(0.01SD)	3	ETS	94

Reaction No. 50774



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.48(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.76(0.01SD)	3	ETS	94


Reaction No. 50775



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.72(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:3.00(0.01SD)	3	ETS	94
---	----	------	--------------	------------------	---	-----	----

Reaction No. 50776




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.67(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.95(0.01SD)	3	ETS	94

Reaction No. 50777




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.87(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.15(0.01SD)	3	ETS	94

Reaction No. 50778




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.71(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.99(0.01SD)	3	ETS	94

Reaction No. 50779




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.35(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.15(0.01SD)	3	ETS	94

Reaction No. 50780



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.94(0.01SD)	3	ETS	94

Reaction No. 50781



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.9(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:3.80(0.01SD)	3	ETS	94

Reaction No. 50782							
Mn+2 + Arg-1 + Malic-2 = Mn+2_Arg-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.71(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.75(0.01SD)	3	ETS	94

Reaction No. 50783							
Mn+2 + Asn-1 + Malic-2 = Mn+2_Asn-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.76(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.80(0.01SD)	3	ETS	94

Reaction No. 50784							
Mn+2 + Asp-2 + Malic-2 = Mn+2_Asp-2_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.36(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.40(0.01SD)	3	ETS	94

Reaction No. 50785							
Mn+2 + Citrul-1 + Malic-2 = Mn+2_Citrul-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.06(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.10(0.01SD)	3	ETS	94

Reaction No. 50786							
Mn+2 + Cys-2 + Malic-2 = Mn+2_Cys-2_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.35(0.01SD)	3	ETS	94

Reaction No. 50787							
Mn+2 + Glu-2 + Malic-2 = Mn+2_Glu-2_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.21(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.25(0.01SD)	3	ETS	94

Reaction No. 50788							
--------------------	--	--	--	--	--	--	--

Mn+2 + Gln-1 + Malic-2 = Mn+2_Gln-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.76(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.80(0.01SD)	3	ETS	94

Reaction No. 50789							
Mn+2 + Gly-1 + Malic-2 = Mn+2_Gly-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.14(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.18(0.01SD)	3	ETS	94

Reaction No. 50790							
Mn+2 + His-1 + Malic-2 = Mn+2_His-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.84(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.88(0.01SD)	3	ETS	94

Reaction No. 50791							
Mn+2 + Histamine + Malic-2 = Mn+2_Histamine_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.46(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.50(0.01SD)	3	ETS	94


Reaction No. 50792							
Mn+2 + Hyp-1 + Malic-2 = Mn+2_Hyp-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.21(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.25(0.01SD)	3	ETS	94

Reaction No. 50793							
Mn+2 + Ile-1 + Malic-2 = Mn+2_Ile-1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.11(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.15(0.01SD)	3	ETS	94

Reaction No. 50794							
Mn+2 + Leu-1 + Malic-2 = Mn+2_Leu-1_Malic-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.86(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.90(0.01SD)	3	ETS	94

Reaction No. 50795




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.89(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.93(0.01SD)	3	ETS	94

Reaction No. 50796




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.91(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.95(0.01SD)	3	ETS	94

Reaction No. 50797




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.53(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.57(0.01SD)	3	ETS	94

Reaction No. 50798




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.76(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.80(0.01SD)	3	ETS	94

Reaction No. 50799



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.71(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.75(0.01SD)	3	ETS	94


Reaction No. 50800



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:4.91(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.95(0.01SD)	3	ETS	94

Reaction No. 50801




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.75(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.79(0.01SD)	3	ETS	94

Reaction No. 50802




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.91(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.95(0.01SD)	3	ETS	94

Reaction No. 50803




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.46(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:2.50(0.01SD)	3	ETS	94

Reaction No. 50804




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.84(0.01SD)	3	ETS	94

Reaction No. 50805



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.8(2SF)	1	EAE	
2	25	0	Inf. Dilution	lgK:4.9(2SF)	1	ESC	
3	37	0.15	Blood Plasma	lgK:4.70(0.01SD)	3	ETS	94


Reaction No. 50806



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:5.61(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.65(0.01SD)	3	ETS	94

Reaction No. 50807




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.66(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:5.66(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:4.70(0.01SD)	3	ETS	94

Reaction No. 50808




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.26(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:6.26(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:5.30(0.01SD)	3	ETS	94

Reaction No. 50809




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.96(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:4.96(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:4.00(0.01SD)	3	ETS	94

Reaction No. 50810



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.21(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:7.21(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:6.25(0.01SD)	3	ETS	94

Reaction No. 50811



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.11(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:6.11(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:5.15(0.01SD)	3	ETS	94

Reaction No. 50812							
Oxalic-2 + Gln-1 + Mn+2 = Mn+2_Gln-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.66(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:5.66(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:4.70(0.01SD)	3	ETS	94

Reaction No. 50813							
Mn+2 + Gly-1 + Oxalic-2 = Mn+2_Gly-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.04(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.08(0.01SD)	3	ETS	94

Reaction No. 50814							
Oxalic-2 + His-1 + Mn+2 = Mn+2_His-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.74(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:6.74(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:5.78(0.01SD)	3	ETS	94


Reaction No. 50815							
Oxalic-2 + Histamine + Mn+2 = Mn+2_Histamine_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.36(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:5.36(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:4.40(0.01SD)	3	ETS	94

Reaction No. 50816							
Oxalic-2 + Hyp-1 + Mn+2 = Mn+2_Hyp-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.11(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:6.11(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:5.15(0.01SD)	3	ETS	94

Reaction No. 50817							
Oxalic-2 + Ile-1 + Mn+2 = Mn+2_Ile-1_Oxalic-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.01(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:6.01(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:5.05(0.01SD)	3	ETS	94

Reaction No. 50818




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.76(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:5.76(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:4.80(0.01SD)	3	ETS	94

Reaction No. 50819




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.79(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:5.79(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:4.83(0.01SD)	3	ETS	94

Reaction No. 50820




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.81(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.85(0.01SD)	3	ETS	94

Reaction No. 50821



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.42(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.46(0.01SD)	3	ETS	94

Reaction No. 50822



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.66(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.70(0.01SD)	3	ETS	94

Reaction No. 50823							
Mn+2 + Thr-1 + Oxalic-2 = Mn+2_Thr-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.61(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.65(0.01SD)	3	ETS	94

Reaction No. 50824							
Mn+2 + Trp-1 + Oxalic-2 = Mn+2_Trp-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.81(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.85(0.01SD)	3	ETS	94

Reaction No. 50825							
Mn+2 + Val-1 + Oxalic-2 = Mn+2_Val-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.64(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.68(0.01SD)	3	ETS	94

Reaction No. 50826							
Mn+2 + Citric-3 + Oxalic-2 = Mn+2_Oxalic-2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.81(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.85(0.01SD)	3	ETS	94

Reaction No. 50827							
Oxalic-2 + Lactic-1 + Mn+2 = Mn+2_Lactic-1_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.36(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:4.36(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:3.40(0.01SD)	3	ETS	94

Reaction No. 50828							
Oxalic-2 + Malic-2 + Mn+2 = Mn+2_Malic-2_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.16(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:5.16(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:4.20(0.01SD)	3	ETS	94

Reaction No. 50829							
Mn+2 + Ala-1 + Salicylic-2 = Mn+2_Ala-1_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.94(0.01SD)	3	ETS	94

Reaction No. 50830							
Mn+2 + bAla-1 + Salicylic-2 = Mn+2_bAla-1_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.0(2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:6.80(0.01SD)	3	ETS	94

Reaction No. 50831							
Mn+2 + Arg-1 + Salicylic-2 = Mn+2_Arg-1_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.71(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.75(0.01SD)	3	ETS	94

Reaction No. 50832							
Mn+2 + Asn-1 + Salicylic-2 = Mn+2_Asn-1_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.76(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.80(0.01SD)	3	ETS	94

Reaction No. 50833							
Mn+2 + Asp-2 + Salicylic-2 = Mn+2_Asp-2_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.36(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:7.40(0.01SD)	3	ETS	94

Reaction No. 50834							
Mn+2 + Citrul-1 + Salicylic-2 = Mn+2_Citrul-1_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.06(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.10(0.01SD)	3	ETS	94

Reaction No. 50835							
--------------------	--	--	--	--	--	--	--

Mn+2 + Cys-2 + Salicylic-2 = Mn+2_Cys-2_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.31(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:8.35(0.01SD)	3	ETS	94

Reaction No. 50836							
Mn+2 + Glu-2 + Salicylic-2 = Mn+2_Glu-2_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.21(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:7.25(0.01SD)	3	ETS	94

Reaction No. 50837							
Mn+2 + Gln-1 + Salicylic-2 = Mn+2_Gln-1_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.76(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.80(0.01SD)	3	ETS	94

Reaction No. 50838							
Mn+2 + Gly-1 + Salicylic-2 = Mn+2_Gly-1_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.14(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:7.18(0.01SD)	3	ETS	94


Reaction No. 50839							
Mn+2 + His-1 + Salicylic-2 = Mn+2_His-1_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.84(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:7.88(0.01SD)	3	ETS	94

Reaction No. 50840							
Mn+2 + Histamine + Salicylic-2 = Mn+2_Histamine_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.46(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.50(0.01SD)	3	ETS	94

Reaction No. 50841							
Mn+2 + Hyp-1 + Salicylic-2 = Mn+2_Hyp-1_Salicylic-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.21(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:7.25(0.01SD)	3	ETS	94

Reaction No. 50842




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.11(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:7.15(0.01SD)	3	ETS	94

Reaction No. 50843




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.86(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.90(0.01SD)	3	ETS	94

Reaction No. 50844




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.88(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.92(0.01SD)	3	ETS	94

Reaction No. 50845




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.91(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.95(0.01SD)	3	ETS	94

Reaction No. 50846



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.53(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:7.57(0.01SD)	3	ETS	94


Reaction No. 50847



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:7.76(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.80(0.01SD)	3	ETS	94

Reaction No. 50848




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.71(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.75(0.01SD)	3	ETS	94

Reaction No. 50849




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.91(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.95(0.01SD)	3	ETS	94

Reaction No. 50850




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.74(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.78(0.01SD)	3	ETS	94

Reaction No. 50851




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.91(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.95(0.01SD)	3	ETS	94

Reaction No. 50852



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.46(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.50(0.01SD)	3	ETS	94


Reaction No. 50853



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.26(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:6.30 (0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 50854




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.16 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:7.20 (0.01SD)	3	ETS	94

Reaction No. 50855




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.12 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.16 (0.01SD)	3	ETS	94

Reaction No. 50856




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.1 (2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:5.02 (0.01SD)	3	ETS	94

Reaction No. 50857




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.93 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.97 (0.01SD)	3	ETS	94

Reaction No. 50858



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.98 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.02 (0.01SD)	3	ETS	94

Reaction No. 50859



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.58 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.62 (0.01SD)	3	ETS	94

Reaction No. 50860							
Mn+2 + Citrul-1 + Succinic-2 = Mn+2_Citrul-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.28(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.32(0.01SD)	3	ETS	94

Reaction No. 50861							
Mn+2 + Cys-2 + Succinic-2 = Mn+2_Cys-2_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.53(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.57(0.01SD)	3	ETS	94

Reaction No. 50862							
Mn+2 + Glu-2 + Succinic-2 = Mn+2_Glu-2_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.43(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.47(0.01SD)	3	ETS	94

Reaction No. 50863							
Mn+2 + Gln-1 + Succinic-2 = Mn+2_Gln-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.98(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.02(0.01SD)	3	ETS	94

Reaction No. 50864							
Mn+2 + Gly-1 + Succinic-2 = Mn+2_Gly-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.36(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.40(0.01SD)	3	ETS	94

Reaction No. 50865							
Mn+2 + His-1 + Succinic-2 = Mn+2_His-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.06(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:6.10(0.01SD)	3	ETS	94

Reaction No. 50866							
--------------------	--	--	--	--	--	--	--

Mn+2 + Histamine + Succinic-2 = Mn+2_Histamine_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.68(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.72(0.01SD)	3	ETS	94

Reaction No. 50867							
Mn+2 + Hyp-1 + Succinic-2 = Mn+2_Hyp-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.43(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.47(0.01SD)	3	ETS	94

Reaction No. 50868							
Mn+2 + Ile-1 + Succinic-2 = Mn+2_Ile-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.33(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.37(0.01SD)	3	ETS	94

Reaction No. 50869							
Mn+2 + Leu-1 + Succinic-2 = Mn+2_Leu-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.08(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.12(0.01SD)	3	ETS	94


Reaction No. 50870							
Mn+2 + Met-1 + Succinic-2 = Mn+2_Met-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.11(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.15(0.01SD)	3	ETS	94

Reaction No. 50871							
Mn+2 + Phe-1 + Succinic-2 = Mn+2_Phe-1_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.13(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.17(0.01SD)	3	ETS	94

Reaction No. 50872							
Mn+2 + Pro-1 + Succinic-2 = Mn+2_Pro-1_Succinic-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.75(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.79(0.01SD)	3	ETS	94

Reaction No. 50873




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.98(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.02(0.01SD)	3	ETS	94

Reaction No. 50874




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.93(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.97(0.01SD)	3	ETS	94

Reaction No. 50875




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.13(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.17(0.01SD)	3	ETS	94

Reaction No. 50876




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.96(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.00(0.01SD)	3	ETS	94

Reaction No. 50877



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.13(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.17(0.01SD)	3	ETS	94


Reaction No. 50878



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:4.68(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:3.72(0.01SD)	3	ETS	94

Reaction No. 50879




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.48(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:4.52(0.01SD)	3	ETS	94

Reaction No. 50880




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.38(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:5.42(0.01SD)	3	ETS	94

Reaction No. 50881




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.48(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:7.52(0.01SD)	3	ETS	94

Reaction No. 50882




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.94(0.01SD)	3	ETS	94

Reaction No. 50883



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.1(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:13.80(0.01SD)	3	ETS	94


Reaction No. 50884



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.9(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:13.75 (0.01SD)	3	ETS	94
---	----	------	--------------	--------------------	---	-----	----

Reaction No. 50885




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.80 (0.01SD)	3	ETS	94

Reaction No. 50886




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.40 (0.01SD)	3	ETS	94

Reaction No. 50887




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.10 (0.01SD)	3	ETS	94

Reaction No. 50888




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.35 (0.01SD)	3	ETS	94

Reaction No. 50889



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.25 (0.01SD)	3	ETS	94

Reaction No. 50890



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.0 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.80 (0.01SD)	3	ETS	94

Reaction No. 50891							
Gly-1 + Cis-2 + Mn+2 + H+1 = Mn+2_H+1_Gly-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.4 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:15.4 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:14.18 (0.01SD)	3	ETS	94

Reaction No. 50892							
H+1 + Mn+2 + His-1 + Cis-2 = Mn+2_H+1_His-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.88 (0.01SD)	3	ETS	94

Reaction No. 50893							
H+1 + Mn+2 + Histamine + Cis-2 = Mn+2_H+1_Histamine_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.50 (0.01SD)	3	ETS	94

Reaction No. 50894							
H+1 + Mn+2 + Hyp-1 + Cis-2 = Mn+2_H+1_Hyp-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.25 (0.01SD)	3	ETS	94

Reaction No. 50895							
H+1 + Mn+2 + Ile-1 + Cis-2 = Mn+2_H+1_Ile-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.15 (0.01SD)	3	ETS	94

Reaction No. 50896							
H+1 + Mn+2 + Leu-1 + Cis-2 = Mn+2_H+1_Leu-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.90 (0.01SD)	3	ETS	94

Reaction No. 50897							
H+1 + Mn+2 + Met-1 + Cis-2 = Mn+2_H+1_Met-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.93(0.01SD)	3	ETS	94

Reaction No. 50898							
H+1 + Mn+2 + Phe-1 + Cis-2 = Mn+2_H+1_Phe-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.95(0.01SD)	3	ETS	94

Reaction No. 50899							
H+1 + Mn+2 + Pro-1 + Cis-2 = Mn+2_H+1_Pro-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.57(0.01SD)	3	ETS	94

Reaction No. 50900							
H+1 + Mn+2 + Ser-1 + Cis-2 = Mn+2_H+1_Ser-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.80(0.01SD)	3	ETS	94

Reaction No. 50901							
H+1 + Mn+2 + Thr-1 + Cis-2 = Mn+2_H+1_Thr-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.75(0.01SD)	3	ETS	94

Reaction No. 50902							
H+1 + Mn+2 + Trp-1 + Cis-2 = Mn+2_H+1_Trp-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.95(0.01SD)	3	ETS	94

Reaction No. 50903							
--------------------	--	--	--	--	--	--	--

H+1 + Mn+2 + Val-1 + Cis-2 = Mn+2_H+1_Val-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.78(0.01SD)	3	ETS	94

Reaction No. 50904							
Citric-3 + Cis-2 + Mn+2 + H+1 = Mn+2_H+1_Cis-2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.6(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:15.6(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:13.95(0.01SD)	3	ETS	94

Reaction No. 50905							
H+1 + Mn+2 + Lactic-1 + Cis-2 = Mn+2_H+1_Lactic-1_Cis-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.50(0.01SD)	3	ETS	94

Reaction No. 50906							
H+1 + Mn+2 + Malic-2 + Cis-2 = Mn+2_H+1_Cis-2_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.30(0.01SD)	3	ETS	94

Reaction No. 50907							
Oxalic-2 + Cis-2 + Mn+2 + H+1 = Mn+2_H+1_Cis-2_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.6(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:15.6(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:14.20(0.01SD)	3	ETS	94

Reaction No. 50908							
H+1 + Mn+2 + Salicylic-2 + Cis-2 = Mn+2_H+1_Cis-2_Salicylic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:16.30(0.01SD)	3	ETS	94

Reaction No. 50909							
H+1 + Mn+2 + Succinic-2 + Cis-2 = Mn+2_H+1_Cis-2_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.52(0.01SD)	3	ETS	94

Reaction No. 50910							
H+1 + Mn+2 + Ala-1 + Lys-1 = Mn+2_H+1_Ala-1_Lys-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.62(0.01SD)	3	ETS	94

Reaction No. 50911							
H+1 + Mn+2 + bAla-1 + Lys-1 = Mn+2_H+1_bAla-1_Lys-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.9(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:14.47(0.01SD)	3	ETS	94

Reaction No. 50912							
H+1 + Mn+2 + Arg-1 + Lys-1 = Mn+2_H+1_Arg-1_Lys-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.43(0.01SD)	3	ETS	94

Reaction No. 50913							
H+1 + Mn+2 + Asn-1 + Lys-1 = Mn+2_H+1_Asn-1_Lys-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.47(0.01SD)	3	ETS	94

Reaction No. 50914							
H+1 + Mn+2 + Asp-2 + Lys-1 = Mn+2_H+1_Lys-1_Asp-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.08(0.01SD)	3	ETS	94

Reaction No. 50915							
--------------------	--	--	--	--	--	--	--

H+1 + Mn+2 + Citrul-1 + Lys-1 = Mn+2_H+1_Citrul-1_Lys-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.78(0.01SD)	3	ETS	94

Reaction No. 50916							
H+1 + Mn+2 + Cys-2 + Lys-1 = Mn+2_H+1_Lys-1_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:16.02(0.01SD)	3	ETS	94

Reaction No. 50917							
H+1 + Mn+2 + Glu-2 + Lys-1 = Mn+2_H+1_Lys-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.93(0.01SD)	3	ETS	94

Reaction No. 50918							
H+1 + Mn+2 + Gln-1 + Lys-1 = Mn+2_H+1_Gln-1_Lys-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.47(0.01SD)	3	ETS	94


Reaction No. 50919							
H+1 + Mn+2 + Gly-1 + Lys-1 = Mn+2_H+1_Gly-1_Lys-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.86(0.01SD)	3	ETS	94

Reaction No. 50920							
H+1 + Mn+2 + His-1 + Lys-1 = Mn+2_H+1_His-1_Lys-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.55(0.01SD)	3	ETS	94

Reaction No. 50921							
H+1 + Mn+2 + Histamine + Lys-1 = Mn+2_H+1_Histamine_Lys-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.17 (0.01SD)	3	ETS	94

Reaction No. 50922




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.93 (0.01SD)	3	ETS	94

Reaction No. 50923




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.82 (0.01SD)	3	ETS	94

Reaction No. 50924




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.58 (0.01SD)	3	ETS	94

Reaction No. 50925




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.60 (0.01SD)	3	ETS	94

Reaction No. 50926



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.63 (0.01SD)	3	ETS	94


Reaction No. 50927



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:16.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.24(0.01SD)	3	ETS	94

Reaction No. 50928




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.47(0.01SD)	3	ETS	94

Reaction No. 50929




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.43(0.01SD)	3	ETS	94

Reaction No. 50930




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.63(0.01SD)	3	ETS	94

Reaction No. 50931




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.46(0.01SD)	3	ETS	94

Reaction No. 50932



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.63(0.01SD)	3	ETS	94


Reaction No. 50933



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.9(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:13.18(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 50934




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.97(0.01SD)	3	ETS	94

Reaction No. 50935




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.1(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:16.1(3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:14.88(0.01SD)	3	ETS	94

Reaction No. 50936




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:16.98(0.01SD)	3	ETS	94

Reaction No. 50937




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.20(0.01SD)	3	ETS	94

Reaction No. 50938



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.98(0.01SD)	3	ETS	94


Reaction No. 50939



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.0(3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:14.29(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 50940




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.6(3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:14.15(0.01SD)	3	ETS	94

Reaction No. 50941




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.10(0.01SD)	3	ETS	94

Reaction No. 50942




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.15(0.01SD)	3	ETS	94

Reaction No. 50943




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.75(0.01SD)	3	ETS	94

Reaction No. 50944



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.45(0.01SD)	3	ETS	94

Reaction No. 50945



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.70(0.01SD)	3	ETS	94

Reaction No. 50946							
H+1 + Mn+2 + Glu-2 + Orn-1 = Mn+2_H+1_Orn-1_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.60(0.01SD)	3	ETS	94

Reaction No. 50947							
H+1 + Mn+2 + Gln-1 + Orn-1 = Mn+2_H+1_Gln-1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.15(0.01SD)	3	ETS	94

Reaction No. 50948							
H+1 + Mn+2 + Gly-1 + Orn-1 = Mn+2_H+1_Gly-1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.53(0.01SD)	3	ETS	94

Reaction No. 50949							
H+1 + Mn+2 + His-1 + Orn-1 = Mn+2_H+1_His-1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.23(0.01SD)	3	ETS	94

Reaction No. 50950							
H+1 + Mn+2 + Histamine + Orn-1 = Mn+2_H+1_Histamine_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.85(0.01SD)	3	ETS	94

Reaction No. 50951							
H+1 + Mn+2 + Hyp-1 + Orn-1 = Mn+2_H+1_Hyp-1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.60(0.01SD)	3	ETS	94

Reaction No. 50952							
--------------------	--	--	--	--	--	--	--

H+1 + Mn+2 + Ile-1 + Orn-1 = Mn+2_H+1_Ile-1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.50(0.01SD)	3	ETS	94

Reaction No. 50953							
H+1 + Mn+2 + Leu-1 + Orn-1 = Mn+2_H+1_Leu-1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.25(0.01SD)	3	ETS	94

Reaction No. 50954							
H+1 + Mn+2 + Met-1 + Orn-1 = Mn+2_H+1_Met-1_Orn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.28(0.01SD)	3	ETS	94

Reaction No. 50955							
H+1 + Mn+2 + Phe-1 + Orn-1 = Mn+2_H+1_Orn-1_Phe-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.30(0.01SD)	3	ETS	94


Reaction No. 50956							
H+1 + Mn+2 + Pro-1 + Orn-1 = Mn+2_H+1_Orn-1_Pro-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.92(0.01SD)	3	ETS	94

Reaction No. 50957							
H+1 + Mn+2 + Ser-1 + Orn-1 = Mn+2_H+1_Orn-1_Ser-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.15(0.01SD)	3	ETS	94

Reaction No. 50958							
H+1 + Mn+2 + Thr-1 + Orn-1 = Mn+2_H+1_Orn-1_Thr-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.10(0.01SD)	3	ETS	94

Reaction No. 50959




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.30(0.01SD)	3	ETS	94

Reaction No. 50960




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.13(0.01SD)	3	ETS	94

Reaction No. 50961




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.0(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.30(0.01SD)	3	ETS	94

Reaction No. 50962




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.85(0.01SD)	3	ETS	94

Reaction No. 50963



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.65(0.01SD)	3	ETS	94


Reaction No. 50964



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:15.7 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:15.7 (3SF)	2	EAE	
3	37	0.15	Blood Plasma	lgK:14.55 (0.01SD)	3	ETS	94

Reaction No. 50965




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:16.65 (0.01SD)	3	ETS	94

Reaction No. 50966




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.87 (0.01SD)	3	ETS	94

Reaction No. 50967




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.65 (0.01SD)	3	ETS	94

Reaction No. 50968




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:24.33 (0.01SD)	3	ETS	94

Reaction No. 50969



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.39 (0.01SD)	3	ETS	94


Reaction No. 50970



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:14.7 (3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:14.25 (0.01SD)	3	ETS	94

Reaction No. 50971




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.20 (0.01SD)	3	ETS	94

Reaction No. 50972




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.25 (0.01SD)	3	ETS	94

Reaction No. 50973




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.85 (0.01SD)	3	ETS	94

Reaction No. 50974




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.55 (0.01SD)	3	ETS	94

Reaction No. 50975



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.80 (0.01SD)	3	ETS	94


Reaction No. 50976



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.1 (3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:14.70 (0.01SD)	3	ETS	94
---	----	------	--------------	--------------------	---	-----	----

Reaction No. 50977




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.25 (0.01SD)	3	ETS	94

Reaction No. 50978




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.63 (0.01SD)	3	ETS	94

Reaction No. 50979




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.33 (0.01SD)	3	ETS	94

Reaction No. 50980




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.9 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.95 (0.01SD)	3	ETS	94

Reaction No. 50981



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.9 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.70 (0.01SD)	3	ETS	94

Reaction No. 50982



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.60 (0.01SD)	3	ETS	94

Reaction No. 50983							
H+1 + Mn+2 + Leu-1 + Tyr-2 = Mn+2_H+1_Leu-1_Tyr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.5 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.35 (0.01SD)	3	ETS	94

Reaction No. 50984							
H+1 + Mn+2 + Met-1 + Tyr-2 = Mn+2_H+1_Met-1_Tyr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.38 (0.01SD)	3	ETS	94

Reaction No. 50985							
H+1 + Mn+2 + Phe-1 + Tyr-2 = Mn+2_H+1_Phe-1_Tyr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.40 (0.01SD)	3	ETS	94

Reaction No. 50986							
H+1 + Mn+2 + Pro-1 + Tyr-2 = Mn+2_H+1_Pro-1_Tyr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.01 (0.01SD)	3	ETS	94

Reaction No. 50987							
H+1 + Mn+2 + Ser-1 + Tyr-2 = Mn+2_H+1_Ser-1_Tyr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.25 (0.01SD)	3	ETS	94

Reaction No. 50988							
H+1 + Mn+2 + Thr-1 + Tyr-2 = Mn+2_H+1_Thr-1_Tyr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.20 (0.01SD)	3	ETS	94

Reaction No. 50989							
--------------------	--	--	--	--	--	--	--

H+1 + Mn+2 + Trp-1 + Tyr-2 = Mn+2_H+1_Trp-1_Tyr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.6(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.40(0.01SD)	3	ETS	94

Reaction No. 50990							
H+1 + Mn+2 + Val-1 + Tyr-2 = Mn+2_H+1_Val-1_Tyr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.4(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.24(0.01SD)	3	ETS	94

Reaction No. 50991							
H+1 + Mn+2 + Citric-3 + Tyr-2 = Mn+2_H+1_Tyr-2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.40(0.01SD)	3	ETS	94

Reaction No. 50992							
H+1 + Mn+2 + Lactic-1 + Tyr-2 = Mn+2_H+1_Lactic-1_Tyr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:12.95(0.01SD)	3	ETS	94


Reaction No. 50993							
H+1 + Mn+2 + Malic-2 + Tyr-2 = Mn+2_H+1_Malic-2_Tyr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.75(0.01SD)	3	ETS	94

Reaction No. 50994							
H+1 + Mn+2 + Oxalic-2 + Tyr-2 = Mn+2_H+1_Oxalic-2_Tyr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.65(0.01SD)	3	ETS	94

Reaction No. 50995							
H+1 + Mn+2 + Salicylic-2 + Tyr-2 = Mn+2_H+1_Salicylic-2_Tyr-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.2 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:16.75 (0.01SD)	3	ETS	94

Reaction No. 50996




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.97 (0.01SD)	3	ETS	94

Reaction No. 50997




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:23.75 (0.01SD)	3	ETS	94

Reaction No. 50998




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.6 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:24.42 (0.01SD)	3	ETS	94

Reaction No. 50999




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:24.10 (0.01SD)	3	ETS	94

Reaction No. 51000



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.9 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.24 (0.01SD)	3	ETS	94


Reaction No. 51001



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:15.5 (3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:15.10 (0.01SD)	3	ETS	94

Reaction No. 51002




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.7 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.05 (0.01SD)	3	ETS	94

Reaction No. 51003




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.8 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.10 (0.01SD)	3	ETS	94

Reaction No. 51004




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.4 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.70 (0.01SD)	3	ETS	94

Reaction No. 51005




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.1 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.40 (0.01SD)	3	ETS	94

Reaction No. 51006



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.3 (3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:16.65 (0.01SD)	3	ETS	94


Reaction No. 51007



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.2 (3SF)	2	EAE	


2	37	0.15	Blood Plasma	lgK:15.55(0.01SD)	3	ETS	94
---	----	------	--------------	-------------------	---	-----	----

Reaction No. 51008




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.10(0.01SD)	3	ETS	94

Reaction No. 51009




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.48(0.01SD)	3	ETS	94

Reaction No. 51010




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:16.18(0.01SD)	3	ETS	94

Reaction No. 51011




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.80(0.01SD)	3	ETS	94

Reaction No. 51012



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.55(0.01SD)	3	ETS	94

Reaction No. 51013



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.1(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.45(0.01SD)	3	ETS	94

Reaction No. 51014							
H+1 + Mn+2 + Leu-1 + PO4-3 = Mn+2_H+1_Leu-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.20(0.01SD)	3	ETS	94

Reaction No. 51015							
H+1 + Mn+2 + Met-1 + PO4-3 = Mn+2_H+1_Met-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.23(0.01SD)	3	ETS	94

Reaction No. 51016							
H+1 + Mn+2 + Phe-1 + PO4-3 = Mn+2_H+1_Phe-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.25(0.01SD)	3	ETS	94

Reaction No. 51017							
H+1 + Mn+2 + Pro-1 + PO4-3 = Mn+2_H+1_Pro-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.86(0.01SD)	3	ETS	94

Reaction No. 51018							
H+1 + Mn+2 + Ser-1 + PO4-3 = Mn+2_H+1_Ser-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.10(0.01SD)	3	ETS	94

Reaction No. 51019							
H+1 + Mn+2 + Thr-1 + PO4-3 = Mn+2_H+1_Thr-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.05(0.01SD)	3	ETS	94

Reaction No. 51020							
--------------------	--	--	--	--	--	--	--

H+1 + Mn+2 + Trp-1 + PO4-3 = Mn+2_H+1_Trp-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.25(0.01SD)	3	ETS	94

Reaction No. 51021							
H+1 + Mn+2 + Val-1 + PO4-3 = Mn+2_H+1_Val-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.8(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.09(0.01SD)	3	ETS	94

Reaction No. 51022							
H+1 + Mn+2 + Citric-3 + PO4-3 = Mn+2_H+1_Citric-3_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.25(0.01SD)	3	ETS	94

Reaction No. 51023							
H+1 + Mn+2 + Lactic-1 + PO4-3 = Mn+2_H+1_Lactic-1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:13.80(0.01SD)	3	ETS	94


Reaction No. 51024							
H+1 + Mn+2 + Malic-2 + PO4-3 = Mn+2_H+1_Malic-2_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:14.60(0.01SD)	3	ETS	94

Reaction No. 51025							
H+1 + Mn+2 + Oxalic-2 + PO4-3 = Mn+2_H+1_Oxalic-2_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.50(0.01SD)	3	ETS	94

Reaction No. 51026							
H+1 + Mn+2 + Salicylic-2 + PO4-3 = Mn+2_H+1_Salicylic-2_PO4-3							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.3(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:17.60(0.01SD)	3	ETS	94

Reaction No. 51027




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.5(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:15.82(0.01SD)	3	ETS	94

Reaction No. 51028




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:26.7(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:24.60(0.01SD)	3	ETS	94

Reaction No. 51029




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:27.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:25.27(0.01SD)	3	ETS	94

Reaction No. 51030




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:26.9(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:24.95(0.01SD)	3	ETS	94

Reaction No. 51031



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:27.2(3SF)	2	EAE	
2	37	0.15	Blood Plasma	lgK:25.05(0.01SD)	3	ETS	94


Reaction No. 52343



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	UCT_Sea	lgK:2.73 (0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:1.95 (0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:1.79 (0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:1.69 (0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:1.63 (0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:1.58 (0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:1.54 (0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:1.50 (0.01SD)	4	EDH	5390

Reaction No. 52344




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:0.80 (0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:0.81 (0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:0.82 (0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:0.83 (0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:0.84 (0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:0.85 (0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:0.86 (0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:0.87 (0.01SD)	4	EDH	5390

Reaction No. 52345



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:2.35 (0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:1.76 (0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:1.64 (0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:1.58 (0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:1.54 (0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:1.52 (0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:1.50 (0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:1.49 (0.01SD)	4	EDH	5390
9	25	1	NaClO ₄	lgK:1.54 (3SF)	5	MQH	7703


Reaction No. 52346



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	UCT_Sea	lgK:2.74 (0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:2.74 (0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:2.74 (0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:2.75 (0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:2.75 (0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:2.75 (0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:2.76 (0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:2.76 (0.01SD)	4	EDH	5390

Reaction No. 52347




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:4.79 (0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:4.80 (0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:4.81 (0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:4.82 (0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:4.82 (0.01SD)	4	EDH	5390
6	25	0.5	UCT_Sea	lgK:4.83 (0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:4.84 (0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:4.85 (0.01SD)	4	EDH	5390

Reaction No. 52386



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	MeCN Et4NCl	lgK:4.73 (0.09MD)	5	MCL	4493
2	25	0.1	MeCN Et4NCl	dH:-49. (2.MD) kJ	5	MCL	4493

Reaction No. 52387



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	DMF Et4NClO4	dH:-15.1 (0.8SD) kJ	4	MCL	2334
2	25	0.1	MeCN Et4NCl	lgK:2.9 (0.1MD)	5	MCL	4493
3	25	0.1	MeCN Et4NCl	dH:-25.8 (0.9MD) kJ	5	MCL	4493

Reaction No. 52388							
2<3MePyridine> + Mn+2 = Mn+2_3MePyridine(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	MeCN Et4NCl	lgK:5.1(0.1MD)	5	MCL	4493
2	25	0.1	MeCN Et4NCl	dH:-48.(2.MD)kJ	5	MCL	4493

Reaction No. 52389							
4MePyridine + Mn+2 = Mn+2_4MePyridine							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	DMF Et4NClO4	dH:-20.6(0.5SD)kJ	4	MCL	2334
2	25	0.1	MeCN Et4NCl	lgK:2.95(0.07MD)	5	MCL	4493
3	25	0.1	MeCN Et4NCl	dH:-30.3(0.7MD)kJ	5	MCL	4493

Reaction No. 52390							
2<4MePyridine> + Mn+2 = Mn+2_4MePyridine(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	MeCN Et4NCl	lgK:5.28(0.09MD)	5	MCL	4493
2	25	0.1	MeCN Et4NCl	dH:-52.(1.MD)kJ	5	MCL	4493

Reaction No. 52391							
3<Pyridine> + Mn+2 = Mn+2_Pyridine(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	MeCN Et4NCl	lgK:5.9(0.1MD)	5	MCL	4493
2	25	0.1	MeCN Et4NCl	dH:-83.(4.MD)kJ	5	MCL	4493

Reaction No. 52392							
3<3MePyridine> + Mn+2 = Mn+2_3MePyridine(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	MeCN Et4NCl	lgK:6.4(0.2MD)	5	MCL	4493
2	25	0.1	MeCN Et4NCl	dH:-79.(4.MD)kJ	5	MCL	4493

Reaction No. 52393							
3<4MePyridine> + Mn+2 = Mn+2_4MePyridine(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	MeCN Et4NCl	lgK:6.9(0.2MD)	5	MCL	4493
2	25	0.1	MeCN Et4NCl	dH:-83.(6.MD)kJ	5	MCL	4493

Reaction No. 52542							
[18]N6 + Mn+2 = Mn+2_[18]N6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaClO4	lgK:10.50(0.02SD)	6	MPS	11

Reaction No. 52543							
[24]N8 + Mn+2 = Mn+2_[24]N8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaClO4	lgK:6.3(0.03SD)	6	MPS	11

Reaction No. 52544							
H+1 + [24]N8 + Mn+2 = Mn+2_H+1_[24]N8							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.15	NaClO4	lgK:14.5(0.04SD)	6	MPS	11

Reaction No. 52763							
I-1 + Mn+2 = Mn+2_I-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.23(2SF)	4	EBU	6372
2	25	0.1	MeCN Et4NClO4	lgK:3.5(2SF)	5	MPL	5398

Reaction No. 52764							
2<I-1> + Mn+2 = Mn+2_I-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.10(2SF)	0	EBU	6372
2	25	0.1	MeCN Et4NClO4	lgK:5.6(2SF)	5	MPL	5398

Reaction No. 52765							
3<I-1> + Mn+2 = Mn+2_I-1(3)							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.27 (2SF)	0	EBU	6372
2	25	0.1	MeCN Et4NC104	lgK:7.8 (2SF)	5	MPL	5398

Reaction No. 52766							
4<I-1> + Mn+2 = Mn+2_I-1 (4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.83 (2SF)	0	EBU	6372
2	25	0.1	MeCN Et4NC104	lgK:10.0 (3SF)	5	MPL	5398


Reaction No. 52767							
5<I-1> + Mn+2 = Mn+2_I-1 (5)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.55 (3SF)	0	EBU	6372
2	25	0.1	MeCN Et4NC104	lgK:12.2 (3SF)	5	MPL	5398

Reaction No. 52768							
6<I-1> + Mn+2 = Mn+2_I-1 (6)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.40 (3SF)	0	EBU	6372
2	25	0.1	MeCN Et4NC104	lgK:14.4 (3SF)	5	MPL	5398

Reaction No. 52852							
Br-1 + Mn+2 = Mn+2_Br-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.69	HClO4	lgK:0.27 (2SF)	4	MCE	931
2	25	0	UCT_Sea	lgK:0.25 (0.01SD)	4	EDH	5390
3	25	0.1	UCT_Sea	lgK:-0.17 (0.01SD)	4	EDH	5390
4	25	0.2	UCT_Sea	lgK:-0.27 (0.01SD)	4	EDH	5390
5	25	0.3	UCT_Sea	lgK:-0.31 (0.01SD)	4	EDH	5390
6	25	0.4	UCT_Sea	lgK:-0.34 (0.01SD)	4	EDH	5390
7	25	0.5	UCT_Sea	lgK:-0.37 (0.01SD)	4	EDH	5390
8	25	0.5	Unknown	lgK:-0.4 (1SF)	6	CRV	552
9	25	0.6	UCT_Sea	lgK:-0.39 (0.01SD)	4	EDH	5390
10	25	0.7	UCT_Sea	lgK:-0.40 (0.01SD)	4	EDH	5390


11	25	1	NaClO ₄	lgK:0.1 (0.06SD)	5	MKN	516
12	25	0.16	DMF Et ₄ NClO ₄	lgK:1.91 (3SF)	5	MCL	7214
13	25	0.16	DMF Et ₄ NClO ₄	dH:3.36 (3SF)	5	MCL	7214
14	25	0.1	DiMeAcetamide Bu ₄ NBF ₄	lgK:2.29 (3SF)	5	MGL	7225
15	25	0.1	DiMeAcetamide Bu ₄ NBF ₄	dH:6.93 (3SF)	5	MCL	7225
16	25	0.1	HMPA Unknown	lgK:4.1 (2SF)	5	ENS	7187
17	25	0.1	HMPA Unknown	dH:2.92 (3SF)	5	ENS	7187
18	23		Methanol	lgK:1.0 (2SF)	4	MES	5398

Reaction No. 52961




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO ₄	lgK:-0.27 (2SF)	5	MKN	516
2	25	1	NaClO ₃	lgR:-0.27 (0.13SD)	5	MDG	4701
3	25	1	NaClO ₃	dH:-5.21 (0.07SD) kJ	6	MDG	4701

Reaction No. 53019




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3.26	NaClO ₄	lgK:0.04 (1SF)	4	MSP	732

Reaction No. 53193




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.04 (3SF)	0	MPL	5398

Reaction No. 53194



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.64 (4SF)	0	MPL	5398


Reaction No. 53195



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:13.4 (3SF)	0	MPL	5398
---	----	---	---------------	----------------	---	-----	------

Reaction No. 53196




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.7 (3SF)	0	MPL	5398

Reaction No. 53197




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.5 (3SF)	0	MPL	5398

Reaction No. 53198




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	5.35	HClO4	lgR:2.28 (3SF)	5	MSP	5398

Reaction No. 53245



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:2.2 (0.02SD)	5	MIS	5230
2	10	0	Inf. Dilution	lgK:2.29 (0.02SD)	5	MIS	5230
3	20	0	Inf. Dilution	lgK:2.39 (3SF)	4	MHY	5398
4	25	0	Inf. Dilution	lgK:2.430 (0.012SD)	6	CMN	5230
5	25	0	Inf. Dilution	lgK:2.43 (0.01SD)	3	EOD	32222
6	35	0	Inf. Dilution	lgK:2.52 (0.01SD)	5	MIS	5230
7	45	0	Inf. Dilution	lgK:2.60 (0.01SD)	5	MIS	5230
8	25	0	Inf. Dilution	dH:4. (0.3SD)	5	MIS	5230

Reaction No. 53345



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0	0	Inf. Dilution	lgK:0.48 (2SF)	4	MDG	8675
2	23	7.5	NH4NO3	lgK:-0.30 (2SF)	4	MEF	4999
3	23	7.5	NH4NO3	lgK:-0.3 (1SF)	4	MEF	5398
4	23			lgK:0.04 (0.05SD)	3	MPS	4999
5	23			lgK:0.04 (1SF)	3	MSP	5398

6	25	0	Inf. Dilution	lgK:0.48 (2SF)	4	MDG	8675
7	25	1	NaClO4	lgK:0.58 (2SF)	5	MSL	11516
Note (7): Fedorov V et al., Koord. Khim., 1975, 1, 836							
8	25			lgK:0.54 (2SF)	4	MMR	8378

Reaction No. 53423							
P207-4 + Mn+3 = Mn+3_P207-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.34	NaClO4	lgK:16.7 (3SF)	4	MIE	5398

Reaction No. 53424							
2<P207-4> + Mn+3 = Mn+3_P207-4 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.34	NaClO4	lgK:30.9 (3SF)	4	MIE	5398

Reaction No. 53425							
Mn+3 + H+1 (2)_P207-4 = Mn+3_H+1 (2)_P207-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1.8	HClO4	lgK:9.0 (2SF)	0	MSP	5398
2	25	0	Inf. Dilution	lgK:8.0 (2SF)	1	ERG	
Note (2): Was lgK=7.8 prev iter							
3	25	0.34	NaClO4	lgK:5.1 (2SF)	0	MIE	5398


Reaction No. 53426							
Mn+3 + 2<H+1 (2)_P207-4> = Mn+3_H+1 (4)_P207-4 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.4 (3SF)	1	ERG	
Note (1): Was lgK=12.2 prev iter							
2	25	0.34	NaClO4	lgK:8.4 (2SF)	4	MIE	5398

Reaction No. 53427							
Mn+3 + 3<H+1 (2)_P207-4> = Mn+3_H+1 (6)_P207-4 (3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.34	NaClO4	lgK:11.2 (3SF)	4	MIE	5398

Reaction No. 53468							
P3010-5 + Mn+2 = Mn+2_P3010-5							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	2	0.1	KNO3	lgK:7.12 (3SF)	0	MGL	281
2	20	0.1	Me4NNO3	lgK:8.04 (0.01SD)	7	MGL	284
3	25	0	Inf. Dilution	lgK:9.9 (2SF)	4	ENS	6405
4	25	0.1	KCl	lgK:7.21 (0.02SD)	0	MGL	277
5	25	0.1	KNO3	lgK:6.20 (3SF)	0	MGL	281
6	25	0.1	Me4N+ salt	lgK:8.08 (3SF)	6	CRV	552
7	25	0.1	Unknown	lgK:7.15 (3SF)	0	CRV	552
8	35	0.1	KNO3	lgK:7.11 (3SF)	0	MGL	281
9	45	0.1	KNO3	lgK:6.31 (3SF)	0	MGL	281
10	20	0.1	Me4N+ salt	dH:2.8 (2SF)	6	CRV	552
11	20	0.1	Me4NNO3	dH:2.8 (0.1SD)	6	MCL	284
12	25	0.1	KNO3	dH:-6.0 (0.1SD)	0	MTD	281

Reaction No. 53469




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:2.00 (3SF)	0	MGL	5398

Reaction No. 53470



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	2	0.1	KNO3	lgK:3.90 (3SF)	3	MGL	281
2	20	0.1	Me4NNO3	lgK:5.08 (0.01SD)	0	MGL	284
3	25	0.1	KCl	lgK:3.77 (0.02SD)	0	MGL	277
4	25	0.1	KNO3	lgK:4.30 (3SF)	3	MGL	281
5	25	0.1	NaClO4	lgK:4.31 (0.02SD) w	5	MPH	125
6	35	0.1	KNO3	lgK:4.51 (3SF)	3	MGL	281
7	45	0.1	KNO3	lgK:4.07 (3SF)	3	MGL	281
8	25	0.1	KNO3	dH:-0.01 (0.01SD)	4	MTD	281
9	25	0.1	KNO3	dH:0.0 (1SF)	3	MTD	5398

Reaction No. 53471



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	45	0.1	KNO3	lgK:2.9 (2SF)	5	MGL	5398

Reaction No. 53569							
$\text{NH}_2\text{OH} + \text{Mn}^{+2} = \text{Mn}^{+2}\text{NH}_2\text{OH}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	NaNO ₃	lgK:0.5 (1SF)	2	MGL	931
2	20	0.5	Unknown	lgK:0.53 (2SF)	5	CRV	7271
3	25	0	Inf. Dilution	lgK:0.8 (1SF)	1	EES	
4	25	1	KNO ₃	lgK:4.04 (3SF)w	0	MPH	5398
Note (4): Ivaskovich & Skoblei, Zh. Neorg. Kh., 1974, 19, 760 (E:411)							

Reaction No. 53570							
$\text{Mn}^{+2}\text{NH}_2\text{OH} + \text{NH}_2\text{OH} = \text{Mn}^{+2}\text{NH}_2\text{OH}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO ₃	lgK:3.52 (3SF)w	0	MPH	5398
Note (1): See ML rxn. S&M have rejected RJIC. 1974, 19, 411 source							

Reaction No. 53571							
$\text{Mn}^{+2}\text{NH}_2\text{OH}(2) + \text{NH}_2\text{OH} = \text{Mn}^{+2}\text{NH}_2\text{OH}(3)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO ₃	lgK:3.28 (3SF)w	0	MPH	5398
Note (1): See ML rxn. S&M have rejected RJIC. 1974, 19, 411 source							


Reaction No. 53572							
$\text{Mn}^{+2}\text{NH}_2\text{OH}(3) + \text{NH}_2\text{OH} = \text{Mn}^{+2}\text{NH}_2\text{OH}(4)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO ₃	lgK:3.16 (3SF)w	0	MPH	5398
Note (1): See ML rxn. S&M have rejected RJIC. 1974, 19, 411 source							

Reaction No. 53586							
$\text{Mn}^{+3} + \text{H}^{+1}\text{N}_3^{-1} = \text{Mn}^{+3}\text{N}_3^{-1} + \text{H}^{+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3.8	NaClO ₄	lgK:1.85 (3SF)	5	MKN	5398
2	25	3.8	NaClO ₄	lgK:1.95 (3SF)	5	MSP	5398

Reaction No. 53776							
$\text{N}_2\text{H}_4 + \text{Mn}^{+2} = \text{Mn}^{+2}\text{N}_2\text{H}_4$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.76 (3SF)	2	EAE	


2	25			lgK:1.93 (3SF)	0	MPL	140
3	30	1	NaClO4	lgK:4.76 (3SF)	5	MGL	931

Reaction No. 53797




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.25	NaClO4	lgK:1.51 (3SF)	4	MSP	931

Reaction No. 53967




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.62 (0.04SD)	2	MGL	277
2	25	0.1	Me4NNO3	lgK:5.86 (3SF)	0	MGL	931

Reaction No. 54293




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.69	HClO4	lgK:-0.26 (2SF)	4	MCE	931
2	25	0	Inf. Dilution	lgK:0.0375 (3SF)	2	EAE	
3	25	0.1	DiMeAcetamide Bu4NBF4	lgK:2.1 (2SF)	5	MGL	7225
4	25	0.1	DiMeAcetamide Bu4NBF4	dH:6.45 (3SF)	5	MCL	7225
5	25	0.1	HMPA Unknown	lgK:2.4 (2SF)	5	ENS	7187
6	25	0.1	HMPA Unknown	dH:3.25 (3SF)	5	ENS	7187

Reaction No. 54426



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20			lgK:0.64 (2SF)	2	MSP	931
2	20			dH:-4.0 (2SF)	2	MCL	931

Reaction No. 54486



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.569 (4SF)	1	EOR	
2	25	2	H2SO4	lgK:5.1 (2SF)	5	MCT	437

Reaction No. 54524							
$\text{Ba(s)} + \text{Mn(s)} + 2\text{O}_2\text{(g)} = \text{Ba}_2\text{MnO}_4\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-267.5(0.05SD)	5	ENS	802

Reaction No. 54594							
$2\text{Mn}^{2+} + \text{H}_2\text{SiO}_4^{2-} = 2\text{MnO} \cdot \text{SiO}_2\text{(s)} + 4\text{H}^+$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-23.3(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-24.5(0.05SD)	0	ENS	557
3	25	0	Inf. Dilution	lgK:-23.47(4SF)	4	CRV	32224

Reaction No. 54595							
$\text{MnO}_2\text{(beta,s)} + 4\text{H}^+ + 2\text{e}^- = \text{Mn}^{2+} + 2\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:41.9(0.05SD)	2	ENS	557
2	25	0	Inf. Dilution	lgK:41.38(4SF)	3	ENS	6496
3	25	0	Inf. Dilution	lgK:41.55(4SF)	4	CRV	32224
4	25	0	Inf. Dilution	E:1.230(4SF)	5	CRV	7761
5	25	0	Inf. Dilution	E:1.23(3SF)	4	CRV	22551
6	25	0	Inf. Dilution	dH:-65.11(4SF)	4	ENS	6496
7	25	0	Inf. Dilution	dH:-272.4(4SF) kJ	5	CRV	7761

Reaction No. 54596							
$\text{MnO}_{1.9}\text{(gamma,s)} + 3.8\text{H}^+ + 1.8\text{e}^- = \text{Mn}^{2+} + 1.9\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:38.9(0.05SD)	0	ENS	557

Reaction No. 54597							
$\text{MnO}_{1.8}\text{(delta,s)} + 3.6\text{H}^+ + 1.6\text{e}^- = \text{Mn}^{2+} + 1.8\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:35.4(0.05SD)	0	ENS	557

Reaction No. 54598							
$\text{MnOOH(s)} + 3\text{H}^+ + \text{e}^- = \text{Mn}^{2+} + 2\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0	Inf. Dilution	lgK:25.3(0.05SD)	4	ENS	557
2	25	0	Inf. Dilution	lgK:25.34(4SF)	3	ENS	6496
3	25	0	Inf. Dilution	lgK:25.27(4SF)	4	CRV	32224
4	25	0	Inf. Dilution	E:1.48(3SF)	5	CRV	7761
5	25	0	Inf. Dilution	dH:-144.8(4SF)kJ	3	CRV	7761

Reaction No. 54599							
Mn2O3(s) + 6<H+1> + 2<e-1> = 2<Mn+2> + 3<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:49.9(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:51.5(0.05SD)	0	ENS	557
3	25	0	Inf. Dilution	lgK:50.17(4SF)	4	CRV	32224
4	25	0	Inf. Dilution	E:1.485(4SF)	0	CRV	7761
5	25	0	Inf. Dilution	dH:-339.8(4SF)kJ	2	CRV	7761


Reaction No. 54600							
Mn3O4(s) + 8<H+1> + 2<e-1> = 3<Mn+2> + 4<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:60.9(3SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:63.0(0.05SD)	0	ENS	557
3	25	0	Inf. Dilution	lgK:61.03(4SF)	3	ENS	6496
4	25	0	Inf. Dilution	lgK:61.28(4SF)	4	CRV	32224
5	25	0	Inf. Dilution	dH:-100.64(5SF)	3	ENS	6496

Reaction No. 54603							
3<Mn+2> + 2<PO4-3> = Mn+2(3)_PO4-3(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.8(0.05SD)	4	ENS	5458
2	25	0	Inf. Dilution	lgK:22.0(3SF)	0	ENS	5648
3	25	0	Inf. Dilution	lgK:23.83(4SF)	4	CRV	32224
4	25	0	CHEMVAL2	lgK:23.83(0.01SD)	5	ENS	5156
5	25	0	CHEMVAL3	lgK:28.83(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:23.80(0.01SD)	5	ENS	5156
7	25	0	Unknown	dH:-2.1(0.1SD)	4	ENS	766

Reaction No. 54604							
Mn+2 + 2<Cl-1> + 4<H2O> = Mn+2_Cl-1(2)_H2O(4)_(s)							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.68(3SF)	4	CRV	32224
2	25	0	CHEMVAL1	lgK:-2.68(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:-2.68(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:-2.68(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:-2.71(0.01SD)	5	ENS	5156
6	25	0	Unknown	lgK:-2.7(0.05SD)	4	ENS	5458
7	25	0	Unknown	dH:-17.4(0.1SD)	4	ENS	766

Reaction No. 54605




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-5.51(3SF)	4	CRV	32224
2	25	0	CHEMVAL1	lgK:-5.51(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:-5.51(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:-5.51(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:-5.53(0.01SD)	5	ENS	5156
6	25	0	Unknown	lgK:-5.5(0.05SD)	4	ENS	5458

Reaction No. 54606




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-3.96(3SF)	4	CRV	32224
2	25	0	CHEMVAL1	lgK:-3.96(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:-3.96(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:-3.96(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:-3.98(0.01SD)	5	ENS	5156
6	25	0	Unknown	lgK:-4.0(0.05SD)	4	ENS	5458

Reaction No. 54721



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:-28.7(0.05SD)	0	ENS	5468
2	25	0	Inf. Dilution	lgK:-33.0(3SF)	1	ELC	


Reaction No. 55028



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0	Inf. Dilution	lgK:-40.86(4SF)	0	MEF	931
2	25	0	Inf. Dilution	lgK:-39.95(4SF)	4	CRV	32224
3	25	0	Inf. Dilution	dG:54.5(0.1SD)	4	ENS	802
4	25	0	Inf. Dilution	dG:54.50(4SF)	4	CRV	6488
5	25	0	Inf. Dilution	dG:228.1(4SF) kJ	5	CRV	6494
6	25	0	Inf. Dilution	dG:228.1(4SF) kJ	4	ENS	7381
7	25	0	Inf. Dilution	dG:228.1(4SF) kJ	5	CRV	7421
8	25	0	Inf. Dilution	dG:54.500(5SF)	4	CRV	8875
9	25	0	Inf. Dilution	dG:55.100(5SF)	0	CRV	9029
10	25	0	Inf. Dilution	dG:54.50(4SF)	4	CRV	10174
11	25	0	Inf. Dilution	dG:226.8(2.SD) kJ	2	CRV	24493
12	25	0	Inf. Dilution	dG:228.10(5SF) kJ	5	CRV	28172
13	25	0	Inf. Dilution	dG:228.1(4SF) kJ	4	EOD	29025
14	25	0	Inf. Dilution	dG:19.600(5SF)	0	EOD	29489
15	25	0	Inf. Dilution	dG:228.1(4SF) kJ	4	EFE	32152
16	50	0	Inf. Dilution	dG:54.06(4SF)	2	CRV	10174
17	75	0	Inf. Dilution	dG:53.61(4SF)	1	CRV	10174
18	100	0	Inf. Dilution	dG:53.16(4SF)	1	CRV	10174
19	125	0	Inf. Dilution	dG:52.70(4SF)	2	CRV	10174
20	150	0	Inf. Dilution	dG:52.23(4SF)	2	CRV	10174
21	175	0	Inf. Dilution	dG:51.74(4SF)	1	CRV	10174
22	200	0	Inf. Dilution	dG:51.22(4SF)	1	CRV	10174
23	225	0	Inf. Dilution	dG:50.68(4SF)	0	CRV	10174
24	250	0	Inf. Dilution	dG:50.09(4SF)	0	CRV	10174
25	300	0	Inf. Dilution	dG:48.75(4SF)	0	CRV	10174
26	15	0	Inf. Dilution	E:-1.168(4SF)	0	MEF	931
27	25	0	Inf. Dilution	E:-1.185(4SF)	3	CRV	6330
28	25	0	Inf. Dilution	E:-1.18(3SF)	4	ENS	7276
29	25	0	Inf. Dilution	E:-1.18(3SF)	3	CRV	7372
30	25	0	Inf. Dilution	E:-1.18(3SF)	4	ENS	7381
31	25	0	Inf. Dilution	E:-1.182(4SF)	5	CRV	7761
32	25	0	Inf. Dilution	E:-1.18(3SF)	4	CRV	22551
33	25	0	Inf. Dilution	dH:52.8(0.05SD)	4	ENS	802
34	25	0	Inf. Dilution	dH:52.724(5SF)	4	CRV	6488
35	25	0	Inf. Dilution	dH:220.8(4SF) kJ	5	CRV	6494

36	25	0	Inf. Dilution	dH:220.75 (5SF) kJ	4	ENS	7381
37	25	0	Inf. Dilution	dH:220.7 (4SF) kJ	5	CRV	7761
38	25	0	Inf. Dilution	dH:52.724 (5SF)	4	CRV	8875
39	25	0	Inf. Dilution	dH:52.900 (5SF)	4	CRV	9029
40	25	0	Inf. Dilution	dH:221.9 (1.SD) kJ	3	CRV	24493
41	25	0	Inf. Dilution	dH:220.75 (5SF) kJ	5	CRV	28172
42	25	0	Inf. Dilution	dH:220.8 (4SF) kJ	4	EOD	29025
43	25	0	Inf. Dilution	dH:27.000 (5SF)	0	EOD	29489
44	25	0	Inf. Dilution	dH:220.8 (4SF) kJ	4	EFE	32152
45	25	0	GAMSPATH	dH:220.600 (6SF) kJ	3	CRV	12638
46	25	0	Inf. Dilution	Cp:17.2 (3SF) J/K	4	EOD	29025

Reaction No. 55105




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	ClO4-1 salt	lgK:4.8 (0.1SD)	5	MGL	5053

Reaction No. 55106




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	ClO4-1 salt	lgK:4.2 (0.2SD)	3	MGL	5053

Reaction No. 55107




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.6 (2SF)	1	ERG	
2	25	3	ClO4-1 salt	lgK:6.5 (0.1SD)	5	MGL	5053

Reaction No. 55108



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	ClO4-1 salt	lgK:6.7 (0.1SD)	5	MGL	5053


Reaction No. 55167



Note: The species S-2 does not exist in aqueous solution See reaction: $\text{H}^{+1} + \text{S}^{-2} = \text{H}^{+1}_{\text{S}^{-2}}$

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.61(4SF)	0	EOR	
2	25	0	Inf. Dilution	lgK:13.5(3SF)	0	CRV	6405
3	25	0	Inf. Dilution	lgK:14.85(4SF)	0	ENS	7694
4	25	3	NaClO ₄	lgK:14.6(0.1SD)	0	MSL	931


Reaction No. 55169



Note: The species S-2 does not exist in aqueous solution See reaction: $\text{H}^{+1} + \text{S-2} = \text{H}^{+1}\text{S-2}$


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.23(4SF)	0	EOR	
2	25	0	Inf. Dilution	lgK:10.(0.6SD)	0	ENS	140
3	25	0	Inf. Dilution	lgK:15.2(3SF)	0	ENS	5648
4	25	0	Inf. Dilution	lgK:15.25(4SF)	0	CRV	22551

Reaction No. 55217




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:51.1(0.05SD)	4	ENS	557

Reaction No. 55218




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-6.0(0.05SD)	4	ENS	557
2	25	3	(Na)ClO ₄	lgK:-7.6(0.08SD)	6	MGL	5220

Reaction No. 55219



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-18.9(0.05SD)	0	ENS	557


Reaction No. 55220



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:77.17(4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:77.17(4SF)	4	ENS	6494

3	27	0	Inf. Dilution	lgK:76.65 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:76.65 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:55.73 (4SF)	4	ENS	6422
6	127	0	Inf. Dilution	lgK:55.73 (4SF)	4	ENS	6494
7	227	0	Inf. Dilution	lgK:43.21 (4SF)	3	ENS	6422
8	227	0	Inf. Dilution	lgK:43.21 (4SF)	3	ENS	6494
9	327	0	Inf. Dilution	lgK:34.89 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:34.89 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-105.3 (0.05SD)	4	ENS	802
12	25	0	Inf. Dilution	dG:-105.3 (0.05SD)	5	ENS	802
13	25	0	Inf. Dilution	dG:-440.5 (4SF) kJ	3	CRV	6330
14	25	0	Inf. Dilution	dG:-105.3 (4SF)	4	EFE	6422
15	25	0	Inf. Dilution	dG:-105.3 (4SF)	4	EFE	6494
16	25	0	Inf. Dilution	dG:-440.4 (4SF) kJ	4	EOD	29025
17	25	0	Inf. Dilution	dH:-115.0 (0.1SD)	4	ENS	802
18	25	0	Inf. Dilution	dH:-115.0 (0.1SD)	5	ENS	802
19	25	0	Inf. Dilution	dH:-481.3 (4SF) kJ	3	CRV	6330
20	25	0	Inf. Dilution	dH:-115.0 (4SF)	4	MTD	6422
21	25	0	Inf. Dilution	dH:-115.0 (4SF)	4	MTD	6494
22	25	0	Inf. Dilution	dH:-481.3 (4SF) kJ	4	EOD	29025
23	127	0	Inf. Dilution	dH:-114.7 (4SF)	4	MTD	6422
24	127	0	Inf. Dilution	dH:-114.7 (4SF)	4	MTD	6494
25	227	0	Inf. Dilution	dH:-114.4 (4SF)	3	MTD	6422
26	227	0	Inf. Dilution	dH:-114.4 (4SF)	3	MTD	6494
27	327	0	Inf. Dilution	dH:-114.1 (4SF)	0	MTD	6422
28	327	0	Inf. Dilution	dH:-114.1 (4SF)	0	MTD	6494
29	25	0	Inf. Dilution	Cp:72.9 (3SF) J/K	4	EOD	29025


Reaction No. 55233



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:224.8 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:224.7 (4SF)	3	ENS	6494
3	27	0	Inf. Dilution	lgK:223.3 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:223.2 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:162.9 (4SF)	2	ENS	6422


6	127	0	Inf. Dilution	lgK:162.9(4SF)	2	ENS	6494
7	227	0	Inf. Dilution	lgK:126.7(4SF)	1	ENS	6422
8	227	0	Inf. Dilution	lgK:126.8(4SF)	1	ENS	6494
9	327	0	Inf. Dilution	lgK:102.6(4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:102.8(4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-306.7(0.05SD)	4	ENS	802
12	25	0	Inf. Dilution	dG:-306.7(0.05SD)	5	ENS	802
13	25	0	Inf. Dilution	dG:-306.7(4SF)	4	EFE	6422
14	25	0	Inf. Dilution	dG:-306.5(4SF)	2	EFE	6494
15	25	0	Inf. Dilution	dG:-306.73(5SF)	3	CRV	31291
16	25	0	Inf. Dilution	dH:-331.7(0.1SD)	4	ENS	802
17	25	0	Inf. Dilution	dH:-331.7(0.1SD)	5	ENS	802
18	25	0	Inf. Dilution	dH:-331.7(4SF)	4	MTD	6422
19	25	0	Inf. Dilution	dH:-330.9(4SF)	2	MTD	6494
20	25	0	Inf. Dilution	dH:-331.70(5SF)	3	CRV	31291
21	127	0	Inf. Dilution	dH:-331.5(4SF)	1	MTD	6422
22	127	0	Inf. Dilution	dH:-330.6(4SF)	1	MTD	6494
23	227	0	Inf. Dilution	dH:-331.3(4SF)	0	MTD	6422
24	227	0	Inf. Dilution	dH:-330.3(4SF)	0	MTD	6494
25	327	0	Inf. Dilution	dH:-331.0(4SF)	0	MTD	6422
26	327	0	Inf. Dilution	dH:-330.1(4SF)	0	MTD	6494

Reaction No. 55234



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-166.4(0.05SD)	5	ENS	802
2	25	0	Inf. Dilution	dG:-696.2(4SF) kJ	4	EOD	29025
3	25	0	Inf. Dilution	dH:-188.8(0.1SD)	5	ENS	802
4	25	0	Inf. Dilution	dH:-789.9(4SF) kJ	4	EOD	29025
5	25	0	Inf. Dilution	Cp:114.6(4SF) J/K	4	EOD	29025

Reaction No. 55235



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-225.2(0.05SD)	5	ENS	802
2	25	0	Inf. Dilution	dG:-942.2(4SF) kJ	4	EOD	29025

3	25	0	Inf. Dilution	dH:-261.0 (0.1SD)	5	ENS	802
4	25	0	Inf. Dilution	dH:-1092.0 (5SF) kJ	4	EOD	29025
5	25	0	Inf. Dilution	Cp:156.3 (4SF) J/K	4	EOD	29025


Reaction No. 55236							
$\text{Cl}_2(\text{g}) + 4\text{H}_2(\text{g}) + \text{Mn}(\text{s}) + 2\text{O}_2(\text{g}) = \text{Mn} + 2\text{Cl} + 1(2)\text{H}_2\text{O}(4)\text{_(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-340.3 (0.05SD)	5	ENS	802
2	25	0	Inf. Dilution	dG:-1423.8 (5SF) kJ	4	EOD	29025
3	25	0	Inf. Dilution	dH:-403.3 (0.1SD)	5	ENS	802
4	25	0	Inf. Dilution	dH:-1687.4 (5SF) kJ	4	EOD	29025
5	25	0	Inf. Dilution	Cp:239.8 (4SF) J/K	4	EOD	29025

Reaction No. 55237							
$\text{Mn}(\text{s}) + 2\text{O}_2(\text{g}) + \text{S}(\text{s}) = \text{Mn} + 2\text{SO}_4 - 2$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:172.6 (4SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-236.1 (0.1SD)	0	ENS	557
Note (2): Low Wgt for internal consistency							
3	25	0	Inf. Dilution	dG:-235.64 (5SF)	0	CRV	10174
4	25	0	GAMSPATH	dG:-985.5 (4SF) kJ	0	CRV	12638
5	50	0	Inf. Dilution	dG:-235.75 (5SF)	0	CRV	10174
6	75	0	Inf. Dilution	dG:-235.82 (5SF)	0	CRV	10174
7	100	0	Inf. Dilution	dG:-235.88 (5SF)	0	CRV	10174
8	125	0	Inf. Dilution	dG:-235.92 (5SF)	0	CRV	10174
9	150	0	Inf. Dilution	dG:-235.94 (5SF)	0	CRV	10174
10	175	0	Inf. Dilution	dG:-235.96 (5SF)	0	CRV	10174
11	200	0	Inf. Dilution	dG:-235.96 (5SF)	0	CRV	10174
12	225	0	Inf. Dilution	dG:-235.95 (5SF)	0	CRV	10174
13	250	0	Inf. Dilution	dG:-235.94 (5SF)	0	CRV	10174
14	300	0	Inf. Dilution	dG:-235.89 (5SF)	0	CRV	10174
15	25	0	Inf. Dilution	dH:-270.1 (0.1SD)	3	ENS	802
16	25	0	GAMSPATH	dH:-1121.00 (6SF) kJ	3	CRV	12638

Reaction No. 55238							
$\text{Mn}(\text{s}) + 2\text{O}_2(\text{g}) + \text{S}(\text{s}) = \text{Mn} + 2\text{SO}_4 - 2\text{_(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:167.7 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:168.6 (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:166.6 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:167.4 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:120.2 (4SF)	3	ENS	6422
6	127	0	Inf. Dilution	lgK:121.0 (4SF)	3	ENS	6494
7	227	0	Inf. Dilution	lgK:92.28 (4SF)	2	ENS	6422
8	227	0	Inf. Dilution	lgK:93.10 (4SF)	1	ENS	6494
9	327	0	Inf. Dilution	lgK:73.69 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:74.49 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-228.8 (4SF)	0	ENS	802
12	25	0	Inf. Dilution	dG:-228.8 (4SF)	4	EFE	6422
13	25	0	Inf. Dilution	dG:-229.9 (4SF)	4	EFE	6494
14	25	0	Inf. Dilution	dG:-957.3 (4SF) kJ	4	EOD	29025
15	25	0	Inf. Dilution	dH:-254.6 (0.1SD)	5	ENS	802
16	25	0	Inf. Dilution	dH:-254.6 (4SF)	4	MTD	6422
17	25	0	Inf. Dilution	dH:-254.7 (4SF)	4	MTD	6494
18	25	0	Inf. Dilution	dH:-1065.3 (5SF) kJ	4	EOD	29025
19	127	0	Inf. Dilution	dH:-255.1 (4SF)	2	MTD	6422
20	127	0	Inf. Dilution	dH:-255.2 (4SF)	2	MTD	6494
21	227	0	Inf. Dilution	dH:-255.2 (4SF)	1	MTD	6422
22	227	0	Inf. Dilution	dH:-255.4 (4SF)	1	MTD	6494
23	327	0	Inf. Dilution	dH:-255.2 (4SF)	0	MTD	6422
24	327	0	Inf. Dilution	dH:-255.3 (4SF)	0	MTD	6494
25	25	0	Inf. Dilution	Cp:100.4 (4SF) J/K	4	EOD	29025

Reaction No. 55239



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:244.5 (4SF)	1	ERG	
2	25	0	Inf. Dilution	dG:-332.5 (0.1SD)	1	ENS	802

Reaction No. 55240




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:217.3 (4SF)	4	ENS	6422

2	25	0	Inf. Dilution	lgK:218.1(4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:215.9(4SF)	4	ENS	6422
4	27	0	Inf. Dilution	lgK:216.6(4SF)	4	ENS	6494
5	127	0	Inf. Dilution	lgK:158.4(4SF)	4	ENS	6422
6	127	0	Inf. Dilution	lgK:159.1(4SF)	4	ENS	6494
7	227	0	Inf. Dilution	lgK:123.9(4SF)	4	ENS	6422
8	227	0	Inf. Dilution	lgK:124.6(4SF)	4	ENS	6494
9	327	0	Inf. Dilution	lgK:101.0(4SF)	4	ENS	6422
10	327	0	Inf. Dilution	lgK:101.6(4SF)	4	ENS	6494
11	25	0	Inf. Dilution	dG:-296.5(0.1SD)	4	ENS	802
12	25	0	Inf. Dilution	dG:-296.5(0.1SD)	5	ENS	802
13	25	0	Inf. Dilution	dG:-296.5(4SF)	4	EFE	6422
14	25	0	Inf. Dilution	dG:-297.5(4SF)	4	EFE	6494
15	25	0	Inf. Dilution	dH:-315.7(0.1SD)	4	ENS	802
16	25	0	Inf. Dilution	dH:-315.7(0.1SD)	5	ENS	802
17	25	0	Inf. Dilution	dH:-315.7(4SF)	4	MTD	6422
18	25	0	Inf. Dilution	dH:-315.9(4SF)	4	MTD	6494
19	127	0	Inf. Dilution	dH:-315.7(4SF)	4	MTD	6422
20	127	0	Inf. Dilution	dH:-315.8(4SF)	4	MTD	6494
21	227	0	Inf. Dilution	dH:-315.5(4SF)	4	MTD	6422
22	227	0	Inf. Dilution	dH:-315.6(4SF)	4	MTD	6494
23	327	0	Inf. Dilution	dH:-315.3(4SF)	4	MTD	6422
24	327	0	Inf. Dilution	dH:-315.4(4SF)	4	MTD	6494

Reaction No. 55241							
2<Mn(s)> + Si(s) + 2<O2(g)> = 2MnO.SiO2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:285.9(4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:285.7(4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:284.1(4SF)	4	ENS	6422
4	27	0	Inf. Dilution	lgK:283.9(4SF)	4	ENS	6494
5	127	0	Inf. Dilution	lgK:208.8(4SF)	4	ENS	6422
6	127	0	Inf. Dilution	lgK:208.5(4SF)	4	ENS	6494
7	227	0	Inf. Dilution	lgK:163.6(4SF)	4	ENS	6422
8	227	0	Inf. Dilution	lgK:163.3(4SF)	4	ENS	6494
9	327	0	Inf. Dilution	lgK:133.5(4SF)	4	ENS	6422


10	327	0	Inf. Dilution	lgK:133.2(4SF)	4	ENS	6494
11	25	0	Inf. Dilution	dG:-390.1(0.1SD)	4	ENS	802
12	25	0	Inf. Dilution	dG:-390.1(0.1SD)	5	ENS	802
13	25	0	Inf. Dilution	dG:-390.1(4SF)	4	EFE	6422
14	25	0	Inf. Dilution	dG:-389.8(4SF)	4	EFE	6494
15	25	0	Inf. Dilution	dH:-413.6(0.1SD)	4	ENS	802
16	25	0	Inf. Dilution	dH:-413.6(0.1SD)	5	ENS	802
17	25	0	Inf. Dilution	dH:-413.6(4SF)	4	MTD	6422
18	25	0	Inf. Dilution	dH:-413.8(4SF)	4	MTD	6494
19	127	0	Inf. Dilution	dH:-413.5(4SF)	4	MTD	6422
20	127	0	Inf. Dilution	dH:-413.8(4SF)	4	MTD	6494
21	227	0	Inf. Dilution	dH:-413.3(4SF)	4	MTD	6422
22	227	0	Inf. Dilution	dH:-413.6(4SF)	4	MTD	6494
23	327	0	Inf. Dilution	dH:-413.0(4SF)	4	MTD	6422
24	327	0	Inf. Dilution	dH:-413.4(4SF)	4	MTD	6494

Reaction No. 55298




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.00(0.05SD)	4	MEF	5070

Reaction No. 55347



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	0	Inf. Dilution	lgK:6.51(3SF)	4	MSL	2358
2	25	0	Inf. Dilution	lgK:6.51(3SF)	2	EAE	

Reaction No. 55458



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:64.06(4SF)	1	ELC	
2	25.4	1	KCN	dH:-34.50(0.02SD)	6	MCL	5125


Reaction No. 55459



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18	0:0.2	Unknown	lgK:9.7(0.1SD)	0	MAN	140


2	25	0	Inf. Dilution	lgK:-65.7 (3SF)	1	ELC	
---	----	---	---------------	-----------------	---	-----	--

Reaction No. 55508




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:196.9 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:195.6 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:142.2 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:110.3 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:96.63 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-268. (1.SD)	4	ENT	5182
7	25	0	Inf. Dilution	dG:-268.6 (4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dH:-293. (1.SD)	4	ENT	5182
9	25	0	Inf. Dilution	dH:-293.0 (4SF)	4	MTD	6422
10	127	0	Inf. Dilution	dH:-292.5 (4SF)	4	MTD	6422
11	227	0	Inf. Dilution	dH:-291.9 (4SF)	4	MTD	6422
12	327	0	Inf. Dilution	dH:-291.5 (4SF)	4	MTD	6422
13	25	0	Inf. Dilution	dS:0.036 (0.001SD)	4	ENS	5182

Reaction No. 55511




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:691.1 (4SF)	4	ENS	6494
2	27	0	Inf. Dilution	lgK:686.5 (4SF)	0	ENS	6494
3	127	0	Inf. Dilution	lgK:501.1 (4SF)	2	ENS	6494
4	227	0	Inf. Dilution	lgK:389.9 (4SF)	1	ENS	6494
5	327	0	Inf. Dilution	lgK:315.9 (4SF)	0	ENS	6494
6	25	0	Inf. Dilution	dG:-940. (5.SD)	0	ENT	5182
7	25	0	Inf. Dilution	dG:-942.8 (4SF)	4	EFE	6494
8	25	0	Inf. Dilution	dH:-1010. (5.SD)	4	ENT	5182
9	25	0	Inf. Dilution	dH:-1018. (4SF)	0	MTD	6494
10	127	0	Inf. Dilution	dH:-1018. (4SF)	1	MTD	6494
11	227	0	Inf. Dilution	dH:-1017. (4SF)	0	MTD	6494
12	327	0	Inf. Dilution	dH:-1016. (4SF)	0	MTD	6494

Reaction No. 55630




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-575.69(0.2SD)kJ	3	ENS	5138

Reaction No. 55817



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-34.20(4SF)	4	CRV	9402
2	25	0	Inf. Dilution	lgK:-34.18(4SF)	4	CRV	32224
3	25	0	CHEMVAL1	lgK:-34.18(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL2	lgK:-34.18(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL3	lgK:-34.18(0.01SD)	0	ENS	5156
6	25	0	CHEMVAL4	lgK:-34.80(0.01SD)	4	ENS	5156
7	25	0	UCT_Sea	lgK:-34.80(0.01SD)	3	EDH	5390
8	25	0.1	UCT_Sea	lgK:-34.81(0.01SD)	2	EDH	5390
9	25	0.2	UCT_Sea	lgK:-34.82(0.01SD)	0	EDH	5390
10	25	0.3	UCT_Sea	lgK:-34.84(0.01SD)	0	EDH	5390
11	25	0.4	UCT_Sea	lgK:-34.86(0.01SD)	0	EDH	5390
12	25	0.5	UCT_Sea	lgK:-34.88(0.01SD)	0	EDH	5390
13	25	0.6	UCT_Sea	lgK:-34.90(0.01SD)	2	EDH	5390
14	25	0.7	UCT_Sea	lgK:-34.92(0.01SD)	3	EDH	5390

Reaction No. 55818



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-48.28(4SF)	4	CRV	32224
2	25	0	CHEMVAL1	lgK:-48.30(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:-48.30(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:-48.30(0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:-48.30(0.01SD)	4	ENS	5156
6	25	0	UCT_Sea	lgK:-48.30(0.01SD)	3	EDH	5390
7	25	0.1	UCT_Sea	lgK:-47.85(0.01SD)	2	EDH	5390
8	25	0.2	UCT_Sea	lgK:-47.74(0.01SD)	0	EDH	5390
9	25	0.3	UCT_Sea	lgK:-47.68(0.01SD)	0	EDH	5390
10	25	0.4	UCT_Sea	lgK:-47.64(0.01SD)	0	EDH	5390
11	25	0.5	UCT_Sea	lgK:-47.62(0.01SD)	0	EDH	5390
12	25	0.6	UCT_Sea	lgK:-47.62(0.01SD)	2	EDH	5390

13	25	0.7	UCT_Sea	lgK:-47.61(0.01SD)	3	EDH	5390
----	----	-----	---------	--------------------	---	-----	------

Reaction No. 56055							
$\text{Mn}^{+2} + 9\langle\text{H}^{+1}\rangle + \text{NO}_3^{-1} + 8\langle\text{e}^{-1}\rangle = \text{Mn}^{+2}_{\text{NH}_3} + 3\langle\text{H}_2\text{O}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL4	lgK:111.00(0.01SD)	4	ENS	5156

Reaction No. 56056							
$\text{Mn}^{+2} + 2\langle\text{NO}_3^{-1}\rangle + 18\langle\text{H}^{+1}\rangle + 16\langle\text{e}^{-1}\rangle = \text{Mn}^{+2}_{\text{NH}_3(2)} + 6\langle\text{H}_2\text{O}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL4	lgK:221.00(0.01SD)	4	ENS	5156

Reaction No. 56057							
$\text{Mn}^{+2} + 3\langle\text{NO}_3^{-1}\rangle + 27\langle\text{H}^{+1}\rangle + 24\langle\text{e}^{-1}\rangle = \text{Mn}^{+2}_{\text{NH}_3(3)} + 9\langle\text{H}_2\text{O}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL4	lgK:331.00(0.01SD)	4	ENS	5156

Reaction No. 56058							
$\text{Mn}^{+2} + 4\langle\text{NO}_3^{-1}\rangle + 36\langle\text{H}^{+1}\rangle + 32\langle\text{e}^{-1}\rangle = \text{Mn}^{+2}_{\text{NH}_3(4)} + 12\langle\text{H}_2\text{O}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:441.3(4SF)	1	ELC	
2	25	0	CHEMVAL4	lgK:441.00(0.01SD)	0	ENS	5156


Reaction No. 56093							
$\text{Fe}^{+3}(2)_{\text{Mn}^{+2}_{\text{OH}^{-1}(2)}_{\text{PO}_4^{-3}(2)}_{\text{H}_2\text{O}(8)}(s)} + 2\langle\text{H}^{+1}\rangle + 2\langle\text{e}^{-1}\rangle = \text{Mn}^{+2} + 2\langle\text{Fe}^{+2}\rangle + 2\langle\text{PO}_4^{-3}\rangle + 10\langle\text{H}_2\text{O}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-27.34(4SF)	4	CRV	32224
2	25	0	CHEMVAL2	lgK:-14.33(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:-14.33(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:-27.30(0.01SD)	3	ENS	5156

Reaction No. 56277							
$\text{Mn}^{+2}_{\text{OH}^{-1}(2)}(s) + 2\langle\text{H}^{+1}\rangle = \text{Mn}^{+2} + 2\langle\text{H}_2\text{O}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.30(0.01SD)	5	ENS	5156
2	25	0	Inf. Dilution	lgK:15.2(3SF)	3	CRV	6478
Note (2): < 15.2							

3	25	0	Inf. Dilution	lgK:15.2 (3SF)	3	ENS	6496
4	25	0	Inf. Dilution	lgK:15.20 (4SF)	4	CRV	9402
5	25	0	Inf. Dilution	lgK:15.09 (4SF)	2	CRV	32224
6	25	0	CHEMVAL1	lgK:15.09 (0.01SD)	0	ENS	5156
7	25	0	CHEMVAL2	lgK:15.09 (0.01SD)	0	ENS	5156
8	25	0	CHEMVAL3	lgK:15.09 (0.01SD)	0	ENS	5156
9	25	0	CHEMVAL4	lgK:15.30 (0.01SD)	4	ENS	5156
10	25	0	Inf. Dilution	dH:-22.6 (0.05SD)	4	ENS	766
11	25	0	Inf. Dilution	dH:-23.1 (3SF)	3	CRV	6478


Note (11): > -23.1

Reaction No. 56278




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.77 (3SF)	4	CRV	32224
2	25	0	CHEMVAL1	lgK:2.68 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL2	lgK:2.68 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL3	lgK:2.68 (0.01SD)	0	ENS	5156
5	25	0	CHEMVAL4	lgK:8.77 (0.01SD)	4	ENS	5156

Reaction No. 56281



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-25.27 (4SF)	4	CRV	32224
2	25	0	CHEMVAL2	lgK:-25.27 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:-25.27 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:-25.30 (0.01SD)	4	ENS	5156

Reaction No. 56282



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:-0.24 (0.01SD)	0	ENS	5156
2	25	0	CHEMVAL2	lgK:-0.24 (0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:-0.24 (0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:-0.24 (0.01SD)	0	ENS	5156

Reaction No. 56283

Mn2O3(s) + 6<H+1> = 2<Mn+3> + 3<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:-0.85(0.01SD)	0	ENS	5156
2	25	0	CHEMVAL2	lgK:-0.85(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:-0.85(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:-0.85(0.01SD)	0	ENS	5156

Reaction No. 56284							
Mn+3_OH-1(3)_(s) + 3<H+1> = Mn+3 + 3<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:6.33(0.01SD)	4	ENS	5156
2	25	0	CHEMVAL2	lgK:6.33(0.01SD)	4	ENS	5156
3	25	0	CHEMVAL3	lgK:6.33(0.01SD)	4	ENS	5156
4	25	0	CHEMVAL4	lgK:6.33(0.01SD)	4	ENS	5156


Reaction No. 56285							
Mn3O4(s) + 8<H+1> = 2<Mn+3> + Mn+2 + 4<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	CHEMVAL1	lgK:0.26(0.01SD)	0	ENS	5156
2	25	0	CHEMVAL2	lgK:10.26(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:10.26(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:10.30(0.01SD)	0	ENS	5156

Reaction No. 56286							
Mn+2(3)_PO4-3(2)_H2O(3)_(s) = 3<Mn+2> + 2<PO4-3> + 3<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-36.84(4SF)	4	CRV	32224
2	25	0	CHEMVAL2	lgK:-36.84(0.01SD)	0	ENS	5156
3	25	0	CHEMVAL3	lgK:-36.84(0.01SD)	0	ENS	5156
4	25	0	CHEMVAL4	lgK:-36.80(0.01SD)	4	ENS	5156

Reaction No. 56699							
Mn(s) + 3<O2(g)> + 2<V(s)> = Mn+2_VO3-1(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-442.0(0.05SD)	4	ENS	3006
2	25	0	Inf. Dilution	dG:-441.9(4SF)	5	CRV	22971
3	25	0	Inf. Dilution	dH:-478.0(0.1SD)	4	ENS	3006


4	25	0	Inf. Dilution	dH:-477.9 (4SF)	5	CRV	22971
---	----	---	---------------	-----------------	---	-----	-------

Reaction No. 56757



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-4.90 (0.01SD)	4	ENS	766
2	25	0	Inf. Dilution	dH:22.10 (0.01SD)	4	ENS	766

Reaction No. 56780



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:63.58 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:63.58 (4SF)	4	MTD	6494
3	27	0	Inf. Dilution	lgK:63.16 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:63.16 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:46.40 (4SF)	2	ENS	6422
6	127	0	Inf. Dilution	lgK:46.40 (4SF)	2	ENS	6494
7	227	0	Inf. Dilution	lgK:36.35 (4SF)	2	ENS	6422
8	227	0	Inf. Dilution	lgK:36.35 (4SF)	2	ENS	6494
9	327	0	Inf. Dilution	lgK:29.66 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:29.66 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-362.90 (0.01SD) kJ	4	ENS	5138
12	25	0	Inf. Dilution	dG:-86.73 (4SF)	4	EFE	6422
13	25	0	Inf. Dilution	dG:-86.74 (4SF)	4	EFE	6494
14	25	0	Inf. Dilution	dG:-86.74 (4SF)	3	CRV	31291
15	25	0	GAMSPATH	dG:-362.9 (4SF) kJ	3	CRV	12638
16	25	0	Inf. Dilution	dH:-385.22 (0.01SD) kJ	4	ENS	5138
17	25	0	Inf. Dilution	dH:-92.1 (3SF)	3	MTD	6422
18	25	0	Inf. Dilution	dH:-92.07 (4SF)	4	MTD	6494
19	25	0	Inf. Dilution	dH:-92.07 (4SF)	3	CRV	31291
20	25	0	GAMSPATH	dH:-385.220 (6SF) kJ	3	CRV	12638
21	127	0	Inf. Dilution	dH:-92.0 (3SF)	1	MTD	6422
22	127	0	Inf. Dilution	dH:-92.00 (4SF)	1	MTD	6494
23	227	0	Inf. Dilution	dH:-91.9 (3SF)	0	MTD	6422
24	227	0	Inf. Dilution	dH:-91.90 (4SF)	0	MTD	6494
25	327	0	Inf. Dilution	dH:-91.8 (3SF)	0	MTD	6422

26	327	0	Inf. Dilution	dH:-91.85 (4SF)	0	MTD	6494
27	25	0	Inf. Dilution	Cp:45.44 (0.1SD) J/K	4	ENS	5138

Reaction No. 56781							
$0.5\text{H}_2(\text{g}) + \text{Mn}(\text{s}) + 0.5\text{O}_2(\text{g}) - \text{e}^- = \text{Mn}^{2+}_{\text{OH}-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:70.8 (3SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-405.0 (0.1SD) kJ	2	ENS	5138
3	25	0	Inf. Dilution	dG:-405.0 (4SF) kJ	4	EOD	29025
4	25	0	Inf. Dilution	dH:-450.6 (0.1SD) kJ	2	ENS	5138

Reaction No. 56782							
$\text{Mn}(\text{s}) + 1.5\text{O}_2(\text{g}) + 1.5\text{H}_2(\text{g}) = \text{Mn}^{2+}_{\text{OH}-1(3)} - \text{e}^-$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:129.9 (4SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-740.9 (1.SD) kJ	0	ENS	5138

Reaction No. 56783							
$\text{Mn}(\text{s}) + 2\text{O}_2(\text{g}) + 2\text{H}_2(\text{g}) = \text{Mn}^{2+}_{\text{OH}-1(4)} - 2\text{e}^-$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:157.3 (4SF)	1	EOR	
2	25	0	Inf. Dilution	dG:-901.01 (0.1SD) kJ	3	ENS	5138

Reaction No. 57046							
$\text{H}_2(\text{g}) + \text{Mn}(\text{s}) + \text{O}_2(\text{g}) = \text{Mn}^{2+}_{\text{OH}-1(2)}_{\text{(s)}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:107.8 (4SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-147.8 (0.05SD)	0	ENS	557
3	25	0	Inf. Dilution	dG:-610.4 (4SF) kJ	0	EOD	29025
4	25	0	Inf. Dilution	dH:-693.7 (4SF) kJ	3	EOD	29025

Reaction No. 57178							
$\text{CO}_2(\text{g}) + \text{Mn}^{2+} + \text{H}_2\text{O} = \text{Mn}^{2+}_{\text{CO}_3-2}_{\text{(s)}} + 2\text{H}^+$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-7.9 (2SF)	1	EOR	
2	25	3	NaClO ₄	lgK:-8.0 (0.04SD)	6	MGL	414
3	50	1	NaClO ₄ /m	lgK:-7.36 (0.06SD)	6	MGL	5530

Reaction No. 57188							
S2O3-2 + Mn+2 = Mn+2_S2O3-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.95 (3SF)	4	MSL	140
2	25	0	Inf. Dilution	lgK:1.9 (0.04SD)	5	MPT	140
3	25	0	Inf. Dilution	lgK:1.951 (4SF)	4	EOD	12002
4	25	0	Inf. Dilution	lgK:1.95 (3SF)	4	CRV	18273
Note (4): Table 3, p. 85							
5	25	0.5	NO3-1 salt	lgK:0.67 (0.01SD)	6	MCL	4609
6	25	0.5	NO3-1 salt	dH:0.5 (0.05SD)	6	CMN	4609

Reaction No. 57377							
Mn(s) = Mn(gamma,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:0.34 (0.01SD)	6	ENS	802
2	25	0	Inf. Dilution	dH:0.37 (0.01SD)	6	ENS	802

Reaction No. 57378							
Mn(s) = Mn(g)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:57.0 (0.1SD)	5	ENS	802
2	25	0	Inf. Dilution	dG:238.5 (4SF) kJ	4	ENS	7381
3	25	0	Inf. Dilution	dH:67.1 (0.1SD)	5	ENS	802
4	25	0	Inf. Dilution	dH:280.7 (4SF) kJ	4	ENS	7381

Reaction No. 57519							
Mn+2 + CN-1 = Mn+2_CN-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.479 (4SF)	1	EOR	
2	25	1	NaClO4	lgK:1.88 (0.1SD)	5	MGL	5298

Reaction No. 57520							
Mn+2 + 2<CN-1> = Mn+2_CN-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.258 (4SF)	1	EOR	
2	25	1	NaClO4	lgK:3.36 (0.1SD)	5	MGL	5298

Reaction No. 57649							
$\text{Mn}^{+2} + \text{OH}^{-1} + \text{H}^{+1}\text{Se}^{-2} = \text{Mn}^{+2}\text{Se}^{-2} + \text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:8.0(0.2SD)	6	MSL	5554

Reaction No. 57650							
$\text{Mn}^{+2}\text{Se}^{-2}(\text{s}) = \text{Mn}^{+2} + \text{Se}^{-2}$							
Note: The Se-2 species probably does not exist [18Mar_30641]							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-11.5(0.03SD)	2	CMN	5174
2	25	0	Inf. Dilution	lgK:-11.5(3SF)	2	ENS	12931
3	25	1	NaClO4	lgK:-12.10(0.31SD)	2	MSL	5554


Reaction No. 57675							
$\text{Mn}^{+2}\text{SeO}_3^{-2}(\text{s}) = \text{Mn}^{+2} + \text{SeO}_3^{-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:-7.3(0.05SD)	4	MSL	931
2	20			lgK:-6.9(0.2SD)	0	MSL	12931
3	25	0	Inf. Dilution	lgK:-7.11(0.31SD)	4	MSL	12931
4	25	0	Inf. Dilution	lgK:-7.11(0.31SD)	3	EOD	32222

Reaction No. 57741							
$\text{OH}^{-1} + \text{Mn}^{+3} = \text{Mn}^{+3}\text{OH}^{-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.8(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:14.8(3SF)	1	EOR	
3	25	1	NaNO3	lgK:12.5(0.1SD)	0	ENS	2261
4	25	3	Unknown	lgK:14.6(3SF)	3	CRV	2556
5	25	3	Unknown	lgK:14.9(3SF)	5	CRV	2556
6	25	4	Unknown	lgK:14.4(3SF)	0	CRV	2556
7	0:40	4	Unknown	dH:-8.(1SF)	4	CRV	2556

Reaction No. 57742							
$2\langle\text{OH}^{-1}\rangle + \text{Mn}^{+3} = \text{Mn}^{+3}\text{OH}^{-1}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:28.6(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:28.6(3SF)	1	EOR	

3	25	1	NaNO3	lgK:24.0 (0.1SD)	0	ENS	2261
4	25	3	Unknown	lgK:28.5 (3SF)	3	CRV	2556


Reaction No. 57743



Note: Very strongly formed under oxidizing conditions but appears nowhere else it seems; therefore species is rejected. PMM 8/6/12


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaNO3	lgK:35.6 (0.1SD)	0	ENS	2261

Reaction No. 58144




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:3.85 (0.07SD)	0	MGL	1275
2	25	0	Inf. Dilution	lgK:3.9 (2SF)	1	ESC	
3	25	0.1	KNO3	lgK:3.75 (0.07SD)	0	MGL	1275
4	35	0.1	KNO3	lgK:3.66 (0.07SD)	0	MGL	1275
5	45	0.1	KNO3	lgK:3.61 (0.07SD)	0	MGL	1275
6	25	0.1	KNO3	dH:-14.1 (3SF) kJ	0	MTD	1275

Reaction No. 58155



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:3.70 (0.07SD)	5	MGL	1275
2	25	0.1	KNO3	lgK:3.67 (0.07SD)	5	MGL	1275
3	35	0.1	KNO3	lgK:3.62 (0.07SD)	5	MGL	1275
4	45	0.1	KNO3	lgK:3.59 (0.07SD)	5	MGL	1275
5	25	0.1	KNO3	dH:-6.6 (2SF) kJ	5	MTD	1275

Reaction No. 58171



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	UCT_Sea	lgK:-22.20 (0.01SD)	4	EDH	5390
2	25	0.1	UCT_Sea	lgK:-22.42 (0.01SD)	4	EDH	5390
3	25	0.2	UCT_Sea	lgK:-22.46 (0.01SD)	4	EDH	5390
4	25	0.3	UCT_Sea	lgK:-22.50 (0.01SD)	4	EDH	5390
5	25	0.4	UCT_Sea	lgK:-22.53 (0.01SD)	4	EDH	5390

6	25	0.5	UCT_Sea	lgK:-22.56(0.01SD)	4	EDH	5390
7	25	0.6	UCT_Sea	lgK:-22.58(0.01SD)	4	EDH	5390
8	25	0.7	UCT_Sea	lgK:-22.60(0.01SD)	4	EDH	5390

Reaction No. 58173							
Mn+2_Uridine-1 + Bipy = Mn+2_Bipy_Uridine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	0.1	KNO3	lgK:3.54(0.07SD)	5	MGL	1275
2	25	0.1	KNO3	lgK:3.49(0.07SD)	5	MGL	1275
3	35	0.1	KNO3	lgK:3.43(0.07SD)	5	MGL	1275
4	45	0.1	KNO3	lgK:3.39(0.07SD)	5	MGL	1275
5	25	0.1	KNO3	dH:-8.9(2SF) kJ	5	MTD	1275

Reaction No. 58203							
2<Mn+2> + SiH2O4-2 = 2MnO.SiO2(s) + 2<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.5(1SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:10.70(4SF)	0	CRV	9402
Note (2): Low wgt for inter-reaction consistency							


Reaction No. 58206							
3<NO3-1> + Mn+2 = Mn+2_NO3-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	2	LiClO4	lgK:-1.30(3SF)	2	MSL	5014
2	25	4	LiClO4	lgK:-1.15(3SF)	2	MSL	5014

Reaction No. 58303							
Mn+2_Oxalic-2_(s) = Mn+2 + Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-15.0(3SF)	3	ENS	5648

Reaction No. 58320							
Mn+2_Trp-1 + Trp-1 = Mn+2_Trp-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.45(3SF)	5	MGL	11516
Note (1): Manorik P et al., Zhur. Neorg. Khim., 1988, 33, 977							
2	25	3	NaClO4	lgK:2.31(3SF)	5	MGL	2157


3	25	3	NaClO ₄	dH:-2.5 (2SF)	4	MCL	904
---	----	---	--------------------	---------------	---	-----	-----

Reaction No. 58439




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.57 (3SF)	4	MCN	140

Reaction No. 58534




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:-4.4 (2SF)	0	MSP	140

Reaction No. 58553




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.9 (2SF)	1	ELC	
2	25.2	2	HClO ₄	lgR:2.51 (3SF)	3	MKN	140

Reaction No. 58604




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	Pr4NC1	lgK:2.041 (4SF)	4	MGL	257

Reaction No. 58663



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Methanol:Water 95:5Vol Et4NC1O4	lgK:3.9 (2SF)	3	MGL	4870

Reaction No. 58664



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Methanol:Water 95:5Vol Et4NC1O4	lgK:3.9 (2SF)	3	MGL	4870
2	25	0.1	Methanol:Water 95:5Vol Et4NC1O4	dH:10.75 (4SF) kJ	4	MCL	4870

Reaction No. 58690							
$\text{Mn}^{+2} + \text{H}^{+1}_{\text{Hex16DiPhos-4}} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{Hex16DiPhos-4}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.82 (3SF)	4	MGL	931

Reaction No. 58691							
$2\langle\text{Mn}^{+2}\rangle + \text{Hex16DiPhos-4} = \text{Mn}^{+2}_{(2)}_{\text{Hex16DiPhos-4}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:12.51 (4SF)	4	MGL	931

Reaction No. 58692							
$2\langle\text{Mn}^{+2}\rangle + \text{H}^{+1}_{\text{Hex16DiPhos-4}} = \text{Mn}^{+2}_{(2)}_{\text{H}^{+1}_{\text{Hex16DiPhos-4}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:9.62 (3SF)	4	MGL	931

Reaction No. 58710							
$\text{Mn}^{+2}_{\text{Arg-1}} + \text{Arg-1} = \text{Mn}^{+2}_{\text{Arg-1}(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	-15	0.5	HClO ₄	lgK:0.1 (0.3SD)	0	MIX	6000
2	25			lgK:1.94 (3SF)	0	MGL	140
3	40			lgK:1.90 (3SF)	0	MGL	140


Reaction No. 58727							
$\text{Bipy} + \text{Mn}^{+2} + 5\text{ATP-4} = \text{Mn}^{+2}_{\text{Bipy}_5\text{ATP-4}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO ₄	lgK:7.3 (0.04SD)w	5	MPH	125

Reaction No. 58853							
$[\text{14}]\text{N2O3:MeCOO}^{*2-2} + \text{Mn}^{+2} = \text{Mn}^{+2}_{[\text{14}]\text{N2O3:MeCOO}^{*2-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me ₄ NNO ₃	lgK:12.11 (0.006SD)	5	MGL	1176

Reaction No. 59213							
$\text{Mn}^{+2} + \text{H}^{+1}_{\text{Lys-1}} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{Lys-1}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	HCl	lgK:2.0 (2SF)	3	MGL	6024
2	20			lgK:2.18 (3SF)	0	MGL	6000


3	25	0	Inf. Dilution	lgK:2.0 (3SF)	2	EAE	
---	----	---	---------------	---------------	---	-----	--

Reaction No. 59479




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:6.90 (3SF)	4	MGL	905

Reaction No. 59538




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaCl	lgK:6.64 (3SF)	4	MGL	905

Reaction No. 59686




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KCl	lgK:1.37 (3SF)	0	MGL	1437
2	25	0.1	NaClO4	lgK:2.11 (3SF)	3	MGL	1437

Reaction No. 59688




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.35 (3SF)	4	MGL	1437

Reaction No. 59696



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-11.3 (3SF)	5	MGL	6082

Reaction No. 59700



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-11.2 (3SF)	5	MGL	6082

Reaction No. 59701



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-9.67 (0.03MD)	5	MGL	6082

Reaction No. 59706							
$\text{Mn}^{+2}_{\text{OH-1_5ITP-4}} + \text{H}_2\text{O} = \text{Mn}^{+2}_{\text{OH-1(2)_5ITP-4}} + \text{H}^+$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-11.2(0.2MD)	5	MGL	6082

Reaction No. 59707							
$\text{Mn}^{+2}_{\text{5ITP-4}} + \text{H}_2\text{O} = \text{Mn}^{+2}_{\text{OH-1_5ITP-4}} + \text{H}^+$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-8.93(0.02MD)	5	MGL	6082

Reaction No. 59712							
$\text{Mn}^{+2}_{\text{OH-1_5UTP-4}} + \text{H}_2\text{O} = \text{Mn}^{+2}_{\text{OH-1(2)_5UTP-4}} + \text{H}^+$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-11.1(3SF)	5	MGL	6082

Reaction No. 59713							
$\text{Mn}^{+2}_{\text{5UTP-4}} + \text{H}_2\text{O} = \text{Mn}^{+2}_{\text{OH-1_5UTP-4}} + \text{H}^+$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-9.45(0.02MD)	5	MGL	6082

Reaction No. 59718							
$\text{Mn}^{+2}_{\text{5GTP-4}} + \text{H}_2\text{O} = \text{Mn}^{+2}_{\text{OH-1_5GTP-4}} + \text{H}^+$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-9.36(0.01MD)	5	MGL	6082


Reaction No. 59723							
$\text{Mn}^{+2}_{\text{5CTP-4}} + \text{H}_2\text{O} = \text{Mn}^{+2}_{\text{OH-1_5CTP-4}} + \text{H}^+$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-10.9(0.1MD)	5	MGL	6082

Reaction No. 59880							
$12345\text{OH} \cdot 5\text{PentThiaproline-1} + \text{Mn}^{+2} = \text{Mn}^{+2}_{12345\text{OH} \cdot 5\text{PentThiaproline-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.31(0.06SD)	5	MGL	2292

Reaction No. 59881							
$2<12345\text{OH} \cdot 5\text{PentThiaproline-1}> + 2<\text{Mn}^{+2}> = \text{H}^+ + \text{Mn}^{+2}_{(2)_ \text{H}^+(-1)_12345\text{OH} \cdot 5\text{PentThiaproline-1(2)}}$							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:0.66(0.08SD)	5	MGL	2292

Reaction No. 59882




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-10.30(0.15SD)	5	MGL	2292

Reaction No. 59883



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-30.40(0.22SD)	5	MGL	2292

Reaction No. 59885




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:1.8(2SF)	4	MGL	1437

Reaction No. 60208




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:0.93(2SF)	3	CRV	5406

Reaction No. 60221




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	0.1	KNO3	lgK:12.83(4SF)	0	CRV	5406

Reaction No. 60263



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-7.8(2SF)	1	ELC	
2	25	0	Unknown	lgK:-8.9(2SF)	0	ENS	6325

Reaction No. 60327



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0	Inf. Dilution	lgK:5.0 (2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:10. (0.4SD)	0	CRV	2556

Reaction No. 60328							
Mn+2_S-2_(green,s) + 2<H+1> = Mn+2 + H+1(2)_S-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7. (0.4SD)	4	CRV	2556
2	25	0	Inf. Dilution	lgK:7.48 (3SF)	3	CRV	6330
Note (2): p. 8-58							
3	25	3	NaClO4	lgK:6.1 (2SF)	5	CRV	2556
4	25	0	Inf. Dilution	dH:-13. (2SF)	4	CRV	2556

Reaction No. 60472							
Mn+2 + OH-1 = Mn+2_OH-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.4 (2SF)	4	CRV	2556
2	25	0	Inf. Dilution	lgK:3.4 (2SF)	5	CRV	6405
3	25	0	Inf. Dilution	lgK:3.4 (2SF)	3	EOD	16981
4	25	0.1	Unknown	lgK:2.9 (0.1SD)	5	CRV	2556
5	25	1	Unknown	lgK:3.0 (2SF)	5	CRV	2556
6	25	2	Unknown	lgK:3.5 (2SF)	5	CRV	2556
7	10:40	0	Inf. Dilution	dH:0.0 (1SF)	3	CRV	2556


Reaction No. 60648							
Mn+2 + H+1(2)_PO4-3 = Mn+2_H+1(2)_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	Li+1 salt	lgK:3.2 (2SF)	4	CRV	2556

Reaction No. 60649							
Mn+2 + 2<H+1(2)_PO4-3> = Mn+2_H+1(4)_PO4-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	Li+1 salt	lgK:6.6 (2SF)	4	CRV	2556

Reaction No. 60674							
Mn+3 + F-1 = Mn+3_F-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.364 (4SF)	1	EOR	


2	25	2	Unknown	lgK:5.65 (3SF)	5	CRV	2556
3	25	3	Unknown	lgK:5.9 (2SF)	5	CRV	2556

Reaction No. 60675




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7 (3SF)	2	EES	
2	25	0	Inf. Dilution	lgK:11.7 (4SF)	1	EOR	
3	25	3	Unknown	lgK:11.0 (3SF)	3	CRV	2556

Reaction No. 60739



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	2	NH ₄ NO ₃	lgK:1.54 (3SF)	5	MGL	4992
2	25	0	Inf. Dilution	lgK:1.321 (4SF)	1	EOR	
3	25	0	Inf. Dilution	lgK:1.5 (2SF)	4	ENS	6405
4	25	0	Inf. Dilution	lgK:1.20 (3SF)	4	CRV	9402
5	25	1	Unknown	lgK:1.37 (3SF)	5	CRV	2556
6	25	2	NH ₄ NO ₃	lgK:1.49 (3SF)	5	CRV	2556
7	25	2	NH ₄ NO ₃	lgK:1.60 (3SF)	5	MGL	22560
8	25	3	NH ₄ NO ₃	lgK:1.60 (3SF)	5	CRV	2556
9	25	4	NH ₄ NO ₃	lgK:1.72 (3SF)	5	CRV	2556
10	25	5	NH ₄ NO ₃	lgK:1.84 (3SF)	5	CRV	2556
11	10:40	2	NH ₄ NO ₃	dH:-3. (1SF)	5	CRV	2556

Reaction No. 60740



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.328 (4SF)	1	EOR	
2	25	1	Unknown	lgK:1.56 (3SF)	5	CRV	2556
3	25	2	NH ₄ NO ₃	lgK:1.69 (3SF)	5	CRV	2556
4	25	3	NH ₄ NO ₃	lgK:1.92 (3SF)	5	CRV	2556
5	25	4	NH ₄ NO ₃	lgK:2.09 (3SF)	5	CRV	2556
6	25	5	NH ₄ NO ₃	lgK:2.28 (3SF)	5	CRV	2556
7	10:40	2	NH ₄ NO ₃	dH:-4. (1SF)	5	CRV	2556

Reaction No. 60741

4<NH3> + Mn+2 = Mn+2_NH3(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.22(4SF)	1	EOR	
2	25	1	Unknown	lgK:1.47(3SF)	5	CRV	2556
3	25	2	NH4NO3	lgK:1.71(3SF)	5	CRV	2556
4	25	3	NH4NO3	lgK:1.96(3SF)	5	CRV	2556
5	25	4	NH4NO3	lgK:2.19(3SF)	5	CRV	2556
6	25	5	NH4NO3	lgK:2.45(3SF)	5	CRV	2556
7	10:40	2	NH4NO3	dH:-5.(1SF)	5	CRV	2556

Reaction No. 60869							
Mn+2 + H+1(2)_23DHB-3 = Mn+2_23DHB-3 + 2<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:-15.2(3SF)	6	MGL	5987

Reaction No. 60879							
24DHB-3 + Mn+2 = Mn+2_24DHB-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	NaClO4	lgK:9.00(3SF)	6	MGL	5987

Reaction No. 60923							
25DHB-3 + Mn+2 = Mn+2_25DHB-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	NaClO4	lgK:8.46(3SF)	6	MGL	5987


Reaction No. 60968							
2OH5ClBenz-2 + Mn+2 = Mn+2_2OH5ClBenz-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	NaClO4	lgK:6.46(3SF)	6	MGL	5987

Reaction No. 60976							
2OH35DiClBenz-2 + Mn+2 = Mn+2_2OH35DiClBenz-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	NaClO4	lgK:4.49(3SF)	6	MGL	5987

Reaction No. 60984							
2OH3BrBenz-2 + Mn+2 = Mn+2_2OH3BrBenz-2							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	NaClO4	lgK:5.33 (3SF)	6	MGL	5987

Reaction No. 61005




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	NaClO4	lgK:5.03 (3SF)	6	MGL	5987

Reaction No. 61446




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:11.1 (0.03SD)	3	ENS	3834

Reaction No. 61450




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:3.85 (0.01SD)	3	ENS	3834

Reaction No. 61453




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:-5.50 (0.01SD)	3	ENS	3834

Reaction No. 61454




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:6.45 (0.02SD)	3	ENS	3834

Reaction No. 61475



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KBr	lgK:10.65 (4SF)	5	MPT	6938

Reaction No. 61647



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:2.58 (3SF)	6	CRV	552

Reaction No. 61648							
$2<2\text{PhenGly-1}> + \text{Mn}^{+2} = \text{Mn}^{+2}_{2\text{PhenGly-1}}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:4.50 (3SF)	6	CRV	552

Reaction No. 61713							
$\text{Mn}^{+2}_{\text{PO4Ser-3}} + \text{H}^{+1} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{PO4Ser-3}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:7.68 (3SF)	6	CRV	552

Reaction No. 61729							
$\text{Mn}^{+2} + 2<\text{H}^{+1}_{\text{mTyr-2}}> = \text{Mn}^{+2}_{\text{H}^{+1}(2)_{\text{mTyr-2}}}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:4.9 (2SF)	4	CRV	552
2	25	0.1	Unknown	dH:-1.5 (2SF)	5	CRV	552

Reaction No. 61744							
$\text{Mn}^{+2}_{\text{LDopa-3}} + \text{H}^{+1} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{LDopa-3}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:9.62 (3SF)	6	CRV	552

Reaction No. 61849							
$2<2\text{SHHis-2}> + \text{Mn}^{+2} = \text{Mn}^{+2}_{2\text{SHHis-2}}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:8.6 (2SF)	4	CRV	552


Reaction No. 61855							
$2<\text{Smc-1}> + \text{Mn}^{+2} = \text{Mn}^{+2}_{\text{Smc-1}}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:4.27 (3SF)	6	CRV	552

Reaction No. 61914							
$\text{SCOOMeCys-2} + \text{Mn}^{+2} = \text{Mn}^{+2}_{\text{SCOOMeCys-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Unknown	lgK:2.58 (3SF)	4	CRV	552

Reaction No. 61990							
$\text{Mn}^{+2} + \text{H}^{+1}_{\text{OHLys-1}} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{OHLys-1}}}$							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:2.3 (2SF)	6	CRV	552

Reaction No. 62073




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.2 (2SF)	1	ELC	
2	37	0.15	Unknown	lgK:9.0 (2SF)	0	CRV	552

Reaction No. 62074




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.8 (2SF)	1	ELC	
2	37	0.15	Unknown	lgK:9.2 (2SF)	6	CRV	552

Reaction No. 62114




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:7.80 (0.02SD)	5	MGL	6861
2	25	0.1	Unknown	lgK:7.80 (3SF)	6	CRV	552
3	25	0.1	Unknown	lgK:7.8 (0.1SD)	6	CIU	7242

Reaction No. 62229




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:8.45 (3SF)	6	CRV	552

Reaction No. 62259



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	Unknown	lgK:5.51 (3SF)	6	CRV	552

Reaction No. 62292



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:5.46 (3SF)	6	CRV	552

Reaction No. 62365

Mn+2_HBED-4 + H+1 = Mn+2_H+1_HBED-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:7.66(3SF)	6	CRV	552

Reaction No. 62366							
Mn+2_H+1_HBED-4 + H+1 = Mn+2_H+1(2)_HBED-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:6.58(3SF)	6	CRV	552

Reaction No. 62371							
PLED-4 + Mn+2 = Mn+2_PLED-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:12.7(3SF)	6	CRV	552

Reaction No. 62372							
Mn+2_PLED-4 + H+1 = Mn+2_H+1_PLED-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:8.72(3SF)	6	CRV	552

Reaction No. 62373							
Mn+2_H+1_PLED-4 + H+1 = Mn+2_H+1(2)_PLED-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:7.9(2SF)	6	CRV	552


Reaction No. 62386							
Mn+2_ICRF198-2 + H+1 = Mn+2_H+1_ICRF198-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.2(2SF)	1	ESC	
2	37	0.15	Unknown	lgK:1.2(2SF)	4	CRV	552

Reaction No. 62412							
Mn+2_ICRF243-2 + H+1 = Mn+2_H+1_ICRF243-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37	0.15	Unknown	lgK:1.6(2SF)	4	CRV	552

Reaction No. 62418							
Mn+2_ICRF236-2 + H+1 = Mn+2_H+1_ICRF236-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	37	0.15	Unknown	lgK:1.8 (2SF)	4	CRV	552
---	----	------	---------	---------------	---	-----	-----

Reaction No. 62443




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:4.14 (3SF)	6	CRV	552

Reaction No. 62455




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:4.15 (3SF)	6	CRV	552
2	25	0.1	Me4NNO3	lgK:4.21 (0.06SD)	5	CRV	13242

Reaction No. 62459




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:3.91 (3SF)	6	CRV	552

Reaction No. 62617




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:10.00 (4SF)	6	CRV	552

Reaction No. 62682




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:5.50 (3SF)	6	CRV	552

Reaction No. 62717



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:3.79 (3SF)	6	CRV	552

Reaction No. 62966



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:9. (0.6SD)	6	CRV	552
2	25	0.1	Unknown	dH:-3.9 (2SF)	6	CRV	552

Reaction No. 63040							
2<CarbMeIDA-2> + Mn+2 = Mn+2_CarbMeIDA-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:6.93 (3SF)	6	CRV	552

Reaction No. 63076							
2<UramilIDA-3> + Mn+2 = Mn+2_UramilIDA-3 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:14.04 (4SF)	6	CRV	552

Reaction No. 63077							
Mn+2_UramilIDA-3 + H+1 = Mn+2_H+1_UramilIDA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:3.05 (3SF)	6	CRV	552

Reaction No. 63092							
Mn+2_N2SHetIDA-2 + H+1 = Mn+2_H+1_N2SHetIDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:6.16 (3SF)	6	CRV	552

Reaction No. 65586							
IO3-1 + Mn+2 = Mn+2_IO3-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.84 (2SF)	4	EBU	6372

Reaction No. 65587							
2<IO3-1> + Mn+2 = Mn+2_IO3-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.13 (2SF)	4	EBU	6372

Reaction No. 65588							
Mn+2 + 3<IO3-1> = Mn+2_IO3-1 (3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.88 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:-1.88 (3SF)	4	EBU	6372

Reaction No. 65648							
--------------------	--	--	--	--	--	--	--

Ag+1_MnO4-1_(s) = Ag+1 + MnO4-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-9.88 (3SF)	4	CRV	552
2	25	0	Inf. Dilution	dH:7. (1SF)	4	CRV	552

Reaction No. 65786							
N3-1 + Mn+2 = Mn+2_N3-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:0.58 (2SF)	5	MCN	4604
2	25	1	Unknown	lgK:0.61 (2SF)	6	CRV	552

Reaction No. 65787							
2<N3-1> + Mn+2 = Mn+2_N3-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:0.60 (2SF)	5	MCN	4604
2	25	1	Unknown	lgK:0.6 (1SF)	6	CRV	552

Reaction No. 65790							
N3-1 + Mn+3 = Mn+3_N3-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4	Unknown	lgK:6.9 (2SF)	6	CRV	552

Reaction No. 65802							
NO2-1 + Mn+2 = Mn+2_NO2-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Unknown	lgK:0.45 (2SF)	6	CRV	552

Reaction No. 65836							
Mn+2 + H+1_P2O7-4 = Mn+2_H+1_P2O7-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	Li+1 salt	lgK:11.7 (3SF)	6	CRV	552

Reaction No. 65837							
Mn+2 + H+1 (2)_P2O7-4 = Mn+2_H+1 (2)_P2O7-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	Li+1 salt	lgK:7.1 (2SF)	6	CRV	552

Reaction No. 65838							
--------------------	--	--	--	--	--	--	--

Mn+2 + 2<H+1(2)_P207-4> = Mn+2_H+1(4)_P207-4(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	Li+1 salt	lgK:10.8(3SF)	6	CRV	552

Reaction No. 65885							
P4O12-4 + Mn+2 = Mn+2_P4O12-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.74(3SF)	4	MCN	386
2	25	0	Inf. Dilution	lgK:5.74(3SF)	4	CRV	552

Reaction No. 65940							
Mn+2_SeO4-2_(s) = Mn+2 + SeO4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.05(3SF)	0	CRV	552
2	25	0	Inf. Dilution	dG:6.08(3SF)	3	ENS	12931

Reaction No. 65946							
Mn+2_Te-2_(s) = Mn+2 + Te-2							
Note: The Te-2 species probably does not exist [18Mar_30641]							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-18.3(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-15.9(3SF)	0	CRV	552
3	25	0	Inf. Dilution	lgK:-15.9(3SF)	0	CRV	32224
Note (3): source indicates uncertainty							

Reaction No. 66066							
H+1 + P3O10-5 + Mn+2 = Mn+2_H+1_P3O10-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.5(3SF)	1	ERG	
2	25	0	Inf. Dilution	lgK:14.8(3SF)	0	ENS	6405

Reaction No. 66156							
1PrEDTA-4 + Mn+2 = Mn+2_1PrEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:15.6(0.1SD)	6	MPL	1994

Reaction No. 66209							
--------------------	--	--	--	--	--	--	--

2<Mn+2> + TetMDTA-4 = Mn+2(2)_TetMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:11.35(4SF)	6	CRV	552

Reaction No. 66839							
Mn+2_Oxine-1(2)_(s) = Mn+2 + 2<Oxine-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-21.7(3SF)	4	ENS	773

Reaction No. 66979							
As(s) + Mn(s) = MnAs(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.46(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:10.40(4SF)	4	ENS	6422
3	42.7	0	Inf. Dilution	lgK:9.907(4SF)	4	ENS	6422
4	25	0	Inf. Dilution	dG:-14.27(4SF)	4	EFE	6422
5	25	0	Inf. Dilution	dH:-13.6(3SF)	4	MTD	6422
6	42.7	0	Inf. Dilution	dH:-13.5(3SF)	4	MTD	6422

Reaction No. 66980							
2<As(s)> + 3<Mn(s)> + 4<O2(g)> = Mn+2(3)_AsO4-3(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:379.6(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:377.1(4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:274.1(4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:212.4(4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:171.4(4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-517.9(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-565.5(4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-564.9(4SF)	1	MTD	6422
9	227	0	Inf. Dilution	dH:-564.2(4SF)	0	MTD	6422
10	327	0	Inf. Dilution	dH:-563.3(4SF)	0	MTD	6422

Reaction No. 66981							
B(s) + Mn(s) = MnB(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.91(4SF)	4	ENS	6422


2	27	0	Inf. Dilution	lgK:12.83 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:9.549 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:7.577 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:6.257 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-17.61 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-18.0 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-18.0 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-18.1 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-18.2 (3SF)	4	MTD	6422

Reaction No. 66982							
2<B(s)> + Mn(s) = MnB2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.02 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:15.91 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:11.82 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:9.362 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:7.716 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-21.85 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-22.5 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-22.5 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-22.5 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-22.7 (3SF)	4	MTD	6422

Reaction No. 66983							
Br2(l) + Mn(s) = Mn+2_Br-1(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:65.39 (4SF)	3	ENS	6422
2	27	0	Inf. Dilution	lgK:64.98 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:47.38 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:36.55 (4SF)	2	ENS	6422
5	327	0	Inf. Dilution	lgK:29.35 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-89.21 (4SF)	3	EFE	6422
7	25	0	Inf. Dilution	dH:-384.9 (4SF) kJ	3	CRV	6330
8	25	0	Inf. Dilution	dH:-92.2 (3SF)	3	MTD	6422
9	127	0	Inf. Dilution	dH:-99.3 (3SF)	3	MTD	6422


10	227	0	Inf. Dilution	dH:-99.0 (3SF)	2	MTD	6422
11	327	0	Inf. Dilution	dH:-98.6 (3SF)	0	MTD	6422

Reaction No. 66984




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.966 (3SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:-0.961 (3SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:-0.747 (3SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:-0.598 (3SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:-0.490 (3SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:1.318 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:1.10 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:1.28 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:1.44 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:1.53 (3SF)	4	MTD	6422

Reaction No. 66985



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.01 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:18.89 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:14.18 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:11.40 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:9.552 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-25.93 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-26.1 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-25.6 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-25.4 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-25.4 (3SF)	4	MTD	6422

Reaction No. 66986



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.61 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:11.42 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:3.800 (4SF)	4	ENS	6422

4	227	0	Inf. Dilution	lgK:-0.769 (3SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:-3.844 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-15.84 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-42.0 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-41.8 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-42.0 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-42.6 (3SF)	4	MTD	6422

Reaction No. 66987							
C(s) + Mn(s) + 1.5<O2(g)> = Mn+2_CO3-2_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:143.1 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:143.5 (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:142.1 (4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:142.5 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:103.2 (4SF)	3	ENS	6422
6	127	0	Inf. Dilution	lgK:103.7 (4SF)	3	ENS	6494
7	227	0	Inf. Dilution	lgK:79.88 (4SF)	2	ENS	6422
8	227	0	Inf. Dilution	lgK:80.38 (4SF)	2	ENS	6494
9	327	0	Inf. Dilution	lgK:64.36 (4SF)	0	ENS	6422
10	327	0	Inf. Dilution	lgK:64.87 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-816.7 (4SF) kJ	5	CRV	6330
12	25	0	Inf. Dilution	dG:-195.2 (4SF)	4	EFE	6422
13	25	0	Inf. Dilution	dG:-195.8 (4SF)	4	EFE	6494
14	25	0	Inf. Dilution	dG:-816.0 (4SF) kJ	4	EOD	29025
15	25	0	GAMSPATH	dG:-816.1 (4SF) kJ	3	CRV	12638
16	25	0	Inf. Dilution	dH:-894.1 (4SF) kJ	5	CRV	6330
17	25	0	Inf. Dilution	dH:-213.7 (4SF)	4	MTD	6422
18	25	0	Inf. Dilution	dH:-213.4 (4SF)	4	MTD	6494
19	25	0	Inf. Dilution	dH:-889.3 (4SF) kJ	4	EOD	29025
20	25	0	GAMSPATH	dH:-889.190 (6SF) kJ	3	CRV	12638
21	127	0	Inf. Dilution	dH:-213.5 (4SF)	3	ENS	6422
22	127	0	Inf. Dilution	dH:-213.2 (4SF)	2	MTD	6494
23	227	0	Inf. Dilution	dH:-213.3 (4SF)	1	MTD	6422
24	227	0	Inf. Dilution	dH:-213.1 (4SF)	1	MTD	6494
25	327	0	Inf. Dilution	dH:-212.9 (4SF)	0	MTD	6422

26	327	0	Inf. Dilution	dH:-212.9 (4SF)	0	MTD	6494
27	25	0	Inf. Dilution	Cp:81.5 (3SF) J/K	4	EOD	29025


Reaction No. 66988							
F2(g) + Mn(s) = Mn+2_F-1(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:141.4 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:140.5 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:103.5 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:81.40 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:66.66 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-192.9 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-203.0 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-202.7 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-202.4 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-202.2 (4SF)	4	MTD	6422

Reaction No. 66989							
1.5<F2(g)> + Mn(s) = Mn+3_F-1(3)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:175.2 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:174.0 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:127.4 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:99.50 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:80.93 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-239.0 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-256.0 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-255.6 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-255.2 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-254.8 (4SF)	4	MTD	6422

Reaction No. 66990							
I2(s) + Mn(s) = Mn+2_I-1(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:47.84 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:47.55 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:35.89 (4SF)	4	ENS	6422

4	227	0	Inf. Dilution	lgK:28.07 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:22.40 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-65.27 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-63.6 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-67.6 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-77.9 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-77.6 (3SF)	4	MTD	6422

Reaction No. 66991



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:191.2 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:189.9 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:138.1 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:107.1 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:86.38 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-260.9 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-284.7 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-284.4 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-284.0 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-283.6 (4SF)	4	MTD	6422

Reaction No. 66992



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.31 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:18.17 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:12.59 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:9.271 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:7.078 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-24.98 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-30.7 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-30.5 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-30.2 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-30.0 (3SF)	4	MTD	6422

Reaction No. 66993


5<Mn(s)> + N2(g) = Mn5N2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:27.20 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:26.98 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:18.12 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:12.87 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:9.413 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-37.10 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-48.8 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-48.4 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-47.8 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-47.0 (3SF)	4	MTD	6422

Reaction No. 66994							
Mn(s) + O2(g) = MnO2(alpha,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:81.49 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:80.93 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:58.29 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:44.73 (4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:35.69 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-111.2 (4SF)	3	EFE	6422
7	25	0	Inf. Dilution	dG:-465.14 (5SF) kJ	4	ENS	7381
8	25	0	Inf. Dilution	dG:-111.18 (5SF)	3	CRV	31291
9	25	0	Inf. Dilution	dH:-124.3 (4SF)	4	MTD	6422
10	25	0	Inf. Dilution	dH:-520.03 (5SF) kJ	4	ENS	7381
11	25	0	Inf. Dilution	dH:-124.29 (5SF)	3	CRV	31291
12	127	0	Inf. Dilution	dH:-124.2 (4SF)	1	MTD	6422
13	227	0	Inf. Dilution	dH:-124.1 (4SF)	0	MTD	6422
14	327	0	Inf. Dilution	dH:-123.9 (4SF)	0	MTD	6422

Reaction No. 66995							
2<Mn(s)> + 1.5<O2(g)> = Mn2O3(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:154.4 (4SF)	4	ENS	6422
2	25	0:4	Inf. Dilution	lgK:154.5 (4SF)	4	ENS	6494

3	27	0	Inf. Dilution	lgK:153.3 (4SF)	0	ENS	6422
4	27	0:4	Inf. Dilution	lgK:153.5 (4SF)	0	ENS	6494
5	127	0	Inf. Dilution	lgK:111.6 (4SF)	2	ENS	6422
6	127	0:4	Inf. Dilution	lgK:111.8 (4SF)	2	ENS	6494
7	227	0	Inf. Dilution	lgK:86.57 (4SF)	1	ENS	6422
8	227	0:4	Inf. Dilution	lgK:86.74 (4SF)	1	ENS	6494
9	327	0	Inf. Dilution	lgK:69.91 (4SF)	0	ENS	6422
10	327	0:4	Inf. Dilution	lgK:70.08 (4SF)	0	ENS	6494
11	25	0	Inf. Dilution	dG:-210.6 (4SF)	4	EFE	6422
12	25	0	Inf. Dilution	dG:-210.59 (5SF)	3	CRV	31291
13	25	0:4	Inf. Dilution	dG:-210.8 (4SF)	2	EFE	6494
14	25	0	Inf. Dilution	dH:-229.2 (4SF)	4	MTD	6422
15	25	0	Inf. Dilution	dH:-229.20 (5SF)	3	CRV	31291
16	25	0:4	Inf. Dilution	dH:-229.2 (4SF)	4	MTD	6494
17	127	0	Inf. Dilution	dH:-229.1 (4SF)	1	MTD	6422
18	127	0:4	Inf. Dilution	dH:-229.1 (4SF)	1	MTD	6494
19	227	0	Inf. Dilution	dH:-228.9 (4SF)	0	MTD	6422
20	227	0:4	Inf. Dilution	dH:-228.9 (4SF)	0	MTD	6494
21	327	0	Inf. Dilution	dH:-228.7 (4SF)	0	MTD	6422
22	327	0:4	Inf. Dilution	dH:-228.7 (4SF)	0	MTD	6494

Reaction No. 66996



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:348.4 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:346.1 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:254.8 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:200.0 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:163.4 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-475.3 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-501.6 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-501.6 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-501.4 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-501.2 (4SF)	4	MTD	6422

Reaction No. 66997

Mn(s) + 1.5<O2(g)> + Ti(s) = MnTiO3(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:224.1(4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:244.4(4SF)	0	ENS	6494
3	27	0	Inf. Dilution	lgK:222.7(4SF)	4	ENS	6422
4	27	0	Inf. Dilution	lgK:222.9(4SF)	4	ENS	6494
5	127	0	Inf. Dilution	lgK:163.6(4SF)	4	ENS	6422
6	127	0	Inf. Dilution	lgK:163.7(4SF)	4	ENS	6494
7	227	0	Inf. Dilution	lgK:128.1(4SF)	4	ENS	6422
8	227	0	Inf. Dilution	lgK:128.3(4SF)	4	ENS	6494
9	327	0	Inf. Dilution	lgK:104.5(4SF)	4	ENS	6422
10	327	0	Inf. Dilution	lgK:104.6(4SF)	4	ENS	6494
11	25	0	Inf. Dilution	dG:-305.8(4SF)	4	EFE	6422
12	25	0	Inf. Dilution	dG:-306.1(4SF)	4	EFE	6494
13	25	0	Inf. Dilution	dH:-324.7(4SF)	4	MTD	6422
14	25	0	Inf. Dilution	dH:-322.7(4SF)	4	MTD	6494
15	127	0	Inf. Dilution	dH:-324.5(4SF)	4	MTD	6422
16	127	0	Inf. Dilution	dH:-324.9(4SF)	4	MTD	6494
17	227	0	Inf. Dilution	dH:-324.2(4SF)	4	MTD	6422
18	227	0	Inf. Dilution	dH:-324.6(4SF)	4	MTD	6494
19	327	0	Inf. Dilution	dH:-323.8(4SF)	4	MTD	6422
20	327	0	Inf. Dilution	dH:-324.3(4SF)	4	MTD	6494

Reaction No. 66998							
2<Mn(s)> + 2<O2(g)> + Ti(s) = Mn2TiO4(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:289.1(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:287.2(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:211.0(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:165.4(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:135.0(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-394.4(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-418.2(4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-417.9(4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-417.5(4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-417.1(4SF)	4	MTD	6422


Reaction No. 66999							
$\text{Mn(s)} + \text{P(s)} = \text{MnP(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.38 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:19.26 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:14.32 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:11.34 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:9.345 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-26.44 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-27.0 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-27.2 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-27.3 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-27.4 (3SF)	4	MTD	6422

Reaction No. 67000							
$\text{Mn(s)} + 3\text{P(s)} = \text{MnP}_3\text{(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:34.26 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:34.03 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:24.69 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:19.07 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:15.33 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-46.74 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-50.9 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-51.4 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-51.4 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-51.4 (3SF)	4	MTD	6422

Reaction No. 67001							
$2\text{Mn(s)} + \text{P(s)} = \text{Mn}_2\text{P(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:29.25 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:29.06 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:21.58 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:17.08 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:14.08 (4SF)	4	ENS	6422


6	25	0	Inf. Dilution	dG:-39.90 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-40.9 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-41.1 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-41.2 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-41.3 (3SF)	4	MTD	6422

Reaction No. 67002



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:38.26 (4SF)	4	ENS	6422
2	25	0	Inf. Dilution	lgK:38.32 (4SF)	4	ENS	6494
3	27	0	Inf. Dilution	lgK:38.03 (4SF)	4	ENS	6422
4	27	0	Inf. Dilution	lgK:38.09 (4SF)	4	ENS	6494
5	127	0	Inf. Dilution	lgK:28.70 (4SF)	4	ENS	6422
6	127	0	Inf. Dilution	lgK:28.77 (4SF)	4	ENS	6494
7	227	0	Inf. Dilution	lgK:23.03 (4SF)	4	ENS	6422
8	227	0	Inf. Dilution	lgK:23.10 (4SF)	4	ENS	6494
9	327	0	Inf. Dilution	lgK:19.22 (4SF)	4	ENS	6422
10	327	0	Inf. Dilution	lgK:19.30 (4SF)	4	ENS	6494
11	25	0	Inf. Dilution	dG:-52.20 (4SF)	4	EFE	6422
12	25	0	Inf. Dilution	dG:-52.27 (4SF)	4	EFE	6494
13	25	0	Inf. Dilution	dH:-51.2 (3SF)	4	MTD	6422
14	25	0	Inf. Dilution	dH:-51.12 (4SF)	4	MTD	6494
15	127	0	Inf. Dilution	dH:-51.7 (3SF)	4	MTD	6422
16	127	0	Inf. Dilution	dH:-51.67 (4SF)	4	MTD	6494
17	227	0	Inf. Dilution	dH:-52.1 (3SF)	4	MTD	6422
18	227	0	Inf. Dilution	dH:-52.08 (4SF)	4	MTD	6494
19	327	0	Inf. Dilution	dH:-52.5 (3SF)	4	MTD	6422
20	327	0	Inf. Dilution	dH:-52.41 (4SF)	4	MTD	6494


Reaction No. 67003



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:39.42 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:39.17 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:29.40 (4SF)	4	ENS	6422


4	227	0	Inf. Dilution	lgK:23.40 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:19.34 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-53.77 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-53.5 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-54.6 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-55.4 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-55.9 (3SF)	4	MTD	6422

Reaction No. 67004




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:28.9 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:30.92 (4SF)	0	ENS	6422
3	27	0	Inf. Dilution	lgK:30.73 (4SF)	0	ENS	6422
4	127	0	Inf. Dilution	lgK:23.26 (4SF)	1	ENS	6422
5	227	0	Inf. Dilution	lgK:18.76 (4SF)	1	ENS	6422
6	327	0	Inf. Dilution	lgK:15.64 (4SF)	0	ENS	6422
7	25	0	Inf. Dilution	dG:-42.18 (4SF)	0	EFE	6422
8	25	0	Inf. Dilution	dH:-41.0 (3SF)	1	MTD	6422
9	127	0	Inf. Dilution	dH:-41.1 (3SF)	1	MTD	6422
10	227	0	Inf. Dilution	dH:-42.6 (3SF)	0	MTD	6422
11	327	0	Inf. Dilution	dH:-42.9 (3SF)	0	MTD	6422

Reaction No. 67005



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.62 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:19.51 (4SF)	4	ENS	6422
3	34	0	Inf. Dilution	lgK:19.08 (4SF)	4	ENS	6422
4	25	0	Inf. Dilution	dG:-26.77 (4SF)	4	EFE	6422
5	25	0	Inf. Dilution	dH:-25.9 (3SF)	4	MTD	6422
6	34	0	Inf. Dilution	dH:-25.9 (3SF)	4	MTD	6422

Reaction No. 67006



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.72 (4SF)	4	ENS	6422

2	27	0	Inf. Dilution	lgK:22.59 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:17.12 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:13.82 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:11.61 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-31.00 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-30.0 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-30.1 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-30.3 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-30.6 (3SF)	4	MTD	6422

Reaction No. 67007							
Mn(s) + 2<O2(g)> + W(s) = Mn+2_WO4-2_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:208.0 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:211.2 (4SF)	0	ENS	6422
3	27	0	Inf. Dilution	lgK:209.8 (4SF)	0	ENS	6422
4	127	0	Inf. Dilution	lgK:153.0 (4SF)	0	ENS	6422
5	227	0	Inf. Dilution	lgK:119.0 (4SF)	0	ENS	6422
6	327	0	Inf. Dilution	lgK:96.31 (4SF)	0	ENS	6422
7	25	0	Inf. Dilution	dG:-288.1 (4SF)	0	EFE	6422
8	25	0	Inf. Dilution	dH:-311.9 (4SF)	0	MTD	6422
9	127	0	Inf. Dilution	dH:-311.5 (4SF)	0	MTD	6422
10	227	0	Inf. Dilution	dH:-311.1 (4SF)	0	MTD	6422
11	327	0	Inf. Dilution	dH:-310.7 (4SF)	0	MTD	6422

Reaction No. 67254							
Mn+2_H+1_CO3-2 + H+1_CO3-2 = Mn+2_H+1(2)_CO3-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:0.57 (2SF)	0	ENS	5181

Reaction No. 67396							
Mn(s) + O2(g) = MnO2(beta,s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:81.3 (3SF)	1	ELC	
2	25	0	GAMSPATH	dG:-465.2 (4SF) kJ	0	CRV	12638
3	25	0	GAMSPATH	dH:-520.030 (6SF) kJ	0	CRV	12638

Reaction No. 67778							
$\text{Mn}^{+2}_{5\text{ATP-4}} + \text{NH}_3 = \text{Mn}^{+2}_{\text{NH}_3_{5\text{ATP-4}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO ₃	lgK:1.0 (0.2MD)	5	MGL	411

Reaction No. 67959							
$2\langle\text{SolochromeVR-3}\rangle + \text{Mn}^{+2} = \text{Mn}^{+2}_{\text{SolochromeVR-3}(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.1 (3SF)	4	MPS	7000

Reaction No. 67965							
$\text{Mn}^{+2}(2)_{\text{P207-4}}(\text{s}) + 2\langle\text{H}^{+1}\rangle = 2\langle\text{Mn}^{+2}\rangle + \text{H}^{+1}(2)_{\text{P207-4}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	0	Inf. Dilution	lgK:-1.39 (3SF)	5	MTN	2358
2	25	0	Inf. Dilution	lgK:-1.39 (3SF)	2	EAE	

Reaction No. 67966							
$\text{Mn}^{+2}(2)_{\text{P207-4}}(\text{s}) + \text{P207-4} = 2\langle\text{Mn}^{+2}_{\text{P207-4}}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	0	Inf. Dilution	lgK:-4.22 (3SF)	5	MTN	2358
2	25	0	Inf. Dilution	lgK:-4.22 (3SF)	2	EAE	

Reaction No. 68049							
$\text{IDS-4} + \text{Mn}^{+2} = \text{Mn}^{+2}_{\text{IDS-4}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.97 (3SF)	3	CRV	29666
2	25	0.1	Unknown	lgK:6.78 (3SF)	2	ENS	7168
3	25	0.1	Unknown	lgK:7.36 (0.01SD)	4	ENS	7168

Reaction No. 68077							
$\text{H}^{+1} + \text{IDS-4} + \text{Mn}^{+2} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{IDS-4}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:12.56 (0.01SD)	5	ENS	7168

Reaction No. 68121							
$\text{N6Me2PyridMeAsp-2} + \text{Mn}^{+2} = \text{Mn}^{+2}_{\text{N6Me2PyridMeAsp-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	20	0.1	NaNO3	lgK:6.60 (0.05MD)	5	MPT	6937
---	----	-----	-------	-------------------	---	-----	------

Reaction No. 68122




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaNO3	lgK:3.5 (0.1MD)	5	MPT	6937

Reaction No. 68148




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.45 (3SF)	5	MGL	6935
2	25	0.1	KNO3	dH:-3.2 (2SF)	5	MCL	6935

Reaction No. 68157




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.57 (3SF)	5	MGL	6935
2	25	0.1	KNO3	dH:-0.2 (1SF)	5	MCL	6935

Reaction No. 68309




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:3.5 (0.03SD)	5	MGL	6868

Reaction No. 68310




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:2.0 (0.03SD)	5	MGL	6868

Reaction No. 68320



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:2.12 (0.02SD)	5	MGL	6868


Reaction No. 68345



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:12.30 (0.02SD)	5	MGL	6861


2	25	0.1	Unknown	lgK:12.3(0.1SD)	6	CIU	7242
---	----	-----	---------	-----------------	---	-----	------

Reaction No. 68386




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NC1O4	lgK:12.6(0.2MD)	5	MGL	7205
2	25	0.4	DMF Et4NC1O4	dH:5.1(2SF)	5	MCL	7205

Reaction No. 68393



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NC1O4	lgK:2.40(3SF)	5	MCL	7257
2	25	0.4	DMF Et4NC1O4	dH:6.1(2SF)	5	MCL	7257
3	25	0.4	DMSO Et4NBF4	lgK:1.1(0.1MD)	5	MCL	7215
4	25	0.4	DMSO Et4NBF4	dH:5.5(2SF)	5	MCL	7215
5	25	0.1	DiMeAcetamide Et4NBF4	lgK:3.9(0.3MD)	5	MGL	7222
6	45	0.1	DiMeAcetamide Et4NBF4	lgK:4.3(0.3MD)	5	MGL	7222
7	25	0.1	DiMeAcetamide Et4NBF4	dH:3.82(3SF)	5	MCL	7222
8	45	0.1	DiMeAcetamide Et4NBF4	dH:2.63(3SF)	5	MCL	7222
9	25	0.1	HMPA Unknown	lgK:4.4(2SF)	5	ENS	7187
10	25	0.1	HMPA Unknown	dH:0.007(1SF)	5	ENS	7187

Reaction No. 68394



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NC1O4	lgK:3.93(3SF)	5	MCL	7257
2	25	0.4	DMF Et4NC1O4	dH:1.2(2SF)	5	MCL	7257
3	25	0.4	DMSO Et4NBF4	lgK:1.9(0.2MD)	5	MCL	7215

4	25	0.4	DMSO Et4NBF4	dH:6.2 (2SF)	5	MCL	7215
5	25	0.1	DiMeAcetamide Et4NBF4	lgK:4.3 (0.1MD)	5	MGL	7222
6	45	0.1	DiMeAcetamide Et4NBF4	lgK:4.4 (0.3MD)	5	MGL	7222
7	25	0.1	DiMeAcetamide Et4NBF4	dH:-3.11 (3SF)	5	MCL	7222
8	45	0.1	DiMeAcetamide Et4NBF4	dH:-3.11 (3SF)	5	MCL	7222
9	25	0.1	HMPA Unknown	lgK:2.6 (2SF)	5	ENS	7187
10	25	0.1	HMPA Unknown	dH:-2.63 (3SF)	5	ENS	7187

Reaction No. 68395							
Mn+2_Cl-1(3) + Cl-1 = Mn+2_Cl-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMSO Et4NBF4	lgK:1.5 (0.07MD)	5	MCL	7215
2	25	0.4	DMSO Et4NBF4	dH:-2.63 (3SF)	5	MCL	7215
3	25	0.1	DiMeAcetamide Et4NBF4	lgK:2.1 (0.3MD)	5	MGL	7222
4	45	0.1	DiMeAcetamide Et4NBF4	lgK:2.1 (0.3MD)	5	MGL	7222
5	25	0.1	DiMeAcetamide Et4NBF4	dH:-2.94 (3SF)	5	MCL	7222
6	45	0.1	DiMeAcetamide Et4NBF4	dH:-2.99 (3SF)	5	MCL	7222

Reaction No. 68397							
Mn+2_Br-1(2) + Br-1 = Mn+2_Br-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	DiMeAcetamide Bu4NBF4	lgK:2.59 (3SF)	5	MGL	7225
2	25	0.1	DiMeAcetamide Bu4NBF4	dH:-0.24 (2SF)	5	MCL	7225

Reaction No. 68487							
2<SCN-1> + Mn+2 = Mn+2_SCN-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1.5	NaClO4	lgK:1.30 (3SF)	5	MDS	11516

Note (1): Tribalat S et al., Compt. Rend., 1964, 258, 2828							
2	25	0	Inf. Dilution	lgK:2.09 (3SF)	2	EAE	
3	25	0.4	DMF Et4NC1O4	lgK:3.8 (0.2MD)	5	MCL	7212
4	25	0.4	DMF Et4NC1O4	dH:-0.62 (2SF)	5	MCL	7212
5	25	0.2	DiMeAcetamide Bu4NBF4	lgK:4.5 (0.1MD)	5	MCL	7239
6	25	0.2	DiMeAcetamide Bu4NBF4	dH:2.39 (3SF)	5	MCL	7239

Reaction No. 68488							
3<SCN-1> + Mn+2 = Mn+2_SCN-1 (3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NC1O4	lgK:4.6 (0.2MD)	5	MCL	7212
2	25	0.4	DMF Et4NC1O4	dH:1.67 (3SF)	5	MCL	7212
3	25	0.2	DiMeAcetamide Bu4NBF4	lgK:6.1 (0.2MD)	5	MCL	7239
4	25	0.2	DiMeAcetamide Bu4NBF4	dH:3.35 (3SF)	5	MCL	7239

Reaction No. 68489							
4<SCN-1> + Mn+2 = Mn+2_SCN-1 (4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NC1O4	lgK:5.6 (0.2MD)	5	MCL	7212
2	25	0.4	DMF Et4NC1O4	dH:3.63 (3SF)	5	MCL	7212
3	25	0.2	DiMeAcetamide Bu4NBF4	lgK:7.4 (0.2MD)	5	MCL	7239
4	25	0.2	DiMeAcetamide Bu4NBF4	dH:3.46 (3SF)	5	MCL	7239

Reaction No. 68586							
Mn+2_Trien + Trien = Mn+2_Trien (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	1	KCl	lgK:2.84 (3SF)	5	MGL	6805
2	30	1	KNO3	lgK:2.84 (3SF)	5	MGL	6805
3	40	1	KCl	lgK:2.72 (3SF)	5	MGL	6805
4	40	1	KNO3	lgK:2.72 (3SF)	5	MGL	6805

5	30:40	1	KCl	dH:-4.(1SF)	5	MTD	6805
---	-------	---	-----	-------------	---	-----	------

Reaction No. 68611							
Mn+2_AmMePhos-2 + AmMePhos-2 = Mn+2_AmMePhos-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:3.56(3SF)	5	MGL	6795

Reaction No. 68621							
2AmEtPhos-2 + Mn+2 = Mn+2_2AmEtPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:4.25(3SF)	5	MGL	6795

Reaction No. 68622							
Mn+2_2AmEtPhos-2 + 2AmEtPhos-2 = Mn+2_2AmEtPhos-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:3.13(3SF)	5	MGL	6795

Reaction No. 68633							
3AmPrPhos-2 + Mn+2 = Mn+2_3AmPrPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:4.34(3SF)	5	MGL	6795

Reaction No. 68634							
Mn+2_3AmPrPhos-2 + 3AmPrPhos-2 = Mn+2_3AmPrPhos-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:3.91(3SF)	5	MGL	6795

Reaction No. 68650							
Mn+2_PO4EtAm-2 + PO4EtAm-2 = Mn+2_PO4EtAm-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.88(3SF)	4	MGL	6795

Reaction No. 69097							
MePhos-2 + Mn+2 = Mn+2_MePhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:2.48(0.02MD)	4	MGL	1860
2	25	0.1	NaNO3	lgK:2.20(0.02MD)	5	MGL	6412
3	25	0.1	Unknown	lgK:2.5(0.1SD)	6	CIU	7242

Reaction No. 69206							
$\text{Mn}^{+2} + \text{H}^{+1}_{\text{SelenDiAcet-2}} = \text{Mn}^{+2}_{\text{H}^{+1}_{\text{SelenDiAcet-2}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:0.9(0.08SD)	5	MGL	2610

Reaction No. 69218							
$33'\text{ThioDiPr-2} + \text{Mn}^{+2} = \text{Mn}^{+2}_{33'\text{ThioDiPr-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.8(0.03SD)	5	MGL	2610

Reaction No. 69527							
$\text{Mn}^{+2}_{\text{Bipy}} + \text{Cl-1} = \text{Mn}^{+2}_{\text{Bipy}_{\text{Cl-1}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NClO4	lgK:4.64(3SF)	5	MCL	7257
2	25	0.4	DMF Et4NClO4	dH:-0.3(1SF)	5	MCL	7257

Reaction No. 69528							
$\text{Mn}^{+2}_{\text{Bipy}(2)} + \text{Cl-1} = \text{Mn}^{+2}_{\text{Bipy}(2)_{\text{Cl-1}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NClO4	lgK:5.10(3SF)	5	MCL	7257
2	25	0.4	DMF Et4NClO4	dH:-1.3(2SF)	5	MCL	7257

Reaction No. 69529							
$\text{Mn}^{+2}_{\text{Bipy}_{\text{Cl-1}}} + \text{Cl-1} = \text{Mn}^{+2}_{\text{Bipy}_{\text{Cl-1}}(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NClO4	lgK:2.95(3SF)	5	MCL	7257
2	25	0.4	DMF Et4NClO4	dH:2.2(2SF)	5	MCL	7257

Reaction No. 69530							
$\text{Mn}^{+2}_{\text{Bipy}(2)_{\text{Cl-1}}} + \text{Cl-1} = \text{Mn}^{+2}_{\text{Bipy}(2)_{\text{Cl-1}}(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NClO4	lgK:2.85(3SF)	5	MCL	7257

2	25	0.4	DMF Et4NC1O4	dH:0.53 (2SF)	5	MCL	7257
---	----	-----	-----------------	---------------	---	-----	------

Reaction No. 69531							
Mn+2_Cl-1 + Bipy = Mn+2_Bipy_Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NC1O4	lgK:2.48 (3SF)	5	MCL	7257
2	25	0.4	DMF Et4NC1O4	dH:-2.0 (2SF)	5	MCL	7257

Reaction No. 69532							
Mn+2_Bipy_Cl-1 + Bipy = Mn+2_Bipy(2)_Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NC1O4	lgK:1.55 (3SF)	5	MCL	7257
2	25	0.4	DMF Et4NC1O4	dH:-2.7 (2SF)	5	MCL	7257

Reaction No. 69533							
Mn+2_Cl-1(2) + Bipy = Mn+2_Bipy_Cl-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NC1O4	lgK:3.03 (3SF)	5	MCL	7257
2	25	0.4	DMF Et4NC1O4	dH:-5.9 (2SF)	5	MCL	7257

Reaction No. 69534							
Mn+2_Bipy_Cl-1(2) + Bipy = Mn+2_Bipy(2)_Cl-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NC1O4	lgK:1.06 (3SF)	5	MCL	7257
2	25	0.4	DMF Et4NC1O4	dH:-4.3 (2SF)	5	MCL	7257

Reaction No. 69535							
Mn+2_Bipy + Br-1 = Mn+2_Bipy_Br-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	DMF Et4NC1O4	lgK:2.36 (3SF)	5	MCL	7257
2	25	0.16	DMF Et4NC1O4	dH:2.2 (2SF)	5	MCL	7257

Reaction No. 69536							
Mn+2_Bipy(2) + Br-1 = Mn+2_Bipy(2)_Br-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	DMF Et4NC1O4	lgK:2.84 (3SF)	5	MCL	7257
2	25	0.16	DMF Et4NC1O4	dH:2.3 (2SF)	5	MCL	7257

Reaction No. 69537							
Mn+2_Bipy_Br-1 + Br-1 = Mn+2_Bipy_Br-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	DMF Et4NC1O4	lgK:1.34 (3SF)	5	MCL	7257
2	25	0.16	DMF Et4NC1O4	dH:3.3 (2SF)	5	MCL	7257

Reaction No. 69538							
Mn+2_Br-1 + Bipy = Mn+2_Bipy_Br-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	DMF Et4NC1O4	lgK:1.98 (3SF)	5	MCL	7257
2	25	0.16	DMF Et4NC1O4	dH:-2.6 (2SF)	5	MCL	7257

Reaction No. 69539							
Mn+2_Bipy_Br-1 + Bipy = Mn+2_Bipy(2)_Br-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	DMF Et4NC1O4	lgK:1.17 (3SF)	5	MCL	7257
2	25	0.16	DMF Et4NC1O4	dH:1.6 (2SF)	5	MCL	7257

Reaction No. 69540							
Mn+2_Bipy + SCN-1 = Mn+2_Bipy_SCN-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NC1O4	lgK:2.54 (3SF)	5	MCL	7257
2	25	0.4	DMF Et4NC1O4	dH:-0.4 (1SF)	5	MCL	7257

Reaction No. 69541							
--------------------	--	--	--	--	--	--	--

Mn+2_Bipy(2) + SCN-1 = Mn+2_Bipy(2)_SCN-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NClO4	lgK:2.90 (3SF)	5	MCL	7257
2	25	0.4	DMF Et4NClO4	dH:-0.7 (1SF)	5	MCL	7257

Reaction No. 69542							
Mn+2_SCN-1 + SCN-1 = Mn+2_SCN-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1.5	NaClO4	lgK:0.57 (2SF)	5	MDS	11516
Note (1): Tribalat S et al., Compt. Rend., 1964, 258, 2828							
2	25	0	Inf. Dilution	lgK:0.81 (3SF)	2	EAE	
3	25	0.4	DMF Et4NClO4	lgK:1.50 (3SF)	5	MCL	7257
4	25	0.4	DMF Et4NClO4	dH:-0.4 (1SF)	5	MCL	7257

Reaction No. 69543							
Mn+2_Bipy_SCN-1 + SCN-1 = Mn+2_Bipy_SCN-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NClO4	lgK:2.02 (3SF)	5	MCL	7257
2	25	0.4	DMF Et4NClO4	dH:-0.96 (2SF)	5	MCL	7257

Reaction No. 69544							
Mn+2_Bipy(2)_SCN-1 + SCN-1 = Mn+2_Bipy(2)_SCN-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NClO4	lgK:1.82 (3SF)	5	MCL	7257
2	25	0.4	DMF Et4NClO4	dH:-2.1 (2SF)	5	MCL	7257

Reaction No. 69545							
Mn+2_SCN-1(2) + SCN-1 = Mn+2_SCN-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NClO4	lgK:0.80 (2SF)	5	MCL	7257
2	25	0.4	DMF Et4NClO4	dH:2.3 (2SF)	5	MCL	7257

Reaction No. 69546							
Mn+2_Bipy_SCN-1(2) + SCN-1 = Mn+2_Bipy_SCN-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NC1O4	lgK:0.85 (2SF)	5	MCL	7257
2	25	0.4	DMF Et4NC1O4	dH:-0.91 (2SF)	5	MCL	7257

Reaction No. 69547							
Mn+2_SCN-1 + Bipy = Mn+2_Bipy_SCN-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NC1O4	lgK:1.77 (3SF)	5	MCL	7257
2	25	0.4	DMF Et4NC1O4	dH:-1.6 (2SF)	5	MCL	7257

Reaction No. 69548							
Mn+2_Bipy_SCN-1 + Bipy = Mn+2_Bipy(2)_SCN-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NC1O4	lgK:1.06 (3SF)	5	MCL	7257
2	25	0.4	DMF Et4NC1O4	dH:-2.0 (2SF)	5	MCL	7257

Reaction No. 69549							
Mn+2_SCN-1(2) + Bipy = Mn+2_Bipy_SCN-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NC1O4	lgK:2.29 (3SF)	5	MCL	7257
2	25	0.4	DMF Et4NC1O4	dH:-2.2 (2SF)	5	MCL	7257

Reaction No. 69550							
Mn+2_Bipy_SCN-1(2) + Bipy = Mn+2_Bipy(2)_SCN-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NC1O4	lgK:0.85 (2SF)	5	MCL	7257
2	25	0.4	DMF Et4NC1O4	dH:-3.1 (2SF)	5	MCL	7257

Reaction No. 69551							
--------------------	--	--	--	--	--	--	--

Mn+2_SCN-1(3) + Bipy = Mn+2_Bipy_SCN-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	DMF Et4NC1O4	lgK:2.34(3SF)	5	MCL	7257
2	25	0.4	DMF Et4NC1O4	dH:-5.4(2SF)	5	MCL	7257

Reaction No. 69699							
Mn+2_OxAcet-2 = Mn+2_H+1(-1)_OxAcet-2 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KCl	lgK:-7.9(2SF)	4	MKN	1503

Reaction No. 69796							
EtPhos-2 + Mn+2 = Mn+2_EtPhos-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:2.51(0.03MD)	5	MGL	1860

Reaction No. 69897							
LArabinosylThiaproline-1 + Mn+2 = Mn+2_LArabinosylThiaproline-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.4(0.06SD)	5	MGL	2304

Reaction No. 69898							
2<LArabinosylThiaproline-1> + 2<Mn+2> = H+1 + Mn+2(2)_H+1(-1)_LArabinosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-0.3(0.1SD)	5	MGL	2304

Reaction No. 69899							
2<LArabinosylThiaproline-1> + 2<Mn+2> = 2<H+1> + Mn+2(2)_H+1(-2)_LArabinosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-9.41(0.01SD)	5	MGL	2304

Reaction No. 69900							
2<LArabinosylThiaproline-1> + 2<Mn+2> = 4<H+1> + Mn+2(2)_H+1(-4)_LArabinosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-30.(0.3SD)	5	MGL	2304

Reaction No. 69901							
DXylosylThiaproline-1 + Mn+2 = Mn+2_DXylosylThiaproline-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.3(0.05SD)	5	MGL	2304

Reaction No. 69902							
2<DXylosylThiaproline-1> + 2<Mn+2> = H+1 + Mn+2(2)_H+1(-1)_DXylosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-0.5(0.1SD)	5	MGL	2304

Reaction No. 69903							
2<DXylosylThiaproline-1> + 2<Mn+2> = 2<H+1> + Mn+2(2)_H+1(-2)_DXylosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-9.3(0.2SD)	5	MGL	2304

Reaction No. 69904							
2<DXylosylThiaproline-1> + 2<Mn+2> = 4<H+1> + Mn+2(2)_H+1(-4)_DXylosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-29.(0.3SD)	5	MGL	2304

Reaction No. 69905							
DGlucosylThiaproline-1 + Mn+2 = Mn+2_DGlucosylThiaproline-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.4(0.07SD)	5	MGL	2304

Reaction No. 69906							
2<DGlucosylThiaproline-1> + 2<Mn+2> = H+1 + Mn+2(2)_H+1(-1)_DGlucosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-0.5(0.1SD)	5	MGL	2304

Reaction No. 69907							
2<DGlucosylThiaproline-1> + 2<Mn+2> = 2<H+1> + Mn+2(2)_H+1(-2)_DGlucosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-10.2(0.2SD)	5	MGL	2304

Reaction No. 69908							
--------------------	--	--	--	--	--	--	--

2<DGlucosylThiaproline-1> + 2<Mn+2> = 4<H+1> + Mn+2(2)_H+1(-4)_DGlucosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-30.(0.2SD)	5	MGL	2304

Reaction No. 69909							
DGalactosylThiaproline-1 + Mn+2 = Mn+2_DGalactosylThiaproline-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.3(0.06SD)	5	MGL	2304

Reaction No. 69910							
2<DGalactosylThiaproline-1> + 2<Mn+2> = H+1 + Mn+2(2)_H+1(-1)_DGalactosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-0.7(0.08SD)	5	MGL	2304

Reaction No. 69911							
2<DGalactosylThiaproline-1> + 2<Mn+2> = 2<H+1> + Mn+2(2)_H+1(-2)_DGalactosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-10.3(0.2SD)	5	MGL	2304

Reaction No. 69912							
2<DGalactosylThiaproline-1> + 2<Mn+2> = 4<H+1> + Mn+2(2)_H+1(-4)_DGalactosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-30.(0.2SD)	5	MGL	2304

Reaction No. 69913							
LRhamnosylThiaproline-1 + Mn+2 = Mn+2_LRhamnosylThiaproline-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.2(0.07SD)	5	MGL	2304

Reaction No. 69914							
2<LRhamnosylThiaproline-1> + 2<Mn+2> = H+1 + Mn+2(2)_H+1(-1)_LRhamnosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-0.5(0.1SD)	5	MGL	2304

Reaction No. 69915							
--------------------	--	--	--	--	--	--	--

2<LRhamnosylThiaproline-1> + 2<Mn+2> = 2<H+1> + Mn+2(2)_H+1(-2)_LRhamnosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-10.5(0.2SD)	5	MGL	2304

Reaction No. 69916							
2<LRhamnosylThiaproline-1> + 2<Mn+2> = 4<H+1> + Mn+2(2)_H+1(-4)_LRhamnosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-31.0(0.2SD)	5	MGL	2304

Reaction No. 69917							
DRibosylThiaproline-1 + Mn+2 = Mn+2_DRibosylThiaproline-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.2(0.08SD)	5	MGL	2304

Reaction No. 69918							
2<DRibosylThiaproline-1> + 2<Mn+2> = H+1 + Mn+2(2)_H+1(-1)_DRibosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-0.5(0.1SD)	5	MGL	2304

Reaction No. 69919							
2<DRibosylThiaproline-1> + 2<Mn+2> = 2<H+1> + Mn+2(2)_H+1(-2)_DRibosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-9.9(0.2SD)	5	MGL	2304

Reaction No. 69920							
2<DRibosylThiaproline-1> + 2<Mn+2> = 4<H+1> + Mn+2(2)_H+1(-4)_DRibosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-30.(0.3SD)	5	MGL	2304

Reaction No. 69921							
DArabinosylThiaproline-1 + Mn+2 = Mn+2_DArabinosylThiaproline-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:1.9(0.07SD)	5	MGL	2304

Reaction No. 69922							
--------------------	--	--	--	--	--	--	--

2<DArabinosylThiaproline-1> + 2<Mn+2> = H+1 + Mn+2(2)_H+1(-1)_DArabinosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-0.6(0.2SD)	5	MGL	2304

Reaction No. 69923							
2<DArabinosylThiaproline-1> + 2<Mn+2> = 2<H+1> + Mn+2(2)_H+1(-2)_DArabinosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-10.2(0.2SD)	5	MGL	2304

Reaction No. 69924							
2<DArabinosylThiaproline-1> + 2<Mn+2> = 4<H+1> + Mn+2(2)_H+1(-4)_DArabinosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-31.(0.3SD)	5	MGL	2304

Reaction No. 69925							
DLyxosylThiaproline-1 + Mn+2 = Mn+2_DLyxosylThiaproline-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.2(0.07SD)	5	MGL	2304

Reaction No. 69926							
2<DLyxosylThiaproline-1> + 2<Mn+2> = H+1 + Mn+2(2)_H+1(-1)_DLyxosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-0.5(0.1SD)	5	MGL	2304

Reaction No. 69927							
2<DLyxosylThiaproline-1> + 2<Mn+2> = 2<H+1> + Mn+2(2)_H+1(-2)_DLyxosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-10.3(0.2SD)	5	MGL	2304

Reaction No. 69928							
2<DLyxosylThiaproline-1> + 2<Mn+2> = 4<H+1> + Mn+2(2)_H+1(-4)_DLyxosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-31.(0.3SD)	5	MGL	2304

Reaction No. 69929							
--------------------	--	--	--	--	--	--	--

DMannosylThiaproline-1 + Mn+2 = Mn+2_DMannosylThiaproline-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.1(0.08SD)	5	MGL	2304

Reaction No. 69930							
2<DMannosylThiaproline-1> + 2<Mn+2> = H+1 + Mn+2(2)_H+1(-1)_DMannosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-0.5(0.1SD)	5	MGL	2304

Reaction No. 69931							
2<DMannosylThiaproline-1> + 2<Mn+2> = 2<H+1> + Mn+2(2)_H+1(-2)_DMannosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-10.4(0.2SD)	5	MGL	2304

Reaction No. 69932							
2<DMannosylThiaproline-1> + 2<Mn+2> = 4<H+1> + Mn+2(2)_H+1(-4)_DMannosylThiaproline-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-31.(0.3SD)	5	MGL	2304

Reaction No. 69990							
Tau-1 + Mn+2 = Mn+2_Tau-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:3.0(0.1SD)	5	MGL	2739


Reaction No. 69991							
Mn+2_Tau-1 + Tau-1 = Mn+2_Tau-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:3.4(0.1SD)	5	MGL	2739

Reaction No. 70004							
3AmPrSulf-1 + Mn+2 = Mn+2_3AmPrSulf-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:2.4(0.2SD)	5	MGL	2739

Reaction No. 70005							
Mn+2_3AmPrSulf-1 + 3AmPrSulf-1 = Mn+2_3AmPrSulf-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0.1	NaClO4	lgK:2.9(0.2SD)	5	MGL	2739
---	----	-----	--------	----------------	---	-----	------

Reaction No. 70250




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-5.(1SF)	0	ENS	7276

Reaction No. 70251




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:57.8(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:58.(2SF)	0	ENS	7276

Reaction No. 70482



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:86.2(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:1.679(4SF)	0	ENS	7381
3	25	0	Inf. Dilution	E:1.692(4SF)	0	CRV	7761
4	25	0	Inf. Dilution	dH:-547.7(4SF)kJ	2	CRV	7761

Reaction No. 70510



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:78.7(3SF)	1	EOR	
2	25	0	Inf. Dilution	dG:-106.9(4SF)	4	CRV	6488
3	25	0	Inf. Dilution	dG:-500.7(4SF)kJ	0	ENS	7381
4	25	0	Inf. Dilution	dG:-447.2(4SF)kJ	5	CRV	7421
5	25	0	Inf. Dilution	dG:-107.600(6SF)	0	CRV	9029
6	25	0	Inf. Dilution	dG:-106.90(5SF)	2	CRV	10174
7	50	0	Inf. Dilution	dG:-108.04(5SF)	0	CRV	10174
8	75	0	Inf. Dilution	dG:-109.18(5SF)	0	CRV	10174
9	100	0	Inf. Dilution	dG:-110.33(5SF)	0	CRV	10174
10	125	0	Inf. Dilution	dG:-111.47(5SF)	0	CRV	10174
11	150	0	Inf. Dilution	dG:-112.60(5SF)	0	CRV	10174
12	175	0	Inf. Dilution	dG:-113.72(5SF)	0	CRV	10174
13	200	0	Inf. Dilution	dG:-114.82(5SF)	0	CRV	10174

14	225	0	Inf. Dilution	dG:-115.89(5SF)	0	CRV	10174
15	250	0	Inf. Dilution	dG:-116.91(5SF)	0	CRV	10174
16	300	0	Inf. Dilution	dG:-118.69(5SF)	0	CRV	10174
17	25	0	Inf. Dilution	dH:-129.4(4SF)	4	CRV	6488
18	25	0	Inf. Dilution	dH:-653.(3SF) kJ	0	ENS	7381
19	25	0	Inf. Dilution	dH:-129.900(6SF)	2	CRV	9029

Reaction No. 70710							
$\text{Mn}^{2+}_{\text{OH}-1(2)}(\text{s}) = \text{Mn}^{2+} + 2\text{OH}^{-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-12.8(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-8.72(3SF)	0	CRV	
Note (2): http://www.saltlakemetals.com/SolubilityProducts.htm (15/7/14)							
3	25	0	Inf. Dilution	lgK:-12.69(4SF)	3	CRV	6330
Note (3): p. 8-58							
4	25	0	Inf. Dilution	lgK:-12.8(3SF)	0	CRV	6405
5	25	0	Inf. Dilution	lgK:-13.40(4SF)	0	ENS	7694
6	25	0	Inf. Dilution	lgK:-12.8(3SF)	3	EOD	16981
7	25	0	Inf. Dilution	lgK:-13.4(3SF)	0	CRV	22551

Reaction No. 70761							
$3\text{OH}^{-1} + \text{Mn}^{2+} = \text{Mn}^{2+}_{\text{OH}^{-1}(3)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:1.74(3SF)	4	MQH	7703

Reaction No. 71074							
$\text{Mn}^{3+}_{\text{OH}-1(3)}(\text{s}) + \text{e}^{-1} = \text{Mn}^{2+}_{\text{OH}-1(2)}(\text{s}) + \text{OH}^{-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.9(2SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.15(2SF)	0	CRV	6330
3	25	0	Inf. Dilution	E:0.05(1SF)	0	CRV	7761
4	25	0	Inf. Dilution	dH:-30.7(3SF) kJ	2	CRV	7761

Reaction No. 71075							
$\text{Mn}^{2+}_{\text{OH}-1(2)}(\text{s}) + 2\text{e}^{-1} = \text{Mn}(\text{s}) + 2\text{OH}^{-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-52.6(3SF)	1	ELC	

2	25	0	Inf. Dilution	E:-1.56(3SF)	0	CRV	6330
3	25	0	Inf. Dilution	E:-1.560(4SF)	0	CRV	7761
4	25	0	Inf. Dilution	E:-1.56(3SF)	0	CRV	22551
5	25	0	Inf. Dilution	dH:235.4(4SF) kJ	2	CRV	7761

Reaction No. 71076							
$\text{MnO4-2} + 2\text{<H2O>} + 2\text{<e-1>} = \text{MnO2}(\alpha, s) + 4\text{<OH-1>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:0.60(2SF)	0	CRV	6330

Reaction No. 71077							
$\text{MnO4-1} + 2\text{<H2O>} + 3\text{<e-1>} = \text{MnO2}(\alpha, s) + 4\text{<OH-1>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:30.26(4SF)	1	ELC	
Note (1): seems odd; implies alpha less stable than beta polymorph							
2	25	0	Inf. Dilution	E:0.595(3SF)	0	CRV	6330

Reaction No. 71078							
$\text{MnO4-1} + 4\text{<H+1>} + 3\text{<e-1>} = \text{MnO2}(\alpha, s) + 2\text{<H2O>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:86.3(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:1.697(4SF)	0	CRV	6330

Reaction No. 71079							
$\text{MnO4-1} + \text{e-1} = \text{MnO4-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:0.558(3SF)	5	CRV	6330
2	25	0	Inf. Dilution	E:0.56(2SF)	5	CRV	7761
3	25	0	Inf. Dilution	E:0.56(2SF)	4	CRV	22551
4	25	0	Inf. Dilution	dH:-113.0(4SF) kJ	5	CRV	7761

Reaction No. 71080							
$\text{MnO2}(\alpha, s) + 4\text{<H+1>} + 2\text{<e-1>} = \text{Mn+2} + 2\text{<H2O>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:41.6(3SF)	5	CRV	6405
2	25	0	Inf. Dilution	E:1.224(4SF)	5	CRV	6330
3	25	0	Inf. Dilution	E:1.236(0.002SD)	3	CRV	18118

Reaction No. 71218							
$K(s) + Mn(s) + 2O_2(g) = K+1_MnO4-1(s)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-737.6(4SF)kJ	5	CRV	6330
2	25	0	Inf. Dilution	dH:-837.2(4SF)kJ	5	CRV	6330

Reaction No. 71466							
$H+1(3)_MnO4-3 + H+1 + e-1 = MnO2(beta,s) + 2H_2O$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:49.0(3SF)	1	EDH	
2	25	0	Inf. Dilution	E:2.9(2SF)	3	CRV	7761

Reaction No. 71467							
$H+1(3)_MnO4-3 + H+1 + e-1 = MnO2(am.,s) + 2H_2O$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:45.6(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:2.7(2SF)	0	CRV	7761

Reaction No. 71468							
$H+1(3)_MnO4-3 + 3H+1 + e-1 = Mn+4_OH-1(2) + 2H_2O$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:42.9(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:2.5(2SF)	0	CRV	7761

Reaction No. 71469							
$H+1_MnO4-2 + 3H+1 + 2e-1 = MnO2(beta,s) + 2H_2O$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:70.7(3SF)	1	EES	
2	25	0	Inf. Dilution	E:2.09(3SF)	3	CRV	7761

Reaction No. 71470							
$H+1_MnO4-2 + 3H+1 + 2e-1 = MnO2(am.,s) + 2H_2O$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:67.2(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:2.00(3SF)	0	CRV	7761

Reaction No. 71471							
--------------------	--	--	--	--	--	--	--

H+1_MnO4-2 + 5<H+1> + 2<e-1> = Mn+4_OH-1(2) + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:64.5(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:1.9(2SF)	0	CRV	7761

Reaction No. 71472							
MnO4-1 + 4<H+1> + 3<e-1> = MnO2(am.,s) + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:82.7(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:1.63(3SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:-528.8(4SF)kJ	2	CRV	7761

Reaction No. 71473							
MnO4-1 + 6<H+1> + 3<e-1> = Mn+4_OH-1(2) + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:80.0(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:1.57(3SF)	0	CRV	7761

Reaction No. 71474							
Mn+4_OH-1(2) + 2<H+1> + 2<e-1> = Mn+2 + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:1.41(3SF)	3	CRV	7761

Reaction No. 71475							
MnO4-1 + 7<H+1> + 5<e-1> = Mn+2_OH-1 + 3<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:117.2(4SF)	1	ELC	
2	25	0	Inf. Dilution	E:1.382(4SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:-759.9(4SF)kJ	3	CRV	7761

Reaction No. 71476							
MnO2(am.,s) + 4<H+1> + 2<e-1> = Mn+2 + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:45.1(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:1.32(3SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:-290.4(4SF)kJ	2	CRV	7761

Reaction No. 71477							
$\text{H}+1_ \text{MnO4-2} + 2\text{<H}+1\text{>} + \text{e-1} = \text{H}+1(3)_ \text{MnO4-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.6(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:1.3(2SF)	0	CRV	7761

Reaction No. 71478							
$\text{Mn}+4_ \text{OH-1}(2) + 2\text{<H}+1\text{>} + \text{e-1} = \text{Mn}+3 + 2\text{<H}_2\text{O>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:1.3(2SF)	5	CRV	7761

Reaction No. 71479							
$\text{MnO2}(\text{am.,s}) + 4\text{<H}+1\text{>} + \text{e-1} = \text{Mn}+3 + 2\text{<H}_2\text{O>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.3(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:1.08(3SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:-190.5(4SF) kJ	2	CRV	7761

Reaction No. 71480							
$\text{MnO2}(\text{beta,s}) + \text{H}+1 + \text{e-1} = \text{MnOOH}(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:0.98(2SF)	4	CRV	7761
2	25	0	Inf. Dilution	dH:-108.9(4SF) kJ	3	CRV	7761

Reaction No. 71481							
$2\text{<MnO2}(\text{beta,s})\text{>} + 2\text{<H}+1\text{>} + 2\text{<e-1>} = \text{Mn}_2\text{O}_3(\text{s}) + \text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:33.4(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.974(3SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:-204.8(4SF) kJ	3	CRV	7761

Reaction No. 71482							
$\text{MnO2}(\text{beta,s}) + 3\text{<H}+1\text{>} + 2\text{<e-1>} = \text{Mn}+2_ \text{OH-1} + \text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:0.916(3SF)	5	CRV	7761
2	25	0	Inf. Dilution	dH:-212.1(4SF) kJ	5	CRV	7761

Reaction No. 71483							
$\text{MnO4-1} + \text{H+1} + \text{e-1} = \text{H+1_MnO4-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.5 (3SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.90 (2SF)	0	CRV	7761

Reaction No. 71484							
$\text{MnO4-3} + 2\langle\text{H2O}\rangle + \text{e-1} = \text{MnO2}(\text{beta},\text{s}) + 4\langle\text{OH-1}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.1 (3SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.93 (2SF)	0	CRV	7761

Reaction No. 71485							
$\text{MnO4-3} + 2\langle\text{H2O}\rangle + \text{e-1} = \text{MnO2}(\text{am.},\text{s}) + 4\langle\text{OH-1}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.7 (3SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.76 (2SF)	0	CRV	7761


Reaction No. 71486							
$\text{MnO4-3} + 4\langle\text{H2O}\rangle + \text{e-1} = \text{Mn+4_OH-1(6)} + 2\langle\text{OH-1}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.3 (3SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.7 (1SF)	0	CRV	7761

Reaction No. 71487							
$\text{MnO4-2} + 2\langle\text{H2O}\rangle + 2\langle\text{e-1}\rangle = \text{MnO2}(\text{beta},\text{s}) + 4\langle\text{OH-1}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.7 (3SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.60 (2SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:-210.7 (4SF) kJ	2	CRV	7761

Reaction No. 71488							
$\text{MnO4-1} + 3\langle\text{e-1}\rangle + 2\langle\text{H2O}\rangle = \text{MnO2}(\text{beta},\text{s}) + 4\langle\text{OH-1}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:30.2 (3SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.588 (3SF)	0	CRV	7761
3	25	0	Inf. Dilution	E:0.06 (1SF)	0	CRV	10174


4	25	0	Inf. Dilution	E:0.587(3SF)	0	CRV	13213
5	25	0	Inf. Dilution	dH:-324.2(4SF)kJ	2	CRV	7761

Reaction No. 71489




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:26.7(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.53(2SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:-307.0(4SF)kJ	2	CRV	7761

Reaction No. 71490




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:0.51(2SF)	3	CRV	7761
2	25	0	Inf. Dilution	dH:-192.8(4SF)kJ	3	CRV	7761

Reaction No. 71491




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:26.4(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.50(2SF)	0	CRV	7761

Reaction No. 71492



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.9(3SF)	1	EDH	
2	25	0	Inf. Dilution	E:0.5(1SF)	3	CRV	7761

Reaction No. 71493



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:0.27(2SF)	3	CRV	7761
2	25	0	Inf. Dilution	E:0.27(2SF)	3	CRV	22551


Reaction No. 71494



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	E:0.15 (2SF)	4	CRV	7761
2	25	0	Inf. Dilution	dH:-54.7 (3SF) kJ	3	CRV	7761

Reaction No. 71495




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.3 (2SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.146 (3SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:-92.7 (3SF) kJ	2	CRV	7761

Reaction No. 71496




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.8 (2SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.04 (1SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:-81.4 (3SF) kJ	2	CRV	7761

Reaction No. 71497



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.0 (2SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.03 (1SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:-51.8 (3SF) kJ	2	CRV	7761

Reaction No. 71498



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.3 (1SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.002 (1SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:-72.3 (3SF) kJ	2	CRV	7761

Reaction No. 71499



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.5 (1SF)	1	ELC	
2	25	0	Inf. Dilution	E:-0.02 (1SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:-15.3 (3SF) kJ	2	CRV	7761

Reaction No. 71500							
$\text{Mn}^{2+}_{\text{OH}-1} + \text{H}^{+1} + 2\text{e}^{-1} = \text{Mn(s)} + \text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: -29.3(3\text{SF})$	1	ELC	
2	25	0	Inf. Dilution	$E: -0.869(3\text{SF})$	0	CRV	7761
3	25	0	Inf. Dilution	$\text{dH}: 160.5(4\text{SF}) \text{ kJ}$	2	CRV	7761

Reaction No. 71501							
$\text{Mn}^{3+}_{\text{OH}-1(4)} + \text{e}^{-1} = \text{Mn}^{2+}_{\text{OH}-1(4)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$E: -0.1(1\text{SF})$	3	CRV	7761

Reaction No. 71502							
$\text{Mn}^{4+}_{\text{OH}-1(6)} + \text{e}^{-1} = \text{Mn}^{3+}_{\text{OH}-1(4)} + 2\text{OH}^{-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: -1.2(2\text{SF})$	1	ELC	
2	25	0	Inf. Dilution	$E: -0.1(1\text{SF})$	0	CRV	7761

Reaction No. 71503							
$\text{MnO}_2(\text{beta}, \text{s}) + 4\text{H}^{+1} + \text{e}^{-1} = \text{Mn}^{3+} + 2\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 15.9(3\text{SF})$	1	ELC	
2	25	0	Inf. Dilution	$E: 0.90(2\text{SF})$	0	CRV	7761
3	25	0	Inf. Dilution	$\text{dH}: -173.1(4\text{SF}) \text{ kJ}$	3	CRV	7761

Reaction No. 71504							
$\text{Mn}_2\text{O}_3(\text{s}) + 4\text{H}^{+1} + 2\text{e}^{-1} = 2\text{Mn}^{2+}_{\text{OH}-1} + \text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 28.7(3\text{SF})$	1	ELC	
2	25	0	Inf. Dilution	$E: 0.858(3\text{SF})$	0	CRV	7761
3	25	0	Inf. Dilution	$\text{dH}: -219.4(4\text{SF}) \text{ kJ}$	2	CRV	7761

Reaction No. 71505							
$\text{MnOOH(s)} + 2\text{H}^{+1} + \text{e}^{-1} = \text{Mn}^{2+}_{\text{OH}-1} + \text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 14.6(3\text{SF})$	1	ELC	


2	25	0	Inf. Dilution	E:0.85 (2SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:-102.1 (4SF) kJ	2	CRV	7761

Reaction No. 71506




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-4.1 (2SF)	1	ELC	
2	25	0	Inf. Dilution	E:-0.129 (3SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:-39.3 (3SF) kJ	2	CRV	7761

Reaction No. 71507




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-13.5 (3SF)	1	ELC	
2	25	0	Inf. Dilution	E:-0.404 (3SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:14.4 (3SF) kJ	2	CRV	7761

Reaction No. 71508




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-20.1 (3SF)	1	ELC	
2	25	0	Inf. Dilution	E:-0.607 (3SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:58.0 (3SF) kJ	2	CRV	7761

Reaction No. 71509



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-47.6 (3SF)	1	ELC	
2	25	0	Inf. Dilution	E:-1.42 (3SF)	0	CRV	7761

Reaction No. 71510



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-50.2 (3SF)	1	ELC	
2	25	0	Inf. Dilution	E:-1.480 (4SF)	0	CRV	7761
3	25	0	Inf. Dilution	dH:211.1 (4SF) kJ	2	CRV	7761

Reaction No. 71574							
PMEDAP-2 + Mn+2 = Mn+2_PMEDAP-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:2.51(0.03MD)w	5	MPH	8309

Reaction No. 71575							
Mn+2 + H+1_PMEDAP-2 = Mn+2_H+1_PMEDAP-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:0.8(0.3MD)w	5	MPH	8309

Reaction No. 72390							
Mn(s) - 3<e-1> = Mn+3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.1(3SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-74.(2SF)kJ	0	CRV	7421
3	25	0	Inf. Dilution	dG:-20.300(5SF)	0	CRV	9029
4	25	0	Inf. Dilution	dH:-30.700(5SF)	1	CRV	9029

Reaction No. 72391							
Mn(s) + 2<O2(g)> + 2<e-1> = MnO4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:87.8(3SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-119.7(4SF)	0	CRV	6488
3	25	0	Inf. Dilution	dG:-500.8(4SF)kJ	0	CRV	7421
4	25	0	Inf. Dilution	dG:-120.400(6SF)	0	CRV	9029
5	25	0	Inf. Dilution	dG:-119.70(5SF)	0	CRV	10174
6	50	0	Inf. Dilution	dG:-120.00(5SF)	0	CRV	10174
7	75	0	Inf. Dilution	dG:-120.20(5SF)	0	CRV	10174
8	100	0	Inf. Dilution	dG:-120.31(5SF)	0	CRV	10174
9	125	0	Inf. Dilution	dG:-120.34(5SF)	0	CRV	10174
10	150	0	Inf. Dilution	dG:-120.28(5SF)	0	CRV	10174
11	175	0	Inf. Dilution	dG:-120.11(5SF)	0	CRV	10174
12	200	0	Inf. Dilution	dG:-119.83(5SF)	0	CRV	10174
13	225	0	Inf. Dilution	dG:-119.41(5SF)	0	CRV	10174
14	250	0	Inf. Dilution	dG:-118.80(5SF)	0	CRV	10174
15	300	0	Inf. Dilution	dG:-116.75(5SF)	0	CRV	10174
16	25	0	Inf. Dilution	dH:-156.0(4SF)	0	CRV	6488

17	25	0	Inf. Dilution	dH:-156.600(6SF)	0	CRV	9029
----	----	---	---------------	------------------	---	-----	------

Reaction No. 72441							
Mn+2 + H+1_SO4-2 = Mn+2_H+1_SO4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	2.7	NaClO4	lgK:0.08(1SF)	5	MPS	726
2	23	4.3	NaClO4	lgK:0.21(2SF)	5	MPS	726
3	23	5	NaClO4	lgK:0.27(2SF)	5	MPS	726
4	23	6.6	NaClO4	lgK:0.40(2SF)	5	MPS	726
5	23	8.2	NaClO4	lgK:0.57(2SF)	5	MPS	726
6	25	0	Inf. Dilution	lgK:0.727(3SF)	2	EAE	

Reaction No. 72595							
2MeGlutar-2 + Mn+2 = Mn+2_2MeGlutar-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.035	KCl	lgK:2.51(3SF)	4	MSP	5748

Reaction No. 72599							
3MeGlutar-2 + Mn+2 = Mn+2_3MeGlutar-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.035	KCl	lgK:2.45(3SF)	4	MSP	5748


Reaction No. 72604							
33DiMeGlutar-2 + Mn+2 = Mn+2_33DiMeGlutar-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.035	KCl	lgK:2.82(3SF)	4	MSP	5748

Reaction No. 72794							
FAcet-1 + Mn+2 = Mn+2_FAcet-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:1.43(3SF)	5	MGL	6036

Reaction No. 72801							
BrAcet-1 + Mn+2 = Mn+2_BrAcet-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:1.49 (3SF)	5	MGL	6036
---	----	-----	------------------------------------	----------------	---	-----	------

Reaction No. 72805




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:1.41 (3SF)	5	MGL	6036

Reaction No. 72816




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:1.69 (3SF)	5	MGL	6036

Reaction No. 72820




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Dioxan:Water 50:50Wgt NaClO4	lgK:1.68 (3SF)	5	MGL	6036

Reaction No. 72902




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:0.70 (0.05SD)	5	MGL	6089

Reaction No. 72903



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:0.6 (0.2SD)	5	MGL	6089

Reaction No. 72916



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:0.9 (1SF)	3	MGL	6086
2	25	1	KNO3	lgK:1.0 (2SF)	3	MGL	6086

Reaction No. 72959							
$\text{Mn+2_SeO3-2_H2O(2)} = \text{Mn+2} + \text{SeO3-2} + 2\text{<H2O>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-7.07 (3SF)	4	MSL	12931

Reaction No. 72979							
$\text{Mn+2_H+1_OH-1_Se-2} = \text{Mn+2} + \text{H+1_Se-2} + \text{OH-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:-8.02 (0.20SD)	5	MSL	5554

Reaction No. 73016							
$\text{Mn+2_5ATP-4} + \text{H+1} = \text{Mn+2_H+1_5ATP-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:4.20 (0.04SD)	5	MGL	6100

Reaction No. 73022							
$\text{Mn+2_5CTP-4} + \text{H+1} = \text{Mn+2_H+1_5CTP-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.4 (2SF)	1	ELC	
2	25	0.1	NaNO3	lgK:4.75 (0.15SD)	0	MGL	6100

Reaction No. 73030							
$\text{Mn+2_5UTP-4} + \text{H+1} = \text{Mn+2_H+1_5UTP-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.4 (2SF)	1	ELC	
2	25	0.1	NaNO3	lgK:4.24 (0.045SD)	0	MGL	6100

Reaction No. 73404							
$\text{Mn+2_AmMePhos-2} + \text{H+1} = \text{Mn+2_H+1_AmMePhos-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:8.2 (0.1SD)	6	CIU	7242

Reaction No. 73564							
$\text{Mn+2} + \text{H+1_Oxonic-3} = \text{Mn+2_H+1_Oxonic-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.2	Inf. Dilution	lgK:3.85 (0.08SD)	4	MPH	1853

Reaction No. 73700							
--------------------	--	--	--	--	--	--	--

Mn+2 + H+1_S-2 = Mn+2_H+1_S-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.07	NaCl	lgK:4.65 (0.04SD)	0	MSV	16946
Note (1): Measurement Using A Tenth-Strength Seawater							
2	25	0.35	NaCl	lgK:4.88 (0.24SD)	0	MSV	16946
Note (2): Measurement Using Half-Strength Seawater							
3	25	0.55	NaCl	lgK:4.78 (0.20SD)	3	MSV	16946
Note (3): This is an average constant from measurements at I=0.7, 0.35 and 0.07M Seawater							
4	25	0.7	NaCl	lgK:4.76 (0.21SD)	0	MSV	16946
Note (4): Measurement Using Seawater							

Reaction No. 73704							
2<Mn+2> + H+1_S-2 = Mn+2 (2)_H+1_S-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.07	NaCl	lgK:9.70 (0.01SD)	0	MSV	16946
Note (1): Measurement Using A Tenth-Strength Seawater							
2	25	0.35	NaCl	lgK:10.03 (0.18SD)	0	MSV	16946
Note (2): Measurement Using A Half-Strength Seawater							
3	25	0.55	NaCl	lgK:9.82 (0.28SD)	3	MSV	16946
Note (3): This is an average constant from measurements at I=0.7, 0.35 and 0.07M Seawater							
4	25	0.7	NaCl	lgK:9.67 (0.36SD)	0	MSV	16946
Note (4): Measurement Using Seawater							

Reaction No. 73708							
3<Mn+2> + H+1_S-2 = Mn+2 (3)_H+1_S-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.07	NaCl	lgK:15.15 (0.04SD)	0	MSV	16946
Note (1): Measurement Using A Tenth-Strength Seawater							
2	25	0.35	NaCl	lgK:15.47 (0.39SD)	0	MSV	16946
Note (2): Measurement Using A Half-Strength Seawater							
3	25	0.55	NaCl	lgK:15.44 (0.31SD)	3	MSV	16946
Note (3): This is an average constant from measurements at I=0.7, 0.35 and 0.07M Seawater							
4	25	0.7	NaCl	lgK:15.43 (0.34SD)	0	MSV	16946
Note (4): Measurement Using Seawater							

Reaction No. 73715							
$\text{Mn}^{+2} + \text{S}^{4-2} = \text{Mn}^{+2}_{\text{S}^{4-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Na ₂ SO ₄	lgK:5.63 (0.13SD)	3	MCV	20758
2	25	0.55	NaCl	lgK:5.81 (0.13SD)	3	MCV	20758

Reaction No. 73719							
$2\langle\text{Mn}^{+2}\rangle + \text{S}^{4-2} = \text{Mn}^{+2}(2)_{\text{S}^{4-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	Na ₂ SO ₄	lgK:11.69 (0.16SD)	3	MCV	20758
2	25	0.55	NaCl	lgK:11.26 (0.20SD)	3	MCV	20758

Reaction No. 74058							
$\text{Mn}^{+3}_{\text{CN-1}(6)} + \text{e-1} = \text{Mn}^{+2}_{\text{CN-1}(6)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:-0.24 (2SF)	4	CRV	22551

Reaction No. 74059							
$\text{MnO}^{4-1} + 5\langle\text{e-1}\rangle + 4\langle\text{H}_2\text{O}\rangle = \text{Mn}^{+2}_{\text{OH-1}(2)}(\text{s}) + 6\langle\text{OH-1}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:28.5 (3SF)	1	ELC	
2	25	0	Inf. Dilution	E:1.34 (3SF)	0	CRV	22551

Reaction No. 74060							
$\text{MnO}_2(\text{gamma},\text{s}) + \text{e-1} + \text{H}_2\text{O} = \text{MnOOH}(\text{alpha},\text{s}) + \text{OH-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:0.3 (1SF)	1	CRV	22551
Note (1): Looks like an incorrect swapping of greek solid phase designators							

Reaction No. 74678							
$\text{Mn}^{+2} + \text{H}^{+1}(3)_{\text{Citric-3}} = \text{Mn}^{+2}_{\text{H}^{+1}(2)_{\text{Citric-3}}} + \text{H}^{+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.7	KNO ₃	lgK:-1.44 (3SF)	4	MEP	13105

Reaction No. 74679							
$\text{Mn}^{+2}_{\text{H}^{+1}(2)_{\text{Citric-3}}} = \text{Mn}^{+2}_{\text{Citric-3}} + 2\langle\text{H}^{+1}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0	Inf. Dilution	lgK:-8.1(2SF)	1	EOR	
2	25	0.7	KNO3	lgK:-8.6(2SF)	3	MEP	13105

Reaction No. 74680							
$\text{Mn}^{+2} + \text{H}^{+1}(3)\text{Citric-3} = \text{Mn}^{+2}\text{H}^{+1}\text{Citric-3} + 2\text{H}^{+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-4.58(3SF)	2	EAE	
2	33	0.25	NaClO4	lgK:-4.9(2SF)	4	MGL	22560

Reaction No. 74831							
$0.333334\text{Mn}_3\text{O}_4(\text{s}) + 2\text{H}^{+1} = \text{Mn}^{+2} + 0.16667\text{O}_2(\text{g}) + \text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.5(2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:6.61(3SF)	0	EOD	22834

Reaction No. 74832							
$\text{Mn}_3\text{O}_4(\text{s}) + 2\text{H}^{+1} = \text{Mn}^{+2} + 2\text{MnOOH}(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.7(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:10.69(4SF)	0	EOD	22834

Reaction No. 74860							
$\text{Mn}^{+2} + \text{H}^{+1}(3)\text{PO}_4\text{-3} = \text{Mn}^{+2}\text{H}^{+1}\text{PO}_4\text{-3} + 2\text{H}^{+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-5.7(2SF)	1	ELC	
2	25	3	NaClO4	lgK:1.5(2SF)	0	MEF	725

Reaction No. 74861							
$\text{Mn}^{+2} + \text{H}^{+1}(3)\text{PO}_4\text{-3} = \text{Mn}^{+2}\text{H}^{+1}(2)\text{PO}_4\text{-3} + \text{H}^{+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO4	lgK:1.3(2SF)	4	MEF	725

Reaction No. 74862							
$\text{Mn}^{+2} + 2\text{H}^{+1}(3)\text{PO}_4\text{-3} = \text{Mn}^{+2}\text{H}^{+1}(4)\text{PO}_4\text{-3}(2) + 2\text{H}^{+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO4	lgK:2.9(2SF)	4	MEF	725

Reaction No. 74966							
--------------------	--	--	--	--	--	--	--

Mn+2 + Lys-1 = Mn+2_Lys-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.01	Unknown	lgK:2.18 (3SF)	5	MGL	6024
2	25	0	Inf. Dilution	lgK:2.32 (3SF)	2	EAE	

Reaction No. 75006							
CrO4-2 + Mn+2 = Mn+2_CrO4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	0.01	0	Inf. Dilution	lgK:2.7356 (5SF)	4	EOD	22958
2	25	0	Inf. Dilution	lgK:2.5765 (5SF)	4	EOD	22958
3	60	0	Inf. Dilution	lgK:2.4917 (5SF)	4	EOD	22958
4	100	0	Inf. Dilution	lgK:2.5112 (5SF)	4	EOD	22958
5	150	0	Inf. Dilution	lgK:2.6779 (5SF)	4	EOD	22958
6	200	0	Inf. Dilution	lgK:3.0108 (5SF)	4	EOD	22958

Reaction No. 75247							
2<H+1> + 2<SeO4-2> + Mn+2 = Mn+2_H+1(2)_SeO4-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.15	NaClO4	lgK:9.19 (0.04SD)	5	MGL	23134
2	25	0	Inf. Dilution	lgK:10.8 (3SF)	2	EAE	


Reaction No. 75276							
3<bAla-1> + Mn+2 = Mn+2_bAla-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.8 (2SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:5.7 (2SF)	5	CRV	22388

Reaction No. 75277							
bAla-1 + Mn+2 + H+1 = Mn+2_H+1_bAla-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.3 (3SF)	1	EAE	
2	37	0.15	Blood Plasma	lgK:10. (2SF)	5	CRV	22388

Reaction No. 75278							
2<bAla-1> + Mn+2 + H+1 = Mn+2_H+1_bAla-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.2 (3SF)	1	EAE	


2	37	0.15	Blood Plasma	lgK:12.85 (4SF)	5	CRV	22388
---	----	------	--------------	-----------------	---	-----	-------

Reaction No. 75354



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.3 (3SF)	1	ESC	
2	37	0.15	Blood Plasma	lgK:11. (2SF)	5	CRV	22388


Reaction No. 75393



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-464. (3SF) kJ	1	EES	

Note (1): Based on MnO2(beta,s) for rxn linkage

Reaction No. 75657




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.4 (2SF)	1	ELC	
2	27	0.3	Unknown	lgK:2.69 (3SF)	0	MMR	1173

Note (2): In IUPAC database with Ionic Strength 0

3	37	0.15	KNO3	lgK:2.69 (3SF)	5	MGL	181
---	----	------	------	----------------	---	-----	-----


Reaction No. 75709



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.51 (3SF)	5	MGL	11516

Note (1): Manorik P et al., Zhur. Neorg. Khim., 1983, 28, 2292

Reaction No. 75711



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.59 (4SF)	3	EOD	

Note (1): R.C. Aller, in Treatise on Geochemistry (Second Edition), 2014

2	25	0	Inf. Dilution	lgK:10.31 (4SF)	3	EOD	12584
3	25	0	Inf. Dilution	lgK:11.0 (0.2SD)	6	CRV	24993
4	25	0	Inf. Dilution	lgK:10.41 (4SF)	2	EOD	29419
5	25	0	Inf. Dilution	lgK:10.54 (4SF)	4	CRV	32224

Reaction No. 75781							
Mn+2_Asn-1 + Asn-1 = Mn+2_Asn-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO4	lgK:2.12(3SF)	4	MGL	1602

Reaction No. 75803							
Mn+2_Glu-2 + Glu-2 = Mn+2_Glu-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.5(2SF)	1	ELC	
2	25	0.1	KNO3	lgK:3.53(3SF)	0	MGL	11516
Note (2): Girdhar H et al., Indian J. Chem., 1976, 14A, 1021							

Reaction No. 75850							
Mn+2_Gln-1 + Gln-1 = Mn+2_Gln-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO4	lgK:1.76(3SF)	5	MGL	2161

Reaction No. 75893							
Mn+2_Citric-3 + Citric-3 = Mn+2_Citric-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4N+ salt	lgK:1.99(3SF)	5	MGL	152


Reaction No. 76119							
Mn+2 + 2<SO4-2> = Mn+2_SO4-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:1.15(3SF)	5	MSL	11516
Note (1): Fedorov V et al., Koord. Khim., 1975, 1, 836							

Reaction No. 76169							
Mn+2_Succinic-2 + Succinic-2 = Mn+2_Succinic-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.8(3SF)	2	EAE	
2	37	0.15	NaClO4	lgK:2.73(3SF)	5	MGL	2156

Reaction No. 76197							
Mn+2_BAL-2 + BAL-2 = Mn+2_BAL-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	30	0.1	KCl	lgK:5.20 (3SF)	5	MGL	8200
---	----	-----	-----	----------------	---	-----	------


Reaction No. 76260



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.07 (3SF)	5	MGL	11516

Note (1): Siddhanta S et al., J. Indian Chem. Soc., 1958, 35, 419

Reaction No. 76464




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:1.73 (3SF)	5	MGL	11516

Note (1): Lianfen J et al., Chem. J. of Chin. Univ., 1984, 879

2	30	0.1	NaClO4	lgK:2.00 (3SF)	5	MSP	11516
---	----	-----	--------	----------------	---	-----	-------

Note (2): Khadikar P et al., Indian J. Chem., 1975, 13, 525


Reaction No. 76465



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	NaClO4	lgK:1.40 (3SF)	5	MSP	11516

Note (1): Khadikar P et al., Indian J. Chem., 1975, 13, 525

Reaction No. 76595




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-6.77 (3SF)	3	CRV	6330

Note (1): p. 8-58

2	25	0	Inf. Dilution	lgK:-6.54 (3SF)	3	MSL	23272
---	----	---	---------------	-----------------	---	-----	-------

Reaction No. 76864



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	31	0.1	NaClO4	lgK:5.11 (3SF)	1	EOD	22560

Note (1): Singh et al., Thermochim. Acta, 1984, 78, 175

Reaction No. 76865



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	31	0.1	NaClO ₄	lgK:3.75 (3SF)	1	EOD	22560
Note (1): Singh et al., Thermochim. Acta, 1984, 78, 175							

Reaction No. 76866							
2<2Thiobarb-2> + Mn+2 = Mn+2_2Thiobarb-2 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	31	0.1	NaClO ₄	lgK:8.86 (3SF)	1	EOD	22560
Note (1): Singh et al., Thermochim. Acta, 1984, 78, 175							

Reaction No. 76946							
SemiXylenolOrange-4 + Mn+2 = Mn+2_SemiXylenolOrange-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	K+1 salt	lgK:9.4 (2SF)	3	CRV	7271

Reaction No. 77404							
K+1 + MnO ₄ -1 = K+1_MnO ₄ -1 (s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.151 (4SF)	1	ELC	

Reaction No. 77422							
ClO ₄ -1 + Mn+2 = Mn+2_ClO ₄ -1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1. (1SF)	1	EAC	


Reaction No. 77438							
2<Fe+3> + Mn+2 + 2<OH-1> + 2<PO ₄ -3> + 8<H ₂ O> = Fe+3 (2)_Mn+2_OH-1 (2)_PO ₄ -3 (2)_H ₂ O (8)_ (s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:81.4 (3SF)	1	ELC	

Reaction No. 77590							
SO ₄ -2 + Mn+3 + H+1 = Mn+3_H+1_SO ₄ -2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.073 (4SF)	1	ELC	

Reaction No. 77682							
PO ₄ -3 + Mn+3 + H+1 = Mn+3_H+1_PO ₄ -3							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.67 (4SF)	1	ELC	

Reaction No. 77694




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.3 (4SF)	1	ELC	

Reaction No. 77719




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:46.74 (4SF)	1	ELC	

Reaction No. 77726




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:35.67 (4SF)	1	ELC	

Reaction No. 77818




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.15 (4SF)	1	ELC	

Reaction No. 77828




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.53 (4SF)	1	ELC	

Reaction No. 77953



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:35.03 (4SF)	1	ELC	

Reaction No. 77957



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.339 (4SF)	1	ELC	

Reaction No. 78184							
$\text{As(s)} + \text{H}_2(\text{g}) + \text{Mn(s)} + 2\langle\text{O}_2(\text{g})\rangle - \text{e-1} = \text{Mn+2_H+1(2)_AsO4-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-989.44 (5SF) kJ	5	CRV	29482
2	25	0	Inf. Dilution	dH:-1133.10 (6SF) kJ	5	CRV	29482

Reaction No. 78210							
$\text{Citric-3} + \text{Mn+3} + 2\langle\text{H+1}\rangle = \text{Mn+3_H+1(2)_Citric-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.33 (4SF)	1	ELC	

Reaction No. 78294							
$3\langle\text{Gly-1}\rangle + \text{Mn+2} + \text{H+1} = \text{Mn+2_H+1_Gly-1(3)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.36 (4SF)	1	ELC	

Reaction No. 78344							
$\text{EDTA-4} + \text{N3-1} + \text{Mn+3} = \text{Mn+3_N3-1_EDTA-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:28.48 (4SF)	1	ELC	

Reaction No. 78351							
$\text{Citric-3} + \text{Mn+2} - \text{H+1} = \text{Mn+2_H+1(-1)_Citric-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-5.441 (4SF)	1	ELC	


Reaction No. 78361							
$\text{Ala-1} + 5\text{ATP-4} + \text{Mn+2} = \text{Mn+2_Ala-1_5ATP-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.511 (4SF)	1	ELC	

Reaction No. 78555							
$\text{Mn+2} + 2\langle\text{Br-1}\rangle = \text{Mn+2_Br-1(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.2127 (4SF)	1	ELC	

Reaction No. 78656							
$\text{PO4-3} + \text{Mn+2} + 2\langle\text{H+1}\rangle = \text{Mn+2_H+1(2)_PO4-3}$							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.05 (4SF)	1	ELC	

Reaction No. 78660



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:46.14 (4SF)	1	ELC	


Reaction No. 78898



Note: The species S-2 does not exist in aqueous solution See reaction: H+1 + S-2 = H+1_S-2


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:80.99 (4SF)	0	ELC	

Reaction No. 78903




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-11.05 (4SF)	1	ELC	

Reaction No. 78904




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.914 (4SF)	1	ELC	

Reaction No. 78905




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.15 (4SF)	1	ELC	

Reaction No. 78906



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-10.21 (4SF)	1	ELC	


Reaction No. 79150



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	lgK:5.699 (4SF)	1	ELC	
---	----	---	---------------	-----------------	---	-----	--

Reaction No. 79151




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:62.01 (4SF)	1	ELC	

Reaction No. 79152




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:35.18 (4SF)	1	ELC	

Reaction No. 79275




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.67 (4SF)	1	ELC	

Reaction No. 79287



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-17.09 (4SF)	3	EOD	29419

Reaction No. 79538




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-6.36 (3SF)	3	CRV	6330

Note (1): p. 8-58


2	25	0	Inf. Dilution	lgK:-6.320 (4SF)	5	MSL	32213
---	----	---	---------------	------------------	---	-----	-------

Reaction No. 79552




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2180.3 (5SF) kJ	4	EOD	29025
2	25	0	Inf. Dilution	dH:-2621.7 (5SF) kJ	4	EOD	29025
3	25	0	Inf. Dilution	Cp:309.0 (4SF) J/K	4	EOD	29025

Reaction No. 79553




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-2669.5 (5SF) kJ	4	EOD	29025
2	25	0	Inf. Dilution	dH:-3244.3 (5SF) kJ	4	EOD	29025
3	25	0	Inf. Dilution	Cp:392.5 (4SF) J/K	4	EOD	29025

Reaction No. 79554




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-1201.9 (5SF) kJ	4	EOD	29025
2	25	0	Inf. Dilution	dH:-1376.5 (5SF) kJ	4	EOD	29025
3	25	0	Inf. Dilution	Cp:142.1 (4SF) J/K	4	EOD	29025

Reaction No. 79561




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-783.9 (4SF) kJ	4	EOD	29025

Reaction No. 79562




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-826.0 (4SF) kJ	4	EOD	29025

Reaction No. 79570



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.08 (3SF)	1	ELC	
2	25	0	Inf. Dilution	dH:21.8 (3SF) kJ	1	ELC	

Reaction No. 79581



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.92 (3SF)	4	CRV	28992
2	25	0	Inf. Dilution	lgK:4.61 (3SF)	0	CRV	32224
3	50	0	Inf. Dilution	lgK:4.37 (3SF)	3	CRV	28992
4	100	0	Inf. Dilution	lgK:5.42 (3SF)	3	CRV	28992
5	150	0	Inf. Dilution	lgK:6.64 (3SF)	2	CRV	28992
6	200	0	Inf. Dilution	lgK:7.95 (3SF)	2	CRV	28992

Reaction No. 79584							
$\text{Mn}^{+2} + \text{WO}_4^{-2} = \text{Mn}^{+2}\text{WO}_4^{-2}(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 7.50 (3\text{SF})$	4	CRV	28992
2	50	0	Inf. Dilution	$\lg K: 7.41 (3\text{SF})$	3	CRV	28992
3	100	0	Inf. Dilution	$\lg K: 7.68 (3\text{SF})$	2	CRV	28992
4	150	0	Inf. Dilution	$\lg K: 8.34 (3\text{SF})$	2	CRV	28992
5	200	0	Inf. Dilution	$\lg K: 9.27 (3\text{SF})$	2	CRV	28992

Reaction No. 79659							
$\text{Mn}^{+2} + \text{H}^{+1}\text{CO}_3^{-2} = \text{Mn}^{+2}\text{CO}_3^{-2}(\text{s}) + \text{H}^{+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 0.1 (1\text{SF})$	1	ELC	
2	25	0	Inf. Dilution	$\lg K: 0.801 (3\text{SF})$	2	EOD	29487
3	90	0	Inf. Dilution	$\lg K: 1.46 (3\text{SF})$	2	EOD	29487
4	25	0	Inf. Dilution	$\text{dH}: 20.884 (5\text{SF}) \text{ kJ}$	2	EOD	29487

Reaction No. 79713							
$\text{Mn}^{+2}\text{H}^{+1}(2)\text{TTHA}-6 + \text{H}^{+1} = \text{Mn}^{+2}\text{H}^{+1}(3)\text{TTHA}-6$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	$\lg K: 2.8 (0.2\text{SD})$	5	CRV	13242

Reaction No. 79756							
$\text{As}(\text{s}) + 0.5\text{H}_2(\text{g}) + \text{Mn}(\text{s}) + 2\text{O}_2(\text{g}) = \text{Mn}^{+2}\text{H}^{+1}\text{AsO}_4^{-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\text{dG}: -960.50 (5\text{SF}) \text{ kJ}$	5	CRV	29482
2	25	0	Inf. Dilution	$\text{dH}: -1121.50 (6\text{SF}) \text{ kJ}$	5	CRV	29482

Reaction No. 79768							
$\text{As}(\text{s}) + \text{Mn}(\text{s}) + 2\text{O}_2(\text{g}) + \text{e}^{-1} = \text{Mn}^{+2}\text{AsO}_4^{-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\text{dG}: -913.32 (5\text{SF}) \text{ kJ}$	5	CRV	29482
2	25	0	Inf. Dilution	$\text{dH}: -1036.80 (6\text{SF}) \text{ kJ}$	5	CRV	29482

Reaction No. 80252							
$\text{AsO}_4^{-3} + \text{Mn}^{+2} = \text{Mn}^{+2}\text{AsO}_4^{-3}$							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:5.76(3SF)	1	MPH	29969
Note (1): Data set looks systematically low cf. NaCl (should be lower but not)							

Reaction No. 80253							
$H+1 + AsO4-3 + Mn+2 = Mn+2_H+1_AsO4-3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	KNO3	lgK:13.25(4SF)	1	MPH	29969
Note (1): Data set looks systematically low cf. NaCl (should be lower but not)							

Reaction No. 80967							
$Ph4As+1_MnO4-1(s) = Ph4As+1 + MnO4-1$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-8.09(3SF)	4	MSL	32204

Reaction No. 80996							
$Mn+2 + H+1_Se-2 = Mn+2_Se-2(s) + H+1$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.50(3SF)	3	EOD	32222
2	25	0	Inf. Dilution	dH:50.043(12.562SD)kJ	3	EOD	32222

Reaction No. 81357							
$Ca+2_Mn+2_CO3-2(2)(s) = Ca+2 + Mn+2 + 2<CO3-2>$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-21.81(4SF)	3	EOD	
Note (1): R.C. Aller, in Treatise on Geochemistry (Second Edition), 2014							

Reaction No. 81477							
$Mn(\gamma,s) = Mn+2 + 2<e-1>$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:40.20(4SF)	4	CRV	32224

Reaction No. 81478							
$Mn+2_S-2(\text{green},s) + 4<H2O> = Mn+2 + SO4-2 + 8<H+1> + 8<e-1>$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-34.04(4SF)	4	CRV	32224

Reaction No. 81479							
--------------------	--	--	--	--	--	--	--

Mn+3(2)_SO4-2(3)_(s) + 2<e-1> = 2<Mn+2> + 3<SO4-2>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:45.31 (4SF)	4	CRV	32224

Reaction No. 81480							
MnO2(birn,s) + 4<H+1> + 2<e-1> = Mn+2 + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:43.60 (4SF)	4	CRV	32224

Reaction No. 81481							
MnO2(nsut,s) + 4<H+1> + 2<e-1> = Mn+2 + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:43.01 (4SF)	4	CRV	32224

Reaction No. 81482							
Mn+3_OH-1(3)_(s) + 3<H+1> + e-1 = Mn+2 + 3<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:31.84 (4SF)	4	CRV	32224

Reaction No. 81545							
Pb(MnO4)2.3PbO(s) + 6<H+1> + 2<e-1> = 4<Pb+2> + 2<MnO4-2> + 3<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:146.63 (5SF)	4	CRV	32224

Data Assessment

Weight	Assessment
9	highest accuracy
8	multi-determined; excellent dependability
7	trustworthy; outstanding single determination
6	better than average reliability
5	average single determination
4	some doubt
3	poorly known
2	guess to achieve consistency (or just as bad)
1	no information but consistent

0	problematic/inconsistent
---	--------------------------

Techniques

Abbrev	Method
CIU	Critical IUPAC publication (crit.)
CMN	Several experimental values (crit.)
CRV	Critical review
CSM	Smith & Martell Vols 1-6 (crit.)
EAC	Activity Coefficient
EAE	Automated extrapolation
EBU	Brown's Unified Theory
EDH	Debye-Hueckel corrections
EES	Personal estimate
EFE	Free Energy relations
EIU	Critical IUPAC review (estim.)
ELC	Linear Combination of Reactions
EMN	Several experimental values (estim.)
EMS	Mean Spherical Approximation
EMU	Method unknown
ENS	Not specified
ENT	Nearest enthalpy & entropy changes
EOD	Calculated from data of others
EOR	Other Reaction Constants
ERG	Relative Gibbs energy
ESC	Standard conditions anchor
ESL	Similar Ligand
ESR	Similar reaction(s)
ETS	Ternary (statistical)
EVH	Van't Hoff Equation (dH = constant)
MAC	Activity coefficient (not specified)
MAG	Silver electrode e.m.f.
MAN	Chemical analysis
MCE	Cation exchange

MCG	Chromatography, Gel
MCL	Calorimetry
MCN	Conductivity
MCT	Coulometric titration
MCV	Cyclic voltammetry
MDG	Combination of Thermodynamic Data
MDM	Emf by differential method (buffer capacity)
MDS	Distribution between two phases
MEF	Electromotoric force, not specified
MEP	Electrophoresis
MES	Electron spin resonance
MGL	Glass electrode
MHG	Emf with amalgam electrode
MHY	Emf with hydrogen electrode
MIE	Current-voltage studies
MIR	Infrared spectra
MIS	Ion selective electrode
MIX	Ion exchange
MJM	Job's continuous variation
MKN	Rate of reaction
MMR	Nuclear magnetic resonance
MMX	Mixed techniques
MPH	pH method, not specified
MPL	Polarography
MPS	Potentiometry and Spectrophotometry
MPT	Potentiometry
MQH	Quinhydrone electrode
MRX	Emf with redox electrode
MSC	Miscellaneous
MSL	Solubility
MSP	Spectroscopy
MSV	Anodic Stripping Voltammetry
MTD	Temperature difference
MTN	Tyndallometry, nephelometry
MVM	Voltametric Methods

References

Reference No.: 8(76SmM)

Critical Stability Constants, Vol. 4, 1976 Smith RM; Martell AE; Plenum, New York

Reference No.: 11(91BBM)

J. Chem. Soc., Dalton Trans., 1991,, 1171 - 1174; Bencini A; Bianchi A; Micheloni M; Paoletti P; Garcia-Espana E; Nino MA; Co-ordination Tendency of [3k]aneNk Polyazacycloalkanes. Thermodynamic Study of Solution Equilibria

Reference No.: 30(63FeS)

Pure Appl. Chem., 1963, 6, 130 - 199; Feitknecht W; Schindler P; Solubility Constants of Metal Oxides, Metal Hydroxides and Metal Hydroxide Salts in Aqueous Solution: 2. Principles of the Determination of Solubility Constants of Hydroxide Precipitates

Reference No.: 50(62Per)

J. Chem. Soc., 1962,, 2197 - 2200; Perrin DD; The Hydrolysis of Manganese(II) Ion

Reference No.: 90(73HeP)

J. Chem. Soc., Dalton Trans., 1973,, 798 - 801; Hedwig GR; Powell HKJ; A Reinvestigation of the Enthalpy Changes for the Interaction of the Sulphate Ion with some Transition-metal Ions in Aqueous Solution

Reference No.: 94(77MLW)

J. Chem. Soc., Dalton Trans., 1977,, 588 - 595; May PM; Linder PW; Williams DR; Computer Simulation of Metal-ion Equilibria in Biofluids: Models for the Low-Molecular-Weight Complex Distribution of Calcium(II), Magnesium(II), Manganese(II), Iron(III), Copper(II), Zinc(II), and Lead(II) Ions in Human Blood Plasma

Reference No.: 97(82HMQ)

Agents Actions, 1982, 12, 536 - 542; Huang Z-X; May PM; Quinlan KM; Williams DR; Creighton AM; Metal Binding by Pharmaceuticals. Part 2. Interactions of Ca(II), Cu(II), Fe(II), Mg(II), Mn(II) and Zn(II) with the Intracellular Hydrolysis Products of the Antitumour Agent ICRF 159 and its Inactive Homologue ICRF 192

Reference No.: 104(62DeN)

J. Chem. Soc., 1962,, 2360 - 2366; Desai IR; Nair VSK; Studies on Metal Complexes in Solution. Part 1. Phthalates of Some Transition Metals

Reference No.: 109(58Per)

Nature (London), 1958, 182, 741 - 742; Perrin DD; Stability of Metal Complexes with Salicylic Acid and Related Substances

Reference No.: 115(57PeB)

Acta Chem. Scand., 1957, 11, 1419 - 1421; Peczek PL; Bjerrum J; Metal Ammine Formation in Solution. XI. Stability of Ethylenediamine Complexes and the Coordination Number of Cr(II)

Reference No.: 116(60CPS)

Nature (London), 1960, 186, 880 - 881; Ciampolini M; Paoletti P; Sacconi L; Heats and Entropies of Reaction of Transition Metal Ions with Ethylenediamine

Reference No.: 125(77SFP)

J. Am. Chem. Soc., 1977, 99, 4489 - 4496; Sigel H; Fisher BE; Prijs B; Biological

Implications from the Stability of Ternary Complexes in Solution. Mixed-Ligand Complexes with Manganese(II) and Other 3d Ions

Reference No.: 136(55McK)

J. Am. Chem. Soc., 1955, 77, 6149 - 6151; McNevin WM; Kriedge OH; Reactions of Divalent Palladium with Ethylenediaminetetraacetic Acid

Reference No.: 139(65WHR)

Anal. Chem., 1965, 37, 884 Wright DL; Holloway JH; Reilley CN; Heats and Entropies of Formation of Metal Chelates of Polyamine and Polyaminocarboxylate Ligands

Reference No.: 140(64SiM)

Stability Constants of Metal-ion Complexes SP17, 1964 Sillen LG; Martell AE; The Chemical Soc., London

Reference No.: 145(69BNS)

J. Am. Chem. Soc., 1969, 91, 4680 - 4683; Brunetti AP; Nancollas GH; Smith PN; Thermodynamics of Ion Association. XIX. Complexes of Divalent Metal Ions with Monoprotonated Ethylenediaminetetraacetate

Reference No.: 146(56SaR)

J. Indian Chem. Soc., 1956, 33, 841 - 851; Sarma BD; Ray P; Stability of Inner-metal Complexes

Reference No.: 148(84Pao)

Pure Appl. Chem., 1984, 56, 491 - 522; Paoletti P; Formation of Metal Complexes with Ethylenediamine: a Critical Survey of Equilibrium Constants, Enthalpy and Entropy Values

Reference No.: 152(70GTD)

J. Chem. Soc. (A), 1970,, 241 - 245; Grzybowski AK; Tate SS; Datta SP; Magnesium and Manganese Complexes of Citric and Isocitric Acids

Reference No.: 162(59LLW)

J. Inorg. Nucl. Chem., 1959, 12, 122 - 128; Li NC; Lindenbaum A; White JM; Some Metal Complexes of Citric and Tricarballic Acids

Reference No.: 166(71RaM)

J. Inorg. Nucl. Chem., 1971, 33, 809 Rao B; Mathur HB; Thermodynamics of the Interaction of Transition Metal Ions with Histamine

Reference No.: 173(69Ger)

Acta Chim. Hung., 1969, 59, 309 - 318; Gergely A; Equilibriums of alpha-Amino Complexes of Transition Metal Ions. I Complexes of Glycine

Reference No.: 179(64LeS)

J. Am. Chem. Soc., 1964, 86, 4846 - 4850; Leussing DL; Schultz DC; Metal Ion Catalysis in Transamination. II. Pyruvate-Glycinate Equilibrium Systems with Some Divalent Metal Ions

Reference No.: 180(68LeB)

Anal. Chem., 1968, 40, 575 - 581; Leussing DL; Bai KS; N-Salicylidene-glycinato Complexes. Comparison with Pyridoxal

Reference No.: 181(69ChP)

J. Chem. Soc. (A), 1969,, 1039 - 1044; Childs CW; Perrin DD; Equilibria in Solutions which Contain a Metal Ion and an Amino-acid

Reference No.: 183(69HoL)

J. Am. Chem. Soc., 1969, 91, 3740 - 3750; Hopgood D; Leussing DL; Kinetic and Equilibrium Studies of Formation of N-Salicylidene-glycinato Complexes. The Promnastic Effect of the Divalent Ions of Magnesium, Manganese, Zinc, Cadmium, and Lead

Reference No.: 184(52Kro)

J. Am. Chem. Soc., 1952, 74, 2034 - 2036; Kroll H; Manganous Complexes of Several Amino Acids

Reference No.: 185(64BDN)

J. Chem. Soc., 1964,, 304 - 310; Brannan JR; Dunsmore HS; Nancollas GH; Thermodynamics of Ion Association. Part XI. Some Transition-metal Glycine Salts

Reference No.: 187(65And)

Helv. Chim. Acta, 1965, 48, 1722 - 1725; Anderegg G; Complexons. XXXIX. Entropy and Enthalpy of Formation of the Metal Complexes of the Diethylenetriaminepentaacetate Ion Komplexe XXXIX. Die Bildungs-Enthalpie und -Entropie der Metallokomplexe des Diathylentriaminpentaacetat-Ions

Reference No.: 189(59CFD)

J. Inorg. Nucl. Chem., 1959, 11, 184 - 196; Chabarek S; Frost AE; Doran MA; Bicknell NJ; Interaction of some Divalent Metal Ions with Diethylenetriamine- pentaacetic Acid

Reference No.: 193(60HoR)

Anal. Chem., 1960, 32, 249 - 256; Holloway JH; Reilly CN; Metal Chelate Stability Constants of Aminopolycarboxylate Ligands

Reference No.: 197(54SGA)

Helv. Chim. Acta, 1954, 37, 937 - 957; Schwarzenbach G; Gut R; Anderegg G; Complexons. XXV. Polarographic Study of Exchange Equilibria. New Data on the Formation Constants of Metal Complexes of Ethylenediaminetetraacetic Acid and 1, 2-Diaminocyclohexanetetraacetic Acid (Komplexe XXV. Die Prographische Unterscuchung von Austauschgleichgewichten Neue Daten der Bildungskonstanten von Metallkomplexen der Athylendiamin-tetraessigsaeure und der 1,2-Diaminocyclohexan-tetraessigsaeure)

Reference No.: 208(72KuB)

Zh. Neorg. Khim., 1972, 17, 129(E:68) - 131; Kublanovskii VS; Belinskii VN; Complexing of Manganese(II) with Ammonia

Reference No.: 233(89SmM)

Critical Stability Constants, Vol. 6, 1989 Smith RM; Martell AE; Plenum, New York

Reference No.: 257(56SmA)

J. Am. Chem. Soc., 1956, 78, 2376 - 2380; Smith RM; Alberty RA; The Apparent Stability Constants of Ionic Complexes of Various Adenosine Phosphates with Divalent Cations

Reference No.: 277(64ElM)

J. Inorg. Nucl. Chem., 1964, 26, 1555 - 1560; Ellison H; Martell AE; Chelating Tendencies of Tripolyphosphate Ions

Reference No.: 281(73KhR)

J. Inorg. Nucl. Chem., 1973, 35, 179 - 186; Khan MMT; Reddy PR; Thermodynamic Quantities Associated with the Interaction of Tripolyphosphoric Acid with Metal Ions

Reference No.: 284(65And)

Helv. Chim. Acta, 1965, 48, 1712 - 1717; Anderegg G; Entropy-Conditioned Complex Formation. Thermodynamic Data Concerning Complex Formation by the Tripolyphosphate Ion Entropiebedingte Komplexbildung. Thermodynamische Daten der Komplexbildung mit dem Tripolyphosphat-Ion

Reference No.: 301(65CiG)

J. Inorg. Nucl. Chem., 1965, 27, 2019 - 2025; Ciavatta L; Grimaldi M; On the Complex Formation between Manganese(II) and Fluoride Ions

Reference No.: 356(71HPP)

Electrochim. Acta, 1971, 16, 677 - 686; Hanna EM; Pethybridge AD; Prue JE; Ion Association and the Analysis of Precise Conductimetric Data

Reference No.: 381(64ArM)

J. Chem. Soc., 1964,, 3117 - 3122; Archer DW; Monk CB; Ion-association Constants of Some Acetates by pH (Glass Electrode) Measurements

Reference No.: 386(50JoM)

J. Chem. Soc., 1950,, 3475 - 3478; Jones HW; Monk CB; The Condensed Phosphoric Acids and Their Salts. Part V. Dissociation Constants of Some Tetrametaphosphates

Reference No.: 411(82SaS)

J. Am. Chem. Soc., 1982, 104, 4100 - 4105; Saha N; Sigel H; Ternary Complexes in solution as Models for Enzyme-Metal-Ion- Substrate Complexes. Comparison of the Coordination Tendency of Imidazole and Ammonia toward the Binary Complexes of Mn(II), Co(II), Ni(II), Cu(II), Zn(II) or Cd(II) and Uridine 5'-Triphosphate or Adenosine 5'-Triphosphate

Reference No.: 412(82Joh)

Geochim. Cosmochim. Acta, 1982, 46, 1805 - 1809; Johnson KS; Solubility of Rhodochrosite (MnCO₃) in Water and Seawater

Reference No.: 414(70GKS)

Helv. Chim. Acta, 1970, 53, 290 - 299; Gamsjager H; Kraft W; Schindler PW; Zur Thermodynamik der Metallcarbonate. 4. Potentiometrische Untersuchungen am System Mn²⁺-CO₂-H₂O

Reference No.: 415(83LTS)

Talanta, 1983, 30, 295 - 298; Linder PW; Torrington RG; Seemann UA; Formation Constants for the Complexes of Levulinate and Acetate with Manganese(II), Cobalt(II), Nickel(II), Copper(II), Zinc(II) and Hydrogen Ions

Reference No.: 419(57LWL)

J. Am. Chem. Soc., 1957, 79, 5864 - 5870; Li NC; Westfall WM; Lindenbaum A; White JM; Schubert J; Manganese-54, Uranium-233 and Cobalt-60 Complexes of Some Organic Acids

Reference No.: 424(68FoB)

Inorg. Chim. Acta, 1968, 2, 179 Fontana S; Brito F; On the Hydrolysis of Manganese(II) in 1 M (Na₂Mn)SO₄ Ionic Medium at 25 degrees C

Reference No.: 437(80BoH)

IUPAC Chemical Data Series No. 27, 1980 Bond AM; Hefter GT; Critical Survey of Stability Constants and Related Thermodynamic Data of Fluoride Complexes in Aqueous Solution; Pergamon, Oxford, U.K.

Reference No.: 477(56YaF)

Zh. Neorg. Khim., 1956, 1, 2310 - 2315; Yatsimirskii KB; Fedorova TI; The Stability of Complex Acetate Compounds of Bivalent Chromium

Reference No.: 491(70Eat)

Anal. Chem., 1970, 42, 635 - 639; Eatough DJ; Calorimetric Determination of Equilibrium Constants for Very Stable Metal-Ligand Complexes

Reference No.: 497(72BoH)

J. Inorg. Nucl. Chem., 1972, 34, 603 - 607; Bond AM; Hefter G; A Study of the Weak Fluoride Complexes of the Divalent First Row Transition Metal Ions with a Fluoride Ion-Selective Electrode

Reference No.: 516(73HuH)

J. Chem. Soc., Dalton Trans., 1973,, 1247 Hutchinson MH; Higginson WCE; Stability Constants for Association between Bivalent Cations and Some Univalent Anions

Reference No.: 538(95OTK)

Talanta, 1995, 42, 535 - 541; Ozutsumi K; Taguchi Y; Kawashima T; Thermodynamics of Formation of Urea Complexes with Manganese(II), Nickel(II) and Zinc(II) Ions in N,N-Dimethylformamide

Reference No.: 552(95SMM)

NIST Critical Stability Constants of Metal Complexes Database, 1995 Smith RM; Martell AE; Motekaitis RJ; Version 2.0; National Institute of Standards and Technology, Gaithersburg, USA

Reference No.: 557(79Lin)

Chemical Equilibria in Soils, 1979 Lindsay WL; Wiley-Interscience, New York

Reference No.: 620(94Sha)

Monatsh. Chem., 1994, 125, 267 - 274; Sharma RK; Stabilities of Mixed Metal Complexes with Biologically Active Colchicine in Dioxan-Water and their Relation to Quantitative Softness Values: A New Approach

Reference No.: 698(68Pra)

J. Indian Chem. Soc., 1968, 45, 1037 - 1046; Prasad B; Incomplete Dissociation of Salts

Reference No.: 724(81CDP)

J. Inorg. Nucl. Chem., 1981, 43, 1305 Ciavatta L; De Capua R; Palombari R; On the Formation of Mn(III) Fluoride Complexes in Aqueous $3M(Li^+, H^+)ClO_4^-$

Reference No.: 725(81CPB)

J. Inorg. Nucl. Chem., 1981, 43, 2485 - 2489; Ciavatta L; Palombari R; Belli E; Manganese(III) Phosphate Complexes in $3M(Li^+, H^+)ClO_4^-$ Media

Reference No.: 726(73GTY)

Russ. J. Inorg. Chem., 1973, 18, 658 - 662; Goncharik VP; Tikhonova LP; Yatsimirskii KB; State of Manganese(III) in Solutions of Perchloric and Sulphuric Acids

Reference No.: 728(65WeD)

Nature (London), 1965, 205, 692 - 693; Wells CF; Davies G; Hydrolysis of the Manganic Ion

Reference No.: 730(69Die)

Z. Phys. Chem., 1969, 68, 64 Diebler H; Untersuchungen zur Komplexbildungskinetik des Ti(III) und Mn(III)

Reference No.: 731(64FaC)

Inorg. Chem., 1964, 3, 1130 - 1134; Fackler JP Jr; Chawla ID; Spectra of Manganese(III) Complexes. I. Aquomanganese(III) Ion and Hydroxide, Fluoride, and Chloride Complexes

Reference No.: 732(74RNK)

J. Chem. Soc., Faraday Trans. 1, 1974, 70, 2232 - 2238; Rosseinsky DR; Nicol MJ; Kite K; Hill RJ; Manganese(III) and its Hydroxo- and Chloro-complexes in Aqueous Perchloric Acid: Comparison with similar Transition-metal(III) Complexes

Reference No.: 733(48Tau)

J. Am. Chem. Soc., 1948, 70, 3928 - 3935; Taube H; Catalysis by Manganic Ion of the Reaction of Bromine and Oxalic Acid. Stability of Manganic Ion Complexes

Reference No.: 747(66GMF)

Russ. J. Inorg. Chem., 1966, 11, 504 - 860; Goloshchapov MV; Martynenko BV; Filatova TN; Solubility of Manganese Hydrogen Phosphate Stability of Isomeric Complexes of Composition $[\text{PtCl}_4(\text{NH}_3)_2]$

Reference No.: 763(82Per)

IUPAC Chemical Data Series No. 29, 1982 Perrin DD; Ionisation Constants of Inorganic Acids and Bases in Aqueous Solution

Reference No.: 766(87BrA)

Report EPA/600/3-87/012, 1987 Brown DS; Allison JD; MINTEQA1, An Equilibrium Metal Speciation Model: Users Manual; U.S. Environmental Protection Agency, Athens, Georgia 30613

Reference No.: 767(69CiG)

J. Inorg. Nucl. Chem., 1969, 31, 3071 - 3082; Ciavatta L; Grimaldi M; Potential of the Couple $\text{Mn(III)}-\text{Mn(II)}$ in Aqueous 3 M Perchloric Acid

Reference No.: 773(85KoS)

Handbook of Chemical Equilibria in Analytical Chemistry, 1985 Kotrly S; Sucha L; Ellis Horwood Series in Anal. Chem.; Eds. Chalmers RA & Masson M; Ellis Horwood, Chichester

Reference No.: 802(90Wea)

CRC Handbook of Chemistry and Physics, 70th Edn., 1990 Weast RC; A Ready-Reference Book of Chemical and Physical Data; CRC Press, Cleveland, Ohio

Reference No.: 903(77And)

Critical Survey of Stability Constants of EDTA Complexes, 1977 Anderegg G; IUPAC Chemical Data Series. 14; Pergamon Press, Oxford

Reference No.: 904(84Pet)

Pure Appl. Chem., 1984, 56, 247 - 292; Pettit LD; Critical Survey of Formation Constants of Complexes of Histidine, Phenylalanine, Tyrosine, L-DOPA and Tryptophan

Reference No.: 905(95Ber)

Pure Appl. Chem., 1995, 67, 1117 - 143; Berthon G; Critical Review of Formation Constants of Selected Amino Acids with Polar Side Chains

Reference No.: 906(79Per)

IUPAC Chemical Data Series No. 22, 1979 Perrin DD; Stability Constants of Metal-Ion Complexes, First Edition Part B, Organic Ligands; Pergamon, Oxford

Reference No.: 931(71SiM)

Stability Constants of Metal-ion Complexes SP25, 1971 Sillen LG; Martell AE; Supplement No 1 to Special Publication No 25; Chemical Society, London

Reference No.: 996(89FSK)

J. Chem. Soc., Dalton Trans., 1989,, 2247 - 2251; Farkas E; Szoke J; Kiss T; Kozlowski H; Bal W; Complex-forming Properties of L-alpha-Alaninehydroxamic Acid (2-Amino-N-hydroxypropanamide)

Reference No.: 999(91MaM)

Estimation of Constants for JESS Database, 1991 May PM; May RF

Reference No.: 1007(89DDV)

J. Chem. Soc., Dalton Trans., 1989,, 133 - 137; Delgado R; da Silva JJRF; Vaz MCTA; Paoletti P; Micheloni M; Thermodynamics of the Formation of Metal Complexes of 1,4,10-Trioxa-7,13-diazacyclopentadecane-N,N'-diacetic acid and of 1,4,10,13-Tetraoxa-7,16-diazacyclo-octadecane-N,N'-diacetic acid

Reference No.: 1031(86ReR)

J. Chem. Soc., Dalton Trans., 1986,, 2331 - 2334; Reddy PR; Rao VBM; Metal Complexes of Uridine in Solution

Reference No.: 1034(86MiN)

J. Chem. Soc., Dalton Trans., 1986,, 2721 - 2723; Micskei K; Nagypal I; Comparison of the Formation Constants of some Chromium(II) and Copper(II) Complexes

Reference No.: 1048(85Lep)

J. Chem. Soc., Dalton Trans., 1985,, 1605 - 1608; Leporati E; Potentiometric Study of the Complex-formation Equilibria of Manganese(II), Cobalt(II), Nickel(II), Copper(II), and Zinc(II) with Ethylenediamine-N-acetic Acid

Reference No.: 1050(84KiG)

J. Chem. Soc., Dalton Trans., 1984,, 1951 - 1957; Kiss T; Gergely A; Complex Forming Properties of Tyrosine Isomers with Transition Metal Ions

Reference No.: 1093(81BLP)

J. Chem. Soc., Dalton Trans., 1981,, 1531 - 1534; Bigoli F; Leporati E; Pellinghelli MA; Equilibria of Some α -Amino-acids containing Sulphur Atoms in the Chain with Metal(II) Ions. Part 1. DL-4,4'-Dithiobis(2-aminobutyric acid) with Manganese(II), Cobalt(II), and Nickel(II) in Aqueous Solution

Reference No.: 1103(89FRR)

Polyhedron, 1989, 8, 1365 - 1370; Fuentes J; Reboso R; Rodriguez A; 2,5-Toluenediamine-N,N'-Disuccinic Acid. Preparation, Dissociation Constants and Coordinating Capacity with Divalent Cations

Reference No.: 1118(82And)

Pure Appl. Chem., 1982, 54, 2693 - 2758; Anderegg G; Critical Survey of Stability Constants of NTA Complexes

Reference No.: 1125(84OaV)

J. Chem. Soc., Dalton Trans., 1984,, 1133 - 1137; Oakes J; van Kralingen CG; Spectroscopic Studies of Transition-metal Ion Complexes of Diethylenetriaminepenta-acetic Acid and Diethylenetriaminepenta-methylphosphonic Acid

Reference No.: 1166(86Ohy)

Polyhedron, 1986, 5, 1165 - 1170; Ohyoshi E; Relative Stabilities of Metal Complexes of 4-(2-Pyridylazo) resorcinol and 4-(2-Thiazolylazo)Resorcinol

Reference No.: 1173(87GoF)

Polyhedron, 1987, 6, 2037 - 2052; Gotsis ED; Fiat D; 17 O and 14 N NMR Studies of the Co(II), Cu(II) and Mn(II) Complexes of L-Proline in Aqueous Solution

Reference No.: 1174(87GoF)

Polyhedron, 1987, 6, 2053 - 2065; Gotsis ED; Fiat D; 17 O and 14 N NMR Studies of the Co(II) and Mn(II) Complexes of Glycine in Aqueous Solution

Reference No.: 1176(87DDV)

Polyhedron, 1987, 6, 29 - 38; Delgado R; da Silva JJRF; Vaz MCTA; Metal Complexes of 1,4,10-Trioxa-7,13-Diazacyclopentadecane- N,N"-Diacetic Acid

Reference No.: 1183(86ReR)

Polyhedron, 1986, 5, 1947 - 1952; Reddy PR; Reddy BM; Ternary Complexes of 5'-Cytidine Monophosphate and Cytosine with some Biologically Important Secondary Ligands

Reference No.: 1187(85ReR)

Polyhedron, 1985, 4, 1603 - 1609; Reddy PR; Rao VBM; Role of Secondary Ligands in the Structure and Stability of Metal-Cytidine Complexes in Solution

Reference No.: 1197(89SAS)

Inorg. Chem., 1989, 28, 2687 - 2688; Sawada K; Araki T; Suzuki T; Doi K; Complex Formation of Amino Polyphosphates. 2. Stability and Structure of Nitrilotris(methylenephosphonato) Complexes of the Divalent Transition-Metal Ions in Aqueous Solution

Reference No.: 1206(68HoA)

J. Am. Chem. Soc., 1968, 90, 2508 - 2613; Hopgood D; Angelici RJ; Equilibrium and Stereochemical Studies of the Interactions of Amino Acids and their Esters with Divalent Metal Nitrilotrilacetate Complexes

Reference No.: 1207(90CBG)

Inorg. Chem., 1990, 29, 5 - 9; Cortes S; Brucher E; Geraldles CFGC; Sherry AD; Potentiometry and NMR Studies of 1,5,9-Triazacyclododecane- N,N',N''-triacetic Acid and Its Metal Ion Complexes

Reference No.: 1217(89MoM)

Inorg. Chem., 1989, 28, 3499 - 3503; Motekaitis RJ; Martell AE; Potentiometry of Mixtures: Metal Chelate Stability Constants of 1-Hydroxy-3-oxapentane-1,2,4,5-tetracarboxylic Acid and 3,6-Dioxaoctane-1,2,4,5,7,8-hexacarboxylic Acid

Reference No.: 1218(89Lep)

Inorg. Chem., 1989, 28, 3752 - 3759; Leporati E; Potentiometric and Spectrophotometric Study of the Proton, Cobalt(II), Nickel(II), and Copper(II) Complexes of 2-Amino-N,3-dihydroxybutanamide and 2-Amino-N-hydroxy-3-phenylpropanamide in Aqueous Solution

Reference No.: 1222(81GKD)

Inorg. Chim. Acta, 1981, 56, 35 - 40; Gergely A; Kiss T; Deak G; Sovago I; Complexes of 3,4-Dihydroxyphenyl Derivatives. IV. Equilibrium Studies on Some Transition Metal Complexes Formed with Adrenaline and Norvaline

Reference No.: 1231(81HMW)

Inorg. Chim. Acta, 1981, 56, 41 - 44; Huang Z-X; May PM; Williams DR; Metal Complexing Ability of Two Inducers of Reverse Transformation

Reference No.: 1255(89BFJ)

J. Coord. Chem., 1989, 20, 209 - 217; Bottari E; Festa MR; Jasionowska R; Complex Formation between Cadmium(II) and Aspartate and Glutamate

Reference No.: 1257(84MoM)

J. Coord. Chem., 1984, 13, 265 - 271; Motekaitis RJ; Martell AE; New Multidentate Ligands. XXV. The Coordination Chemistry of Divalent Metal Ions with Diglycolic Acid, Carboxymethyltartronic Acid and Ditartronic Acid

Reference No.: 1258(89RVM)

J. Coord. Chem., 1989, 20, 69 - 72; Rao AK; Venkataiah P; Mohan MS; Studies on Biologically Relevant Binary and Ternary Metal Complexes. IV. Stability of Binary and Ternary Metal Complexes Containing Bis(Imidazol-2-yl)Methane and Amino Acids

Reference No.: 1274(89SLN)

J. Coord. Chem., 1989, 19, 359 - 369; Strasak M; Lucansky J; Novomesky P; Dvorakova E;

Diastereoselectivity in Metal Complexes of some Phenyl- substituted Ethylenediamine-
N,N,N,N'-Tetraacetate Derivatives

Reference No.: 1275(87KRZ)

J. Coord. Chem., 1987, 16, 237 - 244; Khan BT; Raju RM; Zakeeruddin SM; Binary and Ternary Metal Complexes of Uridine and Thermodynamic Quantities Associated with the Interaction of Uridine with Bivalent Metal Ions in Solution

Reference No.: 1297(86CCS)

Inorg. Chim. Acta, 1986, 123, 69 - 73; Cini R; Cinquantini A; Seeber R; Complexes of Magnesium(II) and other Divalent Metal Ions with Adenosine 5'-Triphosphate and 2,2'-Dipyridylamine in Aqueous Solution

Reference No.: 1336(89AKL)

J. Coord. Chem., 1989, 20, 81 - 93; Armstrong MM; Kramer U; Linder PW; Torrington RG; Modro TA; Equilibrium Studies of the Protonation of 8-Quinolyl Phosphate, 1-Naphthyl Phosphate and 8-Quinolyl Methyl Phosphate and their Complexation with Copper(II), Zinc(II), Nickel(II), Cobalt(II) and Manganese(II) Ions in Aqueous Solution

Reference No.: 1345(88MaS)

Inorg. Chem., 1988, 27, 1447 - 1453; Massoud SS; Sigel H; Metal Ion Coordinating Properties of Pyrimidine-Nucleoside 5'-Monophosphates (CMP,UMP,TMP) and of Simple Phosphate Monoesters, Including D-Ribose 5'-Monophosphate. Establish- ment of Relations between Complex Stability and Phosphate Basicity

Reference No.: 1354(87ChW)

Prog. Inorg. Chem., 1987, 35, 329 - 435; Chaudhuri P; Weighardt K; The Chemistry of 1,4,7-Triazacyclononane and Related Tridentate Macrocyclic Compounds

Reference No.: 1368(87MNT)

Inorg. Chem., 1987, 26, 1419 - 1422; Matsumura K; Nakasuka N; Tanaka M; Thermodynamic Studies on the Protonation of d-Phenylene-diamine-N,N,N,N'-tetraacetate and Its Complexation with Bivalent Transition Metal-Ions in Aqueous Solutions

Reference No.: 1369(87STM)

Inorg. Chem., 1987, 26, 2149 - 2157; Sigel H; Tribolet R; Malini-Balakrishnan R; Martin RB; Comparison of the Stabilities of Monomeric Metal Ion Complexes Formed with Adenosine 5'-Triphosphate (ATP) and Pyrimidine-Nucleoside 5'-Triphosphates (CTP, UTP, TTP) and Evaluation of the Isomeric Equilibria in the Complexes of ATP and CTP

Reference No.: 1370(78MoA)

Inorg. Chem., 1978, 17, 2203 - 2207; Mohan MS; Abbott EH; Metal Complexes of Amino Acid Phosphate Esters

Reference No.: 1379(87BGH)

Inorg. Chem., 1987, 26, 2699 - 2706; Bevilacqua A; Gelb RI; Hebard WB; Zompa LJ; Equilibrium and Thermodynamic Study of the Aqueous Complexation of 1,4,7-Triazacyclononane-N,N',N''- triacetic Acid with Protons, Alkaline-Earth-Metal Cations, and Copper(II)

Reference No.: 1384(89HaM)

Chem. Rev., 1989, 89, 1875 - 1914; Hancock RD; Martell AE; Ligand Design for Selective Complexation of Metal Ions in Aqueous Solution

Reference No.: 1394(70Nan)

Coord. Chem. Rev., 1970, 5, 379 - 415; Nancollas GH; The Thermodynamics of Metal-Complex and Ion-Pair Formation

Reference No.: 1396(74ZZM)

Coord. Chem. Rev., 1974, 14, 29 - 45; Zipp SG; Zipp AP; Madan SK; Thermodynamics and Kinetics of the Transition Metal Complexes of Tripodal Amines

Reference No.: 1428(81BaG)

J. Inorg. Nucl. Chem., 1981, 43, 3275 - 3276; Baseggio AA; Grassi RL; Stability Constants of the Complexes of Zn(II) and Mn(II) with N,N'-Bis(2-Hydroxyethyl)Aminomethyl

Reference No.: 1437(91SMC)

Pure Appl. Chem., 1991, 63, 1015 - 1080; Smith RM; Martell AE; Chen YT; Critical Evaluation of Stability Constants for Nucleotide Complexes with Protons and Metal Ions

Reference No.: 1456(78MCG)

Acta Chem. Scand., 1978, A32, 79 - 83; Madsen HEL; Christensen HH; Gottlieb-Petersen C; Stability Constants of Copper(II), Zinc(II), Manganese(II), Calcium(II), and Magnesium(II) Complexes of N-(Phosphonomethyl)glycine (Glyphosphate)

Reference No.: 1467(88ADD)

Talanta, 1988, 35, 741 - 745; Amorim MTS; Delgado R; da Silva JJRF; Vaz MCTA; Vilhena MF; Metal Complexes of 1-Oxa-4,7,10-Triazacyclododecane- N,N',N''-Triacetic Acid

Reference No.: 1494(86GMP)

Inorg. Chem., 1986, 25, 1435 - 1438; Garcia-Espana E; Micheloni M; Paoletti P; Bianchi A; Thermodynamic Studies on Equilibria between the Branched Hexaamine N,N,N',N'-Tetrakis(3-aminopropyl)ethylenediamine (TAPEN) and Hydrogen, Manganese(II), Iron(II), Cobalt(II), Nickel(II), Copper(II), and Zinc(II) Ions

Reference No.: 1503(82BiL)

Inorg. Chem., 1982, 21, 374 - 380; Birus M; Leussing DL; Comparison of an Enzymatic Reaction and Its Model: Metal Ion Promoted Decarboxylation of Oxalacetate

Reference No.: 1511(81MaL)

Inorg. Chem., 1981, 20, 4240 - 4247; Mao H-K; Leussing DL; An Investigation of an Enzyme Model. The Influence of Solvent on the Metal-Ion-Catalyzed Decarboxylation of Oxalacetate

Reference No.: 1539(78Kra)

Atlas of Metal-Ligand Equilibria in Aqueous Solution, 1978 Kragten J; Ellis Horwood, Chichester UK

Reference No.: 1548(85MMN)

Inorg. Chem., 1985, 24, 3076 - 3080; Mulla F; Marsicano F; Nakani BS; Hancock RD; Stability of Ammonia Complexes that are Unstable to Hydrolysis in Water

Reference No.: 1557(91KiM)

J. Inorg. Biochem., 1991, 43, 51 - 56; Kinjo Y; Maeda M; Coordination of Divalent Transition-Metal Ions to Xanthine in Aqueous Solution

Reference No.: 1565(77AHP)

Helv. Chim. Acta, 1977, 60, 123 - 140; Anderegg G; Hubmann E; Podder NG; Wenk F; Peridinderivate als Komplexbildner. XI. Die Thermodynamik der Metalkomplexbildung mit Bis-, Tris- und Tetrakis [(2-pyridyl)methyl]-aminen

Reference No.: 1599(80RZI)

Talanta, 1980, 27, 715 - 719; Rizkalla EN; Zaki MTM; Ismail MI; Metal Chelates of Phosphonate-containing Ligands - V Stability of Some 1-Hydroxyethane-1,1-Diphosphonic Acid Metal Chelates

Reference No.: 1602(74BaW)

J. Chem. Soc., Dalton Trans., 1974,, 1117 - 1120; Baxter AC; Williams DR; Thermodynamic Considerations in Co-ordination. Part XV. Potentiometric and Calorimetric Study of the Complexes Formed between Protons, First Transition Series Metal Ions, and Asparaginate and Glutamate Anions

Reference No.: 1618(85KSR)

Polyhedron, 1985, 4, 1451 - 1456; Krishnamoorthy CR; Sunil S; Ramalingam K; The Effect of Ligand Donor Atoms on Ternary Complex Stability

Reference No.: 1635(77PeS)

J. Chem. Soc., Dalton Trans., 1977,, 697 - 701; Pettit LD; Swash JLM; Complexes of meso- and (+-)-Butane-2,3-diamine with Manganese-, Cobalt-, Nickel-, Copper-, and Lead(II): A Potentiometric, Calorimetric, and Spectroscopic Study

Reference No.: 1660(79HJE)

J. Chem. Soc., Dalton Trans., 1979,, 1384 - 1387; Hancock RD; Jackson GE; Evers A; Affinity of Lanthanoid(III) Ions for Nitrogen-donor Ligands in Aqueous Solution

Reference No.: 1743(91ACD)

J. Chem. Soc., Dalton Trans., 1991,, 3065 - 3072; Amorim MTS; Chaves S; Delgado R; Frausto da Silva JJR; Oxatriaza Macrocyclic Ligands: Studies of Protonation and Metal Complexation

Reference No.: 1744(92LCB)

J. Am. Chem. Soc., 1992, 114, 7780 - 7785; Liang G; Chen D; Bastian M; Sigel H; Metal Ion Binding Properties of Dihydroxyacetone Phosphate and Glycerol 1-Phosphate

Reference No.: 1747(92MoM)

Inorg. Chem., 1992, 31, 11 - 15; Motekaitis RJ; Martell AE; Stabilities of Metal Complexes of the Meso and SS Isomers of Oxydisuccinic Acid

Reference No.: 1760(90Bur)

Biocoordination Chemistry, 1990 Burger K; Coordination Equilibria in Biologically Active Systems; Ellis Horwood

Reference No.: 1771(92CDF)

Talanta, 1992, 39, 249 - 254; Chaves S; Delgado R; Frausto da Silva JJR; The Stability of the Metal Complexes of Cyclic Tetra-Aza Tetra-Acetic Acids

Reference No.: 1779(81JMW)

J. Inorg. Nucl. Chem., 1981, 43, 825 - 829; Jackson GE; May PM; Williams DR; Metal-Ligand Complexes Involved in Rheumatoid Arthritis - VII Formation of Binary and Ternary Complexes between 2,3-Diamino- Propionic Acid, Histidine and Cu(II), Ni(II) and Zn(II)

Reference No.: 1783(92GiV)

J. Chem. Soc., Dalton Trans., 1992,, 1375 - 1379; Gibson JF; Vaughan OJ; Chelating Tendencies of N,N'-Bis(2-hydroxyphenyl)-ethylenediamine- N,N'-diacetic Acid

Reference No.: 1801(67HoW)

J. Chem. Soc. (A), 1967,, 1702 - 1704; Holmes F; Williams DR; Thermodynamic Considerations in Co-ordination. Part III. The Copper(II) and Nickel(II) Complexes of 1,2-Diaminoethane, 1,3- Diaminopropane, 4(5)-Aminomethylimidazole, 4(5)-2'-Aminoethylimidazole, 2-Aminomethylpyridine, and 2-2'-Aminoethylpyridine

Reference No.: 1835(92RMH)

Inorg. Chem., 1992, 31, 4854 - 4859; Rothermel GL Jr.; Miao L; Hill AL; Jackels SC; Macrocyclic Ligands with 18-Membered Rings Containing Pyridine or Furan Groups: Preparation, Protonation, and Complexation by Metal Ions

Reference No.: 1853(81LDD)

J. Inorg. Nucl. Chem., 1981, 43, 2429 - 2432; Lalart D; Dodin G; Dubois J-E;
Complexation between Oxonic Acid and Divalent Metal Cations. Influence of Metal Salt
Addition on Decarboxylation Kinetics under Acidic Conditions

Reference No.: 1860(92SCC)

Helv. Chim. Acta, 1992, 75, 2634 - 2656; Sigel H; Chen D; Corfu NA; Holy A; Strasak B;
Metal-Ion-Coordinating Properties of Various Phosphonate Derivatives including 9-[2-
(Phosphonylmethoxy)ethyl]adenine (PMEA)- Adenosine Monophosphate (AMP) Analogue with
Antiviral Properties

Reference No.: 1884(78RRK)

J. Inorg. Nucl. Chem., 1978, 40, 1265 - 1267; Reddy PR; Reddy KV; Khan MMT;
Thermodynamic Quantities Associated with the Interaction of Xanthosine with Metal Ions

Reference No.: 1902(79PoB)

J. Inorg. Nucl. Chem., 1979, 41, 205 - 207; Poldoski JE; Bydalek TJ; Metal Ion
Complexes of Ethylene-Bis-N,N'-(2,6-Dicarboxy)Piperidine

Reference No.: 1905(79RRK)

J. Inorg. Nucl. Chem., 1979, 41, 423 - 427; Reddy PR; Reddy KV; Khan MMT; Ternary
Complexes of Xanthosine in Solution

Reference No.: 1933(71IrS)

J. Inorg. Nucl. Chem., 1971, 33, 203 - 215; Irving HMNH; Sharpe K; Divalent Metal
Complexes of meso- and dl-2,3-Diaminobutane- N,N',N'-Tetraacetic Acid

Reference No.: 1940(84DMW)

J. Inorg. Biochem., 1984, 20, 199 - 214; Duffield JR; May PM; Williams DR; Computer
Simulation of Metal Ion Equilibria in Biofluids. IV. Plutonium Speciation in Human
Blood Plasma and Chelation Therapy Using Polyaminopolycarboxylic Acids

Reference No.: 1941(67LMM)

J. Am. Chem. Soc., 1967, 89, 837 - 843; L'Eplattenier F; Murase I; Martell AE; New
Multidentate Ligands. VI. Chelating Tendencies of N,N'-Di(2-
hydroxybenzyl)ethylenediamine-N,N'-diacetic Acid

Reference No.: 1943(63GCP)

Inorg. Chem., 1963, 2, 597 - 600; Green RW; Catchpole KW; Phillip AT; Lions F;
Sexadentate Chelate Compounds. XI

Reference No.: 1956(64And)

Helv. Chim. Acta, 1964, 47, 1801 - 1814; Anderegg G; Komplexe XXXVI.
Reaktionsenthalpie und -entropie bei der Bildung der Metalkomplexe der höheren EDTA-
Homologen

Reference No.: 1959(50PrS)

Helv. Chim. Acta, 1950, 33, 963 - 974; Prue JE; Schwarzenbach G; Metallkomplexe mit
Polyaminen II: Mit Triaminotriethylamin = "tren"

Reference No.: 1960(50Sch)

Helv. Chim. Acta, 1950, 33, 974 - 985; Schwarzenbach G; Metallkomplexe mit Polyaminen
III: Mit Triäthylen-tetramin = "trien"

Reference No.: 1963(63And)

Helv. Chim. Acta, 1963, 46, 1833 - 1842; Anderegg G; Komplexe XXXIII.
Reaktionsenthalpie und -entropie bei der Bildung der Metallkomplexe von Äthylendiamin-
und Diaminocyclohexan-tetra-essigsäure

Reference No.: 1964(53ScM)

Helv. Chim. Acta, 1953, 36, 581 - 597; Schwarzenbach G; Moser P; Metallkomplexe mit Polyaminen. X. Mit Tetrakis-(beta-aminoathyl)-athylendiamin = "penten"

Reference No.: 1965(71PWV)

Helv. Chim. Acta, 1971, 54, 243 - 265; Paoletti P; Walser R; Vacca A; Schwarzenbach G; Die Komplexe der Hexamine <<penten>> und <<ptetaen>>. Thermodynamik ihrer Bildung in Wasseriger Losung

Reference No.: 1967(71And)

Helv. Chim. Acta, 1971, 54, 509 - 512; Anderegg G; Pyridinderivate als Komplexbildner IX. Die Stabilitatskonstanten ion Komplexen mit (a) 2-Aminomethyl-pyridin, (b) 6-Methyl-2-amino- methyl-pyridin, (c) 2-Pyridylhydrazin, (d) 2,2'-Dipyridylamin und (e) 1-(alpha-Pyridylmethylen)-2-(alpha-pyridyl)-hydrazin

Reference No.: 1972(73KhR)

J. Inorg. Nucl. Chem., 1973, 35, 2813 - 2819; Khan HMT; Reddy PR; Thermodynamic Quantities Associated with the Interaction of Guanosine Triphosphate and Inosine Triphosphate with Bivalent Metal Ions

Reference No.: 1978(78NLM)

Chem. Zvesti, 1978, 32, 19 - 26; Novak V; Lucansky J; Majer J; Meue Komplexane. XXXII. Synthese und Studium der Eigenschaften der 2-Methyl-1,2-diaminopropan-N,N,N',N'-tetraessigsaeure

Reference No.: 1981(79MBN)

Chem. Zvesti, 1979, 33, 742 - 748; Majer J; Butvin P; Novak V; Svickova M; Fuleova E; Valaskova I; Novak J; New Complexanes. XXXV. Properties of 1,2-Diaminooctane-N,N,N',N'-tetraacetic Acid

Reference No.: 1982(63And)

Helv. Chim. Acta, 1963, 46, 1011 - 1017; Anderegg G; Pyridinderivate als Komplexbildner IV. Die Metalkomplexe der Chelidamsaeure

Reference No.: 1988(63And)

Helv. Chim. Acta, 1963, 46, 2813 - 2822; Anderegg G; Pyridinderivate als Komplexbildner VI. Reaktionsenthalpie und -entropie bei der Bildung der Metallkomplexe von 1,10-Phenanthroline und alpha,alpha'-Dipyridyl

Reference No.: 1989(63And)

Helv. Chim. Acta, 1963, 46, 2397 - 2410; Anderegg G; Pyridine Derivatives as Complex Formers. V. The Metal Complexes of 1,10-Phenanthroline and alpha,alpha'-Bipyridine Pyridinderivate als Komplexbildner V. Die Metallkomplexe von Pyridinderivate als Komplexbildner V. Die Metallkomplexe von 1,10-Phenanthrolin und alpha,alpha'-Dipyridyl

Reference No.: 1994(74NLS)

Chem. Zvesti, 1974, 28, 324 - 331; Novak V; Lucansky J; Svickova M; Majer J; Neue Komplexane. XXVIII. Polarographisches Studium der Chelatbildenden Eigenschaften der 1,2-Diaminopentan-N,N,N',N'-tetraessigsaeure und der 1,2-Diaminohexan-N,N,N',N'-tetraessigsaeure

Reference No.: 1995(68NLM)

Chem. Zvesti, 1968, 22, 721 - 732; Novak V; Lucansky J; Majer J; Neue Komplexane. (XIV). Die 1,2-Diaminobutan-N,N,N',N'-tetra- essigsaeure und das polarographische Studium ihrer Komplexe mit den Lanthaniden und einigen zweiwertigen Kationen als Zentralatome

Reference No.: 1998(67NKL)

Chem. Zvesti, 1967, 21, 687 - 697; Novak V; Kotoucek M; Lucansky J; Majer J; Nove Komplexany. (X). Polarograficke Sledovanie Chelatov Kyseliny etylendiamin-N,N'-

dioctovej-N,N'-(alpha,alpha'-dipropionovej) s Lantanidmi a Niektorymi Dvojmocnymi Kationmi

Reference No.: 1999(66DvM)

Chem. Zvesti, 1966, 20, 233 - 241; Dvorakova E; Majer J; Nove Komplexany. (IV). Potenciometricke Sledovanie Komplexov mezo- kyseliny a Racemickej Kyseliny 2,3-diaminobutan-N,N,N',N'-tetra- octovej s Niektorymi Dvojmocnymi Kationmi

Reference No.: 2003(64MNS)

Chem. Zvesti, 1964, 18, 481 - 492; Majer J; Novak V; Svickova M; Nove Komplexany (II). Polargraficke Urcenie Konstant Komplexity mezo-kyseliny a Racemickej Kyseliny 2,3-diaminobutan-N,N,N',N'- tetraoctovej s Niektorymi Dvojmocnymi Kationmi

Reference No.: 2004(66MKD)

Chem. Zvesti, 1966, 20, 242 - 251; Majer J; Kotoucek M; Dvorakova E; Nove Komplexany. (V). Komplexy Kyseliny Ethylendiamin-N,N'- dipropionove-alpha,alpha' a Kyseliny Ethylendiamin-N,N'-diprop- ionove-alpha,alpha'-N,N'-dioctove s Kationty Alkalickych Zemin a s Nekterymi Dalsimi Dvojmocnymi Kationty

Reference No.: 2006(68MJD)

Chem. Zvesti, 1968, 22, 415 - 423; Majer J; Jokl V; Dvorakova E; Jurcova M; Nove Komplexany. (XIII). Potenciometricka a Elektroforeticke Studium Kyseliny Etylendiamin-N,N'-dijantarovej a jej Kovovych Chelator

Reference No.: 2008(69NDS)

Chem. Zvesti, 1969, 23, 861 - 868; Novak V; Dvorakova E; Svickova M; Majer J; New Complexanes. XIX. Complex-forming Properties of Ethylenediamine- N,N'-diacetic-N,N'-(2,2'-dialkanecarboxylic) Acids

Reference No.: 2009(80MVV)

Chem. Zvesti, 1980, 34, 637 - 644; Majer J; van Quy T; Valaskova I; Elektrophoretisches Studium der Komplexbildenden Eigenschaften der N-(Methylphosphon)iminodiessigsäure und der Glycin-N,N-bis(methyl- phosphonsäure)

Reference No.: 2010(69NDS)

Chem. Zvesti, 1969, 23, 330 - 335; Novak V; Dvorakova E; Svickova M; Majer J; Neue Komplexane. XVII. Studium der Chelate der Phenylathyldiamin- tetraessigsäure

Reference No.: 2012(68NLM)

Chem. Zvesti, 1968, 22, 733 - 742; Novak V; Lucansky J; Majer J; Neue Komplexane. (XV). Komplexbildende Reagenzien vom Typ der 1,2-Diaminoisoalkan-N,N,N',N'-tetraessigsäuren und das Polaro- graphische Studium ihrer Komplexbildenden Eigenschaften

Reference No.: 2022(83MDN)

J. Chem. Soc., Dalton Trans., 1983,, 1335 - 1338; Micskei K; Debreczeni F; Nagypal I; Equilibria in Aqueous Solutions of Some Chromium(2+) Complexes

Reference No.: 2039(68And)

Helv. Chim. Acta, 1968, 51, 1856 - 1863; Anderegg G; Zur Deutung der thermodynamischen Daten von Komplexbildungs- reaktionen I

Reference No.: 2040(65And)

Helv. Chim. Acta, 1965, 48, 1718 - 1721; Anderegg G; Komplexe XXXVIII. Reaktionsenthalpie und -entropie bei der Bildung der 1:1- und 1:2-Metallkomplexe von Methyliminodiessigsäure

Reference No.: 2041(65AnB)

Helv. Chim. Acta, 1965, 48, 887 - 892; Anderegg G; Bottari E; Pyridinderivate als Komplexbildner VII. Über die Koordinationsten- denz von substituierten Dipicolinat- Ionen

Reference No.: 2043(64LeA)

Helv. Chim. Acta, 1964, 47, 1792 - 1800; L'Eplattenier F; Anderegg G; Komplexe XXXV. Die Metallkomplexe der Tri- und der Tetramethyldiamin-NN'-tetraessigsäure

Reference No.: 2054(79GMP)

Can. J. Chem., 1979, 57, 113 - 118; Gualtieri RJ; McBryde WAE; Powell HKJ; Ethylenediamine-N,N'-diacetic Acid Complexes with Divalent Manganese, Zinc, Cadmium, and Lead: A Thermodynamic Study

Reference No.: 2088(66SuY)

J. Inorg. Nucl. Chem., 1966, 28, 473 - 480; Suzuki K; Yamasaki K; The Stability Constants of Selenodiglycolic Acid Chelates of Bivalent Metals

Reference No.: 2122(60BaS)

J. Inorg. Nucl. Chem., 1960, 15, 125 - 132; Banks CV; Singh RS; Composition and Stability of some Metal-5-Sulphosalicylate Complexes

Reference No.: 2126(67PeS)

J. Chem. Soc. (A), 1967,, 724 - 728; Perrin DD; Sharma VS; Histidine Complexes with some Bivalent Cations

Reference No.: 2131(93SKN)

J. Chem. Soc., Dalton Trans., 1993,, 2557 - 2562; Sawada K; Kanda T; Naganuma Y; Suzuki T; Formation and Protonation of Aminopolyphosphonate Complexes of Alkaline-earth and Divalent Transition-metal Ions in Aqueous Solution

Reference No.: 2152(83Mor)

Principles of Aquatic Chemistry, 1983 Morel FMM; John Wiley & Sons

Reference No.: 2156(77RoW)

J. Inorg. Nucl. Chem., 1977, 39, 367 - 369; Roos JTH; Williams DR; Formation Constants for Citrate-, Folic Acid-, Gluconate- and Succinate-proton, -manganese(II), and -zinc(II) Systems: Relevance to Absorption of Dietary Manganese, Zinc and Iron

Reference No.: 2157(70Wil)

J. Chem. Soc. (A), 1970,, 1550 - 1555; Williams DR; Thermodynamic Considerations in Co-ordination. Part VII. Solubility of the Histidine-H⁺ System and Stability Constants, Free Energies, Enthalpies, and Entropies of Protonation of Histidine and Tryptophan and of Formation of their Manganese(II), Iron(II), Cobalt(II), Nickel(II), Copper(II), and Zinc(II) Complexes

Reference No.: 2161(73Wil)

J. Chem. Soc., Dalton Trans., 1973,, 1064 - 1066; Williams DR; Thermodynamic Considerations in Co-ordination. Part XIII. Formation Constants for the Glutamate- and Serinate-proton, -Manganese(II), -Iron(II), -Cobalt(II), -Nickel(II), -Copper(II), and -Zinc(II) Systems

Reference No.: 2182(85HCW)

Inorg. Chim. Acta, 1985, 107, L29 - L32; Huang Z-X; Creighton AM; Williams DR; Metal Binding Properties of Two Homologues of Razoxane, a Bisdioxopiperazine Antitumour Drug

Reference No.: 2194(88KRZ)

J. Chem. Soc., Dalton Trans., 1988,, 67 - 71; Khan BT; Raju M; Zakeeruddin SM; Binary and Ternary Complexes of Guanosine: Stability and Thermodynamic Parameters

Reference No.: 2261(93PeP)

IUPAC Stability Constants Database, 1993 Pettit LD; Powell HKJ; IUPAC (in co-operation with Academic Software), Otley, UK

Reference No.: 2281(93WLH)

J. Chem. Soc., Dalton Trans., 1993,, 2017 - 2021; Wambeke DM; Lippens W; Herman GG; Goeminne AM; Metal-ion Complexation in Aqueous Solutions of 1-Thia-4,7-diazacyclononane-, 1-Thia-4,8-diazacyclodecane- and 2,5-Diazaheptane-N,N-diacetic Acid

Reference No.: 2292(92GNR)

J. Chem. Soc., Dalton Trans., 1992,, 475 - 479; Gajda T; Nagy L; Rozlosnik N; Korecz L; Burger K; Equilibrium and Spectroscopic Studies of Transition Metal Complexes of Sugar-containing Thiazolidine Derivatives

Reference No.: 2304(92GBN)

Polyhedron, 1992, 11, 2237 - 2243; Gajda T; Buzas N; Nagy L; Burger K; Manganese(II) and Nickel(II) Complexes of Some 2-(Polyhydroxyalkyl)thiazolidine-4-carboxylic Acid Derivatives

Reference No.: 2326(74KhK)

J. Inorg. Nucl. Chem., 1974, 36, 711 - 714; Khan MMT; Krishnamoorthy CR; Interactions of Metal Ions with Pyrimidines

Reference No.: 2334(93KOK)

J. Chem. Soc., Dalton Trans., 1993,, 3379 - 3382; Kurihara M; Ozutsumi K; Kawashima T; Complexation of Manganese(II) and Zinc(II) Ions with Pyridine, 3-Methylpyridine and 4-Methylpyridine in Dimethylformamide

Reference No.: 2350(89Lau)

Comprehensive Coordination Chemistry, Vol. 2, 1989, 739 - 776; Laurie SH; Amino Acids, Peptides and Proteins

Reference No.: 2358(83Bil)

Polyhedron, 1983, 2, 353 - 358; Bilinski H; Precipitation and Complex Formation in the System $Mn(ClO_4)_2 \cdot Na_4P_2O_7$ - pH (295 K, $I=0.5$ and $I=0$ mol dm⁻³)

Reference No.: 2360(83Van)

Polyhedron, 1983, 2, 285 - 289; van Uitert LG; Chelate Compound Stability Constant Calculations on Metal Diketonate Complexes

Reference No.: 2371(83ReR)

Polyhedron, 1983, 2, 1171 - 1175; Reddy PR; Reddy MH; Ternary Complexes of Mixed N/O Donor Ligands in Solution

Reference No.: 2373(89And)

Comprehensive Coordination Chemistry, Vol. 2, 1989, 777 - 792; Anderegg G; Complexones

Reference No.: 2392(93SKG)

Pure Appl. Chem., 1993, 65, 1029 - 1080; Sovago I; Kiss T; Gergely A; Critical Survey of the Stability Constants of Complexes of Aliphatic Amino Acids

Reference No.: 2404(79YMA)

Talanta, 1979, 26, 479 - 485; Yoshino T; Murakami S; Arita K; Ishizu K; Study on Semi-glycinecresol Red Complexes with Bivalent Metal Ions

Reference No.: 2446(91DaK)

J. Inorg. Biochem., 1991, 42, 153 - 159; Dash BC; Kanungo BK; Ternary Complexes of Some Bivalent Metal Ions with (Trans-1,2-Cyclo- hexylene-dinitrilo) Tetra-Acetic Acid and Indole-3-Butyric Acid

Reference No.: 2491(72IJC)

J. Chem. Soc., Dalton Trans., 1972,, 1152 - 1157; Izatt RM; Johnson HD; Christensen JJ;

Log K, delta-H, and delta-S Values for the Interaction of Glycinate Ion with H⁺, Mn²⁺, Fe²⁺, Co²⁺, Ni²⁺, Cu²⁺, Zn²⁺, and Cd²⁺ at 10, 25, and 40 C

Reference No.: 2502(70PoP)

Inorg. Chim. Acta, 1970, 4, 521 - 525; Podlaha J; Podlahova J; Metal Complexes of Thiopolycarboxylic Acids. I. Complexes of Thiodiacetic Acid in Solution

Reference No.: 2503(71PoP)

Inorg. Chim. Acta, 1971, 5, 413 - 419; Podlaha J; Podlahova J; Metal Complexes of Thiopolycarboxylic Acids. III. Ethylenedithiodiacetic Acid

Reference No.: 2504(71PoP)

Inorg. Chim. Acta, 1971, 5, 420 - 424; Podlaha J; Podlahova J; Metal Complexes of Thiopolycarboxylic Acids. IV. Diethylenetrithiodiacetic Acid

Reference No.: 2516(91DLL)

Inorg. Chim. Acta, 1991, 188, 55 - 59; Duckworth PA; Lincoln SF; Lucas J; The Complexation of Divalent Metal Ions by the Cryptand 4,7,13-Trioxa-1,10-diazabicyclo[8.5.5]eicosane (C21C5) in Water and 95% Methanol/Water Solutions

Reference No.: 2551(91And)

Inorg. Chim. Acta, 1991, 180, 69 - 72; Anderegg G; Correlation between Thermodynamic Functions of Metal Complex Formation and Basicities of the Iminodiacetate Derivatives

Reference No.: 2556(93MSM)

NIST Critical Stability Constants of Metal Complexes Database, 1993 Martell AE; Smith RM; Motekaitis RJ; Version 1.0; National Institute of Standards and Technology, Gaithersburg, USA

Reference No.: 2558(54Cha)

J. Am. Chem. Soc., 1954, 76, 5854 - 5858; Charles RG; Heats and Entropies of Reaction of Metal Ions with Ethylenediaminetetraacetate

Reference No.: 2576(59MaE)

J. Am. Chem. Soc., 1959, 81, 4044 - 4047; Martin RB; Edsall JT; The Association of Divalent Cations with Glutathione

Reference No.: 2601(88LTM)

J. Chem. Soc., Faraday Trans. 1, 1988, 84, 969 - 978; Laubry P; Tissier C; Mousset G; Juillard J; Interactions between Metal Cations and the Ionophore Lasalocid Part 3. Interactions of Lasalocid with Mn²⁺, Fe²⁺, Co²⁺, Ni²⁺ and Zn²⁺ in Methanol

Reference No.: 2610(75LaP)

J. Chem. Soc., Dalton Trans., 1975,, 2297 - 2301; Laing DK; Pettit LD; Ligands Containing Elements of Group 6B. Part VII. Comparison of the Donor Properties of some Dicarboxylic Acids of Sulphur, Selenium and Tellurium towards Silver(I) and some Bivalent Metal Ions

Reference No.: 2612(75DaN)

J. Inorg. Nucl. Chem., 1975, 37, 995 - 997; Das AR; Nair VSK; Studies on Metal Complexes in Aqueous Solution - IX. 5-Nitrosalicylates of some Transition Metals

Reference No.: 2618(55EvM)

J. Chem. Soc., Faraday Trans., 1955, 51, 1244 - 1250; Evans WP; Monk CB; Electrolytes in Solutions of Amino Acids. Part 6. - Dissociation Constants of some Triglycinates

Reference No.: 2648(77Sig)

J. Inorg. Nucl. Chem., 1977, 39, 1903 - 1911; Sigel H; Comparison of the Stabilities of

Binary and Ternary Complexes of Divalent Metal Ions with the 5'-Triphosphates of Adenosine, Inosine, Guanosine, Cytidine, Uridine and Thymidine

Reference No.: 2653(80CrF)

J. Inorg. Nucl. Chem., 1980, 42, 1595 - 1602; Crow DR; Fonseca D; Polarographic Studies of some Manganese-Pyrazole Complexes

Reference No.: 2654(68CrW)

J. Inorg. Nucl. Chem., 1968, 30, 179 - 187; Crow DR; Westwood JV; Polarographic Study of Pyrazole Complexes of some Transition Metals

Reference No.: 2697(82TaS)

Inorg. Chim. Acta, 1982, 66, 119 - 124; Takeshima S; Sakurai H; Physico-chemical and Metal-binding Properties of Thiolhistidine

Reference No.: 2702(85WTL)

J. Coord. Chem., 1985, 14, 31 - 38; Warnke Z; Trojanowska C; Liwo A; Potentiometric Study of Complex Formation of some Divalent Metal Ions with 2-Aminooxyacids

Reference No.: 2703(79ADC)

Inorg. Chim. Acta, 1979, 36, 1 - <; Amico P; Daniele PG; Cucinotta V; Rizzarelli E; Sammartano S; Equilibrium Study of Iron(II) and Manganese(II) Complexes with Citrate Ion in Aqueous Solution: Relevance to Coordination of Citrate to the Active Site of Aconitase and to Gastrointestinal Absorption of some Essential Metal Ions

Reference No.: 2710(84KDG)

Inorg. Chim. Acta, 1984, 91, 269 - 277; Kiss T; Deak G; Gergely A; Complexes of 3,4-Dihydroxyphenyl Derivatives. VII. Mixed Ligand Complexes of L-Dopa and Related Compounds

Reference No.: 2717(93BGE)

J. Chem. Soc., Chem. Commun., 1993,, 574 - 575; Brucher E; Gyori B; Emri J; Solymosi P; Sztanyik LB; Varga L; 1,10-Diaza-4,7,13,16-tetraoxacyclooctadecane-1,10-bis(malonate), a Ligand With High Sr²⁺/Ca²⁺ and Pb²⁺/Zn²⁺ Selectivities in Aqueous Solution

Reference No.: 2739(81SaT)

Ganryu Aminosan, 1981, 4, 257 - 265; Sakurai H; Takeshima S

Reference No.: 2906(88SMT)

J. Am. Chem. Soc., 1988, 110, 6857 - 6865; Sigel H; Massoud SS; Tribolet R; Comparison of the Metal Ion Coordinating Properties of Tubercidin 5'-Monophosphate (7-Deaza-AMP) with Those of Adenosine 5'-Monophosphate (AMP) and 1,N6-Ethenoadenosine 5'-Monophosphate (epsilon-AMP). Definite Evidence for Metal Ion-Base Backbinding to N-7 and Extent of Macrochelate Formation in M(AMP) and M(epsilon-AMP)

Reference No.: 2913(85Led)

J. Am. Chem. Soc., 1985, 107, 6755 - 6765; Led JJ; Paramagnetic Carbon-13 and Phosphorus-31 NMR Relaxation Studies in the Stability, Structure, and Dynamics of Complexes in the Glycine/ Manganese(II)/Adenosine 5'-Triphosphate System

Reference No.: 2961(78MiS)

J. Am. Chem. Soc., 1978, 100, 1564 - 1570; Mitchell PR; Sigel H; Enhanced Stability of Ternary Metal Ion/Adenosine 5'-Triphosphate Complexes. Cooperative Effects Caused by Stacking Interactions in Complexes Containing Adenosine Triphosphate, Phenanthroline, and Magnesium, Calcium, or Zinc Ions

Reference No.: 3006(85BPJ)

Standard Potentials in Aqueous Solution, 1985 Bard AJ; Parsons R; Jordan J; Monographs in Electroanalytical Chemistry and Electrochemistry; Marcel Dekker Inc., New York and Basel

Reference No.: 3075(62IrM)

J. Chem. Soc., 1962,, 5222 - 5327; Irving H; Mellor DP; The Stability of Metal Complexes of 1,10-phenanthroline and its Analogues. Part I. 1,10-Phenanthroline and 2,2'-Bipyridyl

Reference No.: 3076(62IrM)

J. Chem. Soc., 1962,, 5237 - 5245; Irving H; Mellor DP; The Stability of Metal Complexes of 1,10-Phenanthroline and its Analogues. Part II. 2-Methyl- and 2,9-Dimethyl-phenanthroline

Reference No.: 3077(62MBI)

J. Chem. Soc., 1962,, 5245 - 5253; McBryde WAE; Brisbin DA; Irving H; The Stability of Metal Complexes of 1,10-Phenanthroline and its Analogues. Part III. 5-Methyl-1,10-phenanthroline

Reference No.: 3082(73StC)

J. Inorg. Nucl. Chem., 1973, 35, 1621 - 1636; Steger HF; Corsini A; Stability of Metal Oxinates - I. Effect of Ligand Basicity

Reference No.: 3100(75FiS)

J. Inorg. Nucl. Chem., 1975, 37, 2127 - 2132; Fischer BE; Sigel H; Hydration, Protonation and Metal Ion-coordination of Di-2-pyridyl Ketone

Reference No.: 3101(75DaN)

J. Inorg. Nucl. Chem., 1975, 37, 2125 - 2126; Das AR; Nair VSK; Studies on Metal Complexes in Aqueous Solution - XI 3,5-Dinitrosalicylates of Some Transition Metals

Reference No.: 3107(73TeS)

J. Inorg. Nucl. Chem., 1973, 35, 2441 - 2446; Tewari RC; Srivastava MN; Formation and Stabilities of Some Bivalent Metal Ion Chelates of L-Glutamine

Reference No.: 3146(76ElE)

J. Inorg. Nucl. Chem., 1976, 38, 1901 - 1905; El-Ezaby MS; El-Eziri FR; Equilibrium Studies of some Divalent Metal Ions Complexes with Pyridoxol, Pyridoxal and Pyridoxamine

Reference No.: 3147(76RRK)

J. Inorg. Nucl. Chem., 1976, 38, 1923 - 1924; Reddy PR; Reddy KV; Khan MMT; Interaction of Metal Ions with Xanthosine

Reference No.: 3159(76KhR)

J. Inorg. Nucl. Chem., 1976, 38, 1234 - 1236; Khan MMT; Reddy PR; Interaction of Metal Ions with Uridine Triphosphate

Reference No.: 3186(75KhR)

J. Inorg. Nucl. Chem., 1975, 37, 771 - 774; Khan MMT; Reddy PR; Interaction of Metal Ions with Cytidinetriphosphate

Reference No.: 3290(74HaM)

J. Chem. Soc., Dalton Trans., 1974,, 254 - 258; Hague DN; Martin SR; Kinetics of Ternary Complex Formation between Manganese(II) Species and 2,2'-Bipyridine

Reference No.: 3335(92GAH)

Monatsh. Chem., 1992, 123, 51 - 58; Ghandour MA; Azab HA; Hassan A; Ali AM; Potentiometric Studies on the Complexes of Tetracycline (TC) and Oxytetracyclin(OTC) with Some Metal Ions

Reference No.: 3369(79Ina)

Monatsh. Chem., 1979, 110, 1205 - 1212; Inamul-Haq; Stability of Bivalent Metal Complex with L-Hydroxyproline

Reference No.: 3429(94GAD)

J. Chem. Soc., Dalton Trans., 1994,, 841 - 845; Gangopadhyay S; Ali M; Dutta A; Banerjee P; Oxidation of Thioglycolic Acid and Glutathione by (trans-Cyclohexane-1,2-diamine-N,N,N',N'-tetraacetato)manganate(III) in Aqueous Media

Reference No.: 3464(66DTS)

J. Inorg. Nucl. Chem., 1966, 28, 833 - 844; Doody E; Tucci ER; Scruggs R; Li NC; Metal Complexes of Pyrimidine Derivatives and Adenosine Monophosphate - III

Reference No.: 3468(70JaC)

Biochim. Biophys. Acta, 1970, 222, 542 - 545; Jallon J-M; Cohn M; Temperature Dependence of Binding Constants of Mn(II) to ADP and ATP

Reference No.: 3469(77RSB)

Biochim. Biophys. Acta, 1977, 499, 411 - 420; Ragot M; Sari JC; Belaich JP; Thermodynamic Study of the Formation of Adenine Nucleotide-Manganese Complexes. I. 'pH Stat' Titration Method Results

Reference No.: 3470(77RSB)

Biochim. Biophys. Acta, 1977, 499, 421 - 431; Ragot M; Sari JC; Belaich JP; Thermodynamic Study of the Formation of Adenine Nucleotide-Manganese Complexes. II. Calorimetric Results

Reference No.: 3481(67KhM)

J. Am. Chem. Soc., 1967, 89, 5585 - 5590; Khan MMT; Martell AE; Thermodynamic Quantities Associated with the Interaction of Adenosinediphosphoric and Adenosinemonophosphoric Acids with Metal Ions

Reference No.: 3482(66KhM)

J. Am. Chem. Soc., 1966, 88, 668 - 671; Khan MMT; Martell AE; Thermodynamic Quantities Associated with the Interaction of Adenosine Triphosphate with Metal Ions

Reference No.: 3486(55SAS)

Helv. Chim. Acta, 1955, 38, 1147 Schwarzenbach G; Anderegg G; Schneider W; Senn H; Complexons. XXVI. The Co-ordination Tendency of N-Substituted Iminoacetic Acids (Komplexone XXVI. Über die Koordinationstendenz von N-Substituierten Iminodienes-Sigsauren)

Reference No.: 3499(71SSC)

Indian J. Chem., 1971, 9, 485 Sekhon BS; Singh PP; Chopra SL; Stability Constants of Mn(2+) and UO2(2+) Complexes with Some Amino Acids

Reference No.: 3504(68Doo)

Pharm. Weekbl., 1968, 103, 1213 - 1227; Doornbos DA; Stability Constants of Metal Complexes of L-Cysteine, D-Penicillamine and N-Acetyl-D-Penicillamine and Some Biguanidides

Reference No.: 3508(90SBW)

Analyst, 1990, 115, 1517 - 1523; Smith RM; Bale SJ; Westcott SG; Martin-Smith M; Modification of the High-performance Liquid Chromatographic Retention Behaviour of beta-Diketones by the Inclusion of Metal Ions in the Mobile Phase

Reference No.: 3511(70ClM)

J. Inorg. Nucl. Chem., 1970, 32, 911 Clarke ER; Martell AE; Metal Chelates of Arginine and Related Ligands

Reference No.: 3514(50Alb)

Biochem. J., 1950, 47, 531 - 537; Albert A; Quantitative Studies of the Avidity of Naturally Occurring Substances for Trace Metals. 1. Amino Acids Having Only Two Ionizing Groups

Reference No.: 3515(70Sta)

Nauch. Tr. Vissh. Pedagog., 1970, 8, 103 Stantcheva P; Co-ordination Compounds of Manganese with Urea and Thiourea

Reference No.: 3516(64LeM)

Biochemistry, 1964, 3, 745 - 750; Lenz GR; Martell AE; Metal Chelates of Some Sulfur-containing Amino Acids

Reference No.: 3535(68IsC)

Talanta, 1968, 15, 1031 Israeli J; Cecchetti M; Complexes Mixtes des Nitrilotriacetates Metalliques avec l'Acide Glutamique ou avec l'Acide Aspartique

Reference No.: 3565(85ReR)

J. Chem. Soc., Dalton Trans., 1985,, 239 - 242; Reddy PR; Reddy MH; Influence of Secondary Ligands on the Stability of Metal-Xanthosine Complexes in Solution

Reference No.: 3627(85GNS)

Gazz. Chim. Ital., 1985, 115, 607 - 611; Garcia-Espana E; Nuzzi F; Sabatini A; Vacca A; Reactions of 2-(Aminomethyl)pyridine with Hydrogen Ion and Divalent Transition Metal Ions. I. Equilibrium Constants

Reference No.: 3676(63SSA)

Helv. Chim. Acta, 1963, 46, 1391 - 1423; Schwarzenbach G; Schwarzenbach K; Anderegg G; L'Eplattenier F; Hydroxamatkomplexe I. Die Stabilitat der Eisen(III)-Komplexe einfacher Hydroxamsauren und des Ferrioxamine B and Hydroxamatkomplexe II. Die Anwendung der pH-Methode and Hydroxamatkomplexe III. Eisen(III)-Austausch zwischen Sideraminen und Komplexonen. Diskussion der Bildungskonstanten der Hydroxamatkomplexe

Reference No.: 3682(56AlR)

Nature (London), 1956, 177, 433 - 434; Albert A; Rees CW; Avidity of the Tetracyclines for the Cations of Metals

Reference No.: 3683(64HDS)

J. Chem. Soc., 1964,, 5422 - 5425; Hull JA; Davies RH; Staveley LAK; Thermodynamics of the Formation of Complexes of Nitrilotriacetic Acid and Bivalent Cations

Reference No.: 3733(74MuM)

Can. J. Chem., 1974, 52, 1821 - 1833; Mui K-K; McBryde WAE; The Stability of Some Metal Complexes in Mixed Solvents

Reference No.: 3750(83JaK)

Polyhedron, 1983, 2, 1313 - 1316; Jackson GE; Kelly MJ; Potentiometric Determination of the Stability Constants of a Model (Na⁺ + K⁺) ATPase Complex

Reference No.: 3761(87RAK)

Polyhedron, 1987, 6, 403 - 409; Rizkalla EN; Anis SS; Khalil LH; The Kinetics and Mechanisms of the Catalysed Decomposition of Hydrogen Peroxide by Ethylenediaminetetra(methylenephosphonato) Complex of Manganese(II)

Reference No.: 3802(89FRR)

Polyhedron, 1989, 8, 2693 - 2699; Fuentes J; Reboso R; Rodriguez A; Binary and Ternary Complexes of 1,3-Phenylenediamine-N,N'-Disuccinic Acid with Divalent Cations

Reference No.: 3834(92KKF)

Coord. Chem. Rev., 1992, 114, 169 - 200; Kurzak B; Kozlowski H; Farkas E; Hydroxamic and Aminohydroxamic Acids and their Complexes with Metal Ions

Reference No.: 3837(93Sig)

Coord. Chem. Rev., 1993, 122, 227 - 242; Sigel H; Quantification of Successive Intramolecular Equilibria in Binary Metal Ion Complexes of N,N-bis-(2-hydroxyethyl)glycinate (Bicinate). A Case Study

Reference No.: 3858(83OZW)

Inorg. Chim. Acta, 1983, 70, 41 - 45; Otto M; Zwanziger H; Werner G; Stabilities of Binary and Ternary Complexes of Divalent Metal Ions with Tiron and 2,2'-Bipyridyl

Reference No.: 3867(83ReR)

Inorg. Chim. Acta, 1983, 80, 95 - 98; Reddy PR; Reddy KV; Stabilities and thermodynamic Parameters of 1:2 Metal-Xanthosine Complexes in Solution

Reference No.: 3882(82FaP)

Inorg. Chim. Acta, 1982, 59, 87 - 91; Farmer RM; Popov AI; ESR Study of Manganese(II) Complexes in Aqueous Solutions

Reference No.: 3886(82KiR)

Inorg. Chim. Acta, 1982, 63, 47 - 52; Kittl WS; Rode BM; Complex Formation of Aliphatic Dipeptides with Zinc(II) and Manganese(II)

Reference No.: 3977(77MoF)

Anal. Chem., 1977, 49, 418 - 423; Moyers EM; Fritz JS; Preparation and Analytical Applications of a Propylenediaminetetraacetic Acid Resin

Reference No.: 4036(78ZLD)

J. Am. Chem. Soc., 1978, 100, 4430 - 4436; Zetter MS; Lo GY-S; Dodgen HW; Hunt JP; Oxygen-17 Nuclear Magnetic Resonance Studies on Bound Water in Manganese(II)-Adenosine Diphosphate

Reference No.: 4259(90BBD)

Inorg. Chem., 1990, 29, 1716 - 1718; Bencini A; Bianchi A; Dapporto P; Garcia-Espana E; Marcelino V; Micheloni M; Paoletti P; Paoli P; Heptacoordination of Manganese(II) by the Polyazacycloalkane [21]aneN7 Crystal Structure of the $[\text{Mn}([21]\text{aneN7})](\text{ClO}_4)_2$ Solid Compound and Thermodynamics of Complexation in Water Solution

Reference No.: 4409(94ASM)

Talanta, 1994, 41, 1107 - 1112; Abollino O; Sarzanini C; Mentasti E; Liberatori A; Evaluation of Stability Constants of Metal Complexes with Sulphonated Azo-Ligands

Reference No.: 4431(66SkK)

Russ. J. Inorg. Chem., 1966, 11, 1478 - 1481; Sklenskaya EV; Karapet'yants MKh; Instability Constants of Complexes of the Transition Metals with Monoethanolamine, Diethanolamine, Triethanolamine, and Butyldiethanolamine [2-Aminoethanol, 2,2'-Iminodi(Ethanol) 2,2',2''-Nitrilotri(Ethanol), and 2,2'-Butyliminodi(Ethanol)]

Reference No.: 4454(48MeM)

Nature (London), 1948, 20, 436 - 437; Mellor DP; Maley L; Order of Stability of Metal Complexes

Reference No.: 4460(94SMC)

J. Am. Chem. Soc., 1994, 116, 2958 - 2971; Sigel H; Massoud SS; Corfu NA; Comparison of the Extent of Macrochelate Formation in Complexes of Divalent Metal Ions with Guanosine (GMP-2), Inosine (IMP-2) and Adenosine 5'-Monophosphate (AMP-2). The Crucial Role of N-7 Basicity in Metal Ion-Nucleic Base Recognition

Reference No.: 4478(94SCB)

Helv. Chim. Acta, 1994, 77, 1738 - 1756; Song B; Chen D; Bastian M; Martin RB; Sigel H; Metal-Ion-Coordinating Properties of a Viral Inhibitor, a Pyrophosphate Analogue, and a Herbicide Metabolite, a Glycinate Analogue: The Solution Properties of the Potentially Five-Membered Chelates Derived from Phosphonoformic Acid and (Aminomethyl)phosphonic Acid

Reference No.: 4493(94KOK)

J. Chem. Soc., Dalton Trans., 1994,, 3267 - 3271; Kurihara M; Ozutsumi K; Kawashima T; Thermodynamics of Complexation of Manganese(II) and Zinc(II) Ions with Pyridine, 3-Methyl- and 4-Methyl-pyridine in Cyanomethane

Reference No.: 4540(76SiN)

J. Am. Chem. Soc., 1976, 98, 730 - 739; Sigel H; Naumann CF; Ternary Complexes in Solution. XXIV. Metal Ion Bridging of Stacked Purine-Indole Adducts. The Mixed-Ligand Complexes of Adenosine 5'-Triphosphate, Tryptophan, and Manganese(II), Copper(II), or Zinc(II)

Reference No.: 4604(80Avs)

J. Inorg. Nucl. Chem., 1980, 42, 881 - 883; Avsar E; A Potentiometric Study of Azide Complexes of Cobalt(II) and Manganese(II)

Reference No.: 4609(74Aru)

J. Inorg. Nucl. Chem., 1974, 36, 3779 - 3782; Aruga R; Thermodynamics of Association of Thiosulphate Ion with Several Mono- and Bivalent Metal Ions

Reference No.: 4701(75Aru)

J. Chem. Soc., Dalton Trans., 1975,, 2534 - 2538; Aruga R; Thermodynamics of Ion Pairing of Nitrate and Chlorate with Metal Ions in Aqueous Solution

Reference No.: 4734(74GeS)

Bull. Soc. Chim. Fr., 1974,, 1307 - 1310; Genin R; Scharff J-P; Etude des Interactions en Solution Aqueuse Entre les Ions Manganese(II) et l'Acide Pyrocatecholdisulfonique-3,5

Reference No.: 4870(91BFK)

J. Chem. Soc., Dalton Trans., 1991,, 2989 - 2994; Bailey NA; Fenton DE; Kitchen SJ; Lilley TH; Williams MG; Tasker PA; Leong AJ; Lindoy LF; Metal-ion Selectivity by Macrocyclic Ligands. Part 3. The Interaction of Mn(II) and Co(II) with Pyridinyl-derived N3O2 Macrocycles: X-Ray Structures of Endomacrocyclic Complexes of Mn(II) and Co(II)

Reference No.: 4914(94CIO)

Chem. Rev., 1994, 94, 467 - 517; Chen X; Izatt RM; Oscarson JL; Thermodynamic Data for Ligand Interaction with Protons and Metal Ions in Aqueous Solutions at High Temperatures

Reference No.: 4992(72KuB)

Russ. J. Inorg. Chem., 1972, 17, 68 - 69; Kublanovskii VS; Belinskii VN; Formation of Ammonia Complexes of Manganese(II)

Reference No.: 4998(86BaM)

The Hydrolysis of Cations, 1986 Baes CF Jr; Mesmer RE; Robert E. Krieger Publ. Co. Malabar, Florida

Reference No.: 4999(71KBZ)

Russ. J. Inorg. Chem., 1971, 16, 1598 - 1600; Kublanovskii VS; Belinskii VN; Zozimovich DP; Sulphato-Complexes of Manganese(II) in the MnSO₄-(NH₄)₂-SO₄-H₂O System

Reference No.: 5000(74BRM)

Russ. J. Phys. Chem., 1974, 48, 82 - 83; Blokhin VV; Razmyslova LI; Makashev YuA; Mironov VE; Thermodynamics of Acido-complexes of Transition Metals

Reference No.: 5014(74FRS)

Russ. J. Inorg. Chem., 1974, 19, 830 - 832; Fedorov VA; Robov AM; Shmy'ko II; Zdanovskii VV; Mironov VE; The Formation of Manganese(II) Nitrate Complexes

Reference No.: 5053(83CiP)

Gazz. Chim. Ital., 1983, 113, 557 - 562; Ciavatta L; Palombari R; On the Equilibria of Complex Formation between Manganese(III) and Pyrophosphate Ions

Reference No.: 5070(91RZS)

J. Solution Chem., 1991, 20, 467 - 478; Roy RN; Zhang J-Z; Sibblies MA; Millero FJ; The pK_2^* for the Dissociation of H_2SO_3 in NaCl Solutions with added Ni^{+2} , Co^{+2} , Mn^{+2} , and Cd^{+2} at 25 degrees Celsius

Reference No.: 5125(64GuH)

Inorg. Chem., 1964, 3, 259 - 264; Guzetta FH; Hadley WB; Crystal Field Effects in Coordination Compounds. A Calorimetric Study of some Hexacyano Metal Complexes

Reference No.: 5138(92Zie)

J. Solution Chem., 1992, 21, 745 - 760; Ziemniak SE; Metal Oxide Solubility Behaviour in High Temperature Aqueous Solutions

Reference No.: 5156(91ReB)

Radiochim. Acta, 1991, 52/53, 453 - 456; Read D; Broyd TW; Recent Progress in Testing Chemical Equilibrium Models: The CHEMVAL Project

Reference No.: 5174(64BUP)

Russ. J. Inorg. Chem., 1964, 9, 292 - 294; Buketov EA; Ugorets MZ; Pashinkin AS; Solubility Products and Entropies of Sulphides, Selenides, and Tellurides

Reference No.: 5181(83PaV)

Chem. Rev., 1983, 83, 651 - 731; Palmer DA; van Eldik R; The Chemistry of Metal Carbonato and Carbon Dioxide Complexes

Reference No.: 5182(87MiB)

Econ. Geol., 1987, 82, 706 - 718; Miyano T; Beukes NJ; Physicochemical Environments for the Formation of Quartz-free Manganese Oxide Ores from the Early Proterozoic Hotazel Formation, Kalahari Manganese Field, South Africa

Reference No.: 5219(78LeB)

Inorg. Chem., 1978, 17, 3332 - 3334; Lesht D; Baumann JE Jr; Thermodynamics of the Manganese(II) Bicarbonate System

Reference No.: 5220(94Neh)

Acta Chem. Scand., 1994, 48, 393 - 398; Neher-Neumann E; Studies on Metal Carbonate Equilibria 26. The Hydrogen Carbonate Complex of Manganese(II) in Acid Solutions and 3M (Na)ClO₄ Ionic Medium at 25C. Determination of the Solubility Product of $MnCO_3(s)$

Reference No.: 5230(70GhN)

J. Inorg. Nucl. Chem., 1970, 32, 3041 - 3051; Ghosh R; Nair VSK; Studies on Metal Complexes in Aqueous Solution III. The Biselenate Ion and Transition Metal Selenates

Reference No.: 5298(87AvB)

Polyhedron, 1987, 6, 1909 - 1912; Avsar E; Basaran B; Formation of Cyanide Complexes of Cobalt(II) and Manganese(II)

Reference No.: 5329(67MNT)

Inorg. Chem., 1967, 6, 136 - 138; McAuley A; Nancollas GH; Torrance K; Thermodynamics of Ion Association. XIII. Divalent Metal Succinates

Reference No.: 5390(95Woo)

Thesis, Univ. Cape Town, 1995 Woolard C; A Computer Simulation of the Trace Metal Speciation in Seawater; Univ. Cape Town, South Africa

Reference No.: 5398(82Hog)

IUPAC Chemical Data Series No. 21, 1982 Hogfeldt E; Stability Constants of Metal-ion Complexes, 2nd Suppl., Part A, Inorganic Ligands; Pergamon, Oxford

Reference No.: 5406(97Sjo)

Pure Appl. Chem., 1997, 69, 1549 - 1570; Sjoberg S; Critical Evaluation of Stability Constants of Metal-Imidazole and Metal-Histamine Systems

Reference No.: 5426(73NMT)

Nippon Kagaku Kaishi, 1973,, 2030 Nozaki T; Mise T; Torii K

Reference No.: 5456(78BiP)

Acta Chem. Scand., 1978, A32, 381 Biedermann G; Palombari R; On the Hydrolysis of the Manganese(III) Ion

Reference No.: 5458(80BeT)

Report LBL-11448, 1980 Benson LV; Teague LS; Tabulation of Thermodynamic Data for Chemical Reactions Involving 58 Elements Common to Radioactive Waste

Reference No.: 5468(77Wag)

Water Res., 1977, 12, 139 - 145; Wagemann R; Some Theoretical Aspects of Stability and Solubility of Inorganic Arsenic in the Fresh Water Environment

Reference No.: 5495(88BLR)

Environmental Inorganic Chemistry, 1988 Bodek I; Lyman WJ; Reehl WF; Rosenblatt DH; Properties, Processes and Estimation Methods; Pergamon

Reference No.: 5530(75Rei)

Thesis, Univ. Leoben, 1975 Reiterer F; Montanuniversitaet Leoben, Austria

Reference No.: 5554(70MeG)

J. Less-Common Met., 1970, 22, 281 - 285; Mehra MC; Gubeli AO; The Complexing Characteristics of Insoluble Selenides. II. Manganese Selenide

Reference No.: 5592(75LiT)

J. Solution Chem., 1975, 4, 1011 - 1022; Libus Z; Tialowska H; Stability and Nature of Complexes of the Type MCl^+ in Aqueous Solution ($M = Mn, Co, Ni, \text{ and } Zn$)

Reference No.: 5648(72MoO)

Ions in Aqueous Systems, 1972 Moller T; O'Connor R; An Introduction to Chemical Equilibrium and Solution Chemistry; McGraw-Hill Book Co., N.Y.

Reference No.: 5674(74DeF)

Biochemistry, 1974, 13, 5022 - 5032; Degani H; Friedman HL; Ion Binding by X-537A. Formulas, Formation Constants, and Spectra of Complexes

Reference No.: 5685(61McN)

J. Chem. Soc., 1961,, 4458 - 4463; McAuley A; Nancollas GH; Thermodynamics of Ion Association. Part IX. Some Transition-metal Succinates

Reference No.: 5693(79McP)

Can. J. Chem., 1979, 57, 1785 - 1791; McBryde WAE; Powell HKJ; Reactions of Triethylenetetramine with Protons and Bivalent Zinc, Cadmium, and Lead in Aqueous Solution and Aqueous Dioxane (50% v/v)

Reference No.: 5703(53KLM)

J. Am. Chem. Soc., 1953, 75, 4159 - 4162; Klotz IM; Ming WCL; Stability Constants for Some Metal Chelates of Pyridine-2-azo-rho-dimethylaniline

Reference No.: 5748(62JoS)

J. Chem. Soc., 1962,, 306 - 311; Jones RH; Stock DI; The Dissociation Constants in Water of Some Bivalent Metal Alkanedicarboxylates

Reference No.: 5843(63McN)

J. Chem. Soc., 1963,, 989 - 993; McAuley A; Nancollas GH; Thermodynamics of Ion Association. Part X. Calorimetric Heats of Formation

Reference No.: 5987(97LPP)

Pure Appl. Chem., 1997, 69, 329 - 381; Lajunen LHJ; Portanova R; Piispanen J; Tolazzi M; Stability Constants for alpha-Hydroxycarboxylic Acid Complexes with Protons and Metal Ions and the Accompanying Enthalpy Changes. Part I: Aromatic ortho-Hydroxycarboxylic Acids

Reference No.: 5991(78SPM)

Arch. Biochem. Biophys., 1978, 187, 208 - 214; Sigel H; Prijs B; McCormick DB; Shih JCH; Stability and Structure of Binary and Ternary Complexes of alpha-Lipoate and Lipoate Derivatives with Mn^{2+} , Cu^{2+} , and Zn^{2+} in Solution

Reference No.: 6000(96YaO)

Pure Appl. Chem., 1996, 68, 469 - 496; Yamauchi O; Odani A; Stability Constants of Metal Complexes of Amino Acids with Charged Side Chains - Part I: Positively Charged Side Chains

Reference No.: 6024(52Alb)

Biochem. J., 1952, 50, 690 - 698; Albert A; Quantitative Studies of the Avidity of Naturally Occurring Substances for Trace Metals. 2. Amino-Acids having Three Ionizing Groups

Reference No.: 6036(69GPS)

Inorg. Nucl. Chem. Lett., 1969, 5, 951 - 956; Griesser R; Prijs B; Sigel H; McCormick DB; Binary and Ternary Me^{2+} Complexes with alpha- or beta-Substituted Halogeno Carboxylic Acids

Reference No.: 6048(69RaM)

J. Inorg. Nucl. Chem., 1969, 31, 425 - 432; Raju EV; Mathur HB; Thermochemical Studies: The Heats and Entropies of Reactions of Transition Metal Ions with Histidine

Reference No.: 6055(64SiB)

Helv. Chim. Acta, 1964, 47, 1701 - 1717; Sigel H; Brintzinger H; Adenosin-5'-Monophosphat-N(1)-Oxid Ein (Ambivalentes) Ligandsystem

Reference No.: 6061(66PSE)

Helv. Chim. Acta, 1966, 49, 1612 - 1616; Petri S; Sigel H; Erlenmeyer H; Metall-Komplexbildung von beta-Hydroxy-thiophenderivaten III

Reference No.: 6068(68EGP)

Helv. Chim. Acta, 1968, 51, 339 - 348; Erlenmeyer H; Griesser R; Prijs B; Sigel H; Metal Ion Complex Formation of Five-Membered Carboxyheterocycles Zur Metallion-Komplexbildung Funfgliedriger alpha-Carboxy-Heterocyclen

Reference No.: 6070(69SGP)

Arch. Biochem. Biophys., 1969, 130, 514 - 520; Sigel H; Griesser R; Prijs B; McCormick DB; Joiner MG; "Hard and Soft" Behavior of Mn²⁺, Cu²⁺, and Zn²⁺ with Respect to Carboxylic Acids and alpha-Oxy- or alpha-Thio-Substituted Carboxylic Acids of Biochemical Significance

Reference No.: 6071(69SMG)

Biochemistry, 1969, 8, 2687 - 2695; Sigel H; McCormick DB; Griesser R; Prijs B; Wright LD; Metal Ion Complexes with Biotin and Biotin Derivatives. Participation of Sulfur in the Orientation of Divalent Cations

Reference No.: 6073(70GPS)

Biochemistry, 1970, 9, 3285 - 3293; Griesser R; Prijs B; Sigel H; Fory W; Wright LD; McCormick DB; Stability and Structure of Binary and Ternary Metal Ion Complexes with Biocytin, the Sulfoxide and Sulfone, N-Acetyl-L-lysine, and L-Alanine

Reference No.: 6082(75Sig)

J. Am. Chem. Soc., 1975, 97, 3209 - 3214; Sigel H; Nucleic Base-Metal Ion Interactions. Acidity of the N(1) or N(3) Proton in Binary and Ternary Complexes of Mn²⁺, Ni²⁺, and Zn²⁺ with the 5'-Triphosphates of Inosine, Guanosine, Uridine, and Thymidine

Reference No.: 6086(79FHT)

Eur. J. Biochem., 1979, 94, 523 - 530; Fischer BE; Haring UK; Tribolet R; Sigel H; Metal Ion/Buffer Interactions. Stability of Binary and Ternary Complexes Containing 2-Amino-2(hydroxymethyl)-1,3-Propanediol (Tris) and Adenosine 5'-Triphosphate (ATP)

Reference No.: 6089(80SAP)

Eur. J. Biochem., 1980, 107, 455 - 466; Scheller KH; Abel THJ; Polanyi PE; Wenk PK; Fischer BE; Sigel H; Metal Ion/Buffer Interactions. Stability of Binary and Ternary Complexes Containing 2-[Bis(2-Hydroxyethyl) Amino]-2(Hydroxymethyl)-1,3-Propanediol (Bistris) and Adenosine 5'-Triphosphate (ATP)

Reference No.: 6097(84SiS)

Eur. J. Biochem., 1984, 138, 291 - 299; Sigel H; Scheller KH; On the Metal-Ion Coordinating Properties of the 5'-Monophosphates of 1, N6-Ethenoadenosine (epsilon-AMP), Adenosine and Uridine. Comparison of the Macrochelate formation in the Complexes of epsilon-AMP, AMP, ADP and ATP

Reference No.: 6100(87Sig)

Eur. J. Biochem., 1987, 165, 65 - 72; Sigel H; Isomeric Equilibria in Complexes of Adenosine 5'-Triphosphate with Divalent Metal Ions. Solution Structures of M(ATP)-2 Complexes

Reference No.: 6104(89MaS)

Eur. J. Biochem., 1989, 179, 451 - 458; Massoud SS; Sigel H; Evaluation of the Metal-ion-coordinating Differences between the 2'-, 3'- and 5'-Monophosphates of Adenosine

Reference No.: 6105(89KTC)

Inorg. Chem., 1989, 28, 1480 - 1489; Kinjo Y; Tribolet R; Corfu NA; Sigel H; Stability and Structure of Xanthosine-Metal Ion Complexes in Aqueous Solution, Together with Intramolecular Adenosine-Metal Ion Equilibria

Reference No.: 6115(92KJC)

Inorg. Chem., 1992, 31, 5588 - 5596; Kinjo Y; Ji L-N; Corfu NA; Sigel H; Ambivalent Metal Ion Binding Properties of Cytidine in Aqueous Solution

Reference No.: 6128(95CDD)

Thermochim. Acta, 1995, 255, 109 - 141; Casale A; De Robertis A; De Stefano C; Gianguzza A; Patane G; Rigano C; Sammartano S; Thermodynamic Parameters for the Formation of Glycine Complexes with Magnesium(II), Calcium(II), Lead(II),

Manganese(II), Cobalt(II), Nickel(II), Zinc(II) and Cadmium(II) at Different Temperatures and Ionic Strengths, with Particular Reference to Natural Fluid Conditions

Reference No.: 6135(95BGE)

J. Chem. Soc., Dalton Trans., 1995,, 3353 - 3357; Brucher E; Gyori B; Emri J; Jakab S; Kovacs Z; Solymosi P; Toth I; Complexation Properties of 1,4,10,13-Tetraoxa-7,16-diazacyclo-octadecane-7-malonate, -7,16-bis(Malonate) and -7,16-bis (alpha-Methylacetate)

Reference No.: 6325(88Sad)

Mar. Chem., 1988, 23, 87 - 96; Sadiq M; Thermodynamic Solubility Relationships of Inorganic Vanadium in the Marine Environment

Reference No.: 6330(95LiF)

CRC Handbook of Chemistry and Physics, 76th Edn., 1995 Lide DR; Frederikse HPR; A Ready-Reference Book of Chemical and Physical Data; CRC Press, Cleveland, Ohio, U.S.A.

Reference No.: 6372(87BrW)

OECD NEA Report, 1987 Brown PL; Wanner H; Predicted Formation Constants Using the Unified Theory of Metal Ion Complexation; Nuclear Energy Authority, Paris

Reference No.: 6405(93MoH)

Principles and Applications of Aquatic Chemistry, 1993 Morel FMM; Hering JG; John Wiley & Sons, Inc

Reference No.: 6412(96SSJ)

J. Biol. Inorg. Chem., 1996, 1, 231 - 238; Saha A; Saha N; Ji L-N; Zhao J; Grogan F; Sajadi SAA; Song B; Sigel H; Stability of Metal Ion Complexes Formed with Methyl Phosphate and Hydrogen Phosphate

Reference No.: 6422(95BaP)

Thermochemical Data of Pure Substances, 3rd Edn., 1995 Barin I; Platzki G; Weinheim, Germany

Reference No.: 6478(81BaM)

Am. J. Sci., 1981, 281, 935 - 962; Baes CF Jr; Mesmer RE; The Thermodynamics of Cation Hydrolysis

Reference No.: 6488(88ShH)

Geochim. Cosmochim. Acta, 1988, 52, 2009 - 2036; Shock EL; Helgeson HC; Calculation of the Thermodynamic and Transport Properties of Aqueous Species at High Pressures and Temperatures: Correlation Algorithms for Ionic Species and Equation of State Predictions to 5 kb and 1000 C

Reference No.: 6494(95RoH)

U.S. Geol. Surv. Bull. 2131, 1995 Robie RA; Hemingway BS; Thermodynamic Properties of Minerals and Related Substances at 298.15 K and 1 Bar (10^5 Pascals) Pressure and at Higher Temperatures; U.S. Government Printing Office, Washington, U.S.A

Reference No.: 6495(97SSH)

Geochim. Cosmochim. Acta, 1997, 61, 1359 - 1412; Sverjensky DA; Shock EL; Helgeson HC; Prediction of the Thermodynamic Properties of Aqueous Metal Complexes to 1000C and 5kb

Reference No.: 6496(96StM)

Aquatic Chemistry, 3rd Edn., 1996 Stumm W; Morgan JJ; Chemical Equilibria and Rates in Natural Waters; John Wiley & Sons, Inc., New York

Reference No.: 6508(58CGC)

J. Am. Chem. Soc., 1958, 80, 2121 - 2128; Courtney RC; Gustafson RL; Chaberek S Jr; Martell AE; Hydrolytic Tendencies of Metal Chelate Compounds. II. Effect of Metal Ion

Reference No.: 6510(66CaB)

Inorg. Chem., 1966, 5, 268 - 277; Carlson RH; Brown TL; Infrared and Proton Magnetic Resonance Spectra of Imidazole, alpha-Alanine, and L-Histidine Complexes in Deuterium Oxide Solution

Reference No.: 6535(61SPC)

J. Chem. Soc., 1961,, 5115 - 5120; Sacconi L; Paoletti P; Ciampolini M; Thermochemical Studies. Part VI. Heats and Entropies of Reaction of Transition-metal Ions with Triethylenetetramine

Reference No.: 6538(61CPS)

J. Chem. Soc., 1961,, 2994 - 2999; Ciampolini M; Paoletti P; Sacconi L; Thermochemical Studies. Part IV. Heats and Entropies of Reaction of Transition-metal Ions with Diethylenetriamine

Reference No.: 6618(64SPC)

J. Chem. Soc., 1964,, 5046 - 5051; Sacconi L; Paoletti P; Ciampolini M; Thermochemical Studies. Part XII. Heats and Entropies of Reaction of Transition-metal Ions with NNN'N'-tetra-(2-aminoethyl)- ethylenediamine

Reference No.: 6619(64PaV)

J. Chem. Soc., 1964,, 5051 - 5057; Paoletti P; Vacca A; Thermochemical Studies. Part XIII. Heats and Entropies of Reaction of Tetraethylenepentamine with Protons and Bivalent Transition-metal Ions

Reference No.: 6627(81CVD)

J. Inorg. Nucl. Chem., 1981, 43, 1573 - 1578; Candida M; Vaz TA; da Silva JJRF; Thermodynamic Parameters for the Reactions of Uramildiacetic Acid with Transition Metal Ions

Reference No.: 6631(83LRN)

Anal. Biochem., 1983, 133, 492 - 501; Lance EA; Rhodes CW III; Nakon R; Free Metal Ion Depletion by "Goods" Buffers. III. N-(2-Acetamido)iminodiacetic Acid, 2:1 Complexes with Zinc(II), Cobalt(II), Nickel(II), and Copper(II); Amide Deprotonation by Zn(II), Co(II), and Cu(II)

Reference No.: 6771(70DeN)

Inorg. Chem., 1970, 9, 1259 - 1262; Degischer G; Nancollas GH; Thermodynamics of Iron Association. XXI. Mixed Complexes of Transition Metal Ions with Aminopolycarboxylate and Amine Ligands

Reference No.: 6795(76SOT)

Yakugaku Zasshi, 1976, 96, 242 - 245; Sakurai H; Okumura H; Takeshima S; Stability Constants of Metal Complexes of 2-Aminoethylphosphonic Acid and Its Related Compounds

Reference No.: 6805(52JHL)

J. Phys. Chem., 1952, 56, 16 - 19; Jonassen HB; Hurst GG; LeBlanc RB; Meibohm AW; Inorganic Complex Compounds Containing Polydentate Groups. VI. Formation Constants of Complex Ions of Diethylenetriamine and Triethylenetetramine with Divalent Ions

Reference No.: 6833(67UhK)

J. Inorg. Nucl. Chem., 1967, 29, 1164 - 1168; Uhlig E; Krannich R; Stabilitätsmessungen an Metallchelaten vierzahliger Aminopolycarbonsäuren

Reference No.: 6845(62CoR)

Trans. Faraday Soc., 1962, 58, 2058 - 2065; Coates E; Rigg B; Complex Formation Solochrome Violet R. Part 4 - Some Metal-Dye Stability Constants

Reference No.: 6861(85MoM)

J. Coord. Chem., 1985, 14, 139 - 149; Motekaitis RJ; Martell AE; Metal Chelate Formation by N-Phosphonomethylglycine and Related Ligands

Reference No.: 6868(78MoA)

J. Coord. Chem., 1978, 8, 175 - 182; Mohan MS; Abbott EH; Metal Complexes of Biologically Occurring Aminophosphonic Acids

Reference No.: 6935(75APB)

J. Coord. Chem., 1975, 4, 267 - 275; Anderegg G; Podder NG; Blauenstein P; Hangartner M; Stunzi H; Pyridine Derivatives as Complexing Agents. X. Thermodynamics of Complex Formation of N,N'-Bis(2-pyridylmethyl)-ethylenediamine and of Two Higher Homologues

Reference No.: 6937(81And)

J. Coord. Chem., 1981, 11, 171 - 175; Anderegg G; Pyridine Derivatives as Complexing Agents. XII. Thermodynamics of Complex Formation with 2-Pyridylmethyl-iminodiacetic Acid and its 6-Methyl Substitute

Reference No.: 6938(88NeJ)

J. Coord. Chem., 1988, 19, 265 - 277; Newton JE; Jackels SC; Synthesis and Characterization of the Mn(II) Complex of [15]aneN5

Reference No.: 7000(69FlB)

J. Electroanal. Chem., 1969, 21, 157 - 167; Florence TM; Belew WL; Interpretation of the Polarographic Behaviour of Metal-Solochrome Violet RS Complexes

Reference No.: 7112(52Sch)

Helv. Chim. Acta, 1952, 35, 2344 - 2350; Schwarzenbach G; Der Chelateeffekt

Reference No.: 7168(97GaW)

Chem. Speciation Bioavail., 1997, 91, 37 Gangoda CK; Williams DR; Linear Free Energy Relationships and the Chemical Speciation of Amino-carboxylate Ligand Complexes

Reference No.: 7187(98Che)

Thesis, Murdoch Univ., 1998 Chen T; Solvation of Complexes Ions in Nonaqueous Solvents

Reference No.: 7205(88IOO)

J. Chem. Soc., Faraday Trans. 1, 1988, 84, 2409 - 2419; Ishiguro S-i; Ozutsumi K; Ohtaki H; Calorimetric and Spectrophotometric Studies of Chloro Complexes of Manganese(II) and Cobalt(II) Ions in N,N-Dimethylformamide

Reference No.: 7212(90IsO)

Inorg. Chem., 1990, 29, 1117 - 1123; Ishiguro S-i; Ozutsumi K; Thermodynamics and Structure of Isothiocyanato Complexes of Manganese(II), Cobalt(II), and Nickel(II) Ions in N,N-Dimethylformamide

Reference No.: 7214(90OzI)

J. Chem. Soc., Faraday Trans., 1990, 86, 271 - 275; Ozutsumi K; Ishiguro S-i; Calorimetric and Spectrophotometric Studies of Complexation of Manganese(II), Cobalt(II) and Nickel(II) with Bromide Ions in N,N-Dimethylformamide

Reference No.: 7215(90SIO)

J. Chem. Soc., Faraday Trans., 1990, 86, 2179 - 2185; Suzuki H; Ishiguro S-i; Ohtaki H; Formation of Chloro Complexes of Manganese(II), Cobalt(II), Nickel(II) and Zinc(II) in Dimethyl Sulphoxide

Reference No.: 7222(93SKI)

J. Chem. Soc., Faraday Trans., 1993, 89, 3055 - 3060; Suzuki H; Kolde M; Ishiguro S-i; Sterically Controlled Complexation of Manganese(II) and Cobalt(II) with Chloride Ions in N,N-Dimethylacetamide

Reference No.: 7225(94KSI)

J. Solution Chem., 1994, 23, 1257 - 1269; Koide M; Suzuki H; Ishiguro S-i; Steric Interaction of Solvation and Sterically Enhanced Halogeno Complexation of Manganese(II), Cobalt(II) and Nickel(II) Ions in N,N-Dimethylacetamide

Reference No.: 7239(95KoI)

Z. Naturforsch., 1995, 50a, 11 - 17; Koide M; Ishiguro S-i; Thermodynamics and Structure of Isothiocyanate Complexes of Manganese(II), Cobalt(II) and Zinc(II) Ions in N,N-Dimethylacetamide

Reference No.: 7242(68Tru)

J. Geol. Educ., 1968, 16, 17 - 20; Truesdell AH; The Advantage of Using pE Rather than Eh in Redox Equilibrium Calculations

Reference No.: 7257(97KYI)

J. Solution Chem., 1997, 26, 997 - 1010; Komiya M; Yoshida S; Ishiguro S-i; Binary and Ternary Complexes Involving Manganese(II), 2,2'-Bipyridine and Halide or Thiocyanate Ions in N,N-Dimethylformamide

Reference No.: 7271(98SMM)

NIST Critical Stability Constants of Metal Complexes Database, 1998 Smith RM; Martell AE; Motekaitis RJ; Version 5.0; U.S. Dept. Commerce, Gaithersburg, MD, U.S.A.

Reference No.: 7276(88CoW)

Advanced Inorganic Chemistry, 5th Edn., 1988 Cotton FA; Wilkinson G; John Wiley & Sons Inc., N.Y., U.S.A

Reference No.: 7372(78BDJ)

Vogel's Textbook of Quantitative Inorganic Analysis, 1978 Bassett J; Denney RC; Jeffery GH; Mendham J; including Elementary Instrumental Analysis; Longman, London, U.K.

Reference No.: 7381(97Woo)

Physical Chemistry, 1997 Woodbury G; Brooks/Cole Publishing Co., Pacific Grove, U.S.A.

Reference No.: 7421(97Mar)

Ion Properties, 1997 Marcus Y; Marcel Dekker Inc., New York, U.S.A.

Reference No.: 7694(84IPZ)

Russ. J. Inorg. Chem., 1984, 29, 860 - 862; Ivanov-Emin BN; Petrishcheva LP; Zaitsev BE; Izmailovich AS; Hydroxo-compounds of Copper(II)

Reference No.: 7703(03PLT)

Pure Appl. Chem., 2003, 75, 495 - 540; Portanova R; Lajunen LHJ; Tolazzi M; Piispanen J; Stability Constants for alpha-Hydroxycarboxylic Acid Complexes with Protons and Metal Ions and the Accompanying Enthalpy Changes - Part II: Aliphatic 2-Hydroxycarboxylic Acids

Reference No.: 7731(54EvM)

J. Chem. Soc., 1954,, 550 - 557; Evans WP; Monk CB; Conductivity and Solubility Studies of Some Glycollates and Lactates

Reference No.: 7761(89Bra)

J. Phys. Chem. Ref. Data, 1989, 18, 1 - 21; Bratsch SG; Standard Electrode Potentials and Temperature Coefficients in Water at 298.15 K

Reference No.: 8200(61LeT)

J. Am. Chem. Soc., 1961, 83, 65 - 70; Leussing DL; Tischer TN; Mononuclear and Polynuclear Complex Formation by Manganese(II) and Zinc(II) Ions with 2,3-Dimercapto-1-propanol: The Behavior of the E_r Function with Mercaptide

Reference No.: 8226(58DuR)

J. Am. Chem. Soc., 1958, 80, 4812 - 4817; Durham EJ; Ryskiewich DP; The Acid Dissociation Constants of Diethylenetriaminepentaacetic Acid and the Stability Constants of Some of its Metal Chelates

Reference No.: 8309(99BSH)

J. Chem. Soc., Dalton Trans., 1999,, 3661 - 3671; Blindauer CA; Sjastad TI; Holy A; Sletten E; Sigel H; Aspects of the Co-ordination Chemistry of the Antiviral Nucleotide Analogue, 9-[2-(Phosphonomethoxy)ethyl]-2,6-diaminopurine (PMEDAP)

Reference No.: 8371(74BrE)

J. Solution Chem., 1974, 3, 757 - 769; Broadwater TL; Evans DF; The Conductance of Divalent Ions in H₂O at 10 and 25 C and in D₂O

Reference No.: 8378(73RuT)

Collect. Czech. Chem. Commun., 1973, 38, 1008 - 1011; Ruzinsky M; Treindl L; An Electron Paramagnetic Resonance Study of the Association of Manganese(II) with Sulphate Ions

Reference No.: 8380(59NaN)

J. Chem. Soc., 1959,, 3934 - 3939; Nair VSK; Nancollas GH; Thermodynamics of Ion Association. Part VI. Some Transition-metal Sulphates

Reference No.: 8396(65Pot)

Ber. Bunsengesellschaft, 1965, 69, 363 - 446; Pottel Von R; Die Komplexe Dielektrizitätskonstante Wabriger Lösungen Einiger 2-2-wertiger Elektrolyte im Frequenzbereich 0,1 bis 38 GHz

Reference No.: 8402(69IEC)

J. Chem. Soc. (A), 1969,, 47 - 53; Izatt RM; Eatough DJ; Christensen JJ; Bartholomew CH; Calorimetrically Determined Log K, ΔH , and ΔS Values for the Interaction of Sulphate Ion with Several Bi- and Ter-valent Metal Ions

Reference No.: 8619(65FiD)

J. Phys. Chem., 1965, 69, 2595 - 2598; Fisher FH; Davis DF; The Effect of Pressure on the Dissociation of Manganese Sulfate

Reference No.: 8634(58KoV)

J. Chem. Phys., 1958, 29, 9 - 14; Kor SK; Verma GS; Ultrasonic Absorption in MnSO₄ Solutions

Reference No.: 8670(32MoD)

Trans. Faraday Soc., 1932, 28, 609 - 614; Money RW; Davies CW; The Extent of Dissociation of Salts in Water. Part IV. Bi-Bivalent Salts

Reference No.: 8675(72Pit)

J. Chem. Soc., Faraday Trans. 2, 1972, 68, 101 - 113; Pitzer KS; Thermodynamic Properties of Aqueous Solutions of Bivalent Sulphates

Reference No.: 8875(81HKF)

Am. J. Sci., 1981, 281, 1249 - 1516; Helgeson HC; Kirkham DH; Flowers GC; Theoretical Prediction of the Thermodynamic Behavior of Aqueous Electrolytes at High Pressures and Temperatures. IV. Calculation of Activity Coefficients, Osmotic Coefficients and Apparent Molal and Standard and Relative Partial Molal Properties to 600 C and 5 Kb

Reference No.: 8888(93ShK)

Geochim. Cosmochim. Acta, 1993, 57, 4899 - 4922; Shock EL; Koretsky CM; Metal-organic Complexes in Geochemical Processes: Calculation of Standard Partial Molal Thermodynamic Properties of Aqueous Acetate Complexes at High Pressures and Temperatures

Reference No.: 9029(97SSW)

Geochim. Cosmochim. Acta, 1997, 61, 907 - 950; Shock EL; Sassani DC; Willis M; Sverjensky DA; Inorganic Species in Geologic Fluids: Correlations among Standard Molal Thermodynamic Properties of Aqueous Ions and Hydroxide Complexes

Reference No.: 9040(96WoK)

Geochim. Cosmochim. Acta, 1996, 60, 3983 - 3994; Wolfram O; Krupp RE; Hydrothermal Solubility of Rhodochrosite, Mn(II) Speciation, and Equilibrium Constants

Reference No.: 9311(99AnA)

J. Chem. Eng. Data, 1999, 44, 1151 - 1157; Anwar ZM; Azab HA; Ternary Complexes in Solution. Comparison of the Coordination Tendency of Some Biologically Important Zwitterionic Buffers toward the Binary Complexes of Some Transition Metal Ions and Some Amino Acids

Reference No.: 9402(86Wan)

EIR-Bericht Nr. 589, 1986 Wanner H; Modelling Interaction of Deep Groundwaters with Bentonite and Radionuclide Speciation; Swiss Federal Institute for Reactor Research, Wurenlingen, Suisse

Reference No.: 10174(95OHS)

J. Phys. Chem. Ref. Data, 1995, 24, 1401 - 1560; Oelkers EH; Helgeson HC; Shock EL; Sverjensky DA; Johnson JW; Pokrovskii VA; Summary of the Apparent Standard Partial Molal Gibbs Free Energies of Formation of Aqueous Species, Minerals, and Gases at Pressures 1 to 5000 Bars and Temperatures 25 to 1000C

Reference No.: 11516(00PeP)

IUPAC Stability Constants Database, 2000 Pettit LD; Powell HKJ; Release 4; Academic Software, U.K.

Reference No.: 11767(93Jan)

J. Chromatogr., 1993, 657, 435 - 439; Janos P; Study of Complex-forming Equilibria between Divalent Metal Cations and Some Inorganic Anions using Ion Chromatography

Reference No.: 11814(76Ash)

Natl. Inst. Metall., Rep. 1820, 1976 Ashurst KG; The Thermodynamics of the Formation of Chlorocomplexes of Iron(III), Cobalt(II), Iron(II), Manganese(II), and Copper(II) in Perchlorate Medium; 44

Reference No.: 12002(59RoS)

Electrolyte Solutions, 2nd Rev. Edn., 1959 Robinson RA; Stokes RH; An Unabridged Re-publication of the Fifth Impression of the Second Revised Edition of the Work Originally Published in 1970 with New Preface Specially Prepared by Dr. Stokes; Dover Publications, N.Y., USA (previously Butterworth & Co., London)

Reference No.: 12547(98SBB)

J. Phys. Chem., 1998, B102, 4411 - 4417; Simonin J-P; Bernard O; Blum L; Real Ionic Solutions in the Mean Spherical Approximation. 3. Osmotic and Activity Coefficients for Associating Electrolytes in the Primitive Model

Reference No.: 12584(00KKH)

Aquat. Geochem., 2000, 6, 147 - 199; Kulik DA; Kersten M; Heiser U; Neumann T; Application of Gibbs Energy Minimization to Model Early-Diagenetic Solid-Solution Aqueous-Solution Equilibria Involving Authigenic Rhodochrosites in Anoxic Baltic Sea Sediments

Reference No.: 12632(82GEE)

Wiss. Z. Wilhelm-Pieck-Univ. Rostock, Naturwiss. Reihe, 1982, 31, 15 - 24; Grigo M; Einfeldt J; Ebeling W; Ion Association of Electrolytic Solutions

Reference No.: 12638(99TPG)

GAMSPATH Users Manual, 1999 Talman SJ; Perkins EH; Gunter WD; A Reaction Path - Mass Transfer Program

Reference No.: 12709(61MoS)

J. Chem. Soc., 1961,, 5148 - 5153; Morris DFC; Short EL; Manganese(II) Chloride Complexes. Part I. Stability Constants

Reference No.: 12931(01SPG)

Chem. Geol., 2001, 171, 173 - 194; Seby F; Potin-Gautier M; Giffaut E; Borge G; Donard OFX; A Critical Review of Thermodynamic Data for Selenium Species at 25C

Reference No.: 13040(71DDS)

Thermochim. Acta, 1971, 2, 435 - 442; Das RC; Dash AC; Satyanarayan D; Dash UN; Studies on Ion Association: Thermodynamics of Thiocyanate Complexes of Some Bivalent Metal Ions

Reference No.: 13105(70BCV)

Bull. Soc. Chim. Fr., 1970,, 4166 Besse G; Chabard JL; Voissiere G; Petit J; Berger JA; Stability of Complexes Studied by Thin-layer Electrophoresis II. Citrate Complexes

Reference No.: 13109(61McN)

J. Chem. Soc., 1961,, 2215 - 2221; McAuley A; Nancollas GH; Thermodynamics of Ion Association. Part VII. Some Transition Metal Oxalates

Reference No.: 13213(61Mac)

The Principles of Electrochemistry, 1961 MacInnes DA; Dover Publications, New York

Reference No.: 13242(05AAD)

Pure Appl. Chem., 2005, 77, 1445 - 1495; Anderegg G; Arnaud-Neu F; Delgado R; Felcman J; Popov K; Critical Evaluation of Stability Constants of Metal Complexes of Complexones for Biomedical and Environmental Applications

Reference No.: 13488(53Alb)

Biochem. J., 1953, 54, 646 - 654; Albert A; Quantitative Studies on the Avidity of Naturally Occurring Substances for Trace Metals

Reference No.: 16058(00KhA)

J. Chem. Eng. Data, 2000, 45, 1108 - 1111; Khalil MM; Attia AE; Potentiometric Studies on the Formation Equilibria of Binary and Ternary Complexes of Some Metal Ions with Dipicolinic Acid and Amino Acids

Reference No.: 16946(96LRT)

Environ. Sci. Technol., 1996, 30, 671 - 679; Luther GW III; Rickard DT; Theberge S; Olroyd A; Determination of Metal (Bi)Sulfide Stability Constants of Mn+2, Fe+2, Co+2, Ni+2, Cu+2, and Zn+2 by Voltammetric Methods

Reference No.: 16981(11OrB)

Russ. J. Inorg. Chem., 2011, 56, 975 - 980; Orlov YF; Belkina EI; Correlations between the Stability Constants of Metal Hydroxo Complexes and the Solubility Products of Crystalline Hydroxides. Series of the Polarizing Effect of Metal Cations

Reference No.: 17327(03LuM)

J. Solution Chem., 2003, 32, 405 - 416; Luo Y; Millero FJ; Solubility of Rhodochrosite (MnCO3) in NaCl Solutions

Reference No.: 17895(85ADO)

Transition Met. Chem., 1985, 10, 11 - 14; Amico P; Daniele PG; Ostacoli G; Arena G; Rizzarelli E; Sammartano S; Mixed Metal Complexes in Solution. Part 4. Formation and Stability of Heterobinuclear Complexes of Cadmium(II)-Citrate with some Bivalent Metal Ions in Aqueous Solution

Reference No.: 17919(99WWW)

Chem. Speciation Bioavail., 1999, 11, 85 - 93; Whitburn JS; Wilkinson SD; Williams DR; Chemical Speciation of Ethylenediamine-N,N'-disuccinic Acid (EDDS) and its Metal Complexes in Solution

Reference No.: 18118(52Con)

Electrochemical Data, 1952 Conway BE; Greenwood Press, Westport, Conn., U.S.A.

Reference No.: 18273(57Dav)

Discuss. Faraday Soc., 1957, 24, 83 - 86; Davies CW; Incomplete Dissociation. Introductory Paper

Reference No.: 18471(51Mon)

Trans. Faraday Soc., 1951, 47, 285 - 291; Monk CB; Electrolytes in Solutions of Amino Acids. Part II. The Cupric Complexes of Glycine, Alanine and Glycyl-Glycine

Reference No.: 20758(01CRL)

Electroanalysis, 2001, 13, 21 - 29; Chadwell SJ; Rickard D; Luther GW III; Electrochemical Evidence for Metal Polysulfide Complexes: Tetrasulfide (S₄-2) Reactions with Mn²⁺, Fe²⁺, Co²⁺, Ni²⁺, Cu²⁺, and Zn²⁺

Reference No.: 22388(09Ber)

Private Communication, 2009 Berthon G; Toulouse Blood Plasma Database

Reference No.: 22551(06Inz)

Encyclopedia of Electrochemistry, Vol. 7a, 2006, 17 - 75; Inzelt G; Standard, Formal and Other Characteristic Potentials of Selected Electrode Reactions

Reference No.: 22560(05PeP)

IUPAC Stability Constants Database, 2005 Pettit LD; Powell HKJ; Release 4.71; Academic Software, U.K.

Reference No.: 22834(07PDB)

Geochim. Cosmochim. Acta, 2007, 71, 5661 - 5671; Pena J; Duckworth OW; Bargar JR; Sposito G; Dissolution of Hausmannite (Mn₃O₄) in the Presence of the Trihydroxamate Siderophore Desferrioxamine B

Reference No.: 22958(10AML)

Appl. Geochem., 2010, 25, 242 - 260; Accornero M; Marini L; Lelli M; Prediction of the Thermodynamic Properties of Metal-chromate Aqueous Complexes to High Temperatures and Pressures and Implications for the Speciation of Hexavalent Chromium in Some Natural Waters

Reference No.: 22971(71HWH)

Chem. Rev., 1971, 71, 127 - 137; Hill JO; Worsley IG; Hepler LG; Thermochemistry and Oxidation Potentials of Vanadium, Niobium and Tantalum

Reference No.: 23134(10TPD)

J. Solution Chem., 2010, 39, 1 - 10; Torres J; Pintos V; Dominguez S; Kremer C; Kremer E; Selenite and Selenate Speciation in Natural Waters: Interaction with Divalent Metal Ions

Reference No.: 23272(07QaF)

J. Solution Chem., 2007, 36, 81 - 95; Qafoku O; Felmy AR; Development of Accurate Chemical Equilibrium Models for Oxalate Species to High Ionic Strength in the System: Na-Ba-Ca-Mn-Sr-Cl-NO₃-PO₄-SO₄-H₂O at 25 C

Reference No.: 24493(12JoN)

Inorg. Chem., 2012, 51, 6116 - 6128; Johnson DA; Nelson PG; Improvements in Estimated Entropies and Related Thermodynamic Data for Aqueous Metal Ions

Reference No.: 24993(99Gra)

PSI Bericht Nr. 99-04, 1999 Grauer R; Solubility Products of M(II)-Carbonates; Waste Management Laboratory, Paul Scherrer Inst., Switzerland

Reference No.: 28172(15DCC)

J. Chem. Eng. Data, 2015, 60, 3792 - 3799; Djamali E; Chapman WG; Cox KR; Prediction of the Standard State Partial Molar Volume of Aqueous Electrolytes to High Temperatures and High Pressures

Reference No.: 28992(71NRK)

Handbook of Thermodynamic Data, 1971 Naumov GB; Ryzhenko BN; Khodakovskiy IL; Translated by G.J. Soleimani and edited by I. Barnes & V. Speltz (U.S. Geological Survey); U.S. National Technical Information Service, Springfield VA

Reference No.: 29025(14ThL)

Desalination, 2014, 346, 54 - 69; Thiel GP; Lienhard JH V; Treating Produced Water from Hydraulic Fracturing: Composition Effects on Scale Formation and Desalination System Selection

Reference No.: 29419(16JeJ)

Environ. Earth Sci., 2016, 75, 1333-1 - 1333-14; Jeong HY; Jeon S-W; Geochemical Interactions of Mine Seepage Water with an Aquifer: Laboratory Tests and Reactive Transport Modeling

Reference No.: 29482(16ZZL)

Comput. Geosci., 2016, 90, 97 - 111; Zimmer K; Zhang Y; Lu P; Chen Y; Zhang G; Dalkilic M; Zhu C; SUPCRTBL: A Revised and Extended Thermodynamic Dataset and Software Package of SUPCRT92

Reference No.: 29487(09CDF)

Geochim. Cosmochim. Acta, 2009, 73, 2283 - 2298; Curti E; Dahn R; Farges F; Vespa M; Na, Mg, Ni and Cs Distribution and Speciation after Long-term Alteration of a Simulated Nuclear Waste Glass: A Micro-XAS/XRF/XRD and Wet Chemical Study

Reference No.: 29489(87POG)

Report PNL-6112 UC-70, 1987 Peterson SR; Opitz BE; Graham MJ; Eary LE; An Overview of the Geochemical Code MINTEQA: Applications to Performance Assessment for Low-Level Wastes; Battelle Mem. Inst., Pacific Northwest Lab., Dept. Energy, USA

Reference No.: 29666(12YLL)

J. Appl. Solution Chem. Model., 2012, 1, 46 - HBED; Yunta F; Lopez-Rayos S; Lucena JJ; Thermodynamic Database Update to Model Synthetic Chelating Agents in Soil Systems

Reference No.: 29969(17TSF)

J. Solution Chem., 2017, 46, 2231 - 2247; Torres J; Santos P; Ferrari C; Kremer C; Kremer E; Solution Chemistry of Arsenic Anions in the Presence of Metal Cations

Reference No.: 31154(58Wal)

Acta Chem. Scand., 1958, 12, 528 - 536; Walaas E; Stability Constants of Metal Complexes with Mononucleotides

Reference No.: 31291(84PSG)

U.S. Bur. Mines Bull. 677, 1984 Pankratz LB; Stuve JM; Gokcen NA; Thermodynamic Data for Mineral Technology; US Det. Interior, Bur. Mines, Washington, DC, USA

Reference No.: 32152(20AAG)

Chem. Geol., 2020, 550, 119699-1 - 119699-12; Aranovich LYa; Akinfiev NN; Golunova M; Quartz Solubility in Sodium Carbonate Solutions at High Pressure and Temperature

Reference No.: 32204(64CoP)

Proc. Iowa Acad. Sci., 1964, 71, 145 - 150; Cole JJ; Pflaum RT; The Solubility and Thermal Decomposition Characteristics of Some Tetraphenylarsonium Compounds

Reference No.: 32213(51HaM)

J. Am. Chem. Soc., 1951, 73, 4853 - 4855; Hayes AM; Martin DS Jr; The Solubility, Activity Coefficients and Solubility Product of Manganese(II) Iodate

Reference No.: 32222(06DGC)

Technical Report TR-O6-17, 2006 Duro L; Grive M; Cera E; Domenech C; Bruno J; Update of a Thermodynamic Database for Radionuclides to Assist Solubility Limits Calculation for Performance Assessment; Swedish Nucl. Fuel & Waste Management Co, Stockholm, Sweden

Reference No.: 32224(80BeT)

Lawrence Berkeley Laboratory Report LBL-11448, 1980 Benson LV; Teague LS; A Tabulation of Thermodynamic Data for Chemical Reactions Involving 8 Elements Common to Radioactive Waste Package Systems