

JESS Thermodynamic Database v8.9

Palladium

24-Jan-23

Reaction No. 1356							
1.5<Cl ₂ (g)> + Pd(s) + e-1 = Pd+2_Cl-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-69.80 (4SF)	3	CRV	10174
2	50	0	Inf. Dilution	dG:-69.79 (4SF)	2	CRV	10174
3	75	0	Inf. Dilution	dG:-69.91 (4SF)	2	CRV	10174
4	100	0	Inf. Dilution	dG:-70.13 (4SF)	1	CRV	10174
5	125	0	Inf. Dilution	dG:-70.43 (4SF)	1	CRV	10174
6	150	0	Inf. Dilution	dG:-70.80 (4SF)	1	CRV	10174
7	175	0	Inf. Dilution	dG:-71.21 (4SF)	0	CRV	10174
8	200	0	Inf. Dilution	dG:-71.66 (4SF)	0	CRV	10174
9	225	0	Inf. Dilution	dG:-72.13 (4SF)	0	CRV	10174
10	250	0	Inf. Dilution	dG:-72.58 (4SF)	0	CRV	10174
11	300	0	Inf. Dilution	dG:-73.28 (4SF)	0	CRV	10174

Reaction No. 1357							
Cl ₂ (g) + Pd(s) = Pd+2_Cl-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-35.20 (4SF)	3	CRV	10174
2	50	0	Inf. Dilution	dG:-35.27 (4SF)	2	CRV	10174
3	75	0	Inf. Dilution	dG:-35.44 (4SF)	2	CRV	10174
4	100	0	Inf. Dilution	dG:-35.69 (4SF)	1	CRV	10174
5	125	0	Inf. Dilution	dG:-36.03 (4SF)	1	CRV	10174
Note (5): 6							
6	150	0	Inf. Dilution	dG:-36.43 (4SF)	1	CRV	10174
7	175	0	Inf. Dilution	dG:-36.90 (4SF)	0	CRV	10174
8	200	0	Inf. Dilution	dG:-37.44 (4SF)	0	CRV	10174
9	225	0	Inf. Dilution	dG:-38.04 (4SF)	0	CRV	10174
10	250	0	Inf. Dilution	dG:-38.71 (4SF)	0	CRV	10174
11	300	0	Inf. Dilution	dG:-40.24 (4SF)	0	CRV	10174

Reaction No. 1358							
-------------------	--	--	--	--	--	--	--

0.5<Cl ₂ (g)> + Pd(s) - e-1 = Pd+2_Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.1 (2SF)	1	ELC	
2	25	0	Inf. Dilution	dG:22.6 (3SF) kJ	0	CRV	3006
3	25	0	Inf. Dilution	dG:2.50 (3SF)	0	CRV	10174
4	50	0	Inf. Dilution	dG:2.64 (3SF)	0	CRV	10174
5	75	0	Inf. Dilution	dG:2.74 (3SF)	0	CRV	10174
6	100	0	Inf. Dilution	dG:2.79 (3SF)	0	CRV	10174
7	125	0	Inf. Dilution	dG:2.81 (3SF)	0	CRV	10174
8	150	0	Inf. Dilution	dG:2.80 (3SF)	0	CRV	10174
9	175	0	Inf. Dilution	dG:2.77 (3SF)	0	CRV	10174
10	200	0	Inf. Dilution	dG:2.72 (3SF)	0	CRV	10174
11	225	0	Inf. Dilution	dG:2.66 (3SF)	0	CRV	10174
12	250	0	Inf. Dilution	dG:2.59 (3SF)	0	CRV	10174
13	300	0	Inf. Dilution	dG:2.47 (3SF)	0	CRV	10174
14	25	0	Inf. Dilution	dH:-38. (2SF) kJ	3	CRV	3006

Reaction No. 3128							
NTA-3 + Pd+2 = Pd+2_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO ₄	lgK:17.1 (3SF)	3	MMX	1562
2	25	0	Inf. Dilution	lgK:17.5 (3SF)	1	EES	
3	25	1	Unknown	lgK:19.30 (4SF)	0	ENS	773

Reaction No. 3129							
Pd+2_NTA-3 + H+1 = Pd+2_H+1_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	Unknown	lgK:7.82 (3SF)	3	CRV	552
2	20	1	Unknown	lgK:0.500 (3SF)	0	ENS	773
3	25	0	Inf. Dilution	lgK:8.2 (2SF)	1	EES	

Reaction No. 3285							
Pd+2_Dien(2) + H+1 = Pd+2_H+1_Dien(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaBr	lgK:9.92 (3SF)	4	MGL	3842
2	25	1	NaClO ₄	lgK:9.92 (3SF)	4	MGL	3842
3	25	1	Unknown	lgK:6.10 (3SF)	0	ENS	773

Reaction No. 3286							
Pd+2_H+1_Dien(2) + H+1 = Pd+2_H+1(2)_Dien(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Unknown	lgK:2.5 (2SF)	4	ENS	773

Reaction No. 4222							
Pd+2_EDTA-4 + H+1 = Pd+2_H+1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:3.1 (2SF)	4	MGL	903
2	20	1	NaClO4	lgK:3.0 (0.05SD)	5	MSP	1562
3	25	0	Inf. Dilution	lgK:3.5 (2SF)	1	EES	

Reaction No. 4223							
Pd+2_H+1_EDTA-4 + H+1 = Pd+2_H+1(2)_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:2.18 (3SF)	6	CRV	552
2	20	1	NaClO4	lgK:2.3 (0.05SD)	5	MSP	1562
3	25	0	Inf. Dilution	lgK:2.5 (2SF)	1	EES	

Reaction No. 4283							
Pd+2_DTPA-5 + H+1 = Pd+2_H+1_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:3.49 (3SF)	6	MGL	1562
2	20	1	NaClO4	lgK:3.49 (0.05SD)	5	CRV	13242
3	20	1	Unknown	lgK:3.67 (3SF)	6	ENS	773
4	25	0	Inf. Dilution	lgK:3.7 (2SF)	1	ESC	

Reaction No. 4494							
4<Thiourea> + Pd+2 = Pd+2_Thiourea(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.5	HCl	lgK:29.4 (3SF)	3	MIS	842
2	10	1	HCl	lgK:31.4 (3SF)	3	MIS	842
3	20	0.5	HCl	lgK:30.0 (3SF)	3	MIS	842
4	20	1	HCl	lgK:31.9 (3SF)	3	MIS	842
5	25	0.5	HCl	lgK:30.1 (3SF)	3	MIS	842
6	25	1	HCl	lgK:31.9 (3SF)	3	MIS	842

7	30	0.5	HCl	lgK:30.2 (3SF)	3	MIS	842
8	30	1	HCl	lgK:31.9 (3SF)	3	MIS	842
9	40	0.5	HCl	lgK:30.3 (3SF)	3	MIS	842
10	40	1	HCl	lgK:31.9 (3SF)	3	MIS	842
11	50	0.5	HCl	lgK:30.5 (3SF)	3	MIS	842
12	50	1	HCl	lgK:31.9 (3SF)	3	MIS	842
13	60	0.5	HCl	lgK:30.4 (3SF)	3	MIS	842
14	60	1	HCl	lgK:32.0 (3SF)	3	MIS	842

Reaction No. 4520							
Pd+2 + 2<H+1_DiMeGlyox-2> = Pd+2_H+1(2)_DiMeGlyox-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:34.1 (3SF)	4	ENS	773
2	25	1	NaClO4	lgK:34.1 (3SF)	4	MDS	999

Reaction No. 4521							
Pd+2_H+1(2)_DiMeGlyox-2(2) + OH-1 = Pd+2_H+1(2)_OH-1_DiMeGlyox-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:5.50 (3SF)	6	ENS	773
2	25	1	NaClO4	lgK:5.50 (3SF)	6	MDS	999
3	25	1	Unknown	lgK:5.6 (2SF)	4	ENS	773

Reaction No. 4575							
Acac-1 + Pd+2 = Pd+2_Acac-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:16.7 (0.2SD)	4	MSP	834
2	25	0	Unknown	lgK:16.4 (3SF)	4	ENS	773
3	30	0	Inf. Dilution	lgK:16.2 (3SF)	4	MPS	834
4	40	0	Inf. Dilution	lgK:15.4 (3SF)	4	MPS	834
5	20:40	0	Inf. Dilution	dH:-18. (0.2SD)	4	MTD	834

Reaction No. 4576							
2<Acac-1> + Pd+2 = Pd+2_Acac-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:28.00 (4SF)	6	ENS	1539
2	25	0	Unknown	lgK:27.5 (3SF)	4	ENS	773

Reaction No. 4936							
Pd+2_IDA-2 + H+1 = Pd+2_H+1_IDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	Unknown	lgK:0.75 (2SF)	6	ENS	773
2	25	0	Inf. Dilution	lgK:1. (1SF)	1	EES	

Reaction No. 5016							
Pd+2_Cl-1 + Cl-1 = Pd+2_Cl-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.8	Unknown	lgK:3.54 (3SF)	5	ENS	8933
2	21	0	Inf. Dilution	lgK:4.7 (0.1SD)	4	MSP	834
3	23			lgK:3.0 (2SF)	0	MEF	5398
4	25	0	Inf. Dilution	lgK:4.6 (2SF)	4	MSP	140
5	25	0	Inf. Dilution	lgK:4.6 (0.05SD)	3	CMN	835
6	25	0.86	HClO4	lgK:3.24 (3SF)	5	ENS	8931
7	25	1	HClO4	lgK:3.29 (3SF)	5	ENS	832
8	25	1	HClO4	lgK:3.06 (3SF)	5	MSC	931
9	25	1	HClO4	lgK:3.29 (0.18SD)	6	CRV	4282
10	25	1	HClO4	lgK:3.03 (3SF)	3	EOD	4282
11	25	1	HClO4	lgK:3.34 (3SF)	3	EOD	4282
Note (11): Data from Weed, 1964							
12	25	1	NaClO4	lgK:3.45 (3SF)	5	MSP	931
13	25	1	NaClO4	lgK:3.2 (0.2SD)	5	CMN	5344
14	29.5	0	Inf. Dilution	lgK:4.5 (2SF)	4	MSP	834
15	38	0	Inf. Dilution	lgK:4.1 (2SF)	4	MSP	834
16	21:38	0	Inf. Dilution	dH:-9. (0.1SD)	4	MTD	834
17	21:38	0	Inf. Dilution	dH:-9.0 (0.1SD)	3	MSP	5462
18	25	1	NaClO4	dH:-2.6 (0.1SD)	3	MCL	832

Reaction No. 5027							
Pd+2 + 2<e-1> = Pd(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	4	HClO4	lgK:34.8 (0.05SD)	5	MEF	828
2	15	4	HClO4	lgK:34.2 (0.05SD)	5	MEF	828
3	20	4	HClO4	lgK:33.5 (0.05SD)	5	MEF	828
4	25	0	Inf. Dilution	lgK:33.4 (3SF)	0	MIS	22560

Note (4): Fasman et al., Zh. Neorg. Khim., 1965, 10, 1338							
5	25	0	Inf. Dilution	lgK:33.03(0.54SD)	0	CRV	32222
6	25	0	Inf. Dilution	lgK:30.94(4SF)	4	CRV	32224
7	25	1	KCl	lgK:33.4(3SF)	0	MIS	842
8	25	1.06	HClO4	lgK:31.1(0.05SD)	2	MEF	829
9	25	2.22	HClO4	lgK:31.3(0.05SD)	2	MEF	829
10	25	3.46	HClO4	lgK:32.2(0.05SD)	0	MEF	829
11	25	4	HClO4	lgK:33.1(0.05SD)	3	MEF	828
12	25	4.87	HClO4	lgK:33.7(0.05SD)	3	MEF	829
13	30	4	HClO4	lgK:32.5(0.05SD)	5	MEF	828
14	35	4	HClO4	lgK:31.8(0.05SD)	2	MEF	828
15	40	4	HClO4	lgK:30.9(0.05SD)	0	MEF	828
16	25	0	Inf. Dilution	dG:-42.2(0.1SD)	3	ENS	802
17	25	0	Inf. Dilution	dG:-176.5(4SF) kJ	5	CRV	3006
18	25	0	Inf. Dilution	dG:-42.20(4SF)	3	CRV	6488
19	25	0	Inf. Dilution	dG:-176.5(4SF) kJ	5	CRV	7421
20	25	0	Inf. Dilution	dG:-42.20(4SF)	4	CRV	10174
21	50	0	Inf. Dilution	dG:-42.77(4SF)	4	CRV	10174
22	75	0	Inf. Dilution	dG:-43.35(4SF)	3	CRV	10174
23	100	0	Inf. Dilution	dG:-43.93(4SF)	3	CRV	10174
24	125	0	Inf. Dilution	dG:-44.53(4SF)	3	CRV	10174
25	150	0	Inf. Dilution	dG:-45.14(4SF)	3	CRV	10174
26	175	0	Inf. Dilution	dG:-45.77(4SF)	3	CRV	10174
27	200	0	Inf. Dilution	dG:-46.42(4SF)	3	CRV	10174
28	225	0	Inf. Dilution	dG:-47.11(4SF)	0	CRV	10174
29	250	0	Inf. Dilution	dG:-47.84(4SF)	0	CRV	10174
30	300	0	Inf. Dilution	dG:-49.48(4SF)	0	CRV	10174
31	25	0	Inf. Dilution	E:0.9(0.05SD)	0	MEF	775
32	25	0	Inf. Dilution	E:0.915(0.005SD)	5	CRV	3006
33	25	0	Inf. Dilution	E:0.951(3SF)	0	CRV	6330
34	25	0	Inf. Dilution	E:0.987(3SF)	0	CRV	7372
35	25	0	Inf. Dilution	E:0.915(0.005SD)	4	CRV	22551
36	25	0	Inf. Dilution	dH:-149.0(4SF) kJ	0	CRV	3006
37	25	0	Inf. Dilution	dH:-42.08(4SF)	3	CRV	6488
38	25	0	Inf. Dilution	dH:-187.880(3.097SD) kJ	2	CRV	32222

Reaction No. 5028							
$\text{Pd}+2\text{Cl-1(4)} + 2\text{e-1} = \text{Pd(s)} + 4\text{Cl-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.2(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:20.0(0.05SD)	0	ENS	802
3	15	1	HCl	lgR:21.8(0.05SD)	5	MEF	830
4	25	1	HCl	lgR:21.0(0.05SD)	5	MEF	830
5	35	1	HCl	lgR:20.3(0.05SD)	5	MEF	830
6	25	0	Inf. Dilution	E:0.591(3SF)	0	CRV	6330
7	25	1	HCl	E:0.59(2SF)	0	EOD	3006
Note (7): p. 343							
8	25	1	HCl	E:0.62(2SF)	4	CRV	22551
9	25	1	KCl	E:0.60(2SF)	0	EOD	3006
Note (9): p. 343							

Reaction No. 5029							
$\text{Pd}+2 + \text{OH-1} = \text{Pd}+2_{\text{OH-1}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	17	0.1	HClO4	lgK:11.7(0.05SD)	0	MSL	5398
2	25	0	Inf. Dilution	lgK:13.0(0.4SD)	4	MGL	831
3	25	0	Inf. Dilution	lgK:12.4(0.6SD)	0	MPS	831
4	25	0	Inf. Dilution	lgK:13.1(3SF)	3	EOD	16981
5	25	0.1	Unknown	lgK:12.4(0.1SD)	3	CSM	8

Reaction No. 5030							
$\text{Pd}+2 + 2\text{OH-1} = \text{Pd}+2_{\text{OH-1(2)}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:25.8(0.4SD)	3	MGL	831
2	25	0	Inf. Dilution	lgK:26.5(0.7SD)	3	MPS	831
3	25	0	Inf. Dilution	lgK:25.8(3SF)	3	EOD	16981
4	25	0.1	Unknown	lgK:25.2(0.05SD)	6	CSM	8

Reaction No. 5031							
$\text{Pd}+2 + 2\text{H}_2\text{O} = \text{Pd}+2_{\text{OH-1(2)}}(\text{s}) + 2\text{H}+1$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	17	0.1	NaClO4	lgK:0.6(0.1SD)	0	ENS	4998
2	25	0	Inf. Dilution	lgK:0.7(1SF)	1	ELC	

3	25	0	Inf. Dilution	lgK:4.70 (3SF)	0	EBU	6372
Note (3): Low wgt for internal consistency & suspect other values							
4	25	0	Inf. Dilution	lgK:0.8 (0.1SD)	0	CRV	6478
Note (4): Solid phase given in source as Pd(OH)3 but seems to be a typo							
5	25	0	Inf. Dilution	lgK:4.040 (0.15SD)	0	CRV	31301
6	25	0	Inf. Dilution	lgK:1.61 (3SF)	0	CRV	32222
7	25	0	Inf. Dilution	lgK:14.51 (4SF)	0	CRV	32224
8	25	0	Inf. Dilution	dH:-13.223 (3.099SD) kJ	2	CRV	32222


Reaction No. 5032							
3<OH-1> + Pd+2 = Pd+2_OH-1 (3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	17	0.1	HClO4	lgK:1.9 (0.05SD)	0	ENS	827
Note (1): Probably the step-wise constant							
2	25	0	Inf. Dilution	lgK:26.4 (3SF)	1	ELC	

Reaction No. 5033							
4<OH-1> + Pd+2 = Pd+2_OH-1 (4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	17	0.1	HClO4	lgK:1.0 (0.05SD)	0	ENS	827
Note (1): Low wgt for internal consistency							
2	25	0.5:1	HClO4	lgK:26.4 (3SF)	4	ENS	4282

Reaction No. 5034							
Cl-1 + Pd+2 = Pd+2_Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	HClO4	lgK:5.1 (2SF)	0	MSL	931
2	20	0.8	HClO4	lgK:4.34 (3SF)	5	ENS	8933
3	21	0	Inf. Dilution	lgK:6.2 (0.1SD)	4	MSP	834
4	23			lgK:4.7 (2SF)	0	MEF	5398
5	25	0	Inf. Dilution	lgK:6.1 (0.05SD)	4	MSP	5462
6	25	0	Inf. Dilution	lgK:5.00 (3SF)	2	EBU	6372
7	25	0	Inf. Dilution	lgK:6.0 (0.2SD)	4	MSP	8931
8	25	0	Inf. Dilution	lgK:5.031 (0.10SD)	2	CRV	31301
9	25	0	Inf. Dilution	lgK:6.10 (3SF)	4	CRV	32224
10	25	0.1	NaClO4	lgK:5.1 (0.1SD)	0	MSL	5398
11	25	0.86	HClO4	lgK:3.98 (3SF)	0	ENS	8931

12	25	1	HClO4	lgK:4.47 (3SF)	2	ENS	832
13	25	1	HClO4	lgK:4.21 (0.27SD)	6	CRV	4282
14	25	1	HClO4	lgK:4.4 (2SF)	3	EOD	4282
Note (14): Data from Weed, 1964							
15	25	1	HClO4	lgK:4.2 (0.2SD)	5	CMN	5344
16	25	1	HClO4	lgK:3.88 (3SF)	2	MSL	8932
17	25	1	NaClO4	lgK:4.00 (3SF)	5	MSP	931
18	25	1	NaClO4	lgK:3.5 (0.05SD)	0	MSP	5398
19	25	1	Unknown	lgK:4.47 (3SF)	4	ENS	6496
20	25			lgK:4.00 (3SF)	0	MSP	931
21	29.5	0	Inf. Dilution	lgK:6.0 (2SF)	4	MSP	834
22	38	0	Inf. Dilution	lgK:5.9 (0.05SD)	4	MSP	834
23	21:38	0	Inf. Dilution	dH:-8.0 (0.1SD)	0	MSP	834
24	25	0	Inf. Dilution	dH:-24.542 (6.372SD) kJ	0	CRV	32222
25	25	1	HClO4	dH:-3.0 (0.1SD)	3	MCL	832
26	25	1	Unknown	dH:-3.0 (2SF)	3	ENS	6496

Reaction No. 5035



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.8	Unknown	lgK:2.68 (3SF)	5	ENS	8933
2	21	0	Inf. Dilution	lgK:2.5 (0.1SD)	4	MSP	834
3	23			lgK:2.6 (2SF)	0	MEF	5398
4	25	0	Inf. Dilution	lgK:2.5 (2SF)	4	MSP	931
5	25	0	Inf. Dilution	lgK:2.4 (0.05SD)	5	MSP	5462
6	25	0.86	HClO4	lgK:2.3 (2SF)	5	ENS	8931
7	25	1	HClO4	lgK:2.41 (3SF)	5	ENS	832
8	25	1	HClO4	lgK:2.14 (3SF)	5	MSC	931
9	25	1	HClO4	lgK:2.38 (0.19SD)	6	CRV	4282
10	25	1	HClO4	lgK:2.18 (3SF)	3	EOD	4282

Note (10): Data from Burger & Dyrssen, 1963


11	25	1	HClO4	lgK:2.34 (3SF)	3	EOD	4282
----	----	---	-------	----------------	---	-----	------

Note (11): Data from Weed, 1964

12	25	1	NaClO4	lgK:2.4 (0.05SD)	5	MSP	838
13	25	3	H2SO4	lgK:1.8 (0.05SD)	5	MEF	839
14	29.5	0	Inf. Dilution	lgK:2.4 (2SF)	4	MSP	834

15	38	0	Inf. Dilution	lgK:2.2 (2SF)	4	MSP	834
16	21:38	0	Inf. Dilution	dH:-8.0 (0.1SD)	4	MSP	834
17	25	1	HClO4	dH:-2.6 (0.1SD)	3	MCL	832

Reaction No. 5036



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10			lgK:1.50 (3SF)	0	MSP	931
2	15	2	LiClO4	lgK:1.68 (3SF)	5	MSP	931
3	20	0.8	Unknown	lgK:1.68 (3SF)	5	ENS	8933
4	21	0	Inf. Dilution	lgK:2.6 (0.1SD)	0	MSP	834
5	23	1	NaClO4	lgK:1.27 (3SF)	4	MSP	5398
6	23			lgK:1.6 (2SF)	0	MEF	5398
7	25	0	Inf. Dilution	lgK:2.6 (2SF)	2	MSP	140
8	25	0	Inf. Dilution	lgK:2.4 (0.2SD)	0	CMN	835
9	25	0	Inf. Dilution	lgK:2.0 (2SF)	2	MSP	931
10	25	0.2	HClO4	lgK:1.4 (0.05SD)	5	MPL	5398
11	25	0.5	NaClO4	lgK:1.35 (3SF)	5	MSP	931
12	25	0.86	HClO4	lgK:2.0 (2SF)	0	ENS	8931
Note (12): Excluded by Byrne & Kump, GCA, 93, 57, 1151 [4282]							
13	25	1	HClO4	lgK:0.8 (1SF)	0	MSP	140
14	25	1	HClO4	lgK:1.37 (3SF)	5	ENS	832
15	25	1	HClO4	lgK:1.3 (0.05SD)	5	MSP	836
16	25	1	HClO4	lgK:1.44 (0.29SD)	6	CRV	4282
17	25	1	HClO4	lgK:1.38 (3SF)	3	EOD	4282
Note (17): Data from Weed, 1964							
18	25	1	HClO4	lgK:1.34 (3SF)	5	MSC	8932
19	25	1	LiClO4	lgK:1.43 (3SF)	5	MSP	931
20	25	1	NaClO4	lgK:1. (0.3SD)	0	CMN	5464
Note (20): Looks like it got truncated							
21	25	1.07	HClO4	lgK:1.44 (3SF)	5	MSP	931
22	25	2	LiClO4	lgK:1.59 (3SF)	5	MSP	931
23	25	3	H2SO4	lgK:2.4 (0.05SD)	0	MEF	839
24	25	3	LiClO4	lgK:1.77 (3SF)	5	MSP	931
25	25	3.4	HClO4	lgK:1.77 (3SF)	5	MSP	931
26	25	4	LiClO4	lgK:2.00 (3SF)	5	MSP	931

27	25			lgK:1.42 (3SF)	0	MSP	931
28	29.5	0	Inf. Dilution	lgK:2.6 (2SF)	0	MSP	834
29	38	0	Inf. Dilution	lgK:2.5 (2SF)	0	MSP	834
30	40	2	LiClO ₄	lgK:1.51 (3SF)	5	MSP	931
31	45			lgK:1.28 (3SF)	0	MSP	931
32	10:45			dH:-2.8 (2SF)	0	MTD	931
33	21:38	0	Inf. Dilution	dH:-8.0 (0.1SD)	3	MSP	834
34	25	1	HClO ₄	dH:-3.4 (0.1SD)	3	MCL	832

Reaction No. 5037							
Pd+2_Cl-1(2)_(cis) = Pd+2_Cl-1(2)_(trans)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	HClO ₄	lgK:0.3 (0.05SD)	0	MKN	840


Reaction No. 5038							
Pd+4_Cl-1(6) + 2<e-1> = Pd+2_Cl-1(4) + 2<Cl-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:45.2 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:43.5 (0.05SD)	0	ENS	802
3	25	1	HCl	lgR:43.5 (0.05SD)	3	MEF	843
4	25	1	NaCl	lgR:44.0 (0.05SD)	3	MEF	843
5	25	0	Inf. Dilution	E:1.288 (4SF)	0	CRV	6330
6	25	0	Inf. Dilution	E:1.288 (4SF)	0	CRV	18118
7	25	1	HCl	E:1.47 (3SF)	0	CRV	22551

Reaction No. 5041							
PdO ₂ (s) + H ₂ O + 2<e-1> = PdO(s) + 2<OH-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.9 (3SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.7 (0.05SD)	0	ENS	600

Reaction No. 5122							
0.5<O ₂ (g)> + Pd(s) = PdO(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.9 (0.1SD)	5	CMN	869
2	25	0	Inf. Dilution	lgK:14.93 (4SF)	4	ENS	6422
3	27	0	Inf. Dilution	lgK:14.81 (4SF)	0	ENS	6422


4	127	0	Inf. Dilution	lgK:9.761(4SF)	4	ENS	6422
5	227	0	Inf. Dilution	lgK:6.717(4SF)	3	ENS	6422
6	327	0	Inf. Dilution	lgK:4.679(4SF)	0	ENS	6422
7	25	0	Inf. Dilution	dG:-14.4(0.1SD)	0	ENS	5253
8	25	0	Inf. Dilution	dG:-20.37(4SF)	4	EFE	6422
9	25	0	Inf. Dilution	dH:-27.6(0.2SD)	5	CMN	869
10	25	0	Inf. Dilution	dH:-85.4(3SF) kJ	0	CRV	3006
11	25	0	Inf. Dilution	dH:-27.6(3SF)	4	MTD	6422
12	127	0	Inf. Dilution	dH:-27.8(3SF)	4	MTD	6422
13	227	0	Inf. Dilution	dH:-27.9(3SF)	3	MTD	6422
14	327	0	Inf. Dilution	dH:-28.0(3SF)	0	MTD	6422

Reaction No. 5267



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:15.25(4SF)	4	MSP	1555
2	20	1	Unknown	lgK:12.25(4SF)	0	CRV	552
3	25	0	Inf. Dilution	lgK:19.35(4SF)	0	EBU	6372

Reaction No. 5270




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:27.50(4SF)	4	MSP	1555
2	25	0	Inf. Dilution	lgK:37.90(4SF)	0	EBU	6372

Note (2): Low wgt for internal consistency

3	25	0.01	Unknown	lgK:17.55(4SF)	0	MGL	11516
---	----	------	---------	----------------	---	-----	-------


Note (3): Maley L et al., Australian J. Sci. Res., 1949, 92, 579

Reaction No. 5573



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:9.4(2SF)	0	MGL	905
2	25	0	Inf. Dilution	lgK:9.6(2SF)	1	EES	


Reaction No. 5574



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	20	0.5	KNO3	lgK:18.6(3SF)	4	MGL	905
---	----	-----	------	---------------	---	-----	-----

Reaction No. 5702




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	27	0.02	Unknown	lgK:16.97(4SF)	3	MGL	905

Reaction No. 5767




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:1.5(2SF)	3	MGL	1562
2	25	0	Inf. Dilution	lgK:1.6(2SF)	1	EES	

Reaction No. 5796




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:9.14(3SF)	0	MGL	905

Reaction No. 5797




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:0.74(2SF)	0	MGL	905

Reaction No. 9223




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:6.6(2SF)	4	MMX	1562
2	25	0	Inf. Dilution	lgK:6.9(2SF)	1	EES	

Reaction No. 9391



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:7.82(3SF)	6	MGL	1118
2	25	0	Inf. Dilution	lgK:7.9(2SF)	1	ESC	

Reaction No. 11431



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------

1	25	0	Inf. Dilution	lgK:11.9(3SF)	1	ELC	
2	30	0	Inf. Dilution	lgK:10.9(0.2SD)	0	MPS	834
3	40	0	Inf. Dilution	lgK:10.5(3SF)	2	MPS	834
4	30:40	0	Inf. Dilution	dH:-18.(0.2SD)	0	MCL	834

Reaction No. 14111							
EDDS-4 + Pd+2 = Pd+2_EDDS-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:13.6(3SF)	4	MGL	5662

Reaction No. 14743							
DTPA-5 + Pd+2 = Pd+2_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	HClO4	lgK:29.7(0.1SD)	5	CRV	13242
2	20	1	NaBr	lgK:29.7(3SF)	4	MMX	1562
3	25	0	Inf. Dilution	lgK:30.1(3SF)	1	ESC	
4	25	0.2	Unknown	lgK:24.60(4SF)	0	MPT	999
Note (4): Low wgt for internal consistency							

Reaction No. 15894							
Pd+2 + H+1_Gly-1 = Pd+2_H+1_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	Unknown	lgK:5.4(2SF)	3	CRV	7271
2	25	0	Inf. Dilution	lgK:5.4(2SF)	1	EES	7271

Reaction No. 16689							
Pd+2 + [18]14S2O4 = Pd+2_[18]14S2O4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	HNO3	lgK:25.(0.4SD)	3	MGL	1210
2	25	0.5	HNO3	dH:-44.(0.3SD)	5	MCL	1210

Reaction No. 16691							
Pd+2 + [18]110S2O4 = Pd+2_[18]110S2O4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	HNO3	lgK:21.(0.4SD)	3	MGL	1210
2	25	0.5	HNO3	dH:-20.(0.3SD)	5	MCL	1210

Reaction No. 17813							
Pd+2_Dien + Uracil-1 = Pd+2_Dien_Uracil-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:8.01(0.01SD)	4	MGL	1414

Reaction No. 17814							
Pd+2_EtDiAm + Uracil-1 = Pd+2_EtDiAm_Uracil-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:8.59(0.01SD)	6	MGL	1414

Reaction No. 17815							
Pd+2_EtDiAm_Uracil-1 + Uracil-1 = Pd+2_EtDiAm_Uracil-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:6.79(0.01SD)	6	MGL	1414

Reaction No. 17816							
Pd+2_Dien + Uridine-1 = Pd+2_Dien_Uridine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.8(2SF)	1	EDH	
2	25	0.5	KNO3	lgK:8.08(0.01SD)	2	MGL	1414
3	34	0.5	KNO3	lgK:8.60(3SF)	2	MMR	1309


Reaction No. 17817							
Pd+2_EtDiAm + Uridine-1 = Pd+2_EtDiAm_Uridine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:8.65(0.01SD)	6	MGL	1414

Reaction No. 17818							
Pd+2_EtDiAm_Uridine-1 + Uridine-1 = Pd+2_EtDiAm_Uridine-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:5.92(0.01SD)	4	MGL	1414

Reaction No. 17820							
Pd+2_Dien + Thymidine-1 = Pd+2_Dien_Thymidine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.0(2SF)	1	EDH	
2	25	0.5	KNO3	lgK:8.31(0.01SD)	3	MGL	1414


3	34	0.5	KNO3	lgK:8.7 (0.05SD)	2	MMR	1309
---	----	-----	------	------------------	---	-----	------

Reaction No. 17821




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:8.84 (0.01SD)	6	MGL	1414

Reaction No. 17822




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:5.85 (0.01SD)	6	MGL	1414

Reaction No. 18071




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18	0.1	Unknown	lgK:26.4 (0.5MD)	3	MLC	1594
2	20	0.1	Unknown	lgK:26.50 (4SF)	3	ENS	1539
3	20	1	KBr	lgK:25.5 (3SF)	6	MMX	1562
4	20	1	NaBr	lgK:24.5 (3SF)	0	MMX	1562
5	20	1	NaClO4	lgK:23.7 (3SF)	0	MGL	903
6	20	1	Unknown	lgK:25.5 (3SF)	5	ENS	2373
7	21	0.2	NaClO4	lgK:25.6 (0.2SD)	5	MLC	2884
8	25	0	Inf. Dilution	lgK:26.4 (3SF)	0	MSP	1594
9	25	0.2	HClO4	lgK:18.5 (3SF)	0	MEF	136

Reaction No. 18072



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:19.30 (4SF)	0	ENS	1539
2	25	0	Inf. Dilution	lgK:19.4 (3SF)	1	EES	

Reaction No. 18073



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:13.90 (4SF)	0	ENS	1539
2	25	0	Inf. Dilution	lgK:15.0 (3SF)	1	ELC	

Reaction No. 18074							
Pd+2_EDTA-4 + H2O = Pd+2_OH-1_EDTA-4 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:-8.08 (3SF)	0	CRV	552
2	20	0.1	Unknown	lgK:-9.80 (3SF)	0	ENS	1539
3	25	0	Inf. Dilution	lgK:-8. (1SF)	1	EES	

Reaction No. 18187							
EtDiAm + Pd+2 = Pd+2_EtDiAm							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:8.50 (3SF)	0	ENS	1539
2	25	0	Inf. Dilution	lgK:26.9 (3SF)	4	ENS	4454
3	25	0	Inf. Dilution	lgK:25.49 (4SF)	4	EBU	6372
4	25	1	NaClO4	lgK:23.60 (0.01MD)	4	MGL	3842
5	25	1	NaClO4	lgK:20. (2SF)	0	MPT	5023

Reaction No. 18188							
2<EtDiAm> + Pd+2 = Pd+2_EtDiAm(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:27.3 (3SF)	0	MSC	148
2	20	0.1	Unknown	lgK:26.90 (4SF)	0	ENS	1539
3	25	0	Inf. Dilution	lgK:44.7 (3SF)	1	EOR	
4	25	0	Inf. Dilution	lgK:49.46 (4SF)	0	EBU	6372
5	25	1	NaClO4	lgK:42.20 (0.02MD)	3	MGL	3842


Reaction No. 18364							
2<Citru1-1> + Pd+2 = Pd+2_Citru1-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:16.23 (0.02SD)	4	MGL	1537

Reaction No. 18587							
Pd+2 + EtDiAm_EtOlAm = Pd+2_EtDiAm_EtOlAm							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:7.88 (0.02SD)	4	MGL	1504

Reaction No. 18588							
Pd+2_EtDiAm_EtOlAm = Pd+2_H+1(-1)_EtDiAm_EtOlAm + H+1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:-5.16(0.02SD)	4	MGL	1504

Reaction No. 18589




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:11.01(0.01SD)	4	MGL	1504

Reaction No. 18590




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:-8.51(0.01SD)	5	MGL	1504

Reaction No. 18591




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:11.09(0.02SD)	4	MGL	1504

Reaction No. 18592




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:10.96(0.01SD)	4	MGL	1504

Reaction No. 18593




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:-8.05(0.01SD)	4	MGL	1504

Reaction No. 18594



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:-9.60(0.02SD)	6	MGL	1504

Reaction No. 18595



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:11.47(0.02SD)	6	MGL	1504

Reaction No. 18596							
$\text{Pd+2_EtDiAm_Hyp-1} = \text{Pd+2_H+1(-1)_EtDiAm_Hyp-1} + \text{H+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:-10.82(0.02SD)	4	MGL	1504

Reaction No. 19053							
$\text{Pd+2_H+1(2)_EDTA-4} + \text{H+1} = \text{Pd+2_H+1(3)_EDTA-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:0.9(0.1SD)	2	MSP	1562
2	25	0	Inf. Dilution	lgK:1.0(2SF)	1	EES	

Reaction No. 19379							
$\text{Pd+2_EDTA-4} + \text{Cl-1} = \text{Pd+2_Cl-1_EDTA-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18	0.1	Unknown	lgK:4.5(2SF)	5	MLC	1594
2	20	1	NaClO4	lgK:0.6(1SF)	0	MGL	1562
3	21	0.2	NaClO4	lgK:5.3(0.1SD)	5	MLC	2884
4	25	0	Inf. Dilution	lgK:4.7(2SF)	1	ESC	

Reaction No. 19380							
$\text{Pd+2_EDTA-4} + 2\text{Cl-1} = \text{Pd+2_Cl-1(2)_EDTA-4}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18	0.1	Unknown	lgK:6.5(2SF)	5	MLC	1594
2	25	0	Inf. Dilution	lgK:6.7(2SF)	1	ESC	

Reaction No. 19615							
$\text{Asp-2} + \text{Pd+2} = \text{Pd+2_Asp-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:10.44(4SF)	5	MGL	6628
2	30	0.1	KNO3	lgK:10.55(4SF)	5	MGL	5662

Reaction No. 19616							
$\text{Pd+2_Asp-2} + \text{Asp-2} = \text{Pd+2_Asp-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:7.70(3SF)	5	MGL	6628
2	30	0.1	KNO3	lgK:7.7(2SF)	4	MGL	5662

Reaction No. 19904							
Pd+2_Gly-1 + Gly-1 = Pd+2_Gly-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:12.25(4SF)	4	MMX	1562
2	25	0.01	Unknown	lgK:8.43(3SF)	0	MGL	11516
Note (2): Maley L et al., Australian J. Sci. Res., 1949, 92, 579							

Reaction No. 20428							
Pd+2_EtDiAm + GlyGly-1 = Pd+2_EtDiAm_GlyGly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:9.60(3SF)	6	MGL	1629

Reaction No. 20429							
Pd+2_H+1(-1)_EtDiAm_GlyGly-1 + H+1 = Pd+2_EtDiAm_GlyGly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:3.76(3SF)	6	MGL	1629

Reaction No. 20430							
Pd+2_EtDiAm + GlyNH2 = Pd+2_EtDiAm_GlyNH2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:8.64(3SF)	6	MGL	1629

Reaction No. 20431							
Pd+2_H+1(-1)_EtDiAm_GlyNH2 + H+1 = Pd+2_EtDiAm_GlyNH2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:2.47(3SF)	6	MGL	1629

Reaction No. 20458							
Pd+2_EtDiAm_Gln-1 = Pd+2_H+1(-1)_EtDiAm_Gln-1 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:-9.03(0.02SD)	4	MGL	1640

Reaction No. 20459							
Pd+2_EtDiAm_Asn-1 = Pd+2_H+1(-1)_EtDiAm_Asn-1 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:-6.46(0.01SD)	6	MGL	1640

Reaction No. 20736							
--------------------	--	--	--	--	--	--	--

Pd+2_CDTA-4 + H+1 = Pd+2_H+1_CDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	Unknown	lgK:3.60 (3SF)	6	ENS	773
2	25	0	Inf. Dilution	lgK:3.7 (2SF)	1	ESC	

Reaction No. 20789							
Pd+2_EtDiAm_H2O(2) + Gly-1 = Pd+2_EtDiAm_Gly-1 + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:11.21 (0.01SD)	5	MGL	1651

Reaction No. 20790							
Pd+2_EtDiAm_H2O(2) + Ala-1 = Pd+2_EtDiAm_Ala-1 + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:11.22 (0.01SD)	5	MGL	1651

Reaction No. 20791							
Pd+2_EtDiAm_H2O(2) + Sar-1 = Pd+2_EtDiAm_Sar-1 + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:11.28 (0.01SD)	5	MGL	1651

Reaction No. 20792							
Pd+2_EtDiAm_H2O(2) + DMG-1 = Pd+2_EtDiAm_DMG-1 + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:11.02 (0.01SD)	5	MGL	1651


Reaction No. 20793							
Pd+2_EtDiAm_H2O(2) + Leu-1 = Pd+2_EtDiAm_Leu-1 + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:11.41 (0.01SD)	6	MGL	1651

Reaction No. 20794							
Pd+2_EtDiAm_H2O(2) + Phe-1 = Pd+2_EtDiAm_Phe-1 + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:10.86 (0.01SD)	5	MGL	1651

Reaction No. 20795							
Pd+2_EtDiAm_H2O(2) + Pro-1 = Pd+2_EtDiAm_Pro-1 + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0.5	KNO3	lgK:12.2 (0.03SD)	5	MGL	1651
---	----	-----	------	-------------------	---	-----	------

Reaction No. 20796




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:10.8 (0.03SD)	5	MGL	1651

Reaction No. 20797




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:9.38 (0.01SD)	5	MGL	1651

Reaction No. 20798




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:9.1 (0.03SD)	5	MGL	1651

Reaction No. 20799




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:10.46 (0.01SD)	5	MGL	1651

Reaction No. 20800




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:10.76 (0.02SD)	5	MGL	1651

Reaction No. 20801



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:1.18 (0.01SD)	5	MGL	1651

Reaction No. 20802



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:0.74 (0.02SD)	5	MGL	1651

Reaction No. 20902

Pd+2_EtDiAm + Asn-1 = Pd+2_EtDiAm_Asn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:10.46(0.01SD)	6	MGL	1640

Reaction No. 20903							
Pd+2_EtDiAm + Gln-1 = Pd+2_EtDiAm_Gln-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:10.76(0.01SD)	6	MGL	1640

Reaction No. 20968							
Pd+2_Dien + H+1_Inosine-1 = Pd+2_H+1_Dien_Inosine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	NaClO4	lgK:5.2(2SF)	4	MSC	1760
2	34	0.5	KNO3	lgK:5.34(3SF)	6	MMR	1760

Reaction No. 20975							
Pd+2_Dien + Inosine-1 = Pd+2_Dien_Inosine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	34	0.5	KNO3	lgK:8.3(2SF)	4	MMR	1760

Reaction No. 20989							
Pd+2_Dien + Cytidine = Pd+2_Cytidine_Dien							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	NaClO4	lgK:5.29(3SF)	4	MSP	1760
2	34	0.5	KNO3	lgK:5.4(0.05SD)	4	MMR	1309

Reaction No. 20990							
Pd+2_EtDiAm + Cytidine = Pd+2_Cytidine_EtDiAm							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	34	0.5	KNO3	lgK:6.0(2SF)	4	MMR	1760

Reaction No. 21018							
Pd+2_Nioxime-1(2) + OH-1 = Pd+2_Nioxime-1(2)_OH-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	Unknown	lgK:4.(0.4SD)	5	CRV	2556

Reaction No. 21039							
Pd+2_Dien + 5CMP-2 = Pd+2_Dien_5CMP-2							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	NaClO ₄	lgK:2.63 (3SF)	6	MSP	1760

Reaction No. 21266							
Gly-1 + Pd+2 + 2<Cl-1> = Pd+2_Cl-1(2)_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:20.6 (4SF)	1	EOR	
2	25	1	Inert	lgK:19.7 (3SF)	5	MGL	1761

Reaction No. 22012							
Pd+2_Glu-2(2) + H+1 = Pd+2_H+1_Glu-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.76 (3SF)w	5	MPH	1908

Reaction No. 22034							
Pd+2_H+1_EDTA-4 + Cl-1 = Pd+2_H+1_Cl-1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO ₄	lgK:1.0 (2SF)	4	MGL	1562
2	25	0	Inf. Dilution	lgK:1.0 (2SF)	1	ESC	

Reaction No. 22197							
Pd+2_H+1(3)_EDTA-4 + Cl-1 = Pd+2_H+1(3)_Cl-1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO ₄	lgK:2.5 (2SF)	4	MGL	1562
2	25	0	Inf. Dilution	lgK:2.5 (2SF)	1	ESC	

Reaction No. 22198							
Pd+2_EDTA-4 + Br-1 = Pd+2_Br-1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO ₄	lgK:1.1 (2SF)	4	MGL	1562
2	25	0	Inf. Dilution	lgK:1.1 (2SF)	1	ESC	

Reaction No. 22199							
Pd+2_H+1_EDTA-4 + Br-1 = Pd+2_H+1_Br-1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO ₄	lgK:1.45 (3SF)	6	MGL	1562
2	25	0	Inf. Dilution	lgK:1.5 (2SF)	1	ESC	

Reaction No. 22200							
Pd+2_H+1(2)_EDTA-4 + Br-1 = Pd+2_H+1(2)_Br-1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:1.9(2SF)	2	MGL	1562
2	25	0	Inf. Dilution	lgK:2.2(2SF)	1	EES	

Reaction No. 22201							
Pd+2_H+1(3)_EDTA-4 + Br-1 = Pd+2_H+1(3)_Br-1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:3.0(2SF)	4	MGL	1562
2	25	0	Inf. Dilution	lgK:3.0(2SF)	1	ESC	

Reaction No. 22210							
IDA-2 + Pd+2 = Pd+2_IDA-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:17.5(3SF)	4	MMX	1562
2	20	1	NaClO4	lgK:17.5(0.1SD)	5	CRV	13242
3	25	0.1	KCl	lgK:9.62(3SF)	0	MMX	3178

Reaction No. 22211							
Pd+2_IDA-2 + IDA-2 = Pd+2_IDA-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:9.3(2SF)	4	MMX	1562
2	20	1	NaClO4	lgK:9.3(2SF)	5	CRV	13242


Reaction No. 22212							
TriMDTA-4 + Pd+2 = Pd+2_TriMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaBr	lgK:28.7(3SF)	4	MMX	1562

Reaction No. 22213							
TetMDTA-4 + Pd+2 = Pd+2_TetMDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaBr	lgK:25.8(3SF)	4	MMX	1562

Reaction No. 22214							
PentMDTA-4 + Pd+2 = Pd+2_PentMDTA-4							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaBr	lgK:26.4 (3SF)	4	MMX	1562

Reaction No. 22215




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaBr	lgK:26.3 (3SF)	4	MMX	1562

Reaction No. 22216




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:2.7 (2SF)	4	MMX	1562
2	25	0	Inf. Dilution	lgK:2.7 (2SF)	1	ESC	

Reaction No. 22217




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:6.47 (3SF)	6	MMX	1562

Reaction No. 22218




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:3.83 (3SF)	6	MMX	1562

Reaction No. 22219



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:-1. (1SF)	6	MMX	1562
2	25	0	Inf. Dilution	lgK:-1.0 (2SF)	1	ESC	

Reaction No. 22263



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:2.93 (3SF)	6	MGL	1562
2	20	1	NaClO4	lgK:2.9 (0.1SD)	5	CRV	13242
3	25	0	Inf. Dilution	lgK:3.0 (2SF)	1	ESC	

Reaction No. 22264

Pd+2_H+1(2)_DTPA-5 + H+1 = Pd+2_H+1(3)_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:2.56(3SF)	6	MGL	1562
2	20	1	NaClO4	lgK:2.6(0.1SD)	5	CRV	13242
3	25	0	Inf. Dilution	lgK:2.7(2SF)	1	ESC	

Reaction No. 22265							
Pd+2_H+1(3)_DTPA-5 + H+1 = Pd+2_H+1(4)_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:1.93(3SF)	6	MGL	1562
2	20	1	NaClO4	lgK:1.9(2SF)	5	CRV	13242
3	25	0	Inf. Dilution	lgK:2.0(2SF)	1	ESC	

Reaction No. 22266							
Pd+2_EDTA-4 + SCN-1 = Pd+2_SCN-1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:2.9(2SF)	4	MMX	1562
2	25	0	Inf. Dilution	lgK:2.9(2SF)	1	ESC	

Reaction No. 22267							
Pd+2_SCN-1_EDTA-4 + SCN-1 = Pd+2_SCN-1(2)_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:1.2(2SF)	4	MMX	1562
2	25	0	Inf. Dilution	lgK:1.2(2SF)	1	ESC	

Reaction No. 22268							
Pd+2_DTPA-5 + SCN-1 = Pd+2_SCN-1_DTPA-5							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:1.45(3SF)	6	MMX	1562
2	25	0	Inf. Dilution	lgK:1.5(2SF)	1	ESC	

Reaction No. 22460							
Pd+2_Dien + NH3 = Pd+2_Dien_NH3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaNO3	lgK:6.9(2SF)	4	MGL	999

Reaction No. 24000							
--------------------	--	--	--	--	--	--	--

EDDG-4 + Pd+2 = Pd+2_EDDG-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	30	0.1	KNO3	lgK:13.4 (3SF)	4	MGL	5662

Reaction No. 24647							
H+1 + Asn-1 + Pd+2 = Pd+2_H+1_Asn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.0 (3SF)	1	EES	
2	25	3	NaClO4	lgK:12.1 (0.04SD)	4	MGL	1604

Reaction No. 24648							
Asn-1 + Pd+2 = H+1 + Pd+2_H+1(-1)_Asn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO4	lgK:9. (0.5SD)	3	MGL	1604

Reaction No. 24649							
H+1 + Asn-1 + Pd+2 + Cl-1 = Pd+2_H+1_Asn-1_Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO4	lgK:18.29 (0.01SD)	5	MGL	1604

Reaction No. 24650							
Asn-1 + Pd+2 + Cl-1 = H+1 + Pd+2_H+1(-1)_Asn-1_Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO4	lgK:17.0 (0.2SD)	4	MGL	1604

Reaction No. 25007							
Dien + Pd+2 + Imidazole = Pd+2_Dien_Imidazole							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	KNO3	lgK:5.62 (0.01SD)	5	MPT	2229

Reaction No. 25008							
Pd+2 + Imidazole = Pd+2_Imidazole							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	KNO3	lgK:6.40 (0.01SD)	5	MPT	2229

Reaction No. 25009							
Formic-1 + Pd+2 = Pd+2_Formic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0	Inf. Dilution	lgK:2.796(4SF)	1	EOR	
2	25	0.4	KNO3	lgK:2.22(0.01SD)	3	MPT	2229
3	25	1	NaClO4	lgK:3.67(3SF)	0	MKN	11516
Note (3): Shi T et al., Inorg. Chem., 1997, 36, 528							

Reaction No. 25010							
Formic-1 + Dien + Pd+2 = Pd+2_Dien_Formic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.716(4SF)	1	EOR	
2	25	0.4	KNO3	lgK:2.14(0.02SD)	5	MPT	2229

Reaction No. 25011							
Acetic-1 + Pd+2 = Pd+2_Acetic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.82(4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:2.82(3SF)	4	EBU	6372
3	25	0.4	KNO3	lgK:2.73(0.01SD)	0	MPT	2229
4	25	0.92	NaClO4	lgK:4.9(2SF)	0	MSP	11516
Note (4): Yatsimirskii A et al., Izv. Akad. Nauk (USSR), 1976, 7, 1490							
5	25	1	NaClO4	lgK:4.34(3SF)	3	MIS	11516
Note (5): Shi T et al., Inorg. Chem., 1996, 35, 5941							

Reaction No. 25012							
Dien + Pd+2 + Acetic-1 = Pd+2_Dien_Acetic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	KNO3	lgK:2.52(0.01SD)	5	MPT	2229

Reaction No. 25013							
Propanoic-1 + Pd+2 = Pd+2_Propanoic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.919(4SF)	1	EOR	
2	25	0.4	KNO3	lgK:2.94(0.01SD)	0	MPT	2229
3	25	1	NaClO4	lgK:4.32(3SF)	3	MSP	16994

Reaction No. 25014							
Propanoic-1 + Dien + Pd+2 = Pd+2_Dien_Propanoic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0	Inf. Dilution	lgK:3.176(4SF)	1	EOR	
2	25	0.4	KNO3	lgK:2.60(0.01SD)	5	MPT	2229

Reaction No. 25015

Pd+2 + Lactic-1 = Pd+2_Lactic-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	KNO3	lgK:2.02(0.01SD)	3	MPT	2229
2	25	1	NaClO4	lgK:3.79(3SF)	0	MKN	11516

Note (2): Shi T et al., Inorg. Chem., 1997, 36, 528

Reaction No. 25016

Dien + Pd+2 + Lactic-1 = Pd+2_Dien_Lactic-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	KNO3	lgK:1.89(0.02SD)	5	MPT	2229

Reaction No. 25017

Pd+2 + Phthalic-2 = Pd+2_Phthalic-2

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	KNO3	lgK:3.31(0.01SD)	5	MPT	2229

Reaction No. 25018

Dien + Pd+2 + Phthalic-2 = Pd+2_Dien_Phthalic-2

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	KNO3	lgK:3.04(0.01SD)	5	MPT	2229

Reaction No. 25019

Dien + Pd+2 + PO4-3 = Pd+2_Dien_PO4-3

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	KNO3	lgK:2.63(0.01SD)	5	MPT	2229

Reaction No. 25020

Dien + Pd+2 + NH3 = Pd+2_Dien_NH3

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:39.5(3SF)	1	ELC	
2	25	0.4	KNO3	lgK:5.36(0.01SD)	0	MPT	2229

Reaction No. 25021

Dien + Pd+2 + Butanoic-1 = Pd+2_Dien_Butanoic-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	KNO3	lgK:2.58 (0.01SD)	5	MPT	2229

Reaction No. 25022

Dien + Pd+2 + Pyridine = Pd+2_Dien_Pyridine

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	KNO3	lgK:4.04 (0.03SD)	5	MPT	2229

Reaction No. 25261

Pd+2 + Dien + H2O = Pd+2_Dien_OH-1 + H+1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:-8.68 (0.06SD)	5	MPT	2229

Reaction No. 25672

[12]N3O:Acet*3-3 + Pd+2 = Pd+2_[12]N3O:Acet*3-3

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:19.27 (4SF)	6	MGL	2284

Reaction No. 25673

Pd+2_[12]N3O:Acet*3-3 + H+1 = Pd+2_H+1_[12]N3O:Acet*3-3

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:3.48 (3SF)	6	MGL	2284

Reaction No. 25711

[15]N3O2:Acet*3-3 + Pd+2 = Pd+2_[15]N3O2:Acet*3-3

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:16.58 (0.01SD)	6	MGL	2284

Reaction No. 25712

Pd+2_[15]N3O2:Acet*3-3 + H+1 = Pd+2_H+1_[15]N3O2:Acet*3-3

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.88 (0.01SD)	6	MGL	2284

Reaction No. 25713

Pd+2_H+1_[15]N3O2:Acet*3-3 + H+1 = Pd+2_H+1(2)_[15]N3O2:Acet*3-3

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.18 (0.01SD)	6	MGL	2284

Reaction No. 25714							
$2\text{Pd} + 2[\text{15}]\text{N3O2:Acet*3-3} = \text{Pd}_2 + 2[\text{15}]\text{N3O2:Acet*3-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:19.82(0.01SD)	6	MGL	2284

Reaction No. 25715							
$\text{Pd}_2\text{OH} + [\text{15}]\text{N3O2:Acet*3-3} + \text{H} = \text{Pd}_2 + [\text{15}]\text{N3O2:Acet*3-3} + \text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:10.77(0.01SD)	6	MGL	2284

Reaction No. 25764							
$[\text{18}]\text{N3O3:Acet*3-3} + \text{Pd}_2 = \text{Pd}_2 + [\text{18}]\text{N3O3:Acet*3-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:15.82(0.01SD)	6	MGL	2284

Reaction No. 25765							
$\text{Pd}_2 + [\text{18}]\text{N3O3:Acet*3-3} + \text{H} = \text{Pd}_2\text{H} + [\text{18}]\text{N3O3:Acet*3-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.47(0.01SD)	6	MGL	2284

Reaction No. 25766							
$2\text{Pd} + 2[\text{18}]\text{N3O3:Acet*3-3} = \text{Pd}_2 + 2[\text{18}]\text{N3O3:Acet*3-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:19.39(0.01SD)	6	MGL	2284

Reaction No. 25767							
$\text{Pd}_2 + 2[\text{18}]\text{N3O3:Acet*3-3} + \text{H} = \text{Pd}_2\text{H} + 2[\text{18}]\text{N3O3:Acet*3-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:2.53(0.01SD)	6	MGL	2284

Reaction No. 25768							
$\text{Pd}_2 + 2[\text{18}]\text{N3O3:Acet*3-3} + \text{H} = \text{Pd}_2\text{H} + 2[\text{18}]\text{N3O3:Acet*3-3}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:10.98(0.01SD)	6	MGL	2284

Reaction No. 25769							
$\text{Pd}_2\text{OH} + [\text{18}]\text{N3O3:Acet*3-3} + \text{H} = \text{Pd}_2 + [\text{18}]\text{N3O3:Acet*3-3} + \text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0.1	KCl	lgK:11.54 (0.01SD)	6	MGL	2284
---	----	-----	-----	--------------------	---	-----	------

Reaction No. 25880							
[21]N7 + Pd+2 = Pd+2_[21]N7							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:24.6 (0.06SD)	6	MGL	2729

Reaction No. 26474							
OHEtDiPhos-4 + Pd+2 = Pd+2_OHEtDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:5.74 (3SF)	3	MGL	1599

Reaction No. 26475							
Pd+2 + H+1_OHEtDiPhos-4 = Pd+2_H+1_OHEtDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:4.44 (3SF)	3	MGL	1599

Reaction No. 26476							
Pd+2 + H+1(2)_OHEtDiPhos-4 = Pd+2_H+1(2)_OHEtDiPhos-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:2.41 (3SF)	3	MGL	1599

Reaction No. 26791							
Pd+2 + H+1(2)_Cat-2 = Pd+2_Cat-2 + 2<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	NaClO4	dS:-2.22 (3SF)	5	MGL	1675

Reaction No. 27245							
3<H+1> + [21]N7 + Pd+2 = Pd+2_H+1(3)_[21]N7							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:47.1 (0.04SD)	6	MGL	2729

Reaction No. 27794							
33'ThioDiPr-2 + Pd+2 + 3<Cl-1> = Pd+2_Cl-1(3)_33'ThioDiPr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.9 (3SF)	1	ELC	
2	25	0.5	NaClO4	lgK:16.9 (0.09SD)	0	MSP	1180

Reaction No. 27795							
$2<33'\text{ThioDiPr-2}> + \text{Pd+2} + 2<\text{Cl-1}> = \text{Pd+2_Cl-1(2)}_{33'\text{ThioDiPr-2(2)}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.2(3SF)	1	ELC	
2	25	0.5	NaClO4	lgK:19.8(0.1SD)	0	MSP	1180

Reaction No. 27796							
$2<33'\text{ThioDiPr-2}> + \text{Pd+2} + \text{Cl-1} = \text{Pd+2_Cl-1}_{33'\text{ThioDiPr-2(2)}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaClO4	lgK:17.3(0.1SD)	5	MSP	1180

Reaction No. 27797							
$\text{Pd+2_Cl-1(4)} + 33'\text{ThioDiPr-2} = \text{Pd+2_Cl-1(3)}_{33'\text{ThioDiPr-2}} + \text{Cl-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.0(2SF)	1	EES	
2	25	0.5	NaClO4	lgK:5.42(3SF)	5	MSP	1180

Reaction No. 27798							
$\text{Pd+2_Cl-1(3)}_{33'\text{ThioDiPr-2}} + 33'\text{ThioDiPr-2} = \text{Pd+2_Cl-1(2)}_{33'\text{ThioDiPr-2(2)}} + \text{Cl-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaClO4	lgK:2.87(3SF)	5	MSP	1180

Reaction No. 27879							
$\text{Pd+4}_{33'\text{ThioDiPr-2(2)}}_{\text{H2O(2)}} + \text{Cl-1} = \text{Pd+4_Cl-1}_{33'\text{ThioDiPr-2(2)}}_{\text{H2O}} + \text{H2O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaClO4	lgK:4.30(3SF)	5	MSP	1180

Reaction No. 27880							
$\text{Pd+4_Cl-1}_{33'\text{ThioDiPr-2(2)}}_{\text{H2O}} + \text{Cl-1} = \text{Pd+4_Cl-1(2)}_{33'\text{ThioDiPr-2(2)}} + \text{H2O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaClO4	lgK:2.51(3SF)	5	MSP	1180

Reaction No. 28027							
$2<\text{H+1}> + 33'\text{ThioDiPr-2} + \text{Pd+2} = \text{Pd+2_H+1(2)}_{33'\text{ThioDiPr-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaClO4	lgK:16.7(0.2MD)	5	MSP	1170

Reaction No. 28028							
--------------------	--	--	--	--	--	--	--

4<H+1> + 2<33'ThioDiPr-2> + Pd+2 = Pd+2_H+1(4)_33'ThioDiPr-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaClO4	lgK:31.6(3SF)	5	MSP	1170

Reaction No. 28029							
2<H+1> + 33'DiThioDiPr-2 + Pd+2 = Pd+2_H+1(2)_33'DiThioDiPr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaClO4	lgK:15.2(0.1MD)	5	MSP	1170

Reaction No. 28030							
2<H+1> + 33'DiThioDiPr-2 + 2<Pd+2> = Pd+2(2)_H+1(2)_33'DiThioDiPr-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaClO4	lgK:19.6(3SF)	5	MSP	1170

Reaction No. 28038							
MetHydroxam-1 + Pd+2 = Pd+2_MetHydroxam-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:13.23(0.02SD)	5	MGL	2430

Reaction No. 28039							
2<MetHydroxam-1> + Pd+2 = Pd+2_MetHydroxam-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:23.3(0.04SD)	5	MGL	2430

Reaction No. 28040							
MetHydroxam-1 + Pd+2 + GlyGly-1 = Pd+2_GlyGly-1_MetHydroxam-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:21.1(0.09SD)	5	MGL	2430

Reaction No. 28041							
H+1 + MetHydroxam-1 + Pd+2 + GlyGly-1 = Pd+2_H+1_GlyGly-1_MetHydroxam-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:24.4(0.1SD)	5	MGL	2430

Reaction No. 28042							
Pd+2 + GlyGly-1 = Pd+2_GlyGly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:9.2(0.09SD)	5	MGL	2430

Reaction No. 28515							
232Tet + Pd+2 = Pd+2_232Tet							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:46.5(0.2SD)	5	ENS	3931
2	25	1	NaClO4	lgK:46.3(0.1SD)	5	MGL	3931

Reaction No. 28530							
242Tet + Pd+2 = Pd+2_242Tet							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:42.0(0.1SD)	5	MGL	3931

Reaction No. 29211							
Val-1 + Pd+2 = Pd+2_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:9.62(0.02SD)	6	MGL	2392

Reaction No. 29212							
2<Val-1> + Pd+2 = Pd+2_Val-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:17.8(0.04SD)	6	MGL	2392
2	27			lgK:17.54(4SF)	3	MGL	2392

Reaction No. 29224							
Leu-1 + Pd+2 = Pd+2_Leu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:9.71(0.02SD)	4	MGL	2392
2	20	0.5	KNO3	lgK:9.94(3SF)	3	MGL	11516
Note (2): Kollmann J et al., J. Prakt. Chem., 1974, 316, 119							

Reaction No. 29225							
2<Leu-1> + Pd+2 = Pd+2_Leu-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:18.15(0.02SD)	6	MGL	2392
2	27			lgK:18.22(4SF)	3	MGL	2392

Reaction No. 29248							
Pd+2_Thiourea(2) + Thiourea = Pd+2_Thiourea(3)							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.2	SCN- salt	lgK:2.95 (3SF)	0	MSP	4450
2	23	1	NaBr	lgK:4.65 (3SF)	4	MSP	4450
3	23	1	NaCl	lgK:4.86 (3SF)	4	MSP	4450

Reaction No. 29254							
Ile-1 + Pd+2 = Pd+2_Ile-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:9.9 (0.03SD)	4	MGL	2392
2	20	0.5	KNO3	lgK:9.71 (3SF)	3	MGL	11516
Note (2): Kollmann J et al., J. Prakt. Chem., 1974, 316, 119							

Reaction No. 29255							
2<Ile-1> + Pd+2 = Pd+2_Ile-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:18.2 (0.05SD)	6	MGL	2392

Reaction No. 29277							
Ala-1 + Pd+2 = Pd+2_Ala-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:9.98 (0.02SD)	3	MGL	2392


Reaction No. 29278							
2<Ala-1> + Pd+2 = Pd+2_Ala-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:18.3 (0.04SD)	3	MGL	2392
2	27			lgK:18.17 (4SF)	0	MGL	2392

Reaction No. 29300							
bAla-1 + Pd+2 = Pd+2_bAla-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:8.7 (0.04SD)	6	MGL	2392
2	25	0	Inf. Dilution	lgK:9.0 (2SF)	1	EAE	

Reaction No. 29301							
2<bAla-1> + Pd+2 = Pd+2_bAla-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	20	0.5	KNO3	lgK:15.8 (0.04SD)	6	MGL	2392
2	25	0	Inf. Dilution	lgK:16.4 (3SF)	1	EAE	

Reaction No. 29710




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.04:0.5	Unknown	lgK:10.8 (3SF)	5	CMN	1388

Reaction No. 30541




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:3.68 (3SF) w	5	MPH	1908

Reaction No. 30542




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.52 (3SF) w	5	MPH	1908

Reaction No. 30543




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.06 (3SF) w	5	MPH	1908

Reaction No. 30847




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.45 (3SF) w	5	MPH	1908

Reaction No. 30848



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.04 (3SF) w	5	MPH	1908

Reaction No. 30849



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:4.58 (3SF) w	5	MPH	1908

Reaction No. 30850							
$\text{Pd+2_2AmPimelic-2(2)} + \text{H+1} = \text{Pd+2_H+1_2AmPimelic-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KCl	lgK:5.33 (3SF)w	5	MPH	1908

Reaction No. 30983							
$2\text{<H+1>} + [\text{21}]\text{N7} + \text{Pd+2} = \text{Pd+2_H+1(2)_[21]N7}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:42.6 (0.04SD)	6	MGL	2729

Reaction No. 30984							
$\text{H+1} + [\text{21}]\text{N7} + \text{Pd+2} = \text{Pd+2_H+1_}[21]\text{N7}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:34.5 (0.06SD)	6	MGL	2729

Reaction No. 31222							
$[\text{18}]\text{N6} + \text{Pd+2} = \text{Pd+2_}[18]\text{N6}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:29.2 (0.1SD)	6	MGL	2729

Reaction No. 31223							
$\text{H+1} + [\text{18}]\text{N6} + \text{Pd+2} = \text{Pd+2_H+1_}[18]\text{N6}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:37.5 (0.07SD)	6	MGL	2729


Reaction No. 31224							
$2\text{<H+1>} + [\text{18}]\text{N6} + \text{Pd+2} = \text{Pd+2_H+1(2)_[18]N6}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgK:42.4 (0.07SD)	6	MGL	2729

Reaction No. 31225							
$2\text{<Pd+2>} + [\text{18}]\text{N6} + 2\text{<Cl-1>} = \text{Pd+2(2)_[18]N6_Cl-1(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgR:52. (0.8SD)	5	MGL	2729
2	25	0.5	NaCl	dH:-49.7 (3SF)	4	MCL	6878

Reaction No. 31976							
$2\text{<BuXanthate-1>} + \text{Pd+2} = \text{Pd+2_BuXanthate-1(2)}$							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.25	Unknown	lgK:24.(2SF)	5	MDS	2261

Reaction No. 33104




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	21	0.2	Cl-1 salt	lgK:16.0(0.2SD)	5	MSP	2877

Reaction No. 33915




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:16.0(0.08SD)	5	MGL	3345

Reaction No. 33916




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:20.3(0.08SD)	5	MGL	3345

Reaction No. 33917




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:15.4(0.03SD)	5	MGL	3345

Reaction No. 33918



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:19.8(0.07SD)	5	MGL	3345


Reaction No. 33919



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:9.10(3SF)	4	MGL	905
2	25	0.1	NaNO3	lgK:8.10(0.02SD)	0	MGL	3345

Note (2): Low wgt for internal consistency


Reaction No. 33920



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0.1	NaNO3	lgK:8.94(0.01SD)	5	MGL	3345
---	----	-----	-------	------------------	---	-----	------

Reaction No. 33921




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:10.26(4SF)	3	MGL	11516
Note (1): Kollmann J et al., J. Prakt. Chem., 1974, 316, 119							
2	25	0.1	NaNO3	lgK:10.2(0.03SD)	3	MGL	3345

Reaction No. 33922




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:9.32(3SF)	5	MGL	11516
Note (1): Kollmann J et al., J. Prakt. Chem., 1974, 316, 119							
2	25	0.1	NaNO3	lgK:9.5(0.08SD)	5	MGL	3345

Reaction No. 33923




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:6.83(0.02SD)	5	MGL	3345

Reaction No. 33924




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:5.5(0.04SD)	5	MGL	3345

Reaction No. 33925




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:15.1(0.03SD)	5	MGL	3345

Reaction No. 33926




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:4.5(0.08SD)	5	MGL	3345

Reaction No. 33927




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:3.8(0.08SD)	5	MGL	3345

Reaction No. 33928




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:5.82(0.02SD)	5	MGL	3345

Reaction No. 33929




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaNO3	lgK:15.76(0.02SD)	5	MGL	3345

Reaction No. 34201




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20		CCl4	lgK:1.6(0.2SD)	5	MSP	931

Reaction No. 35720




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-97.4(1.6SD)kJ	4	MCL	3833

Reaction No. 35721




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-136.3(1.0SD)kJ	4	MCL	3833

Reaction No. 36094



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	lgR:52.(2SF)	3	MGL	2729
2	25	0.5	NaCl	dH:-51.7(3SF)	4	MCL	6878

Reaction No. 36414



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	NaCl	lgK:5.0590(0.0002SD)	5	MGL	3754

Reaction No. 36415							
Pd+2_Cl-1(4) + Ethionine-1 = Pd+2_Cl-1(4)_Ethionine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	NaCl	lgK:9.1120(0.0002SD)	5	MGL	3754

Reaction No. 36416							
Pd+2_Cl-1(4) + Ethionine-1 + 2<H+1> = Pd+2_H+1(2)_Cl-1(4)_Ethionine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	NaCl	lgK:14.36(0.02SD)	5	MGL	3754

Reaction No. 36417							
Pd+2_Cl-1(4) + 2<Ethionine-1> = Pd+2_Cl-1(4)_Ethionine-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	NaCl	lgK:18.487(0.001SD)	5	MGL	3754

Reaction No. 36418							
Pd+2_Cl-1(4) + 2<Ethionine-1> + 2<H+1> = Pd+2_H+1(2)_Cl-1(4)_Ethionine-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	NaCl	lgK:23.98(0.008SD)	5	MGL	3754

Reaction No. 36419							
Ethionine-1 + Pd+2 + 2<Cl-1> = Pd+2_Cl-1(2)_Ethionine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	NaCl	lgR:20.22(4SF)	5	MPT	3754

Reaction No. 36420							
2<H+1> + Ethionine-1 + Pd+2 + 3<Cl-1> = Pd+2_H+1(2)_Cl-1(3)_Ethionine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	NaCl	lgR:25.60(4SF)	5	MKN	3754
2	25	0.16	NaCl	lgR:25.47(4SF)	5	MPT	3754

Reaction No. 36761							
Pd+2_Cl-1(4) + Cytidine = Pd+2_Cytidine_Cl-1(3) + Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaNO3	lgK:4.49(3SF)	5	MPS	3878

Reaction No. 36762							
--------------------	--	--	--	--	--	--	--

Pd+2_Cytidine_Cl-1(3) + Cytidine = Pd+2_Cytidine(2)_Cl-1(2) + Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaNO3	lgK:3.45(3SF)	5	MPS	3878

Reaction No. 36763							
Pd+2_EtDiAm_Cl-1(2) + Cytidine = Pd+2_Cytidine_EtDiAm_Cl-1 + Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaNO3	lgK:3.32(3SF)	5	MPS	3878

Reaction No. 36764							
Pd+2_Cytidine_EtDiAm_Cl-1 + Cytidine = Pd+2_Cytidine(2)_EtDiAm + Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaNO3	lgK:2.56(3SF)	5	MPS	3878

Reaction No. 36765							
Pd+2_EtDiAm_Cl-1(2) + Pyridine = Pd+2_EtDiAm_Pyridine_Cl-1 + Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaNO3	lgK:4.31(3SF)	5	MPS	3878

Reaction No. 36766							
Pd+2_EtDiAm_Pyridine_Cl-1 + Pyridine = Pd+2_EtDiAm_Pyridine(2) + Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaNO3	lgK:3.15(3SF)	5	MPS	3878

Reaction No. 36767							
2<Ethionine-1> + Pd+2 = Pd+2_Ethionine-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	NaCl	lgK:29.60(4SF)	5	MPT	3754

Reaction No. 36768							
2<H+1> + 2<Ethionine-1> + Pd+2 = Pd+2_H+1(2)_Ethionine-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	NaCl	lgK:35.09(4SF)	5	MPT	3754

Reaction No. 36769							
Pd+2 + OH-1 + Ethionine-1 + Cl-1 = Pd+2_Cl-1_Ethionine-1_OH-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	NaCl	lgR:29.95(4SF)	5	MPT	3754

Reaction No. 37985							
Dien + Pd+2 = Pd+2_Dien							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:32.60(0.01MD)	4	MGL	3842
2	25	1	NaNO3	lgK:34.(2SF)	0	MGL	906
Note (2): Low wgt for internal consistency							

Reaction No. 37986							
2<Dien> + Pd+2 = Pd+2_Dien(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:40.40(0.02MD)	4	MGL	3842

Reaction No. 37987							
2<Tren> + 2<Pd+2> = Pd+2(2)_Tren(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:77.4(0.03SD)	4	MGL	3842

Reaction No. 38044							
Pd+2_Bipy(2) + OH-1 = Pd+2_Bipy(2)_OH-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KMeSO3	lgK:4.79(0.05MD)	5	MPS	3844
2	25	0.1	KNO3	lgK:4.65(0.05MD)	5	MPS	3844

Reaction No. 38045							
Pd+2_Bipy(2)_OH-1 + OH-1 = Pd+2_Bipy_OH-1(2) + Bipy							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KMeSO3	lgK:1.86(0.05MD)	5	MPS	3844
2	25	0.1	KNO3	lgK:1.89(0.05MD)	5	MPS	3844

Reaction No. 38046							
Pd+2_Bipy + 2<OH-1> = Pd+2_Bipy_OH-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KMeSO3	lgK:15.58(0.05MD)	5	MPS	3844

Reaction No. 38047							
Pd+2_Phenanth + 2<OH-1> = Pd+2_Phenanth_OH-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0.1	KMeSO3	lgK:15.8 (0.08MD)	5	MPS	3844
---	----	-----	--------	-------------------	---	-----	------

Reaction No. 38048							
Pd+2_Phenanth(2) + OH-1 = Pd+2_Phenanth(2)_OH-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KMeSO3	lgK:4.04 (0.05MD)	5	MPS	3844

Reaction No. 38049							
Pd+2_Phenanth(2)_OH-1 + OH-1 = Pd+2_Phenanth_OH-1(2) + Phenanth							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KMeSO3	lgK:1.42 (0.05MD)	5	MPS	3844

Reaction No. 38059							
Pd+2_DiAmPropan-1(2) + Spermidine = Pd+2_Spermidine_DiAmPropan-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:2.4 (2SF)	0	MMR	684

Reaction No. 38060							
Pd+2_DiAmButan-1(2) + Spermidine = Pd+2_Spermidine_DiAmButan-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:2.6 (2SF)	0	MMR	684

Reaction No. 38062							
Pd+2 + H+1_Tren = Pd+2_H+1_Tren							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KBr	lgK:30.1 (3SF)	4	MGL	3842

Reaction No. 38063							
Dien + Pd+2 + Cl-1 = Pd+2_Dien_Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.0 (1SF)	1	ELC	
2	25	1	NaClO4	lgK:2.65 (0.05MD)	0	MGL	3842

Reaction No. 38064							
H+1 + Tren + Pd+2 + Cl-1 = Pd+2_H+1_Tren_Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:3.17 (0.05MD)	4	MGL	3842

Reaction No. 38065							
EtDiAm + Pd+2 + Br-1 = Pd+2_EtDiAm_Br-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:3.72 (0.05MD)	4	MGL	3842

Reaction No. 38066							
Dien + Pd+2 + Br-1 = Pd+2_Dien_Br-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:3.30 (0.05MD)	4	MGL	3842

Reaction No. 38067							
H+1 + Tren + Pd+2 + Br-1 = Pd+2_H+1_Tren_Br-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:3.79 (0.05MD)	4	MGL	3842

Reaction No. 38068							
H+1 + Tren + Pd+2 + I-1 = Pd+2_H+1_Tren_I-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:5.6 (0.08MD)	4	MGL	3842

Reaction No. 38069							
H+1 + Tren + Pd+2 + SCN-1 = Pd+2_H+1_Tren_SCN-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KNO3	lgK:6.3 (0.08MD)	4	MGL	3842


Reaction No. 38207							
Pd+2_EtDiAm_Br-1 + Br-1 = Pd+2_EtDiAm_Br-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:2.2 (0.1MD)	4	MGL	3842

Reaction No. 38635							
Pd+2_H+1 (2)_GlyOEt_OH-1 (2) + EtDiAm = Pd+2_EtDiAm_GlyOEt + 2<H2O>							
Note: Weighted out coz its thermodynamically isolated; not nec. bad data							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO3	lgK:7.1 (0.03SD) w	0	MPH	2978

Reaction No. 40065							
2<IDA-2> + Pd+2 = Pd+2_IDA-2 (2)							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	Na+1 salt	lgK:26.8 (3SF)	6	CRV	552
2	25	0.1	KCl	lgK:14.87 (4SF)	0	MMX	3178

Reaction No. 41110




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18:22	0.1	Methanol:Water 50:50Wgt NaClO4	lgK:17.1 (3SF)	5	MSP	931

Reaction No. 41629



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0	Dioxan:Water 50:50Vol Inf. Dilution	lgK:7.74 (3SF)	5	ENS	4455

Reaction No. 41630




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0	Dioxan:Water 50:50Vol Inf. Dilution	lgK:7.03 (3SF)	5	ENS	4455

Reaction No. 42102




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.2	SCN- salt	lgK:2.52 (3SF)	0	MSP	4450
2	23	1	NaBr	lgK:4.18 (3SF)	4	MSP	4450
3	23	1	NaCl	lgK:4.24 (3SF)	4	MSP	4450
4	25	0	Inf. Dilution	lgK:4.1 (2SF)	1	EDH	

Reaction No. 42158




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KCl	lgR:3.602 (4SF)	5	MKN	2549

Reaction No. 42159




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KCl	lgR:2.137(4SF)	5	MKN	2549

Reaction No. 42507




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KBr	lgK:40.1(0.1SD)	5	MGL	3931
2	25	1	NaClO4	lgK:40.2(0.1SD)	5	MGL	3931

Reaction No. 42508




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:46.7(0.1SD)	5	MGL	3931

Reaction No. 42509




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KBr	lgR:44.7(0.1SD)	5	MGL	3931

Reaction No. 42510




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KBr	lgK:4.58(0.02SD)	5	MGL	3931
2	25	1	NaBr	lgK:4.37(0.02SD)	5	MGL	3931
3	25	1	NaClO4	lgK:4.3(0.08SD)	5	MGL	3931

Reaction No. 42511




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:0.8(0.04SD)	5	MGL	3931

Reaction No. 42512




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:38.(0.5SD)	4	MGL	3931

Reaction No. 42513




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:38.(0.3SD)	5	MGL	3931
2	25	1	KNO3	lgK:39.(0.3SD)	5	MGL	3931

Reaction No. 42514




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:54.5(3SF)	5	MGL	3931

Reaction No. 42631




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaBr	lgK:35.6(0.1SD)	5	MGL	3931

Reaction No. 42638




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaBr	lgK:39.1(0.1SD)	5	MGL	3931

Reaction No. 42643




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaBr	lgK:37.0(0.1SD)	5	MGL	3931

Reaction No. 42644




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaBr	lgR:36.(0.3SD)	5	MGL	3931

Reaction No. 42649



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaBr	lgR:2.5(2SF)	5	MGL	3931

Reaction No. 42650



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:34.0(0.2SD)	5	MGL	3931

2	25	1	KNO3	lgK:34.7(0.2SD)	5	MGL	3931
3	25	1	NaBr	lgK:34.7(0.2SD)	5	MGL	3931

Reaction No. 42655							
262Dpa + Pd+2 = Pd+2_262Dpa							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KBr	lgK:34.7(3SF)	3	MGL	3931

Reaction No. 42726							
Pd+2_252Dpa + 2<Br-1> + 2<H+1> = Pd+2_H+1(2)_252Dpa_Br-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaBr	lgR:3.5(2SF)	5	MGL	3931

Reaction No. 42859							
Oxalic-2 + Pd+2 = Pd+2_Oxalic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18	0.2	HClO4	lgK:8.7(0.1SD)	5	MIX	906
2	25	0	Inf. Dilution	lgK:8.9(2SF)	1	ESC	

Reaction No. 42860							
Pd+2_Oxalic-2 + Oxalic-2 = Pd+2_Oxalic-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18			lgK:3.55(3SF)	0	MSC	906
2	25	0	Inf. Dilution	lgK:3.6(2SF)	1	ESC	


Reaction No. 42905							
Pd+2_Acetic-1(2) + Ce+3_Acetic-1(3) = Ce+3_Pd+2_Acetic-1(5)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Acetic acid	lgK:4.8(2SF)	3	MSP	906

Reaction No. 43166							
2<DMPS-3> + Pd+2 = Pd+2_DMPS-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	1	HNO3	lgK:21.1(3SF)	4	MPT	906

Reaction No. 43621							
Glu-2 + Pd+2 = Pd+2_Glu-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0.1	NaClO4	lgK:10.38 (4SF)	5	MGL	6628
---	----	-----	--------	-----------------	---	-----	------

Reaction No. 43622




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:7.46 (3SF)	5	MGL	6628

Reaction No. 43646




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23			lgK:64.9 (3SF)	4	MDS	906

Reaction No. 43647




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23			lgK:44.6 (3SF)	4	MDS	906

Reaction No. 44395




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Dioxan:Water 70:30Wgt	lgK:9.52 (3SF)	4	MGL	906

Reaction No. 44396




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Dioxan:Water 70:30Wgt	lgK:8.03 (3SF)	4	MGL	906

Reaction No. 44441



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	2	Unknown	lgK:7.81 (3SF)	0	MKN	906

Reaction No. 44718



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23			lgK:11.6 (3SF)	4	MFL	906

Reaction No. 44719							
Pd+2_Sulfox-2 + Sulfox-2 = Pd+2_Sulfox-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23			lgK:8.54 (3SF)	4	MFL	906

Reaction No. 45191							
Dithizone-1 + Pd+2 = Pd+2_Dithizone-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	24:26	0.1	NaClO4	lgK:11.4 (0.1SD)	5	MSP	906

Reaction No. 45192							
2<Dithizone-1> + Pd+2 = Pd+2_Dithizone-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	24:26	0.1	NaClO4	lgK:21.8 (0.08SD)	5	MSP	906

Reaction No. 45208							
2<Procaine> + Pd+2 = Pd+2_Procaine(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22			lgK:7.88 (3SF)	4	MCO	906

Reaction No. 45349							
2<Pd+2_NTA-3> = Pd+2(2)_NTA-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:2.(1SF)	3	MGL	1562

Reaction No. 45446							
Pd+2 + H+1_CEDTA-5 = Pd+2_CEDTA-5 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23			lgK:6.57 (3SF)	4	MDS	906

Reaction No. 52645							
Pd+2_Br-1(4) + Cl-1 = Pd+2_Br-1(3)_Cl-1 + Br-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.1 (2SF)	1	ELC	
2	25	4.5	LiClO4	lgK:0.3 (0.04SD)	0	MSP	5398
3	25	1.5	MeCN Bu4NBr	lgK:1.24 (3SF)	5	MSP	5398

Reaction No. 52646							
$\text{Pd+2_Br-1(4)} + 2\text{<Cl-1>} = \text{Pd+2_Br-1(2)_Cl-1(2)} + 2\text{<Br-1>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.1(2SF)	1	ELC	
2	25	1	Unknown	lgK:-0.06(1SF)	0	MSP	931
3	25	1.5	MeCN Bu4NBr	lgK:1.84(3SF)	5	MSP	5398

Reaction No. 52647							
$\text{Pd+2_Br-1(4)} + 3\text{<Cl-1>} = \text{Pd+2_Br-1_Cl-1(3)} + 3\text{<Br-1>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1.5	MeCN Bu4NBr	lgK:2.50(3SF)	5	MSP	5398

Reaction No. 52648							
$\text{Pd+2_Br-1(4)} + 4\text{<Cl-1>} = \text{Pd+2_Cl-1(4)} + 4\text{<Br-1>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1.5	MeCN Bu4NBr	lgK:2.39(3SF)	5	MSP	5398


Reaction No. 52670							
$\text{Pd+2_Cl-1(4)} + 3\text{<Br-1>} = \text{Pd+2_Br-1(3)_Cl-1(3)} + \text{Cl-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4.5	LiClO4	lgK:1.55(3SF)	5	MSP	5398

Reaction No. 52891							
$\text{Br-1} + \text{Pd+2} = \text{Pd+2_Br-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:7.(2.SD)	5	MSL	5398
2	20	0.8	ClO4-1 salt	lgK:4.37(3SF)	0	MSP	931
3	25	0	Inf. Dilution	lgK:5.07(3SF)	0	EBU	6372
4	25	0	Inf. Dilution	lgK:5.77(0.02SD)	0	CRV	32222
5	25	1	HClO4	lgK:5.2(0.04SD)	4	MSP	5398
6	25	0	Inf. Dilution	dH:-30.140(7.639SD) kJ	2	CRV	32222
7	25	1	HClO4	dH:-5.1(0.1SD)	2	MCL	5398

Reaction No. 53037							
$\text{Pd+2(2)_Li+1(2)_Cl-1(6)} + 2\text{<Li+1_Cl-1>} = 2\text{<Pd+2_Li+1(2)_Cl-1(4)>}$							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	37.5		Acetic acid	lgK:-1.0(2SF)	4	MVP	5398

Reaction No. 53758




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.2:1	Unknown	lgK:4.86(3SF)	4	MSP	931

Reaction No. 53759




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.2:1	Unknown	lgK:4.65(3SF)	4	MSP	931

Reaction No. 53760




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.2:1	Unknown	lgK:2.95(3SF)	4	MSP	931

Reaction No. 53761




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.2:1	Unknown	lgK:4.24(3SF)	4	MSP	931

Reaction No. 53762




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.2:1	Unknown	lgK:4.18(3SF)	4	MSP	931

Reaction No. 53763



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.2:1	Unknown	lgK:2.52(3SF)	4	MSP	931

Reaction No. 53765



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.5	KCl	lgK:25.7(3SF)	3	MIS	842
2	10	0.5	NH4Cl	lgK:28.3(3SF)	0	MIS	842

3	10	1	NH4Cl	lgK:25.6 (3SF)	3	MIS	842
4	20	0.5	KCl	lgK:26.0 (3SF)	0	MIS	842
5	20	0.5	NH4Cl	lgK:29.2 (3SF)	0	MIS	842
6	20	1	NH4Cl	lgK:24.8 (3SF)	3	MIS	842
7	25	0	Inf. Dilution	lgK:24.2 (3SF)	1	EDH	
8	25	0	Inf. Dilution	lgK:29.31 (4SF)	0	EBU	6372
9	25	0.5	KCl	lgK:25.4 (3SF)	0	MIS	842
10	25	0.5	NH4Cl	lgK:29.6 (3SF)	0	MIS	842
11	25	0.5	Unknown	lgK:29.6 (3SF)	0	MEF	931
12	25	1	NH4Cl	lgK:24.4 (3SF)	3	MIS	842
13	25	1	Unknown	lgK:32.8 (3SF)	0	CRV	2556
14	30	0.5	KCl	lgK:25.1 (3SF)	0	MIS	842
15	30	0.5	NH4Cl	lgK:30.0 (3SF)	0	MIS	842
16	30	1	NH4Cl	lgK:23.9 (3SF)	3	MIS	842
17	40	0.5	KCl	lgK:24.2 (3SF)	0	MIS	842
18	40	0.5	NH4Cl	lgK:30.3 (3SF)	0	MIS	842
19	40	1	NH4Cl	lgK:23.1 (3SF)	3	MIS	842
20	50	0.5	KCl	lgK:23.7 (3SF)	0	MIS	842
21	50	0.5	NH4Cl	lgK:30.6 (3SF)	0	MIS	842
22	50	1	NH4Cl	lgK:22.7 (3SF)	3	MIS	842
23	60	0.5	KCl	lgK:23.1 (3SF)	0	MIS	842
24	60	0.5	NH4Cl	lgK:31.0 (3SF)	0	MIS	842
25	60	1	NH4Cl	lgK:22.2 (3SF)	3	MIS	842

Reaction No. 53818							
4<NO2-1> + Pd+2 = Pd+2_NO2-1 (4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.5	KCl	lgK:20.5 (3SF)	5	MIS	842
2	10	1	KCl	lgK:21.7 (3SF)	5	MIS	842
3	20	0.5	KCl	lgK:20.4 (3SF)	5	MIS	842
4	20	1	KCl	lgK:21.7 (3SF)	5	MIS	842
5	25	0.5	KCl	lgK:20.3 (3SF)	5	MIS	842
6	25	1	KCl	lgK:21.6 (3SF)	5	MIS	842
7	25			lgK:21. (2SF)	0	MEF	931
8	30	0.5	KCl	lgK:20.2 (3SF)	5	MIS	842
9	30	1	KCl	lgK:21.5 (3SF)	5	MIS	842

10	40	0.5	KCl	lgK:20.0 (3SF)	5	MIS	842
11	40	1	KCl	lgK:21.5 (3SF)	5	MIS	842
12	50	0.5	KCl	lgK:19.3 (3SF)	5	MIS	842
13	50	1	KCl	lgK:21.3 (3SF)	5	MIS	842
14	60	0.5	KCl	lgK:19.2 (3SF)	5	MIS	842
15	60	1	KCl	lgK:21.2 (3SF)	5	MIS	842

Reaction No. 54210							
4<Cl-1> + Pd+2 = Pd+2_Cl-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18:20			lgK:12.2 (3SF)	0	MEF	931
2	25	0	Inf. Dilution	lgK:13.9 (3SF)	1	ELC	
3	25	0	Inf. Dilution	lgK:13.8 (3SF)	0	EOR	
4	25	0	Inf. Dilution	lgK:12.30 (4SF)	0	MEF	140
5	25	0	Inf. Dilution	lgK:11. (2SF)	0	CRV	3006
6	25	0	Inf. Dilution	lgK:13.09 (4SF)	0	EBU	6372
7	25	0	Inf. Dilution	lgK:15.1 (0.2SD)	0	MSP	8931
8	25	0	Inf. Dilution	lgK:11.464 (0.20SD)	0	CRV	31301
9	25	0	Inf. Dilution	lgK:15.40 (4SF)	0	CRV	32224
10	25	0.5	Unknown	lgK:9.5 (2SF)	0	CRV	552
11	25	1	H(ClO4)	lgK:11.5 (0.1SD)	3	MSP	5398
12	25	1	HClO4	lgK:10.42 (4SF)	0	MSC	931
13	25	1	HClO4	lgK:11.32 (4SF)	4	CRV	4282
14	25	1	Unknown	lgK:11.5 (3SF)	0	ENS	6496
15	25	3.4	HClO4	lgK:11.4 (3SF)	3	MEF	931
16	25	4	HClO4	lgK:13.22 (4SF)	0	MEF	830
17	25			lgK:12.6 (3SF)	0	MEF	931
18	25			lgK:11.11 (4SF)	0	MSP	931
19	40			lgK:12.05 (4SF)	0	MEF	931
20	10	1	KCl	lgR:12.2 (3SF)	5	MIS	842
21	20	1	KCl	lgR:12.0 (3SF)	5	MIS	842
22	25	1	KCl	lgR:11.8 (3SF)	5	MIS	842
23	30	1	KCl	lgR:11.7 (3SF)	5	MIS	842
24	40	1	KCl	lgR:11.4 (3SF)	5	MIS	842
25	50	1	KCl	lgR:11.2 (3SF)	5	MIS	842
26	60	1	KCl	lgR:11.2 (3SF)	5	MIS	842

27	25	0	Inf. Dilution	dH:-112.470 (6.376SD) kJ	0	CRV	32222
28	25	0.1	NaCl	dH:-5.5 (0.01SD)	0	MCL	5882
29	25	1	Unknown	dH:-4.6 (2SF)	2	CRV	552
30	25	1	Unknown	dH:-11.6 (3SF)	0	ENS	6496
31	25		Dioxan:Water 72:28Wgt	lgK:17.7 (3SF)	4	MEF	931
32	40		Dioxan:Water 72:28Wgt	lgK:16.6 (3SF)	4	MEF	931

Reaction No. 54211							
2<Cl-1> + Pd+2 = Pd+2_Cl-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.4 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:10.7 (3SF)	2	CRV	552
3	25	0	Inf. Dilution	lgK:8.77 (3SF)	0	EBU	6372
4	25	0	Inf. Dilution	lgK:10.7 (0.14SD)	4	CRV	31301
5	25	0	Inf. Dilution	lgK:6.86 (3SF)	0	CRV	32224
6	25	1	HClO4	lgK:7.50 (3SF)	3	CRV	4282
7	25	1	HClO4	lgK:7.8 (0.05SD)	3	MSP	5398
8	25	1	Unknown	lgK:7.74 (3SF)	4	ENS	6496
9	25			lgK:7.49 (3SF)	0	MSP	931
10	25	0	Inf. Dilution	dH:-47.297 (6.372SD) kJ	0	CRV	32222
11	25	1	Unknown	dH:-5.6 (2SF)	2	CRV	552
12	25	1	Unknown	dH:-5.6 (2SF)	2	ENS	6496

Reaction No. 54212							
3<Cl-1> + Pd+2 = Pd+2_Cl-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.1 (3SF)	3	CRV	552
2	25	0	Inf. Dilution	lgK:11.46 (4SF)	0	EBU	6372
3	25	0	Inf. Dilution	lgK:13.1 (0.2SD)	3	MSP	8931
4	25	0	Inf. Dilution	lgK:10.582 (0.17SD)	0	CRV	31301
5	25	0	Inf. Dilution	lgK:13.10 (4SF)	4	CRV	32224
6	25	0.2	HClO4	lgK:7.9 (0.05SD)	0	MPL	5398
7	25	1	HClO4	lgK:9.88 (3SF)	2	CRV	4282
8	25	1	HClO4	lgK:10.2 (0.1SD)	4	MSP	5398
9	25	1	Unknown	lgK:10.2 (3SF)	4	ENS	6496


10	25			lgK:9.73 (3SF)	0	MSP	931
11	25	0	Inf. Dilution	dH:-77.344 (6.374SD) kJ	0	CRV	32222
12	25	1	Unknown	dH:-8.2 (2SF)	2	CRV	552
13	25	1	Unknown	dH:-8.2 (2SF)	2	ENS	6496

Reaction No. 54213							
Pd+2_Cl-1(3)_OH-1 + Cl-1 = Pd+2_Cl-1(4) + OH-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	19:50	0.1:1	NaClO4	lgK:-5.7 (2SF)	0	MGL	931
2	25	0	Inf. Dilution	lgK:-2.8 (2SF)	1	ELC	

Reaction No. 54297							
4<Br-1> + Pd+2 = Pd+2_Br-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.5	KCl	lgK:14.2 (3SF)	2	MIS	842
2	10	1	KCl	lgK:14.9 (3SF)	2	MIS	842
3	18:20			lgK:16.1 (3SF)	0	MEF	931
4	20	0.5	KCl	lgK:13.8 (3SF)	2	MIS	842
5	20	1	KCl	lgK:14.3 (3SF)	2	MIS	842
6	25	0	Inf. Dilution	lgK:13.7 (3SF)	1	EES	
7	25	0	Inf. Dilution	lgK:13.10 (4SF)	0	MDG	140
8	25	0	Inf. Dilution	lgK:15.31 (4SF)	0	EBU	6372
9	25	0	Inf. Dilution	lgK:15.11 (0.08SD)	2	CRV	32222
10	25	0	Inf. Dilution	lgK:13.77 (4SF)	4	CRV	32224
11	25	0.5	KCl	lgK:13.7 (3SF)	2	MIS	842
12	25	1	HClO4	lgK:14.9 (0.1SD)	0	MSP	5398
13	25	1	KCl	lgK:14.2 (3SF)	2	MIS	842
14	25	1	NaCl	lgK:13.0 (0.05SD)	0	MSP	5398
15	25			lgK:14. (2SF)	0	MEF	931
16	25			lgK:16.2 (3SF)	3	MEF	931
17	30	0.5	KCl	lgK:13.4 (3SF)	2	MIS	842
18	30	1	KCl	lgK:14.1 (3SF)	2	MIS	842
19	40	0.5	KCl	lgK:13.2 (3SF)	2	MIS	842
20	40	1	KCl	lgK:13.9 (3SF)	2	MIS	842
21	40			lgK:15.35 (4SF)	0	MEF	931
22	50	0.5	KCl	lgK:13.0 (3SF)	2	MIS	842


23	50	1	KCl	lgK:13.8 (3SF)	2	MIS	842
24	60	0.5	KCl	lgK:12.8 (3SF)	2	MIS	842
25	60	1	KCl	lgK:13.6 (3SF)	2	MIS	842
26	25	0	Inf. Dilution	dH:-126.680 (7.703SD) kJ	0	CRV	32222
27	25	0.1	NaCl	dH:-13.11 (0.05SD)	4	MCL	5882
28	25:45	0.1	NaBr	dH:-13.11 (4SF)	5	MCL	931
29	25		Dioxan:Water 71:29Wgt	lgK:19.0 (3SF)	4	MEF	931
30	40		Dioxan:Water 71:29Wgt	lgK:18.1 (3SF)	4	MEF	931

Reaction No. 54298




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.8	ClO4-1 salt	lgK:4.08 (3SF)	0	MSC	931
2	25	0	Inf. Dilution	lgK:1.7 (2SF)	1	ELC	

Reaction No. 54299




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.8	ClO4-1 salt	lgK:3.79 (3SF)	3	MSC	931

Reaction No. 54300



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	1	NaClO4	lgK:2.50 (3SF)	3	MSP	931
2	20	0.8	ClO4-1 salt	lgK:3.50 (3SF)	3	MSP	931
3	25	0.5	NaClO4	lgK:2.20 (3SF)	5	MSP	931
4	25	1	NaClO4	lgK:2.30 (3SF)	3	MSP	931
5	45	1	NaClO4	lgK:2.16 (3SF)	3	MSP	931
6	10:45	1	NaClO4	dH:-4.3 (2SF)	3	MCL	931

Reaction No. 54301



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	19:50	0.1:1	NaClO4	lgK:-4.23 (3SF)	0	MGL	931
2	25	0	Inf. Dilution	lgK:-4.3 (2SF)	1	EES	


Reaction No. 54350							
4<I-1> + Pd+2 = Pd+2_I-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	1	KCl	lgK:24.4 (3SF)	5	MIS	842
2	18:20			lgK:24.9 (3SF)	0	MEF	931
3	20	0.8	ClO4-1 salt	lgK:15.74 (4SF)	0	MSP	931
4	20	1	KCl	lgK:24.1 (3SF)	5	MIS	842
5	25	0	Inf. Dilution	lgK:25. (2SF)	0	CRV	3006
Note (5): p. 344							
6	25	0	Inf. Dilution	lgK:28.21 (4SF)	0	EBU	6372
7	25	0	Inf. Dilution	lgK:24.64 (0.55SD)	4	CRV	32222
8	25	0	Inf. Dilution	lgK:22.41 (4SF)	0	CRV	32224
9	25	1	KCl	lgK:24.0 (3SF)	5	MIS	842
10	25	1	Unknown	lgK:28.3 (3SF)	0	CRV	2556
11	30	1	KCl	lgK:23.9 (3SF)	5	MIS	842
12	40	1	KCl	lgK:23.7 (3SF)	5	MIS	842
13	50	1	KCl	lgK:23.5 (3SF)	5	MIS	842
14	60	1	KCl	lgK:23.3 (3SF)	5	MIS	842
15	25	1	KI	lgR:24.0 (3SF)	3	MEF	931
16	25	0	Inf. Dilution	dH:-190.050 (7.009SD) kJ	0	CRV	32222

Reaction No. 54351							
I-1 + Pd+2 = Pd+2_I-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	HClO4	lgK:10.0 (3SF)	3	MSL	931
2	20	0.1	NaClO4	lgK:10.0 (0.1SD)	3	MSL	5398
3	20	0.8	ClO4-1 salt	lgK:4.95 (3SF)	0	MSP	931
4	25	0	Inf. Dilution	lgK:7.67 (3SF)	0	EBU	6372
5	25	0	Inf. Dilution	lgK:10.4 (3SF)	4	CRV	32222
6	25	1	Unknown	lgK:6.08 (3SF)	4	CRV	2556
7	25	0	Inf. Dilution	dH:-58.201 (5SF) kJ	4	CRV	32222

Reaction No. 54352							
Pd+2_I-1 + I-1 = Pd+2_I-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.8	ClO4-1 salt	lgK:4.27 (3SF)	0	EMU	931


2	25	0	Inf. Dilution	lgK:4.5 (2SF)	1	EES	
---	----	---	---------------	---------------	---	-----	--

Reaction No. 54353




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.8	ClO4-1 salt	lgK:3.60 (3SF)	0	EMU	931
2	25	0	Inf. Dilution	lgK:6.8 (2SF)	1	ELC	

Reaction No. 54354




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.8	ClO4-1 salt	lgK:2.92 (3SF)	3	MSP	931
2	25	0	Inf. Dilution	lgK:2.9 (2SF)	1	EOR	
3	25	1	Unknown	lgK:2.56 (3SF)	3	CRV	2556

Reaction No. 54393




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Unknown	lgK:1.99 (3SF)	3	MSP	931
2	25	4.5	LiClO4	lgK:2.6 (0.04SD)	5	MSP	5398

Reaction No. 54394



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	NaClO4	lgK:10.5 (3SF)	3	MSL	5398
2	25	0	Inf. Dilution	lgK:10.8 (3SF)	1	ESC	

Reaction No. 54536



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	300	0	Inf. Dilution	lgK:12.65 (0.5SD)	0	MSL	9077


Reaction No. 54661



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:0.07 (1SF)	3	CRV	6330
2	25	0.1	K2SO4	E:-0.19 (0.01SD)	0	MEF	775


Note (2): Low wgt for internal consistency

Reaction No. 54662




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KCN	E:-1.53(0.01SD)	0	MPL	775
2	25	1	KCN	E:-1.53(0.01SD)	0	MPL	775

Reaction No. 54697



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:71.0(3SF)	1	EAE	
2	18	0	Inf. Dilution	E:1.2(0.05SD)	0	MEF	5463

Reaction No. 54698




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:44.9(3SF)	1	ELC	
2	18	0	Inf. Dilution	E:1.(0.05SD)	0	MEF	5463
3	25	0	Inf. Dilution	E:1.47(3SF)	0	CRV	22551

Note (3): "measured"

4	25	0	Inf. Dilution	E:1.263(4SF)	0	CRV	22551
---	----	---	---------------	--------------	---	-----	-------


Note (4): "calculated"

Reaction No. 54741



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.86(3SF)	4	EBU	6372
2	25	1	NaClO4	lgK:9.6(0.05SD)	5	MGL	5023

Reaction No. 54742



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.7(2SF)	1	ELC	
2	25	1	NaClO4	lgK:8.9(0.05SD)	3	MGL	5023

Reaction No. 54743

Pd+2_NH3(2) + NH3 = Pd+2_NH3(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:7.5(0.05SD)	5	MGL	5023

Reaction No. 54744							
Pd+2_NH3(3) + NH3 = Pd+2_NH3(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.2(2SF)	1	ELC	
2	25	1	NaClO4	lgK:6.8(0.05SD)	0	MGL	5023


Reaction No. 54753							
Pd(s) + Cl2(g) = Pd+2_Cl-1(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.2(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:22.2(0.1SD)	0	ENS	5472
3	25	0	Inf. Dilution	lgK:26.62(4SF)	0	ENS	6422
4	27	0	Inf. Dilution	lgK:26.408(5SF)	0	ENS	6422
5	127	0	Inf. Dilution	lgK:17.79(4SF)	1	ENS	6422
6	227	0	Inf. Dilution	lgK:12.66(4SF)	0	ENS	6422
7	327	0	Inf. Dilution	lgK:9.269(4SF)	0	ENS	6422
8	25	0	Inf. Dilution	dG:-36.32(4SF)	0	EFE	6422
9	25	0	Inf. Dilution	dG:-126.(3SF)	0	EOD	6435
10	25	0	Inf. Dilution	dH:-47.49(4SF)	0	MTD	6422
11	27	0	Inf. Dilution	dH:-47.48(4SF)	0	MTD	6422
12	127	0	Inf. Dilution	dH:-47.12(4SF)	0	MTD	6422
13	227	0	Inf. Dilution	dH:-46.74(4SF)	0	MTD	6422
14	327	0	Inf. Dilution	dH:-46.34(4SF)	0	MTD	6422

Reaction No. 55667							
Pd(s) + 2<O2(g)> + 2<H2(g)> = Pd+4_OH-1(4)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-120.(2.SD)	3	CMN	5253

Reaction No. 55668							
Pd(s) + O2(g) + H2(g) = Pd+2_OH-1(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:52.7(3SF)	1	ELC	


2	25	0	Inf. Dilution	dG:-72.0(0.1SD)	0	ENS	5253
---	----	---	---------------	-----------------	---	-----	------

Reaction No. 55669




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:74.8(3SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-97.(1.SD)	0	CMN	5253
3	25	0	Inf. Dilution	dG:-104.00(5SF)	0	CRV	10174
4	25	1	HCl	dG:-417.1(4SF)kJ	2	CRV	3006
5	50	0	Inf. Dilution	dG:-103.55(5SF)	0	CRV	10174
6	75	0	Inf. Dilution	dG:-103.21(5SF)	0	CRV	10174
7	100	0	Inf. Dilution	dG:-102.97(5SF)	0	CRV	10174
8	125	0	Inf. Dilution	dG:-102.80(5SF)	0	CRV	10174
9	150	0	Inf. Dilution	dG:-102.67(5SF)	0	CRV	10174
10	175	0	Inf. Dilution	dG:-102.56(5SF)	0	CRV	10174
11	200	0	Inf. Dilution	dG:-102.44(5SF)	0	CRV	10174
12	225	0	Inf. Dilution	dG:-102.27(5SF)	0	CRV	10174
13	250	0	Inf. Dilution	dG:-102.01(5SF)	0	CRV	10174
14	300	0	Inf. Dilution	dG:-100.88(5SF)	0	CRV	10174
15	25	1	HCl	dH:-550.2(4SF)kJ	2	CRV	3006

Reaction No. 55670




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:24.1(0.1SD)	4	ENS	5253

Reaction No. 55671



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7(3SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-12.8(0.1SD)	0	ENS	5253

Reaction No. 57552




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.5	KCl	lgK:51.5(3SF)	4	MIS	842
2	10	1	KCl	lgK:51.8(3SF)	4	MIS	842

3	20	0.5	KCl	lgK:51.5 (3SF)	4	MIS	842
4	20	1	KCl	lgK:51.8 (3SF)	4	MIS	842
5	25	0	Inf. Dilution	lgK:42.4 (0.1SD)	0	MEF	222
6	25	0	Inf. Dilution	lgK:42.4 (3SF)	0	MIS	22560
Note (6): Izatt et al., 1967,, 1304							
7	25	0	KCN	lgK:51.6 (3SF)	0	MPT	931
8	25	0	Unknown	lgK:63. (2SF)	0	MIS	2261
9	25	0	Unknown	lgK:63. (1.SD)	0	MIS	2261
10	25	0.1	NaClO4	lgK:62.3 (3SF)	0	MSP	22560
Note (10): Harrington, Jones & Hancock, Inorg. Chim. Acta, 2005, 358, 4473							
11	25	0.5	KCl	lgK:51.5 (3SF)	4	MIS	842
12	25	0.5	Unknown	lgK:51.2 (3SF)	4	CRV	552
13	25	1	KCN	lgK:51.6 (0.1SD)	0	MEF	222
14	25	1	KCl	lgK:51.7 (3SF)	4	MIS	842
15	30	0.5	KCl	lgK:51.4 (3SF)	4	MIS	842
16	30	1	KCl	lgK:51.7 (3SF)	4	MIS	842
17	40	0.5	KCl	lgK:51.3 (3SF)	4	MIS	842
18	40	1	KCl	lgK:51.6 (3SF)	4	MIS	842
19	50	0.5	KCl	lgK:51.2 (3SF)	4	MIS	842
20	50	1	KCl	lgK:51.5 (3SF)	4	MIS	842
21	60	0.5	KCl	lgK:51.2 (3SF)	4	MIS	842
22	60	1	KCl	lgK:51.4 (3SF)	4	MIS	842
23	25	0	Inf. Dilution	dH:-92.3 (0.9SD)	0	MCL	5882
Note (23): Low wgt for internal consistency							
24	25	0.5	Unknown	dH:-91.9 (3SF)	0	CRV	552
Note (24): Low wgt for internal consistency							

Reaction No. 57739							
Pd+2 + H2O = Pd+2_OH-1 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.1 (2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-1.23 (3SF)	0	EBU	6372
3	25	0	Inf. Dilution	lgK:-2.1 (2SF)	2	CRV	6478
4	25	0	Inf. Dilution	lgK:-0.680 (0.22SD)	0	CRV	31301
5	25	0	Inf. Dilution	lgK:-1.86 (3SF)	4	CRV	32222
6	25	0	Inf. Dilution	lgK:-0.99 (2SF)	2	CRV	32224


7	17	0.1	HClO4	lgR:-2.3 (0.1SD)	0	ENS	4998
8	25	1	HClO4	lgR:-2.0 (0.2SD)	0	ENS	4998
9	25	0	Inf. Dilution	dH:7.4 (2SF)	0	CRV	6478
10	25	0	Inf. Dilution	dH:11.900 (5SF) kJ	4	CRV	32222

Reaction No. 57751




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.1 (2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-3.42 (3SF)	0	EBU	6372
3	25	0	Inf. Dilution	lgK:-3.110 (0.15SD)	0	CRV	31301
4	25	0	Inf. Dilution	lgK:-3.79 (3SF)	0	CRV	32222
5	25	0	Inf. Dilution	lgK:11.81 (4SF)	0	CRV	32224
6	25	1	HClO4	lgK:-4. (1SF)	1	EES	
7	17	0.1	HClO4	lgR:-4.8 (0.2SD)	5	ENS	4998
8	25	1	HClO4	lgR:-4.0 (0.2SD)	3	ENS	4998
9	25	0	Inf. Dilution	dH:15.293 (5SF) kJ	2	CRV	32222

Reaction No. 57752




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	17	0.1	HClO4	lgK:-5.4 (0.05SD)	0	ENS	4998
2	25	0	Inf. Dilution	lgK:-2.7 (2SF)	1	ESC	

Reaction No. 57753



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	17	0.1	HClO4	lgK:-28.96 (0.02SD)	0	MSL	5398
2	25	0	Inf. Dilution	lgK:-28.8 (3SF)	1	EOR	
3	25	0	Inf. Dilution	lgK:-28.5 (0.1SD)	4	CSM	8
4	25	0	Inf. Dilution	lgK:-31.0 (3SF)	0	EOD	16981
5	25	0	Inf. Dilution	lgK:-28.96 (4SF)	3	MSL	22604


Reaction No. 57766



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:49.9 (3SF)	1	ELC	


2	25	0	Inf. Dilution	dG:-68.(1.SD)	0	ENS	869
---	----	---	---------------	---------------	---	-----	-----

Reaction No. 57767




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.4(2SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-13.(1.SD)	0	ENS	869
3	25	0	Inf. Dilution	dG:-13.00(4SF)	0	CRV	10174
4	50	0	Inf. Dilution	dG:-12.69(4SF)	0	CRV	10174
5	75	0	Inf. Dilution	dG:-12.43(4SF)	0	CRV	10174
6	100	0	Inf. Dilution	dG:-12.19(4SF)	0	CRV	10174
7	125	0	Inf. Dilution	dG:-11.99(4SF)	0	CRV	10174
8	150	0	Inf. Dilution	dG:-11.80(4SF)	0	CRV	10174
9	175	0	Inf. Dilution	dG:-11.64(4SF)	0	CRV	10174
10	200	0	Inf. Dilution	dG:-11.48(4SF)	0	CRV	10174
11	225	0	Inf. Dilution	dG:-11.33(4SF)	0	CRV	10174
12	250	0	Inf. Dilution	dG:-11.18(4SF)	0	CRV	10174
13	300	0	Inf. Dilution	dG:-10.86(4SF)	0	CRV	10174

Reaction No. 57768




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-103.(1.SD)	4	ENS	869
2	25	0	Inf. Dilution	dG:-430.(3SF) kJ	0	CRV	7421
3	25	1	HCl	dG:-430.0(4SF) kJ	5	CRV	3006
4	25	1	HCl	dH:-598.(3SF) kJ	5	CRV	3006

Reaction No. 57769




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.1(3SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-25.(1.SD)	0	ENS	869
3	25	0	Inf. Dilution	dG:-75.(2SF) kJ	0	CRV	3006
4	25	0	Inf. Dilution	dG:-75.(2SF) kJ	0	CRV	7421

Reaction No. 57770




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.1(3SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-20.(1.SD)	0	ENS	869
3	25	0	Inf. Dilution	dG:-68.(2SF)kJ	1	CRV	3006

Reaction No. 57805




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	17	0.1	HClO4	lgK:11.8(0.05SD)	0	MSL	5398
2	25	0	Inf. Dilution	lgK:12.9(3SF)	1	ELC	

Reaction No. 57806




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	17	0.1	HClO4	lgK:1.8(0.05SD)	0	MSL	5398
2	25	0	Inf. Dilution	lgK:0.4(1SF)	1	ELC	

Reaction No. 57809



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.8(3SF)	1	EES	
2	25	0	Inf. Dilution	lgK:13.10(4SF)	0	EBU	6372
3	25	1	NaClO4	lgK:15.46(0.024SD)	5	MSP	30060
Note (3): Complex is given as Pd+2_SCN-1(2)_H2O(2)							
4	30	0	H(ClO4)	lgK:16.9(0.1SD)	3	MSP	5398
5	30	0.1	H(ClO4)	lgK:16.2(0.1SD)	3	MSP	5398


Reaction No. 57810



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0.1	KCl	lgK:25.1(3SF)	1	MIS	842
2	10	0.5	KCl	lgK:27.1(3SF)	1	MIS	842
3	10	1	KCl	lgK:26.5(3SF)	0	MIS	842
4	20	0.1	KCl	lgK:25.0(3SF)	1	MIS	842
5	20	0.5	KCl	lgK:27.0(3SF)	1	MIS	842
6	20	1	KCl	lgK:26.3(3SF)	0	MIS	842
7	25	0	Inf. Dilution	lgK:21.96(4SF)	0	EBU	6372


8	25	0.1	KCl	lgK:24.4 (3SF)	1	MIS	842
9	25	0.5	Unknown	lgK:26.8 (3SF)	1	MIS	842
10	25	1	ClO4-1 salt	lgK:27.6 (3SF)	4	MLC	1562
11	25	1	KCl	lgK:26.1 (3SF)	1	MIS	842
12	25	1	NaClO4	lgK:27.42 (0.274SD)	5	MSP	30060
13	30	0	H (ClO4)	lgK:25.6 (0.1SD)	0	MSP	5398
14	30	0.1	H (ClO4)	lgK:25.2 (0.1SD)	0	MSP	5398
15	30	0.1	KCl	lgK:24.3 (3SF)	1	MIS	842
16	30	0.5	KCl	lgK:26.7 (3SF)	1	MIS	842
17	30	1	KCl	lgK:26.0 (3SF)	1	MIS	842
18	40	0.1	KCl	lgK:24.1 (3SF)	1	MIS	842
19	40	0.5	KCl	lgK:26.6 (3SF)	0	MIS	842
20	40	1	KCl	lgK:25.8 (3SF)	1	MIS	842
21	50	0.1	KCl	lgK:23.8 (3SF)	1	MIS	842
22	50	0.5	KCl	lgK:26.4 (3SF)	0	MIS	842
23	50	1	KCl	lgK:25.6 (3SF)	1	MIS	842
24	60	0.1	KCl	lgK:23.2 (3SF)	1	MIS	842
25	60	0.5	KCl	lgK:26.3 (3SF)	0	MIS	842
26	60	1	KCl	lgK:25.3 (3SF)	1	MIS	842

Reaction No. 57813



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.033 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:3.16 (0.15SD)	2	EOD	3006
Note (2): p. 344							
3	25	0	Inf. Dilution	lgK:5.06 (3SF)	0	EBU	6372
4	25	0	Inf. Dilution	lgK:4.17 (3SF)	3	CRV	32222
5	25	0.2	HClO4	lgK:3.2 (0.05SD)	3	MPL	5398

Reaction No. 57829



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.24 (3SF)	4	EBU	6372
2	25	0	Inf. Dilution	lgK:10.06 (0.04SD)	2	CRV	32222
3	25	1	HClO4	lgK:9.4 (0.04SD)	5	MSP	5398

4	25	0	Inf. Dilution	dH:-57.708(7.652SD)kJ	2	CRV	32222
---	----	---	---------------	-----------------------	---	-----	-------

Reaction No. 57830							
3<Br-1> + Pd+2 = Pd+2_Br-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.7(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:12.64(4SF)	0	EBU	6372
3	25	0	Inf. Dilution	lgK:13.75(0.06SD)	0	CRV	32222
4	25	0	Inf. Dilution	lgK:12.05(4SF)	4	CRV	32224
5	25	1	HClO4	lgK:12.7(0.1SD)	5	MSP	5398
6	25	0	Inf. Dilution	dH:-92.385(7.021SD)kJ	2	CRV	32222

Reaction No. 57831							
Pd+2_Br-1(2)_(cis) = Pd+2_Br-1(2)_(trans)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	HClO4	lgK:0.8(0.04SD)	5	MKN	5398

Reaction No. 57832							
Pd+4_Br-1(4) + Br-1 = Pd+4_Br-1(5)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	HClO4	lgK:3.5(0.04SD)	5	MRX	5398


Reaction No. 57833							
Pd+2_Br-1 + Br-1 = Pd+2_Br-1(2)_(cis)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.0(2SF)	1	ELC	
2	25	1	HClO4	lgK:4.2(0.04SD)	5	MKN	5398

Reaction No. 57834							
Pd+2_Br-1 + Br-1 = Pd+2_Br-1(2)_(trans)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.8(2SF)	1	ELC	
2	25	1	HClO4	lgK:3.4(0.04SD)	2	MKN	5398

Reaction No. 57835							
Pd+2_Br-1(2)_(cis) + Br-1 = Pd+2_Br-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:-0.4(1SF)	1	ELC	
2	25	1	HClO4	lgK:3.4(0.04SD)	0	MKN	5398

Reaction No. 57836




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.2(2SF)	1	ELC	
2	25	1	HClO4	lgK:4.2(0.04SD)	0	MKN	5398

Reaction No. 57837




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.4	HClO4	lgK:2.6(0.04SD)	5	MRX	5398

Reaction No. 57853




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4.5	LiClO4	lgK:1.4(0.04SD)	5	MSP	5398

Reaction No. 57854




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4.5	LiClO4	lgK:1.1(0.04SD)	5	MSP	5398

Reaction No. 57855




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.0(2SF)	1	ELC	
2	25	4.5	LiClO4	lgK:0.7(0.04SD)	4	MSP	5398

Reaction No. 57856




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.6(2SF)	1	ELC	
2	25	4.5	LiClO4	lgK:4.0(0.04SD)	3	MSP	5398

Reaction No. 57857




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4.5	LiClO4	lgK:4.1(0.1SD)	5	MSP	5398

Reaction No. 57858




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4.5	LiClO4	lgK:2.8(0.1SD)	5	MSP	5398

Reaction No. 57859




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4.5	LiClO4	lgK:1.3(0.04SD)	5	MSP	5398

Reaction No. 57860




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.9(2SF)	1	EES	
2	25	4.5	LiClO4	lgK:4.1(0.04SD)	5	MSP	5398

Reaction No. 57861




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4.5	LiClO4	lgK:2.8(0.04SD)	5	MSP	5398

Reaction No. 57862




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4.5	LiClO4	lgK:5.8(0.04SD)	5	MSP	5398

Reaction No. 57863



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4.5	LiClO4	lgK:7.5(0.04SD)	5	MSP	5398


Reaction No. 57864



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.9(3SF)	1	ELC	


2	25	4.5	LiClO ₄	lgK:8.2(0.04SD)	3	MSP	5398
---	----	-----	--------------------	-----------------	---	-----	------

Reaction No. 57868




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.9(2SF)	4	MGL	931
2	25	0	Inf. Dilution	lgK:2.9(2SF)	2	MIS	22560
Note (2): Izatt et al., 1967,, 1304							
3	25	0	Inf. Dilution	dH:-0.2(0.4SD)	4	MCL	5882

Reaction No. 57872




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Unknown	lgK:20.8(3SF)	4	MIS	2261

Reaction No. 57873




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-32.(2SF)	1	EES	
2	25	0	Unknown	lgK:-42.(2SF)	0	MIS	22560
Note (2): Hancock & Evers, Inorg. Chem., 1976, 15, 995							

Reaction No. 58347




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23			lgK:-9.22(3SF)	0	MSP	140

Reaction No. 58597



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.1(2SF)	4	MSP	140
2	25	0	Inf. Dilution	dH:0.0(1SF)	4	MTD	140


Reaction No. 58598



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.1(2SF)	4	MSP	140


2	25	0	Inf. Dilution	dH:0.0(1SF)	4	MTD	140
---	----	---	---------------	-------------	---	-----	-----

Reaction No. 59339



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	24	0.1	NaClO4	lgK:5.60(3SF)	4	MGL	905

Reaction No. 59428




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:9.7(2SF)	0	MGL	905

Note (1): Low wgt for internal consistency


2	25	0.1	NaCl	lgK:8.66(3SF)	4	MGL	905
3	27	0.02	Unknown	lgK:16.88(4SF)	0	MGL	905

Reaction No. 59429




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:18.8(3SF)	4	MGL	905

Reaction No. 59493




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaCl	lgK:5.10(3SF)	4	MGL	905

Reaction No. 59542




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaCl	lgK:4.15(3SF)	4	MGL	905

Reaction No. 59563



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:9.15(3SF)	4	MGL	905


Reaction No. 59564



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0.1	NaClO4	lgK:17.65 (4SF)	4	MGL	905
2	27	0.02	Unknown	lgK:15.11 (4SF)	0	MGL	905

Reaction No. 59592




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:6.46 (3SF)	0	MGL	905

Reaction No. 59608




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:17.45 (4SF)	4	MGL	905

Reaction No. 59629




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	KNO3	lgK:9.03 (3SF)	0	MGL	905

Reaction No. 60129



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	HClO4	lgK:18.60 (0.01SD)	5	MGL	3842
2	25	1	NaClO4	lgK:18.4 (3SF)	5	MPT	5023

Reaction No. 60192




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	22	1	NaCl	lgK:3.8 (0.2SD)	0	MPS	903
2	25	0	Inf. Dilution	lgK:32.8 (3SF)	1	ELC	

Reaction No. 60624




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:26.68 (4SF)	1	EOR	
2	25	0.7	Unknown	lgK:29.1 (3SF)	4	CRV	2556

Reaction No. 60730




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.86 (4SF)	4	EBU	6372
2	25	1	Unknown	lgK:22. (2SF)	0	CRV	2556

Reaction No. 60731




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.6 (3SF)	1	EES	
2	25	0	Inf. Dilution	lgK:21.69 (4SF)	0	EBU	6372
3	25	1	Unknown	lgK:25.8 (3SF)	2	CRV	2556

Reaction No. 60732




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	Unknown	lgK:1.32 (3SF)	3	CRV	2556

Reaction No. 60733




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-25.87 (4SF)	4	CRV	32222
2	25	0	Inf. Dilution	lgK:-23.74 (4SF)	0	CRV	32224
3	25	1	Unknown	lgK:-31.15 (4SF)	4	CRV	2556
4	25	0	Inf. Dilution	dH:139.930 (6SF) kJ	4	CRV	32222

Reaction No. 60748



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:16.53 (4SF)	4	EBU	6372
2	25	1	Unknown	lgK:18.5 (3SF)	3	CRV	2556

Reaction No. 60749



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:23.43 (4SF)	4	EBU	6372
2	25	1	Unknown	lgK:26.0 (3SF)	3	CRV	2556

Reaction No. 61491

Pd+2_NTA-3 + Pd+2_OH-1_NTA-3 = Pd+2(2)_OH-1_NTA-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:3.1(2SF)	6	MGL	1562
2	25	0	Inf. Dilution	lgK:3.1(2SF)	1	ESC	

Reaction No. 61819							
Pd+2 + H+1_Asn-1 = Pd+2_H+1_Asn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO4	lgK:2.81(3SF)	6	CRV	552

Reaction No. 62709							
2<NTA-3> + Pd+2 = Pd+2_NTA-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	Unknown	lgK:23.7(3SF)	6	CRV	552
2	25	0	Inf. Dilution	lgK:23.8(3SF)	1	ESC	

Reaction No. 62710							
Pd+2_H+1_NTA-3 + H+1 = Pd+2_H+1(2)_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	Unknown	lgK:0.5(1SF)	6	CRV	552
2	25	0	Inf. Dilution	lgK:0.5(1SF)	1	ESC	

Reaction No. 64220							
Pd+2 + 3<H2O> = Pd+2_OH-1(3) + 3<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-6.45(3SF)	0	EBU	6372
2	25	0	Inf. Dilution	lgK:-15.400(0.20SD)	4	CRV	31301
3	25	0	Inf. Dilution	lgK:-15.93(4SF)	4	CRV	32222
4	25	0	Inf. Dilution	dH:54.863(5SF)kJ	4	CRV	32222

Reaction No. 64221							
Pd+2 + 4<H2O> = Pd+2_OH-1(4) + 4<H+1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-29.0(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-10.25(4SF)	0	EBU	6372
3	25	0	Inf. Dilution	lgK:-29.36(4SF)	4	CRV	32222
4	25	0	Inf. Dilution	dH:118.560(6SF)kJ	4	CRV	32222

Reaction No. 64222							
F-1 + Pd+2 = Pd+2_F-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.75 (3SF)	1	EBU	6372

Reaction No. 64223							
2<F-1> + Pd+2 = Pd+2_F-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.18 (4SF)	1	EBU	6372

Reaction No. 64224							
3<F-1> + Pd+2 = Pd+2_F-1 (3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.42 (4SF)	1	EBU	6372

Reaction No. 64225							
4<F-1> + Pd+2 = Pd+2_F-1 (4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:29.52 (4SF)	1	EBU	6372

Reaction No. 64226							
IO3-1 + Pd+2 = Pd+2_IO3-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.58 (3SF)	1	EBU	6372


Reaction No. 64227							
2<IO3-1> + Pd+2 = Pd+2_IO3-1 (2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.58 (3SF)	1	EBU	6372

Reaction No. 64228							
3<IO3-1> + Pd+2 = Pd+2_IO3-1 (3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.23 (2SF)	1	EBU	6372

Reaction No. 64229							
4<IO3-1> + Pd+2 = Pd+2_IO3-1 (4)							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.34 (3SF)	1	EBU	6372

Reaction No. 64230




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.91 (3SF)	1	EBU	6372
2	25	0	Inf. Dilution	lgK:2.91 (3SF)	1	CRV	32222

Reaction No. 64231




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.70 (3SF)	1	EBU	6372

Reaction No. 64232



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.93 (3SF)	1	EBU	6372

Reaction No. 64233




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.93 (2SF)	1	EBU	6372
2	25	0	Inf. Dilution	lgK:0.167 (0.012SD)	4	CRV	31301

Reaction No. 64234




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.41 (2SF)	1	EBU	6372
2	25	0	Inf. Dilution	lgK:-0.762 (0.02SD)	4	CRV	31301

Reaction No. 64235




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.30 (3SF)	1	EBU	6372

Reaction No. 64236




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-4.11(3SF)	1	EBU	6372

Reaction No. 64237




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.87(3SF)	1	EBU	6372

Reaction No. 64238




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.10(4SF)	1	EBU	6372

Reaction No. 64239




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.95(4SF)	1	EBU	6372

Reaction No. 64240




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:24.52(4SF)	1	EBU	6372

Reaction No. 64241




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.35(3SF)	1	EBU	6372

Reaction No. 64242



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.05(3SF)	1	EBU	6372

Reaction No. 64243



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.36(3SF)	1	EBU	6372

Reaction No. 64244							
$\text{Pd}+2 + 4\text{<H}+1(2)\text{_{PO4-3}} = \text{Pd}+2\text{_{H}+1(8)\text{_{PO4-3}}(4)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.37(3SF)	1	EBU	6372

Reaction No. 64245							
$\text{CO3-2} + \text{Pd}+2 = \text{Pd}+2\text{_{CO3-2}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.83(3SF)	1	EBU	6372
2	25	0	Inf. Dilution	lgK:6.83(3SF)	1	CRV	32222

Reaction No. 64246							
$2\text{<CO3-2>} + \text{Pd}+2 = \text{Pd}+2\text{_{CO3-2}}(2)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.53(4SF)	1	EBU	6372
2	25	0	Inf. Dilution	lgK:12.53(4SF)	1	CRV	32222

Reaction No. 64247							
$3\text{<CO3-2>} + \text{Pd}+2 = \text{Pd}+2\text{_{CO3-2}}(3)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:17.34(4SF)	1	EBU	6372

Reaction No. 64248							
$4\text{<CO3-2>} + \text{Pd}+2 = \text{Pd}+2\text{_{CO3-2}}(4)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.37(4SF)	1	EBU	6372

Reaction No. 64249							
$\text{Pd}+2 + \text{H}+1\text{_{CO3-2}} = \text{Pd}+2\text{_{H}+1\text{_{CO3-2}}}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.32(3SF)	1	EBU	6372

Reaction No. 64250							
$\text{Pd}+2 + 2\text{<H}+1\text{_{CO3-2}} = \text{Pd}+2\text{_{H}+1(2)\text{_{CO3-2}}(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.68(3SF)	1	EBU	6372

Reaction No. 64251							
--------------------	--	--	--	--	--	--	--

Pd+2 + 3<H+1_CO3-2> = Pd+2_H+1(3)_CO3-2(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.35(3SF)	1	EBU	6372

Reaction No. 64252							
Pd+2 + 4<H+1_CO3-2> = Pd+2_H+1(4)_CO3-2(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.41(3SF)	1	EBU	6372

Reaction No. 64253							
SCN-1 + Pd+2 = Pd+2_SCN-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.2(2SF)	1	EES	
2	25	0	Inf. Dilution	lgK:7.14(3SF)	0	EBU	6372
3	25	1	NaClO4	lgK:8.14(0.026SD)	5	MSP	30060
Note (3): Complex is given as Pd+2_SNC-1_H2O(3)							

Reaction No. 64254							
3<SCN-1> + Pd+2 = Pd+2_SCN-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:22.(2SF)	1	EES	
2	25	0	Inf. Dilution	lgK:18.03(4SF)	0	EBU	6372
3	25	1	NaClO4	lgK:21.94(0.096SD)	5	MSP	30060
Note (3): Complex is given as Pd+2_SCN-1(3)_H2O							

Reaction No. 64255							
2<Acetic-1> + Pd+2 = Pd+2_Acetic-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.61(3SF)	1	EBU	6372
2	25	0.92	NaClO4	lgK:8.0(2SF)	5	MSP	11516
Note (2): Yatsimirskii A et al., Izv. Akad. Nauk (USSR), 1976, 7, 1490							

Reaction No. 64256							
3<Acetic-1> + Pd+2 = Pd+2_Acetic-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.63(3SF)	1	EBU	6372

Reaction No. 64257							
4<Acetic-1> + Pd+2 = Pd+2_Acetic-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.98(3SF)	1	EBU	6372

Reaction No. 64258							
Benzoic-1 + Pd+2 = Pd+2_Benzoic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.14(3SF)	1	EBU	6372

Reaction No. 64259							
2<Benzoic-1> + Pd+2 = Pd+2_Benzoic-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.09(3SF)	1	EBU	6372

Reaction No. 64260							
3<Benzoic-1> + Pd+2 = Pd+2_Benzoic-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.10(3SF)	1	EBU	6372

Reaction No. 64261							
4<Benzoic-1> + Pd+2 = Pd+2_Benzoic-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.28(3SF)	1	EBU	6372


Reaction No. 64262							
Cat-2 + Pd+2 = Pd+2_Cat-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.47(4SF)	1	EBU	6372

Reaction No. 64263							
2<Cat-2> + Pd+2 = Pd+2_Cat-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:27.65(4SF)	1	EBU	6372

Reaction No. 64264							
Glycolic-1 + Pd+2 = Pd+2_Glycolic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:2.53 (3SF)	1	EBU	6372
2	25	1	NaClO4	lgK:3.81 (3SF)	3	MSP	16994

Reaction No. 64265




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.10 (3SF)	1	EBU	6372

Reaction No. 64266




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.96 (3SF)	1	EBU	6372

Reaction No. 64267




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.22 (3SF)	1	EBU	6372

Reaction No. 64268




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.81 (3SF)	1	EBU	6372

Reaction No. 64269




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.84 (3SF)	1	EBU	6372

Reaction No. 64270



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.21 (4SF)	1	EBU	6372

Reaction No. 64271



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.96 (4SF)	1	EBU	6372

Reaction No. 65521							
Pd+2 + CO3-2 = Pd+2_CO3-2_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.29(4SF)	4	EBU	6372

Reaction No. 65691							
5<CN-1> + Pd+2 = Pd+2_CN-1(5)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:55.(2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:45.3(3SF)	0	CRV	552
3	25	0	Inf. Dilution	dH:-92.5(3SF)	0	CRV	552

Reaction No. 65915							
4<S2O3-2> + Pd+2 = Pd+2_S2O3-2(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:32.63(4SF)	1	EOR	
2	25	0.5	Unknown	lgK:35.0(3SF)	6	CRV	552

Reaction No. 66133							
MeEDTA-4 + Pd+2 = Pd+2_MeEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0	Inf. Dilution	lgK:20.2(3SF)	3	CRV	552
2	20	0.1	Unknown	lgK:19.4(3SF)	4	CRV	552
3	20	0.1	Unknown	dH:-7.4(2SF)	6	CRV	552

Reaction No. 66134							
Pd+2_H+1_MeEDTA-4 + H+1 = Pd+2_H+1(2)_MeEDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Unknown	lgK:3.44(3SF)	4	CRV	552

Reaction No. 66857							
Pd+2_N3-1(2)_(alpha,s) = Pd+2 + 2<N3-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-8.57(3SF)	3	ENS	773

Reaction No. 67155							
F2(g) + Pd(s) = Pd+2_F-1(2)_(s)							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:74.16 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:73.66 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:53.28 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:41.07 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:32.95 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-101.2 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-112.0 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-111.8 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-111.6 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-111.4 (4SF)	4	MTD	6422

Reaction No. 67156							
I2(s) + Pd(s) = Pd+2_I-1(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.96 (4SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:12.44 (4SF)	2	ENS	6422
3	27	0	Inf. Dilution	lgK:12.37 (4SF)	0	ENS	6422
4	127	0	Inf. Dilution	lgK:9.530 (4SF)	2	ENS	6422
5	227	0	Inf. Dilution	lgK:7.012 (4SF)	0	ENS	6422
6	327	0	Inf. Dilution	lgK:4.884 (4SF)	0	ENS	6422
7	25	0	Inf. Dilution	dG:-11.5 (3SF) kJ	0	CRV	3006
8	25	0	Inf. Dilution	dG:-16.96 (4SF)	0	EFE	6422
9	25	0	Inf. Dilution	dH:-63.2 (3SF) kJ	0	CRV	3006
10	25	0	Inf. Dilution	dH:-15.11 (4SF)	0	MTD	6422
11	127	0	Inf. Dilution	dH:-19.09 (4SF)	0	MTD	6422
12	227	0	Inf. Dilution	dH:-29.38 (4SF)	0	MTD	6422
13	327	0	Inf. Dilution	dH:-29.0 (3SF)	0	MTD	6422

Reaction No. 67157							
Pd(s) + S(s) = Pd+2_S-2_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.69 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:11.61 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:8.512 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:6.575 (4SF)	1	ENS	6422

5	327	0	Inf. Dilution	lgK:5.253 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-67. (2SF) kJ	4	CRV	3006
7	25	0	Inf. Dilution	dG:-15.95 (4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dH:-75. (2SF) kJ	4	CRV	3006
9	25	0	Inf. Dilution	dH:-16.90 (4SF)	4	MTD	6422
10	127	0	Inf. Dilution	dH:-17.55 (4SF)	1	MTD	6422
11	227	0	Inf. Dilution	dH:-17.98 (4SF)	0	MTD	6422
12	327	0	Inf. Dilution	dH:-18.29 (4SF)	0	MTD	6422

Reaction No. 67158							
Pd(s) + 2<S(s)> = Pd+4_S-2(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:12.97 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:12.89 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:9.448 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:7.241 (4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:5.714 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-74.5 (3SF) kJ	4	CRV	3006
7	25	0	Inf. Dilution	dG:-17.70 (4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dH:-81.2 (3SF) kJ	4	CRV	3006
9	25	0	Inf. Dilution	dH:-18.70 (4SF)	4	MTD	6422
10	127	0	Inf. Dilution	dH:-19.88 (4SF)	1	MTD	6422
11	227	0	Inf. Dilution	dH:-20.66 (4SF)	0	MTD	6422
12	327	0	Inf. Dilution	dH:-21.23 (4SF)	0	MTD	6422

Reaction No. 67159							
4<Pd(s)> + S(s) = Pd4S(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.96 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:11.88 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:8.839 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:6.920 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:5.600 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-67. (2SF) kJ	4	CRV	3006
7	25	0	Inf. Dilution	dG:-16.31 (4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dH:-67. (2SF) kJ	4	CRV	3006

9	25	0	Inf. Dilution	dH:-16.50 (4SF)	4	MTD	6422
10	127	0	Inf. Dilution	dH:-17.31 (4SF)	4	MTD	6422
11	227	0	Inf. Dilution	dH:-17.90 (4SF)	4	MTD	6422
12	327	0	Inf. Dilution	dH:-18.34 (4SF)	0	MTD	6422

Reaction No. 67160							
Pd(s) + Te(s) = Pd+2_Te-2_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.717 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:6.677 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:5.036 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:4.046 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:3.380 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-9.16 (3SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-9.00 (3SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-9.03 (3SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-9.10 (3SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-9.10 (3SF)	4	MTD	6422

Reaction No. 67930							
Pd+2_Dien_Cl-1_Uridine-1 = Pd+2_Dien_Cl-1 + Uridine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:7.42 (0.02SD)w	5	MPH	7159


Reaction No. 67931							
Pd+2_Terpy_Cl-1_Uridine-1 = Pd+2_Terpy_Cl-1 + Uridine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:7.56 (0.02SD)w	5	MPH	7159

Reaction No. 67932							
Pd+2_Dien_9MeAdenine-1_Cl-1 = Pd+2_Dien_Cl-1 + 9MeAdenine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:4.6 (0.03SD)w	5	MPH	7159

Reaction No. 67933							
Pd+2_Terpy_9MeAdenine-1_Cl-1 = Pd+2_Terpy_Cl-1 + 9MeAdenine-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0.2	KNO3	lgK:2.4(0.1SD)w	5	MPH	7159
---	----	-----	------	-----------------	---	-----	------

Reaction No. 67934




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:6.8(0.03SD)w	5	MPH	7159

Reaction No. 67935




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:6.8(0.06SD)w	5	MPH	7159

Reaction No. 67936




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:12.8(0.1SD)w	5	MPH	7159

Reaction No. 67937




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:6.9(0.06SD)w	5	MPH	7159

Reaction No. 67938




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:12.1(0.1SD)w	5	MPH	7159

Reaction No. 67939



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:6.45(0.02SD)w	5	MPH	7159

Reaction No. 67940



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:6.0(0.03SD)w	5	MPH	7159

Reaction No. 67942

Pd+2_Dien_Cl-1_NAcHis-1 = Pd+2_Dien_Cl-1 + NAcHis-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:6.9(0.03SD)w	5	MPH	7159

Reaction No. 67943							
Pd+2_H+1_Dien_Cl-1_NAcHis-1 = Pd+2_Dien_Cl-1 + NAcHis-1 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:9.7(0.05SD)w	5	MPH	7159

Reaction No. 67944							
Pd+2_Terpy_Cl-1_NAcHis-1 = Pd+2_Terpy_Cl-1 + NAcHis-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:6.33(0.02SD)w	5	MPH	7159

Reaction No. 67945							
Pd+2_Dien_Cl-1 + OH-1 = Pd+2_Dien_OH-1 + Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:5.58(3SF)w	5	MPH	7159

Reaction No. 67946							
Pd+2_Terpy_Cl-1 + OH-1 = Pd+2_Terpy_OH-1 + Cl-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.2	KNO3	lgK:6.01(3SF)w	5	MPH	7159

Reaction No. 68273							
2<Pd+2_Cl-1(4)> + [18]N6 = Pd+2(2)_[18]N6_Cl-1(2) + 6<Cl-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	dH:-26.5(0.05SD)	4	MCL	6878

Reaction No. 68274							
2<Pd+2_Cl-1(4)> + [21]N7 = Pd+2(2)_[21]N7_Cl-1 + 7<Cl-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	dH:-28.5(0.05SD)	4	MCL	6878

Reaction No. 68275							
2<Pd+2_Cl-1(4)> + [24]N8 = Pd+2(2)_[24]N8 + 8<Cl-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	dH:-28.4(0.03SD)	4	MCL	6878

Reaction No. 68276							
$2\text{<Pd+2>} + [24]\text{N8} = \text{Pd+2(2)}_{-}[24]\text{N8}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	NaCl	dH:-51.6(3SF)	4	MCL	6878

Reaction No. 72246							
$\text{Pd+2} + 3\text{<Cl-1>} + \text{OH-1} = \text{Pd+2_Cl-1(3)}_{-}\text{OH-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5:1	HClO4	lgK:16.12(4SF)	5	ENS	4282

Reaction No. 72247							
$\text{Pd+2} + 2\text{<Cl-1>} + 2\text{<OH-1>} = \text{Pd+2_Cl-1(2)}_{-}\text{OH-1(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5:1	HClO4	lgK:19.66(4SF)	4	ENS	4282

Reaction No. 72248							
$\text{Pd+2} + \text{Cl-1} + 3\text{<OH-1>} = \text{Pd+2_Cl-1_OH-1(3)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5:1	HClO4	lgK:23.23(4SF)	4	ENS	4282

Reaction No. 72705							
$\text{Pd+2_Br-1(4)} + 4\text{<CN-1>} = \text{Pd+2_CN-1(4)} + 4\text{<Br-1>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaCl	dH:-78.8(0.2SD)	4	MCL	5882

Reaction No. 72940							
$\text{Pd+2_Se-2(s)} = \text{Pd+2} + \text{Se-2}$							
Note: The Se-2 species probably does not exist [18Mar_30641]							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-73.4(3SF)	2	ENS	12931

Reaction No. 73880							
$\text{Pd+2_S-2(s)} + \text{H+1} = \text{Pd+2} + \text{H+1_S-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-44.8(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-44.8(3SF)	0	CRV	5081
3	25	0	Inf. Dilution	lgK:-46.86(1.32SD)	0	CRV	32222

4	25	0	Inf. Dilution	dH:244.290 (7.157SD)kJ	2	CRV	32222
---	----	---	---------------	------------------------	---	-----	-------

Reaction No. 74180							
$\text{Pd+4_K+1(2)_Cl-1(6)_(s)} = 2\text{<K+1>} + \text{Pd+4_Cl-1(6)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-5.23(3SF)	4	CRV	22551

Reaction No. 74205							
$\text{PdO2(s)} + 2\text{<e-1>} + 4\text{<H+1>} = \text{Pd+2} + 2\text{<H2O>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:1.194(4SF)	2	CRV	22551

Reaction No. 74206							
$\text{Pd+4_Br-1(6)} + 2\text{<e-1>} = \text{Pd+2_Br-1(4)} + 2\text{<Br-1>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KBr	E:0.99(2SF)	3	CRV	22551

Reaction No. 74207							
$\text{Pd+4_I-1(6)} + 2\text{<e-1>} = \text{Pd+2_I-1(4)} + 2\text{<I-1>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:18.1(3SF)	1	EOR	
2	25	1	KI	E:0.48(2SF)	3	CRV	22551

Reaction No. 74208							
$\text{PdO(s)} + 2\text{<e-1>} + 2\text{<H+1>} = \text{Pd(s)} + \text{H2O}$							
Note: "Divergent values have been obtained" [85BPJ_3006] The 0.917V and 0.79 V data are noted but no preference given.							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:0.917(3SF)	0	CRV	22551
Note (1): "calculated"							
2	25	0	Inf. Dilution	E:0.79(2SF)	1	CRV	22551
Note (2): "measured"							

Reaction No. 74209							
$\text{Pd+2_Br-1(4)} + 2\text{<e-1>} = \text{Pd(s)} + 4\text{<Br-1>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	KBr	E:0.49(2SF)	5	CRV	22551
Note (1): Value confirmed p. 343 Bard et al. [85BPJ_3006]							

Reaction No. 74210							
$\text{Pd}+2_{\text{I}-1}(4) + 2\text{e-1} = \text{Pd(s)} + 4\text{I-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.5 (2SF)	1	EOR	
2	25	1	KI	E:0.18 (2SF)	4	CRV	22551
Note (2): Value confirmed p. 343 Bard et al. [85BPJ_3006]							

Reaction No. 74283							
$\text{Pd(s)} = \text{Pd(g)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:339.7 (4SF) kJ	5	CRV	3006
2	25	0	Inf. Dilution	dH:378.2 (4SF) kJ	5	CRV	3006

Reaction No. 74284							
$0.5\text{O}_2(\text{g}) + \text{Pd(s)} = \text{PdO(g)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:325.9 (4SF) kJ	5	CRV	3006
2	25	0	Inf. Dilution	dH:348.9 (4SF) kJ	5	CRV	3006

Reaction No. 74302							
$1.5\text{Br}_2(\text{l}) + \text{Pd(s)} + \text{e-1} = \text{Pd}+2_{\text{Br}-1}(3)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-204.2 (4SF) kJ	4	CRV	3006


Reaction No. 74303							
$2\text{Br}_2(\text{l}) + \text{Pd(s)} + 2\text{e-1} = \text{Pd}+2_{\text{Br}-1}(4)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-318.0 (4SF) kJ	4	CRV	3006
2	25	0	Inf. Dilution	dH:-384.9 (4SF) kJ	4	CRV	3006

Reaction No. 74304							
$3\text{Br}_2(\text{l}) + \text{Pd(s)} + 2\text{e-1} = \text{Pd}+4_{\text{Br}-1}(6)$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-335.1 (4SF) kJ	4	CRV	3006

Reaction No. 74305							
$2\text{I}_2(\text{s}) + \text{Pd(s)} + 2\text{e-1} = \text{Pd}+2_{\text{I}-1}(4)$							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:29.8(3SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-159.0(4SF)kJ	0	CRV	3006

Reaction No. 74306




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-170.3(4SF)kJ	4	CRV	3006

Reaction No. 74307




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-210.3(4SF)kJ	4	CRV	3006
2	25	0	Inf. Dilution	dH:-370.3(4SF)kJ	4	CRV	3006

Reaction No. 74308




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-49.8(3SF)	1	ELC	
2	25	0	Inf. Dilution	dG:289.(3SF)kJ	0	CRV	3006

Reaction No. 74309




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-97.8(3SF)	1	ELC	
2	25	0	Inf. Dilution	dG:628.(3SF)kJ	0	CRV	3006

Reaction No. 74310



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-41.1(3SF)	1	ELC	
2	25	0	Inf. Dilution	dG:243.3(4SF)kJ	0	CRV	3006

Reaction No. 74311



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:314.3(4SF)kJ	0	CRV	3006

Reaction No. 74312							
$4\text{C(s)} + 2\text{N}_2\text{(g)} + \text{Pd(s)} + 4\text{S(s)} + 2\text{e-1} = \text{Pd+2_SCN-1(4)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-71.0(3SF)	1	ELC	
2	25	0	Inf. Dilution	dG:410.5(4SF) kJ	0	CRV	3006

Reaction No. 74313							
$\text{C(s)} + \text{I}_2\text{(s)} + 0.5\text{N}_2\text{(g)} + \text{Pd(s)} + \text{S(s)} + \text{e-1} = \text{Pd+2_I-1(2)_SCN-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:23.9(3SF) kJ	4	CRV	3006

Reaction No. 74314							
$\text{Pd+2_OH-1(2)_(s)} + 2\text{H+1} + 2\text{e-1} = \text{Pd(s)} + 2\text{H}_2\text{O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:30.5(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.897(3SF)	0	CRV	3006

Reaction No. 74530							
$\text{Pd+2_NO}_2\text{-1(4)} + 2\text{e-1} = \text{Pd(s)} + 4\text{NO}_2\text{-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.5	KNO2	E:0.34(2SF)	4	EOD	3006

Reaction No. 74531							
$\text{Pd+2_NH}_3\text{(4)} + 2\text{e-1} = \text{Pd(s)} + 4\text{NH}_3$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.4(2SF)	1	ELC	
2	25	1	NH4+ salt	E:0.0(1SF)	0	EOD	3006
Note (2): p. 344							

Reaction No. 74532							
$\text{Pd+2_SO}_4\text{-2(2)} + 2\text{e-1} = \text{Pd(s)} + 2\text{SO}_4\text{-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:26.9(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.82(0.01SD)	0	EOD	3006
Note (2): p. 344							

Reaction No. 75642							
--------------------	--	--	--	--	--	--	--

Pd+2_Leu-1 + Leu-1 = Pd+2_Leu-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:8.23(3SF)	3	MGL	11516
Note (1): Kollmann J et al., J. Prakt. Chem., 1974, 316, 119							

Reaction No. 75648							
Pd+2_Ile-1 + Ile-1 = Pd+2_Ile-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:8.44(3SF)	5	MGL	11516
Note (1): Kollmann J et al., J. Prakt. Chem., 1974, 316, 119							

Reaction No. 75658							
Pd+2_Pro-1 + Pro-1 = Pd+2_Pro-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:8.84(3SF)	5	MGL	11516
Note (1): Kollmann J et al., J. Prakt. Chem., 1974, 316, 119							

Reaction No. 75659							
Pd+2 + 2<Pro-1> = Pd+2_Pro-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:19.10(4SF)	5	MGL	11516
Note (1): Kollmann J et al., J. Prakt. Chem., 1974, 316, 119							

Reaction No. 75667							
Pd+2_Alal-1 + Alal-1 = Pd+2_Alal-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:8.35(3SF)	3	MGL	11516
Note (1): Kollmann J et al., J. Prakt. Chem., 1974, 316, 119							

Reaction No. 75675							
Pd+2_bAlal-1 + bAlal-1 = Pd+2_bAlal-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:7.06(3SF)	5	MGL	11516
Note (1): Kollmann J et al., J. Prakt. Chem., 1974, 316, 119							
2	25	0	Inf. Dilution	lgK:7.3(2SF)	1	EAE	

Reaction No. 75688							
--------------------	--	--	--	--	--	--	--

Pd+2_Phe-1 + Phe-1 = Pd+2_Phe-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:8.95(3SF)	5	MGL	11516
Note (1): Kollmann J et al., J. Prakt. Chem., 1974, 316, 119							

Reaction No. 75689							
Pd+2 + 2<Phe-1> = Pd+2_Phe-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:18.27(4SF)	5	MGL	11516
Note (1): Kollmann J et al., J. Prakt. Chem., 1974, 316, 119							

Reaction No. 75807							
Pd+2 + 2<Glu-2> = Pd+2_Glu-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:17.84(4SF)	5	MGL	6628

Reaction No. 75837							
Pd+2 + 2<Asp-2> = Pd+2_Asp-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:18.14(4SF)	5	MGL	6628
2	30	0.1	KNO3	lgK:18.25(4SF)	4	MGL	5662

Reaction No. 75899							
Citric-3 + Pd+2 = Pd+2_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.257(4SF)	1	EOR	
2	25	1	NaClO4	lgK:3.46(3SF)	5	MKN	11516
Note (2): Shi T et al., Inorg. Chem., 1997, 36, 528							

Reaction No. 75988							
Pd+2 + Malic-2 = Pd+2_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:3.65(3SF)	5	MKN	11516
Note (1): Shi T et al., Inorg. Chem., 1997, 36, 528							

Reaction No. 76105							
Pd+2 + Hyp-1 = Pd+2_Hyp-1							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:9.88(3SF)	5	MGL	11516
Note (1): Kollmann J et al., J. Prakt. Chem., 1974, 316, 119							

Reaction No. 76106							
Pd+2_Hyp-1 + Hyp-1 = Pd+2_Hyp-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:9.57(3SF)	5	MGL	11516
Note (1): Kollmann J et al., J. Prakt. Chem., 1974, 316, 119							

Reaction No. 76107							
Pd+2 + 2<Hyp-1> = Pd+2_Hyp-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.5	KNO3	lgK:19.45(4SF)	5	MGL	11516
Note (1): Kollmann J et al., J. Prakt. Chem., 1974, 316, 119							

Reaction No. 76172							
Pd+2 + Succinic-2 = Pd+2_Succinic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:4.03(3SF)	5	MKN	11516
Note (1): Shi T et al., Inorg. Chem., 1997, 36, 528							

Reaction No. 76229							
Pd+2 + 2<H+1_Gly-1> = Pd+2_H+1(2)_Gly-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	Unknown	lgK:8.2(2SF)	3	CRV	7271
2	25	0	Inf. Dilution	lgK:8.2(2SF)	1	EES	7271

Reaction No. 76311							
Pd+2 + Malonic-2 = Pd+2_Malonic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:3.40(3SF)	5	MKN	11516
Note (1): Shi T et al., Inorg. Chem., 1997, 36, 528							

Reaction No. 76372							
Pd+2 + Butanoic-1 = Pd+2_Butanoic-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	1	NaClO ₄	lgK:4.38 (3SF)	5	MKN	11516
Note (1): Shi T et al., Inorg. Chem., 1997, 36, 528							

Reaction No. 77385							
Pd+2_H+1_DiMeGlyox-2(2) + H+1 = Pd+2_H+1(2)_DiMeGlyox-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:5.50 (3SF)	3	CRV	7271

Reaction No. 78620							
Gly-1 + EtDiAm + Pd+2 = Pd+2_EtDiAm_Gly-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8 (4SF)	1	ELC	

Reaction No. 78833							
PO4-3 + Pd+2 + H+1 = Pd+2_H+1_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.2 (4SF)	1	ELC	

Reaction No. 78834							
2<PO4-3> + Pd+2 + 2<H+1> = Pd+2_H+1(2)_PO4-3(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:37.75 (4SF)	1	ELC	

Reaction No. 78835							
3<PO4-3> + Pd+2 + 3<H+1> = Pd+2_H+1(3)_PO4-3(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:55.93 (4SF)	1	ELC	

Reaction No. 78836							
4<PO4-3> + Pd+2 + 4<H+1> = Pd+2_H+1(4)_PO4-3(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:73.83 (4SF)	1	ELC	

Reaction No. 78837							
PO4-3 + Pd+2 + 2<H+1> = Pd+2_H+1(2)_PO4-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:21.87 (4SF)	1	ELC	

Reaction No. 78838							
$2\text{<PO4-3>} + \text{Pd+2} + 4\text{<H+1>} = \text{Pd+2_H+1(4)_PO4-3(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:43.09(4SF)	1	ELC	

Reaction No. 78839							
$3\text{<PO4-3>} + \text{Pd+2} + 6\text{<H+1>} = \text{Pd+2_H+1(6)_PO4-3(3)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:63.92(4SF)	1	ELC	

Reaction No. 78840							
$4\text{<PO4-3>} + \text{Pd+2} + 8\text{<H+1>} = \text{Pd+2_H+1(8)_PO4-3(4)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:84.45(4SF)	1	ELC	

Reaction No. 79011							
$\text{S-2} + \text{Pd+2} = \text{Pd+2_S-2(s)}$							
Note: The species S-2 does not exist in aqueous solution See reaction: $\text{H+1} + \text{S-2} = \text{H+1_S-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:58.0(3SF)	0	ELC	

Reaction No. 79290							
$2\text{<Gly-1>} + \text{Pd+2} + 2\text{<H+1>} = \text{Pd+2_H+1(2)_Gly-1(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:27.79(4SF)	1	ELC	

Reaction No. 79291							
$\text{Gly-1} + \text{Pd+2} + \text{H+1} = \text{Pd+2_H+1_Gly-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:15.2(4SF)	1	ELC	

Reaction No. 79535							
$\text{Pd+2_SCN-1(2)_(s)} = \text{Pd+2} + 2\text{<SCN-1>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-22.36(4SF)	3	CRV	6330
Note (1): p. 8-58							

Reaction No. 79536							
$\text{Pd+2_S-2_ (s)} + 2\text{<H+1>} = \text{Pd+2} + \text{H+1(2)_S-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-37.9(3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:-36.7(3SF)	0	CRV	6330
Note (2): p. 8-58							

Reaction No. 80083							
$5\text{<SCN-1>} + \text{Pd+2} = \text{Pd+2_SCN-1(5)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:32.0(3SF)	1	EES	
2	25	1	NaClO4	lgK:31.94(0.277SD)	5	MSP	30060

Reaction No. 80619							
$\text{Pd+2} + \text{NO3-1} + \text{H2O} = \text{Pd+2_NO3-1_OH-1} + \text{H+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.650(0.018SD)	1	CRV	31301
Note (1): rxn not balanced in source							

Reaction No. 80999							
$\text{Pd+2} + \text{H+1_Se-2} = \text{Pd+2_Se-2_ (s)} + \text{H+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:59.40(4SF)	3	EOD	32222

Reaction No. 81055							
$\text{Pd+2} + \text{H2O} = \text{PdO(s)} + 2\text{<H+1>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:4.4(2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:6.02(3SF)	0	CRV	32222
3	25	0	Inf. Dilution	dH:10.547(3.099SD) kJ	2	CRV	32222

Reaction No. 81056							
$\text{Pd+2} + 3\text{<Cl-1>} + \text{H2O} = \text{Pd+2_Cl-1(3)_OH-1} + \text{H+1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.31(3SF)	4	CRV	32222

Reaction No. 81057							
--------------------	--	--	--	--	--	--	--

Pd+2 + 2<Cl-1> = Pd+2_Cl-1(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.20(3SF)	4	CRV	32222
2	25	0	Inf. Dilution	lgK:6.86(3SF)	0	CRV	32224
3	25	0	Inf. Dilution	dH:-54.423(3.105SD)kJ	4	CRV	32222

Reaction No. 81058							
Pd+2 + 2<Br-1> = Pd+2_Br-1(2)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:13.31(4SF)	4	CRV	32222
2	25	0	Inf. Dilution	dH:-51.263(3.113SD)kJ	4	CRV	32222

Reaction No. 81550							
Pd+2_S-2_(s) + 4<H2O> = Pd+2 + SO4-2 + 8<H+1> + 8<e-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-78.40(4SF)	4	CRV	32224

Reaction No. 81551							
Pd+4_S-2(2)_(s) + 8<H2O> = Pd+2 + 2<SO4-2> + 16<H+1> + 14<e-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-115.46(5SF)	4	CRV	32224

Reaction No. 81552							
Pd4S(s) + 4<H2O> = 4<Pd+2> + SO4-2 + 8<H+1> + 14<e-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-171.22(5SF)	4	CRV	32224

Reaction No. 81553							
Pd+4_Br-1(6) + 2<e-1> = Pd+2 + 6<Br-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:19.67(4SF)	4	CRV	32224

Reaction No. 81554							
Pd+4_I-1(6) + 2<e-1> = Pd+2 + 6<I-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-6.20(3SF)	4	CRV	32224

Data Assessment

Weight	Assessment
9	highest accuracy
8	multi-determined; excellent dependability
7	trustworthy; outstanding single determination
6	better than average reliability
5	average single determination
4	some doubt
3	poorly known
2	guess to achieve consistency (or just as bad)
1	no information but consistent
0	problematic/inconsistent

Techniques

Abbrev	Method
CMN	Several experimental values (crit.)
CRV	Critical review
CSM	Smith & Martell Vols 1-6 (crit.)
EAE	Automated extrapolation
EBU	Brown's Unified Theory
EDH	Debye-Hueckel corrections
EES	Personal estimate
EFE	Free Energy relations
ELC	Linear Combination of Reactions
EMU	Method unknown
ENS	Not specified
EOD	Calculated from data of others
EOR	Other Reaction Constants
ESC	Standard conditions anchor
MCL	Calorimetry
MCO	Colorimetry (often for measuring pH)
MDG	Combination of Thermodynamic Data

MDS	Distribution between two phases
MEF	Electromotoric force, not specified
MFL	Fluorescence
MGL	Glass electrode
MIS	Ion selective electrode
MIX	Ion exchange
MKN	Rate of reaction
MLC	Ligand competition
MMR	Nuclear magnetic resonance
MMX	Mixed techniques
MPH	pH method, not specified
MPL	Polarography
MPS	Potentiometry and Spectrophotometry
MPT	Potentiometry
MRX	Emf with redox electrode
MSC	Miscellaneous
MSL	Solubility
MSP	Spectroscopy
MTD	Temperature difference
MVP	Vapour phase osmometry

References

Reference No.: 8(76SmM)

Critical Stability Constants, Vol. 4, 1976 Smith RM; Martell AE; Plenum, New York

Reference No.: 136(55McK)

J. Am. Chem. Soc., 1955, 77, 6149 - 6151; McNevin WM; Kriedge OH; Reactions of Divalent Palladium with Ethylenediaminetetraacetic Acid

Reference No.: 140(64SiM)

Stability Constants of Metal-ion Complexes SP17, 1964 Sillen LG; Martell AE; The Chemical Soc., London

Reference No.: 148(84Pao)

Pure Appl. Chem., 1984, 56, 491 - 522; Paoletti P; Formation of Metal Complexes with Ethylenediamine: a Critical Survey of Equilibrium Constants, Enthalpy and Entropy Values

Reference No.: 222(87Bec)

Pure Appl. Chem., 1987, 59, 1703 - 1720; Beck MT; Critical Survey of Stability Constants of Cyano Complexes

Reference No.: 552(95SMM)

NIST Critical Stability Constants of Metal Complexes Database, 1995 Smith RM; Martell AE; Motekaitis RJ; Version 2.0; National Institute of Standards and Technology, Gaithersburg, USA

Reference No.: 600(52Lat)

The Oxidation States of the Elements, 2nd Edn, 1952 Latimer WM; and their Potentials in Aqueous Solutions; Prentice-Hall Inc., New York, USA

Reference No.: 684(94LOY)

Inorg. Chim. Acta, 1994, 219, 107 - 114; Lomozik L; Odani A; Yamauchi O; Spectroscopic Studies on Complex Formation and Non-covalent Interactions in Ternary Palladium(II) Systems Involving Spermidine and 2,3-Diaminopropionate or 2,4-Diaminobutyrate

Reference No.: 773(85KoS)

Handbook of Chemical Equilibria in Analytical Chemistry, 1985 Kotrly S; Sucha L; Ellis Horwood Series in Anal. Chem.; Eds. Chalmers RA & Masson M; Ellis Horwood, Chichester

Reference No.: 775(71CCM)

Selected Constants, 1971 Charlot G; Collumeau A; Marchon MJC; Oxidation-Reduction Potentials of Inorganic Substances in Aqueous Solution; Butterworths, London

Reference No.: 802(90Wea)

CRC Handbook of Chemistry and Physics, 70th Edn., 1990 Weast RC; A Ready-Reference Book of Chemical and Physical Data; CRC Press, Cleveland, Ohio

Reference No.: 827(70NaK)

Russ. J. Inorg. Chem., 1970, 15, 818 - 821; Nabivanets BI; Kalabina LV; State of Palladium(II) in Perchlorate Solutions

Reference No.: 828(70IEM)

J. Chem. Soc. (A), 1970,, 2514 - 2515; Izatt RM; Eatough DJ; Morgan CE; Half Cell Potential of the Pd, Pd+2 Couple in 3.94m Perchloric Acid and the Entropy of Pd+2(aq)

Reference No.: 829(68LMV)

Izv. Akad. Nauk SSSR, Ser. Khim., 1968,, 2368 - 2370; Levanda OG; Moiseev II; Vargaftig MN; Potentiometric Study of Palladium(II) Complexing with Chloride Ions

Reference No.: 830(43TWG)

J. Am. Chem. Soc., 1943, 65, 1608 - 1612; Templeton DH; Watt GW; Garner CS; The Formal Electrode Potentials of Palladium in Aqueous Hydrochloric and Perchloric Acid Solutions. Stability of Chloropalladidite Ion

Reference No.: 831(67IEC)

J. Chem. Soc. (A), 1967,, 1301 - 1304; Izatt RM; Eatough DJ; Christensen JJ; A Study of Pd+2(aq). Hydrolysis Constants and the Standard Potential for the Pd, Pd+2 Couple

Reference No.: 832(72Eld)

Inorg. Chim. Acta, 1972, 6, 647 - 651; Elding LI; Palladium(II) Halide Complexes. I. Stabilities and Spectra of Palladium(II) Chloro and Bromo Aqua Complexes

Reference No.: 834(57DBF)

J. Phys. Chem., 1957, 61, 1000 - 1004; Droll HA; Block BP; Fernelius WC; Studies on Coordination Compounds. XV. Formation Constants for Chloride and Acetylacetonate Complexes of Palladium(II)

Reference No.: 835(64BiS)

Zh. Neorg. Khim., 1964, 9, 813 - 816; Biryukov AA; Shlenskaya VI; Composition and Stability Constants of Bivalent Palladium Chloride Complexes

Reference No.: 836(64Bur)

Acta Chim. Hung., 1964, 40, 261 - 273; Burger K; Complexes of Palladium(II) Chloride. Determination of the Successive Stability Constants

Reference No.: 838(70RGS)

Talanta, 1970, 17, 807 - 816; Rittner WF; Gulko A; Schmuckler G; Interaction of Palladium with Sulfaguanidine

Reference No.: 839(71KrM)

Zh. Neorg. Khim., 1971, 16, 858 - 860; Kravtsov VI; Martynova LB; Potentiometric Study of the Stability of Palladium(II) Chloride Complexes Using the $PtCl_6^{2-}/PtCl_4^{2-}$ System

Reference No.: 840(73Eld)

Inorg. Chim. Acta, 1973, 7, 581 - 588; Elding LI; Palladium(II) Halide Complexes. III. Acid Hydrolysis and Halide Anations of cis- and trans-Dichlorodiaquapalladium(II) and - Dibromodiaquapalladium(II)

Reference No.: 842(65FKS)

Zh. Neorg. Khim., 1965, 10, 1338 Fasman AB; Kutjukov GG; Sokolskii DV; Reactivity of Complex Compounds of Palladium(II) in Aqueous Solution

Reference No.: 843(42GrS)

Zh. Obshch. Khim., 1942, 12, 55 - 72; Grinberg AA; Shamslev AS; Oxidation-reduction Potentials of Compounds of Platinum Metals. III

Reference No.: 869(68GoH)

Chem. Rev., 1968, 68, 229 - 252; Goldberg RN; Hepler LG; Thermochemistry and Oxidation Potentials of the Platinum Group Metals and their Compounds

Reference No.: 903(77And)

Critical Survey of Stability Constants of EDTA Complexes, 1977 Anderegg G; IUPAC Chemical Data Series. 14; Pergamon Press, Oxford

Reference No.: 905(95Ber)

Pure Appl. Chem., 1995, 67, 1117 - 143; Berthon G; Critical Review of Formation Constants of Selected Amino Acids with Polar Side Chains

Reference No.: 906(79Per)

IUPAC Chemical Data Series No. 22, 1979 Perrin DD; Stability Constants of Metal-Ion Complexes, First Edition Part B, Organic Ligands; Pergamon, Oxford

Reference No.: 931(71SiM)

Stability Constants of Metal-ion Complexes SP25, 1971 Sillen LG; Martell AE; Supplement No 1 to Special Publication No 25; Chemical Society, London

Reference No.: 999(91MaM)

Estimation of Constants for JESS Database, 1991 May PM; May RF

Reference No.: 1118(82And)

Pure Appl. Chem., 1982, 54, 2693 - 2758; Anderegg G; Critical Survey of Stability Constants of NTA Complexes

Reference No.: 1170(86CCM)

Polyhedron, 1986, 5, 1777 - 1784; Coello J; Cassou SH; Martinez HI; Stability Constants of Palladium(II) Complexes with Thio- and Dithiodiacids

Reference No.: 1180(87CaM)

Polyhedron, 1987, 6, 447 - 453; Cassou SH; Martinez HI; Stability Constants of the Ternary Complexes of Palladium(II) with Thiodipropionic Acid and Chloride Ion

Reference No.: 1210(90IWJ)

Inorg. Chem., 1990, 29, 3828 - 3832; Izatt RM; Wu G; Jiang W; Dalley NK; Interactions in Aqueous Solution at 25 C of Palladium(II) and Mercury(II) with 1,4-Dithia-18-crown-6 and 1,10-Dithia-18-crown-6. A Thermodynamic, Spectral and X-ray Crystallographic Study

Reference No.: 1309(81SSM)

J. Am. Chem. Soc., 1981, 103, 6833 - 6839; Scheller KH; Scheller-Krattiger V; Martin RB; Equilibria in Solutions of Nucleosides, 5'-Nucleotides, and dienPd+2

Reference No.: 1388(74SuM)

Chem. Rev., 1974, 74, 471 - 517; Sundberg RJ; Martin B; Interactions of Histidine and Other Imidazole Derivatives with Transition Metal Ions in Chemical and Biological Systems

Reference No.: 1414(81Lim)

J. Inorg. Nucl. Chem., 1981, 43, 221 - 223; Lim M-C; Mixed-Ligand Complexes of Pd(II) - IV. Aqua (Diethylenetriamine)Palladium and Diaqua (Ethylenediamine)Palladium Complexes of Uracil, Uridine and Thymidine

Reference No.: 1504(81Lim)

Inorg. Chem., 1981, 20, 1377 - 1379; Lim M-C; Mixed-Ligand Complexes of Palladium. 5. Diaqua(ethylenediamine)palladium(II) Complexes of Ethanolamine, L-Serine, L-Threonine, L-Homoserine, and L-Hydroxyproline

Reference No.: 1537(91GLC)

Polyhedron, 1991, 10, 333 - 336; Ganadu ML; Leoni V; Crisponi G; Nurchi V; An Investigation on the Interaction between Palladium(II) and L-Citrulline by ¹H and ¹³C NMR Spectroscopy and Potentiometry

Reference No.: 1539(78Kra)

Atlas of Metal-Ligand Equilibria in Aqueous Solution, 1978 Kragten J; Ellis Horwood, Chichester UK

Reference No.: 1555(91KSG)

Pure Appl. Chem., 1991, 63, 597 - 638; Kiss T; Sovago I; Gergely A; Critical Survey of Stability Constants of Complexes of Glycine

Reference No.: 1562(76AnM)

Helv. Chim. Acta, 1976, 59, 1498 - 1511; Anderegg G; Malik SC; Komplexe XLVII. The Stability of Palladium(II) Complexes with Aminopolycarboxylate Anions

Reference No.: 1594(78Kra)

Talanta, 1978, 25, 239 - 240; Kragten J; The Stability Constant of Pd-EDTA

Reference No.: 1599(80RZI)

Talanta, 1980, 27, 715 - 719; Rizkalla EN; Zaki MTM; Ismail MI; Metal Chelates of Phosphonate-containing Ligands - V Stability of Some 1-Hydroxyethane-1,1-Diphosphonic Acid Metal Chelates

Reference No.: 1604(74GrW)

J. Chem. Soc., Dalton Trans., 1974,, 1123 - 1125; Graham RD; Williams DR; Thermodynamic Considerations in Co-ordination. Part XVII. Chloride Electrode Studies of Carcinostatic Ternary and Quaternary Complexes of Nickel(II) and Palladium(II) Ions with Asparaginate and Chloride Ligands

Reference No.: 1629(77Lim)

J. Chem. Soc., Dalton Trans., 1977,, 15 - 17; Lim M-C; Mixed-ligand Complexes of Palladium(II). Part 1. Diaqua(ethylenediamine)palladium(II) Complexes of Glycylglycine and Glycinamide

Reference No.: 1640(77Lim)

J. Chem. Soc., Dalton Trans., 1977,, 1398 - 1400; Lim M-C; Mixed-ligand Complexes of Palladium(II). Part 2. Diaqua(ethylenediamine)palladium(II) Complexes of L-Asparagine and L-Glutamine

Reference No.: 1651(78Lim)

J. Chem. Soc., Dalton Trans., 1978,, 726 - 728; Lim MC; Mixed Ligand Complexes of Palladium(II). Part 3. Diaqua(ethylenediamine)palladium(II) Complexes of L-Amino-acids

Reference No.: 1675(81CoM)

J. Chem. Soc., Dalton Trans., 1981,, 137 - 141; Coe JS; Mentasti E; Mechanism of Complex Formation between Benzene-1,2-diol and Aquapalladium(II). Equilibria and Kinetics in Acidic Aqueous Perchlorate Media

Reference No.: 1760(90Bur)

Biocoordination Chemistry, 1990 Burger K; Coordination Equilibria in Biologically Active Systems; Ellis Horwood

Reference No.: 1761(90LiB)

Environ. Sci. Technol., 1990, 24, 1038 - 1041; Li J-H; Byrne RH; Amino Acid Complexation of Palladium in Seawater

Reference No.: 1908(79FrW)

J. Inorg. Nucl. Chem., 1979, 41, 591 - 592; Frye H; Williams GH; Ionization and Stability Constants of the Palladium(II) and Platinum(II) Complexes of alpha Amino Dicarboxylic Acids

Reference No.: 2229(88SKS)

J. Coord. Chem., 1988, 17, 305 - 310; Shoukry MM; Khairy EM; Saeed A; Mixed-Ligand Complexes of Palladium(II) with Diethylenetriamine

Reference No.: 2261(93PeP)

IUPAC Stability Constants Database, 1993 Pettit LD; Powell HKJ; IUPAC (in co-operation with Academic Software), Otley, UK

Reference No.: 2284(93DSM)

Inorg. Chem., 1993, 32, 3320 - 3326; Delgado R; Sun Y; Motekaitis RJ; Martell AE; Stabilities of Divalent and Trivalent Metal Ion Complexes of Macrocyclic Triazatriacetic Acids

Reference No.: 2373(89And)

Comprehensive Coordination Chemistry, Vol. 2, 1989, 777 - 792; Anderegg G; Complexones

Reference No.: 2392(93SKG)

Pure Appl. Chem., 1993, 65, 1029 - 1080; Sovago I; Kiss T; Gergely A; Critical Survey of the Stability Constants of Complexes of Aliphatic Amino Acids

Reference No.: 2430(90MSG)

J. Inorg. Biochem., 1990, 38, 27 - 36; Marafie HM; Shuaib NM; Ghodsian R; El-Ezaby MS; Complexes of Hydroxamates VI. Binary and Ternary Complexes Involved in the Palladium(II) Monohydroxamic Acids-Glycylglycine Systems

Reference No.: 2549(90HoV)

Inorg. Chim. Acta, 1990, 174, 87 - 92; Hohmann H; van Eldik R; Rate and Equilibrium

Data for Substitution Reactions of Diaqua- (ethylenediamine)palladium(II) with Chloride in Aqueous Solution

Reference No.: 2556(93MSM)

NIST Critical Stability Constants of Metal Complexes Database, 1993 Martell AE; Smith RM; Motekaitis RJ; Version 1.0; National Institute of Standards and Technology, Gaithersburg, USA

Reference No.: 2729(92BBM)

J. Inclusion Phenom. Mol. Recognit. Chem., 1992, 12, 291 - 304; Bencini A; Bianchi A; Micheloni M; Paoletti P; Dapporto P; Paoli P; Garcia-Espana E; Cation and Anion Coordination Chemistry of Palladium(II) with Polyazacycloalkanes. Thermodynamic and Structural Studies

Reference No.: 2877(80KrD)

Talanta, 1980, 27, 685 - 688; Kragten J; Decnop-Weever LG; Photometric Determination of the Stability Constant of the Palladium(II)-Pyridine-2,6-Dicarboxylate Complex

Reference No.: 2884(83KrD)

Talanta, 1983, 30, 449 - 453; Kragten J; Decnop-Weever LG; The Stability Constants of PdEDTA and its Chloride Complexes

Reference No.: 2978(83Lim)

J. Chem. Soc., Dalton Trans., 1983,, 1675 - 1677; Lim M-C; Formation and Hydrolysis of a Diaqua(ethane-1,2-diamine) Palladium(II) Complex of Ethyl Glycinate

Reference No.: 3006(85BPJ)

Standard Potentials in Aqueous Solution, 1985 Bard AJ; Parsons R; Jordan J; Monographs in Electroanalytical Chemistry and Electrochemistry; Marcel Dekker Inc., New York and Basel

Reference No.: 3178(75GoC)

J. Inorg. Nucl. Chem., 1975, 37, 316 - 318; Gonzalez-Vilchez FA; Castillo M; The Stabilities of Palladium(II)-Iminodiacetate Compounds

Reference No.: 3345(93ShS)

Collect. Czech. Chem. Commun., 1993, 58, 1103 - 1108; Shoukry MM; Shoukry EM; Equilibrium Studies of Binary and Ternary Complexes of Palladium(II) Involving Amino Acids

Reference No.: 3754(86AEM)

Polyhedron, 1986, 5, 633 - 641; Al-Salem NA; El-Ezaby MS; Marafie HM; Abu-Soud HM; Palladium Complexes with Biological Ligands - I. Equilibrium and Reaction Mechanism of Pd(II) Complexes with Ethionine

Reference No.: 3833(93KUO)

Russ. J. Inorg. Chem., 1993, 38, 288 - 290; Kamysbaev DKh; Utegulov RN; Ospanov KhK; The Thermodynamics of Complex Formation of Metals(II) with Unithiol in Aqueous Solutions

Reference No.: 3842(86And)

Inorg. Chim. Acta, 1986, 111, 25 - 30; Anderegg G; The Stability of the Palladium(II) Complexes with Ethylenediamine, Diethylenetriamine and Tris(beta-aminoethyl)-amine

Reference No.: 3844(86AnW)

Inorg. Chim. Acta, 1986, 113, 101 - 108; Anderegg G; Wanner H; Pyridine Derivatives as Complexing Agents. XIII. The Stability of the Palladium(II) Complexes with Pyridine, 2,2'-Bipyridyl, and 1,10-Phenanthroline

Reference No.: 3878(84Ett)

Inorg. Chim. Acta, 1984, 91, 167 - 172; Ettorre R; Equilibrium Studies of Cytidine for Chloride Substitution in Palladium Complexes

Reference No.: 3931(85YaA)

Inorg. Chim. Acta, 1985, 105, 121 - 128; Yan QY; Anderegg G; The Stability of the Palladium(II) Complexes with Linear Tetraamines

Reference No.: 4282(93ByK)

Geochim. Cosmochim. Acta, 1993, 57, 1151 - 1156; Byrne RH; Kump LR; Comment on "Speciation of Aqueous Palladium(II) Chloride Solutions Using Optical Spectroscopies" by C.D. Tait, D.R. Janecky, and P.S.Z. Rogers

Reference No.: 4450(66SBM)

Russ. J. Inorg. Chem., 1966, 11, 325 - 328; Shlenskaya VI; Biryukov AA; Moskovkina EM; A Spectrophotometric Study of Thiourea Complexes of Palladium(II)

Reference No.: 4454(48MeM)

Nature (London), 1948, 20, 436 - 437; Mellor DP; Maley L; Order of Stability of Metal Complexes

Reference No.: 4455(47MeM)

Nature (London), 1947, 159, 370 - 370; Mellor DP; Maley L; Stability Constants of Internal Complexes

Reference No.: 4998(86BaM)

The Hydrolysis of Cations, 1986 Baes CF Jr; Mesmer RE; Robert E. Krieger Publ. Co. Malabar, Florida

Reference No.: 5023(68RaJ)

Acta Chem. Scand., 1968, 22, 2313 Rasmussen L; Jorgensen CK

Reference No.: 5081(88Lic)

J. Electrochem. Soc., 1988, 135, 2971 - 2975; Licht S; Aqueous Solubilities, Solubility Products and Standard Oxidation- Reduction Potentials of the Metal Sulfides

Reference No.: 5253(90LoT)

Collect. Czech. Chem. Commun., 1990, 55, 987 - 993; Loucka T; Ternbach Z; Potential-pH Diagrams for the Systems Ir-H₂O-Cl⁻, Pt-H₂O-Cl⁻, and Pd-H₂O-Cl⁻ at 25 degrees Celsius

Reference No.: 5344(66ShB)

Russ. J. Inorg. Chem., 1966, 11, 28 - 31; Shlenskaya VI; Biryukov AA; Spectrophotometric Investigation of Chloro- and Bromo- Complexes of Palladium(II) in the Ultraviolet Region

Reference No.: 5398(82Hog)

IUPAC Chemical Data Series No. 21, 1982 Hogfeldt E; Stability Constants of Metal-ion Complexes, 2nd Suppl., Part A, Inorganic Ligands; Pergamon, Oxford

Reference No.: 5462(56Dro)

Thesis, Penn. State Univ., 1956 Droll HA; Univ. Microfilms 16705

Reference No.: 5463(24Jir)

Z. Phys. Chem., 1924, 113, 241 Jirsa F

Reference No.: 5464(64ShB)

Vestn. Mosk. Univ., Khim., 1964, 3, 65 Shlenskaya VI; Bryukov AA

Reference No.: 5472(89BaM)

Report No. 34: PSI-Ber., 1989 Baeyens B; McKinley IG; A PHREEQE Database for Palladium, Nickel and Selenium; PSI, Switzerland

Reference No.: 5662(71SuT)

J. Inorg. Nucl. Chem., 1971, 33, 3990 - 3993; Sunar OP; Trevedi CP; Complexes of Palladium(II) with Multidentate Ligands

Reference No.: 5882(67IWE)

J. Chem. Soc. (A), 1967,, 1304 - 1308; Izatt RM; Watt GD; Eatough DJ; Christensen JJ; Thermodynamics of Metal Cyanide Co-ordination. Part VII. Log K, delta H, and delta S Values for the Interaction of CN- with Pd+2. delta H Values for the Interaction of Cl- and Br- with Pd+2

Reference No.: 6330(95LiF)

CRC Handbook of Chemistry and Physics, 76th Edn., 1995 Lide DR; Frederikse HPR; A Ready-Reference Book of Chemical and Physical Data; CRC Press, Cleveland, Ohio, U.S.A.

Reference No.: 6372(87BrW)

OECD NEA Report, 1987 Brown PL; Wanner H; Predicted Formation Constants Using the Unified Theory of Metal Ion Complexation; Nuclear Energy Authority, Paris

Reference No.: 6422(95BaP)

Thermochemical Data of Pure Substances, 3rd Edn., 1995 Barin I; Platzki G; Weinheim, Germany

Reference No.: 6435(97Gra)

Modelling in Aquatic Chemistry, 1997, 131 - 152; Grauer R; Solubility Limitations: An "Old Timer's" View

Reference No.: 6478(81BaM)

Am. J. Sci., 1981, 281, 935 - 962; Baes CF Jr; Mesmer RE; The Thermodynamics of Cation Hydrolysis

Reference No.: 6488(88ShH)

Geochim. Cosmochim. Acta, 1988, 52, 2009 - 2036; Shock EL; Helgeson HC; Calculation of the Thermodynamic and Transport Properties of Aqueous Species at High Pressures and Temperatures: Correlation Algorithms for Ionic Species and Equation of State Predictions to 5 kb and 1000 C

Reference No.: 6496(96StM)

Aquatic Chemistry, 3rd Edn., 1996 Stumm W; Morgan JJ; Chemical Equilibria and Rates in Natural Waters; John Wiley & Sons, Inc., New York

Reference No.: 6628(72SiS)

J. Inorg. Nucl. Chem., 1972, 34, 2067 - 2069; Singh MK; Srivastava MN; Stepwise Formation of Palladium(II), Platinum(IV), Gold(III) and Bismuth(III) Chelates with Aspartic and Glutamic Acids

Reference No.: 6878(93BBD)

Inorg. Chem., 1993, 32, 1204 - 1208; Bencini A; Bianchi A; Dapporto P; Garcia-Espana E; Paoletti P; Paoli P; Ramirez JA; Rodriguez A; Thermodynamic and Structural Properties of Palladium(II) Polynuclear Complexes of Azamacrocycles. Crystal Structure of the [Pd2([24]aneN8)](ClO4)4 Complex

Reference No.: 7159(97KFS)

J. Inorg. Biochem., 1997, 68, 85 - 92; Kiss A; Farkas E; Sovago I; Thormann B; Lippert B; Solution Equilibria of the Ternary Complexes of [Pd(dien)Cl]+ and [Pd(terpy)Cl]+ with Nucleobases and N-acetyl Amino Acids

Reference No.: 7271(98SMM)

NIST Critical Stability Constants of Metal Complexes Database, 1998 Smith RM; Martell AE; Motekaitis RJ; Version 5.0; U.S. Dept. Commerce, Gaithersburg, MD, U.S.A.

Reference No.: 7372(78BDJ)

Vogel's Textbook of Quantitative Inorganic Analysis, 1978 Bassett J; Denney RC; Jeffery GH; Mendham J; including Elementary Instrumental Analysis; Longman, London, U.K.

Reference No.: 7421(97Mar)

Ion Properties, 1997 Marcus Y; Marcel Dekker Inc., New York, U.S.A.

Reference No.: 8931(64BiS)

Russ. J. Inorg. Chem., 1964, 9, 450 - 452; Biryukov AA; Shlenskaya VI; Composition and Stability Constants of Chloro-complexes of Palladium(II)

Reference No.: 8932(63BuD)

Acta Chem. Scand., 1963, 17, 1489 - 1501; Burger K; Dyrssen D; On the Complex Formation of Palladium with Dimethylglyoxime

Reference No.: 8933(61SLI)

Vestn. Leningr. Univ., Fiz., Khim., 1961, 16, 152 - 155; Shchukarev SA; Lobaneva OA; Ivanova MA; Kononova MA; Spectrophotometric Investigations of the Chloride Complexes of Bivalent Palladium in Aqueous Solutions

Reference No.: 9077(92GBY)

Geochim. Cosmochim. Acta, 1992, 56, 3881 - 3894; Gammons CH; Bloom MS; Yu Y; Experimental Investigation of the Hydrothermal Geochemistry of Platinum and Palladium: I. Solubility of Platinum and Palladium Sulfide Minerals in NaCl / H₂SO₄ Solutions at 300C

Reference No.: 10174(95OHS)

J. Phys. Chem. Ref. Data, 1995, 24, 1401 - 1560; Oelkers EH; Helgeson HC; Shock EL; Sverjensky DA; Johnson JW; Pokrovskii VA; Summary of the Apparent Standard Partial Molal Gibbs Free Energies of Formation of Aqueous Species, Minerals, and Gases at Pressures 1 to 5000 Bars and Temperatures 25 to 1000C

Reference No.: 11516(00PeP)

IUPAC Stability Constants Database, 2000 Pettit LD; Powell HKJ; Release 4; Academic Software, U.K.

Reference No.: 12931(01SPG)

Chem. Geol., 2001, 171, 173 - 194; Seby F; Potin-Gautier M; Giffaut E; Borge G; Donard OFX; A Critical Review of Thermodynamic Data for Selenium Species at 25C

Reference No.: 13242(05AAD)

Pure Appl. Chem., 2005, 77, 1445 - 1495; Anderegg G; Arnaud-Neu F; Delgado R; Felcman J; Popov K; Critical Evaluation of Stability Constants of Metal Complexes of Complexones for Biomedical and Environmental Applications

Reference No.: 16981(11OrB)

Russ. J. Inorg. Chem., 2011, 56, 975 - 980; Orlov YF; Belkina EI; Correlations between the Stability Constants of Metal Hydroxo Complexes and the Solubility Products of Crystalline Hydroxides. Series of the Polarizing Effect of Metal Cations

Reference No.: 16994(96ShE)

Inorg. Chem., 1996, 35, 735 - 740; Shi T; Elding LI; Equilibrium and High-Pressure Kinetic Study of Formation and Proton-Assisted Aquation of Monodentate Acetate, Propionate, and Glycolate Complexes of Palladium(II) in Aqueous Solution

Reference No.: 18118(52Con)

Electrochemical Data, 1952 Conway BE; Greenwood Press, Westport, Conn., U.S.A.

Reference No.: 22551(06Inz)

Encyclopedia of Electrochemistry, Vol. 7a, 2006, 17 - 75; Inzelt G; Standard, Formal and Other Characteristic Potentials of Selected Electrode Reactions

Reference No.: 22560(05PeP)

IUPAC Stability Constants Database, 2005 Pettit LD; Powell HKJ; Release 4.71; Academic Software, U.K.

Reference No.: 22604(70NKK)

Izv. Sib. Otd. Akad. Nauk SSSR, Ser. Khim. Nauk, 1970, (4), 51 - 53; Nabivanets BI; Kalabina LV; Kudritskaya LN; State of Palladium(II) and Platinum(IV) in Inorganic Acid Solutions

Reference No.: 30060(14LGK)

J. Coord. Chem., 2014, 67, 1520 - 1529; Le Roux CJ; Gans P; Kriek RJ; Complexation of Palladium(II) with Thiocyanate - a Spectrophotometric Investigation

Reference No.: 31301(10KFD)

Japan Atomic Energy Agency Data/Code 2009-024, 2010 Kitamura A; Fujiwara K; Doi R; Yoshida Y; Mihara M; Terashima M; Yui M; JAEA Thermodynamic Database for Performance Assessment of Geological Disposal of High-level Radioactive and TRU Wastes; Geological Isolation Research Unit, JAEA, Japan

Reference No.: 32222(06DGC)

Technical Report TR-06-17, 2006 Duro L; Grive M; Cera E; Domenech C; Bruno J; Update of a Thermodynamic Database for Radionuclides to Assist Solubility Limits Calculation for Performance Assessment; Swedish Nucl. Fuel & Waste Management Co, Stockholm, Sweden

Reference No.: 32224(80BeT)

Lawrence Berkeley Laboratory Report LBL-11448, 1980 Benson LV; Teague LS; A Tabulation of Thermodynamic Data for Chemical Reactions Involving 8 Elements Common to Radioactive Waste Package Systems