

JESS Thermodynamic Database v8.9

Rubidium

24-Jan-23

Reaction No. 1352							
0.5<I2(s)> + Rb(s) = Rb+1_I-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-79.10 (4SF)	4	CRV	10174
2	50	0	Inf. Dilution	dG:-80.49 (4SF)	4	CRV	10174
3	75	0	Inf. Dilution	dG:-81.86 (4SF)	4	CRV	10174
4	100	0	Inf. Dilution	dG:-83.22 (4SF)	4	CRV	10174
5	125	0	Inf. Dilution	dG:-84.56 (4SF)	4	CRV	10174
6	150	0	Inf. Dilution	dG:-85.89 (4SF)	4	CRV	10174
7	175	0	Inf. Dilution	dG:-87.21 (4SF)	4	CRV	10174
8	200	0	Inf. Dilution	dG:-88.52 (4SF)	4	CRV	10174
9	225	0	Inf. Dilution	dG:-89.82 (4SF)	4	CRV	10174
10	250	0	Inf. Dilution	dG:-91.10 (4SF)	4	CRV	10174
11	300	0	Inf. Dilution	dG:-93.63 (4SF)	4	CRV	10174

Reaction No. 1353							
0.5<F2(g)> + Rb(s) = Rb+1_F-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-136.45 (5SF)	3	CRV	10174
2	50	0	Inf. Dilution	dG:-137.23 (5SF)	2	CRV	10174
3	75	0	Inf. Dilution	dG:-137.98 (5SF)	4	CRV	10174
4	100	0	Inf. Dilution	dG:-138.72 (5SF)	1	CRV	10174
5	125	0	Inf. Dilution	dG:-139.45 (5SF)	1	CRV	10174
6	150	0	Inf. Dilution	dG:-140.18 (5SF)	1	CRV	10174
7	175	0	Inf. Dilution	dG:-140.89 (5SF)	0	CRV	10174
8	200	0	Inf. Dilution	dG:-141.60 (5SF)	0	CRV	10174
9	225	0	Inf. Dilution	dG:-142.30 (5SF)	0	CRV	10174
10	250	0	Inf. Dilution	dG:-142.99 (5SF)	0	CRV	10174
11	300	0	Inf. Dilution	dG:-144.35 (5SF)	0	CRV	10174

Reaction No. 1354							
0.5<Cl2(g)> + Rb(s) = Rb+1_Cl-1							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-97.87 (4SF)	3	CRV	10174
2	50	0	Inf. Dilution	dG:-99.07 (4SF)	2	CRV	10174
3	75	0	Inf. Dilution	dG:-100.24 (5SF)	2	CRV	10174
4	100	0	Inf. Dilution	dG:-101.39 (5SF)	1	CRV	10174
5	125	0	Inf. Dilution	dG:-102.53 (5SF)	1	CRV	10174
6	150	0	Inf. Dilution	dG:-103.66 (5SF)	1	CRV	10174
7	175	0	Inf. Dilution	dG:-104.77 (5SF)	0	CRV	10174
8	200	0	Inf. Dilution	dG:-105.88 (5SF)	0	CRV	10174
9	225	0	Inf. Dilution	dG:-106.97 (5SF)	0	CRV	10174
10	250	0	Inf. Dilution	dG:-108.05 (5SF)	0	CRV	10174
11	300	0	Inf. Dilution	dG:-110.17 (5SF)	0	CRV	10174

Reaction No. 1355



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-91.01 (4SF)	4	CRV	10174
2	50	0	Inf. Dilution	dG:-92.35 (4SF)	4	CRV	10174
3	75	0	Inf. Dilution	dG:-93.66 (4SF)	4	CRV	10174
4	100	0	Inf. Dilution	dG:-94.96 (4SF)	4	CRV	10174
5	125	0	Inf. Dilution	dG:-96.23 (4SF)	4	CRV	10174
6	150	0	Inf. Dilution	dG:-97.50 (4SF)	4	CRV	10174
7	175	0	Inf. Dilution	dG:-98.75 (4SF)	4	CRV	10174
8	200	0	Inf. Dilution	dG:-100.00 (5SF)	4	CRV	10174
9	225	0	Inf. Dilution	dG:-101.23 (5SF)	4	CRV	10174
10	250	0	Inf. Dilution	dG:-102.44 (5SF)	4	CRV	10174
11	300	0	Inf. Dilution	dG:-104.84 (5SF)	4	CRV	10174

Reaction No. 4858



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-51.12 (4SF)	2	CRV	32224
2	25	0	Inf. Dilution	dG:67.80 (4SF)	2	CRV	6488
3	25	0	Inf. Dilution	dG:284. (3SF) kJ	5	CRV	7421
4	25	0	Inf. Dilution	dG:211.4 (4SF) kJ	0	CRV	8746
5	25	0	Inf. Dilution	dG:67.800 (5SF)	2	CRV	9029

6	25	0	Inf. Dilution	dG:67.80 (4SF)	2	CRV	10174
7	25	0	Inf. Dilution	dG:284.010 (0.08SD) kJ	5	CRV	27292
8	25	0	Inf. Dilution	dG:283.98 (5SF) kJ	5	CRV	28172
9	25	0	Inf. Dilution	dG:284.01 (5SF) kJ	5	EOD	29520
10	25	0	Inf. Dilution	dG:283.98 (5SF) kJ	2	EOD	30015
11	25	0	Inf. Dilution	dG:284.0 (4SF) kJ	4	EFE	32152
12	50	0	Inf. Dilution	dG:68.52 (4SF)	3	CRV	10174
13	75	0	Inf. Dilution	dG:69.24 (4SF)	3	CRV	10174
14	100	0	Inf. Dilution	dG:69.96 (4SF)	3	CRV	10174
15	125	0	Inf. Dilution	dG:70.68 (4SF)	2	CRV	10174
16	150	0	Inf. Dilution	dG:71.41 (4SF)	2	CRV	10174
17	175	0	Inf. Dilution	dG:72.14 (4SF)	1	CRV	10174
18	200	0	Inf. Dilution	dG:72.87 (4SF)	1	CRV	10174
19	225	0	Inf. Dilution	dG:73.59 (4SF)	0	CRV	10174
20	250	0	Inf. Dilution	dG:74.32 (4SF)	0	CRV	10174
21	300	0	Inf. Dilution	dG:75.75 (4SF)	0	CRV	10174
22	23	0	Inf. Dilution	E:-2.99 (3SF)	0	ENS	7276
23	25	0	Inf. Dilution	E:-2.93 (0.01SD)	0	MEF	775
24	25	0	Inf. Dilution	E:-2.98 (3SF)	0	CRV	6330
25	25	0	Inf. Dilution	E:-2.98 (3SF)	0	ENS	7381
26	25	0	Inf. Dilution	E:-2.943 (4SF)	3	CRV	7761
27	25	0	Inf. Dilution	E:-2.9239 (5SF)	0	CRV	13213
Note (27): p. 256							
28	25	0	Inf. Dilution	E:-2.924 (0.001SD)	0	CRV	22551
29	25	0	Inf. Dilution	dH:60.0 (0.03SD)	5	CRV	5605
30	25	0	Inf. Dilution	dH:60.02 (4SF)	4	CRV	6488
31	25	0	Inf. Dilution	dH:251.2 (4SF) kJ	5	CRV	7761
32	25	0	Inf. Dilution	dH:251.12 (0.10MD) kJ	6	CRV	8746
33	25	0	Inf. Dilution	dH:60.020 (5SF)	4	CRV	9029
34	25	0	Inf. Dilution	dH:251.12 (0.05SD) kJ	5	CRV	27292
35	25	0	Inf. Dilution	dH:251.17 (5SF) kJ	5	CRV	28172
36	25	0	Inf. Dilution	dH:251.12 (5SF) kJ	5	EOD	29520
37	25	0	Inf. Dilution	dH:251.17 (5SF) kJ	2	EOD	30015
38	25	0	Inf. Dilution	dH:251.2 (4SF) kJ	4	EFE	32152

Reaction No. 10623


Malic-2 + Rb+1 = Rb+1_Malic-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:0.04 (0.04SD)	6	ENS	999
2	25	0.28	Me4NBr	lgK:0.2 (0.06SD)	4	MGL	999

Reaction No. 12207							
Citric-3 + Rb+1 = Rb+1_Citric-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:0.49 (0.02SD)	6	MIS	999
2	37	0.15	Unknown	lgK:0.52 (0.06MD)	6	MGL	1230

Reaction No. 14206							
5ATP-4 + Rb+1 = Rb+1_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Pr4N+ salt	lgK:1.96 (3SF)	4	MGL	5326
2	10	0.04	Pr4N+ salt	lgK:1.42 (3SF)	4	MGL	5326
3	10	0.16	Pr4N+ salt	lgK:1.21 (3SF)	4	MGL	5326
4	10	0.25	Pr4N+ salt	lgK:1.18 (3SF)	4	MGL	5326
5	10	0.49	Pr4N+ salt	lgK:1.17 (3SF)	4	MGL	5326
6	10	1	Pr4N+ salt	lgK:1.25 (3SF)	4	MGL	5326
7	25	0	Pr4N+ salt	lgK:1.98 (3SF)	4	MGL	5326
8	25	0.04	Pr4N+ salt	lgK:1.44 (3SF)	4	MGL	5326
9	25	0.1	Me4N+ salt	lgK:1.1 (0.05SD)	7	CIU	1437
10	25	0.16	Pr4N+ salt	lgK:1.24 (3SF)	4	MGL	5326
11	25	0.25	Pr4N+ salt	lgK:1.23 (0.05SD)	5	MGL	3595
12	25	0.32	Unknown	lgK:0.9 (1SF)	4	MGL	999
13	25	0.49	Pr4N+ salt	lgK:1.28 (3SF)	4	MGL	5326
14	25	0.6	Unknown	lgK:0.90 (2SF)	4	MGL	1437
15	25	1	Pr4N+ salt	lgK:1.44 (3SF)	4	MGL	5326
16	35	0	Pr4N+ salt	lgK:1.99 (3SF)	4	MGL	5326
17	35	0.04	Pr4N+ salt	lgK:1.45 (3SF)	4	MGL	5326
18	35	0.16	Pr4N+ salt	lgK:1.26 (3SF)	4	MGL	5326
19	35	0.25	Pr4N+ salt	lgK:1.26 (3SF)	4	MGL	5326
20	35	0.49	Pr4N+ salt	lgK:1.32 (3SF)	4	MGL	5326
21	35	1	Pr4N+ salt	lgK:1.56 (3SF)	4	MGL	5326
22	45	0	Pr4N+ salt	lgK:2.00 (3SF)	4	MGL	5326


23	45	0.04	Pr4N+ salt	lgK:1.46 (3SF)	4	MGL	5326
24	45	0.16	Pr4N+ salt	lgK:1.27 (3SF)	4	MGL	5326
25	45	0.25	Pr4N+ salt	lgK:1.27 (3SF)	4	MGL	5326
26	45	0.49	Pr4N+ salt	lgK:1.35 (3SF)	4	MGL	5326
27	45	1	Pr4N+ salt	lgK:1.66 (3SF)	4	MGL	5326
28	10:45	0.25	Pr4N+ salt	dH:5. (3.SD) kJ	4	MTD	3595
29	25	0.1	Inert	dH:4. (4.SD) kJ	5	CIU	1437

Reaction No. 20690



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.32	Unknown	lgK:0.0 (1SF)	6	MGL	999

Reaction No. 20691



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Pr4N+ salt	lgK:0.2 (1SF)	4	MGL	1437
2	10	0.04	Pr4N+ salt	lgK:-0.2 (1SF)	4	MGL	1437
3	10	0.16	Pr4N+ salt	lgK:-0.37 (2SF)	4	MGL	1437
4	10	0.25	Pr4N+ salt	lgK:-0.4 (1SF)	4	MGL	1437
5	10	0.49	Pr4N+ salt	lgK:-0.4 (1SF)	4	MGL	1437
6	10	1	Pr4N+ salt	lgK:-0.3 (1SF)	4	MGL	1437
7	25	0	Pr4N+ salt	lgK:0.4 (1SF)	4	MGL	1437
8	25	0.04	Pr4N+ salt	lgK:-0.06 (1SF)	4	MGL	1437
9	25	0.16	Pr4N+ salt	lgK:-0.19 (2SF)	4	MGL	1437
10	25	0.25	Pr4N+ salt	lgK:-0.21 (2SF)	4	MGL	1437
11	25	0.32	Unknown	lgK:-0.3 (1SF)	4	MGL	999
12	25	0.49	Pr4N+ salt	lgK:-0.15 (2SF)	4	MGL	1437
13	25	1	Pr4N+ salt	lgK:0.0 (1SF)	4	MGL	1437
14	35	0	Pr4N+ salt	lgK:0.5 (1SF)	4	MGL	1437
15	35	0.04	Pr4N+ salt	lgK:0.1 (1SF)	4	MGL	1437
16	35	0.16	Pr4N+ salt	lgK:-0.08 (1SF)	4	MGL	1437
17	35	0.25	Pr4N+ salt	lgK:-0.1 (1SF)	4	MGL	1437
18	35	0.49	Pr4N+ salt	lgK:0.0 (1SF)	4	MGL	1437
19	35	1	Pr4N+ salt	lgK:0.2 (1SF)	4	MGL	1437
20	45	0	Pr4N+ salt	lgK:0.6 (1SF)	4	MGL	1437

21	45	0.04	Pr4N+ salt	lgK:0.2 (1SF)	4	MGL	1437
22	45	0.16	Pr4N+ salt	lgK:0.0 (1SF)	4	MGL	1437
23	45	0.25	Pr4N+ salt	lgK:0.1 (1SF)	4	MGL	1437
24	45	0.49	Pr4N+ salt	lgK:0.1 (1SF)	4	MGL	1437
25	45	1	Pr4N+ salt	lgK:0.4 (1SF)	4	MGL	1437

Reaction No. 22116							
[2.2.2]crypt + Rb+1 = Rb+1_[2.2.2]crypt							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	KCl	lgK:4.35 (3SF)	5	MGL	3283
2	25	0.1	Me4NCl	lgK:4.06 (3SF)	6	MGL	1572
3	25	0.1	Me4NCl	dH:-11.8 (3SF)	5	MCL	1572
4	25			dH:-10.5 (3SF)	3	ENS	3560
5	25	0.05	Acetone Et4NClO4	lgK:8.39 (0.03SD)	5	MAG	4399
6	25	0.05	Acetone Et4NClO4	dH:-64.9 (0.5SD) kJ	5	MCL	4399
7	25	0.01	DMF Et4NClO4	lgK:6.78 (3SF)	5	MGL	2931
8	25		DMF	dH:-13.2 (0.2SD)	5	MCL	4802
9	25	0.01	DMSO Et4NClO4	lgK:5.85 (3SF)	5	MGL	2931
10	25		DMSO	dH:-14.1 (0.1SD)	5	MCL	4802
11	25		Ethanol:Water 95:5Vol	lgK:9.28 (3SF)	5	MGL	2931
12	25	0.05	MeCN Et4NClO4	lgK:9.65 (3SF)	4	MPT	3850
13	25		MeCN	lgK:7. (1SF)	3	MCN	4650
14	25	0.05	MeCN Et4NClO4	dH:-71.6 (3SF) kJ	4	MCL	3850
15	25		MeCN	dH:-17. (0.4SD)	5	MCL	4801
16	25	0.01	Methanol KCl	lgK:6.0 (2SF)	3	MGL	3283
17	25	0.05	Methanol Et4NClO4	lgK:8.98 (3SF)	5	MAG	2956
18	25		Methanol	lgK:9.10 (3SF)	5	MPT	2511
19	25		Methanol	lgK:9.10 (3SF)	5	MMC	3854
20	25		Methanol	dH:-72.7 (3SF) kJ	4	MCL	3854
21	25		NMePrAmide	lgK:7.28 (3SF)	5	MGL	2931
22	25		Nitromethane	lgK:10.3 (0.1SD)	5	MCN	4799

23	25		Nitromethane	dG:-14.05(4SF)	5	EFE	4799
24	25		Nitromethane	dH:-18.0(0.2SD)	5	MCL	4798
25	25		PrCarbonate	lgK:9.0(0.1SD)	5	MPT	4822
26	25		PrCarbonate	dH:-16.3(0.2SD)	5	MCL	4801

Reaction No. 29104							
EDTA-4 + Rb+1 = Rb+1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.32	CsCl	lgK:0.59(2SF)	6	EIU	903
2	25	0.32	CsCl	lgK:0.59(2SF)	5	MGL	2373

Reaction No. 30061							
BisTris + Rb+1 = Rb+1_BisTris							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.25	DMSO:Water 90:10Vol Me4NNO3	lgK:0.26(0.01SD)	6	MGL	2542

Reaction No. 30063							
TriEtOlAm + Rb+1 = Rb+1_TriEtOlAm							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.25	DMSO:Water 90:10Vol Me4NNO3	lgK:-0.07(0.1SD)	6	MGL	2542

Reaction No. 35800							
[2.1.1]crypt + Rb+1 = Rb+1_[2.1.1]crypt							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	KCl	lgK:2.0(2SF)	3	MGL	3283
2	25	0.05	Acetone Et4NC1O4	lgK:1.52(0.03SD)	5	MAG	4399
3	25	0.05	Acetone Et4NC1O4	dH:-2.1(0.7SD)kJ	5	MCL	4399
4	25	0.01	DMF Et4NC1O4	lgK:3.08(3SF)	5	MGL	2931
5	25	0.05	MeCN Et4NC1O4	lgK:3.9(2SF)	4	MPT	3850
6	25	0.05	MeCN Et4NC1O4	dH:-9.5(2SF)kJ	4	MCL	3850
7	25	0.01	Methanol KCl	lgK:1.9(2SF)	5	MGL	3283

8	25		Methanol	lgK:2.50 (3SF)	5	MMC	3854
9	25		Methanol	dH:-8.0 (2SF) kJ	4	MCL	3854
10	25	0.01	Methanol:Water 95:5Vol KCl	lgK:2.0 (2SF)	3	MGL	3283
11	25		PrCarbonate	lgK:2.2 (0.1SD)	3	MPT	4822

Reaction No. 35808							
[2.2.1]crypt + Rb+1 = Rb+1_[2.2.1]crypt							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	KCl	lgK:2.55 (3SF)	5	MGL	3283
2	25	0.05	Acetone Et4NC1O4	lgK:6.50 (0.02SD)	5	MAG	4399
3	25	0.05	Acetone Et4NC1O4	dH:-53.7 (0.4SD) kJ	5	MCL	4399
4	25	0.01	DMF Et4NC1O4	lgK:5.35 (3SF)	5	MGL	2931
5	25	0.01	DMSO Et4NC1O4	lgK:4.64 (3SF)	5	MGL	2931
6	25		Ethanol:Water 95:5Vol	lgK:6.88 (3SF)	5	MGL	2931
7	25	0.05	MeCN Et4NC1O4	lgK:6.74 (3SF)	4	MPT	3850
8	25	0.05	MeCN Et4NC1O4	dH:-56.3 (3SF) kJ	4	MCL	3850
9	25	0.01	Methanol KCl	lgK:6.0 (2SF)	3	MGL	3283
10	25	0.05	Methanol Et4NC1O4	lgK:6.74 (3SF)	5	MAG	2956
11	25		Methanol	lgK:7.35 (3SF)	5	MMC	3854
12	25		Methanol	dH:-55.7 (3SF) kJ	4	MCL	3854
13	25	0.01	Methanol:Water 95:5Vol KCl	lgK:5.80 (3SF)	5	MGL	3283
14	25		NMePrAmide	lgK:5.55 (3SF)	5	MGL	2931
15	25		PrCarbonate	lgK:7.0 (0.1SD)	5	MPT	4822

Reaction No. 37220							
DiBenzoylmethane-1 + Rb+1 = Rb+1_DiBenzoylmethane-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Dioxan:Water 75:25Wgt	lgK:3.52 (3SF)	5	MGL	2360

Reaction No. 37909							
[18]N2O4:Meox*2 + Rb+1 = Rb+1_[18]N2O4:Meox*2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:2. (1SF)	3	MPT	425
2	25		DMF	lgK:3.1 (0.05SD)	4	MPT	425
3	25		MeCN	lgK:5.2 (0.05SD)	4	MPT	425
4	25		Methanol	lgK:4.4 (0.05SD)	4	MPT	425
5	25		PrCarbonate	lgK:4.7 (0.1SD)	4	MPT	425

Reaction No. 38286							
[18]O6:DiBenzo + Rb+1 = Rb+1_[18]O6:DiBenzo							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.097 (4SF)	5	MSP	3303
2	27	0	DMF Inf. Dilution	lgK:2.38 (0.11SD)	5	MMR	6236
3	25	0.05	MeCN Et4NClO4	dH:-12.0 (3SF) kJ	5	MCL	5758

Reaction No. 38532							
[18]O6 + Rb+1 = Rb+1_[18]O6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Many Media	lgK:1.51 (0.08SD)	7	CIU	13297
2	25	0.1	Unknown	lgK:1.56 (0.02SD)	5	MCL	4523
3	25	0.1	Many Media	dH:-16.0 (0.5SD) kJ	8	CIU	13297
4	25	0.1	Unknown	dH:-3.8 (0.1SD)	5	MCL	4523
5	25	0.05	Acetone Et4NClO4	lgK:5.16 (3SF)	5	MAG	4399
6	25	0.1	Acetone Unknown	lgK:5.16 (0.03SD)	6	CIU	13297
7	25	0.05	Acetone Et4NClO4	dH:-47.8 (0.6SD) kJ	5	MCL	4399
8	25	0.1	Acetone Unknown	dH:-47.8 (0.6SD) kJ	6	CIU	13297
9	25	0.1	DMF Et4NClO4	lgK:3.92 (0.02MD)	5	MCL	2802
10	25	0.1	DMF Many Media	lgK:4.0 (0.1SD)	7	CIU	13297
11	27	0	DMF Inf. Dilution	lgK:3.75 (0.11SD)	5	MMR	6236
12	25	0.1	DMF Et4NClO4	dH:-44.6 (0.1MD) kJ	5	MCL	2802

13	25	0.1	DMF Many Media	dH:-43.(2.SD)kJ	7	CIU	13297
14	25	0.05	MeCN Et4NClO4	lgK:5.24(3SF)	5	MAG	5758
15	25	0.05	MeCN Et4NClO4	lgK:4.9(0.2MD)	5	MCL	7232
16	25	0.1	MeCN Many Media	lgK:5.1(0.18SD)	7	CIU	13297
17	25	0.05	MeCN Et4NClO4	dH:-12.6(3SF)kJ	5	MCL	5758
18	25	0.05	MeCN Et4NClO4	dH:-15.0(0.5MD)kJ	5	MCL	7232
19	25	0.1	MeCN Many Media	dH:-14.(1.SD)kJ	7	CIU	13297
20	25	0.1	Methanol Many Media	lgK:5.4(0.1SD)	7	CIU	13297
21	25		Methanol	lgK:5.35(3SF)	5	MCN	2251
22	25		Methanol	lgK:5.335(4SF)	5	MDG	2251
23	25		Methanol	lgK:5.515(4SF)	5	MDG	2511
24	25		Methanol	lgK:5.32(0.11SD)	5	MCL	2944
25	25		Methanol	lgK:5.82(3SF)	5	MMC	3854
26	25	0.1	Methanol Many Media	dH:-50.0(0.4SD)kJ	8	CIU	13297
27	25		Methanol	dH:-12.09(0.05SD)	5	MCL	2944
28	25		Methanol	dH:-49.6(3SF)kJ	4	MCL	3854
29	25	0.1	Methanol:Water 70:30Wgt Unknown	lgK:3.5(0.1SD)	5	MCL	4522
30	25	0.1	Methanol:Water 70:30Wgt Unknown	dH:-38.8(0.3SD)kJ	6	CIU	13297
31	25	0.1	Methanol:Water 80:20Vol Unknown	lgK:3.99(0.03SD)	6	CIU	13297
32	25	0.1	Methanol:Water 80:20Vol Unknown	dH:-36.6(0.4SD)kJ	6	CIU	13297
33	25	0.05	PrCarbonate Et4NClO4	lgK:5.3(0.07MD)	5	MCL	7232
34	25	0.1	PrCarbonate Many Media	lgK:5.33(0.07SD)	7	CIU	13297
35	25	0.05	PrCarbonate Et4NClO4	dH:-44.1(0.3MD)kJ	5	MCL	7232
36	25	0.1	PrCarbonate Many Media	dH:-44.(1.SD)	8	CIU	13297

Reaction No. 38533							
[18]N2O4 + Rb+1 = Rb+1_[18]N2O4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Acetone Et4NClO4	lgK:2.70 (0.03SD)	5	MPT	4399
2	25	0.05	Acetone Et4NClO4	dH:-15.0 (0.6SD) kJ	5	MCL	4399
3	27	0	DMF Inf. Dilution	lgK:1.68 (0.04SD)	5	MMR	6236
4	25	0.05	MeCN Et4NClO4	lgK:3.32 (3SF)	5	MPT	3850
5	25		MeCN	lgK:3.4 (0.03SD)	5	MCN	4650
6	25	0.05	MeCN Et4NClO4	dH:-10.1 (3SF) kJ	4	MCL	3850
7	25		Methanol	lgK:1. (1SF)	3	MMC	3854
8	25		Methanol	dH:2. (1SF) kJ	3	MCL	3854

Reaction No. 38536							
[18]N2O4:DiDec + Rb+1 = Rb+1_[18]N2O4:DiDec							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:3.51 (3SF)	5	MMC	3854
2	25		Methanol	dH:-34.4 (3SF) kJ	4	MCL	3854

Reaction No. 38588							
[2.2.2]crypt:DiLactam + Rb+1 = Rb+1_[2.2.2]crypt:DiLactam							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	MeCN Et4NClO4	lgK:2.32 (3SF)	4	MPT	3850
2	25	0.05	MeCN Et4NClO4	dH:-4.2 (2SF) kJ	4	MCL	3850

Reaction No. 38632							
Monensin-1 + Rb+1 = Rb+1_Monensin-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	DMF Inf. Dilution	lgK:6.2 (0.1SD)	5	MPT	4763
2	25	0	DMSO Inf. Dilution	lgK:4.3 (0.1SD)	5	MPT	4763
3	25		Ethanol	lgK:6.23 (3SF)	4	MPT	2938

4	25	0	MeCN Inf. Dilution	lgK:7.9(0.1SD)	5	MPT	4763
5	25	0	Methanol Inf. Dilution	lgK:4.3(0.1SD)	5	MPT	4763
6	25	0.16	Methanol Bu4NOH	lgK:4.6(0.05SD)	5	MIS	4777
7	25	0.16	Methanol Bu4NOH	lgK:4.5(0.2SD)	5	MCV	4777
8	25	0	PrCarbonate Inf. Dilution	lgK:7.3(0.1SD)	5	MPT	4763


Reaction No. 38644							
Lasalocid-1 + Rb+1 = Rb+1_Lasalocid-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	DMF Inf. Dilution	lgK:4.0(0.1SD)	5	MPT	4763
2	25	0	Ethanol Inf. Dilution	lgK:4.4(0.1SD)	5	MPT	4763
3	25	0	Methanol Inf. Dilution	lgK:3.6(0.1SD)	5	MPT	4763
4	25	1	Methanol Tris buffer	lgK:3.56(3SF)	4	MPH	5674
5	25		Methanol	lgK:3.39(3SF)	4	MPT	2604
6	25		Methanol	dH:-13.2(3SF) kJ	4	MCL	2600
7	25	0	PrCarbonate Inf. Dilution	lgK:4.6(0.1SD)	5	MPT	4763

Reaction No. 39358							
Pentaglyme + Rb+1 = Rb+1_Pentaglyme							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:1.98(3SF)	5	MCL	2511
2	25		Methanol	lgK:2.07(3SF)	5	MCN	2511

Reaction No. 39652							
[2.2.2]crypt:DiBenz + Rb+1 = Rb+1_[2.2.2]crypt:DiBenz							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	DMF Et4NClO4	lgK:4.3(0.09SD)	5	MGL	4796
2	25	0.1	DMF Et4NClO4	dG:-5.89(3SF)	5	EFE	4796
3	25		DMF	dH:-11.4(0.08SD)	5	MCL	2185


4	25	0.1	DMSO Et4NC1O4	lgK:4.6(0.05SD)	5	MGL	4796
5	25	0.1	DMSO Et4NC1O4	dG:-6.34(3SF)	5	EFE	4796
6	25		DMSO	dH:-12.8(0.05SD)	5	MCL	2185
7	25	0.1	MeCN Et4NC1O4	lgK:7.7(0.05SD)	5	MGL	4796
8	25	0.1	MeCN Et4NC1O4	dG:-10.50(4SF)	5	EFE	4796
9	25		MeCN	dH:-14.5(0.09SD)	5	MCL	2185
10	25	0.1	Nitromethane Et4NC1O4	lgK:8.4(0.04SD)	5	MGL	4796
11	25	0.1	Nitromethane Et4NC1O4	dG:-11.46(4SF)	5	EFE	4796
12	25	0.1	PrCarbonate Et4NC1O4	lgK:6.7(0.04SD)	5	MGL	4796
13	25	0.1	PrCarbonate Et4NC1O4	dG:-9.06(3SF)	5	EFE	4796
14	25		PrCarbonate	dH:-14.4(0.07SD)	5	MCL	2185

Reaction No. 39930




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:27.35(0.02SD)	5	MGL	1318

Reaction No. 39931




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:36.28(0.02SD)	5	MGL	1318

Reaction No. 39932



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Me4NNO3	lgK:43.7(0.03SD)	5	MGL	1318


Reaction No. 41342



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:0.62(0.1SD)	3	MCL	4523
2	25			lgK:0.58(2SF)	0	MSC	4791


3	25	0.1	Unknown	dH:-1.90 (0.01SD)	5	MCL	4523
4	25	0.05	Acetone Et4NClO4	lgK:4.34 (0.03SD)	5	MPT	4399
5	25	0.1	Acetone Unknown	lgK:4.34 (0.03SD)	6	CIU	13297
6	25	0.05	Acetone Et4NClO4	dH:-24.3 (0.3SD) kJ	5	MCL	4399
7	25	0.1	Acetone Unknown	dH:-24.3 (0.3SD) kJ	6	CIU	13297
8	27	0	DMF Inf. Dilution	lgK:1.84 (0.04SD)	5	MMR	6236
9	25	0.05	MeCN Et4NClO4	lgK:3.98 (3SF)	5	MAG	5758
10	25	0.1	MeCN Many Media	lgK:3.6 (0.2SD)	7	CIU	13297
11	25	0.05	MeCN Et4NClO4	dH:-28.6 (3SF) kJ	5	MCL	5758
12	25	0.1	MeCN Many Media	dH:-29. (1.SD) kJ	6	CIU	13297
13	25	0.1	Methanol Many Media	lgK:2.80 (0.08SD)	7	CIU	13297

Reaction No. 42201




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:3.55 (3SF)	5	MGL	2600
2	25		Methanol	dH:-11.7 (3SF) kJ	4	MCL	2600

Reaction No. 43916



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.94 (3SF)	5	MCN	906
2	25	0	Inf. Dilution	lgK:1.94 (3SF)	5	MDS	906
3	25			lgK:2.5 (2SF)	4	MSC	906
4	25		Nitrobenzene	lgK:2.65 (3SF)	5	MDS	906

Reaction No. 45086



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	100			lgK:-0.80 (2SF)	4	MMR	906

Reaction No. 45622							
[18]O6:[Hex]*2 + Rb+1 = Rb+1_[18]O6:[Hex]*2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	10	0	Inf. Dilution	lgK:1.61(0.01SD)	3	MCL	6727
2	23	0.01	Unknown	lgK:1.47(0.02SD)	4	MCL	6655
3	25	0	Inf. Dilution	lgK:1.52(0.01SD)	4	MCL	6727
4	40	0	Inf. Dilution	lgK:1.40(0.02SD)	3	MCL	6727
5	10	0	Inf. Dilution	dH:-3.4(0.03SD)	3	MCL	6747
6	23	0.01	Unknown	dH:-3.5(0.06SD)	4	MTD	6655
7	25	0	Inf. Dilution	dH:-3.33(3SF)	4	MCL	6727
8	25			dH:-3.3(2SF)	3	ENS	3560
9	40	0	Inf. Dilution	dH:-3.3(0.03SD)	3	MCL	6747
10	27	0	DMF Inf. Dilution	lgK:3.70(0.11SD)	5	MMR	6236
11	25	0.05	MeCN Et4NClO4	lgK:6.05(3SF)	5	MAG	5758
12	25	0.05	MeCN Et4NClO4	dH:-24.5(3SF)kJ	5	MCL	5758

Reaction No. 45778							
2<[12]O4> + Rb+1 = Rb+1_[12]O4(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		Methanol	lgK:3.03(3SF)	5	MCN	2251
2	25		Methanol	dH:-14.7(3SF)kJ	4	MCL	2251

Reaction No. 45788							
[12]O4 + Rb+1 = Rb+1_[12]O4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Methanol Unknown	lgK:1.65(0.05SD)	6	CIU	13297
2	25		Methanol	dH:-9.9(2SF)kJ	4	MCL	2251
3	25	0.1	PrCarbonate Unknown	lgK:1.69(0.04SD)	6	CIU	13297
4	25		PrCarbonate	lgK:1.69(0.04SD)	3	MPL	2970

Reaction No. 45879							
[2.2.2]crypt:56Benz + Rb+1 = Rb+1_[2.2.2]crypt:56Benz							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0.02	Methanol Et4NC1O4	lgK:7.2(0.05SD)	5	MPT	4821
2	25	0.02	Methanol Et4NC1O4	dH:-57.7(0.8SD)kJ	5	MCL	4821

Reaction No. 45886

Rb+1_24DiNitrphenol-1 + TriEtOlAm = Rb+1_TriEtOlAm_24DiNitrphenol-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		THF	lgK:1.886(4SF)	5	MCN	4832

Reaction No. 52572

Cl-1 + Rb+1 = Rb+1_Cl-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	100	0	P=500 Inf. Dilution	lgK:-0.52(2SF)	5	EOD	6495
2	150	0	P=500 Inf. Dilution	lgK:-0.21(2SF)	5	EOD	6495
3	200	0	P=500 Inf. Dilution	lgK:0.08(1SF)	5	EOD	6495
4	250	0	P=500 Inf. Dilution	lgK:0.4(1SF)	4	EOD	6495
5	300	0	P=500 Inf. Dilution	lgK:0.76(2SF)	3	EOD	6495
6	100	0	P=1000 Inf. Dilution	lgK:-0.58(2SF)	5	EOD	6495
7	150	0	P=1000 Inf. Dilution	lgK:-0.29(2SF)	5	EOD	6495
8	200	0	P=1000 Inf. Dilution	lgK:-0.02(1SF)	5	EOD	6495
9	250	0	P=1000 Inf. Dilution	lgK:0.26(2SF)	4	EOD	6495
10	300	0	P=1000 Inf. Dilution	lgK:0.54(2SF)	3	EOD	6495
11	100	0	P=2000 Inf. Dilution	lgK:-0.67(2SF)	5	EOD	6495
12	150	0	P=2000 Inf. Dilution	lgK:-0.4(1SF)	5	EOD	6495
13	200	0	P=2000 Inf. Dilution	lgK:-0.16(2SF)	5	EOD	6495
14	250	0	P=2000 Inf. Dilution	lgK:0.07(1SF)	4	EOD	6495
15	300	0	P=2000 Inf. Dilution	lgK:0.29(2SF)	3	EOD	6495

16	100	0	P=3000 Inf. Dilution	lgK: -0.72 (2SF)	5	EOD	6495
17	150	0	P=3000 Inf. Dilution	lgK: -0.47 (2SF)	5	EOD	6495
18	200	0	P=3000 Inf. Dilution	lgK: -0.25 (2SF)	5	EOD	6495
19	250	0	P=3000 Inf. Dilution	lgK: -0.05 (1SF)	4	EOD	6495
20	300	0	P=3000 Inf. Dilution	lgK: 0.14 (2SF)	3	EOD	6495
21	100	0	P=4000 Inf. Dilution	lgK: -0.74 (2SF)	5	EOD	6495
22	150	0	P=4000 Inf. Dilution	lgK: -0.51 (2SF)	5	EOD	6495
23	200	0	P=4000 Inf. Dilution	lgK: -0.31 (2SF)	5	EOD	6495
24	250	0	P=4000 Inf. Dilution	lgK: -0.14 (2SF)	4	EOD	6495
25	300	0	P=4000 Inf. Dilution	lgK: 0.03 (1SF)	3	EOD	6495
26	100	0	P=5000 Inf. Dilution	lgK: -0.75 (2SF)	5	EOD	6495
27	150	0	P=5000 Inf. Dilution	lgK: -0.54 (2SF)	5	EOD	6495
28	200	0	P=5000 Inf. Dilution	lgK: -0.36 (2SF)	5	EOD	6495
29	250	0	P=5000 Inf. Dilution	lgK: -0.2 (1SF)	4	EOD	6495
30	300	0	P=5000 Inf. Dilution	lgK: -0.05 (1SF)	3	EOD	6495
31	0	0	Inf. Dilution	lgK: -1.16 (3SF)	2	EOD	6495
32	18	0	Inf. Dilution	lgK: -0.77 (2SF)	4	MCN	140
33	25	0	Inf. Dilution	lgK: -0.3 (1SF)	3	MAC	931
34	25	0	Inf. Dilution	lgK: -0.4 (0.1SD)	3	CRV	2556
35	25	0	Inf. Dilution	lgK: -1.70 (3SF)	0	EES	5398
36	25	0	Inf. Dilution	lgK: -0.6 (1SF)	4	MCN	5398
37	25	0	Inf. Dilution	lgK: -0.96 (2SF)	3	EOD	6495
38	25	0	Inf. Dilution	lgK: -0.56 (0.083SD)	4	MCN	6562
39	25	0	Inf. Dilution	lgK: -0.55 (2SF)	4	EOD	9361
40	25	0	Inf. Dilution	lgK: -1.19 (3SF)	2	EMS	12547
41	25	0	Inf. Dilution	lgK: -0.55 (2SF)	4	CRV	32224
42	50	0	Inf. Dilution	lgK: -0.77 (2SF)	3	EOD	6495

43	75	0	Inf. Dilution	lgK:-0.6 (1SF)	6	EOD	6495
44	100	0	Inf. Dilution	lgK:-0.43 (2SF)	5	EOD	6495
45	125	0	Inf. Dilution	lgK:-0.27 (2SF)	5	EOD	6495
46	150	0	Inf. Dilution	lgK:-0.11 (2SF)	5	EOD	6495
47	175	0	Inf. Dilution	lgK:0.05 (1SF)	5	EOD	6495
48	200	0	Inf. Dilution	lgK:0.22 (2SF)	5	EOD	6495
49	225	0	Inf. Dilution	lgK:0.39 (2SF)	4	EOD	6495
50	250	0	Inf. Dilution	lgK:0.59 (2SF)	4	EOD	6495
51	275	0	Inf. Dilution	lgK:0.81 (2SF)	3	EOD	6495
52	300	0	Inf. Dilution	lgK:1.09 (3SF)	3	EOD	6495
53	25		Butan-1-ol:Methanol 19.7:80.3Wgt	lgK:1.25 (3SF)	4	MCN	5398
54	25		Butan-1-ol:Methanol 39.8:60.2Wgt	lgK:1.43 (3SF)	4	MCN	5398
55	25		Butan-1-ol:Methanol 51.4:48.6Wgt	lgK:1.53 (3SF)	4	MCN	5398
56	25		Butan-1-ol:Methanol 9.57:90.43Wgt	lgK:1.20 (3SF)	4	MCN	5398
57	25		Butan-1-ol:Water 89:11Wgt	lgK:3.27 (3SF)	4	MCN	5398
58	25		DMSO	lgK:0.42 (2SF)	4	MCN	5398
59	25		Dioxan:Methanol 29.3:70.7Wgt	lgK:1.92 (3SF)	4	MCN	5398
60	25		Dioxan:Methanol 45.2:54.8Wgt	lgK:2.59 (3SF)	4	MCN	5398
61	25		Dioxan:Methanol 52.6:47.4Wgt	lgK:3.00 (3SF)	4	MCN	5398
62	25		Dioxan:Methanol 62.3:37.7Wgt	lgK:3.86 (3SF)	4	MCN	5398
63	25		Dioxan:Water 70:30Wgt	lgK:2.59 (3SF)	4	MAG	140
64	25		Methanol	lgK:1.37 (3SF)	4	MCN	5398

Reaction No. 52743

IO3-1 + Rb+1 = Rb+1_IO3-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.19 (2SF)	3	MCN	5398
2	25	0	Inf. Dilution	lgK:-0.195 (3SF)	3	MDG	5398

Reaction No. 52759

I-1 + Rb+1 = Rb+1_I-1

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	100	0	P=500 Inf. Dilution	lgK:-0.71 (2SF)	5	EOD	6495
2	150	0	P=500 Inf. Dilution	lgK:-0.48 (2SF)	5	EOD	6495
3	200	0	P=500 Inf. Dilution	lgK:-0.24 (2SF)	5	EOD	6495
4	250	0	P=500 Inf. Dilution	lgK:0.03 (1SF)	4	EOD	6495
5	300	0	P=500 Inf. Dilution	lgK:0.35 (2SF)	3	EOD	6495
6	100	0	P=1000 Inf. Dilution	lgK:-0.79 (2SF)	5	EOD	6495
7	150	0	P=1000 Inf. Dilution	lgK:-0.57 (2SF)	5	EOD	6495
8	200	0	P=1000 Inf. Dilution	lgK:-0.34 (2SF)	5	EOD	6495
9	250	0	P=1000 Inf. Dilution	lgK:-0.11 (2SF)	4	EOD	6495
10	300	0	P=1000 Inf. Dilution	lgK:0.15 (2SF)	3	EOD	6495
11	100	0	P=2000 Inf. Dilution	lgK:-0.89 (2SF)	5	EOD	6495
12	150	0	P=2000 Inf. Dilution	lgK:-0.69 (2SF)	5	EOD	6495
13	200	0	P=2000 Inf. Dilution	lgK:-0.49 (2SF)	5	EOD	6495
14	250	0	P=2000 Inf. Dilution	lgK:-0.29 (2SF)	4	EOD	6495
15	300	0	P=2000 Inf. Dilution	lgK:-0.09 (1SF)	3	EOD	6495
16	100	0	P=3000 Inf. Dilution	lgK:-0.95 (2SF)	5	EOD	6495
17	150	0	P=3000 Inf. Dilution	lgK:-0.76 (2SF)	5	EOD	6495
18	200	0	P=3000 Inf. Dilution	lgK:-0.58 (2SF)	5	EOD	6495
19	250	0	P=3000 Inf. Dilution	lgK:-0.41 (2SF)	4	EOD	6495
20	300	0	P=3000 Inf. Dilution	lgK:-0.24 (2SF)	3	EOD	6495
21	100	0	P=4000 Inf. Dilution	lgK:-0.97 (2SF)	5	EOD	6495
22	150	0	P=4000 Inf. Dilution	lgK:-0.8 (1SF)	5	EOD	6495

23	200	0	P=4000 Inf. Dilution	lgK:-0.64 (2SF)	5	EOD	6495
24	250	0	P=4000 Inf. Dilution	lgK:-0.49 (2SF)	4	EOD	6495
25	300	0	P=4000 Inf. Dilution	lgK:-0.34 (2SF)	3	EOD	6495
26	100	0	P=5000 Inf. Dilution	lgK:-0.97 (2SF)	5	EOD	6495
27	150	0	P=5000 Inf. Dilution	lgK:-0.82 (2SF)	5	EOD	6495
28	200	0	P=5000 Inf. Dilution	lgK:-0.67 (2SF)	5	EOD	6495
29	250	0	P=5000 Inf. Dilution	lgK:-0.54 (2SF)	4	EOD	6495
30	300	0	P=5000 Inf. Dilution	lgK:-0.41 (2SF)	3	EOD	6495
31	0	0	Inf. Dilution	lgK:-1.08 (3SF)	6	EOD	6495
32	25	0	Inf. Dilution	lgK:0.04 (1SF)	0	MCN	931
33	25	0	Inf. Dilution	lgK:-1.52 (3SF)	3	EES	5398
34	25	0	Inf. Dilution	lgK:-0.96 (2SF)	6	EOD	6495
35	25	0	Inf. Dilution	lgK:0.04 (1SF)	0	CRV	7271
36	25	0	Inf. Dilution	lgK:-0.68 (2SF)	2	EMS	12547
37	25	0	Inf. Dilution	lgK:0.04 (1SF)	2	CRV	32224
38	50	0	Inf. Dilution	lgK:-0.84 (2SF)	3	EOD	6495
39	75	0	Inf. Dilution	lgK:-0.73 (2SF)	6	EOD	6495
40	100	0	Inf. Dilution	lgK:-0.61 (2SF)	5	EOD	6495
41	125	0	Inf. Dilution	lgK:-0.49 (2SF)	5	EOD	6495
42	150	0	Inf. Dilution	lgK:-0.37 (2SF)	5	EOD	6495
43	175	0	Inf. Dilution	lgK:-0.24 (2SF)	5	EOD	6495
44	200	0	Inf. Dilution	lgK:-0.1 (1SF)	5	EOD	6495
45	225	0	Inf. Dilution	lgK:0.05 (1SF)	4	EOD	6495
46	250	0	Inf. Dilution	lgK:0.22 (2SF)	4	EOD	6495
47	275	0	Inf. Dilution	lgK:0.42 (2SF)	3	EOD	6495
48	300	0	Inf. Dilution	lgK:0.67 (2SF)	3	EOD	6495
49	25		Acetone	lgK:2.32 (3SF)	3	MDG	5398
50	18		DMSO	lgK:0.64 (2SF)	3	MFP	931
51	25		DMSO	lgK:-0.13 (2SF)	5	MCN	5398
52	25		Ethanol	lgK:1.80 (3SF)	5	MCN	5398
53	25		Ethanol:Water 6.3:93.7Wgt	lgK:1.54 (3SF)	5	MCN	5398

54	25		Methanol	lgK:0.78 (2SF)	5	MCN	5398
55	25		Propan-1-ol	lgK:2.63 (3SF)	5	MCN	5398

Reaction No. 52842							
Br-1 + Rb+1 = Rb+1_Br-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	100	0	P=500 Inf. Dilution	lgK:-0.74 (2SF)	5	EOD	6495
2	150	0	P=500 Inf. Dilution	lgK:-0.43 (2SF)	5	EOD	6495
3	200	0	P=500 Inf. Dilution	lgK:-0.12 (2SF)	5	EOD	6495
4	250	0	P=500 Inf. Dilution	lgK:0.19 (2SF)	4	EOD	6495
5	300	0	P=500 Inf. Dilution	lgK:0.55 (2SF)	3	EOD	6495
6	100	0	P=1000 Inf. Dilution	lgK:-0.81 (2SF)	5	EOD	6495
7	150	0	P=1000 Inf. Dilution	lgK:-0.5 (1SF)	5	EOD	6495
8	200	0	P=1000 Inf. Dilution	lgK:-0.22 (2SF)	5	EOD	6495
9	250	0	P=1000 Inf. Dilution	lgK:0.06 (1SF)	4	EOD	6495
10	300	0	P=1000 Inf. Dilution	lgK:0.35 (2SF)	3	EOD	6495
11	100	0	P=2000 Inf. Dilution	lgK:-0.89 (2SF)	5	EOD	6495
12	150	0	P=2000 Inf. Dilution	lgK:-0.61 (2SF)	5	EOD	6495
13	200	0	P=2000 Inf. Dilution	lgK:-0.36 (2SF)	5	EOD	6495
14	250	0	P=2000 Inf. Dilution	lgK:-0.12 (2SF)	4	EOD	6495
15	300	0	P=2000 Inf. Dilution	lgK:0.11 (2SF)	3	EOD	6495
16	100	0	P=3000 Inf. Dilution	lgK:-0.93 (2SF)	5	EOD	6495
17	150	0	P=3000 Inf. Dilution	lgK:-0.67 (2SF)	5	EOD	6495
18	200	0	P=3000 Inf. Dilution	lgK:-0.44 (2SF)	5	EOD	6495
19	250	0	P=3000 Inf. Dilution	lgK:-0.23 (2SF)	4	EOD	6495

20	300	0	P=3000 Inf. Dilution	lgK:-0.04(1SF)	3	EOD	6495
21	100	0	P=4000 Inf. Dilution	lgK:-0.95(2SF)	5	EOD	6495
22	150	0	P=4000 Inf. Dilution	lgK:-0.71(2SF)	5	EOD	6495
23	200	0	P=4000 Inf. Dilution	lgK:-0.49(2SF)	5	EOD	6495
24	250	0	P=4000 Inf. Dilution	lgK:-0.31(2SF)	4	EOD	6495
25	300	0	P=4000 Inf. Dilution	lgK:-0.14(2SF)	3	EOD	6495
26	100	0	P=5000 Inf. Dilution	lgK:-0.94(2SF)	5	EOD	6495
27	150	0	P=5000 Inf. Dilution	lgK:-0.72(2SF)	5	EOD	6495
28	200	0	P=5000 Inf. Dilution	lgK:-0.53(2SF)	5	EOD	6495
29	250	0	P=5000 Inf. Dilution	lgK:-0.36(2SF)	4	EOD	6495
30	300	0	P=5000 Inf. Dilution	lgK:-0.21(2SF)	3	EOD	6495
31	0	0	Inf. Dilution	lgK:-1.43(3SF)	6	EOD	6495
32	25	0	Inf. Dilution	lgK:-1.60(3SF)	4	EES	5398
33	25	0	Inf. Dilution	lgK:-1.22(3SF)	6	EOD	6495
34	25	0	Inf. Dilution	lgK:-1.09(3SF)	2	EMS	12547
35	50	0	Inf. Dilution	lgK:-1.02(3SF)	6	EOD	6495
36	75	0	Inf. Dilution	lgK:-0.83(2SF)	6	EOD	6495
37	100	0	Inf. Dilution	lgK:-0.66(2SF)	5	EOD	6495
38	125	0	Inf. Dilution	lgK:-0.49(2SF)	5	EOD	6495
39	150	0	Inf. Dilution	lgK:-0.33(2SF)	5	EOD	6495
40	175	0	Inf. Dilution	lgK:-0.16(2SF)	5	EOD	6495
41	200	0	Inf. Dilution	lgK:0.01(1SF)	5	EOD	6495
42	225	0	Inf. Dilution	lgK:0.19(2SF)	4	EOD	6495
43	250	0	Inf. Dilution	lgK:0.38(2SF)	4	EOD	6495
44	275	0	Inf. Dilution	lgK:0.61(2SF)	3	EOD	6495
45	300	0	Inf. Dilution	lgK:0.87(2SF)	3	EOD	6495
46	25		DMSO	lgK:0.03(1SF)	4	MCN	5398
47	25		Dioxan:Methanol 29.3:70.7Wgt	lgK:1.88(3SF)	5	MCN	5398

48	25		Dioxan:Methanol 45.2:54.8Wgt	lgK:2.54 (3SF)	5	MCN	5398
49	25		Dioxan:Methanol 52.6:47.4Wgt	lgK:2.82 (3SF)	5	MCN	5398
50	25		Dioxan:Methanol 62.3:37.7Wgt	lgK:3.78 (3SF)	5	MCN	5398
51	25		Methanol	lgK:1.23 (3SF)	5	MCN	5398


Reaction No. 52941							
BrO3-1 + Rb+1 = Rb+1_BrO3-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.22 (2SF)	3	MCN	5398
2	25	0	Inf. Dilution	lgK:-0.235 (3SF)	3	MCN	5398
3	25	0	Inf. Dilution	lgK:-0.25 (2SF)	5	MCN	22093

Reaction No. 52956							
ClO3-1 + Rb+1 = Rb+1_ClO3-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.10 (2SF)	4	MCN	5398
2	25	0	Inf. Dilution	lgK:-0.14 (2SF)	5	MCN	22093

Reaction No. 53615							
NO3-1 + Rb+1 = Rb+1_NO3-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.05 (1SF)	4	MCN	5398
2	25	0	Inf. Dilution	lgK:-0.09 (1SF)	4	MCN	5398
3	25	0	Inf. Dilution	lgK:-0.075 (2SF)	4	MDG	5398
4	25	0	Inf. Dilution	lgK:-0.05 (1SF)	2	EMS	12547
5	25	0	Inf. Dilution	lgK:-0.09 (1SF)	5	MCN	20724
6	25	0	Inf. Dilution	lgK:-0.06 (1SF)	5	MCN	22093
7	25		Dioxan	lgK:1.25 (3SF)	4	MCN	5398
8	25		Dioxan:Methanol 29.3:70.8Wgt	lgK:1.98 (3SF)	4	MCN	5398
9	25		Dioxan:Methanol 45.2:54.8Wgt	lgK:2.78 (3SF)	4	MCN	5398
10	25		Dioxan:Methanol 52.6:47.4Wgt	lgK:3.26 (3SF)	4	MCN	5398
11	25		Dioxan:Methanol 62.3:37.7Wgt	lgK:4.08 (3SF)	4	MCN	5398


12	25		Dioxan:Water 65.1:34.9Wgt	lgK:1.65 (3SF)	4	MCN	5398
13	25		Dioxan:Water 68.5:31.5Wgt	lgK:1.94 (3SF)	4	MCN	5398
14	25		Dioxan:Water 71.1:28.9Wgt	lgK:2.20 (3SF)	4	MCN	5398
15	25		Dioxan:Water 75.1:24.9Wgt	lgK:2.63 (3SF)	4	MCN	5398

Reaction No. 53748




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:53.08 (4SF) kJ	6	CRV	8746
2	25	0	Inf. Dilution	dG:53.078 (0.4SD) kJ	5	CRV	27292
3	25	0	Inf. Dilution	dH:80.9 (0.8MD) kJ	6	CRV	8746
4	25	0	Inf. Dilution	dH:80.900 (0.4SD) kJ	5	CRV	27292
5	25	0	Inf. Dilution	Cp:20.786 (0.001SD) J/K	5	CRV	27292

Reaction No. 53811




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.53 (2SF)	4	MCN	931

Reaction No. 54020



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.60 (2SF)	3	CRV	552
2	25	0	Inf. Dilution	lgK:0.8 (1SF)	3	MAC	931
3	25	0	Inf. Dilution	lgK:0.60 (0.05SD)	4	CMN	7391
4	25	0.1	Unknown	lgK:0.6 (0.08SD)	5	MAC	5583
5	25	0.7	Unknown	lgK:-0.09 (0.05SD)	3	EES	7391
6	37	0.15	Unknown	lgK:0.60 (2SF)	6	CRV	552

Reaction No. 54229



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4	LiClO4	lgK:-0.1 (1SF)	2	MHG	931

Reaction No. 54230

Zn+2_Cl-1(3) + 2<Rb+1> = Zn+2_Rb+1(2)_Cl-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4	LiClO4	lgK:-0.5(1SF)	0	MHG	931

Reaction No. 54246							
Pb+2_Cl-1(4) + Rb+1 = Pb+2_Rb+1_Cl-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	LiCl	lgK:0.42(2SF)	5	MHG	931

Reaction No. 54249							
Pb+2_Cl-1(3) + Rb+1 = Pb+2_Rb+1_Cl-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	LiCl	lgK:-0.2(1SF)	5	MHG	931

Reaction No. 54257							
Bi+3_Cl-1(6) + Rb+1 = Bi+3_Rb+1_Cl-1(6)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.3(1SF)	1	EES	
2	25	3	LiCl	lgK:0.30(2SF)	3	MHG	931
3	45	3	LiCl	lgK:0.23(2SF)	3	MHG	931
4	65	3	LiCl	lgK:0.18(2SF)	3	MHG	931
5	25:65	3	LiCl	dH:-1.3(2SF)	3	MTD	931

Reaction No. 54258							
Bi+3_Cl-1(6) + 2<Rb+1> = Bi+3_Rb+1(2)_Cl-1(6)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.3(1SF)	1	EES	
2	25	3	LiCl	lgK:0.32(2SF)	3	MHG	931
3	45	3	LiCl	lgK:0.20(2SF)	3	MHG	931
4	65	3	LiCl	lgK:0.11(2SF)	3	MHG	931

Reaction No. 54311							
Zn+2_Br-1(4) + Rb+1 = Zn+2_Rb+1_Br-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	Unknown	lgK:0.20(2SF)	4	MHG	931
2	25	4	Unknown	lgK:0.17(2SF)	4	MHG	931

Reaction No. 54315							
$\text{Zn+2_Br-1(3)} + \text{Rb+1} = \text{Zn+2_Rb+1_Br-1(3)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	Unknown	$\lg K: -0.37(2\text{SF})$	4	MHG	931
2	25	4	Unknown	$\lg K: -0.4(1\text{SF})$	4	MHG	931

Reaction No. 54318							
$\text{Cd+2_Br-1(4)} + \text{Rb+1} = \text{Cd+2_Rb+1_Br-1(4)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4	LiClO ₄	$\lg K: -0.7(1\text{SF})$	4	MHG	931
2	35	4	LiClO ₄	$\lg K: -0.8(1\text{SF})$	4	MHG	931

Reaction No. 54937							
$2\text{<Rb+1>} + \text{CrO4-2} = \text{Rb+1(2)_CrO4-2(s)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 0.097(0.05\text{SD})$	4	ENS	766
2	25	0	Inf. Dilution	$\text{dH}: -5.9(0.1\text{SD})$	4	ENS	766

Reaction No. 56908							
$\text{Co+2_CN-1(5)} + \text{Rb+1} = \text{Co+2_Rb+1_CN-1(5)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	3	NaNO ₃	$\lg K: 0.57(0.01\text{SD})$	6	MPS	5951
2	25	0	Inf. Dilution	$\lg K: 0.6(1\text{SF})$	1	ESC	

Reaction No. 58329							
$[\text{15}]\text{O5:Benzo} + \text{Rb+1} = \text{Rb+1_}[\text{15}]\text{O5:Benzo}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	27	0	DMF Inf. Dilution	$\lg K: 2.15(0.09\text{SD})$	5	MMR	6236
2	25	0.05	MeCN Et ₄ NClO ₄	$\lg K: 3.84(3\text{SF})$	5	MAG	5758
3	25	0.05	MeCN Et ₄ NClO ₄	$\text{dH}: -18.9(3\text{SF}) \text{ kJ}$	5	MCL	5758
4	25	0.1	Methanol:Water 70:30Wgt Unknown	$\lg K: 1.8(0.2\text{SD})$	0	MCL	4522

Reaction No. 59075							
$[\text{24}]\text{O8:DiBenzo} + \text{Rb+1} = \text{Rb+1_}[\text{24}]\text{O8:DiBenzo}$							

No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	27	0	DMF Inf. Dilution	lgK:1.74(0.03SD)	5	MMR	6236
2	25	0.1	Methanol:Water 70:30Wgt Unknown	lgK:2.55(0.01SD)	5	MCL	4522

Reaction No. 59640							
H+1 + 5ATP-4 + Rb+1 = H+1_Rb+1_5ATP-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.25	Pr4N+ salt	lgK:6.69(0.09SD)	5	MGL	3595
2	10:45	0.25	Pr4N+ salt	dH:15.(2SF)kJ	3	MTD	3595

Reaction No. 60169							
Rb+1 + H+1_EDTA-4 = H+1_Rb+1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.32	CsCl	lgK:-0.57(2SF)	4	MGL	903

Reaction No. 60759							
V10028-6 + Rb+1 = Rb+1_V10028-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Me4N+ salt	lgK:2.8(2SF)	5	CRV	2556
2	25	0	Inf. Dilution	lgK:4.04(3SF)	2	EAE	


Reaction No. 60760							
Rb+1 + H+1_V10028-6 = H+1_Rb+1_V10028-6							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	Me4N+ salt	lgK:1.8(2SF)	5	CRV	2556
2	25	0	Inf. Dilution	lgK:2.83(3SF)	2	EAE	

Reaction No. 62689							
NTA-3 + Rb+1 = Rb+1_NTA-3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Unknown	lgK:0.4(1SF)	6	CRV	552
2	25	0.1	Unknown	lgK:0.25(2SF)	5	MSP	11516
Note (2): Harju L, Finn. Chem. Lett., 1985, 235							

Reaction No. 65878							
Rb+1 + P4012-4 = Rb+1_P4012-4							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.972 (4SF)	1	EOR	
2	25	0.1	Unknown	lgK:2.14 (3SF)	6	CRV	552

Reaction No. 65894




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.77 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:3.77 (3SF)	4	CRV	552

Reaction No. 65928




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.153 (4SF)	1	EOR	
2	25	0	Inf. Dilution	lgK:1.17 (3SF)	4	CRV	552
3	25	0.1	Unknown	lgK:0.73 (2SF)	6	CRV	552
4	20:40	0	Inf. Dilution	dH:1. (1SF)	4	CRV	552

Reaction No. 65936




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.97 (2SF)	4	CRV	552

Reaction No. 65975



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.2 (0.03SD)	3	CRV	552
2	25	0	Inf. Dilution	lgK:0.14 (2SF)	5	MCN	22093
3	25		MeCN	lgK:1.5 (2SF)	4	MCN	6714

Reaction No. 65976




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.54 (3SF)	4	CRV	552
2	25	0	Inf. Dilution	lgK:-2.60 (3SF)	2	CRV	22551
Note (2): Diff. values from same source! This one on p. 69							
3	25	0	Inf. Dilution	lgK:-2.42 (3SF)	2	CRV	22551

Note (3): Diff. values from same source! This one on p. 22


4	25	0	Inf. Dilution	dH:13.570 (5SF)	5	MCL	18892
---	----	---	---------------	-----------------	---	-----	-------

Reaction No. 67202



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:271.0 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:269.2 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:196.3 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:152.6 (4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:123.4 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-369.7 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-398.9 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-400.6 (4SF)	1	MTD	6422
9	227	0	Inf. Dilution	dH:-400.4 (4SF)	0	MTD	6422
10	327	0	Inf. Dilution	dH:-400.1 (4SF)	0	MTD	6422

Reaction No. 67203



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:66.89 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:66.46 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:48.79 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:38.04 (4SF)	3	ENS	6422
5	327	0	Inf. Dilution	lgK:30.87 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-381.8 (4SF) kJ	3	CRV	6330
7	25	0	Inf. Dilution	dG:-91.25 (4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dG:-381.79 (5SF) kJ	4	CRV	24003
9	25	0	Inf. Dilution	dG:-381.79 (5SF) kJ	2	EOD	30015
10	25	0	Inf. Dilution	dH:-394.6 (4SF) kJ	3	CRV	6330
11	25	0	Inf. Dilution	dH:-94.31 (4SF)	3	MTD	6422
12	25	0	Inf. Dilution	dH:-394.59 (5SF) kJ	2	EOD	30015
13	127	0	Inf. Dilution	dH:-98.48 (4SF)	2	MTD	6422
14	227	0	Inf. Dilution	dH:-98.39 (4SF)	1	MTD	6422
15	327	0	Inf. Dilution	dH:-98.25 (4SF)	0	MTD	6422

Reaction No. 67204

C(s) + 1.5<O2(g)> + 2<Rb(s)> = Rb+1(2)_CO3-2_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:184.1 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:182.9 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:133.3 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:103.5 (4SF)	4	ENS	6422
5	303	0	Inf. Dilution	lgK:87.82 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-1051.0 (5SF) kJ	5	CRV	6330
7	25	0	Inf. Dilution	dG:-251.1 (4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dH:-1136.0 (5SF) kJ	5	CRV	6330
9	25	0	Inf. Dilution	dH:-271.5 (4SF)	4	MTD	6422
10	127	0	Inf. Dilution	dH:-272.5 (4SF)	4	MTD	6422
11	227	0	Inf. Dilution	dH:-272.2 (4SF)	4	MTD	6422
12	303	0	Inf. Dilution	dH:-271.8 (4SF)	4	MTD	6422

Reaction No. 67205							
0.5<Cl2(g)> + Rb(s) = Rb+1_Cl-1_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:71.44 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:70.97 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:51.95 (4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:40.53 (4SF)	3	ENS	6422
5	327	0	Inf. Dilution	lgK:32.93 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-407.8 (4SF) kJ	3	CRV	6330
7	25	0	Inf. Dilution	dG:-97.46 (4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dG:-407.80 (5SF) kJ	5	CRV	24003
9	25	0	Inf. Dilution	dG:-407.80 (5SF) kJ	2	EOD	30015
10	25	0	Inf. Dilution	dH:-435.4 (4SF) kJ	3	CRV	6330
11	25	0	Inf. Dilution	dH:-104.1 (4SF)	4	MTD	6422
12	25	0	Inf. Dilution	dH:-435.35 (5SF) kJ	2	EOD	30015
13	27	0	Inf. Dilution	dH:-104.0 (4SF)	2	MTD	6422
14	127	0	Inf. Dilution	dH:-104.5 (4SF)	2	MTD	6422
15	227	0	Inf. Dilution	dH:-104.4 (4SF)	2	MTD	6422
16	327	0	Inf. Dilution	dH:-104.3 (4SF)	0	MTD	6422

Reaction No. 67206							
--------------------	--	--	--	--	--	--	--


0.5<F2(g)> + Rb(s) = Rb+1_F-1_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:92.60 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:91.99 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:67.64 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:53.03 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:43.31 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-126.3 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-133.3 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-133.7 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-133.6 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-133.4 (4SF)	4	MTD	6422

Reaction No. 67207							
0.5<I2(s)> + Rb(s) = Rb+1_I-1_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:57.63 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:57.27 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:42.61 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:33.38 (4SF)	3	ENS	6422
5	327	0	Inf. Dilution	lgK:26.99 (4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-78.62 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dG:-328.86 (5SF) kJ	5	CRV	24003
8	25	0	Inf. Dilution	dG:-328.86 (5SF) kJ	2	EOD	30015
9	25	0	Inf. Dilution	dH:-79.79 (4SF)	4	MTD	6422
10	25	0	Inf. Dilution	dH:-333.80 (5SF) kJ	2	EOD	30015
11	127	0	Inf. Dilution	dH:-80.04 (4SF)	2	MTD	6422
12	227	0	Inf. Dilution	dH:-87.67 (4SF)	2	MTD	6422
13	327	0	Inf. Dilution	dH:-87.53 (4SF)	0	MTD	6422

Reaction No. 67208							
0.5<O2(g)> + 2<Rb(s)> = Rb2O(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:52.57 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:52.20 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:37.27 (4SF)	4	ENS	6422


4	227	0	Inf. Dilution	lgK:28.29 (4SF)	4	ENS	6422
5	270	0	Inf. Dilution	lgK:25.44 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-71.72 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-81.02 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-82.21 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-82.22 (4SF)	4	MTD	6422
10	270	0	Inf. Dilution	dH:-82.18 (4SF)	4	MTD	6422

Reaction No. 67209



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:252.5 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:250.9 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:183.8 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:143.5 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:116.7 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-344.5 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-367.2 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-368.4 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-368.3 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-368.1 (4SF)	4	MTD	6422

Reaction No. 67210



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:406.9 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:404.2 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:296.4 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:231.6 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:188.5 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-555.1 (4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-591.4 (4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-592.5 (4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-592.2 (4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-591.7 (4SF)	4	MTD	6422

Reaction No. 67211

4.5<O2(g)> + 2<Rb(s)> + 4<Si(s)> = Rb20.4SiO2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:710.7(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:706.0(4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:518.0(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:405.1(4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:329.9(4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-969.6(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-1032.(4SF)	4	MTD	6422
8	127	0	Inf. Dilution	dH:-1033.(4SF)	4	MTD	6422
9	227	0	Inf. Dilution	dH:-1033.(4SF)	4	MTD	6422
10	327	0	Inf. Dilution	dH:-1032.(4SF)	4	MTD	6422

Reaction No. 67212							
2<O2(g)> + 2<Rb(s)> + S(s) = Rb+1(2)_SO4-2_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:230.7(4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:229.1(4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:166.4(4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:128.6(4SF)	3	ENS	6422
5	327	0	Inf. Dilution	lgK:103.4(4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-314.7(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dG:-1316.90(6SF) kJ	5	CRV	24003
8	25	0	Inf. Dilution	dH:-343.1(4SF)	4	MTD	6422
9	127	0	Inf. Dilution	dH:-345.4(4SF)	4	MTD	6422
10	227	0	Inf. Dilution	dH:-346.1(4SF)	3	MTD	6422
11	327	0	Inf. Dilution	dH:-346.4(4SF)	0	MTD	6422

Reaction No. 67249							
O2(g) + Rb(s) = RbO2(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:40.89(4SF)	3	ENS	6422
2	27	0	Inf. Dilution	lgK:40.59(4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:28.41(4SF)	2	ENS	6422
4	227	0	Inf. Dilution	lgK:21.15(4SF)	1	ENS	6422
5	327	0	Inf. Dilution	lgK:16.35(4SF)	0	ENS	6422


6	25	0	Inf. Dilution	dG:-55.78 (4SF)	3	EFE	6422
7	25	0	Inf. Dilution	dG:-55.788 (5SF)	3	CRV	31291
8	25	0	Inf. Dilution	dH:-66.60 (4SF)	2	MTD	6422
9	127	0	Inf. Dilution	dH:-66.69 (4SF)	1	MTD	6422
10	227	0	Inf. Dilution	dH:-66.16 (4SF)	0	MTD	6422
11	327	0	Inf. Dilution	dH:-65.55 (4SF)	0	MTD	6422

Reaction No. 67775							
F-1 + Rb+1 = Rb+1_F-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	P=136.1 Unknown/m	lgK:-0.07 (1SF)	5	MSP	6571
2	25	1	P=408.3 Unknown/m	lgK:-0.09 (1SF)	5	MSP	6571
3	100	0	P=500 Inf. Dilution	lgK:1.03 (3SF)	5	EOD	6495
4	150	0	P=500 Inf. Dilution	lgK:1.14 (3SF)	5	EOD	6495
5	200	0	P=500 Inf. Dilution	lgK:1.28 (3SF)	5	EOD	6495
6	250	0	P=500 Inf. Dilution	lgK:1.47 (3SF)	4	EOD	6495
7	300	0	P=500 Inf. Dilution	lgK:1.72 (3SF)	3	EOD	6495
8	25	1	P=680.5 Unknown/m	lgK:-0.10 (2SF)	5	MSP	6571
9	25	1	P=952.6 Unknown/m	lgK:-0.12 (2SF)	5	MSP	6571
10	100	0	P=1000 Inf. Dilution	lgK:0.98 (2SF)	5	EOD	6495
11	150	0	P=1000 Inf. Dilution	lgK:1.07 (3SF)	5	EOD	6495
12	200	0	P=1000 Inf. Dilution	lgK:1.18 (3SF)	5	EOD	6495
13	250	0	P=1000 Inf. Dilution	lgK:1.32 (3SF)	4	EOD	6495
14	300	0	P=1000 Inf. Dilution	lgK:1.5 (2SF)	3	EOD	6495
15	25	1	P=1225 Unknown/m	lgK:-0.15 (2SF)	5	MSP	6571
16	25	1	P=1497 Unknown/m	lgK:-0.17 (2SF)	5	MSP	6571

17	25	1	P=1769 Unknown/m	lgK:-0.20 (2SF)	5	MSP	6571
18	100	0	P=2000 Inf. Dilution	lgK:0.92 (2SF)	5	EOD	6495
19	150	0	P=2000 Inf. Dilution	lgK:0.98 (2SF)	5	EOD	6495
20	200	0	P=2000 Inf. Dilution	lgK:1.05 (3SF)	5	EOD	6495
21	250	0	P=2000 Inf. Dilution	lgK:1.13 (3SF)	4	EOD	6495
22	300	0	P=2000 Inf. Dilution	lgK:1.24 (3SF)	3	EOD	6495
23	25	1	P=2041 Unknown/m	lgK:-0.23 (2SF)	5	MSP	6571
24	100	0	P=3000 Inf. Dilution	lgK:0.89 (2SF)	5	EOD	6495
25	150	0	P=3000 Inf. Dilution	lgK:0.92 (2SF)	5	EOD	6495
26	200	0	P=3000 Inf. Dilution	lgK:0.96 (2SF)	5	EOD	6495
27	250	0	P=3000 Inf. Dilution	lgK:1.01 (3SF)	4	EOD	6495
28	300	0	P=3000 Inf. Dilution	lgK:1.07 (3SF)	3	EOD	6495
29	100	0	P=4000 Inf. Dilution	lgK:0.87 (2SF)	5	EOD	6495
30	150	0	P=4000 Inf. Dilution	lgK:0.88 (2SF)	5	EOD	6495
31	200	0	P=4000 Inf. Dilution	lgK:0.9 (1SF)	5	EOD	6495
32	250	0	P=4000 Inf. Dilution	lgK:0.93 (2SF)	4	EOD	6495
33	300	0	P=4000 Inf. Dilution	lgK:0.95 (2SF)	3	EOD	6495
34	100	0	P=5000 Inf. Dilution	lgK:0.87 (2SF)	5	EOD	6495
35	150	0	P=5000 Inf. Dilution	lgK:0.86 (2SF)	5	EOD	6495
36	200	0	P=5000 Inf. Dilution	lgK:0.86 (2SF)	5	EOD	6495
37	250	0	P=5000 Inf. Dilution	lgK:0.86 (2SF)	4	EOD	6495
38	300	0	P=5000 Inf. Dilution	lgK:0.87 (2SF)	3	EOD	6495
39	0	0	Inf. Dilution	lgK:0.94 (2SF)	6	EOD	6495


40	25	0	Inf. Dilution	lgK:0.96 (2SF)	6	EOD	6495
41	25	1	Unknown/m	lgK:-0.07 (1SF)	5	MSP	6571
42	50	0	Inf. Dilution	lgK:1. (1SF)	6	EOD	6495
43	75	0	Inf. Dilution	lgK:1.04 (3SF)	6	EOD	6495
44	100	0	Inf. Dilution	lgK:1.09 (3SF)	5	EOD	6495
45	125	0	Inf. Dilution	lgK:1.15 (3SF)	5	EOD	6495
46	150	0	Inf. Dilution	lgK:1.22 (3SF)	5	EOD	6495
47	175	0	Inf. Dilution	lgK:1.31 (3SF)	5	EOD	6495
48	200	0	Inf. Dilution	lgK:1.4 (2SF)	5	EOD	6495
49	225	0	Inf. Dilution	lgK:1.52 (3SF)	4	EOD	6495
50	250	0	Inf. Dilution	lgK:1.67 (3SF)	4	EOD	6495
51	275	0	Inf. Dilution	lgK:1.85 (3SF)	3	EOD	6495
52	300	0	Inf. Dilution	lgK:2.08 (3SF)	3	EOD	6495

Reaction No. 68824




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		MeCN	lgK:1.8 (2SF)	4	MCN	6714

Reaction No. 70354




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-806. (3SF) kJ	5	ENS	7275

Reaction No. 70359




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-664. (3SF) kJ	0	ENS	7275

Reaction No. 70364



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-637. (3SF) kJ	0	ENS	7275


Reaction No. 70369



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	25	0	Inf. Dilution	dH:-596.(3SF)kJ	5	ENS	7275
---	----	---	---------------	-----------------	---	-----	------

Reaction No. 70582




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:3.083(4SF)	5	MSL	14335

Reaction No. 71163




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:-2.66(3SF)	3	CRV	7761
2	25	0	Inf. Dilution	dH:199.4(4SF)kJ	3	CRV	7761

Reaction No. 71164




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:-2.91(3SF)	3	CRV	7761

Reaction No. 71221




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-306.2(4SF)kJ	5	CRV	6330
2	25	0	Inf. Dilution	dH:-367.4(4SF)kJ	5	CRV	6330

Reaction No. 72504



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.05	Et4NClO4	lgK:2.(1SF)	3	MGL	5315
2	25	0.05	DMF Et4NClO4	lgK:2.84(0.05SD)	4	MMC	5315
3	25	0.05	MeCN Et4NClO4	lgK:4.39(0.05SD)	4	MMC	5315
4	25	0.05	Methanol Et4NClO4	lgK:3.97(0.05SD)	4	MMC	5315
5	25	0.05	PrCarbonate Et4NClO4	lgK:4.2(0.01SD)	4	MMC	5315

Reaction No. 72587



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25		HMPT	lgK:1.17 (3SF)	4	MCN	5756
Note (1): Using Fuoss-Hia equ; other fits also given							

Reaction No. 73322							
Rb+1_[12]O4 + [12]O4 = Rb+1_[12]O4(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Methanol Unknown	lgK:0.87 (0.05SD)	6	CIU	13297

Reaction No. 73325							
Rb+1_[15]O5 + [15]O5 = Rb+1_[15]O5(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	Methanol Unknown	lgK:2.23 (0.05SD)	6	CIU	13297

Reaction No. 75049							
RbVUO6(s) + 4<H+1> = Rb+1 + VO2+1 + UO2+2 + 2<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:105.4 (4SF) kJ	1	MCL	22973

Reaction No. 75053							
RbNbUO6(s) + 6<H+1> + 3<F-1> = Rb+1 + NbOF3 + UO2+2 + 3<H2O>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:229.8 (4SF) kJ	1	MCL	22973


Reaction No. 75057							
3<O2(g)> + Rb(s) + U(s) + V(s) = RbVUO6(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-2460. (4SF) kJ	1	MCL	22973

Reaction No. 75061							
Nb(s) + 3<O2(g)> + Rb(s) + U(s) = RbNbUO6(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-2633. (4SF) kJ	1	MCL	22973

Reaction No. 75546							
0.5<N2(g)> + 1.5<O2(g)> + Rb(s) = Rb+1_NO3-1_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #

1	25	0	Inf. Dilution	dG:-395.78 (5SF) kJ	5	CRV	24003
---	----	---	---------------	---------------------	---	-----	-------

Reaction No. 75576




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-913.0 (4SF) kJ	3	CRV	6330
2	25	0	Inf. Dilution	dH:-971.0 (4SF) kJ	3	CRV	6330

Reaction No. 75607




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-306.9 (4SF) kJ	3	CRV	6330
2	25	0	Inf. Dilution	dH:-437.2 (4SF) kJ	3	CRV	6330

Reaction No. 75902




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.77 (3SF)	2	EAE	
2	37	0.15	KCl	lgK:-0.4 (1SF)	5	MGL	1230

Reaction No. 75903




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.533 (3SF)	2	EAE	
2	37	0.15	KCl	lgK:0.12 (2SF)	5	MGL	1230

Reaction No. 76265



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.16	Unknown	lgK:-0.37 (2SF)	5	MGL	14764

Reaction No. 76528



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.322 (4SF)	5	MSL	14335
2	25	0	Inf. Dilution	lgK:1.313 (4SF)	5	CRV	26559
3	25	0	Inf. Dilution	lgK:1.285 (4SF)	5	MSL	26595

Reaction No. 76529							
$\text{Rb+1(2)}_{\text{SO4-2}}(\text{s}) = 2\langle\text{Rb+1}\rangle + \text{SO4-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: -0.834(3\text{SF})$	5	CRV	26559

Reaction No. 76530							
$\text{Rb+1}_{\text{ClO3-1}}(\text{s}) = \text{Rb+1} + \text{ClO3-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$dH: 11.410(5\text{SF})$	5	MCL	18892

Reaction No. 76534							
$\text{Rb+1}_{\text{Br-1}}(\text{s}) = \text{Rb+1} + \text{Br-1}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 1.120(4\text{SF})$	5	MSL	14335

Reaction No. 76535							
$\text{Mg+2}_{\text{Rb+1}_{\text{Br-1}}(3)}_{\text{H2O(6)}}(\text{s}) = \text{Rb+1} + \text{Mg+2} + 3\langle\text{Br-1}\rangle + 6\langle\text{H2O}\rangle$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 4.612(4\text{SF})$	5	MSL	14335

Reaction No. 77390							
$1.5\langle\text{Cl2(g)}\rangle + 6\langle\text{H2(g)}\rangle + \text{Mg(s)} + 3\langle\text{O2(g)}\rangle + \text{Rb(s)} = \text{Mg+2}_{\text{Rb+1}_{\text{Cl-1}}(3)}_{\text{H2O(6)}}(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$dG: -2538.2(5\text{SF})\text{ kJ}$	3	EPZ	14335


Reaction No. 77391							
$1.5\langle\text{Br2(l)}\rangle + 6\langle\text{H2(g)}\rangle + \text{Mg(s)} + 3\langle\text{O2(g)}\rangle + \text{Rb(s)} = \text{Mg+2}_{\text{Rb+1}_{\text{Br-1}}(3)}_{\text{H2O(6)}}(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$dG: -2447.9(5\text{SF})\text{ kJ}$	3	EPZ	14335

Reaction No. 77480							
$\text{Rb+1} + \text{NO3-1} = \text{Rb+1}_{\text{NO3-1}}(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	$\lg K: 0.2(1\text{SF})$	1	ELC	

Reaction No. 78235							
$\text{Zn+2} + \text{Rb+1} + 3\langle\text{Br-1}\rangle = \text{Zn+2}_{\text{Rb+1}_{\text{Br-1}}(3)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:0.4546(4SF)	1	ELC	
---	----	---	---------------	-----------------	---	-----	--

Reaction No. 78249




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.5238(4SF)	1	ELC	

Reaction No. 78265




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.35(4SF)	1	ELC	

Reaction No. 78268




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.183(4SF)	1	ELC	

Reaction No. 78289




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.536(4SF)	1	ELC	

Reaction No. 78485




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.3742(4SF)	1	ELC	

Reaction No. 78517



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.017(4SF)	1	ELC	

Reaction No. 78534



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:1.861(4SF)	1	ELC	

Reaction No. 78628

EDTA-4 + Rb+1 + H+1 = H+1_Rb+1_EDTA-4							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.3(4SF)	1	ELC	

Reaction No. 79006							
3<Rb+1> + AsO4-3 = Rb+1(3)_AsO4-3_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.405(4SF)	1	ELC	

Reaction No. 79007							
Rb+1 + F-1 = Rb+1_F-1_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-6.42(4SF)	1	ELC	

Reaction No. 79018							
Rb+1 + I-1 = Rb+1_I-1_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-1.17(4SF)	1	ELC	

Reaction No. 79022							
2<Rb+1> + CO3-2 = Rb+1(2)_CO3-2_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-7.75(4SF)	1	ELC	

Reaction No. 79136							
Rb+1 + OH-1 = Rb+1_OH-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-0.5053(4SF)	1	ELC	

Reaction No. 79142							
Rb+1 + NO2-1 = Rb+1_NO2-1_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-2.503(4SF)	1	ELC	

Reaction No. 80136							
3<Cl2(g)> + Rb(s) + Ta(s) = Ta+5_Rb+1_Cl-1(6)_(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH:-326.(3SF)	4	CRV	22971

Reaction No. 80179							
$3\text{Cl}_2(\text{g}) + \text{Nb}(\text{s}) + \text{Rb}(\text{s}) = \text{Nb}_5\text{Rb}_{11}\text{Cl}_{16}(\text{s})$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dH: -306. (3SF)	4	CRV	22971

Data Assessment

Weight	Assessment
9	highest accuracy
8	multi-determined; excellent dependability
7	trustworthy; outstanding single determination
6	better than average reliability
5	average single determination
4	some doubt
3	poorly known
2	guess to achieve consistency (or just as bad)
1	no information but consistent
0	problematic/inconsistent

Techniques

Abbrev	Method
CIU	Critical IUPAC publication (crit.)
CMN	Several experimental values (crit.)
CRV	Critical review
EAE	Automated extrapolation
EES	Personal estimate
EFE	Free Energy relations
EIU	Critical IUPAC review (estim.)
ELC	Linear Combination of Reactions
EMS	Mean Spherical Approximation
ENS	Not specified

EOD	Calculated from data of others
EOR	Other Reaction Constants
EPZ	Pitzer model correction
ESC	Standard conditions anchor
MAC	Activity coefficient (not specified)
MAG	Silver electrode e.m.f.
MCL	Calorimetry
MCN	Conductivity
MCV	Cyclic voltammetry
MDG	Combination of Thermodynamic Data
MDS	Distribution between two phases
MEF	Electromotoric force, not specified
MFP	Freezing point
MGL	Glass electrode
MHG	Emf with amalgam electrode
MIS	Ion selective electrode
MMC	Metal competition
MMR	Nuclear magnetic resonance
MPH	pH method, not specified
MPL	Polarography
MPS	Potentiometry and Spectrophotometry
MPT	Potentiometry
MSC	Miscellaneous
MSL	Solubility
MSP	Spectroscopy
MTD	Temperature difference

References

Reference No.: 140(64SiM)

Stability Constants of Metal-ion Complexes SP17, 1964 Sillen LG; Martell AE; The Chemical Soc., London

Reference No.: 425(94LuL)

Inorg. Chim. Acta, 1994, 219, 217 - 220; Lucas J; Lincoln SF; Solution Studies of

Monovalent Metal Complex Ions of the Bibracchial Lariat Ether 7,16-Bis(2-methoxyethyl)-1,4,10,13-tetraoxa-7,16-diazacyclooctadecane

Reference No.: 552(95SMM)

NIST Critical Stability Constants of Metal Complexes Database, 1995 Smith RM; Martell AE; Motekaitis RJ; Version 2.0; National Institute of Standards and Technology, Gaithersburg, USA

Reference No.: 766(87BrA)

Report EPA/600/3-87/012, 1987 Brown DS; Allison JD; MINTEQA1, An Equilibrium Metal Speciation Model: Users Manual; U.S. Environmental Protection Agency, Athens, Georgia 30613

Reference No.: 775(71CCM)

Selected Constants, 1971 Charlot G; Collumeau A; Marchon MJC; Oxidation-Reduction Potentials of Inorganic Substances in Aqueous Solution; Butterworths, London

Reference No.: 903(77And)

Critical Survey of Stability Constants of EDTA Complexes, 1977 Anderegg G; IUPAC Chemical Data Series. 14; Pergamon Press, Oxford

Reference No.: 906(79Per)

IUPAC Chemical Data Series No. 22, 1979 Perrin DD; Stability Constants of Metal-Ion Complexes, First Edition Part B, Organic Ligands; Pergamon, Oxford

Reference No.: 931(71SiM)

Stability Constants of Metal-ion Complexes SP25, 1971 Sillen LG; Martell AE; Supplement No 1 to Special Publication No 25; Chemical Society, London

Reference No.: 999(91MaM)

Estimation of Constants for JESS Database, 1991 May PM; May RF

Reference No.: 1230(81CDR)

Inorg. Chim. Acta, 1981, 56, L45 - L47; Cucinotta V; Daniele PG; Rigano C; Sammartano S; The Formation of Proton and Alkali-Metal Complexes with Ligands of Biological Interest in Aqueous Solution. Potentiometric and PMR Investigation of Li⁺, Na⁺, K⁺, Rb⁺, Cs⁺ and NH₄⁺ Complexes with Citrate

Reference No.: 1318(90DSK)

Helv. Chim. Acta, 1990, 73, 140 - 148; Delgado R; Siegfried LC; Kaden TA; Metal Complexes with Macrocyclic Ligands. Part XXXI. Protonation Studies and Complexation Properties of Tetraazamacrocyclic Methylene phosphonates with Earth-Alkali-Ions

Reference No.: 1437(91SMC)

Pure Appl. Chem., 1991, 63, 1015 - 1080; Smith RM; Martell AE; Chen YT; Critical Evaluation of Stability Constants for Nucleotide Complexes with Protons and Metal Ions

Reference No.: 1572(75And)

Helv. Chim. Acta, 1975, 58, 1218 - 1225; Anderegg G; Thermodynamik der Metallkomplexbildung mit Polyoxadiazamacrocyclen

Reference No.: 2185(88DaS)

J. Chem. Soc., Faraday Trans. 1, 1988, 84, 3539 - 3545; Danil de Namor AF; Salazar FF; Thermodynamic Parameters for the Complexation Process between Metal(I) Cations and Dibenzocryptand 222 in Dipolar, Aprotic Solvents

Reference No.: 2251(87Bus)

J. Solution Chem., 1987, 16, 181 - 190; Buschmann H-J; Stability Constants and

Thermodynamic Data for Complexes of 12-Crown-4 with Alkali Metal and Alkaline-Earth Cations in Methanol Solutions

Reference No.: 2360(83Van)

Polyhedron, 1983, 2, 285 - 289; van Uitert LG; Chelate Compound Stability Constant Calculations on Metal Diketonate Complexes

Reference No.: 2373(89And)

Comprehensive Coordination Chemistry, Vol. 2, 1989, 777 - 792; Anderegg G; Complexones

Reference No.: 2511(92Bus)

Inorg. Chim. Acta, 1992, 195, 51 - 61; Buschmann H-J; A Comparison of Different Experimental Techniques for the Determination of the Stabilities of Polyether, Crown Ether and Cryptand Complexes in Solution

Reference No.: 2542(82SSP)

Inorg. Chim. Acta, 1982, 66, 147 - 155; Sigel H; Scheller KH; Prus B; Metal Ion/Buffer Interactions. Stability of Alkali and Alkaline Earth Ion Complexes with Triethanolamine (Tea), 2-Amino-2(hydroxy- methyl)-1,3-Propanediol (Tris) and 2-[Bis(2-hydroxyethyl)amino]2 (hydroxymethyl)-1,3-propanediol (Bistris) in Aqueous and Mixed Solvents

Reference No.: 2556(93MSM)

NIST Critical Stability Constants of Metal Complexes Database, 1993 Martell AE; Smith RM; Motekaitis RJ; Version 1.0; National Institute of Standards and Technology, Gaithersburg, USA

Reference No.: 2600(88PoJ)

J. Chem. Soc., Faraday Trans. 1, 1988, 84, 959 - 967; Pointud Y; Juillard J; Interactions between Metal Cations and the Ionophore Lasalocid Part 2- Gibbs Functions, Enthalpies and Entropies for Complexation of Alkali-metal Cations by Lasalocid and Bromolasalocid

Reference No.: 2604(82BDJ)

Can. J. Chem., 1982, 60, 981 - 989; Bolte J; Demuyne C; Jeminet G; Juillard J; Tissier C; Etude Comparee de Trois Antibiotiques Ionophores: X.537 A (Lasalocide), A.23187 (Calcimycine) et X.14547 A. Complexation des Cations IA et IIA, Transport de Ca++

Reference No.: 2802(94OOK)

J. Chem. Soc., Faraday Trans., 1994, 90, 127 - 131; Ozutsumi K; Ohtsu K; Kawashima T; Thermodynamics of Complexation of 18-Crown-6 with Sodium, Potassium, Rubidium, Caesium and Ammonium Ions in N,N-Dimethylformamide

Reference No.: 2931(81CGS)

J. Am. Chem. Soc., 1981, 103, 1384 - 1389; Cox BG; Garcia-Rosas J; Schneider H; Solvent Dependence of the Stability of Cryptate Complexes

Reference No.: 2938(84CVR)

J. Am. Chem. Soc., 1984, 106, 5965 - 5969; Cox BG; van Truong Ng.; Rzeszutarska J; Schneider H; Rates and Equilibria of Alkali Metal and Silver Ion Complex Formation with Monensin in Ethanol

Reference No.: 2944(80LIS)

J. Am. Chem. Soc., 1980, 102, 475 - 479; Lamb JD; Izatt RM; Swain CS; Christensen JJ; A Systematic Study of the Effect of Macrocyclic Ring Size and Donor Atom Type on the Log K, ΔH , and ΔS of Reactions at 25 C in Methanol of Mono- and Divalent Cations with Crown Ethers

Reference No.: 2956(78CSS)

J. Am. Chem. Soc., 1978, 100, 4746 - 4749; Cox BG; Schneider H; Stroka J; Kinetics of Alkali Metal Complex Formation with Cryptands in Methanol

Reference No.: 2970(80MDD)

J. Chem. Soc., Dalton Trans., 1980,, 865 - 868; Massaux J; Desreux JF; Duyckaerts G; Electrochemical Studies on Alkali-metal Complexes with the Small Macrocyclic 1,4,7,10-Tetraoxacyclododecane. Polarographic and Potentiometric Determination of the Stability Constants in Propylene Carbonate

Reference No.: 3283(75LeS)

J. Am. Chem. Soc., 1975, 97, 6700 - 6707; Lehn J-M; Sauvage JP; [2]-Cryptates: Stability and Selectivity of Alkali and Alkaline-Earth Macrobicyclic Complexes

Reference No.: 3303(75SNJ)

J. Chem. Soc., Dalton Trans., 1975,, 2381 - 2386; Shchori E; Nae N; Jagur-Grodzinski JJ; Stability Constants of Complexes of a Series of Metal Cations with 6,7,9,10,17,18,20,21-Octahydrodibenzo[b,k][1,4,7,10,13,16]hexa-oxa- -cylo-octadecin (Dibenzo-18-crown-6) in Aqueous Solutions

Reference No.: 3560(75Mid)

Chem. Soc. Rev., 1975, 4, 549 - 568; Midgley D; Alkali-metal Complexes in Aqueous Solution

Reference No.: 3595(86DDS)

J. Chem. Res. (S), 1986,, 164 - 165; De Robertis A; De Stefano C; Sammartano S; Cali R; Purrello R; Rigano C; Alkali-metal and Alkaline-earth-metal Ion Complexes with Adenosine 5'-triphosphate in Aqueous Solution. Thermodynamic Parameters and their Dependence on Temperature and Ionic Strength

Reference No.: 3850(86Bus)

Inorg. Chim. Acta, 1986, 120, 125 - 129; Buschmann H-J; The Macrocyclic and Cryptate Effect. 7. Influence of Structural Changes on the Complexation Behaviour of Aza Crown Ethers and Cryptands in Different Solvents

Reference No.: 3854(86Bus)

Inorg. Chim. Acta, 1986, 125, 31 - 35; Buschmann H-J; The Macrocyclic and Cryptate Effects. 5. Complexation of Alkali Ions by Monocyclic and Bicyclic Ligands in Methanol

Reference No.: 4399(94BCS)

J. Solution Chem., 1994, 23, 569 - 577; Buschmann H-J; Cleve E; Schollmeyer E; The Complexation of Alkaline Cations by Crown Ethers and Cryptands in Acetone

Reference No.: 4522(76ITN)

J. Am. Chem. Soc., 1976, 98, 7626 - 7630; Izatt RM; Terry RE; Nelson DP; Chan Y; Eatough DJ; Bradshaw JS; Hansen LD; Christensen JJ; Calorimetric Titration Study of the Interaction of Some Uni- and Bivalent Cations with Benzo-15-crown-5, 18-Crown-6, Dibenzo-24-crown-8, and Dibenzo-27-crown-9 in Methanol-Water Solvents, at 25 C and $\mu = 0.1$

Reference No.: 4523(76ITH)

J. Am. Chem. Soc., 1976, 98, 7620 - 7626; Izatt RM; Terry RE; Haymore BL; Hansen LD; Dalley NK; Avondet AG; Christensen JJ; Calorimetric Titration Study of the Interaction of Several Uni- and Bivalent Cations with 15-Crown-5, 18-Crown-6, and Two Isomers of Dicyclohexo-18-crown-6 in Aqueous Solution at 25C and $\mu = 0.1$

Reference No.: 4650(80KuM)

J. Inorg. Nucl. Chem., 1980, 42, 573 - 578; Kulstad S; Malmsten LA; Diaza-Crown Ethers - II. Stability Constants of a Cyclic and a Bicyclic Diaza-Polyether with Some Alkali Cations in Acetonitrile

Reference No.: 4763(84CVR)

J. Chem. Soc., Faraday Trans. 1, 1984, 80, 3275 - 3284; Cox BG; van Truong Ng.; Rzeszutarska J; Schneider H; Stability Constants of Complexes of Monensin and Lasalocid with Alkali-metal and Alkaline-earth-metal Ions in Protic and Polar Aprotic Solvents

Reference No.: 4777(78HoP)

J. Solution Chem., 1978, 7, 357 - 372; Hoogerheide JG; Popov AI; Study of Monensin Complexes with Monovalent Metal Ions in Anhydrous Methanol Solutions

Reference No.: 4791(77RLW)

J. Phys. Chem., 1977, 81, 2118 - 2122; Rodriguez LJ; Liesegang GW; White RD; Farrow MM; Purdie N; Eyring EM; Kinetic Studies of the Complexation of Monovalent Sodium, Potassium, Rubidium, Thallium, and Silver Cations by Aqueous 15-Crown-5

Reference No.: 4796(87DSG)

J. Chem. Soc., Faraday Trans. 1, 1987, 83, 2663 - 2670; Danil de Namor AF; Salazar FF; Greenwood P; Complexation and Transfer Free Energies of Metal-ion Dibenzo cryptates

Reference No.: 4798(86DGH)

J. Chem. Soc., Faraday Trans. 1, 1986, 82, 349 - 357; Danil de Namor AF; Ghousseini L; Hill T; Alkali-metal Cryptates in Nitromethane

Reference No.: 4799(85DGL)

J. Chem. Soc., Faraday Trans. 1, 1985, 81, 2495 - 2502; Danil de Namor AF; Ghousseini L; Lee WH; Stability Constants and Free Energies of Complexation of Metal-ion Cryptates in Nitromethane

Reference No.: 4801(85DaG)

J. Chem. Soc., Faraday Trans. 1, 1985, 81, 781 - 791; Danil de Namor AF; Ghousseini L; Enthalpies and Entropies of Complexation of Cryptand 222 and Metal Ions in Propylene Carbonate and Acetonitrile

Reference No.: 4802(84DaG)

J. Chem. Soc., Faraday Trans. 1, 1984, 80, 2349 - 2360; Danil de Namor AF; Ghousseini L; Thermodynamics of Metal-ion Cryptates and Cryptand 222 in N,N-Dimethylformamide and Dimethyl Sulphoxide

Reference No.: 4821(80CKS)

J. Phys. Chem., 1980, 84, 320 - 323; Cox BG; Knop D; Schneider H; Thermodynamics and Kinetics of Alkali Metal Ion Complexes with 5,6-Benzo-4,7,13,16,21,24-hexaoxa-1,10-diazabicyclo[8.8.8] hexacosane in Methanol

Reference No.: 4822(80CGS)

J. Phys. Chem., 1980, 84, 3178 - 3183; Cox BG; Garcia-Rosas J; Schneider H; Kinetics and Equilibria of Cryptate Formation in Propylene Carbonate

Reference No.: 4832(76FlG)

J. Phys. Chem., 1976, 80, 679 - 685; Flora HB; Gilkerson WR; Association of Triethanolamine and Related Ligands with Alkali Metal Ions and Ion Pairs in Tetrahydrofuran at 25 C

Reference No.: 5315(94LuL)

J. Chem. Soc., Dalton Trans., 1994,, 423 - 427; Lucas JB; Lincoln SF; Monovalent Metal-ion Complexation by a Bibracchial Lariat Ether in Several Solvents

Reference No.: 5326(86DDS)

J. Chem. Res. (M), 1986,, 1301 - 1347; De Robertis A; De Stefano C; Sammartano S; Cali R; Purrello R; Rigano C; Alkali-metal and Alkali-earth-metal Ion Complexes with Adenosine 5'-Triphosphate in Aqueous Solution. Thermodynamic Parameters and their Dependence on Temperature and Ionic Strength

Reference No.: 5398(82Hog)

IUPAC Chemical Data Series No. 21, 1982 Hogfeldt E; Stability Constants of Metal-ion Complexes, 2nd Suppl., Part A, Inorganic Ligands; Pergamon, Oxford

Reference No.: 5583(75Rea)

J. Phys. Chem., 1975, 79, 422 - 425; Reardon EJ; Dissociation Constants of some Monovalent Sulfate Ion Pairs at 25C from Stoichiometric Activity Coefficients

Reference No.: 5605(78CDH)

J. Chem. Thermodyn., 1978, 10, 903 - 906; Cox JD; Drowart J; Hepler LG; Medvedev VA; Wagman DD; CODATA recommended Key Values for Thermodynamics, 1977. Report of the CODATA Task Group on Key Values for Thermodynamics, 1977

Reference No.: 5674(74DeF)

Biochemistry, 1974, 13, 5022 - 5032; Degani H; Friedman HL; Ion Binding by X-537A. Formulas, Formation Constants, and Spectra of Complexes

Reference No.: 5756(74HPP)

J. Solution Chem., 1974, 3, 563 - 583; Hanna EM; Pethybridge AD; Prue JE; Spiers DJ; Electrolyte Conductivity of Salts in Hexamethylphosphotriamide

Reference No.: 5758(88Bus)

J. Solution Chem., 1988, 17, 277 - 286; Buschmann H-J; The Influence of Acetonitrile on Complex Formation of Crown Ethers Containing Different Donor Atoms

Reference No.: 5951(67PrW)

J. Chem. Soc. (A), 1967,, 1291 - 1298; Pratt JM; Williams RJP; Low-spin Cobalt(II) Complexes. Part II. Cyanide Complexes

Reference No.: 6236(96GMS)

Polyhedron, 1996, 15, 3897 - 3903; Goff CM; Matchette MA; Shabestary N; Khazaeli S; Complexation of Caesium and Rubidium Cations with Crown Ethers in N,N-Dimethylformamide

Reference No.: 6330(95LiF)

CRC Handbook of Chemistry and Physics, 76th Edn., 1995 Lide DR; Frederikse HPR; A Ready-Reference Book of Chemical and Physical Data; CRC Press, Cleveland, Ohio, U.S.A.

Reference No.: 6422(95BaP)

Thermochemical Data of Pure Substances, 3rd Edn., 1995 Barin I; Platzki G; Weinheim, Germany

Reference No.: 6488(88ShH)

Geochim. Cosmochim. Acta, 1988, 52, 2009 - 2036; Shock EL; Helgeson HC; Calculation of the Thermodynamic and Transport Properties of Aqueous Species at High Pressures and Temperatures: Correlation Algorithms for Ionic Species and Equation of State Predictions to 5 kb and 1000 C

Reference No.: 6495(97SSH)

Geochim. Cosmochim. Acta, 1997, 61, 1359 - 1412; Sverjensky DA; Shock EL; Helgeson HC; Prediction of the Thermodynamic Properties of Aqueous Metal Complexes to 1000C and 5kb

Reference No.: 6562(72DJP)

J. Chem. Soc., Faraday Trans. 1, 1972, 68, 1583 - 1585; Dunsmore HS; Jalota SK; Paterson R; Ion Association of Rubidium Chloride in Aqueous Solutions at 25C

Reference No.: 6571(93MaA)

J. Solution Chem., 1993, 22, 859 - 872; Manohar S; Atkinson G; The Effect of High Pressure on the Ion Pair Equilibrium Constant of Alkali Metal Fluorides: A Spectrophotometric Study

Reference No.: 6655(69IRN)

Science, 1969, 164, 443 - 444; Izatt RM; Rytting JH; Nelson DP; Haymore BL; Christensen JJ; Binding of Alkali Metal Ions by Cyclic Polyethers: Significance in Ion Transport Processes

Reference No.: 6714(75YeK)

Can. J. Chem., 1975, 53, 3448 - 3451; Yeager HL; Kratochvil B; Conductance Study of Ion Pairing of Alkali Metal Tetrafluoroborates and Hexafluorophosphates in Acetonitrile

Reference No.: 6727(71INR)

J. Am. Chem. Soc., 1971, 93, 1619 - 1623; Izatt RM; Nelson DP; Rytting JH; Haymore BL; Christensen JJ; A Calorimetric Study of the Interaction in Aqueous Solution of Several Uni- and Bivalent Metal Ions with the Cyclic Polyether Dicyclohexyl-18-crown-6 at 10, 25, and 40C

Reference No.: 6747(86BWF)

Can. J. Chem., 1986, 64, 5 - 10; Boughriet A; Wartel M; Fischer J-C; Influence de Nitrates Metalliques sur l'Equilibre de Dissociation Ionique $\text{N}_2\text{O}_4 = \text{NO} + \text{NO}_2$ dans le Sulfolane

Reference No.: 7232(95OKO)

J. Chem. Soc., Faraday Trans., 1995, 91, 4375 - 4380; Ohtsu K; Kawashima T; Ozutsumi K; Thermodynamics of Complexation of Sodium, Potassium, Rubidium, Caesium and Ammonium Ions with 18-Crown-6 in Acetonitrile and Propylene Carbonate

Reference No.: 7271(98SMM)

NIST Critical Stability Constants of Metal Complexes Database, 1998 Smith RM; Martell AE; Motekaitis RJ; Version 5.0; U.S. Dept. Commerce, Gaithersburg, MD, U.S.A.

Reference No.: 7275(98Atk)

Physical Chemistry, 6th Edn., 1998 Atkins PW; Oxford University Press, Oxford, U.K.

Reference No.: 7276(88CoW)

Advanced Inorganic Chemistry, 5th Edn., 1988 Cotton FA; Wilkinson G; John Wiley & Sons Inc., N.Y., U.S.A

Reference No.: 7381(97Woo)

Physical Chemistry, 1997 Woodbury G; Brooks/Cole Publishing Co., Pacific Grove, U.S.A.

Reference No.: 7391(82MiS)

Am. J. Sci., 1982, 282, 1508 - 1540; Millero FJ; Schreiber DR; Use of the Ion Pairing Model to Estimate Activity Coefficients of the Ionic Components of Natural Waters

Reference No.: 7421(97Mar)

Ion Properties, 1997 Marcus Y; Marcel Dekker Inc., New York, U.S.A.

Reference No.: 7761(89Bra)

J. Phys. Chem. Ref. Data, 1989, 18, 1 - 21; Bratsch SG; Standard Electrode Potentials and Temperature Coefficients in Water at 298.15 K

Reference No.: 8746(89CWM)

CODATA Key Values for Thermodynamics, 1989 Cox JD; Wagman DD; Medvedev VA; Values obtained from www.codata.org/codata/databases Apr. 2000 and <http://www.codata.org/resources/databases/key1.html> Sept. 2011; Hemisphere Publishing Corp., N.Y., U.S.A.

Reference No.: 9029(97SSW)

Geochim. Cosmochim. Acta, 1997, 61, 907 - 950; Shock EL; Sassani DC; Willis M;

Sverjensky DA; Inorganic Species in Geologic Fluids: Correlations among Standard Molal Thermodynamic Properties of Aqueous Ions and Hydroxide Complexes

Reference No.: 9361(84WCB)

Am. J. Sci., 1984, 284, 668 - 705; Wood SA; Crerar DA; Brantley SL; Borcsik M; Mean Molal Stoichiometric Activity Coefficients of Alkali Halides and Related Electrolytes in Hydrothermal Solutions

Reference No.: 10174(95OHS)

J. Phys. Chem. Ref. Data, 1995, 24, 1401 - 1560; Oelkers EH; Helgeson HC; Shock EL; Sverjensky DA; Johnson JW; Pokrovskii VA; Summary of the Apparent Standard Partial Molal Gibbs Free Energies of Formation of Aqueous Species, Minerals, and Gases at Pressures 1 to 5000 Bars and Temperatures 25 to 1000C

Reference No.: 11516(00PeP)

IUPAC Stability Constants Database, 2000 Pettit LD; Powell HKJ; Release 4; Academic Software, U.K.

Reference No.: 12547(98SBB)

J. Phys. Chem., 1998, B102, 4411 - 4417; Simonin J-P; Bernard O; Blum L; Real Ionic Solutions in the Mean Spherical Approximation. 3. Osmotic and Activity Coefficients for Associating Electrolytes in the Primitive Model

Reference No.: 13213(61Mac)

The Principles of Electrochemistry, 1961 MacInnes DA; Dover Publications, New York

Reference No.: 13297(03ADC)

Pure Appl. Chem., 2003, 75, 71 - 102; Arnaud-Neu F; Delgado R; Chaves S; Critical Evaluation of Stability Constants and Thermodynamic Functions of Metal Complexes of Crown-ethers

Reference No.: 14335(93BCV)

J. Solution Chem., 1993, 22, 173 - 181; Balarew C; Christov C; Valyashko V; Petrenko S; Thermodynamics of Formation of Carnallite Type Double Salts

Reference No.: 14764(64StS)

Solubilities of Inorganic and Organic Compounds, Vol. 2, Part 2, 1964 Stephen H; Stephen T; Ternary and Multicomponent Systems, Part 2; Pergamon Press, The Macmillan Company, New York, 1964

Reference No.: 18892(38Pit)

J. Am. Chem. Soc., 1938, 60, 1828 - 1829; Pitzer KS; The Heats of Solution of Cesium Perchlorate, Rubidium Perchlorate, and Lead Phosphate

Reference No.: 20724(74MWK)

J. Solution Chem., 1974, 3, 91 - 102; Masterton WL; Welles H; Knox JH; Millero FJ; Volume Change of Ion Pair Formation. Rubidium Nitrate and Thallium(I) Nitrate in Water

Reference No.: 22093(71JBJ)

Electrochim. Acta, 1971, 16, 687 - 700; Justice M-C; Bury R; Justice J-C; Determination Conductimetrique des Coefficients d'Activite: sels Alcalins a Anions Oxygenes dans l'Eau a 25C

Reference No.: 22551(06Inz)

Encyclopedia of Electrochemistry, Vol. 7a, 2006, 17 - 75; Inzelt G; Standard, Formal and Other Characteristic Potentials of Selected Electrode Reactions

Reference No.: 22971(71HWH)

Chem. Rev., 1971, 71, 127 - 137; Hill JO; Worsley IG; Heppler LG; Thermochemistry and Oxidation Potentials of Vanadium, Niobium and Tantalum

Reference No.: 22973(96KCS)

Thermochim. Acta, 1996, 277, 53 - 63; Kariakine N; Chernoroukov N; Souleimanov E; La Thermochimie des Oxydes Complexes d'Uranium(VI), du Vanadium(V), (du Niobium(V)) et des Elements Alcalins

Reference No.: 24003(10Bal)

Collect. Czech. Chem. Commun., 2010, 75, 21 - 31; Balej J; Verification of Accuracy of Standard Thermodynamic Data of Inorganic Substances

Reference No.: 26559(13Hub)

Russ. J. Phys. Chem., 2013, A87, 777 - 779; Hu B; Prediction of Phase Equilibrium for the Aqueous Systems Rb+, Cs+/Cl-, SO42- _ H2O and K+, Cs+/Cl-, SO42- _ H2O at 25 C

Reference No.: 26595(07HSL)

Calphad, 2007, 31, 541 - 544; Hu B; Song P; Li Y; Li W; Solubility Prediction in the Ternary Systems NaCl-RbCl-H2O, KCl-CsCl-H2O and KBr-CsBr-H2O at 25 C Using the Ion-Interaction Model

Reference No.: 27292(13LBM)

OECD Chemical Thermodynamics Series, Volume 13a, 2013 Lemire RJ; Berner U; Musikas C; Palmer DA; Taylor P; Tochiyama O; Chemical Thermodynamics of Iron Part 1; OECD (NEA) Issy-les-Moulineaux, France

Reference No.: 28172(15DCC)

J. Chem. Eng. Data, 2015, 60, 3792 - 3799; Djamali E; Chapman WG; Cox KR; Prediction of the Standard State Partial Molar Volume of Aqueous Electrolytes to High Temperatures and High Pressures

Reference No.: 29520(17WoC)

Geochim. Cosmochim. Acta, 2017, 213, 635 - 676; Wolery TJ; Colon CFJ; Chemical Thermodynamic Data. 1. The Concept of Links to The Chemical Elements and the Historical Development of Key Thermodynamic Data

Reference No.: 30015(16KAK)

Fluid Phase Equilib., 2016, 412, 177 - 198; Kim SH; Anantpinijwatna A; Kang JW; Gani R; Analysis and Modeling of Alkali Halide Aqueous Solutions

Reference No.: 31291(84PSG)

U.S. Bur. Mines Bull. 677, 1984 Pankratz LB; Stuve JM; Gokcen NA; Thermodynamic Data for Mineral Technology; US Det. Interior, Bur. Mines, Washington, DC, USA

Reference No.: 32152(20AAG)

Chem. Geol., 2020, 550, 119699-1 - 119699-12; Aranovich LYa; Akinfiev NN; Golunova M; Quartz Solubility in Sodium Carbonate Solutions at High Pressure and Temperature

Reference No.: 32224(80BeT)

Lawrence Berkeley Laboratory Report LBL-11448, 1980 Benson LV; Teague LS; A Tabulation of Thermodynamic Data for Chemical Reactions Involving 8 Elements Common to Radioactive Waste Package Systems