

JESS Thermodynamic Database v8.9

Rhodium

24-Jan-23

Reaction No. 5004							
Rh+3 + 3<e-1> = Rh(s)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:38.4(0.05SD)	3	MDG	5461
2	25	0	Inf. Dilution	dG:-46.(1.SD)	0	ENS	869
Note (2): Low wgt for internal consistency							
3	25	0	Inf. Dilution	dG:-192.(3SF)kJ	0	CRV	7421
4	25	0	Inf. Dilution	dG:-52.450(5SF)	4	CRV	9029
5	25	0	Inf. Dilution	E:0.758(3SF)	5	CRV	6330
6	25	0	Inf. Dilution	E:0.758(3SF)	4	CRV	22551
Note (6): Reported as E0 (not E0') but conditions indicated are HClO4, pH 5							
7	25	0	Inf. Dilution	dH:-42.830(5SF)	4	CRV	9029


Reaction No. 5005							
Rh+6 + 3<e-1> = Rh+3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18	0.15	HNO3	lgK:76.0(0.05SD)	0	MEF	812
Note (1): Low wgt for internal consistency							
2	18	1	HClO4	lgK:77.0(0.05SD)	3	MEF	812

Reaction No. 5006							
Rh+4 + e-1 = Rh+3							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	18	0.1	H2SO4	lgK:24.2(0.05SD)	3	MEF	813
2	18	0.5	H2SO4	lgK:24.8(0.05SD)	3	MEF	813
3	25	0.25	H2SO4	lgK:23.3(0.05SD)	0	MEF	814
4	25	0.5	H2SO4	lgK:24.3(0.05SD)	3	MEF	814
5	25	3	H2SO4	lgK:24.4(0.05SD)	3	MEF	814

Reaction No. 5007							
Rh+3 + e-1 = Rh+2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:18.2(0.06SD)	4	ENS	802
---	----	---	---------------	------------------	---	-----	-----

Reaction No. 5008




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:44.0(0.1SD)	0	MDG	600

Reaction No. 5010




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1:7	NaOH	lgK:-4.(0.3SD)	3	ENS	4998

Reaction No. 5011




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:-33.(0.3SD)	4	ENS	4998

Reaction No. 5012




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23	0.001	Unknown	lgK:-22.32(0.3SD)	0	MSP	817
2	25	0	Inf. Dilution	lgK:-21.2(3SF)	1	ELC	

Reaction No. 5013




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO ₄	lgK:-5.(0.3SD)	3	MSP	810

Reaction No. 5020



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.1(2SF)	1	ELC	
2	25	1	HClO ₄	lgK:7.42(0.05SD)	0	MPL	820
3	90	4	HClO ₄	lgK:7.6(0.05SD)	0	MSP	819


Reaction No. 5023



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
----	---	-------	--------	-------------	---	-------	--------


1	55	0.1	NaClO4	lgK:-4.8(0.05SD)	0	MGL	5022
---	----	-----	--------	------------------	---	-----	------

Reaction No. 5024




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	55	0.1	NaClO4	lgK:-6.0(0.05SD)	0	MGL	5022

Reaction No. 5025




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	55	0.1	NaClO4	lgK:-7.3(0.05SD)	0	MGL	5022

Reaction No. 5026




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	75	2.5	NaClO4	lgK:-0.22(0.05SD)	5	MKN	815
2	80	2.5	NaClO4	lgK:-0.30(0.05SD)	5	MKN	815
3	85	2.5	NaClO4	lgK:-0.40(0.05SD)	5	MKN	815
4	75:85	2.5	NaClO4	dH:-9.03(0.8SD)	5	EVH	815

Reaction No. 5108




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:10.1(0.05SD)	4	ENS	802
2	25	0	Inf. Dilution	E:0.600(3SF)	5	CRV	6330

Reaction No. 5592




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.02	Unknown	lgK:6.86(3SF)	4	MGL	905

Reaction No. 5593




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.02	Unknown	lgK:9.88(3SF)	4	MGL	905

Reaction No. 5703




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.02	Unknown	lgK:6.69(3SF)	3	MGL	905

Reaction No. 5704




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.02	Unknown	lgK:9.38(3SF)	3	MGL	905

Reaction No. 5741




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.02	Unknown	lgK:6.92(3SF)	5	MGL	905

Reaction No. 5742




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.02	Unknown	lgK:9.95(3SF)	5	MGL	905

Reaction No. 18524




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	27	0.1	Cl-1 salt	lgK:7.34(3SF)	4	MGL	1555

Reaction No. 18525




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	27	0.1	Cl-1 salt	lgK:10.37(4SF)	4	MGL	1555

Reaction No. 42723



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:4.47(3SF)	5	MSP	4090

Reaction No. 42724



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	1	NaClO4	lgK:7.91(3SF)	5	MSP	4090

Reaction No. 42764							
Rh+2(2)_Butanoic-1(4) + MeCN = Rh+2(2)_MeCN_Butanoic-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23		Benzene	lgK:3.230(4SF)	5	MCV	4040
2	23		Benzene	dH:-5.1(0.2SD)	4	MCL	4040

Reaction No. 42765							
Rh+2(2)_MeCN_Butanoic-1(4) + MeCN = Rh+2(2)_MeCN(2)_Butanoic-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23		Benzene	lgK:1.431(4SF)	5	MCV	4040
2	23		Benzene	dH:-8.3(0.4SD)	4	MCL	4040

Reaction No. 42766							
Rh+2(2)_Butanoic-1(4) + Pyridine = Rh+2(2)_Pyridine_Butanoic-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23		Benzene	lgK:8.204(4SF)	5	MCV	4040
2	23		Benzene	dH:-11.2(0.2SD)	4	MCL	4040

Reaction No. 42767							
Rh+2(2)_Pyridine_Butanoic-1(4) + Pyridine = Rh+2(2)_Pyridine(2)_Butanoic-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23		Benzene	lgK:4.380(4SF)	5	MCV	4040
2	23		Benzene	dH:-11.2(0.3SD)	4	MCL	4040

Reaction No. 42768							
Rh+2(2)_Butanoic-1(4) + 1MeImidazole = Rh+2(2)_1MeImidazole_Butanoic-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23		Benzene	lgK:9.00(3SF)	5	MCV	4040
2	23		Benzene	dH:-12.4(0.3SD)	4	MCL	4040

Reaction No. 42769							
Rh+2(2)_1MeImidazole_Butanoic-1(4) + 1MeImidazole = Rh+2(2)_1MeImidazole(2)_Butanoic-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23		Benzene	lgK:4.903(4SF)	5	MCV	4040
2	23		Benzene	dH:-10.5(0.5SD)	4	MCL	4040

Reaction No. 42770							
--------------------	--	--	--	--	--	--	--

Rh+2(2)_Butanoic-1(4) + Piperid = Rh+2(2)_Piperid_Butanoic-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23		Benzene	lgK:9.00(3SF)	5	MCV	4040
2	23		Benzene	dH:-13.2(0.1SD)	4	MCL	4040

Reaction No. 42771							
Rh+2(2)_Piperid_Butanoic-1(4) + Piperid = Rh+2(2)_Piperid(2)_Butanoic-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23		Benzene	lgK:4.778(4SF)	5	MCV	4040
2	23		Benzene	dH:-12.5(0.4SD)	4	MCL	4040

Reaction No. 44319							
2SHBenz-2 + Rh+3 = Rh+3_2SHBenz-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23		Ethanol:Water 40:60Wgt	lgK:8.55(3SF)	4	ENS	906

Reaction No. 44320							
Rh+3_2SHBenz-2 + 2SHBenz-2 = Rh+3_2SHBenz-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23		Ethanol:Water 40:60Wgt	lgK:6.75(3SF)	4	ENS	906

Reaction No. 44707							
Rh+3 + H+1_TAR-2 = Rh+3_H+1_TAR-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23			lgK:8.45(3SF)	4	MSP	906

Reaction No. 45061							
Rh+3 + H+1_PAR-2 = Rh+3_H+1_PAR-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23			lgK:10.55(4SF)	4	MSP	906

Reaction No. 45062							
Rh+3 + 2<H+1_PAR-2> = Rh+3_H+1(2)_PAR-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	23			lgK:22.6(3SF)	4	MSP	906

Reaction No. 53798							
--------------------	--	--	--	--	--	--	--

Rh+3_NH3(5)_N3-1 + H+1 = Rh+3_H+1_NH3(5)_N3-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	60			lgK:-1.95 (3SF)	0	MKN	931

Reaction No. 54084							
Rh+3_NH3(5) + SO4-2 = Rh+3_NH3(5)_SO4-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4	NaClO4	lgK:0.0 (1SF)	4	MSP	931
2	65	4	NaClO4	lgK:-0.15 (2SF)	4	MSP	931


Reaction No. 54204							
Rh+3_Cl-1(2) + Cl-1 = Rh+3_Cl-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.5 (1SF)	1	ELC	
2	25	1	HClO4	lgK:1.38 (3SF)	0	MPL	140
3	40			lgK:1.69 (3SF)	0	MEP	931
4	120	6	HClO4	lgK:3. (1SF)	0	MSP	140

Reaction No. 54205							
Rh+3_Cl-1(3) + Cl-1 = Rh+3_Cl-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	HClO4	lgK:1.39 (3SF)	4	MRX	931
2	25	1	HClO4	lgK:1.16 (3SF)	4	MPL	140
3	40			lgK:0.47 (2SF)	0	MEP	931
4	120	6	HClO4	lgK:2.4 (2SF)	3	MSP	140

Reaction No. 54206							
Rh+3_Cl-1(4) + Cl-1 = Rh+3_Cl-1(5)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	HClO4	lgK:0.6 (0.05SD)	5	MRX	818
2	25	1	HClO4	lgK:1.67 (0.01SD)	0	MPL	821
3	30	2.5	HClO4	lgK:0.90 (2SF)	4	MKN	931
4	30	4	HClO4	lgK:0.9 (0.05SD)	5	MKN	824
5	35	2.5	HClO4	lgK:0.83 (2SF)	4	MKN	931
6	35	4	HClO4	lgK:0.8 (0.05SD)	5	MKN	824
7	40	2.5	HClO4	lgK:0.80 (2SF)	4	MKN	931
8	40	4	HClO4	lgK:0.8 (0.05SD)	5	MKN	824


9	40			lgK:-0.51 (2SF)	0	MEP	931
10	45	2.5	HClO4	lgK:0.77 (2SF)	4	MKN	931
11	45	4	HClO4	lgK:0.8 (0.05SD)	5	MKN	824
12	90	4	HClO4	lgK:0.5 (0.1SD)	5	MSP	5460
13	120	6	HClO4	lgK:1.4 (2SF)	3	MSP	140
14	30:45	4	HClO4	dH:-3.8 (0.2SD)	5	EVH	899

Reaction No. 54207




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	15	4	HClO4	lgK:-0.72 (2SF)	5	MGL	823
2	18			lgK:-0.3 (1SF)	0	MSP	140
3	20	4	HClO4	lgK:-0.85 (0.05SD)	5	MKN	823
4	25	0.1	HClO4	lgK:-0.2 (0.05SD)	5	MRX	818
5	25	1	HClO4	lgK:-0.3 (0.05SD)	5	MPL	821
6	25	4	HClO4	lgK:-0.93 (0.05SD)	5	MKN	823
7	30	4	HClO4	lgK:-1.04 (3SF)	5	MGL	823
8	35	4	HClO4	lgK:-1.14 (3SF)	4	MKN	823
9	35	4	NaClO4	lgK:-1.1 (0.05SD)	5	MKN	822
10	90	4	HClO4	lgK:-0.3 (0.1SD)	5	MSP	5460
11	120	6	HClO4	lgK:-0.25 (2SF)	3	MSP	140

Reaction No. 54208



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	HClO4	lgK:3.0 (0.2SD)	3	MSP	5460
2	25	1	HClO4	lgK:2.45 (3SF)	4	MPL	140
3	25	1	HClO4	lgK:2.62 (0.1SD)	5	MPL	820
4	75	2.5	NaClO4	lgK:-0.05 (1SF)	4	MKN	815
5	80	2.5	NaClO4	lgK:-0.18 (2SF)	4	MKN	815
6	85	2.5	NaClO4	lgK:-0.15 (2SF)	4	MKN	815
7	90	4	HClO4	lgK:2.5 (0.05SD)	5	MSP	819
8	120	6	HClO4	lgK:3. (1SF)	3	MSP	140
9	75:85	4	NaClO4	dH:1.04 (3SF)	5	MTD	815

Reaction No. 54209



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4	NaClO4	lgK:-0.80 (2SF)	3	MKN	931
2	65	4	LiClO4	lgK:-0.60 (2SF)	3	MKN	931
3	65	4	NaClO4	lgK:-0.74 (2SF)	3	MKN	931
4	65	5	NaClO4	lgK:-0.66 (2SF)	3	MKN	931
5	84	0	Inf. Dilution	lgK:4.95 (3SF)	0	MAN	931
6	77:97			dH:3.5 (2SF)	3	MKN	931

Reaction No. 54296							
Rh+3_NH3(5) + Br-1 = Rh+3_NH3(5)_Br-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	4	NaClO4	lgK:-1.0 (2SF)	4	MKN	931
2	35	1.5	NaClO4	lgK:-1.2 (0.05SD)	5	MKN	5398
3	35	1.5	NaClO4	lgK:-0.8 (0.05SD)	5	MSP	5398
4	65	4	NaClO4	lgK:-1.1 (2SF)	4	MKN	931
5	84	0	Inf. Dilution	lgK:3.20 (3SF)	0	MAN	931
Note (5): Low wgt for internal consistency							

Reaction No. 54672							
Rh+3_Cl-1(6) + 3<e-1> = Rh(s) + 6<Cl-1>							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:31.6 (3SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:21.8 (0.05SD)	0	MDG	600
3	25	0	Inf. Dilution	E:0.431 (3SF)	0	CRV	6330
4	25	0	Inf. Dilution	E:0.5 (1SF)	0	CRV	22551
Note (4): Reported as E0 (not E0') but condition indicated is HCl - reactive							

Reaction No. 54693							
Rh+3 + H2O = Rh+3_OH-1 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	1	NaClO4	lgK:-2.9 (0.05SD)	5	MSP	5021
2	23	0.001	Unknown	lgK:-3.43 (3SF)	4	MSP	817
3	25	0	Inf. Dilution	lgK:-3.4 (2SF)	3	CRV	6478
4	25	2.5	NaClO4	lgK:-3.4 (0.05SD)	5	MGL	
Note (4): Cited Ref: 815 incorrectly							
5	45	2.5	NaClO4	lgK:-3.2 (0.05SD)	5	MGL	
Note (5): Cited Ref: 815 incorrectly							

6	60	2.5	NaClO4	lgK:-3.1(0.05SD)	5	MGL	
Note (6): Cited Ref: 815 incorrectly							
7	75	2.5	NaClO4	lgK:-3.0(0.05SD)	5	MGL	815
8	80	2.5	NaClO4	lgK:-2.9(0.05SD)	5	MGL	815
9	85	2.5	NaClO4	lgK:-2.9(0.05SD)	5	MGL	815
10	25	0	Inf. Dilution	dH:11.1(3SF)	0	CRV	6478
Note (10): Low wgt for internal consistency							
11	25:85	2.5	NaClO4	dH:4.3(0.1SD)	5	MGL	815

Reaction No. 54694							
Rh+3_NH3(5) + H2O = Rh+3_NH3(5)_OH-1 + H+1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	NaClO4	lgK:-6.1(0.05SD)	5	MCL	5398
2	25	0.1	NaClO4	dH:9.4(0.05SD)	5	MCL	5398


Reaction No. 54695							
Rh+3_Cl-1 + Cl-1 = Rh+3_Cl-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	HClO4	lgK:1.8(0.2SD)	3	MSP	5460
2	25	1	HClO4	lgK:2.1(0.05SD)	5	MPL	821
3	120	6	HClO4	lgK:3.(1SF)	3	MSP	140

Reaction No. 54696							
Rh+3 + 3<Cl-1> = Rh+3_Cl-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	20	0.1	HClO4	lgK:5.3(0.2SD)	3	MSP	5460
2	25	1	HClO4	lgK:5.97(0.05SD)	5	MPL	820
3	90	4	HClO4	lgK:6.2(0.05SD)	5	MSP	819

Reaction No. 54751							
Rh+3_Cl-1 + 2<Cl-1> = Rh+3_Cl-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:2.6(2SF)	1	ELC	
2	25	0.1	HClO4	lgK:4.3(0.05SD)	0	MIS	5022
3	40	0.1	HClO4	lgK:4.1(0.05SD)	0	MIS	5022
4	55	0.1	HClO4	lgK:4.1(0.05SD)	0	MIS	5022
5	70	0.1	HClO4	lgK:3.8(0.05SD)	0	MIS	5022


6	85	0.1	HClO4	lgK:3.7 (0.05SD)	0	MIS	5022
7	25:85	0.1	HClO4	dH:-4.8 (0.1SD)	0	MIS	5022

Reaction No. 57466




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.1	ClO4-1 salt	lgK:3.4 (0.03SD)	6	MIS	5257

Reaction No. 57761




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:77.2 (3SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-112. (1.SD)	0	ENS	869

Reaction No. 57762




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:48.49 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:48.11 (4SF)	4	ENS	6422
3	127	0	Inf. Dilution	lgK:32.65 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:23.41 (4SF)	4	ENS	6422
5	327	0	Inf. Dilution	lgK:17.27 (4SF)	4	ENS	6422
6	25	0	Inf. Dilution	dG:-65. (1.SD)	3	ENS	869
7	25	0	Inf. Dilution	dG:-66.15 (4SF)	4	EFE	6422
8	25	0	Inf. Dilution	dH:-85.0 (3SF)	4	MTD	6422
9	127	0	Inf. Dilution	dH:-84.73 (4SF)	4	MTD	6422
10	227	0	Inf. Dilution	dH:-84.41 (4SF)	4	MTD	6422
11	327	0	Inf. Dilution	dH:-84.03 (4SF)	4	MTD	6422

Reaction No. 57763



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:0.9 (1SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-6. (1.SD)	0	ENS	869

Reaction No. 57764




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:106.4 (4SF)	1	ELC	
2	25	0	Inf. Dilution	dG:-154. (1.SD)	0	ENS	869

Reaction No. 57765



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-126. (1.SD)	3	ENS	869

Reaction No. 57788




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-15.0 (0.1SD)	5	ENS	5551

Reaction No. 57789




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-20.0 (0.1SD)	5	ENS	5551

Reaction No. 57790




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-18.0 (0.1SD)	5	ENS	5551

Reaction No. 57791




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-15.0 (0.1SD)	5	ENS	5551

Reaction No. 57808



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	4	NaClO4	lgK:1. (0.05SD)	5	MKN	5398

Reaction No. 57818



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:5.2 (2SF)	1	ELC	

2	25	1	H(ClO4)	lgK:4.38(0.05SD)	0	MPL	820
3	90	4	H(ClO4)	lgK:4.4(0.05SD)	0	MSP	819

Reaction No. 57819							
Rh+3 + 5<Cl-1> = Rh+3_Cl-1(5)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:7.5(2SF)	1	ELC	
2	25	1	H(ClO4)	lgK:8.79(0.05SD)	0	MPL	820
3	90	4	H(ClO4)	lgK:8.1(0.1SD)	0	MSP	819

Reaction No. 57820							
Rh+3 + 6<Cl-1> = Rh+3_Cl-1(6)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:6.8(2SF)	1	ELC	
2	25	1	HClO4	lgK:8.43(3SF)	0	MPL	140
3	90	4	H(ClO4)	lgK:7.8(0.1SD)	0	MSP	819

Reaction No. 57828							
Rh+3_Cl-1(5) + Br-1 = Rh+3_Br-1_Cl-1(5)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	4	NaClO4	lgK:0.10(0.02SD)	5	MKN	5398

Reaction No. 57852							
Rh+3_Cl-1(5) + I-1 = Rh+3_Cl-1(5)_I-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	35	4	NaClO4	lgK:0.5(0.04SD)	5	MKN	5398

Reaction No. 58778							
Br-1 + Rh+3 = Rh+3_Br-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:14.3(3SF)	3	MPL	140

Reaction No. 58779							
2<Br-1> + Rh+3 = Rh+3_Br-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:16.3(3SF)	3	MPL	140

Reaction No. 58780							
--------------------	--	--	--	--	--	--	--

3<Br-1> + Rh+3 = Rh+3_Br-1(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:17.6(3SF)	3	MPL	140

Reaction No. 58781							
4<Br-1> + Rh+3 = Rh+3_Br-1(4)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:18.4(3SF)	3	MPL	140

Reaction No. 58782							
5<Br-1> + Rh+3 = Rh+3_Br-1(5)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25			lgK:17.2(3SF)	3	MPL	140

Reaction No. 59291							
Cys-2 + Rh+3 = Rh+3_Cys-2							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:8.60(3SF)	4	MGL	905
2	35	0	Inf. Dilution	lgK:8.25(3SF)	4	MGL	905
3	45	0	Inf. Dilution	lgK:7.90(3SF)	4	MGL	905
4	25	0	Inf. Dilution	dH:-14.7(3SF)	4	MCL	905

Reaction No. 59292							
2<Cys-2> + Rh+3 = Rh+3_Cys-2(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.95(4SF)	4	MGL	905
2	35	0	Inf. Dilution	lgK:11.45(4SF)	4	MGL	905
3	45	0	Inf. Dilution	lgK:11.00(4SF)	4	MGL	905
4	25	0	Inf. Dilution	dH:-19.0(3SF)	4	MCL	905

Reaction No. 59293							
3<Cys-2> + Rh+3 = Rh+3_Cys-2(3)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:14.20(4SF)	4	MGL	905
2	35	0	Inf. Dilution	lgK:13.60(4SF)	4	MGL	905
3	45	0	Inf. Dilution	lgK:13.05(4SF)	4	MGL	905
4	25	0	Inf. Dilution	dH:-23.18(4SF)	4	MCL	905

Reaction No. 59567							
Asn-1 + Rh+3 = Rh+3_Asn-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.02	Unknown	lgK:6.86(3SF)	3	MGL	905

Reaction No. 59568							
2<Asn-1> + Rh+3 = Rh+3_Asn-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0.02	Unknown	lgK:9.73(3SF)	3	MGL	905

Reaction No. 59995							
Ala-1 + Rh+3 = Rh+3_Ala-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	27			lgK:7.19(3SF)	0	MGL	2392

Reaction No. 59996							
2<Ala-1> + Rh+3 = Rh+3_Ala-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	27			lgK:10.28(4SF)	0	MGL	2392

Reaction No. 60003							
Val-1 + Rh+3 = Rh+3_Val-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	27			lgK:7.14(3SF)	3	MGL	2392


Reaction No. 60004							
2<Val-1> + Rh+3 = Rh+3_Val-1(2)							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	27			lgK:9.80(3SF)	3	MGL	2392

Reaction No. 60022							
Leu-1 + Rh+3 = Rh+3_Leu-1							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	27			lgK:7.13(3SF)	0	MGL	2392

Reaction No. 60023							
2<Leu-1> + Rh+3 = Rh+3_Leu-1(2)							


No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	27			lgK:10.10 (4SF)	0	MGL	2392

Reaction No. 60028




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	28			lgK:7.16 (3SF)	0	MGL	2392

Reaction No. 60029




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	28			lgK:9.92 (3SF)	0	MGL	2392

Reaction No. 60078




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	27			lgK:6.63 (3SF)	3	MGL	2392

Reaction No. 60079




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	27			lgK:9.92 (3SF)	3	MGL	2392

Reaction No. 60500



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:11.8 (3SF)	1	EOR	
2	25	2.5	Unknown	lgK:10.67 (4SF)	5	CRV	2556
3	20:60	2.5	Unknown	dH:-9. (1SF)	5	CRV	2556

Reaction No. 67223



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:39.91 (4SF)	4	ENS	6422
2	27	0	Inf. Dilution	lgK:39.59 (4SF)	0	ENS	6422
3	127	0	Inf. Dilution	lgK:26.61 (4SF)	4	ENS	6422
4	227	0	Inf. Dilution	lgK:18.88 (4SF)	3	ENS	6422

5	327	0	Inf. Dilution	lgK:13.79(4SF)	0	ENS	6422
6	25	0	Inf. Dilution	dG:-54.45(4SF)	4	EFE	6422
7	25	0	Inf. Dilution	dH:-299.2(4SF) kJ	3	CRV	6330
8	25	0	Inf. Dilution	dH:-71.51(4SF)	4	MTD	6422
9	27	0	Inf. Dilution	dH:-71.50(4SF)	4	MTD	6422
10	127	0	Inf. Dilution	dH:-70.99(4SF)	4	MTD	6422
11	227	0	Inf. Dilution	dH:-70.31(4SF)	3	MTD	6422
12	327	0	Inf. Dilution	dH:-69.55(4SF)	0	MTD	6422

Reaction No. 71026							
$\text{Rh+3_OH-1} + \text{H+1} + 3\text{<e-1>} = \text{Rh(s)} + \text{H2O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:40.6(3SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.83(2SF)	0	CRV	6330

Reaction No. 72277							
$\text{Rh+3_OH-1(3)_(s)} + 3\text{<H+1>} = \text{Rh+3} + 3\text{<H2O>}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:9.0(2SF)	1	ELC	
2	25	0	Inf. Dilution	lgK:9.0(2SF)	0	CRV	6478
Note (2): < 9.0							


Reaction No. 73347							
$\text{Rh+3_EtDiAm(3)} + \text{SO4-2} = \text{Rh+3_EtDiAm(3)_SO4-2}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO4	lgK:1.4(0.2SD)	5	MSL	6556
2	25	3	NaClO4	dH:-1.8(0.2SD)	5	MCL	6556

Reaction No. 73348							
$\text{Rh+3_EtDiAm(3)_SO4-2} + \text{SO4-2} = \text{Rh+3_EtDiAm(3)_SO4-2(2)}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	3	NaClO4	lgK:1.3(0.3SD)	5	MSL	6556
2	25	3	NaClO4	dH:-1.0(0.3SD)	5	MCL	6556

Reaction No. 74293							
$2\text{<RhO2(s)>} + 2\text{<e-1>} + 2\text{<H+1>} = \text{Rh2O3(s)} + \text{H2O}$							
No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #


1	25	0	Inf. Dilution	lgK:68.0 (3SF)	1	ELC	
2	25	0	Inf. Dilution	E:1.73 (3SF)	0	CRV	22551

Reaction No. 74294




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:76.3 (3SF)	1	ELC	
2	25	0	Inf. Dilution	E:0.88 (2SF)	0	CRV	22551

Reaction No. 74295




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	E:0.9 (1SF)	4	CRV	22551

Reaction No. 78228




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	lgK:46.68 (4SF)	1	ELC	

Reaction No. 80084




No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-127.360 (6SF) kJ	3	ETR	30061

Reaction No. 80085



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-548.03 (5SF) kJ	3	ETR	30061

Reaction No. 80086



No	t	I-Str	Medium	Value (Dev)	W	Tech.	Ref. #
1	25	0	Inf. Dilution	dG:-403.84 (5SF) kJ	3	ETR	30061

Data Assessment

Weight	Assessment
9	highest accuracy
8	multi-determined; excellent dependability
7	trustworthy; outstanding single determination
6	better than average reliability
5	average single determination
4	some doubt
3	poorly known
2	guess to achieve consistency (or just as bad)
1	no information but consistent
0	problematic/inconsistent

Techniques

Abbrev	Method
CRV	Critical review
EFE	Free Energy relations
ELC	Linear Combination of Reactions
ENS	Not specified
EOR	Other Reaction Constants
ETR	Thermodynamic relationships
EVH	Van't Hoff Equation ($dH = \text{constant}$)
MAN	Chemical analysis
MCL	Calorimetry
MCV	Cyclic voltammetry
MDG	Combination of Thermodynamic Data
MEF	Electromotoric force, not specified
MEP	Electrophoresis
MGL	Glass electrode
MIS	Ion selective electrode
MKN	Rate of reaction
MPL	Polarography
MRX	Emf with redox electrode
MSL	Solubility

MSP	Spectroscopy
MTD	Temperature difference

References

Reference No.: 140(64SiM)

Stability Constants of Metal-ion Complexes SP17, 1964 Sillen LG; Martell AE; The Chemical Soc., London

Reference No.: 600(52Lat)

The Oxidation States of the Elements, 2nd Edn, 1952 Latimer WM; and their Potentials in Aqueous Solutions; Prentice-Hall Inc., New York, USA

Reference No.: 802(90Wea)

CRC Handbook of Chemistry and Physics, 70th Edn., 1990 Weast RC; A Ready-Reference Book of Chemical and Physical Data; CRC Press, Cleveland, Ohio

Reference No.: 810(56Jor)

Acta Chem. Scand., 1956, 10, 500 - 517; Jorgensen CK; Complexes of the 4d- and 5d-Groups. I. Crystal Field Spectra of Rhodium(III) and Iridium(III)

Reference No.: 812(38GrA)

Z. Elektrochem., 1938, 44, 296 - 299; Grube G; Autenrieth H; The Electrochemical Behaviour of Rhodium. V. Higher Oxidation States of Rhodium

Reference No.: 813(37GrG)

Z. Elektrochem., 1937, 43, 397 - 403; Grube G; Gu B; The Electrochemical Behaviour of Rhodium. II. The Higher Oxidation States of Rhodium

Reference No.: 814(47DMN)

J. Proc. R. Soc. N.S.W., 1947, 81, 216 - 220; Dwyer FP; McKenzie HA; Nyholm RS; The Chemistry of Bivalent and Trivalent Iridium. IV. The Oxidation-reduction Potential of the Bromiridate - Bromiridite System

Reference No.: 815(66SwH)

J. Am. Chem. Soc., 1966, 88, 4411 - 4414; Swaminathan K; Harris GM; Kinetics and Mechanism of the Reaction of Chloride Ion with Hexaaquorhodium(III) Ion in Acidic Aqueous Solution

Reference No.: 817(59FoA)

J. Phys. Chem., 1959, 63, 1979 - 1981; Forrester JS; Ayres GH; Rhodium(III) in Aqueous Solutions

Reference No.: 818(65BeP)

Zh. Obshch. Khim., 1965, 35, 1887 - 1891; Belyaev AV; Ptitsyn BV; Effect of Bivalent Mercury on the Hydrolysis of K₃RhCl₆

Reference No.: 819(69SEO)

Izv. Akad. Nauk SSSR, Ser. Khim., 1969, 18, 1643(E:1525) - 1646; Shlenskaya VI; Efremenko OA; Oleinikova SV; Alimarin IP; Rhodium(III) Chloride Complexes in Aqueous Solutions

Reference No.: 820(74MMK)

J. Inorg. Nucl. Chem., 1974, 36, 115 - 120; Mihailov MH; Mihailov VT; Khalkin VA; A Correlation Between the Overall Stability Constants of Metal Complexes - II. Application to Data Obtained by the Polarographic Method for Metal-Inorganic Ligand Systems

Reference No.: 821(58CoP)

J. Inorg. Nucl. Chem., 1958, 8, 385 Cozzi D; Pantani F; The Polarographic Behaviour of Rhodium(III) Chlorocomplexes

Reference No.: 822(69RSK)

Inorg. Chim. Acta, 1969, 3, 383 - 387; Robb W; Steyn MMdeV; Kruger H; Kinetics and Mechanism of the Anation by Chloride, Bromide, Iodide, Nitrite, Azide and Thiocyanate of the Aquapentachlororhodate(III) Ion

Reference No.: 823(65RoH)

J. Am. Chem. Soc., 1965, 87, 4472 - 4476; Robb W; Harris GM; Some Exchange and Substitution Reactions of Hexachlororhodium(III) and Pentachloroaquorhodium(III) Ions in Aqueous Acid Solutions

Reference No.: 824(67RoS)

Inorg. Chem., 1967, 6, 616 - 619; Robb W; Steyn MMdeV; Kinetics of Aquation of Aquopentachlororhodium(III) and Chloride Anation of Diaquotetrachlororhodium(iii) Anions

Reference No.: 869(68GoH)

Chem. Rev., 1968, 68, 229 - 252; Goldberg RN; Hepler LG; Thermochemistry and Oxidation Potentials of the Platinum Group Metals and their Compounds

Reference No.: 899(90Mur)

Estimation of Constants for JESS Database, 1990 Murray K; Record of ad hoc estimations

Reference No.: 905(95Ber)

Pure Appl. Chem., 1995, 67, 1117 - 143; Berthon G; Critical Review of Formation Constants of Selected Amino Acids with Polar Side Chains

Reference No.: 906(79Per)

IUPAC Chemical Data Series No. 22, 1979 Perrin DD; Stability Constants of Metal-Ion Complexes, First Edition Part B, Organic Ligands; Pergamon, Oxford

Reference No.: 931(71SiM)

Stability Constants of Metal-ion Complexes SP25, 1971 Sillen LG; Martell AE; Supplement No 1 to Special Publication No 25; Chemical Society, London

Reference No.: 1555(91KSG)

Pure Appl. Chem., 1991, 63, 597 - 638; Kiss T; Sovago I; Gergely A; Critical Survey of Stability Constants of Complexes of Glycine

Reference No.: 2392(93SKG)

Pure Appl. Chem., 1993, 65, 1029 - 1080; Sovago I; Kiss T; Gergely A; Critical Survey of the Stability Constants of Complexes of Aliphatic Amino Acids

Reference No.: 2556(93MSM)

NIST Critical Stability Constants of Metal Complexes Database, 1993 Martell AE; Smith RM; Motekaitis RJ; Version 1.0; National Institute of Standards and Technology, Gaithersburg, USA

Reference No.: 4040(79DTR)

J. Am. Chem. Soc., 1979, 101, 2897 - 2903; Drago RS; Tanner SP; Richman RM; Long JR;

Quantitative Studies of Chemical Reactivity of Tetra-mu-butyrate-dirhodium(II) Complexes

Reference No.: 4090(83HoS)

Acta Chem. Scand., 1983, A37, 647 - 657; Howland K; Skibsted LH; Aqueous Solution Photochemistry of cis-and trans-Diaquabis(ethylenediamine)rhodium(III) Ions and Their Conjugated Bases. Photoisomerization and Photostationary States and Their Correlation with Spectroscopic Properties

Reference No.: 4998(86BaM)

The Hydrolysis of Cations, 1986 Baes CF Jr; Mesmer RE; Robert E. Krieger Publ. Co. Malabar, Florida

Reference No.: 5021(60Col)

Gazz. Chim. Ital., 1960, 90, 1037 Cola M

Reference No.: 5022(66BeP)

Russ. J. Inorg. Chem., 1966, 11, 836 Belyaev AV; Ptitsyn BV; The "Aging" of Rhodium Chloride Solutions

Reference No.: 5257(75LaM)

J. Inorg. Nucl. Chem., 1975, 37, 1832 - 1833; Lalor GC; Miller H; Equilibrium of Silver Ions with Free and Coordinated Thiocyanate

Reference No.: 5398(82Hog)

IUPAC Chemical Data Series No. 21, 1982 Hogfeldt E; Stability Constants of Metal-ion Complexes, 2nd Suppl., Part A, Inorganic Ligands; Pergamon, Oxford

Reference No.: 5460(82BeV)

Sov. J. Coord. Chem. (Engl. Transl.), 1982, 8, 443 - 450; Belyaev AV; Venediktov AB; Equilibrium Chloroaquo Complex Compounds of Rhodium(III) and their Reactivity

Reference No.: 5461(70ARB)

C. R. Acad. Sci., 1970, 271, 661 - 664; Amosse J; Rubaud M; Barbier MJ; Kinetics of Rhodium(III)-Rhodium and Rhodium(II)-Rhodium Systems in Aqueous Media studied by the Galvanostatic Double Pulse Method

Reference No.: 5551(74Pou)

Atlas of Electrochemical Equilibria in Aqueous Solutions, 1974 Pourbaix M; Cebelcor, Brussels

Reference No.: 6330(95LiF)

CRC Handbook of Chemistry and Physics, 76th Edn., 1995 Lide DR; Frederikse HPR; A Ready-Reference Book of Chemical and Physical Data; CRC Press, Cleveland, Ohio, U.S.A.

Reference No.: 6422(95BaP)

Thermochemical Data of Pure Substances, 3rd Edn., 1995 Barin I; Platzki G; Weinheim, Germany

Reference No.: 6478(81BaM)

Am. J. Sci., 1981, 281, 935 - 962; Baes CF Jr; Mesmer RE; The Thermodynamics of Cation Hydrolysis

Reference No.: 6556(72MRU)

Russ. J. Phys. Chem., 1972, 46, 155 - 156; Mironov VE; Ragulin GK; Umova IE; Solov'ev YuB; Mikhailova VP; Dong FT; Thermodynamics of Outer-sphere Complexes. VII. Trisethylenediaminecobalt(III), Trisethylenediaminechromium(III) Sulphate Complexes

Reference No.: 7421(97Mar)

Ion Properties, 1997 Marcus Y; Marcel Dekker Inc., New York, U.S.A.

Reference No.: 9029(97SSW)

Geochim. Cosmochim. Acta, 1997, 61, 907 - 950; Shock EL; Sassani DC; Willis M; Sverjensky DA; Inorganic Species in Geologic Fluids: Correlations among Standard Molal Thermodynamic Properties of Aqueous Ions and Hydroxide Complexes

Reference No.: 22551(06Inz)

Encyclopedia of Electrochemistry, Vol. 7a, 2006, 17 - 75; Inzelt G; Standard, Formal and Other Characteristic Potentials of Selected Electrode Reactions

Reference No.: 30061(14JaG)

J. Chem. Thermodyn., 2014, 70, 39 - 45; Jacob KT; Gupta PC; Gibbs Free Energy of Formation of Rhodium Sulfides